

User Guide

This is a 「User Guide」 installed on the TV.


The contents of this guide are subject to change without prior notice for quality improvement.

❏ To view program information

Wheel(OK) ⇒ Info.

Displays information about the current program and/or current time, etc.

✎ Image shown may differ from your TV.



❑ To set favorite channels

HOME ⇒ Settings → CHANNEL → Channel Edit

- 1 Move to the desired channel on Wheel(OK) button. Channel is selected.
- 2 Press Set as Favorite.
- 3 Select the desired favorite channel group.
- 4 Select Enter. Favorite is set.

❑ To use Favorite

HOME ⇒ Ch. List

Channel list will appear. Select the desired preset favorite channel from Favorite List A to D.

❏ To set Auto Tuning

HOME ⇒ Settings → CHANNEL → Auto Tuning

Automatically tunes the channels.

- ✎ Channels are not registered properly unless the antenna/cable is connected correctly.
- ✎ Auto Tuning only sets channels that are currently broadcasting.
- ✎ If Lock System is turned on, a pop-up window will appear asking for password.

❑ To set channels manually

HOME ⇒ Settings → CHANNEL → Manual Tuning

Adjusts channels manually and saves the results.

For digital broadcasting, signal strength, etc. can be checked.

❏ To edit channels

HOME ⇒ Settings → CHANNEL → Channel Edit

Edits the saved channels.

Set as favorite, block/unblock and skip etc. the selected channel.

HOME ⇒ Settings → PICTURE → Aspect Ratio

Selects the screen aspect ratio.

16:9	Resizes the image ratio to fit a 16:9 screen.
Just Scan	Displays high-quality image without loss.  In DTV/HDMI/Component (over 720p) mode, Just Scan is available.
Set by Program	Depending on the input signal, screen aspect ratio changes to 4:3 or 16:9.
4:3	Resizes the image ratio to fit 4:3 screen.
Zoom	Resizes the image to fit the screen width. The top and bottom parts of the image may be cut off.
Cinema Zoom	Formats an image to the cinemascope ratio (2.35:1) and zooms in on the ratio.

- ✎ While viewing an external device, these cases may result in image burn:
 - a video with stationary caption (such as network name)
 - 4 : 3 aspect ratio mode for an extended period

Take caution when using these functions.

- ✎ Available picture size may differ depending on the input signal.
- ✎ The screen aspect ratios on HDMI/RGB-PC input are available in 4:3 and 16:9 only.
- ✎ [For models supporting 2160p] When a 2160p signal is input or your PC resolution is set to 3840 x 2160, the **Aspect Ratio** is fixed to **Just Scan**.

❑ To adjust pictures in PC input mode

HOME ⇒ Settings → PICTURE → Screen (RGB-PC)

Adjusts picture in RGB-PC mode.

Resolution	Sets the desired resolution. ✎ Resolution may only be selected when the PC resolution is set to 1024x768, 1280x768 or 1360x768.
Auto Configuration	Optimizes picture.
Position/Size/Phase	If screen size or location is distorted, user can directly adjust the screen size and position.
Reset	Resets all the changes on picture settings on PC input mode.

❏ To set PC resolution

- 1 Right-click on the desktop of PC and select 「Properties」.
 - 2 Click on 「Settings」 and refer to supported formats to set the resolution.
 - 3 Select 「Advanced → Monitor → Monitor Settings」 on the setting window.
Refer to supported formats to select the optimal vertical frequency.
- ✎ On PC mode, 1920x1080 resolution delivers the optimum picture quality.
 - ✎ Resolution settings differ depending on the type of PC.

□ Formats Supported

PC Input Mode	Resolution	Horizontal Frequency (KHz)	Vertical Frequency (Hz)
HDMI-PC / RGB-PC	640x350	31.468	70.09
	720x400	31.469	70.08
	640x480	31.469	59.94
	800x600	37.879	60.31
	1024x768	48.363	60.00
	1152x864	54.348	60.053
	1360x768	47.712	60.015
	1920x1080	67.5	60.00
HDMI-PC	1280x1024	63.981	60.020

HOME ⇒ Quick Menu → AV Mode

Views the TV with the best picture / audio optimized for different AV modes.

Off	Views with the value set at the picture / sound menu.
Cinema / <u>THX</u> Cinema	Optimizes picture and audio settings for movies.
Game	Optimizes picture and audio settings for games.

 THX [Depending on model]

THX (Thomlinson Holman's Experiment) is an audio and video certification standard established by George Lucas and Thomlinson. A THX certified display guarantees screen quality that exceeds the display standard specification in both hardware and software.

❑ To adjust pictures with Picture Wizard

HOME ⇒ Settings → PICTURE → Picture Wizard II

Use the remote control and follow the instructions of the Picture Wizard to calibrate and adjust for the optimum picture quality without expensive pattern devices or help from a specialist.

Follow the instructions to obtain the optimum picture quality.

❑ To select Picture Mode

HOME ⇒ Settings → PICTURE → Picture Mode

Selects the picture mode optimized for the viewing environment or the program.

Intelligent Sensor	Detects the ambient illumination and automatically adjusts TV's brightness level to reduce power consumption. Automatically adjusts the brightness, sharpness, color or tint for optimum picture quality.
Vivid	Heightens contrast, brightness, and sharpness to display vivid images.
Standard	Displays images in standard levels of contrast, brightness, and sharpness.

Cinema/ THX Cinema Game	Displays images that have been optimized for movies or games. [THX Cinema : Depending on model]
 Expert	Menu for adjusting picture quality that allows experts and amateurs to enjoy the best TV viewing. This menu is ISF-certified and provided for picture tuning experts. (ISF logo can only be used on ISF-certified TV units.) ISFccc: Imaging Science Foundation Certified Calibration Control

- ✎ Depending on the input signal, available range of picture modes may differ.
- ✎  **Expert** mode is for picture tuning professionals to control and fine-tune using a specific image. For normal images, the effects may not be drastic.

❑ To fine-tune picture mode

HOME ⇒ Settings → PICTURE → Picture Mode → Backlight/Contrast/Brightness/Sharpness/Color/Tint/Color Temp.

Selects the desired Picture Mode first.

Backlight	Adjusts the display brightness by varying the brightness of the LCD panel.
Contrast	Adjusts the difference between bright and dark regions of the screen.
Brightness	Adjusts the overall screen brightness.
Sharpness	Adjusts the sharpness of the borders between bright and dark.
Color	Adjusts the color that appears on the screen darker or lighter.

Tint	Adjusts the red/green color balance.
Color Temp.	Adjusts the overall tone of colors to hot or cool.

- ✎ Depending on the input signal or other picture settings, the range of detailed items for adjustment may differ.

❑ To set advanced control

HOME ⇒ Settings → PICTURE → Picture Mode → Advanced control/
Expert Control

For each picture mode, screen can be calibrated; or for a special screen, picture settings can be adjusted.

Selects the desired Picture Mode first.

Dynamic Contrast	Adjusts the contrast to the optimal level according to the image's brightness.
Dynamic Color	Adjusts colors to make the image appear in more natural colors.
Clear White	Enhances whites on screen to make the image brighter and sharper.

Preferred Color	Skin Color : Skin color spectrum can be separately set to implement the skin color defined by the user.
	Grass Color : Natural color spectrum (meadows, hills, etc.) can be separately set.
	Sky Color : Sky color is set separately.
Super Resolution	Provides a crystal-clear picture by improving the details in an area that has a blurry or unclear picture.
Gamma	Sets the gradation curve according to the output of picture signal in relation to the input signal.
Color Gamut	Selects the range of colors that can be expressed.
Edge Enhancer	Shows clearer and distinctive yet natural edges of the video.
xvYCC	[Depending on model] Expresses richer colors.

Color Filter	Filters a specific color spectrum in RGB colors to fine-tune color saturation and hue accurately.
Expert Pattern	Patterns used for expert adjustment.
White Balance	Adjusts the overall tone of the screen as desired. In Expert mode, detailed fine-tuning can be set via Method / Pattern and the like.
Color Management System	This is a function used by experts when they adjust colors with test pattern of six colors (Red/Green/Blue/Cyan/Magenta/Yellow) without affecting other color areas. For normal images, adjustments may not result in noticeable color change.

 Depending on input signal, or other picture settings, the range of detailed items for adjustment may differ.

❑ To set additional picture options

HOME ⇒ Settings → PICTURE → Picture Mode → Picture Option

Adjusts detailed setting for images

Noise Reduction	Reduces screen noise in the video.
MPEG Noise Reduction	Reduces noise caused by compressing digital video.
Black Level	Adjusts the brightness or darkness of the screen to fit the black level of the picture input using the screen's degree of darkness (black level).
Real Cinema	Optimizes the screen for movie viewing.
Eye Care/ Motion Eye Care	Adjusts screen brightness to prevent eye glare. [Motion Eye Care : Depending on model]

❏ To reset Picture Mode

HOME ⇒ Settings → PICTURE → Picture Mode → Picture Reset

Resets the values customized by the user.

Each picture mode is reset. Select the desired picture mode.

HOME ⇒ Settings → PICTURE → Picture Mode → Picture Option → TruMotion

Corrects images to display smoother motion sequences.

Smooth	De-Judder value is set at 3.
Clear	De-Judder value is set at 7.
User	De-Judder can be set manually. • De-Judder : This function adjusts juddering of the screen.

 If the video signal is 60Hz, TruMotion may not work.

HOME ⇒ Settings → PICTURE → Picture Mode → Picture Option → LED Local Dimming

Brightens bright areas and darkens dark areas of the image for maximum contrast and minimum blur while reducing power consumption.

Off	Turns off LED Local Dimming.
Low	Expresses in natural black tones. Use this setting for viewing movies.
Medium	Deepens black tones than Low. Use this setting for regular TV viewing.
High	Deepens black tones and delivers clearer image than Medium. Perfect for viewing in brightly lit areas.

✎ Setting LED Local Dimming to Medium / High reduces power consumption.

❏ To use Sound Mode

HOME ⇒ Settings → SOUND → Sound Mode

Optimizes TV audio to the selected sound mode.

Standard	Suitable for all types of video
Music/Cinema/Sport/ Game	Sets audio optimized for a specific genre.
Vivid	Delivers distinct voices with rich bass and clear, high-pitched sounds.
User Setting	Adjusts the volume to the desired level using the User EQ.

❑ To fine-tune the volume

HOME ⇒ Settings → SOUND → User EQ

Sets Sound Mode at User Setting first.

100 Hz / 300 Hz / 1 kHz /
3 kHz / 10 kHz

Sets EQ by manually adjusting sound bands.

Reset

Resets previously changed equalizer value.

❑ To set Volume Mode

HOME ⇒ Settings → SOUND → Volume Mode

Sets various modes for volume control.

Auto Volume	Sets Auto Volume to On. Different volume outputs from channel to channel. They are then automatically adjusted for convenient TV watching when, clicking through different channels.
Volume Control	Using a single volume curve may result in an inaudible or loud sound depending on the environment. This function adjusts comfortable volume levels depending on day/night.

❑ To use Sound Optimizer function

HOME ⇒ Settings → SOUND → Sound Optimizer

Allows optimized sound for individual TV installation.

Normal	General sound mode
Wall Mount Type	Optimizes sound for a wall-mounted TV.
Stand Type	Optimizes sound for a stand-mounted TV.

❑ To use Virtual Surround feature

HOME ⇒ Settings → SOUND → Virtual Surround

LG's proprietary audio processing technology allows 5.1ch-like surround sound from two speakers.

✎ When Clear Voice II is set to On, Virtual Surround cannot be selected.

❑ To use Clear Voice II feature

HOME ⇒ Settings → SOUND → Clear Voice II

Boosts voice clarity.

❏ To set AV Sync

HOME ⇒ Settings → SOUND → AV Sync.

Synchronizes unmatched video and audio. Select AV Sync. to On to synchronize audio output (TV speaker or SPDIF) with the video.

TV Speaker	Adjusts the sync of the sound from the TV's internal speakers. The "-" button makes the sound output faster and the "+" button slower than the default value.
SPDIF	(Sony Philips Digital InterFace) Adjusts the sync of the sound from speakers connected to digital audio out terminal. The "-" button makes the sound output faster and the "+" button slower than the default value.

Bypass

Outputs broadcasting signals or the audio of an external device without audio delay. Audio may be output before video as it takes time to process video input into the TV.

❑ To use ARC mode

HOME ⇒ **Settings** → **SOUND** → **Sound Setting** → **ARC Mode**

External audio devices that support Audio Return Channel (ARC) can be connected with High-Speed HDMI® cable without an extra optical audio cable to output SPDIF. It interfaces with SIMPLINK.

For an external device that supports ARC (Audio Return Channel), connect it to the **HDMI(ARC)** port.

Off	Even when the connected ARC-supported external audio device is turned on, audio output is not processed through the external audio device's speakers.
On	When an ARC-supported external audio device is turned on, audio output is automatically processed through the external audio device's speakers. SIMPLINK must be turned on. For SIMPLINK, refer to 「General → To use input device」.

-  Connect to ARC-only terminal when connecting to external devices.
-  Use high-speed HDMI® cable when connecting to external devices.
-  Use of a third-party device with an ARC function may cause malfunctions.

❑ To adjust audio balance

HOME ⇒ Settings → SOUND → Sound Setting → Balance

Adjusts left/right audio balance.

❏ To use TV's speakers

HOME ⇒ Settings → SOUND → Sound Setting → TV Speaker

When listening to the speakers on the external audio devices connected to TV such as home theater, TV speaker may be turned off. When there are SIMPLINK connected home theater devices, selecting TV Speaker to OFF will automatically turn on home theater.

Off

There is no sound from the TV speakers.

Delivers TV sound through external audio device speakers connected to the TV.

🔊 Adjusts the volume with the knob attached to the external device.

On

Produces TV sound through the TV's internal speaker.

❑ To use Digital Sound Out

HOME ⇒ **Settings** → **SOUND** → **Sound Setting** → **Digital Sound Out**

Sets up Digital Sound Out.

Item	Sound Input	Digital Sound output
Auto	MPEG	PCM
	Dolby Digital	Dolby Digital
	Dolby Digital Plus	Dolby Digital
	HE-AAC	Dolby Digital
PCM	All	PCM

❑ To select external input

HOME ⇒ Input List

Selects external input.



Selects speaker.

Selects input.

Sets SIMPLINK.

Edits the name of external device connected to external terminal.

❑ To use SIMPLINK

SIMPLINK allows users to control and manage multiple multimedia devices using the convenient TV remote control and SIMPLINK menu.

- 1 Connect the TV's **HDMI IN** terminal with SIMPLINK device's HDMI output terminal using HDMI cable. For home theater units with SIMPLINK function, connect HDMI terminals as above and use an optical cable to connect Optical Digital Audio Out from the TV to Optical Digital Audio In of the SIMPLINK device.
- 2 Select **HOME** ⇒ **SIMPLINK**. SIMPLINK menu window appears.
- 3 Select **Set SIMPLINK** on SIMPLINK menu window. SIMPLINK setup window appears.
- 4 Set **SIMPLINK** to **On** in SIMPLINK setup window.
- 5 Close SIMPLINK setup window.
- 6 Select the device to control from **HOME** ⇒ **SIMPLINK**.

- ✎ This function works only on devices with the SIMPLINK logo (). Make sure that the external device has a SIMPLINK logo.
- ✎ To use SIMPLINK function, use a high-speed HDMI® cable (with CEC, or Consumer Electronics Control feature added) and No. 13 pin connected for information exchange between devices.
- ✎ Turn on or select the media of a device with home theater features to see the speaker switch to **HT Speaker**.
- ✎ Connect with an Optical cable (sold separately) to use **HT Speaker**.
- ✎ Switching to external input causes devices operating with SIMPLINK to stop.
- ✎ Use of a third-party device with HDMI-CEC features may cause malfunctions.

□ Explanation on SIMPLINK features

Direct Play	Play the multimedia device on the TV instantly without extra steps.
Select multimedia device.	Select the desired device through the SIMPLINK menu and instantly control it from the TV screen.
Disc playback	Manage the multimedia device with the TV remote control.
Power off all devices	Turning the TV off with Auto Power function On in SIMPLINK setting will turn the power off on all SIMPLINK-connected devices.

Sync Power on

If the Auto Power function is set to On in the SIMPLINK settings, turning on a SIMPLINK device will turn the TV on.

Speaker

Selects speaker on the home theater unit or TV.

HOME ⇒ Settings → PICTURE → Energy Saving

Reduces power consumption by adjusting screen brightness.

Auto	TV sensor detects the ambient lighting and automatically adjusts the screen brightness. • Min. Luminance : Select the minimum brightness for the screen under low ambient light. • Sensing Strength : Select the TV's range of brightness in the viewing environment.
Off	Turns off the Energy Saving mode.
Minimum/ Medium/ Maximum	Applies the pre-set Energy Saving mode.
Screen Off	Screen is turned off and only sound is played. Press any button on the remote control to turn the screen back on.

❏ To use Sleep Timer

HOME ⇒ Settings → TIME → Sleep Timer

Turns off the TV after a prescribed number of minutes.

To cancel the Sleep Timer, select Off.

❏ To set current time

HOME ⇒ Settings → TIME → Clock

Checks or changes the time while watching TV.

Auto	Synchronizes the TV clock to the digital time information sent by the TV station.
Manual	Sets the time and date manually if the auto setup does not correspond to the current time.

❑ To set the TV to turn on and off automatically

HOME ⇒ Settings → TIME → On Time/Off Time

Sets On/Off time.

Select Off on Repeat to discontinue On Time/Off Time.

- ✎ To use On Time/Off Time, set the current time correctly.
- ✎ Even when the On Time function is on, the TV will turn off automatically in 120 minutes when no button is pressed within that time.

❏ To set password

HOME ⇒ Settings → LOCK → Set Password

Sets or changes TV password.

✎ The initial password is set as 「0000」.

❑ To lock system

HOME ⇒ Settings → LOCK → Lock System

Permits only specific programs by blocking channels or external input.

Select the Lock System to On.

Block Channel

Blocks the channels that contain inappropriate contents for children. The channels can be selected but the screen is blank and the audio is muted.

To watch a locked channel, enter the password.

Movie Rating

[Depending on model]

Blocks the movies that are only broadcasted on the TV and contain inappropriate contents, based on the Motion Picture Association of America (MPAA) rating.

- G : (General audiences) All ages admitted
- PG : (Parental guidance suggested) Some material may not be suitable for children
- PG-13 : (Parents strongly cautioned) Some material may be inappropriate for children under 13
- R : (Restricted) Under 17 requires accompanying parent or adult guardian
- NC-17 : No one 17 and under admitted.
- X : Adults only

TV Rating- Children

[Depending on model]

Blocks the children's TV programs that parents do not want their children to watch. To block other TV programs, you should set the TV Rating-General feature.

- Age : TV-Y (All children, including children from ages 2-6), TV-Y7 (Directed to older children, suitable for children age 6 and above)
- Fantasy Violence : TY-Y7 (Directed to older children – Fantasy violence, suitable for children age 6 and above, containing more intense or combative fantasy violence)

TV Rating- General

Blocks the TV programs that you want based on the ratings by using the Parental Control Function (V-Chip).

 The V-Chip electronically reads TV program ratings and allows parents to block program that are unsuitable for children.

- Age : TV-G (General audience, suitable for all ages)
TV-PG (Parental guidance suggested, containing material that are unsuitable for younger children)
TV-14 (Parents strongly cautioned, containing material that are unsuitable for children age 14 and under)
TV-MA (Mature audience only, unsuitable for children age under 17)
- Dialog : (suggestive dialogue) TV-PG or TV-14
- Language : (coarse language)TV-PG, TV-14, or TV-MA
- Sex : (sexual situation) TV-PG, TV-14, or TV-MA
- Violence : TV-PG, TV-14, or TV-MA

Downloadable
Rating

[In Digital mode Only]

This function operates only when TV has received Region5 Rating data. The name of the rating option may differ.

Input Block

Block the input sources.

❏ To set password

HOME ⇒ Settings → LOCK → Set Password

Sets or changes TV password.

✎ The initial password is set as 「0000」.

❑ To lock system

HOME ⇒ Settings → LOCK → Lock System

Permits only specific programs by blocking channels or external input.

Select the Lock System to On.

Block Channel

Blocks the channels that contain inappropriate contents for children. The channels can be selected but the screen is blank and the audio is muted.

To watch a locked channel, enter the password.

TV Rating- English

[Depending on model]

Selecting Canadian English rating system.

- E : Exempt
- C : Children
- C8+ : Children eight years and older
- G : General programming, suitable for all audiences
- PG : Parental Guidance
- 14+ : Viewers 14 years and older
- 18+ : Adult programming
- Blocking Off : Permits all programs

TV Rating- French

[Depending on model]

Selecting Canadian French rating system.

- E : Exempt
- G : General
- 8ans+ : General-Not convenient for little children
- 13ans+ : Not convenient for children of 13 years and younger
- 16ans+ : Not convenient for children of 16 years and younger
- 18ans+ : This programs is only for adults
- Blocking Off : Permits all programs

Downloadable
Rating

[In Digital mode Only]

This function operates only when TV has received Region5 Rating data. The name of the rating option may differ.

Input Block

Block the input sources.

HOME ⇒ Settings → OPTION → Language

Selects Menu Language and Audio Language displayed on the screen.

Menu Language	Selects a screen menu language.
Audio Language	[In Digital Mode Only] Selects the desired language when watching digital broadcasting containing several audio languages.
Voice Search Language	Select the language to make voice search.  Only the voice search adopted model can support this setting.

HOME ⇒ Settings → OPTION → Caption

View subtitles when the TV station provides subtitled programming. Program subtitles work only on digital/analog broadcasts or external input.

Change **Caption** to **On** and select caption setting.

Mode	CC 1-4 (Closed Captioning) / Text 1-4 Text 1-4 Displays the audio portion of a TV program as text on the TV screen. CC1 is the most common mode in use. Field 1 data channels: two Captions (CC1, CC2), two Text (T1, T2). Field 2 data channels: two Captions (CC3, CC4), two Text (T3, T4). Service 1-6 This is only available for the digital broadcasting system.
------	--

Digital
Option

Set up the size and color of the subtitles on **Digital Option**. Please select **Set by Program** or **Custom**.

Select **Custom** to adjust minute options such as the subtitles' size and color.

❑ To register the Magic Remote Control

To use the Magic Remote Control, register it with your TV first.

Register Magic Remote Control as follows:

- 1 Turn on the TV and wait for about 10 seconds and then press **Wheel(OK)** button while pointing the remote control at the TV.
 - 2 The remote control is automatically registered and a registration completion message appears on the TV screen.
- ✎ If you failed to register the Magic Remote Control, turn off the TV and try again.

❏ To re-register the Magic Remote Control

- 1 Press the **HOME** and **BACK** buttons at the same time for about 5 seconds.
 - 2 Point the remote control at the TV and press **Wheel(OK)** button for about 5 seconds.
- ✎ Press the **BACK** button while pointing the remote control at the TV for five seconds to reset and re-register it.

❑ To set the pointer of the Magic Remote Control

HOME ⇒ Settings → OPTION → Pointer

Sets the speed and shape of the pointer that appears on the TV screen.

Speed	Sets the moving speed of the pointer.
Shape	Chooses from different shapes of the pointer.
Size	Chooses the size of the pointer.
Alignment	Set it to On. If there is any misalignment between the pointer and the actual direction the remote control indicates, move the Magic Remote Control left and right to realign. The pointer will automatically realign to the center, making it easier to control.

- ✎ If the pointer has not been used for a certain period of time, it will disappear. When the pointer disappears from the screen, shake the Magic Remote Control to the right and left. Then, it appears again.
- ✎ If you press the navigation button while moving the pointer on the screen, the pointer disappears, and the Magic remote control works as a regular remote control.
- ✎ Use within an effective distance of 33 ft. (10 meters). Using the Remote Control from greater distances or when obstructions block the sight line may cause malfunctions.

- ✎ Electronic devices nearby may cause communication interference. Devices such as microwave oven and wireless LAN use the same frequency range (2.4 GHz) as the Magic Remote Control, which may interfere with the remote control.
- ✎ The Magic Remote Control may be broken if dropped or damaged in any other way.
- ✎ Do not drop or subject the Magic Remote Control to heavy impacts.

❏ To use the pattern gesture function

Press the **Wheel(OK)** button with the normal video screen on and draw a pattern toward the screen.



Previous channel: Moves back to the previous channel.



Recent list: Shows channels recently watched.

 It may not work when certain windows are open.

❏ To set Power Indicator

HOME ⇒ Settings → OPTION → Standby Light

[Depending on model]

Turns on/off the standby light in the front panel of the TV.

❏ To change TV mode

HOME ⇒ Settings → OPTION → Mode Setting

Selects Home Use or Store Demo.

For use in the home, select Home Use.

Store Demo is for store display.

❏ To return to initial settings

HOME ⇒ **Settings** → **OPTION** → **Initial Setting**

Returns to initial default mode by deleting all user settings.

Once initialization is completed, the TV will turn off and then back on.

- ✎ If **Lock System** is turned on, a pop-up will be prompted to ask for password.
- ✎ Do not turn off the power during initialization.

A wireless or wired network connection is necessary to use Smart features.

Once the network connection is established, Premium Content, LG Smart World, DLNA, and more are available.

❑ Network connection by one-click

It's easy to connect to a wired/wireless network.

Select HOME ⇒ Settings → NETWORK → Network Connection to be automatically connected to an available network. Refer to prompts on the TV.

❑ To connect network through Set Expert

HOME ⇒ Settings → NETWORK → Network Connection

Used in special circumstances such as in offices (in case where static IP is used).

- 1 Select a network connection either through **Wired** or **Wireless**.
- 2 When connecting via Wi-Fi, use the one of the following network connection methods.

AP List	Connects the network by selecting a network from the AP List.
Enter the SSID	Connects by typing in the name of wireless AP.
WPS-PBC	Connects easily by pressing the button of the wireless AP supporting PBC.

WPS-PIN

Connects easily by typing in the PIN on the web site of the desired wireless AP.

Ad-hoc

Connects to the network via a wireless-enabled PC or mobile phone.

❑ To use Wi-Fi Screen function

HOME ⇒ Settings → NETWORK → Wi-Fi Screen Share

Allows use of wireless connection functions such as Wi-Fi Direct and WiDi.
Shares screen of devices connected via Wi-Fi Screen Share in Smart Share.

- 1 Set Wi-Fi Screen Share to On. (If you do not use it, please change it to Off.)
- 2 Enable the Wi-Fi Direct settings on the device that you want to connect to.
- 3 A list of devices that can be connected to the TV is displayed.
- 4 Select a device to connect.
- 5 Select Yes, when the connection request message appears.
- 6 If the device that you want to connect to accepts the request, Wi-Fi Screen Share is connected.

❏ Warning when setting network

- ✎ Use standard LAN cable (connect to Cat5 or higher with RJ45 connector, 10 Base-T, or 100 Base TX LAN port).
- ✎ Resetting modem may cause network connection problems. Turn the power OFF, disconnect and reconnect it, and then turn the power on to solve the problem.
- ✎ LG Electronics is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- ✎ Network connection may not work properly depending on Internet service provider.

- ✎ DSL service must use the DSL modem; and cable service must use the cable modem. Since only a limited number of network connections may be available, TV network setting may not be used depending on the contract with Internet service provider. (If the contract does not allow more than one device per line, only the already-connected PC may be used.)
- ✎ Wireless network can experience interference from other devices with 2.4 GHz frequency (wireless phone, Bluetooth device, or microwave oven). Interference may also be caused by devices with 5 GHz frequency, the same as any other Wi-Fi devices.
- ✎ The surrounding wireless environment can make wireless network service run slowly.
- ✎ Failure to turn off all local home networks may cause excessive traffic on some devices.

- ✎ The access point device must support wireless connection and wireless connection feature must be enabled on the device to have AP connection. Contact the service provider for availability of wireless connection on the access point.
- ✎ Check SSID and security settings of the AP for AP connection. Refer to the appropriate documentation for SSID and security settings of the AP.
- ✎ Invalid settings of network devices (wired/wireless line sharer, hub) can cause TV to operate slowly or not operate properly. Install the devices correctly according to the appropriate manual and set network.
- ✎ Connection may not work depending on the connected device (e.g., laptop) when using Ad-hoc.
- ✎ Connection method may differ depending on the AP manufacturer.

❑ To use Premium

HOME ⇒ Premium

This service delivers a wealth of content such as news, weather, stock data, replay TV programming, and video at any time while connected to a network. For Premium content, specialized country-specific services are offered that take into account regional cultural sensitivities, in addition to globally provided content.



❑ To use paid Content

Some Premium Content is provided as for-free services. To purchase for-free services, use either LG Electronics' proprietary billing system or that of each content provider. With LG's billing system, sign up for membership and register payment information on www.lgappstv.com before paying.

- 1 Click **Sign In** button in upper right corner of Home screen to sign in.
- 2 Move to the desired Premium service.
- 3 After checking the content's pricing and service information, click the Purchase button. (Some Content may be subject to a time limit or restricted number of views.)

- 4 Once the purchasing process is completed, view the paid content by clicking the **Buy** button.
- 5 Select your ID on upper menu of Home screen and check history of purchases from **My Page** → **Payment inquiry**. It is also available on My Page → Purchase History of web site (www.lgappstv.com).

❑ To reset Premium

HOME ⇒ **Settings** → **SUPPORT** → **Initialization of Premium**

Premium list, Premium information, country setting, and user sign-in information will be reset. When an error occurs during Premium update, reset will fix the problem.

- ✎ Content on offer by service providers are subject to change to enhance their service quality or deletion without any prior notice. Refer to the web site of each content provider for questions, troubleshooting, or latest information about Content. LG Electronics does not take any legal responsibility for content services and related information including discontinuation of service by the service provider.
- ✎ The quality of Premium service may be affected by Internet connections. For any questions related to Internet speed or any other service problems, contact the Internet service provider.
- ✎ For best service quality, subscribe to an Internet service of 4.0 Mbps (1.5 Mbps or faster). Contact the ISP (Internet service provider) for any problems related to Internet speed.
- ✎ Content providers may make available content that is unsuitable for minors. Parental discretion advised.

HOME ⇒ Internet (Web browser)

You can type the URL manually on TV or visit web sites in the Favorites list.

Type in Web addresses here.

Add the current page to favorites.

Open a new tab.

Moves to a previously visited website.



- ✎ The **Internet** (Web browser) supports up to Flash 10 but does not support platform-dependent technology like ActiveX.
- ✎ The **Internet** (Web browser) only works with pre-installed plug-ins.
- ✎ The **Internet** (Web browser) only replays the following media file formats:
JPEG / PNG / GIF / WMV (ASF) / WMA / MP3 / MP4
- ✎ The **Internet** (Web browser) is forcibly closed when memory is insufficient.
- ✎ For the **Internet** (Web browser) , fonts installed on the TV are used and may not be displayed normally depending on the content played.
- ✎ The **Internet** (Web browser) does not support file and font download.
- ✎ The **Internet** (Web browser) is made for TV so it may function differently from PC browsers.
- ✎ The **Internet** (Web browser) is a TV browser and may not work properly when playing some content files.

HOME ⇒ Social Center

LG Smart TV provides Social Center app that delivers SNS service such as Facebook or Twitter while watching TV.

With Social Center app, users can communicate with friends and see all messages and photos posted by SNS friends.

- 1 Sign in to LG TV account or if not a member, sign up first.
 - 2 Sign in to the desired service (Facebook or Twitter) or if not a member, create an account first.
 - 3 Check SNS services and post messages while watching TV.
- New messages posted on Facebook or Twitter from Social Center app also appear on account's web page and mobile web.



Toggles Facebook/Twitter.

- ✎ If there is no **Social Center** app on the **My Apps**, install one from LG Smart World.
- ✎ Log on to SNS services using smart phone's LG Magic Remote app to conveniently compose text messages. The apps are available on Google Play Store or Apple App Store.

Sign up is required to use LG Smart World.

Membership to use free apps: Sign up at TV or PC.

Membership to purchase paid apps: Sign up only at PC.

Problem	Solution
When entering menu, the "Initializing" message always appears.	• The "Initializing" message shows you how long it takes to reboot the microprocessor and hardware, set up network communications, and communications with SDP (device authentication and basic information download). It takes about 20 seconds and this is a normal process.
There is no content shown on the Premium card.	• Content may not be shown when changing country setting on Smart TV. Change to desired country in HOME ⇒ Settings → OPTION → Smart TV Setting → Smart TV Country.

Problem	Solution
While using internet features, there is space that does not appear in some web sites.	• The internet of the TV supports up to Flash 10 and may not replay any file format other than the following : JPEG, PNG, GIF, WMV (ASF), WMA, MP3, MP4
Internet closes automatically when visiting website.	• If memory is insufficient because of large volume of image information in the web page, internet may be forced to close.
I already signed up on TV. Do I need to sign up again at web site (www.lgappstv.com)?	• Use ID and password registered with TV to sign in to the website (www.lgappstv.com). Type in personal information after signing in with the same ID and password registered with the TV. After completing the email authentication process, the website (www.lgappstv.com) membership registration is completed.

Problem	Solution
Can each family member use a different ID with a single TV?	• It is possible to register and use more than one ID on one TV. • To check the ID registered with TV from HOME ⇒ Settings → OPTION → Smart TV Setting → ID List. • You can check the list of apps purchased by each ID. However, you can see all apps installed by each ID in My Apps.
What should I do if I forget my ID?	• After signing up on a PC, use “Forgot ID?” feature on web site (www.lgappstv.com) when needed. • After signing up on TV, check it from HOME ⇒ Settings → OPTION → Smart TV Setting → ID List.

Problem	Solution
I purchased an app from website (www.lgappstv.com). How can I use it on TV?	• To check purchased apps on TV, sign in and view on the Purchased Apps menu. Select the ID at the top of Home and check the app in My Page → Purchased Apps.
Can I see history of my purchased apps?	• Select the ID at the top of Home and check the app in My Page → Purchased Apps. • Sign in to website (www.lgappstv.com) and then select My Page → Purchase History.
I deleted a paid app, then do I have to purchase again to download it?	• Once app has been purchased, it may be re-downloaded within one year, even if accidentally erased. You can re-download apps only if they were purchased apps available for service. Select the ID at the top of Home and re-download apps in My Page → Purchased Apps.

Problem	Solution
Can I use apps provided from LG Smart TV's LG Smart World on both TV and PC?	• Please check if the TV model supports LG Smart World. • The apps provided from LG Smart TV's LG Smart World can only be run on LG Smart TV. • Apps may be purchased from the website (www.lgappstv.com) but cannot be used on a PC or Mac. Use care when purchasing.
How can I check the ID currently signed in to TV?	• Select the ID at the top of Home and check the currently signed-in ID in My Page → My Information.
I installed an app on TV. Where can I check the installed app?	• Select HOME ⇒ My Apps. All paid and free apps installed on TV are displayed.

Problem	Solution
There is a difference between the app size shown in the screen and the actual app size installed on TV.	• The app size shown in the screen includes the additional space needed for installing apps so it may be different from actually installed app size.
I forgot password on TV. What should I do?	• If you only have the TV account, you cannot recover your password when it is lost. Create a new ID and log in with the ID. • But, if signed up on both TV and PC, use the “Forgot Password?” feature at website (www.lgappstv.com).

Problem	Solution
Do I need to store payment information in web site to purchase paid apps?	• To purchase paid apps from TV, enter payment method information at the website (www.lgappstv.com) but to not store payment information, use quick payment service. But, quick payment service is only available on the website, and apps may not be purchased from TV unless payment information is stored on the web site.
Can I cancel an app that I have purchased?	• As a member you cannot demand refund just because you changed your mind after purchase. • If there is a defect in the product or a problem of using the product, which does not caused by your fault, you can ask for a refund. However, the valid reason for refund must be provided.

Problem	Solution
I am resistered as a member, but I cannot purchase paid apps.	• Log in with the ID you created on your PC and add your payment information. Then, log out from TV and log in again so you can buy paid apps.

❏ To view 3D images

3D imaging is a technology that utilizes the slight difference in left/right eyes to make the images on TV appear just like real-life 3-dimensional space.

- 1 Play a 3D-image title or tune to a 3D channel.
- 2 Put on 3D glasses.
- 3 Press **3D** button to activate 3D.
- 4 While viewing 3D images, press the **3D** button on the remote control to end 3D image viewing.

✎ Depending on the input signal, available 3D type may differ.

❑ To adjust details of 3D images

HOME ⇒ Settings → PICTURE → 3D Settings

Adjusts various aspects of 3D imaging.

3D Mode

Provides the appropriate 3D depth.

- 3D Depth : Adjust 3D depth between the foreground object(s) and the background.
- 3D Viewpoint : 3D image can be made closer or farther from user.

3D Sound Zooming	Provides 3D-optimized sound.
3D Pattern Recognition	This will activate and deactivate 3D mode automatically based on the input.
Normal Image View	This will down-convert a 3D signal to 2D.
3D Color Correction	Corrects the color of 3D images.  Depending on model, the 3D Color Correction may not be available.
3D Image Correction	Switches the left/right images of 3D video.

❏ Caution when viewing 3D images

- ✎ When viewing 3D images, it is recommended that the viewer maintain a distance of at least twice the screen's diagonal length.
- ✎ 3D images may not be viewed correctly with shutter-type glasses that require recharging.
- ✎ If a future 3D broadcasting format that is not supported by this TV becomes the standard, an additional device such as a set-top box may be required.

❏ Warning when using 3D glasses

- ✎ Do not use the 3D glasses as a replacement for your own corrective glasses, sunglasses, or protective goggles. Improper use of 3D glasses may cause eye injuries.
- ✎ Do not store 3D glasses in extreme conditions. Exposure to excessively high or low temperatures may deform the lenses. Do not use deformed glasses.
- ✎ Do not apply pressure to or subject 3D glasses to any impact. Subjecting 3D glasses to rough handling may cause a defect.
- ✎ The lenses on 3D glasses (with polarizing film) are vulnerable to scratches. Use only a clean and soft cloth for cleaning. Dirty cloth may scratch the polarizing film.
- ✎ Scratching the lens surface of the 3D glasses with sharp objects or cleaning with chemicals may distort 3D images.

❑ What is Dual Play mode?

When playing a 1:1 battle game with a game console, such as Playstation, XBox and Wii, users used to play the game with the screen divided top and bottom or side by side.

With Dual Play mode, each player can enjoy the game with a full screen.

To play in Dual Play mode, the Dual Play glasses (type A and B) are required.

If your model does not include the Dual Play glasses, please purchase them separately.

❑ Resetting Dual Play

HOME ⇒ Settings → OPTION → Dual Play

Select the Screen split mode (Side by Side / Top & Bottom) that the game supports.

If the selected Screen split mode is not supported by the game you want to play, the Dual Play mode is not available.

❑ Starting Dual Play

- 1 Connect your game console to your TV.
 - 2 Select **HOME** ⇒ **My Apps** → **Dual Play**. The Dual Play mode starts.
 - 3 Put on the Dual Play glasses to enjoy game.
 - 4 The Dual Play mode turns off when you select **HOME** ⇒ **My Apps** → **Dual Play** while it is on.
- ✎ The game should support the Screen split mode to be played in Dual Play mode.
 - ✎ If the screen does not look clear enough with the Dual Play glasses on, players can change the glasses with each other. You should choose proper glasses according to the operation type of Dual Play.

- ✎ To set up the game menu, turn off the Dual Play mode.
- ✎ Certain images may appear to be overlapped during playing game. It is recommended to play a game facing the centre of the screen.
- ✎ When the game console has a low resolution, the picture quality may not be good in Dual Play mode.
- ✎ The picture on the screen is only in 2D in Dual Play mode.

❏ Cautions When Using Dual Play Glasses

- ✎ Please note that Dual Play glasses are different from regular 3D glasses. There is the mark "Dual Play" written on the Dual Play glasses.
- ✎ Do not use Dual Play glasses as ordinary glasses, sunglasses or protective goggles. If you do so, this may cause injury.
- ✎ Do not store Dual Play glasses in very hot or very cold conditions. If you do, this may cause them to become distorted. Do not use distorted glasses.

- ✎ Do not drop Dual Play glasses or allow them to come into contact with other objects. This can result in damage to the product.
- ✎ The lenses of Dual Play glasses (polarizing film) are easily scratched. Use a soft clean cloth when cleaning them. Foreign particles on the cloth may cause scratches.
- ✎ Do not scratch the surface of the Dual Play glasses' lenses with sharp objects or wipe them with chemicals. If the lenses get scratched, images may not look normal when viewing 3D.

❑ Dual Play Supporting Mode

Input	Signal	Resolution	Horizontal Frequency (KHz)	Vertical Frequency (Hz)
Composite	480i	720x480	15.73	60
Component	480i	720x480	15.73	60
	480p	720x480	31.50	60
HDMI/ Component	720P	1280 x 720	45	60
	1080i	1920 x 1080	33.75	60
	1080p	1920 x 1080	67.50	60
			27	24
			33.75	30

✎ Some models may not support Composite/Component input.

✎ Supported Dual Play Formats: Side by Side / Top & Bottom

Download the LG Magic Remote app from Google Play Store or Apple App Store to watch TV with your smartphone.

- Now you can enjoy your favorite TV shows on your smartphone. (Some models only)
 - Add your favorite channels on your smartphone.
 - You can use the functions such as PREMIUM, MY APPS directly on your smartphone.
 - Select an item using the TV Search function from your smartphone to watch it on TV.
 - The text input function is supported, so you can enter text easily. (Text cannot be entered on some screens.)
 - Select the app's touch pad to control in the same way the pointer of the Magic Remote Control works.
-  The supported functions may vary depending on the TV or the version of the LG Magic Remote app.

❑ To use a USB wired/wireless mouse

Connect your mouse to a USB port on the TV. Use the mouse to move the pointer on the TV screen and select the menu you want.

Mouse	Magic Remote Control
Left Button	OK Button on Magic Remote Control
Wheel Button	Wheel Button on Magic Remote Control

- ✎ The right mouse button and any special buttons will not work with the TV.
- ✎ The usability of a wireless USB mouse and keyboard may be affected by Radio Frequency environment and the distance.

❑ To use a USB wired/wireless keyboard

Connect your keyboard to a USB port on the TV. You can enter text with the keyboard when using the search function and the Web browser.

✎ Text cannot be entered on some screens.

✎ Applicable Keyboards

It is recommended to use a product which is tested for compatibility with LG TV.

LOGITECH K200, LOGITECH K400, MICROSOFT Comfort Curve 2000, MICROSOFT MS800, and LG Electronics ST-800

❏ To use a game pad

Connect your game pad to the USB port on the TV if the game supports the use of game pad.

🖱 Applicable Game Pads

It is recommended to use an authorized game pad which is tested for compatibility with LG TV.

Logitech F310, Logitech F510, and Logitech F710

❑ Set-Top Box Control

If you have a Magic Remote, you can use it to control your Set-Top Box tuner (cable box, satellite box, or IPTV box). Before set up, make sure that the set-top box is connected to your TV.

Set the set-top box following the instructions on the screen.

✎ If no instructions are displayed, set in **MY APPS** ⇒ **INPUT** → **Set the set-top box manipulation.**

❑ To reset/disconnect the set-top box

MY APPS ⇒ INPUT → Set the set-top box manipulation → Resetting/
Disconnect


Resetting	Deletes the set-top box settings and set it again.
Disconnect	The set-top box cannot be controlled by the Magic Remote Control.

❑ To control the set-top box with the Magic Remote Control

Select the external input connected to the set-top box. You can use the direction, OK, and channel buttons on the Magic Remote Control.

You can use various function buttons of the set-top box by pressing **MY APPS** button on the Magic Remote Control.

✍ Some buttons may not work depending on the set-top box model.



❑ Brands supporting the set-top box

- Cable: Evolution, General Instrument, Hamlin, Hitachi, Homecast, Kaon, Motorola, Moxi, Pace Micro, Panasonic, Pioneer, Samsung, Scientific Atlanta (CISCO), Sky, Sony, Telnet, Tivo, Tocom, Zenith
- IPTV: ADB, Amino, Entone, Minerva, Motorola, Myrio, Pace, Scientific Atlanta (Cisco), Tivo, Wegener
- Satellite: DirecTV, Dish Network (Echostar), Shaw Direct

✎ Some set-top box models may not work properly.

HOME ⇒ Settings → SUPPORT → Software Update

Uses Software Update to check and obtain the latest version.

It is also possible to check manually for available updates.

Software Update

Set it to **On**.

When an update file is detected, the file is automatically downloaded.

When the file download is complete, the software update window appears.

Check Update Version

Checks the version installed and when an update is available, the download process can be performed manually.

- ✎ The latest version can be obtained via digital broadcast signals or internet connections.
- ✎ Changing the channel while downloading the software via digital broadcast signal interrupts the download process. Returning to the initial channel allows downloading to resume.
- ✎ If software is not updated, certain functions may not work properly.

If the following symptoms occur, please recheck the system. It may not be a failure.

❑ General

Problem	Solution
Cannot view certain channels.	• Adjust the location or orientation of the antenna. • Save the desired channels on Auto Tuning or Channel Edit.
After turning on the TV, there is a delay before full images appear.	• It is not a problem because this process was intended to clean up the image noises that may occur when turning on the TV.

❏ Pictures

HOME ⇒ **Settings** → **SUPPORT** → **Picture Test**

Check if the image signal output is normal by beginning with Picture Test.

If there is no problem with the test image, check external device connections or broadcast signals.

Problem	Solution
Images from previous channel or other channels linger or the screen shows annoying lines.	• Try adjusting the antenna to the direction of the TV station or refer to the manual for proper way to connect the antenna.

Problem	Solution
Vibrating horizontal/vertical lines and fishnet patterns appear momentarily.	• Such a problem may happen when there is strong electronic interference. Turn off other electronic devices such as mobile phones, power tools and other small electrical appliances.
The screen display freezes or does not work properly in digital broadcast.	• It may happen when the signals are weak or the reception unstable. Adjust the antenna's orientation or cable connections. • If the signal strength or quality is low on Manual Tuning, call the TV station or administration office for checkup.
Digital broadcast is not on even though the cable is connected.	• Check with cable operator regarding the subscription and/or signal. (Depending on the subscription, digital broadcasting may not be supported.)

Problem	Solution
Image is not on or not clear when connected to HDMI.	• Check the HDMI® cable specifications. Use only HDMI® cable. Other cables may cause images to fade in and out or not be displayed properly. • Verify that all cable connections are securely connected. When connections are not secure, images may not be properly displayed.
Does not work when USB storage device is connected.	• Verify that the USB device and cable is version 2.0 or higher.

❏ Sound

HOME ⇒ Settings → SUPPORT → Sound Test

Try Sound Test first to verify that sound signal output is normal.

When the test sound is normal, check external device connections or broadcast signals.

Problem	Solution
Screen display is on but no sound.	• Check other TV channels. • Make sure the TV Speaker is set to On.
For analog broadcast, stereo is not clear or sound comes from one speaker only.	• In a poor reception area (areas with weak or unstable signal) or if multi audio is not stable, select Mono on Multi Audio. • Adjust the Balance with the Navigation button.

Problem	Solution
TV sound is not in sync with the lips or the sound breaks up occasionally.	• If it happens on a certain TV channel, it may be caused by problems with an individual station's broadcast signal. Check with the TV station or local cable operator.
Whenever changing the channel, the volume is different.	• Depending on the channel, there can be differences in volume. • Please set Auto Volume to On.

Problem	Solution
On certain channels, sound does not come out or only the background music plays. (If it is a program created for overseas)	• On Language, set Language → Audio Language as the desired language. Even if the language on Multi Audio is changed, once the power is turned off or the channel is changed, the default settings will be reset.
There is no sound when connected to HDMI/USB.	• Verify that the HDMI® cable is high speed. • Check if the USB device and cable is version 2.0 or higher. • Use only regular music (*.mp3) files.

❑ PC connection problem

Problem	Solution
The screen display is not on after connecting to the computer.	• Verify that the computer and the TV are securely connected. • Turn the TV off and back on using the remote control. • Restart the PC with the TV on. • Check if the resolution is correctly set for PC input. • To use the TV as a secondary monitor, check if the connected desktop or laptop supports dual monitor displays. • Reconnect the RGB/HDMI cable.
There is no sound after connecting the computer with the HDMI cable.	• Check with the video card manufacturer to ensure it supports HDMI voice output. (Video cards manufactured in DVI format require connection of a separate sound cable.)

Problem	Solution
When connected to the computer, the display is partially cut off or shifts to one side.	• Set up the resolution supporting PC input. (If it does not work, please reboot the computer.) • Select Screen (RGB-PC) and adjust Position/Size/Phase.

❑ Trouble with replaying movies in My Media.

Problem	Solution
Files on the Movie List are not displayed.	• Check if the file on the USB storage device can be read on a computer. • Check that the file extension is supported.
"This file is invalid." The above error message appears or the image display is not normal even though the sound is okay.	• Verify that the file replays normally on the video player in the computer. (Check for damaged files.) • Check if the resolution is supported by the computer. • Verify that the video/audio codec is supported. • Verify that the frame rate is one that is supported.

Problem	Solution
"Unsupported Audio." The above error message appears or the sound is not normal even though the image display is okay.	• Verify that the file replays normally on the video player in the computer. (Check for damaged files.) • Check that the audio codec is supported by the computer. • Verify that the bit rate is supported. • Verify that the sample rate is supported.

Problem	Solution
Subtitle is not displayed.	• Verify that the file replays normally on the video player in the computer. (Check for damaged files.) • Check if the video file shares the same name with the subtitle file. • Verify that the video and subtitle files are placed in the same folder. • Verify that the subtitle file format is supported. • Verify that the subtitle language is supported. (Open the subtitle files in Notepad to check for the language.)

 Image shown may differ from your TV.

 For information on requesting service, refer to the TV's menu.

HOME ⇒ Settings → SUPPORT → Product/Service Info.

Federal Communications Commission (FCC) Statement

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1 this device may not cause harmful interference, and
- 2 this device must accept any interference received, including interference that may cause undesired operation of the device.

Indoor use only

FCC Caution: for indoor use only, use outdoors or in other modes not covered by this manual may violate the FCC regulation and violate the user authority to use the product. Specially, within the 5.15-5.25 GHz band, U-NII device is restricted to indoor operations to reduce any potential for harmful interference to co-channel MSS operations.

FCC RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

❏ COFETEL(Para México)

La operación de este equipo está sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Industry Canada Statement:

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions:

- 1 this device may not cause interference and
- 2 this device must accept any interference, including interference that may cause undesired operation of the device

This class B digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

Avis d'Industrie Canada

Cet appareil est conforme à la norme CNR-210 des règlements d'Industrie Canada. Son fonctionnement est sujet aux deux conditions suivantes:

- 1 Cet appareil ne doit pas provoquer d'interférences et
- 2 Cet appareil doit accepter toutes les interférences, y compris celles pouvant entraîner son dysfonctionnement.

This class B digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

IC Radiation Exposure Statement

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Avis d'Industrie Canada sur l'exposition aux rayonnements

Cet appareil est conforme aux limites d'exposition aux rayonnements d'Industrie Canada pour un environnement non contrôlé.

Il doit être installé de façon à garder une distance minimale de 20 centimètres entre la source de rayonnements et votre corps.

REMARQUE : LE FABRICANT N'EST PAS RESPONSABLE DES INTERFÉRENCES RADIOÉLECTRIQUES CAUSÉES PAR DES MODIFICATIONS NON AUTORISÉES APPORTÉES À CET APPAREIL. DE TELLES MODIFICATIONS POURRAIT ANNULER L'AUTORISATION ACCORDÉE À L'UTILISATEUR DE FAIRE FONCTIONNER L'APPAREIL.

Information for recycling (take-back offer)

This product may contain parts which could be hazardous to the environment.

It is important that this product be recycled after use.

LGE handles all waste products through an environmentally acceptable recycling method. There are several take-back and recycling systems currently in operation worldwide.

Many parts will be reused and recycled, while harmful substances and heavy metals are treated by an environmentally friendly method. If you want to find out more information about our recycling program, please contact your local LG vendor or a corporate representative of LG. and Information of Regional Take back Schemes can be found at :

<http://www.lg.com/global/sustainability/environment/take-back-recycling.jsp>

On Disposal (Only, LCD TV with Hg lamp)

- The fluorescent lamp used in this product contains a small amount of mercury.
- Do not dispose of this product with general household waste.
- Disposal of this product must be carried out in accordance to the regulations of your local authority.

MISE AU REBUS (seules des lampes au mercure sont util-isées avec le Téléviseur ACL)

- Les lampes fluorescentes utilisées dans ce produit contiennent une minime quantité de mercure.
- Ne pas jeter cet appareil avec vos déchets domestiques.
- La mise au rebus de cet appareil doit être effectuée en fonction des règles en vigueur dans votre communauté.

DISPOSICIÓN (Sólo lámpara de Hg utilizada en TV LCD)

- La lámpara fluorescente usada en este producto contiene una cantidad mínima de mercurio.
- No disponga este producto junto con la basura normal de la casa.
- La disposición de este producto debe ser manejado de acuerdo a los reglamentos de la autoridad local.