


OIP-N60D_OIP-N60D , Dante AV-H Quick Installation Guide

www.MyLumens.com

Lumens[®]

1. Product connection



*Decoder supports PoE (IEEE 802.3af) network switches or USB-C power supply

2. Instruction for Installation

■ Using the accessory metal plates

- (1) Lock the accessory metal plate with screws (M3 x 4) to the lock holes on both sides of the decoder



- (2) Install the metal plate and decoder under the table according to the spatial area



■ Use tripod


The camera can be mounted on a 1/4"-20 UNC PTZ tripod deck by using the lock holes on the side for the tripod of decoder



3. Operation Methods

■ Operate through the body button

Connect the HDMI OUT to the display, press the Menu dial to enter the OSD menu. Through the Menu dial to navigate the menu and adjust the parameters.




- Left/Right rotation: Adjust parameters and navigate the menu
- Press: Perform "confirm" action

■ Operate via webpages

3.1 Confirm the IP address

Refer to [Operate through the body button](#), confirm the IP address in Status (If the decoder is directly connected to the computer, the default IP is 192.168.100.200. Please manually set the computer's IP address in the same network segment.)



- 3.2 Open the browser and input the IP address, e.g. 192.168.4.161, to access the login interface.

192.168.4.161

- 3.3 Please enter the account / password to log in

Account : admin
Password : 9999

OIP-N60D_OIP-N60D , Dante AV-H

Quick Installation Guide

www.MyLumens.com

Lumens[®]

4. Virtual USB Network Camera

Oip-N Decoder can convert IP signal source into USB (UVC) for seamless integration with video conferencing platforms.

4.1 Connection Method

- Connect the decoder to LAN
- Connect the computer to the decoder using USB-C cable



Note:

The computer connects to the OIP-N decoder via USB-C and uses the RTSP/NDI source as USB network camera

4.2 Webpage Settings

- [System] > [Output], open [Virtual USB Setting]
- [Source] > [Search new Source] > Select the desired output device > Click [Play] to output device signal source

4.3 USB Camera Screen Output

- Launch a video software like Skype, Zoom, Microsoft Teams, or other similar software
 - Choose the video source, to output USB network camera images
- * Video Source Name: Lumens OIP-N60D Decoder/ Lumens OIP-N60D, Dante AV-H Decoder


5. USB Network Camera Extension (OIP-N40E Encoder Required)

When used with the OIP-N encoder and decoder, it can extend the range of USB network cameras through the network to improve installation flexibility.

5.1 Connection Method

- Connect the OIP-N encoder/decoder to the local network
- Connect the USB camera to the decoder using USB-A cable

- Connect the monitor to the decoder using HDMI cable
- Connect the computer to the encoder using USB-C cable



Note:

- (1) Computers can use USB-C to connect to encoder and use USB network camera
- (2) Computers can project images onto a TV through a USB-C connection to encoder

5.2 OIP-N decoder Webpage Settings

[System] > [Output], open [USB Extender]

5.3 OIP-N40E Webpage Settings

- [System] > [Output] > [Extender Source List]
- [Search new Source] > Click [Available] to select OIP-N decoder > Connection displays [Connected]

5.4 USB Camera Screen Output

- Launch a video software like Skype, Zoom or Microsoft Teams, or other similar software
- Choose the video source, to output USB camera images

*Video Source Name: Select according to the USB Camera

※ For questions about the installation, please scan the QR Code.

A support person will be assigned to assist you.



Get Help ?