



**RJ493 / RJ493RC**

**49 Key MIDI Keyboard**

**User Guide**

# **Important Information**

Be sure to obey the following information so as not to harm yourself or others or damage this instrument or other external equipment.

## **Power Chord:**

- Do not place the USB power cable near to any source of heat such as radiators or other heaters.
- To avoid damaging the USB power cable, please ensure that heavy objects are not placed on it and that it is not subject to stress or over bending.
- Do not insert or unplug the USB power cable with wet hands.

## **Do not open the body of the electronic keyboard:**

- Do not open the electronic keyboard or try to disassemble any part of it. If the keyboard is not functioning correctly, please stop using it and send it to a qualified service agent for repair.

## **Use of the electronic keyboard:**

- To avoid damaging the appearance of the electronic keyboard or damaging the internal parts please do not place the electronic keyboard in a dusty environment, in direct sunlight or in places where there are very high or very low temperatures.
- Do not place the electronic keyboard on an uneven surface. To avoid damaging internal parts do not place any vessel holding liquid onto the electronic keyboard as spillage may occur.

## **Maintenance:**

- To clean the body of the electronic keyboard wipe it with a dry, soft cloth only.

## **Connection:**

- To prevent damage to the speakers of the electronic keyboard please adjust the volume of any peripheral device to the lowest setting and gradually adjust the volume accordingly to an appropriate level once the music is playing.

## **During operation:**

- Do not use the keyboard at the loudest volume level for a long period.
- Do not place heavy objects onto the keyboard or press the keyboard with undue force.
- The packaging should be opened by a responsible adult only and any plastic packaging should be disposed of appropriately.

## **Specification**

- Specifications are subject to change without notice.


## Contents

Important Information .....	2
Controls, Indicators and External Connections .....	5
Front Panel .....	5
External Connections .....	5
LED Display .....	5
Preparation Before First Use .....	6
Power .....	6
Use of USB Type C Cable: .....	6
Battery Operation: .....	6
Charging the Keyboard ( <b>applies only to rechargeable versions - RJ493RC models</b> ): .....	6
Jacks and Accessories .....	6
Using Headphones: .....	6
Connecting an Amplifier or Hi-Fi Equipment: .....	7
Connecting a phone or audio device to the AUX Input to play music through the keyboard: .....	7
Connecting a Microphone: .....	8
Connecting to a Tablet, Laptop or PC: .....	8
Keyboard Operation .....	9
Bluetooth Operation .....	9
Audio: .....	9
MIDI: .....	9
Power and Volume .....	10
Power Control: .....	10
Auto Power Off: .....	10
Adjustment of the Master Volume: .....	10
Tone .....	11
Tone Selection: .....	11
Tone Volume Adjustment: .....	11
Sustain: .....	11
Vibrato: .....	12
Panel Percussion Instruments: .....	12
Rhythm .....	13
Selecting the Rhythm: .....	13

Rhythm Start / Stop: .....	13
Rhythm Volume Adjustment: .....	13
Sync: .....	14
Intro / End: .....	14
Tempo Adjustment: .....	14
Enhanced Features .....	15
Touch Sensitive Keys: .....	15
Demo Songs: .....	15
Chord Mode: .....	15
Metronome: .....	16
Metronome Volume Adjustment: .....	16
Recording Function: .....	16
Appendix I. Percussion Instruments .....	17
Appendix II. Rhythm Table .....	18
Appendix III. Tone Table .....	19
Appendix IV. Demo Song Table .....	20
Appendix V. Chord Table .....	21
Appendix VI. Troubleshooting .....	22
Appendix VII. Technical Specification .....	23
Appendix VIII. MIDI APPs .....	24
FCC Compliance Statement .....	24
Product Disposal Instructions (EU and UK) .....	25
EU and UK Regulatory Compliance .....	25


# Controls, Indicators and External Connections

## Front Panel



- |                                    |                   |                   |
|------------------------------------|-------------------|-------------------|
| 1. Speaker                         | 10. Tempo / Vol + | 18. Start / Stop  |
| 2. Power switch / Charge Indicator | 11. Demo          | 19. Tempo / Vol - |
| 3. Bluetooth indicator             | 12. Tone          | 20. Metronome     |
| 4. Volume wheel                    | 13. Number keys   | 21. Rhythm        |
| 5. Sustain                         | 14. Vibrato       | 22. Tones list    |
| 6. Percussion                      | 15. Touch         | 23. Rhythms list  |
| 7. Record                          | 16. Play          | 24. LED screen    |
| 8. Chord                           | 17. Intro / End   | 25. Chord area    |

## External Connections



1. DC input
2. Headphone output
3. AUX input
4. MIC input (Electret type)
5. USB MIDI output (to Laptop or PC)

## LED Display



1. 3-Digit LED Display

# Preparation Before First Use

## Power

Use of USB Type C Cable:

Please use the USB type C cable that is supplied with the electronic keyboard and a 5V USB - 2A adapter (not included). Connect the cable into the socket on the rear of the keyboard and then connect the other end into the adapter or power supply and switch on.

**NOTE:** Use of a USB adapter with less than 2A rating is not recommended and might cause the keyboard to malfunction. When the keyboard is not in use you should unplug the USB adapter from the mains power socket

Battery Operation:

Open the battery lid on the underneath of the electronic keyboard and insert 4 x 1.5V Size 'AA' alkaline batteries. Ensure the batteries are inserted with the correct polarity and replace the battery lid.

Caution: Do not mix old and new batteries. Do not leave batteries in the keyboard if the keyboard is not going to be used for a long time. This will avoid possible damage caused by leaking batteries.

Charging the Keyboard (**applies only to rechargeable versions - RJ493RC models**):

Unwind the USB power cable to its full length; connect one end to the USB C Socket on the back of the keyboard. Connect the other end to a USB power adapter or PC USB port. The charge indicator LED on the power button will light up red to indicate charging. Charge for at least 4 hours before first use. After the battery has lost charge completely, it will take approximately 6 hours to charge the keyboard fully. The charge indicator LED will turn green when the keyboard is fully charged.

## Jacks and Accessories


Using Headphones:

Connect the 3.5mm headphone plug into the [PHONES] jack on the rear of the keyboard. The internal speaker will cut off automatically once headphones are connected. Headphones are not included.




## Connecting an Amplifier or Hi-Fi Equipment:

This electronic keyboard has a built in speaker system but it can be connected to an external amplifier or other hi-fi equipment. First turn off the power to the keyboard and any external equipment you are looking to connect. Next insert one end of a stereo audio cable (not included) into the LINE IN or AUX IN socket on the external equipment and connect the other end into the [PHONES] jack on the rear of the electronic keyboard.




## Connecting a phone or audio device to the AUX Input to play music through the keyboard:

This keyboard has a built-in speaker system that can be used to play music from your phone or mobile device. Insert one end of a stereo 3.5mm AUX input cable included into the AUX In socket on the back of the keyboard and connect the other end into your phone or audio device. Make sure the keyboard is switched on. Use the volume control of the phone to control the music volume.




## Connecting a Microphone:

Connect the 3.5mm microphone plug into the [MIC] jack on the rear of the keyboard. The microphone should be an electret or condensor type. Microphone not included.



## Connecting to a Tablet, Laptop or PC:

You can connect the keyboard to a tablet, laptop or PC to work with various third party MIDI softwares for recording and playing back songs. Connect a cable with USB B type plug into the MIDI output at the back of the keyboard and then connect the USB A type plug to the PC or Laptop. USB MIDI cable for PC/Laptop connection is not included.






# Keyboard Operation

## Bluetooth Operation

Audio:

Once the keyboard has been switched on the Bluetooth pairing mode will be activated. To play music from a mobile or tablet, open the settings on the selected Bluetooth mobile device and scan for available devices. Select “**RJ493 AUDIO**” for Bluetooth audio. The Bluetooth indicator on the keyboard will light and a sound prompt will be heard to indicate the device has been connected successfully.



MIDI:

**IMPORTANT:** Bluetooth MIDI **cannot** be connected from the 'Bluetooth Settings' of the mobile device.

For Bluetooth MIDI use, switch on the keyboard and then open the APP that supports Bluetooth MIDI, such as 'Garageband' for iPhone/iPad on the selected mobile or tablet. Search and connect “**RJ MIDI**” from the APP's settings or advanced function. The Bluetooth indicator on the keyboard will light and a sound prompt will be heard to indicate the device has been connected successfully.

**Special Function:** If you want to play the APP or MIDI software's built-in sound through the keyboard speakers then proceed as follows:


- Connect the mobile device to the keyboard AUX In port using the 3.5mm AUX input cable included.
- Mute the keyboard's built-in tones (refer to section 'Tone Volume Adjustment').
- Open your favourite MIDI app which supports Bluetooth MIDI, such as 'Garageband'.
- Connect to “RJ MIDI” via the APP's settings.

Now the keyboard can play the tone selected in the MIDI APP. A list of MIDI APPs to try out can be found in Appendix VIII.

## Power and Volume

### Power Control:

Press the [POWER] button to turn the power on and again to turn the power off. The LED screen will light up to indicate power on.




### Auto Power Off:

The keyboard has an 'Auto Power Off' function and will switch off to save power after no key is pressed for approximately 5 minutes. To switch back on, press the [POWER] button.

### Adjustment of the Master Volume:


To change the Master volume, turn the [VOLUME] dial.



# Tone


## Tone Selection:

When the keyboard is switched on the default Tone is ‘000’ Grand Piano. To change the Tone, press the [TONE] button first, the display will briefly show ‘ton’ followed by the currently selected tone number. Then select the required tone by pressing the corresponding digits 0-9. Tones can also be changed by using the [+ / -] buttons on the key pad. Refer to Appendix III for a full list of the available tones.




## Tone Volume Adjustment:

There are 5 levels of volume adjustment (000 – 004). Press and hold the [TONE] button then press the [VOL +/-] buttons to increase or reduce the tone volume. The display will show the volume level selected (000 – 004). Press and hold down the [TONE] button, then press both [VOL +] and [VOL -] buttons at the same time to return to the default volume level of 004. This function is useful when you want to turn down or mute (Mute – Level 000) the keyboards built-in tone and play tones from an external device connected with an AUX input cable.




## Sustain:

Press the [SUSTAIN] button to enter Sustain mode. The LED display will briefly show ‘On’ to show that Sustain is on. Once this mode is selected the sound of each note played is prolonged. Pressing the [SUSTAIN] button again will turn the Sustain feature off and exit this mode. The display will briefly show ‘Off’.




Vibrato:

The Vibrato function adds a wavering quality to the note being played. Press the [VIBRATO] button to enter Vibrato mode. The LED display will briefly show 'On' to show that Vibrato is on. Pressing the [VIBRATO] button again will turn the Vibrato feature off and exit this mode. The display will briefly show 'Off'.



Panel Percussion Instruments:


When the [PERCUSSION] button is pressed, all the keyboard's keys can be used to play percussion sounds. Press the [PERCUSSION] button again to exit percussion mode. Refer to Appendix I. for a table of the 49 different percussion sounds available



# Rhythm


## Selecting the Rhythm:

You can choose from any of the 128 built in rhythms. Please refer to Appendix II. for the detailed rhythm table. Press the [RHYTHM] button to enter the rhythm selection function, the display will briefly show 'Rhy' followed by the current rhythm number. You can select the rhythm you require by pressing the corresponding digits on the numerical keypad or by pressing the + / - buttons.




## Rhythm Start / Stop:

With a rhythm selected, press the [Start/Stop] button to start or stop playing the chosen rhythm




## Rhythm Volume Adjustment:

There are 7 levels of volume adjustment (001 – 007). Press and hold the [RHYTHM] button then press the [VOL +/-] buttons to increase or reduce the rhythm volume. The display will show the volume level selected (001 – 007). Press and hold down the [RHYTHM] button, then press both [VOL +] and [VOL -] buttons at the same time to return to the default volume level of 006.




Sync:

Press the [SYNC] button to select the synchronised accompaniment function, the display will show 'Syn'. The rhythm will start playing as soon as any of the first 19 keys on the left side of the keyboard are pressed. Press the [START /STOP] button to stop the rhythm and exit the sync function.




Intro / End:

To schedule an introductory rhythm section press the [INTRO/END] button, the display will briefly show 'Pre'. Then press the [START/STOP] button to start playback of the intro rhythm section. When the intro finishes playing, accompaniment shifts to the main rhythm section. Press the [INTRO/END] button again to initiate an ending section, the display will briefly show 'End'. When the ending is finished, the auto accompaniment stops automatically.



Tempo Adjustment:


Press the [TEMPO + / -] buttons to adjust the tempo of the rhythm, metronome, or demo songs up or down. Press and hold to adjust the tempo quickly. The adjustment range is 30-250 bpm. Pressing both the [TEMPO] buttons at the same time will revert the tempo to 120 bpm. At power on the tempo will be reset to 120 bpm.



# Enhanced Features


## Touch Sensitive Keys:

The Touch sensitivity mode is switched on by default. Press the [TOUCH] button to switch off the touch response, the display will briefly show 'Off'. Press the [TOUCH] button again to turn the touch response on. The display will briefly show 'On'




## Demo Songs:

Press the [DEMO] button to play a demo song. The LED display will show a number indicating the song being played. By pressing the digits or [+] and [-] buttons on the numerical keypad you can choose the demo song you require. There are 50 (000-049) demo songs to choose from in total. The keyboard will finish the chosen song and then start playing the next demo song. Press the [DEMO] button again to exit the demo mode. Refer to Appendix IV. for a full list of the available Demo songs.




## Chord Mode:

To select the chord mode, touch the [CHORD] button, the display will briefly show 'Cho'. Chords can then be played with a single finger using the 19 keys at the left side of the keyboard. Refer to Appendix V for the Chord table. To exit the chord mode touch the [CHORD] button again.




Metronome:

Press the [METRONOME] button to start the tick-tock beat. There are four beats to choose from (b01 to b04). Depending on the performance, you can press the [TEMPO] buttons to speed up or slow down the beat. Press the [METRONOME] button repeatedly to cycle through the available beat patterns. The LED display will indicate the beat you have chosen. The Metronome effect is added to the music once you start playing. To exit this mode touch the [START/STOP] or [METRONOME] button again until 'Off' is shown on the display.




Metronome Volume Adjustment:

There are 7 levels of volume adjustment (001 – 007). Press and hold the [METRONOME] button then press the [VOL +/-] buttons to increase or reduce the metronome volume. The display will show the volume level selected (001 – 007). Press and hold down the [METRONOME] button, then press both [VOL +] and [VOL -] buttons at the same time to return to the default volume level of 005.




Recording Function:

Press the [REC] button to enter the recording mode. The display will show 'REC'. Press any key to start recording. The maximum recording capacity is limited to 1,000 notes.



Press the [PLAY] button to play back the recorded notes. The display will show 'REP'. Press the [REC] button again to exit recording mode.





## **Appendix I. Percussion Instruments**

<b>No.</b>	<b>Percussion Instrument</b>	<b>No.</b>	<b>Percussion Instrument</b>	<b>No.</b>	<b>Percussion Instrument</b>
<b>1</b>	Bass Drum 1	<b>18</b>	Ride Bell	<b>35</b>	Maracas
<b>2</b>	Side Stick	<b>19</b>	Tambourine	<b>36</b>	Short Whistle
<b>3</b>	Acoustic Snare	<b>20</b>	Splash Cymbal	<b>37</b>	Long Whistle
<b>4</b>	Hand Clap	<b>21</b>	Cowbell	<b>38</b>	Short Guiro
<b>5</b>	Electric Snare	<b>22</b>	Crash Cymbal 2	<b>39</b>	Long Guiro
<b>6</b>	Low Floor Tom	<b>23</b>	Vibraslap	<b>40</b>	Claves
<b>7</b>	Closed Hi-Hat	<b>24</b>	Ride Cymbal 2	<b>41</b>	Hi Wood Block
<b>8</b>	High Floor Tom	<b>25</b>	Hi Bongo	<b>42</b>	Low Wood Block
<b>9</b>	Pedal Hi-Hat	<b>26</b>	Low Bongo	<b>43</b>	Mute Cuica
<b>10</b>	Low Tom	<b>27</b>	Mute Hi Conga	<b>44</b>	Open Cuica
<b>11</b>	Open Hi-Hat	<b>28</b>	Open Hi Conga	<b>45</b>	Mute Triangle
<b>12</b>	Low-Mid Tom	<b>29</b>	Low Conga	<b>46</b>	Open Triangle
<b>13</b>	Hi-Mid Tom	<b>30</b>	High Timbale	<b>47</b>	Shaker
<b>14</b>	Crash Cymbal 1	<b>31</b>	Low Timbale	<b>48</b>	Jingle Bell
<b>15</b>	High Tom	<b>32</b>	High Agogo	<b>49</b>	Bell Tree
<b>16</b>	Ride Cymbal 1	<b>33</b>	Low Agogo		
<b>17</b>	Chinese Cymbal	<b>34</b>	Cabasa		

## Appendix II. Rhythm Table

No.	Rhythm Name	No.	Rhythm Name	No.	Rhythm Name
0	16 beat 1	43	Kinetic 1	86	Love ballad 4
1	16 beat 2	44	Kinetic 2	87	Love ballad 5
2	16 beat 3	45	African	88	Mambo 1
3	16 Beat Tune	46	Bluegrass	89	Mambo 2
4	16 Reggae	47	Blues 1	90	Tango 1
5	8 Beat modern	48	City pop	91	Tango 2
6	Soul 1	49	Classic pop	92	Tango 3
7	Soul 2	50	Euro beat	93	Country and western 1
8	Soul 3	51	Fusion jazz	94	Country and western 2
9	Soul 4	52	Hard beat	95	Country folk
10	Soul 5	53	Reggae 1	96	Polka 1
11	Sou l6	54	Twist	97	Polka 2
12	Sou l7	55	Rhumba 1	98	Polka 3
13	Soul 8	56	Rhumba 2	99	China 1
14	60s Soul	57	Rhumba 3	100	China 2
15	70s Soul	58	Rhumba 4	101	China 3
16	80s Soul	59	Rhumba 5	102	Mideast
17	90s Soul	60	Bachata 1	103	Tarante
18	Disco soul	61	Bachata 2	104	Thailand
19	Euro soul	62	Bachata 3	105	70s Rock
20	New soul	63	Merengue 1	106	Acid
21	Funky	64	Merengue 2	107	Afro pop
22	Funk Pop	65	Bequine	108	Hard rock
23	Funk Samba	66	Lambada	109	Rock cha-cha
24	Funk Slide	67	Plena	110	Rock roll
25	Funky Soul	68	Salsa	111	Rock waltz
26	Funk Disco	69	Vallenato	112	Slow rock 1
27	House 1	70	Bossa nova 1	113	Slow rock 2
28	House 2	71	Bossa nova 2	114	Slow soul 3
29	Big band1	72	Bossa nova 3	115	Pop dance 1
30	Big band2	73	Samba 1	116	Pop dance 2
31	Cobmo	74	Samba 2	117	Pop dance 3
32	Cobmo disco	75	Samba 3	118	Shuffle 1
33	Waltz	76	Calypso	119	Shuffle 2
34	Jazz waltz 1	77	Habanera	120	Baiao
35	Jazz waltz 2	78	Jazz Samba	121	Bolero
36	Jazz waltz 3	79	Jorpo	122	Latin swing
37	Popular waltz	80	Samba pop	123	Swing beat
38	Band march 1	81	8 Ballad	124	Swing 1
39	Band march 2	82	Aor	125	Swing 2
40	Band march 3	83	Love ballad 1	126	Swing 3
41	American march	84	Love ballad 2	127	Swing 4
42	80s Pop	85	Love ballad 3		

## Appendix III. Tone Table

No.	Tone Name	No.	Tone Name	No.	Tone Name
000	Acoustic Grand Piano	047	Timpani	094	Pad 7 (halo)
001	Bright Acoustic Piano	048	String Ensemble 1	095	Pad 8 (sweep)
002	Electric Grand Piano	049	String Ensemble 2	096	FX 1 (rain)
003	Honky-tonk Piano	050	Synth Strings 1	097	FX 2 (soundtrack)
004	Rhodes Piano	051	Synth Strings 2	098	FX 3 (crystal)
005	Chorused Piano	052	Choir Aah	099	FX 4 (atmosphere)
006	Harpsichord	053	Voice Oohs	100	FX 5 (brightness)
007	Clavichord	054	Synth Voice	101	FX 6 (goblins)
008	Celesta	055	Orchestra Hit	102	FX 7 (echoes)
009	Glockenspiel	056	Trumpet	103	FX 8 (sci-fi)
010	Music box	057	Trombone	104	Sitar
011	Vibraphone	058	Tuba	105	Banjo
012	Marimba	059	Muted Trumpet	106	Shamisen
013	Xylophone	060	French Horn	107	Koto
014	Tubular Bells	061	Brass Section	108	Kalimba
015	Dulcimer	062	Synth Brass 1	109	Bagpipe
016	Hammond Organ	063	Synth Brass 2	110	Fiddle
017	Percussive Organ	064	Soprano Sax	111	Shanai
018	Rock Organ	065	Alto Sax	112	Tinkle Bell
019	Church Organ	066	Tenor Sax	113	Agogo
020	Reed Organ	067	Baritone Sax	114	Steel Drums
021	Accordion	068	Oboe	115	Woodblock
022	Harmonica	069	English Horn	116	Taiko Drum
023	Tango Accordion	070	Bassoon	117	Melodic Tom
024	Acoustic Guitar (nylon)	071	Clarinet	118	Synth Drum
025	Acoustic Guitar (steel)	072	Piccolo	119	Reverse Cymbal
026	Electric Guitar (jazz)	073	Flute	120	Guitar Fret Noise
027	Electric Guitar (clean)	074	Recorder	121	Breath Noise
028	Electric Guitar (muted)	075	Pan Flute	122	Seashore
029	Overdrive Guitar	076	Bottle Blow	123	Bird Tweet
030	Distortion Guitar	077	Shakuhachi	124	Telephone Ring
031	Guitar Harmonics	078	Whistle	125	Helicopter
032	Acoustic Bass	079	Ocarina	126	Applause
033	Electric Bass(finger)	080	Lead 1 (square)	127	Gunshot
034	Electric Bass (pick)	081	Lead 2 (sawtooth)	128	Dog Bark
035	Fretless Bass	082	Lead 3 (caliope lead)	129	Cockerel
036	Slap Bass 1	083	Lead 4 (chiff lead)	130	Sheep
037	Slap Bass 2	084	Lead 5 (charang)	131	Cow
038	Synth Bass 1	085	Lead 6 (voice)	132	Mosquito
039	Synth Bass 2	086	Lead 7 (fifths)	133	Crow
040	Violin	087	Lead 8 (bass+lead)	134	Door Creaky
041	Viola	088	Pad 1 (new age)	135	Door Closing
042	Cello	089	Pad 2 (warm)	136	Thunder

<b>043</b>	Contrabass	<b>090</b>	Pad 3 (polysynth)	<b>137</b>	Laser Gun
<b>044</b>	Tremolo Strings	<b>091</b>	Pad 4 (choir)	<b>138</b>	Cheer
<b>045</b>	Pizzicato Strings	<b>092</b>	Pad 5 (bowed)	<b>139</b>	Laughter
<b>046</b>	Orchestral Harp	<b>093</b>	Pad 6 (metallic)		

## **Appendix IV. Demo Song Table**

<b>No.</b>	<b>Name of Song</b>	<b>No.</b>	<b>Name of Song</b>	<b>No.</b>	<b>Name of Song</b>
<b>00</b>	Turkish March	<b>17</b>	Santa Claus is Coming	<b>34</b>	Minuet in G
<b>01</b>	Bach Song	<b>18</b>	Mozart Symphony	<b>35</b>	Schubert Serenade
<b>02</b>	Beethoven Piano Sonatas	<b>19</b>	Mozart Sonatina	<b>36</b>	Four Seasons Spring March
<b>03</b>	Spanish Matador March	<b>20</b>	Come Back To Sorrento	<b>37</b>	Smile Polka
<b>04</b>	Hungarian Dance	<b>21</b>	Cuckoo Waltz	<b>38</b>	Fur Elise
<b>05</b>	Ode to Joy	<b>22</b>	Carman Overture	<b>39</b>	Melody in the Rain
<b>06</b>	Haydn Serenade	<b>23</b>	Canon	<b>40</b>	Santa Lucia
<b>07</b>	The Rivers of Babylon	<b>24</b>	Katyusha	<b>41</b>	Susannah
<b>08</b>	Ballade Pour Adeline	<b>25</b>	Russian Dance Music	<b>42</b>	A Comme Amour
<b>09</b>	Merry Widow Waltz	<b>26</b>	Troika	<b>43</b>	Unchained Melody
<b>10</b>	Cancan	<b>27</b>	Dance of the Flowers	<b>44</b>	Dove
<b>11</b>	Lovely Smurf	<b>28</b>	March Militaire	<b>45</b>	Old Franc
<b>12</b>	Mary Had a Little Lamb	<b>29</b>	Triumphal March	<b>46</b>	Concerto D'Amour
<b>13</b>	American Patrol	<b>30</b>	Carmen Aragon	<b>47</b>	Dream of Love
<b>14</b>	Edelweiss	<b>31</b>	Clarinet Polka	<b>48</b>	Minuet From L'Arlesienne
<b>15</b>	Lullaby	<b>32</b>	Gewolt	<b>49</b>	Moon River
<b>16</b>	Clementine Sonata	<b>33</b>	Chopin Nocturnes		

## Appendix V. Chord Table

	M	m	7	m7
C				
D♭				
D				
E♭				
E				
F				
F♯				
G				
G♯				
A				
B♭				
B				

## Appendix VI. Troubleshooting

Problem	Possible Reason / Solution
A faint noise is heard when turning the power on or off.	This is normal and nothing to worry about.
After turning the power on to the keyboard there was no sound when the keys were pressed.	<p>Check the master volume is not set to minimum.</p> <p>Check that headphones or any other equipment are not plugged into the keyboard as these will cause the built-in speaker system to cut off automatically.</p> <p>Check that the keyboard's built-in tones are not muted (Tone volume set to level 000). Refer to section – 'Tone Volume Adjustment'.</p>
<p>Sound is distorted or interrupted and the keyboard is not working properly.</p> <p>The keyboard behaves strangely and possibly cuts out especially at high volume.</p>	<p>Use of incorrect power cable or USB adapter. Use the Type C USB power cable supplied.</p> <p>Use a USB power adapter with 2A rated output. <b>Lower rated adapters such as 1A or below are not recommended.</b></p>
There is a slight difference in timbre of some notes.	This is normal and is caused by the many different voice sampling ranges of the keyboard.
When using the sustain function some tones have long sustain and some short sustain.	This is normal. The best length of sustain for different tones has been pre-set.
The master volume or rhythm volume are not balanced correctly.	Adjust the master volume and rhythm volume separately as described in the instructions. Note that the master volume also affects the rhythm volume.
In 'Sync' mode the auto accompaniment does not start.	Check to make sure that you are playing a note from the first 19 keys on the left hand side of the keyboard to start the accompaniment.
The keyboard switches off by itself.	This is not a fault and is just the 'Auto Power Off' function coming into play after 5 minutes of not using the keyboard. Press the 'Power' button to switch back on.
Bluetooth MIDI cannot be connected from Bluetooth settings of the mobile phone or tablet.	This is not a fault. The Bluetooth MIDI connection needs to be made from the APP that supports Bluetooth MIDI such as 'Garageband'. It cannot be made from Bluetooth Settings.

## Appendix VII. Technical Specification

- **Display**  
3 Digit LED Display
- **Tone**  
140 tones
- **Rhythm**  
128 stereo rhythms
- **Demo**  
50 different demo songs
- **Effect and Control**  
Touch Sensitive Keys, Sustain, Vibrato
- **MIDI**  
Wired and Wireless MIDI
- **Recording and Playback**  
1,000 Note record memory
- **Percussion**  
49 different instruments
- **Accompaniment Control**  
Start/Stop, Sync, Tempo, Intro/Ending
- **Enhanced Features**  
Metronome, Chord Mode, Sync, Intro/End, Auto Power Off
- **External Jacks**  
Power input, Headphone output, Microphone (Electret) input, USB output, AUX Input
- **Weight**  
1.85 kg
- **Power Requirement**  
5V DC @ 2A, USB Type C
- **Battery operation**  
4 x 1.5V 'AA' Alkaline
- **Output Power**  
2W x 2
- **Accessories included**  
USB Type C Power Cable, Sheet Music Stand, 3.5mm AUX input cable, User guide

## Appendix VIII. MIDI APPs

Apple	Bluetooth MIDI Support	Android	Bluetooth MIDI Support
AudioKit Synth One Synthesizer	Yes	FM Synthesizer [SynprezFM II]	Yes
KORG Gadget 2 le	Yes	Cubasis LE 3 Trial	No
Garageband	Yes	DRC	No
KORG Module	Yes	Caustic 3	No

**NOTE:** The above APPs are not endorsed or supported by the keyboard manufacturer in any way and should be used at the user's own risk. Please contact the APP developer for any support required for use.  
Download from Apple APP Store or Google Play Store.

## FCC Compliance Statement

FCC Class B Part 15

This device complies with Part 15 of the Federal Communications Commission (FCC) Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instructions, may cause interference harmful to radio communications.

There is no guarantee, however, that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio or TV technician for help.



## Product Disposal Instructions (EU and UK)

The symbol shown here and, on the product, means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life. The Waste Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU) has been put in place to encourage the recycling of products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increase of landfill. When you have no further use for this product, please dispose of it using your local authority's recycling processes. For more information, please contact your local authority or the retailer where the product was purchased.



## EU and UK Regulatory Compliance

PDT Ltd. As manufacturer declares that the radio equipment described within is in compliance with Directive 2014/53/EU (Radio Equipment) and bears the CE and UKCA marks in accordance with that directive.

The full text of the EU declaration of conformity is available at the following internet address:

**<https://pdtuk.com/declaration-of-conformity-library/>**

European Distributor and Authorised Representative:

AVESTA, 33 Avenue du Maréchal - de - Lattre - de - Tassigny, 94120 Fontenay-sous-Bois, France



Designed and manufactured by:

PDT Ltd. Unit 4B, Greengate Industrial Estate, White Moss View, Middleton, Manchester, M24 1UN,  
United Kingdom - [info@pdtuk.com](mailto:info@pdtuk.com) - Copyright PDT Ltd. © 2023