说明书归档首页

说明书编号:	P00825Q			版	(本号:	V02			
	□ 全新编制	适用产品	品序列:						
		适用机型系列:							
		衍生产品序列:			日立大天埋出口机(1PH,208-230V~				
				60	OHz				
		衍生机?	型系列:	RI	PI-8.0FSNQ	H、RP	I-10.0FSN	NQH	
	■ 衍生机型	源产品原	亨列:	海	存信大天埋	出口机	L(1PH, 2	08-2	30V \sim
				60	OHz				
编制说明		源机型:	系列:	А١	VD-76UX2S	FH 、A	VD-96UX	(2SFI	Н
(首版编制时请		源说明-	书编号:	P(00804Q		版本号	:	V01
填写)	□ 临时对应	对应简单	要说明:						
		源说明-	书编号:				版本号	:	
	签字区	签名				日期		_	
	设计:	宋旭彤				15.0	3.25		
	审核:	陈林				15.0	3.27		
	标准化:	霍艳萍				15.0			
	批准	前田宪作				15.0	15.03.30		
	标记 管理编		日期:		更改:	审核	:	•	
	⚠×1 BZ/KF1 5				宋旭彤	陈木	沐	前田	完作
	_	804-216 18.04.08			张利娜	陶友	淘	邓玉	平
变更履历	<u> </u>							·	
(变更说明书时	Δ×								
请填写)	Δ×								
	<i>ⓑ</i> ×								
	Δ×								
	变更内容简要抗	 #				渋 乃	.页码		
	增加二维码、更新公司落款								
	垣加二年時、史제公可洛叔					封面封底			
本次变更									
内容简述									
	担当联络方式	0532-80	879310			1			
备注	邮箱			<u>c</u> h	itachi.com				
田 1上	HHAL	ZHAHŞIIII	ما العادات م	اات	reactific COIII				
		Ì							

HITACHI

Operation Installation & Maintenance Manual


INVERTER-DRIVEN
MULTI-SPLIT SYSTEM
HEAT PUMP
AIR CONDITIONERS

- INDOOR UNIT -

Туре	Model
CEILING DUCTED TYPE	RPI-8.0FSNQH RPI-10.0FSNQH



READ AND UNDERSTAND THIS MANUAL BEFORE USING THIS HEAT-PUMP AIR CONDITIONERS. KEEP THIS MANUAL FOR FUTURE REFERENCE.



P00825Q

IMPORTANT NOTICE

- HITACHI pursues a policy of continuing improvement in design and performance of products. The right is therefore reserved to vary specifications without notice.
- HITACHI cannot anticipate every possible circumstance that might involve a potential hazard.
- This heat pump air conditioner is designed for standard air conditioning only. Do not use this heat pump air conditioner for other purposes such as drying clothes, refrigerating foods or for any other cooling or heating process.
- The installer and system specialist shall secure safety against leakage according to local regulations or standards. The following standards may be applicable if local regulations are not available. British Standard, BS4434.
- No part of this manual may be reproduced without written permission.

Signal words (DANGER, WARNING and CAUTION) are used to identify levels of hazard seriousness.
 Definitions for identifying hazard levels are provided below with their respective signal words.

A DANGER

Immediate hazards which WILL result in severe personal injury

or death.

AWARNING

Hazards or unsafe practices which COULD result in severe personal

injury or death.

ACAUTION

Hazards or unsafe practices which COULD result in minor personal

injury or product or property damage.

NOTE: Useful information for operation and/or maintenance.

- It is assumed that this heat pump air conditioner will be operated and serviced by English speaking people. If this is not the case, the customer should add safety, caution and operating signs in the native language.
- If you have any questions, contact your distributor or dealer of HITACHI.
- This manual gives a common description and information for this heat pump air conditioner which you
 operate as well as for other models.
- This heat pump air conditioner has been designed for the following temperatures. Operate the heat pump air conditioner within this range.

Temperature (°C)

		Maximum	Minimum
Cooling	Indoor	32 DB/23 WB	21 DB/15 WB
Operation	Outdoor	43 DB	-5 DB
Heating	Indoor	27 DB	15 DB
Operation	Outdoor	15 WB	-15 WB*1

*1: -10 WB ~ -15 WB: Operation Control Range

DB: Dry Bulb, WB: Wet Bulb

This manual should be considered as a permanent part of the air conditioning equipment and should remain with the air conditioning equipment.

IMPORTANT NOTICE



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

CHECKING PRODUCT RECEIVED

- Upon receiving this product, inspect it for any shipping damage.
 Claims for damage, either apparent or concealed, should be filed immediately with the shipping company.
- Check the model number, electrical characteristics (power supply, voltage and frequency) and accessories to determine if they are correct.

The standard utilization of the unit shall be explained in these instructions.

Therefore, the utilization of the unit other than those indicated in these instructions is not recommended. Please contact your local agent, as the occasion arises.

HITACHI's liability shall not cover defects arising from the alteration performed by a customer without HITACHI's consent in a written form.

TABLE OF CONTENTS

Section1 Operation Manual

1.	Safety Summary	1
2.	System Description	1
3.	Remote Control Switch	2
4.	Before Operation	3
5.	Operation Method	3
6.	Automatic Control	3
7.	Troubleshooting	4
	7.1 If Trouble Still Remains	
	7.2 No Operation	4
	7.3 Not Cooling or Heating Well	-
	7.4 This is Not Abnormal	4
	ection2 Installation & Maintenance Manual	
1.	Safety Summary	5
2.	Structure	5
	2.1 Indoor Unit & Refrigerant Cycle ······	5
	2.2 Necessary Tools and Instrument List for Installation	5
3.	Transportation and Handling ······	5
	3.1 Transportation ·····	5
	3.2 Handling of Indoor Unit	5
4.	Indoor Unit Installation	6
	4.1 Factory-Supplied Accessories	6
	4.2 Initial Check ·····	7
	4.3 Installation ·····	7
5.	Refrigerant Piping Work ·····	10
	5.1 Piping Materials	10
	5.2 Piping Connection	10
6.	Drain Piping	11

7.	Ele	ectric	cal Wiring ·····	12
	7.1	1	General Check ·····	12
	7.2	2	Electrical Wiring Connection ·····	12
8	. 1	Test	Run ·····	13
9	. 8	Safet	ty and Control Device Setting ·····	13
10). (Comr	mon	14
	1	10.1	Field Minimum Wire Size for Power Source Line	14
	1	10.2	Setting of DIP Switch	15

Section 1 Operation Manual

1. Safety Summary

ADANGER

- Do not pour water into the indoor or outdoor unit. These products are equipped with electrical parts. If poured, it will cause a serious electrical shock.
- Do not touch or adjust safety devices inside the indoor or outdoor units. If these devices are touched or readjusted, it may cause a serious accident.
- Do not open the service cover or access the indoor or outdoor units without turning OFF the main power supply.

AWARNING

- Refrigerant leakage can cause difficulty with breathing due to insufficient air.
 If leakage occurs, turn OFF the main switch, put out fire at once and contact your service contractor.
- Do not use any sprays such as insecticide, lacquer, hair spray or other flammable gases within approximately one (1) meter from the system.
- If earth leakage breaker (ELB) or fuse is often activated, stop the system and contact your service contractor.

ACAUTION

- The appliance is not to be used by children or person with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised that they do not play with the appliance.
- The appliance should not be installed in the laundry.

NOTE

 It is recommended that the room be ventilated every 3 to 4 hours.

2. System Description

A maximum total capacity of 130% and a minimum total capacity of 50% can be chosen by combination of the indoor units (Table 2.1).

The heat pump air conditioner is designed to offer cooling, heating, dry and fan operations. These operation modes are controlled by the remote control switch (optional).

Table 2.1 Line-up of Indoor Unit

Capacity (HP)	8.0	10.0
Model	RPI-8.0FSNQH#V2/H	RPI-10.0FSNQH#V2/H

3. Remote Control Switch

ACAUTION

Press switches only with fingers. Do not press switches by any other item, as it may break switches.

Do not touch the CHECK switch. This switch is only for servicing. If touched, press the CHECK switch again to reset.

Temperature Setting

When the TEMP switch is pressed, temperature increases by 1 degree. The minimum setting indication is 17°C and the maximum setting indication is 30°C.

Set and Actual Temperature

The set temperature is for the air temperature at the sensor (thermistor) of the indoor unit. The actual room temperature may be different

from the air temperature of the sensor due to the difference of the sensing location.

Touching Type Switches

This control switch is of touching type. Slightly press the switch by finger. The operation can be checked by the display of the liquid crystal.

Multiple-Unit Control

16 indoor units, as a maximum number, can be controlled by one remote control switch.

Refer to the Installation Manual for Remote Control Switch.

4. Before Operation

ACAUTION

Supply electrical power to the system for approximately 12 hours before start-up after long shutdown. Do not start the system immediately after power supply, it may cause a compressor failure, because the compressor is not heated well.

Make sure that the outdoor unit is not covered with snow or ice. If covered, remove it by using hot water (approximately 50°C). If the water temperature is higher than 50°C, it will cause damage to plastic parts.

When the system is started after a shutdown longer than approximately 3 months, it is recommended that the system be checked by your service contractor.

Turn OFF the main switch when the system is stopped for a long period of time. If the main switch is not turned OFF, electricity is consumed, because the oil heater is always energized during compressor stopping.

5. Operation Method

Regarding the instructions of Wired Remote Control Switch or Wireless Remote Control Switch, read the operation manual attached to the control switch.

6. Automatic Control

The system is equipped with the following functions.

NOTE

Except for a long period of shutdown, keep the main power switch ON. The drain discharge mechanism is operated if the drain level is higher than the setting.

- Three Minute Guard (Enforced Stoppage) The compressor remains off for at least 3 minutes once it has stopped. If the system is started within approximately 3 minutes after it has stopped, the RUN indicator is activated. However, the cooling operation or the heating operation remains off and does not start until after 3 minutes has elapsed.
- Three Minute Guard (Enforced Operation)
 If all indoor units of the system are ThermoOFF within approximately 3 minutes after
 compressor has started, compressor is
 operated during 3 minutes continuously.
 However, if all indoor units of the system are
 stopped by remote control switch, compressor
 is stopped.

Oil Return Operation

If an indoor unit is stopped more than 2 hours continuously, this function is operated during a few minutes.

It has this function to prevent to accumulate in the heat exchanger of stoppage indoor unit at cooling operation.

Frost Prevention During Cooling Operation
 When the indoor unit is operated at low
 discharge air temperature, the cooling
 operation may be changed to fan operation for
 a while to avoid frost formation on the indoor
 heat exchanger.

Hot Start During Heating Operation To prevent cold air discharge in the room, the fan speed is controlled from the slow position

fan speed is controlled from the slow position and the low position and then to the set position according to the discharge air temperature. At this time the louver is fixed horizontally.

Slow Air Control During Defrosting Operation

When the outdoor unit is performing the automatic defrosting operation, the indoor fan is stopped and the louver is fixed horizontally.

Cooling of Indoor Unit

When the heating operation is stopped, the indoor fan operation is maintained at the slow position for the maximum of 2 minutes to lower temperature of the inside unit.

Automatic Defrosting Cycle

When the heating operation is stopped by pressing RUN/STOP switch, frosting on the outdoor unit is checked and the defrosting operation may be performed for the maximum of 10 minutes.

Prevention of Overload Operation

When the outdoor temperature is high during heating operation, heating operation is stopped due to activation of the outdoor thermistor until the temperature becomes low.

NOTE

If the system is stopped due to a power failure, it will not automatically start again although power is restored.

Repeat the start-up procedure from Step 1 to start the system. In the event of a very brief power failure (2 seconds maximum), the settings are memorized.

Therefore, the system starts automatically after approximately 3 minutes.

7. Troubleshooting

ACAUTION

When overflow of drain water from the indoor unit occurs, stop the operation and contact your contractor.

When you smell or see white smoke coming from the unit, turn OFF the main power supply and contact your contractor.

7.1 If Trouble Still Remains ...

If the trouble still remains even after checking the following, contact your contractor and inform them of the following items.

- (1) Unit Model Name
- (2) Content of Trouble
- (3) Alarm Code No. on Liquid Crystal Display

7.2 No Operation

Check whether the SET TEMP is set at the correct temperature.

7.3 Not Cooling or Heating Well

- Check for obstruction of air flow of the outside or inside units.
- Check if too much heat source exists in the room.
- Check if the air filter is clogged with dust.
- Check to see if the doors or windows are opened or not.
- Check if the temperature condition is not within the operation range.

7.4 This is Not Abnormal

Smells from Indoor Unit

Smell adheres on indoor unit after a long period of time. Clean the air filter and panels or allow a good ventilation.

Sound from Deforming Parts

During system starting or stopping, an abrading sound might be heard. However, this is due to thermal deformation of plastic parts. It is not abnormal.

Steam from Outdoor Heat Exchanger
 During defrosting operation, ice on the outdoor heat exchanger is melted, resulting in making steam.

Dew on Air Panel

When the cooling operation continues for a long period of time under high humidity conditions (higher than 27°C/80% R.H.), dew can form on the air panel.

Refrigerant Flow Sound

While the system is being started or stopped, sound from the refrigerant flow may be heard.

NOTE

Except for a long period of shutdown, keep the main switch ON, since the oil heater is energized when the compressor is stopping.

Section 2 Installation & Maintenance Manual

1. Safety Summary

AWARNING

- Do not perform installation work, refrigerant piping work, drain piping and electrical wiring connection without referring to the installation manual.
- Check that the ground wire is securely connected.
- Connect a fuse of specified capacity.
- Pay a special attention to the place, such as a basement, etc. where refrigerant can stay, since refrigerant is heavier than air.

ACAUTION

Do not install the indoor unit, outdoor unit, remote control switch and cable within approximately 3 meters from strong electromagnetic wave radiators such as medical equipment.

2. Structure

2.1 Indoor Unit & Refrigerant Cycle

Regarding the structural drawings and the refrigerant cycle diagrams, refer to Technical Catalogue.

2.2 Necessary Tools and Instrument List for Installation

No.	Tool	No.	Tool
1	Handsaw	11	Spanner
2	Screwdriver	12	Charging Cylinder
3	Vacuum Pump	13	Gauge Manifold
4	Refrigerant Gas Hose	14	Cutter for Wires
5	Megohmmeter	15	Gas Leak Detector
6	Copper Pipe Bender	16	Leveller
7	Manual Water Pump	17	Clamper for Solderless Terminals
8	Pipe Cutter	18	Hoist (for Indoor Unit)
9	Brazing Kit	19	Ammeter
10	Hexagon Wrench	20	Voltage Meter

NOTE

About vacuum pump, gas hose, charging cylinder, gauge manifold, please use suitable equipments for R410A respectively or R22 respectively. Do not mix other refrigerant.

3. Transportation and Handling

3.1 Transportation

Transport the product as close to the installation location as practical before unpacking.

ACAUTION

Do not put any material on the product.

3.2 Handling of Indoor Unit

AWARNING

Do not put any foreign material into the indoor unit and check to ensure that none exists in the indoor unit before the installation and test run. Otherwise, a fire or failure, etc. may occur.

ACAUTION

Be careful not to damage on insulation materials of unitis surface when lifting.

4. Indoor Unit Installation

A DANGER

Do not install the indoor unit in a flammable environment to avoid fire or an explosion.

AWARNING

- Check to ensure that the ceiling slab is strong enough. If not strong enough, the indoor unit may fall down on you.
- Do not install the indoor unit outdoors. If installed outdoors, an electric hazard or electric leakage will occur.

It is recommended that indoor units be installated higher than 2.5 meters from the floor level.

4.1 Factory-Supplied Accessories

Check to ensure that the following accessories are packed with the indoor unit.

NOTE

If any of these accessories are not packed with the unit, please contact your contractor.

Table 4.1 Factory-Supplied Accessories

Access	sory	Q'ty	Purpose
Washer		8	For Unit Suspension
Hose Clamp	600	1	For Drain Hose Connection
Insulation (26 IDx105)		1	For Refrigerant Liquid Piping
Insulation (28 IDx85)		1	For Refrigerant Gas Piping
Cord Clamp	CHARLES OF THE PARTY OF THE PAR	8	For Fixing Thermal Insulation for Refrigerant Pipings

4.2 Initial Check

 Install the indoor unit with a proper clearance around it for operation and maintenance working space, as shown in Fig. 4.1.




Fig. 4.1 Operation and Installation Space

- Consider the air distribution from the indoor unit to the space of the room, and select a suitable location so that uniform air temperature in the room can be obtained.
- Do not install flammable parts in the service space for the indoor unit.
- Avoid obstacles which may hamper the air intake or the air discharge flow.
- Do not install the indoor unit in a machine shop or kitchen where vapor from oil or its mist flows to the indoor unit.

The oil will deposit on the heat exchanger, thereby reducing the indoor unit performance, and may deform and in the worst case, break the plastic parts of the indoor unit.

- Pay attention to the following points when the indoor unit is installed in a hospital or other facilities where there are electronic waves from medical equipment.
 - (A) Do not install the indoor unit where the electromagnetic wave is directly radiated to the electrical box, remote control cable or remote control switch
 - (B) Install the indoor unit and components as far as practical or at least 3 meters from the electromagnetic wave radiator.
 - (C) Prepare a steel box and install the remote control switch in it. Prepare a steel conduit tube and wire the remote control cable in it. Then, connect the ground wire with the box and the tube.

- (D) Install a noise filter when the power supply emits harmful noises.
- To avoid any corrosive action to the heat exchangers, do not install the indoor unit in an acid or alkaline environment.

AWARNING

Check to ensure that the number of below is within 0.3kg/cm³. Otherwise it may cause danger situation if the refrigerant in the Outdoor Unit leaks into the room where this Indoor Unit is installed.

(Total Refrigerant Quantity per one Outdoor Unit)

(Volume of the room where this Indoor Unit is installed.) ≤0.3kg/m³

In detail, refer to the Installation Manual for outdoor unit.

4.3 Installation


4.3.1 Suspension Bolts

Step 1

Select final location and installation direction of the indoor unit paying careful attention to the space for the piping, wiring and maintenance.

Step 2

Mount suspension bolts, as shown in Fig. 4.2





• For Wooden Beam Suspension



Fig. 4.2 Mounting of Suspension Bolts

- 4.3.2 Marking of the Positions of the Sling Bolts and Piping Connections
- (1) Mark the positions of the sling bolts, refrigerant piping connections and drain connection.
- (2) Installation dimensions are shown in Fig 4.3.








Fig. 4.3 Suspension Bolts

Model (HP)	а	b	С	d	е	f	g	h
8.0 10.0	1250	1288	1106	1100	20	1000	21	1050

4.3.3 Mounting the Indoor Unit

Hang the indoor unit as shown in Fig. 4.4.

Field-Supplied Parts

*Sling Bolts 4-M10 or W3/8
*Nut 8-M10 or W3/8




Fig. 4.4 Hanging Indoor Unit

How to put Nuts or Sling Bolts
 Put nuts on each of the four hanging bolts, as shown in Fig. 4.5




Fig. 4.5 Sling Bolts and Nut

- (2) Hanging the Indoor Unit
- * Hook suspension bracket to the nut and washer of each hanging bolt, as shown, starting at the opposite side to service cover side.
- * After checking that the nut and washer are correctly fixed by the retainers of the suspension bracket, hook the suspension bracket of the service cover side to the nut and washer.

(Put the sling bolts away from the unit when hooking.)




Fig. 4.6 Hanging Indoor Unit

4.3.4 Adjusting of the Unit Level

(1) Check to ensure that the foundation is flat, taking into account the maximum foundation gradient.




Fig. 4.7 Foundation Gradient

- (2) The unit should be installed so that the rear side of the unit is slightly (0mm~5mm) lower than the front side, in order to avoid the incorrect position of the drain discharge.
- (3) Tighten the bolts of the sling nuts with the suspension brackets after adjustment is completed.

Special plastic paint must be applied to the bolts in order to prevent them from loosening.

NOTE

Keep the unit as well as relevant equipment covered with the vinyl cover during installation work.

4.3.5 Connecting Supply Duct

- (1) The supply duct should be connected with the indoor unit through canvas ducts, in order to avoid abnormal sound vibration (Refer to Fig. 4.8). The unit is equipped with a pre-drilled duct flange for the supply duct connection.
- (2) Attach the vibration proof rubber to Sling Bolt in order to avoid abnormal sound vibration.
- Duct material should be non-flammable material.
- (4) Perform the heat insulation work over the duct for dew protection.

ACAUTION

- If a lower sound level is further required, install silencer (field-supplied).
- Design duct arrangement as "Unit External Static Pressure=Pressure Drop of Duct+Pressure Drop of Air Outlet and Air Inlet".

If duct design is not appropriate, big sound and splash will occur.




Fig. 4.8 Duct Connection

5. Refrigerant Piping Work

A DANGER

Do not charge oxygen, acetylene or other flammable and poisonous gases into the refrigerant cycle when performing a leakage test or an air-tight test. These types of gases are extremely dangerous and can cause an explosion. It is recommended that compressed air, nitrogen or refrigerant be used for these types of tests.


- 5.1 Piping Materials
 - (1) Prepare locally-supplied copper pipes.
 - (2) Select clean copper tubes making sure there is no dust and moisture inside the tubes.

Before connecting pipes, blow the inside of the tubes with nitrogen or dry air, to remove any dust or foreign materials.


5.2 Piping Connection

ACAUTION

- Cap the end of the pipe when the pipe is to be inserted through a hole.
- Do not put pipes on the ground directly without a cap or vinyl tape at the end of the pipe.




 An excess or a shortage of refrigerant is the main cause of trouble to the units.
 Charge the correct refrigerant quantity.



			mm(in.)
Model (HP)	А	В	С
8.0	Ф19.05(3/4)	Ф9.53(3/8)	VP 25
10.0	Ф22.2(7/8)	Φ9.53(3/8)	VI 20

Fig. 5.1 Position of Piping Connection

** Flaring Dimension (Only for R410A or R407C)
 **Perform the flaring work as shown below.




Diameter	A ⁺⁰ _{-0.4}			
φD	R410A	R407C		
6.35	9.1	9.0		
9.53	13.5	13.0		
12.7	16.5	16.2		
15.88	19.5	19.4		
19.05	24	23.3		

(*)It is impossible to perform the flaring work with 1/2H material. In this case, use an accessory pipe(with a flare).

ACAUTION

 Cut the pipe end before blazing to remove the cap, and discharge gas inside the pipe.
 If not discharged, blazing material will be blown off.



- Pay attention so that the flame does not come into contact with the main body itself.
 - (2) When brazing the refrigerant pipes, be sure to blaze, after covering the part with shown below a wet cloth to the insulation pipes of the units in order to prevent the thermistors on liquid and gas pipes from damaging by heating.






Fig. 5.2 Blazing Pipes

(3) After blazing, insulate the pipes after checking that there is no leakage. At that time, be sure to cover the space between two insulating peaces by insulation pipe (factory-supplied accessory).









Fig. 5.3 Insulating Pipes

(4) Evacuation and refrigerant charging procedures should be performed according to "Installation & Maintenance Manual" of the outdoor unit.

6. Drain Piping

- (1) The position of the drain piping connection is shown in Fig. 6.1.
- (2) Prepare polyvinyl chloride pipe with a 32mm outer diameter.
- (3) Fasten the tube to the drain hose with the adhesive agent and the factory-supplied clamp. The drain piping must be performed with a DOWN-SLOPE pitch of 1/25 to 1/100.
- (4) Insulate the drain pipe after connecting the drain hose.



 Do not connect the drain-hose to the drain outlet pipe of indoor unit BY ADHESIVE.
 If used, the servicing of drain-up mechanism is not available, and drain outlet pipe of indoor unit may be cracked due to invasion of the adhesive.
 But other pipe connecting part, use vinyl chloride type adhesive.




Fig. 6.1 Drain Piping

NOTE

When the relative humidity of inlet or ambient air exceeds 80%, apply an (field-supplied) auxiliary drain pan beneath the indoor unit as shown in Fig. 6.3.




Fig. 6.3 Auxiliary Drain Pan

NOTE

- (1) Do not create an upper-slope or rise for the drain piping, since drain water can flow back to the unit and leakage to the room will occur when the unit operation is stopped.
- (2) Do not connect the drain pipe with sanitary or sewage piping or any other drainage piping.
- (3) When the common drain piping is connected with other indoor units, the connected position of each indoor unit must be higher than the common piping. The pipe size of the common drain pipe must be large enough according to the unit size and number of units.
- (4) After performing drain piping work and electrical wiring, check to ensure that water flows smoothly as in the following procedure. Checking with the Float Switch
 - a. Switch ON the power supply.
 - b. Pour 2 or 2.5 liters of water into the drain pan.
 - c. Check to ensure that the water flows smoothly or whether no water leakage occurs. When water cannot be found at the end of the drain piping, pour another 2 liters of water into the drain.

7. Electrical Wiring

AWARNING

- Turn OFF the main power switch to the indoor unit and the outdoor unit before electrical wiring work or a periodical check is performed.
- Check to ensure that the indoor fan and the outdoor fan have stopped before electrical wiring work or a periodical check is performed.
- Protect the wires, drain pipe, electrical parts, etc. from rats or other small animals.
 If not protected, rats may gnaw at unprotected parts and at the worst, a fire will occur.
- Tighten screws according to the following torque.

M3.5: 1.2 N-m M5: 2.0~2.4 N-m

ACAUTION

 Wrap the accessory packing around the wires, and plug the wiring connection hole with the seal material to protect the product from any condensate water or insects.

- Tightly secure the wires with the cord clamp inside the indoor unit.
- Secure the cable of the remote control switch using the cord clamp inside the electrical box.

7.1 General Check


- (1) Make sure that the field-selected electrical components (main power switches, circuit breakers, wires, conduit connectors and wire terminals) have been properly selected according to the electrical data given in "Technical Catalog I". Make sure that the components comply with National Electrical Code (NEC).
- (2) Check to ensure that the power supply voltage is within ±10% of the rated voltage.
- (3) Check the capacity of the electrical wires.

 If the power source capacity is too low, the system cannot be started due to the voltage drop.
- (4) Check to ensure that the ground wire is connected.
- (5) Power Source Main Switch Install a multi-pole main switch with a space of 3.5mm or more between each phase.

7.2 Electrical Wiring Connection

The electrical wiring connection for the indoor unit is shown in Fig. 7.2.

- Connect the cable of an optional remote control switch or an optional extension cable to the connectors on the printed circuit board inside the electrical box through the connecting hole in the cabinet.
- (2) Connect the power supply and earth wires to the terminals in the electrical box.
- (3) Connect the wires between the indoor unit and the outdoor unit to the terminals in the electrical box.
- (4) Tightly clamp the wires using the cord clamp inside the electrical box.



Remove the fixing screws for electrical box cover.




Fig. 7.2 Electrical Wiring Connection

8. Test Run

Test run should be performed according to "Installation & Maintenance Manual" of the outdoor unit.

AWARNING

- Do not operate the system until all the check points have been cleared.
 - (A) Check to ensure that the electrical resistance is more than 1 megohm, by measuring the resistance between ground and the terminal of the electrical parts. If not, do not operate the system until the electrical leakage is found and repaired.
 - (B) Check to ensure that the stop valves of the outdoor unit are fully opened, and then start the system.
 - (C) Check to ensure that the switch on the main power source has been ON for more than 12 hours, to warm the compressor oil by the crankcase heater.
- Pay attention to the following items while the system is running.
 - (A) Do not touch any of the parts by hand at the discharge gas side, since the compressor chamber and the pipes at the discharge side are heated higher than 90°C.
 - (B) DO NOT PUSH THE BUTTON OF THE MAGNETIC SWITCH(ES). It will cause a serious accident.

9. Safety and Control Device Setting

Indoor Unit

Model			8.0	10.0
For Evaporator Fan Motor Thermostat	Cut-Out Cut-In	ి చి	150 <u>±</u> 5 83 <u>±</u> 15	150 ± 5 83 ±15
For Control Circuit Fuse Capacity		А	5	5
Freeze Protection Thermostat	Cut-Out Cut-In	°C	0 14	0 14
Thermostat Differential		°C	2	2

10. Common

10.1 Field Minimum Wire Sizes for Power Source

AWARNING

- Use an ELB (Electric Leakage Breaker). If not used, it will cause an electric shock or a fire.
- Run through the cables using conduit tube, and completely seal the end of conduit tube with sealing materials.

	Maximum	Power Source Cable Size	Transmtting Cable Size
Capacity	Current	EN60335-1 *1	EN60335-1 *1
8.0	11A	4.0mm²	0.75mm²

NOTES:

- 1) Follow local codes and regulations when selecting field wires.
- 2) The wire sizes marked with *1 in the above table are selected at the maximum current of the unit according to the European Standard, EN60335-1.Use the wires which are not lighter than the ordinary polyvinyl chloride sheathed flexible cord (code designation H05VV-F).
- 3) Use a shielded cable for the transmitting circuit and connect it to ground.
- In the case that power cables are connected in series, add each unit maximum current and select wires below.


According to EN 60335-1			
Current (A)	Wire Size (mm²)		
i≤6	2.5		
6 <i≤10< td=""><td>2.5</td></i≤10<>	2.5		
10 <i≤16< td=""><td>2.5</td></i≤16<>	2.5		
16 <i≤25< td=""><td>4</td></i≤25<>	4		
25 <i≤32< td=""><td>6</td></i≤32<>	6		
32 <i≤40< td=""><td>10</td></i≤40<>	10		
40 <i≤63< td=""><td>16</td></i≤63<>	16		
63 <i< td=""><td>%1</td></i<>	%1		

^{**1} In the case that current exceeds 63A, do not connect cables in series.

10.2 Setting of Dip Switches


(A) Position of Dip Switches

PCB for Indoor unit



- (B) The PCB in the indoor unit is equipped with 5 dip switches and 2 rotary switches. Before testing unit, set these dip switches according to the following instructions. Unless these dip switches are set in the field, the unit can not be operated.
- (1) Unit No. Setting(RSW1 & DSW6) Setting is required. Set the unit No. of all indoor units respectively and serially, by following setting position shown in the table below. Numbering must start from "0" for every outdoor unit.

Unit No. Setting



(2) Capacity Code Setting (DSW3) No setting is required, due to setting before shipment. This switch is utilized for setting the capacity code which corresponds to the capacity of the indoor unit.


Capacity	8.0	10.0	
Setting Position	0N 0FF 1 2 3 4	0N 0FF 1 2 3 4	

(3) Unit Model Code Setting (DSW4) No setting is required.



(4) Refrigerant Cycle No. Setting Setting is required.Setting position before shipment is all OFF.

Refrigerant Cycle No. Setting



(5) DSW7
*Factory Setting



*No.1 Pin: Fuse Recover When fuse is cut, turn No.1 Pin ON.



NOTE

The "
 mark indicates position of dip switches.
 Figures show setting before shipment.

ACAUTION

Before setting dip switches, firstly turn OFF power source and set the position of the dip switches. If the switches are set without turning OFF the power source, the switches can not function.



1055895

Qingdao Hisense Hitachi Air-conditioning Systems Co., Ltd.

Add: 218, Qianwangang Road, Economic & Technical Development Zone, Qingdao, P.R. China