

NIRO

hybrid / plug-in hybrid

Features & Functions Guide



Delivery First
The priority that delivers more

GETTING TO KNOW YOUR **NIRO PLUG-IN HYBRID**

Welcome to the Kia Family!

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and — above all — your satisfaction.

Using This Guide

The information contained in this guide is a brief overview that will help you become familiar with the operation and features of your new Kia vehicle. The flipbook format facilitates information access, while the detailed illustrations help to ensure the instructions are easy to follow.

This **Features & Functions Guide**, and the specific operational and safety information it provides, is not a substitute for your Owner's Manual. In the interest of your safety and that of the vehicle's occupants, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read your Owner's Manual in order to fully familiarize yourself with the important information it contains.

While Kia endeavors to ensure that the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance or after the fact, and assumes no liability in connection with such changes.

www.kia.com

Consumer - Roadside Assistance^{†13}
1-800-333-4KIA (4542)

See Back Pages for Vehicle
Maintenance Schedule

*Always check the Owner's Manual for complete
operating information and safety warnings.*

†LEGAL DISCLAIMERS ON BACK INSIDE COVER

As you get to know your new Kia, you can explore this booklet to better understand how to operate its many features and systems. You can find the complete Table of Contents on the next two pages, but first, be sure to review the following to better understand some of your Kia's most used features:

1	Smart Key / Remote Start*	55
2	Front Seat Headrest Adjustment / Power Adjustable Driver's Seat*	51-52
3	Seat Warmers*	50
4	Folding Rear Seats	53
5	Windshield Wipers & Washers	34
6	Smart Cruise Control (SCC)*	24
7	Normal Maintenance Schedule	Back Cover
8	User Settings – Instrument Cluster	09
9	Bluetooth® Wireless Technology	36-37
10	UVO link Activation* / UVO Assistance*	39
11	Standard Audio System - Value*	41
12	Standard Audio System - Value with UVO link*	42
13	UVO link	43
14	UVO link with Navigation*	44
15	Android Auto™ / Apple CarPlay® Setup	38

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Always check the Owner's Manual for complete operating information and safety warnings.



VIDEOS & QR CODES Inside Front Cover

INSTRUMENT CLUSTER

Instrument Cluster Overview	03
Indicators & Warning Lights	04
Tire Pressure Monitoring System (TPMS)	05
Hybrid / Plug-In Hybrid Indicators at Startup	06
Hybrid / Plug-In Hybrid Modes	06
Sport/ECO Modes	07
Fuel Economy	07

VEHICLE SETTINGS

Trip Modes / Trip Computer	08
LCD Instrument Cluster Modes*	08
User Settings - Instrument Cluster	09
Vehicle Settings* - Audio Head Unit	10
Service Interval Mode	11

HYBRID / PLUG-IN HYBRID SYSTEM

Plug-In Hybrid Display*	12
Instrument Cluster - Energy Flow	13
Emergency Starting* (Hybrid only)	15
Charging the Plug-In Hybrid Vehicle	16
Charging Connector Auto/Lock Mode	18
Scheduled Charging* (Plug-In Hybrid only)	18

ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS)

Forward Collision-Avoidance Assist (FCA)*	19
Lane Keeping Assist (LKA)*	20
Blind-Spot Collision Warning (BCW)*	22
Driver Attention Warning (DAW)*	22
Leading Vehicle Departure Alert (LVDA)*	23
Cruise Control	23
Smart Cruise Control (SCC) with Stop & Go*	24
Navigation-based Smart Cruise Control - Curve (NSCC-C)*	25
Lane Following Assist (LFA)*	26
Highway Driving Assist (HDA)*	27
Rear View Monitor (RVM)*	28

ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS) CONTINUED

Rear Cross-Traffic Collision Warning (RCCW)*	28
Reverse Parking Distance Warning (PDW)*	29

DRIVER'S PANEL

Instrument Cluster Control	30
Electronic Stability Control (ESC)	30
Hill-Start Assist Control (HAC)	30
Reverse Parking Aid Function*	31
Engine Start/Stop Button	31
Power Windows, Window Lock & Central Door Lock	32
Manual Folding Mirrors*	32
Automatic Door Lock/Unlock	32
Power/Heated Outside Mirrors*	32
Power Folding Outside Mirrors*	32

STEERING WHEEL CONTROLS

Headlights & High Beams	33
Turn Signals & Fog Lights*	33
Heated Steering Wheel Button*	34
Windshield / Rear Wipers & Washers	34
Tilt/Telescoping Steering Wheel	35

AUDIO SYSTEMS

Bluetooth® Wireless Technology	36
Audio Controls	37
Android Auto™ / Apple CarPlay® Setup*	38
UVO link Activation* / UVO Assistance*	39
Kia Access with UVO link App Download	40
Kia Access with UVO link App Features Guide	40
Standard Audio System - Value*	41
Standard Audio System* - Value with UVO link	42
UVO link*	43
UVO link with Navigation*	44

CENTER PANEL

Digital Clock	45
Multimedia USB Port, Charger Ports / AC Inverter*	45
Wireless Smartphone Charging System*	46

CENTER PANEL CONTINUED

Automatic Climate Control	47
Automatic Gear Shift with Sportmatic® Shifting	48
Dual Clutch Transmission	48
Paddle Shifters*	48
Electric Parking Brake (EPB)*	49
Auto Hold*	49
Seat Warmers / Ventilated Seats*	50

SEATING

Driver Position Memory System*	51
Front Seat Headrest Adjustment	51
Rear Occupant Alert (ROA) with Door Monitoring	51
Power Adjustable Driver's Seat*	52
6-Way Manual Adjustable Driver's Seat*	52
Folding Rear Seats	53

OTHER KEY FEATURES

Remote Keyless Entry (Folding Key)*	54
Smart Key / Remote Start*	55
Double-Turn Lock/Unlock All	55
Map/Room Lamps	56
Sunroof Operation*	56
Hood Release Lever and Latch	57
Fuel Filler Lid	57
Fuel Cap / Malfunction Indicator	57
Sunvisor	57
Liftgate Release Button*	58
High Voltage Battery Air Intake	58
Child-Protector Rear Door Locks	59
Tire Mobility Kit	59

SAFETY FEATURES


Occupant Detection System (ODS) / Passenger Airbag Off Indicator	60
Seat Belts	60

MAINTENANCE SCHEDULE Back Cover

LEGAL DISCLAIMERS Inside Back Cover

Instrument Cluster Overview


- A** Hybrid / Plug-In Hybrid system gauge
- B** Fuel gauge
- C** Speedometer
- D** Warning and indicator lights
- E** LCD display (including Trip computer)
- F** Hybrid / Plug-In Hybrid Battery SOC (State of Charge) gauge
- G** Distance to empty



Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 4 of the Owner's Manual.

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.

Indicators & Warning Lights



High Beam Indicator

Light ON Indicator

Front Fog Light Indicator*

Master Warning Indicator

FCA/FCW Indicator*

Lane Keeping Assist (LKA) Indicator

 Electronic Brake Force (EBD) System Warning Indicator
(Two separate indicators on Instrument Cluster lit at same time)

Immobilizer Indicator*

READY Indicator

EV Mode Indicator

ECO Indicator

SPORT Mode Indicator

Hybrid System Warning Indicator

Engine Coolant Temperature Warning

Engine Oil Pressure Warning Indicator

Charging System Warning Indicator

Seat Belt Warning Indicator

Malfunction Indicator

Low Tire Pressure Light / Tire Pressure Monitoring System (TPMS) Malfunction Indicator

Electronic Stability Control (ESC) Indicator / ESC Malfunction Indicator

Electronic Stability Control (ESC) OFF Indicator

Parking Brake & Brake Fluid Warning Indicator

Electronic Power Steering (EPS) Warning Indicator

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 4 of the Owner's Manual.

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.

Airbag Warning Indicator

Parking Brake Indicator

Anti-lock Braking System (ABS) Warning Indicator

Low Fuel Level Warning Indicator

CRUISE Cruise Indicator*

Trunk Open Warning Indicator

Door Ajar Warning Indicator

Regenerative Brake Warning Indicator (Two separate indicators on Instrument Cluster lit at same time)

SET Cruise SET Indicator

Icy Road Warning Indicator

LED Headlamp Warning Indicator*

Charging Cable Connection Indicator (Plug-In Hybrid)*

Tire Pressure Monitoring System (TPMS)^{†21}

 The TPMS indicator  functions as both Low Tire Pressure Light and TPMS Malfunction Indicator. The indicator  will illuminate if it detects one or more tires is significantly underinflated, the vehicle has a spare tire installed without TPMS or the outside temperature becomes significantly lower.

The LCD screen in the instrument cluster will display the Low Tire Pressure indicator  showing which tires are underinflated. Inflate tire(s) to specifications using an accurate digital tire pressure gauge to turn off Low Tire Pressure Light . See front driver's door jamb for PSI specification.

When there is a problem with the TPMS, the TPMS Malfunction Indicator  will blink for approximately one minute then illuminate – See dealer for service.


QUICK TIP

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on "cold tires" that have been sitting for 20 minutes, and tires that are not hot in temperature from direct sunlight or heat
- For proper maintenance and optimal fuel economy, maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- In winter or cold weather, the TPMS light may illuminate if the tire pressure was adjusted to the recommended tire inflation pressure during warm weather

REMINDERS:

- Check the recommended tire pressure label located on the left side of driver's door jamb, visible when the door is open
- Consult your dealer for service if Low Tire Pressure Light remains illuminated after inflating your tire(s)

Personal electronic devices (such as laptops, wireless chargers, remote start systems, etc.) may interfere with TPMS system, which may cause the Malfunction Warning Indicator (Check Engine Light) to illuminate.



QR CODES

Tire Pressure Monitoring System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


For more information, refer to section 6 of the Owner's Manual.

Hybrid/Plug-In Hybrid Indicators at Startup

- A Hybrid System Gauge** — Indicates how economically the vehicle is being driven.
 - **CHARGE (Blue zone):** High-efficiency range
 - **ECO (Green zone):** Normal-efficiency range
 - **POWER (Grey zone):** Low-efficiency range
- B EV Mode** — Illuminates when the electric motor is powering the vehicle.
- C Ready** — Illuminates when the hybrid system is operational. Even if the engine is off, the vehicle can be driven.
- D State of Charge (SOC)** — Displays the hybrid battery charge status.

REMINDER: Avoid starting or driving the vehicle when the fuel tank is empty. As the engine will be incapable of charging the high-voltage hybrid battery, the battery will lose its charge and may be damaged.

For more information, refer to the Owner's Manual.




Hybrid/Plug-In Hybrid Modes

To change the Plug-In Hybrid Mode, press the EV/HEV button **E** (PHEV only); switch between Electric (EV) mode and Hybrid (HEV) mode each time the button is pressed. The LCD on the Instrument Cluster will display the following messages:

- **EV Electric Mode - Charge Depleting:** The high-voltage (hybrid) battery is being used to drive the vehicle.
- **HEV Hybrid mode - Charge Sustaining:** The high-voltage (hybrid) battery and gasoline engine are being used to drive the vehicle.

For more information, refer to the Owner's Manual.



Sport/ECO Modes

The shift modes can be changed **A** between SPORT and ECO by moving the shift lever from D to the left gate and back:

(D) - ECO Mode

(S) - Sport Mode - When shift lever is moved into the left gate from (D). If shift lever is not moved through the gears, then the vehicle will shift automatically. Sport Mode changes the Niro's shift points and steering feel, and makes it more fun to drive

The LCD screen **B** on the instrument cluster will display the mode the vehicle is in.

ECO Mode (Active ECO)

Active ECO is designed to help improve fuel economy by controlling several vehicle components. When in ECO Mode, it is designed to optimize drivetrain operations, such as engine power and transmission, to help improve fuel economy in a variety of conditions.



QUICK TIPS

To help improve your fuel economy:

- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Be sure the wheels are properly aligned

REMINDER: Steering effort may be slightly increased in Sport mode.

Refer to section 5 in the Owner's Manual for more information.



(Located in Instrument Cluster)

Fuel Economy

There are several factors that contribute to your vehicle's fuel economy, such as maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics. Below are some tips on how to help improve fuel economy:

- Keep your vehicle in good condition with regular maintenance
- Don't let the engine idle longer than necessary
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicles
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

When the Instrument Cluster LCD screen is in the Trip Computer mode, the screen displays fuel economy information related to the driving range and average fuel economy.

To change modes, go to User Settings in the LCD Instrument Cluster modes.

Average Fuel Consumption - Calculates average fuel consumption from the distance driven and amount of fuel injected into the engine / total fuel used.

QR CODES

Fuel Economy Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to Section 4 in the Owner's Manual for more information.

Fuel Economy

Average 16.8 MPG




(Hybrid screen shown)

Trip Modes / Trip Computer

The Trip Computer is a driver information system that displays information related to driving. It appears on the display when the Engine Start/Stop button is in the ON position.

To cycle through the Trip modes, press the Mode button **A**.

When in the Trip Computer mode , press the Select/Reset (OK) button **B** to cycle through the screens. When displaying ACCUMULATED INFO, DRIVE INFO, DRIVING STYLE or FUEL ECONOMY screens, press and hold the OK button **B** to reset to zero.



REMINDERS:

- Appearance of Trip Computer display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected

For more information, refer to section 4 of the Owner's Manual.

LCD Instrument Cluster Modes*

Press Mode button **A** to scroll through different LCD Instrument Cluster Modes.



Trip Computer Mode: Displays driving information for tripmeter, fuel economy, MPH, energy flow, etc



Turn-by-Turn Mode*: Displays route guidance and destination info




Assist Mode: Displays information on Smart Cruise Control (SCC), Lane Safety, Lane Following Assist*, Driver Attention Warning (DAW) and others



User Settings Mode: Change settings of Driving Assist, Doors, Lights, Sound, Convenience, Service Interval and others



Master Warning: Displays warning messages related to the vehicle when one or more systems is not operating normally



(Buttons located on Steering Wheel – Type A shown)

Your vehicle's steering wheel buttons may differ from those in the illustrations.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering wheel mounted controls while driving.

For more information, refer to section 4 of the Owner's Manual.

QR CODES

Instrument Cluster's LCD Display Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

User Settings – Instrument Cluster

To enter the User Settings mode in the LCD Instrument Cluster Modes, ensure that the vehicle is at a standstill, put the shift lever in Park, and place the Engine Start/Stop button or Key in the ON position. Then press the Mode button **A** and select User Settings .

You can navigate the selections on the display by pressing the OK button **B** up/down and then select the item by pressing the OK button **B** again.

Driving Assistance*:

- Smart Cruise Control (SCC) Reaction
- Driving Assist
- Driver Attention Warning (DAW)*
- Warning Timing
- Forward Safety
- Lane Safety
- Blind-Spot Safety
- Parking Safety

Door:

- Automatically Lock & Unlock

Lights:

- One-Touch Turn Signal
- Ambient Light Brightness
- Ambient Light Color
- Headlamp Delay
- High Beam Assist

Sound:

- Parking Distance Warning/Volume

Convenience:

- Seat Easy Access*
- Welcome Mirror/Light*
- Wireless Charging System*

- Wiper/Light Display*
- Auto Rear Wiper
- Gear Position Pop-Up*
- Coasting Guide*
- Start Coasting*
- Icy Road Warning*

Service Interval:

- Enable Service Interval
- Adjust Interval
- Reset

Other features:


- Aux. Battery Saver+*
- Fuel Economy Reset*
- Speed Unit*
- Fuel Economy Unit*
- Temperature Unit*
- Tire Pressure Unit*

Language

- Language: Set the language

Reset

- Choosing reset will restore defaults for all User Settings menus



(Buttons located on Steering Wheel – Type B)

QR CODES

Vehicle & User Settings Video



Ambient, Mood & Theme Lighting Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to Section 4 in the Owner's Manual for more information.

Vehicle Settings* – Audio Head Unit

To enter the Vehicle Settings mode in the audio head unit **A**, press the SETUP key on the audio head unit. Then press **VEHICLE** , which will take you to Vehicle Settings. Use the touchscreen to navigate through the menus.

Vehicle Settings:

Driver Assistance:

- Driving Convenience*
- Warning Time*
- Warning Volume*
- Driver Attention Warning*
- Forward Safety*
- Lane Safety*
- Blind-Spot Safety*
- Parking Safety*
- Drive Mode
- Drive Mode Alert*

Climate*:

- Recirculate Air*
- Automatic Ventilation*
- Defog/Defrost Options*
- Climate Features*

Lights*:

- Ambient Light*
- One Touch Turn Signal*
- Headlight Display*
- High Beam Assist*

Door*:

- Auto Lock*
- Auto Unlock*
- Walk-Away Lock*
- Two-Press Unlock*
- Smart Trunk*

Cluster*:

- Service Interval*
- Energy Consumption Reset*
- Content Selection*
- Cluster Voice Guidance Volume*
- Welcome Sound*
- Theme Selection*

Convenience*:


- Rear Occupant Alert*
- Welcome Mirror Light*
- Wireless Charging System*
- Vehicle Auto-Shut Off*

Seat*:

- Seat Position Change Alert*
- Smart Posture Care*
- Heated/Ventilated Features*
- Seat Easy Access*
- Rear Seat Heating Control*

Reset:

- Reset Vehicle Settings to Factory Defaults



QR CODES

LCD Display: Maintenance Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to Section 4 in the Owner's Manual for more information.

Service Interval Mode

To enter Service Interval mode, press the Mode button **A**, User Settings , then scroll to Service Mode  and press the OK button **B**. System will display the number of miles remaining until next service is due, as well as the type of service.

When service is required, the following will be displayed:


Service Required

To reset the Service Interval mode system, press and hold the OK button **B** for more than 1 second. To turn Service Interval OFF, go to User Settings.

Service Interval Setting

To set the Service Interval when in User Settings mode:

- Press the OK button **B** up/down and scroll to Service Interval. Press the OK button **B** to enter
- Press the OK button **B** up/down and toggle to ON, then press the OK button **B** again. Then press the OK button **B** to scroll and select the desired miles or months for your next service
- Press the OK button **B** again



(Buttons located on Steering Wheel – Type B)

Service Required



0000 mi.

HOLD  RESET

Service in
Off



Service in



0000 mi.

HOLD  RESET

QR CODES

Fuel Economy Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to Section 4 in the Owner's Manual for more information.


Plug-In Hybrid Display*

The audio head unit screen provides information on economical operation and Plug-In Hybrid* system modes. To enter the Plug-In Hybrid display mode, press the ALL MENUS button on the Home screen. Then select one of the menus **A** - EV Range, Energy Information, Charge Management, ECO Driving, Energy Flow (Systems with Navigation only). Some examples are below:


A Plug-In Hybrid System Home Screen - Range, Energy Info, Charge Management, ECO Driving, Energy Flow



ECO Level - The more economically you drive, the more the ECO Level increases.



Energy Flow - Displays the current flow of power between the main powertrain components.



Fuel Economy - Displays the average fuel economy over the duration of a trip.

Eco Driving			
Fuel Economy	05-06-2019	27 mi	13.2 mpg
Fuel Economy History	05-04-2019	22 mi	12.9 mpg
	05-03-2019	14 mi	13.6 mpg
	05-02-2019	7 mi	12.3 mpg
	05-01-2019	18 mi	13.6 mpg


The images shown are for illustration purposes only. Not all available displays are shown. Screens may vary.

For more information, refer to the Owner's Manual or the Car Infotainment System Quick Reference Guide.


Instrument Cluster – Energy Flow

The instrument cluster LCD screen displays the following plug-in hybrid system modes to inform the driver of its status. To change modes, go to User Settings in the LCD Instrument Cluster modes.


EV Propulsion - The electric motor is moving the vehicle.




Engine-Only Propulsion - The engine is moving your vehicle.



Power Assist - Both the electric motor AND the engine are moving the vehicle.



Engine Generation - While the vehicle is stopped, the engine is charging the hybrid battery.




Plug-In Hybrid displays shown. The images shown are for illustration purposes only. Not all available displays are shown. Screens may vary.

For more information, refer to the Owner's Manual.


Instrument Cluster – Energy Flow

The instrument cluster LCD screen displays the following plug-in hybrid system modes to inform the driver of its status. To change modes, go to User Settings in the LCD Instrument Cluster modes.


Power Reserve - While the engine powers the vehicle, it is also recharging the hybrid battery.




Engine Brake/Regeneration - The regenerative braking system is recharging the hybrid battery.



Vehicle Stop - The vehicle's hybrid system is standing by.



Engine Generation/Regeneration - The engine and the regenerative braking system are both recharging the hybrid battery.



Plug-In Hybrid displays shown. The images shown are for illustration purposes only. Not all available displays are shown. Screens may vary.

For more information, refer to the Owner's Manual.

Emergency Starting* (Hybrid only)

Before Jump-Starting:

1. If the vehicle appears to have a dead battery, first press the 12V Battery Reset button **A**. Then immediately start the vehicle by pressing the brake and turning the ignition on or pressing the Engine Start/Stop button
2. If the vehicle does not start after completing the above steps, then jump-start the vehicle (as described below)

REMINDERS:


- After starting, idle or drive the vehicle for more than 30 minutes to help charge the 12V battery
- If the vehicle does not start immediately after pressing the 12V Battery Reset button **A**, then the power of the 12V battery is automatically disconnected to save any additional discharge
- Repeated use of the 12V Battery Reset button may cause over discharge which will prevent the vehicle from starting

Jump-Starting:


1. Remove the fusebox cover **B** under the front hood
2. The {+} jump start terminal **C** is located in the fuse box; the suitable ground point **D** is located in the engine compartment (See Owner's Manual for detailed description)
3. Connect cables coming from the battery booster source in the following order and disconnect in reverse order:
 - Connect the {+} clamp of your jumper cable to the {+} jump start terminal **C**
 - Connect the {-} clamp of your jumper cable to the suitable ground point **D**
4. Then immediately start the vehicle by pressing the brake and turning the ignition on or pressing the Engine Start/Stop button

REMINDER: Jump-starting your vehicle can be dangerous if done incorrectly. Follow the above jump-starting procedures to avoid harm to yourself or damage to your vehicle and any of its components. You should also consult your Owner's Manual for further detailed instructions for jump-starting your vehicle. If in doubt, we strongly recommend that you have a competent technician or towing service jump-start your vehicle.

For more information on Emergency Starting, please refer to section 6 of the Owner's Manual.



(Located in Driver's Panel to the left of Steering Wheel)



(Niro engine compartment shown, right side)

Charging the Plug-In Hybrid Vehicle (Plug-In Hybrid Only)

Level 1 Charging – “Trickle” Charge

A Level 1 or “trickle” charger is the most common type of charging system for a Plug-In Hybrid. This type of charger uses 110 volts of household electricity and takes up to 9 hours for a full charge.

Trickle Charger Indicators:

- A** 120VAC plug
- B** Power – When the charger and AC plug is plugged in and functioning normally, the indicator will turn green. Indicator is red if plug temperature sensor warning is present
- C** Charge – Indicates that the vehicle is charging
- D** Fault – Indicates charge failure
- E** Charge Level – Indicates the level of charge: L (8A), M (10A), or H (12A)
- F** ICCB – In-Cable Control Box

REMINDER: Do not use an extension cord. Plug trickle charger directly into wall socket. Do not charge to a receptacle that is old, damaged, corroded or cracked.

Level 2 Charging – “Normal” Charge

A Level 2 or “normal” 240-volt charger is the recommended charging system for the Plug-In Hybrid. This type of charger uses 240 volts of electricity and takes approximately 2.5-3 hours for a full charge (Based on Kia Motors Corporation testing with SAE J1772 charger performed at 3.3kW). This charger may be able to be installed at your home or found at a public charging station.

REMINDER: Shape of charger and how to use the charger may be different for each manufacturer. Please see Owner's Manual for more information.

QUICK TIP

A Level 2 or “normal” 240-volt charger is recommended for regular charging of the vehicle.


REMINDER: For more detail and/or subsequent steps in charging your vehicle, please see the Owner's Manual.

QR CODES

Niro EV Charging –
Connecting &
Disconnecting Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos



Charging the Plug-In Hybrid Vehicle (Continued)

To charge the Plug-In Hybrid vehicle using a normal/trickle charger:




1. Connect the ICCB **A** plug to an electrical outlet
2. Check if the power light (green) **B** on the ICCB turns on
3. Press the brake pedal and engage the parking brake
4. Turn off all switches, put the shift lever in P (Park), and turn off the vehicle
5. Open the charging door **E** by pressing the charging door (Ensure doors are unlocked)
6. Remove any dust or water on the charging connector and charging inlet **F**
7. Hold the charging connector handle **G** and connect it to the vehicle's charging inlet **F** by pushing the connector until you hear a clicking sound
8. Charging begins automatically (Ensure the charge indicator light **S** is illuminated on your instrument cluster, indicating the vehicle is charging)

Checking the Charging Status

The charging status can be checked by viewing the charging status indicator on the dash panel. The lights will progressively become lit as the vehicle approaches a full charge.

After charging has started, the light turns green and the estimated charging time is displayed on the Instrument Cluster LCD **H** for about 1 minute. It is also displayed when the driver's door is opened with charging in progress. When fully charged, the light turns off.

REMINDER: For more detail and/or subsequent steps in charging your vehicle, please see the Owner's Manual.



QR CODES

Niro EV Charging –
Connecting &
Disconnecting Video




Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Charging Connector Auto/Lock Mode (Plug-In Hybrid Only)

The Charging Connector can be set to be locked or unlocked while in the charging inlet. Press the AUTO button **A** (LED lit) for the connector to lock while charging and unlock automatically when charging is complete.

When the AUTO button **A** is not pressed (LED not lit), the mode will be set to LOCK. The connector will be locked when charging and remain locked until all doors are unlocked.



(Buttons are located left of the Steering Wheel)

QUICK TIPS

- If the auto/lock mode is set to lock and the vehicle is unlocked but charging cable is not disconnected within 10 seconds, the connector will be automatically locked again
- If charging connector is unlocked but all doors are locked again, immediately, the connector will be automatically locked again

Scheduled Charging* (Plug-In Hybrid Only)

Charging time can be set in the Plug-In Hybrid audio system home screen, under charge management, or using the Kia Access with UVO link app.

Charging with the UVO link Smartphone App:

The UVO link smartphone app can help you find the nearest charging station and displays charging-status and the Scheduled Charging information. On your Smartphone, go to an app store or marketplace to download the UVO link Smartphone app.

REMINDER: When Scheduled Charging is set and the charger is plugged in, charging will not begin until the set time & date are met to complete the charging. The green charge indicator on top of the dash will temporary flash ON/OFF to show that scheduled/reserve charging is set.

Deactivate Scheduled Charging - Depress the Deactivate Scheduled Charging button **B** to disable the scheduled charging feature when immediate charging is required.

QUICK TIP

When you press the Deactivate Scheduled Charging button the reserved charging setting will temporarily disable, and start immediate charging mode. If you need to completely deactivate the scheduled charge setting, change the setting from the audio control unit.

REMINDER: For more detail and/or subsequent steps in charging your vehicle, please see the Owner's Manual.

QR CODES

Niro EV Charging –
Connecting &
Disconnecting Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Forward Collision-Avoidance Assist (FCA)^{†6}

FCA is designed to detect and monitor a vehicle ahead or detect a pedestrian in the roadway through front view camera recognition and front radar signals to warn the driver that a collision is imminent and, if necessary, temporarily apply emergency braking. Initially, FCA provides Forward Collision Warning (FCW) when it detects a potential collision with a vehicle, pedestrian, or cyclist, emitting an audible warning and visual alert on the instrument cluster **A**.




If the system detects that the collision risk has increased, Forward Collision-Avoidance Assist (FCA) automatically applies the brakes to reduce your speed, potentially helping to reduce the effects of a possible collision.

FCA User Settings:

- FCA is ON by default in most Kia models. FCA can be turned ON/ OFF by going to the User Settings in the Instrument Cluster
- To go to User Settings , press the Mode button  **B** on the Steering Wheel when the vehicle is at a standstill, gear shift in Park and with the ignition on or the Engine Start/Stop button* in the ON position
- Press the OK button **C** up/down and select User Settings , then Driver Assistance
 - In some models, go to Driving Assist, then Forward Collision-Avoidance Assist or Forward Collision Warning and press the OK button **C**
 - In other models, go to Forward Safety and select Active Assist, Warning Only or Off
- Active Assist: Vehicle will provide a warning (audible & visual) and apply the brakes if needed
- Warning Only: Vehicle will provide a warning only (audible & visual)
- Off: System is off, no warnings or braking provided
- To adjust the FCA initial warning activation time, go to User Settings , Driver Assistance, Warning Timing, then select Normal, Early or Late, depending on your Kia model:
 - Early/Normal: Maximizes the amount of distance between the vehicles before the initial warning occurs
 - Late: Reduces the amount of distance between the vehicles before the initial warning occurs

FCA/FCW will become active when the:

- Ignition is on or the Engine Start/Stop button* is ON
- Vehicle is traveling faster than 5 mph
- Electronic Stability Control (ESC) is ON



REMINDERS:

- FCA will be activated by default when the ignition is cycled ON, even when previous setting was OFF
- If FCA is operating and ESC (Electronic Stability Control) is turned off, FCA system is automatically turned off
- When the FCA system is off, the FCA warning indicator is on in the Instrument Cluster 

Forward Collision-Avoidance Assist (FCA) is not a substitute for safe driving and may not detect all objects in front of the vehicle. Always drive safely and use caution.

Actual User Settings steps may vary by model. Refer to section 4 in the Owner's Manual for more information.

For illustrative purposes only. Your actual display, buttons and/or features may vary.

QR CODES

Forward Collision-Avoidance Assist (FCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIP

FCA Warning Volume can be adjusted in the User Settings  in the Instrument Cluster or the Vehicle Settings* on the audio head unit. Go to Driver Assistance, then Warning Volume.

Lane Keeping Assist (LKA)*†6

Lane Keeping Assist (LKA) is designed to detect the lane markers on the road with a front view camera on the windshield, and may assist the driver's steering to potentially help keep the vehicle in the lane. When turned on, the instrument cluster indicator  will initially illuminate white when turned on. It will remain white when the vehicle is traveling slower than 40 mph or when the system does not detect the lane markers. When the system detects the lane markers and can assist the steering, the LKA icon will illuminate green.

If the LKA detects that you are moving outside of your lane, the system may give an audible warning and display Lane Departure Warning on the instrument cluster. If the vehicle continues to move outside of the lane, LKA may provide steering inputs, trying to prevent the vehicle from moving outside its lane.

LKA is the operating mode by default when the Lane Safety/LKA button*  is depressed to ON.

There are three available modes:

- **Active LKA** – Provides more frequent steering inputs than standard LKA
- **Lane Keeping Assist** – Guides driver to keep vehicle within lanes and provides steering inputs when vehicle is about to deviate from the lane
- **Lane Departure Warning** – Alerts driver when the system detects the vehicle leaving the lane. In this mode the system will not provide steering inputs

All systems will operate under the following conditions:

- The vehicle speed exceeds approximately 40 mph
- LKA recognizes both sides of the lane markers the vehicle is traveling in
- The vehicle is between the lane markers





When the LKA sensor detects the lane traveled in, both lanes are illuminated



When the LKA sensor does not detect the lane traveled in, the lanes are not illuminated



When the LKA sensor detects the vehicle moving outside of the lane being traveled in, a yellow indicator will illuminate either on the left or right lane (shown in both images above)



(Buttons are located left of the Steering Wheel)

QR CODES

Lane Keeping Assist (LKA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Lane Keeping Assist and Lane Departure Warning are not substitutes for safe driving and may not always alert the driver if the vehicle is driven outside of its lane. Always drive safely and use caution.

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Actual User Settings steps may vary by model. Refer to section 4 in the Owner's Manual for more information.

Lane Keeping Assist (LKA)*†6 (continued)

LKA User Settings:

- To turn LKA ON, with the ignition on or the Engine Start/Stop button* in the ON position, press the Lane Safety/LKA button* **A**. The instrument cluster indicator  will initially illuminate white indicating the system is on
- To turn LKA on in the user settings, go to the User Settings menu  in the Instrument Cluster, press the Mode button  **B** on the Steering Wheel when the vehicle is at a standstill, gear shift in Park and with the ignition on or the Engine Start/Stop button* in the ON position, and select User Settings 
- To switch between LKA modes (Lane Keeping Assist, Lane Departure Warning), go to User Settings  in the Instrument Cluster. Press the Move (OK) button **C** up/down, select desired setting and press the OK button **C**

QUICK TIP

The LKA Warning Volume can be adjusted in the User Settings  in the Instrument Cluster or the Vehicle Settings* on the audio head unit.


REMINDERS:

- LKA will not issue a warning if the turn signals or hazard lights are activated
- When the ignition is cycled, LKA will return to the previously set state
- Some models access settings through the Vehicle Settings in the audio head unit. Press the Setup hard key on the audio head unit, then **VEHICLE**  on the screen to enter Vehicle Settings


Lane Keeping Assist and Lane Departure Warning are not substitutes for safe driving and may not always alert the driver if the vehicle is driven outside of its lane. Always drive safely and use caution.

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Actual User Settings steps may vary by model. Refer to section 4 in the Owner's Manual for more information.



(Buttons are located left of the Steering Wheel)



(Buttons located on Steering Wheel – Type B)

Blind-Spot Collision Warning (BCW)*†6a

The BCW system uses radar sensors to help alert the driver in certain situations, such as if it detects an approaching vehicle in the driver's blind spot before changing lanes. The light on the BCW button **A** will illuminate when turned ON. The outside rearview mirror warning lights will also illuminate for 3 seconds.


The system will become active when the vehicle is traveling more than approximately 20 mph and will alert the driver if another vehicle is detected by the radar sensor.

1st-stage alert: When another vehicle is detected within the BCW system boundary **B**, or when a vehicle is detected within the boundary **C** approaches at a high speed, a yellow indicator will illuminate on the outside rearview mirrors.

2nd-stage alert: When 1st-stage alert is on and the driver activates a turn signal, a flashing yellow indicator will illuminate on the outside rearview mirrors and the system will sound an alert.


REMINDERS:

- The BCW system will only show a warning if the vehicle speed is more than 6 mph above the surrounding vehicles
- If the BCW is turned OFF and the ignition is cycled, the BCW system returns to ON



(Button located left of the Steering Wheel)

BCW is a supplemental system. Do not rely solely on this system, and always drive safely. Refer to sections 4/5 in the Owner's Manual for more information.



Driver Attention Warning (DAW)*†6b

DAW monitors the driving style of the driver and, in certain situations, can give a warning signal for the driver to take a break from driving.

DAW is set to ON by default. To turn DAW OFF, turn the ignition on and then select User Settings in the LCD Display on the Instrument Cluster. Then go to Driving Assist and select Driver Attention Warning. Set DAW to Normal or High Sensitivity.



Driver Attention Warning (DAW) modes:

Off: The DAW is deactivated **D**

Normal: The DAW alerts the driver of his/her fatigue level or inattentive driving practices

High Sensitivity: The DAW alerts the driver of his/her fatigue level or inattentive driving practices faster than Normal mode

If the DAW is activated, the DAW information will appear on the LCD Display **E** when you select the ASSIST mode **F**. A message, "Consider taking a break," appears on the LCD display and a warning sounds to suggest that the driver take a break when the driver's attention level is below one bar **F**.



REMINDERS:

- The setup of DAW will be maintained, as selected, when the ignition is cycled
- When activated, DAW does not display "Consider taking a break" message when the total trip driving time is less than 10 minutes
- DAW will enter a standby mode if the camera does not detect the lanes and/or the driving speed remains under 40 mph

QR CODES

Blind-Spot Collision Warning (BCW) Video



Driver Attention Warning (DAW) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Illustrations are for demonstration purposes only. Actual images or buttons on vehicle may vary.

Driver Attention Warning is not a substitute for safe driving and may not detect all instances of inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.

Leading Vehicle Departure Alert (LVDA)*†6a

Leading Vehicle Departure Alert is designed to inform the driver when the vehicle in front starts moving or departs from a stop. When LVDA is on, your vehicle is stopped, and LVDA detects that the leading vehicle is driving away, LVDA sounds an alert to let you know you can start driving. If no action is taken after the vehicle in front drives away, then a message **A** will appear on the Instrument Cluster LCD.

LVDA User Settings:

- To turn LVDA on, press the Mode **B** button on the Steering Wheel, and go to User Settings **E** in the Instrument Cluster. Press the Move (OK) button **C** up/down and select Drive Assistance, then press the OK button **C** to select. Go to Driver Attention Warning and then Leading Vehicle Departure Alert
- Some models access settings through the Vehicle Settings in the audio head unit. Press the Setup hard key on the audio head unit, then press **VEHICLE** **E** on the screen to enter Vehicle Settings

REMINDERS:



- When the ignition is cycled, the system returns to its previous state, on or off
- Always check the front of the vehicle and road conditions before departure

The Leading Vehicle Departure Alert system is not a substitute for safe and proper driving. Always drive safely and use caution.


Standard Cruise Control†18

- D CRUISE Control ON/OFF button:** Press to turn the Cruise Control ON/OFF
- E Resume Cruising Speed button:** Press up to resume or increase Cruising Speed
- F Set Cruising Speed button:** Press down to set or decrease Cruising Speed
- F Cruise Control CANCEL button:** To cancel Cruise Control setting, do one of the following:
 - Press the brake pedal
 - Press the CANCEL button

Refer to section 5 in the Owner's Manual for more information.



(Buttons located on Steering Wheel – Type B)



(Type A shown)

REMINDER: Standard Cruise Control is a part of Smart Cruise Control (SCC) and can be set as the operating mode. To switch from SCC to Standard Cruise Control, press and hold the Vehicle Distance button **G** for two seconds (the SCC system must not be activated to change modes). Repeat to switch back to SCC mode.

QR CODES

Leading Vehicle Departure Alert (LVDA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Images are for illustrative purposes only and may not reflect actual feature or operation.

Smart Cruise Control (SCC) with Stop & Go*†6a

The Smart Cruise Control with Stop & Go* system is designed to maintain a predetermined distance from vehicles detected ahead by automatically adjusting the driving speed as needed. When traffic is detected, the vehicle will automatically slow to maintain a set distance between traffic without depressing the accelerator or brake pedal.

With the SCC on and activated and the vehicle distance set, when the system detects a vehicle slowing or stopping, it can bring the vehicle to a complete stop. When the vehicle ahead starts to move forward, the SCC system re-engages. If the vehicle ahead stops for more than 3 seconds, the accelerator pedal or the RES+ button must be pressed to start moving the vehicle.

On some models, press the Driving Assist Mode **CRUISE** button* on the Steering Wheel to activate and the speed will be set to the current vehicle speed. SCC may decrease the speed to maintain the distance with the vehicle in front.

To set/adjust the SCC speed:

- Push the Driving Assist **CRUISE** button* **A** to turn the system ON & set the current speed (One-Touch Set). The cruise indicator will illuminate on the instrument cluster
- Accelerate/decelerate to the desired speed and press lever **B** down to set the speed
- Press the RES+/SET- (+/-) button* **B** up/down to increase/decrease the set speed
- The SET indicator light, set speed and vehicle distance will illuminate on the instrument cluster's LCD screen **C**

To set the vehicle distance: Press the Vehicle Distance button **D** on the steering wheel. The image on the LCD screen **C** will change when scrolling through the settings. Each time the button is pressed, the vehicle distance changes.

To pause SCC operation: Press the **RES+/SET** button* **B**. The cruise indicator on the instrument cluster will turn OFF.


To turn SCC OFF: Press the Driving Assist **CRUISE** button **A**. The cruise indicator on the instrument cluster will turn OFF.

To adjust the sensitivity of the SCC system: Press the mode button **E** on the Steering Wheel. With the OK button **F**, select Driver Assistance, then SCC Response. Then select Fast, Normal or Slow.


To change the cruise control mode from SCC to standard cruise control, press and hold button **A**. Repeat to switch back to SCC mode (The SCC system must not be activated to change modes. Some Kia models use the CRUISE button).

The SCC system is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.


See section 5 in the Owner's Manual for more information. Images are for illustrative purposes only and may not reflect actual feature or operation.



(Type B Steering Wheel shown; buttons located on right side of Steering Wheel)



The distance settings are approximations and may vary depending on the vehicle speed at the time. See owner's manual for more information.



QR CODES

Smart Cruise Control with Stop & Go Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Smart Cruise Control (SCC) with Stop & Go^{*†6} (continued)

QUICK TIPS

- The speed setting for SCC can be adjusted under the following conditions:
- You must be traveling at a minimum speed of 20 mph (may vary on newer models)
- When following a vehicle, there is no minimum speed requirement
- When following a vehicle, the system can automatically adjust your cruise speed based on the vehicle detected ahead. If the vehicle detected ahead remains at a standstill and your vehicle is also stopped for longer than 3 seconds, the system will need to be reactivated by pressing the gas pedal or pressing the RES button

REMINDERS:

- The cruise control system will not activate until the brake pedal has been depressed at least once after the ignition is ON or engine starting
- When following a vehicle, the system will automatically adjust your cruise speed based on the vehicle detected in front
- SCC is also canceled when the driver's door is opened, gear shift is changed out of D (Drive), EPB is activated, and various other conditions. See the Owner's Manual for other conditions
- If SCC is left on, it can be activated inadvertently. Keep the system off when not in use to avoid setting a speed which the driver is not aware of
- SCC is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead

Navigation-based Smart Cruise Control – Curve (NSCC-C)^{*†6}

Navigation-based Smart Cruise Control - Curve (NSCC-C) can automatically adjust the vehicle speed when it detects a curved road ahead and when it receives road information from the navigation system.

To turn on NSCC-C, go to User Settings in the instrument cluster or Vehicle Settings^{*} in the audio head unit, by selecting Driving Convenience^{*}, Highway Auto Speed Change. When SCC is on and operating, driving on limited/controlled access highways and NSCC-C is turned on, then NSCC-C is enabled and the AUTO icon **A** will illuminate white on the Instrument Cluster.

When NSCC-C detects a curve ahead, activates and reduces the vehicle speed, the AUTO icon **A** will turn green. When the vehicle passes the curved road, the vehicle may return to its previously set SCC speed.


Autoset (Automatic change of set speed): If the set speed is set to the current speed limit on the highway during NSCC-C operation, the set speed is changed automatically whenever the speed limit changes.

REMINDERS:

- NSCC-C requires an active navigation subscription
- NSCC-C is only available on controlled access roads and highways

See section 5 in the Owner's Manual for more information. For more setting information, refer to the Car Infotainment System Quick Reference Guide.

NSCC-C is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.



(Display on LCD screen)

Lane Following Assist (LFA)*†6

Lane Following Assist (LFA) is designed to help ensure that the vehicle stays centered in its lane **A** by monitoring the detected lane markings ahead and adjust the steering. When turned on, the instrument cluster indicator will initially illuminate white **B** when turned ON, and on some vehicles, when SCC is engaged. It will remain white when the system does not detect the lane markers. When the system detects the lane markers and can assist the steering, the LFA icon will illuminate green **B**.

LFA will operate only when these conditions are met:



- When the SCC is on and operating
- LKA recognizes both sides of the lane markers the vehicle is traveling in
- The vehicle is traveling slower than 95 mph

LFA User Settings:

- To go to User Settings **E** in the Instrument Cluster, press the Mode button **C** on the Steering Wheel when the vehicle is at a standstill, gear shift is in Park and with the ignition on or the Engine Start/Stop button* in the ON position, and select User Settings **E**.
- To enable LFA, when in User Settings, press the Move (OK) button **D** up/down and Select Driver Assistance, then Driving Assist, and then Lane Following Assist. Press the OK button **D**.
- Some models access settings through the Vehicle Settings in the audio head unit. Press the SETUP hard key on the audio head unit, then **VEHICLE** **F** on the screen to enter Vehicle Settings
- Some vehicles have a Lane Driving Assist / Lane Safety button* on the Driver's Panel or the Steering Wheel **G**. Press to activate Lane Following Assist

REMINDERS:

- If the ignition is cycled, LFA returns to its previous state, on or off, if activated in the User Settings menu **E** and when combined with SCC. If using the Steering Wheel LKA button, then LKA defaults to off
- LFA is not a substitute for safe and proper driving. Always drive safely and use caution



(Buttons located on steering wheel)

QR CODES

Lane Following Assist (LFA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Images are for illustrative purposes only and may not reflect actual feature or operation.

LFA is supplemental. Do not solely rely on this system and always pay attention to the road and its conditions.

Actual User Settings steps may vary by model. See section 5 in the Owner's Manual for more detailed information, limitations and conditions.

Highway Driving Assist (HDA)*†6

Highway Driving Assist (HDA) is designed to adjust the speed of the vehicle when driving on limited/controlled access highways/freeways. The system can adjust the vehicle's speed based on available highway speed information. The automatic speed setting mode is designed to set the speed automatically by adjusting to the current speed limits of the highway the vehicle is traveling on.

To activate HDA, turn Smart Cruise Control (SCC) on by pressing the Driving Assist **CRUISE** / Driving Assist Mode  **CRUISE** button* **A** on the Steering Wheel. When HDA is activated and the conditions are met, the Instrument Cluster indicator **B** will illuminate green. If the conditions are not met, HDA will be in standby mode and the indicator light **B** will illuminate white. When in operation, and if both lanes are recognized, the Instrument Cluster will show the lanes illuminated white and the HDA indicator illuminated green **B**.

If HDA is activated, conditions are met and the SCC speed is set by the driver (at the posted highway speed limit or slower), HDA will enter the automatic speed setting mode. The set speed and AUTO will be displayed **C** in green and an audible alert will sound.

HDA will operate only when these conditions are met:

- The vehicle is traveling slower than 95 mph or the highway speed limit
- When driving on limited/controlled access highways/freeways
- When the SCC is on and operating
- When the SCC speed is set to current posted highway speed or slower



HDA User Settings:

To enable HDA, press the Mode button  **D** on the Steering Wheel and go to User Settings  in the Instrument Cluster. Press the Move (OK) button **E** up/down and press Driver Assistance, then Driving Assist, Highway Driving Assist. Then press the OK button **E** to enable.

Some models access settings through the Vehicle Settings in the audio head unit. Press the Setup hard key on the audio head unit, then press **VEHICLE**  on the screen to enter Vehicle Settings.

REMINDERS:

- Current highway speeds and controlled or limited access road information may vary. Future navigation updates may change this information
- If the driver changes the speed while in automatic speed setting mode, it deactivates and enters a manual mode
- When the ignition is cycled, the system returns to its previous state, on or off



QR CODES

Highway Driving Assist (HDA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Highway Driving Assist is not a substitute for safe driving, may not detect all objects around the vehicle, and only functions on certain federal highways. Always drive safely and use caution.


See section 5 in the Owner's Manual for more detailed information, limitations and conditions.

Rear View Monitor (RVM)*†6a

Rear View Monitor is a supplemental system that displays the view behind the vehicle through the rearview display mirror* while the vehicle is in Reverse.

Rear View Monitor activates when the:

- Engine Start/Stop button is in the ON/READY position
- Gear Shift Lever is in the R (Reverse) position



REMINDERS:

- UVO link — While camera is active, only the audio controls on the Audio System can be operated
- UVO link with Navigation — While camera is active, only the Audio System can be operated on the Steering Wheel and Audio Control Unit. All other features are disabled
- RVM may not display every object behind the vehicle

Rear View Monitor is not a substitute for proper and safe backing-up procedures.

Rear View Monitor may not display every object behind the vehicle. Always drive safely and use caution when backing up.

Refer to section 4 in the Owner's Manual for more information.


Rear Cross-Traffic Collision Warning (RCCW)*†6a

If the RCCW system sensors detect approaching vehicles from the rear left or rear right side of the vehicle **A**, the system will sound an audible alert, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the LCD screen. The RCCW system is active under the following conditions:

- When gear shift is in Reverse
- When the vehicle is moving slower than 6 mph

REMINDERS:

- The RCCW feature can be turned OFF/ON in User Settings
- The RCCW system will show a warning if the approaching vehicle speed is between 2.5-22 mph within sensing range. See Owner's Manual for other conditions



RCCW is a supplemental system. Do not rely solely on this system, and always drive safely.

Refer to section 4/5 in the Owner's Manual for more information.


Illustration is for demonstration purposes only. Actual images or buttons on vehicle may vary.

Reverse Parking Distance Warning (PDW)*†6a

Reverse Parking Distance Warning (PDW)* is a supplemental system that is designed to assist the driver by chiming if any object is detected within the sensing area in the rear and rear side of the vehicle when backing up.

PDW is activated when the ignition is ON/READY and the vehicle is in R (Reverse). To deactivate PDW, press the Reverse Parking Distance Warning (PDW) button **A** (LED NOT illuminated), when vehicle is in Drive or Reverse.

To activate, press button **A** again (LED illuminated).



REMINDERS:

- If the vehicle is moving at speeds over 3 mph, PDW may not activate correctly
- When more than two objects are sensed at the same time, the closest one will be recognized first
- Images are for illustration purposes only and may not reflect actual operation

QR CODES

Forward/Reverse
Parking Distance
Warning (PDW) Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Reverse Parking Distance Warning (PDW) is not a substitute for proper and safe parking and backing-up procedures. Always drive safely and use caution when backing up. Reverse Parking Distance Warning (PDW) may not detect every object in front of or behind the vehicle.


Refer to section 4 in the Owner's Manual for more information.

Instrument Cluster Control

Press switch **A** up or down to adjust display brightness of the instrument panel illumination.

REMINDERS:

- The dimmer does not change brightness when lights are turned off
- The dimmer does not adjust brightness on the audio system screens; use the system's setup menu to adjust brightness on the screens



Electronic Stability Control (ESC)⁺⁷

The ESC system is designed to help stabilize the vehicle during certain cornering maneuvers. It is a good idea to keep the ESC turned ON whenever possible.

Press ESC OFF button **B** to disable Traction Control in ESC (ESC OFF indicator will illuminate).

To turn both Traction Control and Stability Control^{†7} off, press and hold ESC OFF button **B** (ESC OFF indicator will illuminate, and an alert sounds).

REMINDERS:

- ESC is active by default at vehicle startup
- The ESC Indicator Light  in the instrument cluster will illuminate whenever the ESC is in operation

Refer to section 5 in the Owner's Manual for more information.

Hill-Start Assist Control (HAC)⁺⁷

HAC is designed to help prevent the vehicle from rolling backward when accelerating from a stop while on a steep incline.

HAC automatically activates whether the ESC is OFF or ON but does NOT activate when the ESC has malfunctioned.

REMINDERS:

- HAC does not operate when the gear shift is in the P (Park) or the N (Neutral) position
- In the event of HAC system malfunction, see Authorized Kia Dealer for service

QUICK TIPS

- When HAC is active (e.g., accelerating from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator. This is normal HAC operation
- HAC provides a 2-second delay before the vehicle may start rolling backward

HAC does not replace the need to apply brakes while the vehicle is stopped on an incline.

Refer to section 5 in the Owner's Manual for more information.

Reverse Parking Aid Function^{*†6a}


When the gear shift lever is moved into R (Reverse) and the vehicle is driven backwards, the outside rearview mirrors **A** will rotate downward to aid in reverse parking.

To turn ON the Reverse Parking Aid Function, depress either L or R mirror buttons **B**.

To turn OFF, depress the same buttons again.

The outside rearview mirrors will automatically return to their original positions when:

- The Engine Start/Stop button is in the OFF position
- The gear shift lever is moved to any position except R (Reverse)
- The L or R mirror buttons are not depressed



(Buttons panel located on Driver's Door)


REMINDER: When the outside rearview mirror buttons are not depressed, the Reverse Parking Aid Function will not operate and the outside rearview mirrors will not rotate downward.

Refer to section 4 in the Owner's Manual for more information.

Engine Start/Stop Button^{†8}

To start the engine:

1. Depress the brake pedal
2. Press the ENGINE START/STOP button while gear shift is in P (Park) or (N) Neutral



To turn the vehicle OFF, press the ENGINE START/STOP button.

To use the ENGINE START/STOP button, you must have the Smart Key fob on your person.

QUICK TIPS

To use electrical accessories:

ACC position

- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button once (amber light **C**)

ON position

- When already in the ACC position (amber light **C**) and without depressing the brake pedal, press the ENGINE START/STOP button again (red light **D**)
- When in the OFF position and without depressing the brake pedal, press the ENGINE START/STOP button twice (red light **D**)

Keeping the vehicle in ACC or ON position without turning the engine on may discharge the vehicle's battery.

REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the engine off and to the ACC position by pressing the ENGINE START/STOP button for more than 2 seconds or 3 times successively within 3 seconds
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the ENGINE START/STOP button (Lock button side closest) and press the button to start the engine

QR CODES

Engine Start/Stop Button Video



Kia Smart & Folding Key Fobs Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

Power Windows, Window Lock & Central Door Lock

- A** Pull/Press to operate Driver's and Front Passenger's Windows Auto-Up/Down*

QUICK TIP


Press the button again to stop Auto Up/Down function.

- B** Press to Unlock/Lock All Doors

- C** Press to disable Rear Passenger Windows

REMINDER: When pressed **C**, controls for the Rear Passenger Windows are disabled.

Refer to section 4 in the Owner's Manual for more information.




Manual Folding Mirrors*

To fold the mirrors in manually, pull the mirror towards the window.

QUICK TIP

If needed, pull the mirror firmly until it folds.

Refer to section 4 in the Owner's Manual for more information.



Automatic Door Lock/Unlock

Auto Door Lock/Unlock will engage when the gear shift is moved into or out of the P (Park) position. Refer to the User Settings in the LCD Instrument Cluster modes on how to turn Auto Door Lock/Unlock ON/OFF.

Power/Heated Outside Mirrors*

Mirror heaters automatically turn ON/OFF at the same time the Rear Window Defroster is turned ON/OFF. Rear Window Defroster button* is located on the climate control system panel.

Power Folding Outside Mirrors*

Press L or R buttons **D** (left or right) to select mirrors. Then press arrows **E** to adjust mirror position.

To both fold and unfold the outside rearview mirrors, press the folding mirror button **F** as pictured:

- Left – The mirrors will unfold
- Right – The mirrors will fold
- Center – The mirrors will fold/unfold automatically when doors are locked/unlocked with the Smart Key or a door handle button is pressed. Also, the mirrors will unfold when approaching the vehicle with the Smart Key fob in proximity

QUICK TIP

To automatically fold mirrors when exiting vehicle, press the LOCK button once on the Smart Key.

REMINDER: To lock position of mirrors, toggle switch to the neutral (center) position.

Refer to section 4 in the Owner's Manual for more information.

Headlights & High Beams

To operate:

- Rotate lever to change the Headlight function
- Push lever to turn High Beams ON
- Pull lever to flash Headlights/High Beams

High Beam Assist (HBA)* – The High Beam Assist is designed to automatically adjust the headlight range by switching between high and low beams based on light detected from oncoming vehicles and road conditions.

When switch is in the AUTO position and the vehicle's ignition or the Engine Start/Stop button* is on, the High Beam Assist will operate. To turn HBA off, change the switch setting.


AUTO Light position – When the light switch is in the AUTO Light position, the tail lights and headlights will turn ON/OFF automatically depending on the amount of light outside the vehicle.

Daytime Running Lights (DRL)* – DRL may help others to see the front of your vehicle during the day. The lights will be on automatically when the ignition or ENGINE START/STOP button* is ON and the headlight switch is in the AUTO position, unless one of the following occurs:

- Headlights are on
- Parking brake is applied
- Fog lights are on
- Engine is turned off

REMINDERS:

- High Beam Assist does not operate below certain speeds, or in some lighting and driving conditions. Please be aware of your surroundings and exercise proper road etiquette when operating a vehicle while using the high beams
- HBA will operate when vehicle speed exceeds 25 mph
- If the lever is pushed away from you while HBA is operational, HBA will turn off and the high beams will be on continuously. If the lever is pulled toward you while HBA is operational, HBA will turn off
- If the light switch is switched to the headlight position, HBA will turn off and low beams will be on continuously
- DRL only operates during the daytime
- The DRL system turns off when the headlights are ON, parking brake is applied or the front fog lights are turned on




Turn Signals & Fog Lights*

To operate:

- Turn Signals - Move lever Up/Down for Right/Left Turn Signal
- Fog Lights - Press switch **A** to turn Fog Lights ON/OFF

REMINDER: Headlights must be ON for Fog Light operation.



One-Touch Lane Change Signal is activated by briefly pressing the Turn Signal Lever slightly for less than 1 second and then releasing. The lane change signal will blink 3 times.


To change how many times (3/5/7) the Lane Change Signal blinks, go to User Settings Mode in the LCD Instrument Cluster modes.

Refer to section 4 in the Owner's Manual for more information.

Heated Steering Wheel Button*

Press button **A** to turn ON/OFF steering wheel heater while the ignition or Engine Start/Stop button is in the ON position.

Steering wheel heater will turn off automatically in 30 minutes, or when button is pressed again to deactivate. Steering wheel heater will turn ON or OFF automatically depending on the steering wheel temperature.



(Located below gear shift)

QUICK TIP

If ignition is cycled, the Heated Steering Wheel turns OFF. Press button again to turn ON.


REMINDER: If the steering wheel becomes too warm, turn the system off. The heated steering wheel may cause burns even at low temperatures, especially if used for long periods of time.

Refer to section 4 in the Owner's Manual for more information.

Windshield/Rear Wipers & Washers

To operate Windshield Wipers and Washers:

- Move lever Up/Down to change Wiper modes
- Press switch **B** Up/Down to adjust Intermittent Wipe Speed
- Pull lever to spray and wipe



QUICK TIPS

- Pressing lever up increases Intermittent wipe frequency and wipe speed. Pressing lever down decreases frequency of wipes
- Set the wiper to OFF position when the wiper is not in use
- LO and HI sets wiper speed. No intermittent wipe function on Rear Wipers

To operate Rear Wiper & Washer:

- Rotate Rear Wiper switch to change Wiper modes
- Push to spray and wipe

Refer to section 4 in the Owner's Manual for more information.

QR CODES

Wipers and Wipers
Stalk Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Tilt/Telescoping Steering Wheel†20

To adjust the Steering Wheel, push the lock-release lever **A** down and adjust the desired angle **B** and distance **C**.

When finished, pull the lock-release lever **A** up to lock Steering Wheel in place.


QUICK TIP

It may be helpful to pull/push bottom of Steering Wheel towards/away from you to adjust desired distance.



Bluetooth® Wireless Technology^{†5,18}

- A Volume button:** Press up/down to raise/lower speaker volume
 - Mute button:** Press to mute the microphone during a call
 - B Talk button:** Press to activate voice recognition/bring up menus/place calls with minimal voice command prompts from the system. Press and hold to exit voice recognition
- UVO link with Navigation system*** – When enrolled with a UVO link subscription, press this button to activate the UVO Voice Assist to use navigation guidance and search destinations
- C Receive/Place Call button:** Press to receive/place/answer calls. In vehicles with navigation, if no phone is paired, press button to pair a phone
 - D End Call button:** Press to end a call, reject an incoming call or cancel a function



(Type B shown)

QUICK TIPS

- Phone book transfer upload time varies by phone model and with the number of phone book entries
- When using the voice command feature, wait for the system BEEP before speaking the command
- Because of differences in phone quality, service providers and Bluetooth® Wireless Technology chip programming, functionality may differ from one phone to another
- The system may register or pair multiple Bluetooth® devices. See the Car Multimedia System User's Manual for more information on setup and limitations

Pairing a Phone

For instructions on how to pair a phone, refer to the Car Multimedia System User's Manual or your vehicle's Quick Start Guide.

QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for contacts download and to allow acceptance of all future Bluetooth® connection requests

How to Place a Call

- Option 1: Press the Receive/Place Call button **C** (displays the phone screen with call history)
- Option 2: Press the Talk button **B**. Then say the command "Call {name}" or "Dial {number}" followed by contact name or number

QUICK TIP

When using the voice command feature, wait for the system BEEP before speaking the command.

Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

For more information, if equipped, refer to the Car Multimedia System User's Manual. For Bluetooth® Wireless Technology FAQs, go to www.kia.com, Owners section, or call Consumer Information for Bluetooth® Technology at (800) 333-4KIA. Refer to your Owner's Manual for more specific Bluetooth® Wireless Technology phone pairing and operation instructions.

Bluetooth® Wireless Technology^{†5,18} (continued)

Voice Recognition and Phone Contact Tips

The system may have difficulty understanding some accents or uncommon names. Improve the performance by making a few simple changes to your phone contacts. To help optimize the *Bluetooth®* Wireless Technology Voice Recognition system, see other tips and reminders under Quick Tips.

- Use full names (first and last names) vs. short or single-syllable names (e.g., “John Smith” vs. “Dad,” “Smith Residence” vs. “Home”)
- Avoid using special characters, emojis or hyphenated names (e.g., @, &, #, /, -, *, +, etc.)
- Avoid using acronyms (e.g., “In Case of Emergency” vs. “ICE”) or words with all capital letters
- Spell words completely, no abbreviations (e.g., “Doctor Smith” vs. “Dr. Smith”)

Audio Controls^{†18}

A Audio MODE button: Press to cycle through FM/AM/SiriusXM®/Media modes

Audio System ON/OFF: Press to turn power on

B Seek/Presets button: *FM/AM/SiriusXM® Modes:* Press up/down to advance through Preset Stations. Press and hold to auto seek
Media Mode: Press up/down to move Track Up/Down. Press & hold up/down to fast forward/rewind (except for *Bluetooth®* Audio)

C Volume button: Press up/down to raise/lower volume
Mute button: Press to mute all audio

QUICK TIPS


- **Bluetooth® Music Streaming:** If the *Bluetooth®* music is inaudible or too low, you may need to turn up the volume on the connected phone
- When placing a call, speak in a natural, moderate tone, with clear pronunciation. The system may have trouble recognizing commands if you speak too softly or too loudly
- Always wait for the beep before speaking any commands
- Close windows and turn off A/C - Open windows, weather (wind/rain), or an A/C fan operating at higher speeds can interfere with Voice Recognition
- Press the talk button and say “Help” to get a list of available commands

QR CODES

Voice Recognition Tips Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



QUICK TIP

Pressing the Audio Mode button for more than 1 second will turn Audio Mode ON/OFF.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

For further audio system operation, refer to pages 36-44.

Your vehicle's steering wheel buttons may differ from those in the illustration. See your Owner's Manual for more details.

Android Auto™^{†3} / Apple CarPlay®^{†4} Setup

Android Auto™ compatible smartphone setup – Download the Android Auto™ app from the Google Play™ Store^{†10}. Open the Android Auto™ app and proceed with the onscreen instructions to complete setup on the mobile device.

Wireless Connection setup for Android Auto™ & Apple CarPlay®
(Standard Audio System & Standard Audio System-Value with UVO link):

1. Press the SETUP key on the audio head unit
2. Press DEVICE CONNECTION SETTINGS
3. Press PHONE PROJECTION, then ADD NEW

Cable Connection setup for Android Auto™ (Standard Audio System, Standard Audio System-Value with UVO link & UVO link with Navigation):

1. Press the SETUP key on the audio head unit
2. Press DEVICE CONNECTION, select Android Auto™ and then select ENABLE ANDROID AUTO. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Android Auto™
3. Connect the Android™ device with the vehicle's USB port using the manufacturer's cable provided with your phone
4. From the vehicle's home screen, select the Android Auto™ button, where you'll see all the Android Auto™ supported apps

QUICK TIPS

- If Android Auto™ / Apple CarPlay® randomly disconnects:
 - Ensure the USB cable is certified by the phone manufacturer for both power and data
 - Clean the phone's port, which the USB cable connects to, with disposable compressed air
 - The phone should not be disturbed while driving as this can cause a disconnection at the phone's USB port
 - Visit the phone manufacturer's website for Android Auto™ / Apple CarPlay® app concerns

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

Cable Connection setup for Apple CarPlay®
(UVO link with Navigation only):

1. Connect the Apple CarPlay® compatible iPhone® with the vehicle's USB port using the manufacturer's cable provided with your iPhone®
2. Press the SETUP key on the audio head unit
3. Press DEVICE CONNECTION on the screen and select Apple CarPlay®
4. Select ENABLE APPLE CARPLAY. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Apple CarPlay®
5. From the audio head unit home screen, select the Apple CarPlay® button, where you'll see all the Apple CarPlay® supported apps

REMINDERS:

- Android Auto™ compatibility requirements for connection:
 - UVO link with Navigation (USB cable connection only): OS Android™ 5.0 or higher, phone manufacturer's USB cable and data plan with applicable feature(s)
 - Standard Audio System-Value (USB cable & wireless connection):
 - USB cable connection - OS Android™ 5.0 or higher, phone manufacturer's USB cable and data plan with applicable feature(s)
 - Wireless connection - OS Android™ 9.0 or higher with data plan for applicable feature(s)
- Apple CarPlay® compatibility requirements for connection:
 - UVO link with Navigation (USB cable connection only): iOS software 8.0 or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
 - Standard Audio System-Value (Wireless connection only): iOS software 10.0 and higher with data plan for applicable feature(s)
- It is recommended to always update your phone to the latest operating system release
- Wireless Android Auto™ system only works for certain Android models. Use the manufacturer's USB cable when wireless feature is not available

QR CODES

Wireless Apple CarPlay® & Android Auto™ Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to the Car Infotainment System Quick Reference Guide for more information.

iPhone is a registered trademark of Apple Inc.

For further audio system operation, refer to pages 36-44.

UVO link Activation^{*†1} (Systems equipped with UVO link only):

Follow these steps to activate your UVO link system:

1. Enter the activation screen on your vehicle's head unit:
 - a. Press SETUP key
 - b. Press UVO icon
 - c. Press Activate UVO
2. Read and agree to Terms of Service and Privacy Policy and press SUBMIT
3. Enter number or email address to receive a verification code, then press SUBMIT
4. Follow these steps to receive your verification code using your phone SMS or email:
 - a. Check your phone SMS or email for verification code
 - b. Open the link in your SMS or email. A page will open requesting that you create your account

Note: If you already have a Kia Owners Portal account using the email or phone number as your login ID, you will need to provide your password prior to receiving the verification code.

- c. Enter your first name, last name, email, phone number, an account password, and click CREATE ACCOUNT. A page will open displaying your verification code
- d. Enter the code in the head unit and press ACTIVATE
- e. Go back to the page with your verification code and press "I have entered my verification code." A link will be provided to download the Kia Access with UVO link app from your app store. After installing the app, log in and enjoy

REMINDER: This vehicle is not equipped with over-the-air system updates.

For further UVO link operations, refer to the Car Infotainment System Quick Reference Guide.

QR CODES

UVO Assistance Video



Kia Access with UVO link app Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


UVO Assistance*

Virtual Assistant ⓘ ⓘ **A** – Press to connect to a virtual assistant to hear information about the UVO features

UVO Voice Local Search UVO ⓘ **B** – Press to connect to the search function to find points of interest or other locations, like “cafe”

Roadside Assist ⓘ ⓘ **C** – Press to connect to a Roadside Assistant where you can request vehicle towing services

For more information, refer to the Car Infotainment System Quick Reference Guide.



(Buttons on rearview mirror*)


Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

Kia Access with UVO link App Download

Go to an app marketplace to download the new Kia Access with UVO link App. Once you download, make sure you register your vehicle and start an account (refer to UVO link Activation page). Get to know your new Kia and the available convenient features on the app.

QUICK TIPS

- The smartphone and vehicle need to be connected to a cellular network with a good wireless signal strength in order to use UVO. If these conditions are not met, remote command may not execute or takes long time. It will also effect voice commands
- To use Remote Start or Remote Start with Climate Control feature, all doors, hood and trunk/liftgate must be closed and locked
- Activate Remote Start or Remote Start with Climate Control feature at least 10 minutes before getting into the vehicle, which will allow vehicle interior to reach a desired temperature. If the driver does not enter the vehicle within the 10 minutes, the Remote Start will turn off the engine
- The quickest way to obtain accurate vehicle status through the app is by pressing the refresh button on the app or refreshing the web page when using the customer web portal
- In order to preserve the vehicle battery, UVO will not turn on seven days after the last ignition was on. You will need to restart the vehicle with a key fob in order to use UVO again



QR CODES

Download the Kia Access with UVO link App by clicking this dynamic QR code. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia Access with UVO link App Features Guide. Click this dynamic QR code to access the guide. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia Access with UVO link App Features Guide


The Kia Access with UVO link App Features Guide is a step-by-guide helping you utilize the app to its full potential by detailing how to set up and use each feature and adjust various settings. Below are some of the topics included:

- Remote Commands
- Set Climate
- Schedule Remote Start/Climate
- Schedule Charge
- Schedule Service
- Dealer Settings
- Manage Vehicles and Profiles

Kia App Screen for illustrative purposes only. Actual App screen and functionality may vary.

For further UVO link operations, refer to the Car Infotainment System Quick Reference Guide.

Standard Audio System – Value* – FM/AM/SiriusXM®¹⁷/Media (USB, Bluetooth® Audio)*



Sound Settings: To adjust the sound settings:

1. Press the SETUP key on the audio head unit or the onscreen MENU button, when in MEDIA mode. Select the onscreen SOUND button, or SOUND SETTINGS
2. Select the menu item (Position, Volume, Tone, Priority, Advanced, Default, FM Radio Noise Cancel*)
3. Use the onscreen buttons to adjust settings. Press the return button  to save settings

Presets: Press the STAR button next to or below the Radio Station display. This saves the current station as a preset

SiriusXM® Smart Favorites: For the first ten favorite SiriusXM® channels, you may play live or repeat from the beginning of a song or a program segment. In Radio mode, choose SiriusXM®, then select any of the first ten favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast

Custom Key ☆: A programmable key to provide quick access to one of several available system features. **To Program the Custom Key:** Press and hold the Custom key. Select one of the available features you would like the Custom key to open

REMINDER: Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the audio system controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

QR CODES

Standard Audio System – Value Videos



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


For more information, refer to the Car Infotainment System Quick Reference Guide. For other audio system information, refer to pages 36-44.

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, Bluetooth® Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to Bluetooth® Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using Bluetooth® Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- This system supports Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only)
- Navigation may be available when connected to Android Auto™ or Apple CarPlay® supported smartphones
- Voice Recognition function is available when connected to Android Auto™ and Apple CarPlay®
- At any time, you can interrupt Command Feedback by pressing the TALK button; when using the voice command feature, wait for the system to BEEP before speaking the command
- A warning screen may appear periodically to remind users that the system should be operated when the engine is running to prevent battery discharge

Standard Audio System - Value with UVO link*

— FM/AM/SiriusXM®^{†17}/Media (USB, *Bluetooth*® Audio)*



Press briefly to do the following:

- FM/AM mode: Play the previous/next frequency
- SiriusXM® mode: Change the channel
- MEDIA mode: Change the track, file or title (except for AUX)

Press and hold to do the following (over 0.8 seconds):

- FM/AM mode: Move quickly through all of the frequencies. When released, the system seeks the next available frequency
- MEDIA mode: Rewinds or fast forwards the track or file (except for AUX and *Bluetooth*® Audio)

Sound Settings: To adjust the sound settings:

1. Press the SETUP key on the audio head unit or the onscreen MENU button, when in MEDIA mode. Select the onscreen SOUND button, or SOUND SETTINGS
2. Select the menu item (Position, Volume, Tone, Priority, Advanced, Default, FM Radio Noise Cancel*)
3. Use the onscreen buttons to adjust settings. Press the return button to save settings

Presets: Press the STAR button next to or below the Radio Station display. This saves the current station as a preset

SiriusXM® Smart Favorites: For the first ten favorite SiriusXM® channels, you may play live or repeat from the beginning of a song or a program segment. In Radio mode, choose SiriusXM®, then select any of the first ten favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast

Custom Key ☆: A programmable key to provide quick access to one of several available system features. **To Program the Custom Key:** Press and hold the Custom key. Select one of the available features you would like the Custom key to open

REMINDERS:

- Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the audio system controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park
- Prolonged use of the audio head unit in ACC mode may drain the vehicle's battery

For more information, refer to the Car Infotainment System Quick Reference Guide.

For other audio system information, refer to pages 36-44.

QR CODES

Standard Audio System - Value Videos




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Your vehicle's audio system may differ from that in the illustration.

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, *Bluetooth*® Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to *Bluetooth*® Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using *Bluetooth*® Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- This system supports Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only)
- Navigation may be available when connected to Android Auto™ or Apple CarPlay® supported smartphones
- When using the voice command feature, wait for the system to BEEP before speaking the command
- At any time, you can interrupt Command Feedback by pressing the TALK button
- A warning screen may appear periodically to remind users that the UVO link should be operated when the engine is running to prevent battery discharge

UVO link^{†1} – FM/AM/SiriusXM[®]*+17/Media (USB, *Bluetooth*[®] Audio, My Music)



Sound Settings: To adjust the audio system sound settings:

1. Press the SETUP key on the audio head unit
2. Select the onscreen SOUND button, or SOUND SETTINGS
3. Select the menu item (Position, Tone, Priority, Advanced, Default)
4. Use the onscreen buttons to adjust settings. Press the return button  to save settings

Radio Presets: You can listen to FM, AM and SiriusXM[®]* radio and save frequently used stations

How to Save a Preset: Press and hold the desired slot. This saves the current station in the selected slot

SiriusXM[®]* Smart Favorites: For the first ten favorite SiriusXM[®]* channels, you may play live or repeat from the beginning of a song or a program segment. In Radio mode, choose SiriusXM[®]*, then select any of the first six favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast

Custom Key ☆: A programmable key to provide quick access to one of several available system features

To Program the Custom Key ☆: Press and hold the Custom Key. Select one of the available features you would like the Custom Key to open

QR CODES

UVO link Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIPS

- The volume level for each source (FM, AM, USB, etc.) will revert to the previously set volume for that source
- Navigation may be available when connected to Android Auto™ or Apple CarPlay® supported smartphones
- When using the voice command feature, wait for the system to BEEP before speaking the command
- At any time, you can interrupt Command Feedback by pressing the TALK button
- Prolonged use of the audio system in ACC mode may drain the vehicle's battery
- A warning screen may appear periodically to remind users that the audio system should be operated when the engine is running to prevent battery discharge


REMINDER: Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the audio system controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Your audio system may differ from those in the illustrations.

For further operational information, refer to the Car Infotainment System Quick Reference Guide.

For other audio system operation, refer to pages 36-44.

UVO link with Navigation^{*†1,11} – FM/AM/SiriusXM®/Media (USB, *Bluetooth*® Audio)



Sound Settings: To adjust the sound settings:

1. Press the SETUP key on the audio head unit. Select the onscreen SOUND button
3. Select the menu item (Position, Tone, Priority, Advanced, Default)
4. Use the onscreen buttons to adjust settings. Press the return button  to save settings

Radio Presets: You can listen to FM, AM and SiriusXM® radio and save frequently used stations

How to Save a Preset: Press and hold the desired slot or the star button ☆ next to or below the radio station display. This saves the current station in the selected slot

SiriusXM® Smart Favorites: For the first ten favorite SiriusXM® channels, you may play live or repeat from the beginning of a song or a program segment. In Radio mode, choose SiriusXM®, then select any of the first six favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast

Custom Key ☆: A programmable key to provide quick access to one of several available system features

To Program the Custom Key: Press and hold the Custom Key ☆. Select one of the available features you would like the Custom Key to open

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, *Bluetooth*® Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to *Bluetooth*® Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using *Bluetooth*® Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- To download map updates for the navigation system, go to update.kia.com. Check for updates that are generally available twice a year.
- This system supports Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only)
- At any time, you can interrupt Command Feedback by pressing the TALK button
- A warning screen may appear periodically to remind users that the audio system should be operated when the engine is running to prevent battery discharge

QR CODES

UVO link with Navigation Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

REMINDER: Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the audio system controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Your audio system may differ from those in the illustrations.

For further operational information, refer to the Car Multimedia System User's Manual. For other audio system operation, refer to pages 36-43.

Prolonged use of the audio system in ACC mode may drain the vehicle's battery.

Digital Clock

Press **SETUP**, then select **General**, and select **Date/Time** from the menu to adjust.

QUICK TIPS

- Press the **Return** button on the audio head unit to ensure changes are saved
- When needed, **Daylight Savings** must be enabled in the **Clock Settings** screen
- To access manual date and time settings, turn **GPS time OFF** in the **Clock Settings (UVO link with Navigation*)**

Multimedia USB Port, Charger Ports

Multimedia USB Port **A** Use the Multimedia USB Port to connect USB audio devices and smartphone devices.

Power Outlets **B**

Use the power outlets for mobile phones and other devices designed to operate on a 12V (180W max) power outlet.

QUICK TIP


The power outlets are inactive when ignition is in the **OFF** position.

USB Charger Ports **C**


Devices can be recharged using a USB cable. The **Engine Start/Stop** button needs to be in the **ACC/ON/START** position to operate the USB Charger Ports. They are located in the **Center Panel** and the **Center Console**.

REMINDERS:

- Using the power outlets (accessory plugs) for prolonged periods of time with the **Engine Start/Stop** button in the **ACC** position (**Engine OFF**) may cause the battery to discharge
- The Multimedia USB data port **A** is located between the Power Outlet and USB Charger Port. The USB Charger Port does not support data transfer



Refer to section 4 in the *Owner's Manual* for more information.



(Rear of Center Console shown)


AC Inverter*

The AC inverter supplies 115V/150W electric power to operate accessories or devices.

To use the AC inverter, open the AC inverter cover and connect a plug to it.

The AC inverter is **ON** when the vehicle is on.

Refer to section 4 in the *Owner's Manual* for more information.



Wireless Smartphone Charging System*

Charge a compatible smartphone wirelessly by placing it on the charging pad **A** at the front of the console, near the Multimedia USB ports and the charging indicator, while the ignition is on.

1. Enable Wireless Charging in the User Settings
2. Place a compatible smartphone on the center of the charging pad
3. Indicator light **B** may change to amber once the wireless charging begins
4. Once charging is complete, the orange light may change to green


QUICK TIPS

- The smartphone must be a compatible phone with Qi function available
- Wireless charging must be enabled in user settings
- If wireless charging does not work, move smartphone around the pad until the charging indicator turns amber. Avoid placing other metal items in the bin while charging as to not impede the charging area
- For wireless charging to occur, all doors (excluding rear hatch) must be closed & the Smart Key Fob must be detected inside the vehicle

REMINDERS:

- Wireless charging technology allows for a device to be charged using inductive charging. See your Owner's Manual for more detailed information and the back page for legal disclaimers
- Inductive charging systems are less efficient than conventional charging through cable. As a result, higher device operating temperatures may be experienced during use
- Charging Performance - Device position on the wireless charging system can affect charging performance. Other factors that may affect the charging rate includes foreign objects, such as coins or pens, and phone case thickness
- If driver door is opened, charging will be disabled

Requires Qi enabled device or Qi enabled case



(Located in front of Gear Shift)


QR CODES

Wireless Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Automatic Climate Control



- A** Driver Only Fan Control
- B** Temperature Control knob
- C** Automatic Climate Control button
- D** Front Windshield Defroster
- E** Rear Windshield Defroster
- F** Air Conditioning On/Off button
- G** Recirculated Air button
- H** Mode Selection button
- I** Dual Temperature Control knob
- J** Dual Climate Control button (SYNC)
- K** CLIMATE information screen selection button
- L** Fan Speed Control buttons
- M** System OFF button

Climate Control Auto Function

1. Press **AUTO** to select Full Auto Operation. The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected
2. Set desired temperature
3. Press **SYNC** to synchronize driver and passenger temperature control

QUICK TIPS

- Defrost mode activates A/C and opens Fresh Air Vent to help dehumidify the air and improve Defroster performance
- During Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity
- Keep inside glass as clean as possible to reduce window fogging

Your Automatic Climate Control system may differ from those in the illustration. Refer to section 4 in the Owner's Manual for more information.

Auto Defogging System: Auto defogging is designed to reduce the fogging up of the inside of the windshield by automatically sensing the moisture of the inside of the windshield. The system will automatically change to defrost mode when needed.

Auto Defogging is set ON by default. To cancel Auto Defogging, press and hold the Front Defrost button for three seconds when the ignition is on (the defrost button light will flash three times and the ADS OFF icon will illuminate). To turn Auto Defogging on again, press and hold the Front Defrost button again for three seconds and the defrost button light will flash six times and ADS OFF icon will turn off.

Driver Only Ventilation: Driver Only Ventilation restricts air flow to the driver's side vents only. This can help to optimize driving range by limiting the power drawn from the battery. Press **DRIVER ONLY** button to enable air flow through the driver's side vents only.

Defrost Outside and/or Inside Windshield:

1. Set fan speed to the highest position
2. Set **temperature to Hot**
3. Press the **Front Defrost** button

Air Flow Modes: To select Air Flow Modes, press the Mode selection buttons:

- Face-Level
- Bi-Level
- Floor-Level
- Floor/Defrost-Level

REMINDERS:

- Continuous use of the climate control system in the recirculated air position may allow humidity to increase inside the vehicle which may fog the glass and obscure visibility
- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for Temperature Control
- MAX A/C Mode automatically engages Recirculated Air
- When in AUTO mode, Air Flow mode and Fan Speed do not display on the Climate Control Display
- Cold or warm ambient air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)

QR CODES

Auto Defogging System Video






Automatic Climate Control Operation Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Automatic Gear Shift with Sportmatic® Shifting

- P:** Park
- R:** Reverse
- N:** Neutral
- D:** Drive (ECO Mode)
- D:** Drive, left gate (Sport Mode)
- [+]:** Manual Sport Mode Upshift
- [-]:** Manual Sport Mode Downshift



Manual Sport Mode: To enter Manual Sport Mode, move shift lever from D to left gate. When in Manual Sport Mode, if the shift lever is not moved up or down, then the vehicle will automatically shift gears. To shift while in Manual Sport mode, move shift lever up [+] to upshift or down [-] to downshift. See page 10 for more information on the Drive Modes.

Dual Clutch Transmission

The Dual Clutch Transmission (DCT) gives the driving feel of a manual transmission, yet provides the ease of a fully automatic transmission.

The following are unique driving tips for the Dual Clutch Transmission:

- To hold the vehicle stationary on an incline, the service brake or parking brake **MUST** be used or the gear shift **MUST** be in the (P) Park position. If the vehicle is held stationary by applying the accelerator pedal on a slope, the clutch/transmission may overheat, resulting in damage
- Avoid aggressive launches on steep grades as this may result in an overheated clutch and transmission
- A slight time lag may be experienced at takeoff from standstill during aggressive acceleration maneuvers
- If the clutch is overheating, the first warning, an amber-colored warning light , will be displayed in the instrument cluster. **When indicator turns red, reduce speed, pull over and place the vehicle in Park until it cools**

Refer to the Owner's Manual for additional information on DCT operation or call Kia Consumer Affairs for additional information.

QR CODES

Sportmatic® Shifting Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Refer to section 5 in the Owner's Manual for additional information

Paddle Shifters*

Paddle Shifters are operable when the shift lever is moved into the left gate of the D position (manual sport mode).

Paddle Shifting: Pull the [+] or [-] paddle shifter once to shift up or down one gear.

REMINDER: When in Manual mode, pulling the left and right paddle shifters at the same time will NOT shift gears.



Auto Hold*

Auto Hold temporarily maintains the vehicle at a standstill even though the brake pedal is not depressed after the driver brings the vehicle to a complete stop by depressing the brake pedal. Auto Hold can be turned On/Off using the AUTO HOLD button **A** on the center panel below the gear shift. Before Auto Hold will operate, the driver's door, engine hood and liftgate must be closed, and the driver's seat belt must be fastened.

The AUTO HOLD indicator on the Instrument Cluster has four states:

White: Standby – When vehicle is in Park and at a standstill, and AUTO HOLD button **A** is pressed ON, the indicator will illuminate white. While driving the vehicle (vehicle is not at a standstill), the Auto Hold indicator will remain white.

Green: Engaged – When coming to a complete stop by depressing the brake pedal, the Auto Hold indicator changes from white to green.


Off (not illuminated) – The indicator will turn Off when the AUTO HOLD button **A** is manually pressed Off or when the EPB is manually turned On.

Yellow: Malfunction – When the indicator is illuminated yellow, there may be a system malfunction. Take your vehicle to a local Kia dealer.

REMINDERS:

- Auto Hold only operates when vehicle is in Drive or Neutral
- To reduce the risk of an accident, do not activate Auto Hold while driving downhill, backing up or parking your vehicle
- Do not solely rely on the Auto Hold system to keep the vehicle stopped. Always pay attention to traffic and road conditions, and be prepared to depress the brakes

Image is for illustrative purposes only and may not reflect actual feature or operation.



(Located on Center Panel)

Electric Parking Brake (EPB)*

The Electric Parking Brake (EPB) system utilizes an electric motor to engage the parking brake.

Applying the Parking Brake

Depress the brake pedal and pull up the EPB switch **B**. Ensure that the indicator light **(P) BRAKE** is illuminated on the instrument cluster.

Releasing the Parking Brake

The EPB will automatically release when the shifter is placed in Reverse or Drive.

To release EPB manually, depress the brake pedal, then press the EPB switch **B** down, with the ignition switch in the ON position. Ensure that the indicator light **(P) BRAKE** is OFF.

QR CODES

Electric Parking Brake Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

QUICK TIPS

- When leaving your keys with parking lot attendants or valet, make sure to inform them how to operate the EPB
- If parked on a steep incline, pull up the EPB switch for more than 3 seconds for a firmer EPB application
- Pull up and hold EPB switch a second time to increase brake pressure if parked on a decline or incline

REMINDERS:

- As a bulb check, the EPB malfunction indicator will illuminate for approximately 3 seconds when the ignition switch is turned ON
- If the warning light does not illuminate temporarily, or continues to remain lit, take your vehicle to an authorized Kia dealer and have the system checked
- The EPB should not be operated while the vehicle is moving
- A click or electric brake motor sound may be heard while operating or releasing the EPB, but these conditions are normal and indicate that the EPB is functioning properly

Seat Warmers⁺¹⁶ / Ventilated Seats*


Seat Warmers – Press top of button once for high setting (3 LEDs lit), again for middle setting (2 LEDs lit), again for low setting (1 LED lit). Press again to turn OFF.

Ventilated Seats – Press bottom of button once for high setting (3 LEDs lit), again for middle setting (2 LEDs lit), again for low setting (1 LED lit). Press again to turn OFF.

QUICK TIPS

- With the seat warmer switch in the ON position, the heating system in the seat turns OFF or ON automatically depending on the seat temperature
- System is OFF by default

REMINDER: Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.



QR CODES

Seat Warmers/ Ventilated Seats Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Refer to section 5 in the Owner's Manual for more information.

Driver Position Memory System^{*†14}

To store a seating position into memory, first place the shifter into P (Park) while the ignition switch is ON. Then:

1. Adjust the driver's seat
2. Press the SET button **A** on the control panel. System will beep once
3. Press one of the memory buttons **B** within 5 seconds. The system will beep twice when memory has been stored
4. "Driver (1 or 2) set is memorized" will appear on the instrument cluster LCD screen

Do not attempt to operate the driver position memory system while the vehicle is moving. This could result in a loss of control of the vehicle.




Front Seat Headrest Adjustment^{†14}

To raise headrest: Pull headrest up.

To lower headrest: Press lock **C**, then press the headrest down.

QUICK TIP

For easy adjustments, hold a headrest post with one hand while using the other hand to pull the headrest from underneath.



Do not operate the vehicle with the headrests removed. Headrests can provide critical neck and head support in an accident.

Rear Occupant Alert (ROA) with Door Monitoring

The Rear Occupant Alert (ROA) with Door Monitoring can help alert the driver when a rear passenger may be left in the vehicle. The alert will be a message on the Instrument Cluster stating to "Check rear seats" **D** and a chime will sound.

The factory default is set to OFF. To turn the system ON or OFF, go to User Settings in the Instrument cluster or Vehicle Settings*, on the audio head unit select Convenience, then Rear Occupant Alert and check/uncheck the box.

QR CODES

Rear Occupant Alert (ROA) with Door Monitoring video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

Check rear seats



REMINDER: Always be sure to check the passenger areas before leaving the vehicle.



ROA is not a substitute for one's attention. Always check the vehicle's interior before exiting.

See section 4 in the Owner's Manual for more information.

Image is for illustrative purposes only and may not reflect actual feature or operation.

Power Adjustable Driver's Seat*†14

Move/Press controls to adjust Seat forward/backward, Seat Cushion tilt up/down, Seatback forward/backward or Lumbar forward/backward.




REMINDER: Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

6-Way Manual Adjustable Driver's Seat*†14

Pull lever **D** to slide Seat forward/backward.

Pull/press lever **E** up/down one or more times to adjust Seat height.

Pull lever **F** to adjust Seatback recline.



QUICK TIP

When adjusting seat forward or backward, ensure seat clicks or locks into place before driving vehicle.

Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 3 in the Owner's Manual for more information.

QR CODES

Manual Adjustable Driver's Seat Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Folding Rear Seats

To Fold:

1. Ensure the belt strap is out of way of the Seatback folding **A**. Insert the metal seat belt tab into the holder **B**
2. Adjust the Front Seatback to the upright position and lower the rear headrest to the lowest position
3. Pull on the Rear Seatback lock release lever **C**, then fold the seat toward the front

To Unfold:

1. Pull the lock release lever **C** and pull and lift the Seatback backward until it clicks firmly in place
2. Return the rear seat belt to the proper position



QUICK TIPS

- It may be necessary to adjust the front seatbacks to fully lower rear seats
- Ensure the seat is locked by pressing down on Seatback and ensuring red line is NOT visible on bottom of Folder Lever

REMINDERS:

- Before unfolding Seatback, ensure the metal seat belt tab is placed into the holder
- Always make sure the seatback is locked in place when unfolded


Refer to section 3 in the Owner's Manual for more information.

Remote Keyless Entry (Folding Key)*

- A** Press the release button to unfold the key
- B** Press to lock All doors; Press twice within two seconds to sound the horn
- C** Press to unlock Driver's Door; Press twice in 4 seconds to unlock All Doors and Liftgate
- D** Press and hold for more than 1 second to unlock Liftgate. Then lift by the handle to manually open Liftgate
- E** Press and hold more than a half second for Panic Alarm. To turn off Alarm, press any button

Remote button configuration may vary depending on vehicle options. To turn OFF Alarm, press any button.

Refer to section 4 in the Owner's Manual for more information.



QR CODES

Kia Smart & Folding
Key Fobs Video



*Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos*

Smart Key / Remote Start*†8

Smart Key Fob:

- A** Press to lock All Doors; Press twice within 2 seconds to sound the horn
- B** Press to unlock Driver's Door. Press twice in 4 seconds to unlock All Doors
- C** Press and hold for more than 1 second to unlock Liftgate. Then lift by the handle to manually open Liftgate

REMINDER:

The Liftgate unlocks when the Smart Key fob is within close proximity of the vehicle's Liftgate.

- D** Press and hold more than 1 second for Panic Alarm. To turn off Alarm, press any button
- E** Press to release Mechanical Key

Driver's Door Lock/Unlock button **F**:

- Press button once to unlock Driver's Door
- Press again within 4 seconds to unlock All Doors
- Press again to lock All Doors

Mechanical Key **G**:


- Use to lock/unlock Driver's Door by turning once or all doors by turning twice
- Use to enable/disable Child Safety Locks

Remote Start* **H**:

Press for more than two (2) seconds within four (4) seconds after locking doors to start the vehicle. Press once to turn off.

QUICK TIPS

- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the Engine Start/Stop button (Lock button side closest) and press to start engine
- The Smart Key's signal can be blocked by the normal operation of a cell phone or smartphone. To help prevent this, store each device separately



QR CODES

Remote Start - Smart Key Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 4 in the Owner's Manual for more information.

Double-Turn Lock/Unlock All

- Turn clockwise once to unlock Driver's Door
- Turn clockwise again within 4 seconds to unlock All Doors
- Turn counterclockwise once to lock All Doors



REMINDER: Remote button configuration may vary depending on vehicle options.

Map/Room Lamps

Automatic turn off function*

The interior lights automatically turn off approximately 30 seconds after the Engine Start/Stop button is OFF.

Map Lamp/Room Lamp Operation


Push the lens **A** to turn the map lamp ON/OFF. This light produces a spot beam for convenient use as a map lamp or as a personal lamp for the driver or the front passenger.

Map/Room Lamp Button – Press button **B** to turn the front and rear room lamps on and off.


Door Mode Button – Press button **C**

to enable or disable Door Mode. In Door Mode the map and room lamps turn on when any door is opened. When all doors are locked or the ignition is on, the map and room lamp will turn off immediately.

Rear Room Lamps – Press the button **D** to turn the rear passenger lamp ON/OFF.



(Type B)



(Type A)

QUICK TIPS

- When doors are unlocked by the Smart Key*, the lamp turns ON for approximately 30 seconds
- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 3 seconds after the system is in armed stage
- Using interior lights for an extended period of time may cause battery discharge

Sunroof Operation*

The Sunroof and Sunshade operation is controlled through a multidirectional switch/lever, and the ignition needs to be in the ON position to operate the Sunroof/Sunshade.

Slide the Sunshade and Sunroof:

- Auto Open: Slide lever **E** backward to the farthest position and release
- Auto Close (Sunroof only): Slide the lever **E** forward to the farthest position and release

Slide the Sunroof (with Sunshade open):

- Open: Press the Sunroof lever **E** backward and press again forward/backward until you reach the desired detent position (manual slide feature)
- Close: Press the Sunroof lever **E** forward and press again forward/backward until you reach the desired detent position (manual slide feature)

Tilt the Sunroof:

- **Raise:** Push lever **E** upward
- **Lower:** Push lever **E** forward

QUICK TIP

To stop the Sunroof at any position, push or pull the Sunroof control lever in any direction.

REMINDER: Sunshade needs to remain OPEN while Sunroof is open and vehicle is moving.

Do not adjust the Sunroof or Sunshade while driving. This could result in loss of control of the vehicle.

QR CODES

Sunroof Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 4 in the Owner's Manual for more information.


Hood Release Lever and Latch

Opening the Hood:

1. Pull the Hood Release Lever **A** to unlatch the Hood
2. In the front of the vehicle, lift the Hood slightly, pull the secondary Latch **B** inside of the Hood's center and lift the Hood



(Located on Driver side kick panel)



(Latch located inside hood)

Closing the Hood: Lower the Hood about halfway and then press down to securely lock in place.

Refer to section 4 in the Owner's Manual for more information.

Fuel Filler Lid

1. Stop the engine
2. Press the Fuel Filler Lid button **C** to open the Fuel Filler Lid. The LCD may display this message: *Wait until fuel door opens* (Plug-In Hybrid Only). Once the Fuel Filler Lid is open, the LCD may display this message: *Fuel door open*.
3. Pull open the Fuel Filler Lid
4. Remove cap by turning counterclockwise



(Buttons located on Driver's Panel to the left of the Steering Wheel)


Refer to section 4 in the Owner's Manual for more information.

QUICK TIP

There may be a delay in Fuel Filler Lid opening for about 20 seconds due to depressurization.

Fuel Cap / Malfunction Indicator (Check Engine Light)

Tighten for ONE CLICK to prevent Malfunction Indicator  from illuminating.



REMINDERS:

- The Fuel Filler Door Release button is located on the left side of the Steering Wheel on the lower button panel
- It is normal to hear one click when tightening and for the Fuel Cap to click back when released

QR CODES

One-Click Fuel Cap Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Refer to section 4 in the Owner's Manual for more information.

Sunvisor^{†19}

Use the Sunvisor to shield direct light through the front or side windows. Slide the Sunvisor out and adjust as needed.

REMINDERS:

- Sunvisor may not shield all direct light
- Do not operate the vehicle if Sunvisor is impairing your visibility
- Be aware of your seating position when adjusting or swinging Sunvisor around from the front or side windows




Refer to section 4 in the Owner's Manual for more information.

Liftgate Release Button*

Button is located on the bottom of the Liftgate lid. With doors unlocked, press the Liftgate Release button **A** and pull the Liftgate up by the handle to open.

QUICK TIPS


- The Liftgate must be unlocked before it can be opened by the Liftgate Release Button
- The Liftgate unlocks automatically and then can be opened manually when the Smart Key* is within close proximity to the vehicle's hatch



Refer to section 4 in the Owner's Manual for more information.

High Voltage Battery Air Intake

The Hybrid Battery Air Intake, located on the side underneath the left rear seat, is used to cool down the hybrid battery. For safety reasons, this vent should never be blocked. Doing so may cause the battery to overheat.



QUICK TIP


Clean the air intake for the hybrid battery regularly with a dry cloth.

WARNING: Never clean the battery vent with a WET cloth or spill liquid over the air intake. This could cause an electric shock, which could cause serious damage, injury or death.

Child-Protector Rear Door Locks

Locate these locks on the rear edge of the rear passenger doors. Move the Child-Protector Rear Door Lock, with the mechanical ignition key, to the lock position  to disable the inner door handles from opening the rear doors.

REMINDER: Child-Protector Rear Door Lock is located on rear passenger's door jamb.



Refer to section 3 in the Owner's Manual for more information.


Tire Mobility Kit

The Tire Mobility Kit is designed to temporarily seal certain types of tire damage.

For operational information, please refer to the Owner's Manual.

A Sealant Bottle

B Compressor



QR CODES

Tire Mobility Kit Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.

QUICK TIPS

- The Tire Mobility Kit is a temporary fix and is to be used for one tire only; the tire should be inspected as soon as possible
- The kit should only be used for sealing/inflating passenger car tires; do not use for inflating any other type of tires
- Some damaged tires cannot be sealed completely; do not use the kit if it appears a tire is damaged beyond repair

REMINDERS:

- The above images are for illustration purposes only and may not reflect actual operation
- After tire is properly sealed, drive cautiously at a maximum speed of 50 mph for a maximum distance of up to 120 miles

Occupant Detection System (ODS)^{†12} / Passenger Airbag Off Indicator^{†2,15}

ODS is designed to detect the presence and position of the front passenger and adjusts or turns off passenger airbag deployment accordingly.



Depending on the situation and type of accident, the system may:

- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the “PASSENGER AIR BAG OFF” light will illuminate.

REMINDERS:


- Do not allow an adult passenger to ride in the front seat when the Passenger Airbag Indicator is illuminated OFF because the airbag will not deploy in the event of a crash. The driver must instruct the passenger to reposition her/himself in the seat
- For more information on the Occupant Detection System/ Passenger Airbag Off Indicator, please refer to the Owner's Manual

Refer to section 3 in the Owner's Manual for more information.

Seat Belts^{†15}

To properly fasten your safety belts:


1. Insert the belt tongue plate **A** into the buckle **B** until it clicks
2. Position the lap portion of the belt across your lap as LOW ON THE HIPS as possible
- C**. Adjust the belt to a SNUG FIT by pulling up on the shoulder portion **D**



Seat belt retractor locks:

Retractor locks allow lap/shoulder seat belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS, seat belt retractors will automatically lock the belts to reduce the risk of injury.



QUICK TIP

The Seat Belt warning chime operates for driver's seat only.

REMINDER: For maximum protection, always wear your Seat Belt.

Refer to section 3 in the Owner's Manual for more information.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and/or death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of the vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.

1. **UVO link:** Purchase/lease of certain 2019 and newer Kia vehicles with UVO link includes a complimentary 1-year subscription starting from new vehicle retail sale/lease date as recorded by the dealer. After your complimentary 1-year UVO link subscription expires, continued access to the full suite of UVO link available on your Kia will require a paid subscription at the then current subscription rate or your use of certain UVO link features may immediately terminate. Use of UVO is subject to agreement to the UVO Privacy Policy (available at <https://owners.kia.com/us/en/privacy-policy.html>) and Terms of Service (available at <https://owners.kia.com/us/en/terms-of-service.html>). UVO link is transferable to subsequent owner during the original UVO link service term. Only use UVO link when safe to do so. Kia Access with UVO link App is available from the Apple® App Store® or Google Play™. Kia Motors America, Inc. reserves the right to change or discontinue UVO link at any time without prior notification or incurring any future obligation. Message and data rates may apply. Cellular and GPS coverage is required to use most features. UVO link features may vary by model, model year, and trim level. Features, specifications, and fees are subject to change. For more on details and limitations, visit <https://owners.kia.com> or your authorized Kia dealer. Apple and App Store are registered trademarks of Apple Inc. Google and logos are trademarks of Google, LLC.
2. **Airbags:** For maximum protection, always wear your seat belt.
3. **Android Auto™:** Vehicle user interface is a product of Google and its terms and privacy statements apply. Requires the Android Auto app on Google Play and an Android compatible smartphone running Android™ 5.0 Lollipop or higher. Data plan rates apply. Android Auto is a trademark of Google LLC..
4. **Apple CarPlay®:** Apple® and Apple CarPlay® are trademarks of Apple, Inc., registered in the U.S. and other countries. Apple CarPlay® runs on your smartphone cellular data service. Normal data rates will apply. Distracted driving can result in a loss of vehicle control. Never use a handheld device or vehicle system that takes your focus away from safe vehicle operation.
5. **Bluetooth® Wireless Technology:** The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc., and any use of such marks by Kia is pursuant to license. A Bluetooth® enabled cell phone is required to use Bluetooth® wireless technology.
- 6a. **Driver Assist Features – Forward Collision-Avoidance Assist (FCA) / Forward Collision Warning (FCW), Blind-Spot Collision Warning (BCW), Rear Cross-Traffic Collision Warning (RCCW), Lane Keeping Assist (LKA), Rear View Monitor (RVM), Reverse Parking Distance Warning (PDW), Smart Cruise Control (SCC) with Stop & Go System, Lane Following Assist (LFA), Reverse Parking Aid Function, Navigation-based Smart Cruise Control - Curve (NSCC-C), Highway Driving Assist (HDA), Leading Vehicle Departure Alert (LVDA):** These features are not substitutes for safe driving, and may not detect all objects surrounding the vehicle. Always drive safely and use caution.
- 6b. **Driver Attention Warning (DAW):** Driver Attention Warning is not a substitute for safe driving and may not detect all instances of driver fatigue or inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.
7. **Electronic Stability Control (ESC)/ Traction Control System (TCS)/Hill-start Assist Control (HAC):** No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.
8. **Engine Start/Stop Button with Smart Key:** Always come to a complete stop before turning the engine on or off. However, if you have an emergency while the vehicle is in motion and must turn the engine off, you can turn the engine off to the ACC position by pressing the Start/Stop button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the engine by pressing the Start/Stop button with the shift lever in Neutral (N). With the engine off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.
9. **Front Seat Headrest Adjustment:** Never attempt to adjust headrests when vehicle is in motion.
10. **Google Play™ Store** is a trademark of Google LLC. ©2021 Google LLC. All rights reserved. Google and the Google Logo are registered trademarks of Google LLC.
11. **Navigation:** Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.
12. **Occupant Detection System (ODS):** Kia vehicles use a number of different ODS types that vary by model.
13. **Roadside Assist:** 24-hour Enhanced Roadside Assistance is a service plan provided by Kia Motors America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. For access to Enhanced Roadside Assistance, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.
14. **Seat adjustments:** Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.
15. **Seat Belts:** For maximum protection, always wear your seatbelt.
16. **Seat Warmers:** Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.
17. **SiriusXM®:** SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com. Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. © 2021 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.
18. **Steering-wheel-mounted controls:** Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.
19. **Sunvisors:** Sunvisor may not shield all direct light. Do not operate the vehicle if sunvisor is impairing your visibility.
20. **Tilt/Telescoping Steering Wheel:** Never attempt to adjust steering wheel position when vehicle is in motion.
21. **Tire Pressure Monitoring System (TPMS):** Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.



NIRO HYBRID/PLUG-IN HYBRID CUSTOMER DELIVERY CHECKLIST

KEY FEATURE WALKTHROUGH

- ☐ Android Auto™ / Apple CarPlay® Setup* – page 38


- ☐ UVO link Activation / UVO Assistance* – page 39

Walk customer through the registration/activation process for UVO link



- ☐ Standard Audio System - Value* / Value with UVO link – pages 41-42

For further operational information, refer to the Car Infotainment System Quick Reference Guide.




- ☐ UVO link* & UVO link with Navigation* – pages 43-44


For further operational information, refer to the Car Infotainment System Quick Reference Guide.



- ☐ Multimedia USB Port, Charger Ports & Power Outlets – page 46




- ☐ Cruise Control – page 23
- Demonstrate operation



- ☐ Bluetooth® Wireless Technology – page 36

Demonstrate operation, and pair customer's phone.



- ☐ Tire Pressure Monitoring System (TPMS) – page 5
- ☐ Trip Modes / Trip Computer – page 8
- ☐ Fuel Economy – page 7
- ☐ Sport/ECO Modes – page 7
- ☐ Engine Start/Stop Button – page 31
- ☐ Audio Controls – page 37
- ☐ Digital Clock – page 45
- ☐ Seat Warmers/Ventilated Seats* – page 50

- ☐ Smart Key / Remote Start – page 55
- ☐ Sunvisor – page 57
- ☐ Reverse Parking Distance Warning (PDW)* – page 29
- ☐ Rear View Monitor (RVM)* – page 28
- ☐ Tire Mobility Kit – page 59
- ☐ Passenger Airbag Off Indicator – page 60

*IF EQUIPPED

DURING DELIVERY

- ☐ Explain first service process and schedule first service appointment
- ☐ Tour Parts & Service departments, introduce staff & explain value of Kia Parts and Service
- ☐ Review recommended maintenance schedule and maintenance requirements to validate warranty
- ☐ Review business hours
- ☐ Review the Kia 10-year/100,000-mile warranty program
- ☐ Ensure 100% satisfaction with sales and delivery process and no problems with the vehicle
- ☐ Confirm time and best contact number for initial dealer follow-up

Sales Consultant: _____ Date: _____

Sales Manager: _____ Date: _____

Customer: _____ Date: _____



NIRO HYBRID/PLUG-IN HYBRID CUSTOMER DELIVERY CHECKLIST

Owner's Name: _____ VIN: _____ Mileage: _____


Dealership Name: _____ Sales Consultant: _____ Date: _____

BEFORE DELIVERY

- ☐ Confirm "Good Battery" with a Kia battery tester
- ☐ Verify all tire pressures are to spec (see driver's door label) LF _____ LR _____ RF _____ RR _____
- ☐ Verify proper operation of Remote Keyless Entry and Smart Key lock/unlock
- ☐ Ensure floor mats are snapped into place (if applicable)
- ☐ Verify vehicle is clean (interior and exterior), in good condition and free of chips and scratches
- ☐ Ensure all key documents are in the vehicle (Owner's Manual, Warranty and Consumer Information booklet, Tire Warranty booklet and Features & Functions Guide and any supplemental audio user's guides)


KEY FEATURE WALKTHROUGH

- ☐ Instrument Cluster / Hybrid / Plug-In Hybrid Displays – pages 3-6



Type A shown

- ☐ Hybrid/Plug-In Hybrid Displays on the audio control unit – page 12



- ☐ Climate Control System* – page 47


Demo Defrost and Defog Windshield



Type B shown

- ☐ Windshield/Rear Wipers & Washers – page 34

Windshield: Move lever Up/Down to change Wiper modes.
Rotate lever to adjust Intermittent Wipe Speed.



Windshield
MIST: Single wipe
OFF: Wipe off
INT: Intermittent wipe
LO: Slow wipe
HI: Fast wipe

Pull to spray and wipe.



NIRO HYBRID / PLUG-IN HYBRID NORMAL MAINTENANCE SCHEDULE

P=Perform • R=Replace • I=Inspect[‡]

(up to 60,000 miles)^A

MAINTENANCE ITEMS	MAINTENANCE INTERVALS (MILES)							
	7,500	15,000	22,500	30,000	37,500	45,000	52,500	60,000
Add fuel additive ^C	P	P	P	P	P	P	P	P
Rotate tires	P	P	P	P	P	P	P	P
Engine oil and filter	R	R	R	R	R	R	R	R
Climate control air filter		R		R		R		R
Vacuum hose		I	I	I	I	I	I	I
Steering gear box, linkage & boots/lower arm ball joint, upper arm ball joint		I		I		I		I
Drive shafts and boots		I		I		I		I
Suspension mounting bolts		I		I		I		I
Air conditioner refrigerant		I		I		I		I
Exhaust pipe and muffler		I		I		I		I
Air cleaner filter	I	I	I	R	I	I	I	R
Engine clutch actuator fluid			R			R		
HSG belt ^D	I							
Brake fluid				I				I
Brake lines, hoses and line				I		I		I
Front brake discs/pads, calipers		I		I		I		I
Fuel tank air filter ^E				I				I
Parking brake				I				I
Engine clutch actuator hose and lines				I		I		I
Vapor hose and fuel filler cap				I				I
Rear brake discs/pads		I		I		I		I
Fuel cap, fuel lines, fuel hoses and connections				I				I
Dual clutch transmission fluid					I			I

QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your UVO link* account by logging into UVO link App or your account on <https://owners.Kia.com> (See page 39 for setup information)

‡ If equipped.

A. See the Owner's Manual for complete maintenance schedule.

B. And, if necessary, adjust, correct, clean or replace.

C. If TOP TIER detergent gasoline is not available, one bottle of additive is recommended. Additives are available from your authorized Kia dealer along with information on how to use them. Do not mix other additives.

D. Inspect HSG belt for evidence of cuts, cracks, excessive wear or oil saturation and replace if necessary. If HSG belt noise occurred, readjust HSG belt tension before replace

E. Both the fuel filter & fuel tank air filter are generally considered to be maintenance free, depending on fuel quality being used. However, periodic inspection is recommended. If your vehicle is having issues like fuel flow restriction, power surging, loss of power, difficulty starting, etc., replace the fuel filter immediately and consult an authorized Kia dealer for service.

See your Owner's Manual for more details and complete maintenance information, including severe maintenance schedule. Warranty may be voided if maintenance schedule is not followed.

© 2021 Kia Motors America, Inc. All rights reserved.
Consumer - Roadside Assistance¹⁵: 1-800-333-4KIA (4542)

Part Number: DE210-PS-004

†LEGAL DISCLAIMERS ON BACK INSIDE COVER