





EN User Manual | Oven

**BBP6252B** 

**BFP6252M** 

**BFP6252W** 

**BKB6P2B0** 

BKH6P2M0

BKH6P2W0

**BXP6200B** 

#### FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it.

#### Visit our website to:



Get usage advice, brochures, trouble shooter, service and repair information: www.aeg.com/support



Register your product for better service:

www.registeraeg.com



Buy Accessories, Consumables and Original spare parts for your appliance: www.aeg.com/shop

#### **CUSTOMER CARE AND SERVICE**

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.


The information can be found on the rating plate.

- Marning / Caution-Safety information
- (i) General information and tips
- Environmental information

Subject to change without notice.

## **CONTENTS**

1. SAFETY INFORMATION	4
2. SAFETY INSTRUCTIONS	6
3. PRODUCT DESCRIPTION	9
4. CONTROL PANEL	10
5. BEFORE FIRST USE	11
6. DAILY USE	12
7. CLOCK FUNCTIONS	18
8. USING THE ACCESSORIES	19
9. ADDITIONAL FUNCTIONS	21
10. HINTS AND TIPS	23
11. CARE AND CLEANING	26
12. TROUBLESHOOTING	
13. TECHNICAL DATA	31
14. ENERGY EFFICIENCY	31
15. MENU STRUCTURE	32
16. ENVIRONMENTAL CONCERNS	33



## 1. A SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

## 1.1 Children and vulnerable people safety

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children of less than 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance and mobile devices with My AEG Kitchen
- Keep all packaging away from children and dispose of it appropriately.
- WARNING: The appliance and its accessible parts become hot during use. Keep children and pets away from the appliance when in use and when cooling down.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

## 1.2 General Safety

- · This appliance is for cooking purposes only.
- This appliance is designed for single household domestic use in an indoor environment.
- This appliance may be used in, offices, hotel guest rooms, bed & breakfast guest rooms, farm guest houses and other similar accommodation where such use does not exceed (average) domestic usage levels.
- Only a qualified person must install this appliance and replace the cable.
- Do not use the appliance before installing it in the built-in structure.
- Disconnect the appliance from the power supply before carrying out any maintenance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- WARNING: The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements or the surface of the appliance cavity.
- Always use oven gloves to remove or insert accessories or ovenware.
- Use only the food sensor (core temperature sensor) recommended for this appliance.
- To remove the shelf supports first pull the front of the shelf support and then the rear end away from the side walls.
   Install the shelf supports in the opposite sequence.
- Do not use a steam cleaner to clean the appliance.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door since they can scratch the surface, which may result in shattering of the glass.
- Before pyrolytic cleaning, remove all accessories and excessive deposits/spills from the appliance cavity.

#### 2. SAFETY INSTRUCTIONS

#### 2.1 Installation

## **↑** WARNING!

Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not pull the appliance by the handle.
- Install the appliance in a safe and suitable place that meets installation requirements.
- Keep the minimum distance from other appliances and units.
- Before mounting the appliance, check if the appliance door opens without restraint.
- The appliance is equipped with an electric cooling system. It must be operated with the electric power supply.
- The built-in unit must meet the stability requirements of DIN 68930.

Cabinet minimum height (Cabinet under the worktop minimum height)	578 (600) mm
Cabinet width	560 mm
Cabinet depth	550 (550) mm
Height of the front of the appliance	594 mm
Height of the back of the appliance	576 mm
Width of the front of the appliance	595 mm
Width of the back of the appliance	559 mm
Depth of the appliance	567 mm
Built in depth of the appliance	546 mm
Depth with open door	1027 mm

Ventilation opening minimum size. Opening placed on the bottom rear side	560x20 mm
Mains supply cable length. Cable is placed in the right corner of the back side	1500 mm
Mounting screws	4x25 mm

#### 2.2 Electrical connection

#### **⚠ WARNING!**

Risk of fire and electric shock.

- All electrical connections should be made by a qualified electrician.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Should the mains cable need to be replaced, this must be carried out by our Authorised Service Centre.
- Do not let mains cables touch or come near the appliance door or the niche below the appliance, especially when it operates or the door is hot.
- The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools.
- Connect the mains plug to the mains socket only at the end of the installation.
   Make sure that there is access to the mains plug after the installation.
- If the mains socket is loose, do not connect the mains plug.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.

- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.
- Fully close the appliance door before you connect the mains plug to the mains
- This appliance is supplied with a main plug and a main cable.

#### 2.3 Use

#### **⚠ WARNING!**

Risk of injury, burns and electric shock or explosion.

- Do not change the specification of this appliance.
- Make sure that the ventilation openings are not blocked.
- Do not let the appliance stay unattended during operation.
- Deactivate the appliance after each use.
- Be careful when you open the appliance door while the appliance is in operation. Hot air can release.
- Do not operate the appliance with wet hands or when it has contact with water.
- · Do not apply pressure on the open door.
- Do not use the appliance as a work surface or as a storage surface.
- Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.
- Do not let sparks or open flames to come in contact with the appliance when you open the door.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- · Do not share your Wi-Fi password.

#### **⚠** WARNING!

Risk of damage to the appliance.

- To prevent damage or discoloration to the enamel:
  - do not put ovenware or other objects in the appliance directly on the bottom.
  - do not put aluminium foil directly on the bottom of cavity of the appliance.

- do not put water directly into the hot appliance.
- do not keep moist dishes and food in the appliance after you finish the cooking.
- be careful when you remove or install the accessories.
- Discoloration of the enamel or stainless steel has no effect on the performance of the appliance.
- Use a deep pan for moist cakes. Fruit juices cause stains that can be permanent.
- Always cook with the appliance door closed.
- If the appliance is installed behind a furniture panel (e.g. a door) make sure the door is never closed when the appliance operates. Heat and moisture can build up behind a closed furniture panel and cause subsequent damage to the appliance, the housing unit or the floor. Do not close the furniture panel until the appliance has cooled down completely after use.

#### 2.4 Care and cleaning

#### **↑** WARNING!

Risk of injury, fire, or damage to the appliance.

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Make sure the appliance is cold. There is the risk that the glass panels can break.
- Replace immediately the door glass panels when they are damaged. Contact the Authorised Service Centre.
- Be careful when you remove the door from the appliance. The door is heavy!
- Clean regularly the appliance to prevent the deterioration of the surface material.
- Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- If you use an oven spray, follow the safety instructions on its packaging.

### 2.5 Pyrolytic cleaning

## **⚠ WARNING!**

Risk of Injury / Fires / Chemical Emissions (Fumes) in Pyrolytic Mode.

- Before carrying out the pyrolytic cleaning and initial preheating remove from the oven cavity:
  - any excess food residues, oil or grease spills / deposits.
  - any removable objects (including shelves, side rails, etc., provided with the appliance) especially any non-stick pots, pans, trays, utensils, etc.
- Read carefully all the instructions for pyrolytic cleaning.
- Keep children away from the appliance while the pyrolytic cleaning operates. The appliance becomes very hot and hot air is released from the front cooling vents.
- Pyrolytic cleaning is a high temperature operation that can release fumes from cooking residues and construction materials, as such consumers are advised to:
  - provide good ventilation during and after the pyrolytic cleaning.
  - provide good ventilation during and after the initial preheating.
- Do not spill or apply water on the oven door during and after the pyrolytic cleaning to avoid damaging the glass panels.
- Fumes released from all pyrolytic ovens / cooking residues as described are not harmful to humans, including children, or persons with medical conditions.
- Keep pets away from the appliance during and after the pyrolytic cleaning and initial preheating. Small pets (especially birds and reptiles) can be highly sensitive to temperature changes and emitted fumes.
- Non-stick surfaces on pots, pans, trays, utensils etc., can be damaged by the high temperature pyrolytic cleaning operation of all pyrolytic ovens and can be also a source for low level harmful fumes.

#### 2.6 Internal lighting

#### ♠ WARNING!

Risk of electric shock.

- Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational status of the appliance. They are not intended to be used in other applications and are not suitable for household room illumination.
- This product contains a light source of energy efficiency class G.
- Use only lamps with the same specifications.

#### 2.7 Service

- To repair the appliance contact the Authorised Service Centre.
- · Use original spare parts only.

## 2.8 Disposal


## **⚠ WARNING!**

Risk of injury or suffocation.

- Contact your municipal authority for information on how to dispose of the appliance.
- For information on how to dispose of the appliance, contact your dealer, manufacturer's authorized person, or your local solid waste operator.
- Disconnect the appliance from the mains supply.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- Remove the door catch to prevent children or pets from becoming trapped in the appliance.

## 3. PRODUCT DESCRIPTION

## 3.1 General overview




- 1 Control panel
- 2 Knob for the heating functions
- 3 Display
- 4 Control knob
- 5 Socket for the food sensor
- 6 Heating element
- 7 Lamp
- 8 Fan
- 9 Shelf support, removable
- 10 Cavity embossment
- 11 Shelf positions

#### 3.2 Accessories


#### Wire shelf

For cookware, cake tins, roasts.




#### **Baking tray**

For cakes and biscuits.




#### Grill- / Roasting pan

To bake and roast or as a pan to collect fat.



#### Food sensor

To measure the temperature inside food.



## 4. CONTROL PANEL

#### 4.1 Retractable knobs

To use the appliance press the knob. The knob comes out.

#### 4.2 Control panel overview

Select a heating function to turn on the appliance. Turn the knob for the heating

functions to the off position to turn the appliance off.




## 4.3 Display



Display with key functions.

#### **Display indicators**



<b>Progress bar</b> - for temperature or time. The bar is fully red when the appliance reaches the set temperature.	
Steam cooking indicator	<u></u>
Steam cooking indicator	W
Food sensor indicator	N

## 5. BEFORE FIRST USE



Refer to Safety chapters.

## 5.1 Initial cleaning

## Before the first use, clean the empty appliance and set the time:









Set the time. Press OK.

## 5.2 Initial preheating

Preheat the empty oven before the first use.

Step 1	Remove all accessories and removable shelf supports from the oven.
Step 2	Set the maximum temperature for the function: .  Let the oven operate for 1 h.
Step 3	Set the maximum temperature for the function:    Set the oven operate for 15 min.
The over	n can emit an odour and smoke during preheating. Make sure that the room is ventilated.

## 5.3 Wireless connection 🦻

To connect the appliance you need:

- · Wireless network with the Internet connection.
- Mobile device connected to the same wireless network.

Step 1	To download My AEG Kitchen app: Scan the QR code on the rating plate with the camera on your		
	mobile device to be redirected to AEG Homepage. The rating plate is on the front frame of the ap-		
pliance cavity. You can also download the app directly from the app store.			

Step 2	Follow the app onboarding instructions.  Turn the knob for the heating functions to select: = .		
Step 3 Turn the ki			
Step 4	Turn the control knob to select: Settings. Turn on Wi-Fi. Refer to "Menu Structure" chapter.		
Frequency	2.4 GHz WLAN		
	2400 - 2483.5 MHz		
Protocol	DI IEEE 802.11b DSSS, 802.11g/n OFDM		
Max Power	er EIRP < 20 dBm (100 mW)		
Wi-Fi module	dule NIUS-50		

#### 5.4 Software licences

The software in this product contains components that are based on free and open source software. AEG acknowledges the contributions of the open software and robotics communities to the development project.

To access the source code of these free and open source software components whose

license conditions require publishing, and to see their full copyright information and applicable license terms, visit: http://aeg.opensoftwarerepository.com (folder NIUS).

## 6. DAILY USE

WARNING!

Refer to Safety chapters.

## 6.1 How to set: Heating functions

Step 1	Step 1 Turn the knob for the heating functions and select a heating function.				
Step 2	tep 2 Turn the control knob to set the temperature.				
	Steam cooking				
Make sure	Make sure that the oven is cold.				
	Step 1	Step 2	Step 3	Step 4	

#### Steam cooking







Preheat the empty oven for 10 min to create humidity. Put food in the oven.

Fill the cavity embossment with tap water.

Select the steam heating function.

Set the temperature.

(i) The maximum capacity of the cavity embossment is 250 ml. Do not refill the cavity embossment during cooking or when the oven is hot.

## When the steam cooking ends:

Step 1 Step 2 Step 3

Turn the knob for the heating functions to the off position to turn off the oven.

Carefully open the door. Released humidity can cause burns.

Make sure that the oven is cold. Remove the remaining water from the cavity embossment.

## 6.2 Heating functions

Heating function	Application
	To bake on up to three shelf positions at the same time and to dry food. Set the temperature 20 - 40 °C lower than for Conventional Cooking.
True Fan Cooking	
	To bake and roast food on one shelf position.
Conventional Cooking	
	To add humidity during the cooking. To get the right colour and crispy crust during baking. To give more juiciness during reheating. To preserve fruit or vegetables.
SteamBake	
	To bake pizza. To make intensive browning and a crispy bottom.
Pizza Function	
Bottom Heat	To bake cakes with crispy bottom and to preserve food.
Bottom neat	
*	To make convenience food (e.g., french fries, potato wedges or spring rolls) crispy.
Frozen Foods	

Heating function	Application
Moist Fan Baking	This function is designed to save energy during cooking. When you use this function, the temperature in the cavity may differ from the set temperature. The residual heat is used. The heating power may be reduced. For more information refer to "Daily Use" chapter, Notes on: Moist Fan Baking.
Grill	To grill thin pieces of food and to toast bread.
Turbo Grilling	To roast large meat joints or poultry with bones on one shelf position. To make gratins and to brown.
Menu	To enter the Menu: Assisted Cooking, Cleaning, Settings.

## 6.3 Notes on: Moist Fan Baking

This function was used to comply with the energy efficiency class and ecodesign requirements (according to EU 65/2014 and EU 66/2014). Tests according to: IEC/EN 60350-1.

The oven door should be closed during cooking so that the function is not interrupted and the oven operates with the highest energy efficiency possible.

When you use this function the lamp automatically turns off after 30 sec.

For the cooking instructions refer to "Hints and tips" chapter, Moist Fan Baking. For general energy saving recommendations refer to "Energy Efficiency" chapter, Energy Saving.

## 6.4 How to set: Assisted Cooking

Every dish in this submenu has a recommended heating function and temperature. Use the function to prepare a dish quickly with default settings. You can also adjust the time and the temperature during cooking.

When the function ends check if the food is ready.

or some of the dishes you can also cook vith:		The degree to which a dish is cooked:	
Food Sensor		Rare Medium Well done	
Step 1	Step 2	Step 3	Step 4
	<b>(</b> )	P1 - P	OK OK

Enter the menu.	Select Assisted Cooking.	Select the dish. Press	Insert the dish to the oven.
	Press OK.	OK.	Confirm setting.

### 6.5 Assisted Cooking

tion

shoulder

لسا

		Legend	
Legend		55	Preheat the appliance before you start cooking.
P	Food sensor available. Place the Food sensor in the thickest part of the dish. The appliance turns off when the set Food sensor temperature is reached.		
			Shelf level.
		The display shows <b>P</b> and a <b>number</b> of the	
البيا	The amount of water for the steam func-		

Dish Weight Shelf level / Accessory Roast Beef, rare 1 🖊 🗀 2; baking tray 2 Roast Beef, medium 1 - 1.5 kg; 4 - 5 cm Fry the meat for a few minutes on a hot pan. Insert to the thick pieces appliance. Roast Beef, well 3 done Steak, medium 180 - 220 g per 3; roasting dish on wire shelf piece; 3 cm thick 4 Fry the meat for a few minutes on a hot pan. Insert to the slices appliance. Beef roast / braised 1.5 - 2 kg 2; roasting dish on wire shelf (prime rib, top round, 5 Fry the meat for a few minutes on a hot pan. Add liquid. thick flank) Insert to the appliance. Roast Beef, rare 6 (slow cooking) 크 2: baking tray Roast Beef, medium - 1.5 kg; 4 - 5 cm Use your favourite spices or simply salt and fresh groun-7 (slow cooking) thick pieces ded pepper. Fry the meat for a few minutes on a hot pan. Insert to the appliance. Roast Beef, well 8 done (slow cooking) Fillet, rare (slow cook-9 ing) 크 2; baking tray Fillet, medium (slow 0,5 - 1.5 kg; 5 - 6 Use your favourite spices or simply salt and fresh groun-10 cooking) cm thick pieces ded pepper. Fry the meat for a few minutes on a hot pan. Insert to the appliance. Fillet, done (slow 11 cooking) Veal roast (e.g. shoul-0.8 - 1.5 kg; 4 cm ☐ 2; roasting dish on wire shelf 12 thick pieces Use your favourite spices. Add liquid. Roast covered. Pork roast neck or 1.5 - 2 kg 2; roasting dish on wire shelf 13

Turn the meat after half of the cooking time.

	Dish	Weight	Shelf level / Accessory
14	Pulled pork (slow cooking)	1.5 - 2 kg	Use your favourite spices. Turn the meat after half of the cooking time to get an even browning.
15	Loin, fresh	1 - 1.5 kg; 5 - 6 cm thick pieces	2; roasting dish on wire shelf Use your favourite spices.
16	Spare Ribs	2 - 3 kg; use raw, 2 - 3 cm thin spare ribs	3; deep pan Add liquid to cover the bottom of a dish. Turn the meat after half of the cooking time.
17	Lamb leg with bones	1.5 - 2 kg; 7 - 9 cm thick pieces	Add liquid. Turn the meat after half of the cooking time.
18	Whole chicken	1 - 1.5 kg; fresh	Use your favourite spices. Turn the chicken after half of the cooking time to get an even browning.
19	Half chicken	0.5 - 0.8 kg	Use your favourite spices.
20	Chicken breast	180 - 200 g per piece	Use your favourite spices. Fry the meat for a few minutes on a hot pan.
21	Chicken legs, fresh	-	If you marinated chicken legs first, set lower temperature and cook them longer.
22	Duck, whole	2 - 3 kg	2; roasting dish on wire shelf Use your favourite spices. Put the meat on roasting dish. Turn the duck after half of the cooking time.
23	Goose, whole	4 - 5 kg	2; deep pan Use your favourite spices. Put the meat on deep baking tray. Turn the goose after half of the cooking time.
24	Meat loaf	1 kg	2; wire shelf Use your favourite spices.
25	Whole fish, grilled	0.5 - 1 kg per fish	Fill the fish with butter and use your favourite spices and herbs.
26	Fish fillet	-	Use your favourite spices.
27	Cheesecake	-	28 cm springform tin on wire shelf
28	Apple cake	-	155 2; 400 - 150 ml; baking tray
29	Apple tart	-	2; pie form on wire shelf
			-

	Dish	Weight	Shelf level / Accessory
30	Apple pie	-	100 - 150 ml;  22 cm pie form on wire shelf
31	Brownies	2 kg of dough	3; deep pan
32	Chocolate muffins	-	100 - 150 ml; muffin tray on wire shelf
33	Loaf cake	-	2; loaf pan on wire shelf
34	Baked potatoes	1 kg	2; baking tray Put the whole potatoes with skin on baking tray.
35	Wedges	1 kg	3; baking tray lined with baking paper Use your favourite spices. Cut potatoes into pieces.
36	Grilled mixed vegeta- bles	1 - 1.5 kg	3; baking tray lined with baking paper Use your favourite spices. Cut the vegetables into pieces.
37	Croquets, frozen	0.5 kg	3; baking tray
38	Pommes, frozen	0.75 kg	3; baking tray
39	Meat / vegetable la- sagna with dry pasta sheets	1 - 1.5 kg	2; casserole dish on wire shelf
40	Potato gratin (raw potatoes)	1 - 1.5 kg	1; casserole dish on wire shelf Rotate the dish after half of the cooking time.
41	Pizza fresh, thin	-	100 ml; baking tray lined with baking paper
42	Pizza fresh, thick	-	35 2; baking tray lined with baking paper
43	Quiche	-	2; baking tin on wire shelf
44	Baguette / Ciabatta / White bread	0.8 kg	150 ml; baking tray lined with baking paper More time needed for white bread.
45	All grain / rye / dark bread all grain in loaf pan	1 kg	150 ml; baking tray lined with baking paper / wire shelf

## 7. CLOCK FUNCTIONS


## 7.1 Clock functions

Clock Function	Application
When the timer ends, the signal sounds.  Minute minder	
Cooking time	When the timer ends, the signal sounds and the heating function stops.
Time Delay	To postpone the start and / or end of cooking.
Ť) Uptimer	Maximum is 23 h 59 min. This function has no effect on the operation of the oven. To turn on and off the Uptimer select: Menu, Settings.

	How to	set: Time of day			
Ste	p 1	Step 2	Step 3		
change the time of day enter the menu and select Settings, Time of day.  Set the clock.  Press: OK.					
How to set: Minute minder					
Step 1		Step 2	Step 3		
	The display shows: 0:00	O			
Press: O.		Set the Minute minder	Press: OK		
Timer starts counting down immediately.					

How to set: Cooking time					
Step 1	Step 2		Step 3	Step 4	
		The display shows: 0:00			
Choose a heating function and set the temperature.	Press repeatedly:	STOP	Set the cooking time.	Press: OK.	

i Timer starts counting down immediately.



i Timer starts counting down at a set start time.

## 8. USING THE ACCESSORIES



Refer to Safety chapters.


## 8.1 Inserting accessories

A small indentation at the top increases safety. The indentations are also anti-tip

devices. The high rim around the shelf prevents cookware from slipping of the shelf.


#### Wire shelf:

Push the shelf between the guide bars of the shelf support.



#### Baking tray / Deep pan:

Push the tray between the guide bars of the shelf support.



## 8.2 Food Sensor

Food Sensor - measures the temperature inside the food.

There are two temperatures to be set:		
°C The oven temperature.	The core temperature.	


	For the best cooking resu	ults:
Ingredients should be at room temperature.	Do not use it for liquid dishes.	During cooking it must remain in the dish.


## 8.3 How to use: Food Sensor

Step 1	Turn on the oven.		
Step 2	Set a heating function and, if necessary, the oven temperature.		
Step 3	Insert: Food Sensor.		
Meat, pou	Itry and fish Casserole		

Insert the tip of Food Sensor into the centre of meat, fish, in the thickest part if possible. Make sure that at least 3/4 of Food Sensor is inside of the dish.

Insert the tip of Food Sensor exactly in the centre of the casserole. Food Sensor should be stabilized in one place during baking. Use a solid ingredient to achieve that. Use the rim of the baking dish to support the silicone handle of Food Sensor. The tip of Food Sensor should not touch the bottom of a baking dish.





Step 4 Plug Food Sensor into the socket at the front of the oven. The display shows the current temperature of: Food Sensor.

Step 5 - press to set the core temperature of the sensor.

Step 6 OK - press to confirm.

When food reaches the set temperature, the signal sounds. You can choose to stop or to continue cooking to make sure the food is well done.

Step 7 Remove Food Sensor plug from the socket and remove the dish from the oven.

#### ♠ WARNING!

There is a risk of burns as Food Sensor becomes hot. Be careful when you unplug it and remove it from the food.

## 9. ADDITIONAL FUNCTIONS

#### 9.1 Lock

#### This function prevents an accidental change of the appliance function.

Turn it on when the appliance works - the set cooking continues, the control panel is locked. Turn it on when the appliance is off - it cannot be turned on, the control panel is locked.






A signal sounds.

(i) 3 x - flashes when the lock is turned on.

#### 9.2 Automatic switch-off

For safety reasons the appliance turns off after some time, if a heating function works and you do not change any settings.

(°C)	(h)
30 - 115	12.5
120 - 195	8.5
200 - 245	5.5




The Automatic switch-off does not work with the functions: Light, Food sensor, Time Delay.

## 9.3 Cooling fan

When the appliance operates, the cooling fan turns on automatically to keep the surfaces of the appliance cool. If you turn off the appliance, the cooling fan can continue to operate until the appliance cools down.

## 9.4 Mechanical door lock

The door lock is unlocked when you buy the oven.



#### **!** CAUTION!

Do not move the door lock vertical-


Do not push the door lock when you close the oven door.



#### 9.5 How to use: Mechanical door lock

Step 1 To lock the door pull the door lock forward until it locks.


Step 2 To unlock the door push the door lock back into the panel.



#### Opening the locked door

You can open the door when the door lock is locked.

**Step 1** Push the door lock slightly and open the door by pulling it with the handle.



When you close the door make sure that the door lock remains locked.

## 10. HINTS AND TIPS

## 10.1 Cooking recommendations



The temperature and cooking times in the tables are guidelines only. They depend on the recipes and the quality and quantity of the ingredients used.

Your appliance may bake or roast differently to the appliance you had before. The hints below show recommended settings for temperature, cooking time and shelf position for specific types of the food.

If you cannot find the settings for a special recipe, look for the similar one.

## 10.2 Moist Fan Baking


For the best results follow suggestions listed in the table below.

Use the third shelf position.

*	(°C)	(min)
Pasta gratin	200 - 220	45 - 55
Potato gratin	180 - 200	70 - 85
Moussaka	170 - 190	70 - 95
Lasagne	180 - 200	75 - 90
Cannelloni	180 - 200	70 - 85
Bread pudding	190 - 200	55 - 70
Rice pudding	170 - 190	45 - 60
Apple cake, made of sponge cake mixture (round cake tin)	160 - 170	70 - 80
White bread	190 - 200	55 - 70

## 10.3 Moist Fan Baking - recommended accessories

Use the dark and non-reflective tins and containers. They have better heat absorption than the light colour and reflective dishes.



# 10.4 Cooking tables for test institutes

#### Information for test institutes

Tests according to: EN 60350, IEC 60350.

Baking on one level - baking in tins

*		°C	min	
Fatless sponge cake	True Fan Cooking	160	45 - 60	2
Fatless sponge cake	Conventional Cooking	160	45 - 60	2

*		°C	min	<u>}</u>
Apple pie, 2 tins Ø20 cm	True Fan Cooking	160	55 - 65	2
Apple pie, 2 tins Ø20 cm	Conventional Cooking	180	55 - 65	1
Short bread	True Fan Cooking	140	25 - 35	2
Short bread	Conventional Cooking	140	25 - 35	2

Baking on one level - biscuits Use the third shelf position.

*		°C	min
Small cakes, 20 per tray, preheat the empty oven	True Fan Cooking	150	20 - 30
Small cakes, 20 per tray, preheat the empty oven	Conventional Cooking	170	20 - 30

## Multilevel baking - biscuits

*		°c	min	<u></u>
Short bread	True Fan Cooking	140	25 - 45	2/4
Small cakes, 20 per tray, preheat the empty oven	True Fan Cooking	150	25 - 35	1 / 4
Fatless sponge cake	True Fan Cooking	160	45 - 55	2/4
Apple pie, 1 tin per grid (Ø 20 cm)	True Fan Cooking	160	55 - 65	2/4

#### Grill

Preheat the empty oven for 5 minutes.

Grill with the maximum temperature setting.

*		min	] <u>←</u>	
Toast	Grill	1 - 2	5	
Beef steak, turn halfway through	Grill	24 - 30	4	

## 11. CARE AND CLEANING

♠ WARNING!

Refer to Safety chapters.

#### 11.1 Notes on cleaning



Clean the front of the appliance only with a microfibre cloth with warm water and a mild detergent.

Use a cleaning solution to clean metal surfaces.

Clean stains with a mild detergent.



Clean the cavity after each use. Fat accumulation or other residue may cause fire.

Do not store the food in the appliance for longer than 20 minutes. Dry the cavity only with a microfibre cloth after each use.



Clean all accessories after each use and let them dry. Use only a microfibre cloth with warm water and a mild detergent. Do not clean the accessories in a dishwasher.

Do not clean the non-stick accessories using abrasive cleaner or sharp-edged objects.

Accessories

#### 11.2 How to clean: Cavity embossment

Clean the cavity embossment to remove limestone residue after cooking with steam.

Step 1	Step 2	Step 3
Pour: 250 ml of white vinegar into the cavity embossment. Use maximum 6% vinegar without any additives	Let the vinegar dissolve the lime- stone residue at the ambient tem- perature for 30 minutes.	Clean the cavity with warm water and a soft cloth.


For the function: SteamBake clean the oven for every 5 - 10 cooking cycles.

## 11.3 How to remove: Shelf supports

Remove the shelf supports to clean the oven.


Step 1 Turn off the oven and wait until it is

Step 2 Pull the front of the shelf support away from the side wall.



Step 3 Pull the rear end of the shelf support away from the side wall and remove

Step 4 Install the shelf supports in the opposite sequence.



## 11.4 How to use: Pyrolytic Cleaning

Clean the oven with Pyrolytic Cleaning.



There is a risk of burns.

#### **↑** CAUTION!

If there are other appliances installed in the same cabinet, do not use them at the same time as this function. It can cause damage to the oven.

#### Before the Pyrolytic Cleaning:

Turn off the oven and wait until it is cold.

ble shelf supports.

Remove all accessories and remova- Clean the oven floor and the inner door glass with warm water, a soft cloth and a mild detergent.

	Pyrolytic Clea	ning
Step 1	Enter menu: Cleaning ເm/.	
	Option	Duration
	C1 - Light cleaning	1 h
(	2 - Normal cleaning	1 h 30 min
C	3 - Thorough cleaning	3 h
Step 2	OK - press to select the cleaning programme.	
Step 3	OK - press to start the cleaning.	
Step 4	After cleaning, turn the knob for the heating functions to the off position.	

# When the cleaning ends: Turn off the oven and wait until it is cold. Clean the cavity with a soft cloth. Remove the residue from the bottom of the cavity.

## 11.5 Cleaning Reminder

#### The oven reminds you when to clean it with pyrolytic cleaning.

flashes in the display for 5 sec after each cooking session.

To turn off the reminder enter the Menu and select Settings, Cleaning Reminder.

## 11.6 How to remove and install: Door

You can remove the door and the internal glass panels to clean it. The number of glass panels is different for different models.


#### **. !** WARNING!

The door is heavy.

## **⚠** CAUTION!


Carefully handle the glass, especially around the edges of the front panel. The glass can break.


Step 2 Lift and press the clamping levers (A) on the two door hinges.




Step 3	Close the oven door to the first opening position (approximately 70° angle). Hold the door at both
	sides and pull it away from the oven at an upwards angle. Put the door with the outer side down on
	a soft cloth on a stable surface.

Step 4	edge of the door at the two sides
	and push inwards to release the clip seal.








Step 7	Clean the glass panel with water and soap. Dry the glass panel care-
	fully. Do not clean the glass panels in the dishwasher.

Step 8 After cleaning, do the above steps in the opposite sequence.



Step 9 Install the smaller panel first, then the larger and the door.

Make sure that the glasses are inserted in the correct position otherwise the surface of the door may overheat.

## 11.7 How to replace: Lamp




Risk of electric shock.

The lamp can be hot.

	Before you replace the lamp:	
Step 1	Step 2	Step 3
Turn off the oven. Wait until the oven is cold.	Disconnect the oven from the mains.	Put a cloth on the bottom of the cavity.

## Top lamp

Step 1 Turn the glass cover to remove it.



Step 2	Clean the glass cover.
Step 3	Replace the lamp with a suitable 300 °C heat-resistant lamp.
Step 4	Install the glass cover.

## 12. TROUBLESHOOTING



Refer to Safety chapters.

#### 12.1 What to do if...

In any cases not included in this table please contact with an Authorised Service Centre.

0	=	=	_	ì
-			₹	1
IL			J	ı

#### The appliance does not turn on or does not heat up

Problem	Check if	
You cannot activate or operate the appliance.	The appliance is correctly connected to an electrical supply.	
The appliance does not heat up.	The automatic switch-off is deactivated.	
The appliance does not heat up.	The appliance door is closed.	
The appliance does not heat up.	The fuse is not blown.	
The appliance does not heat up.	The Lock is off.	



#### Components

Problem	Check if	
The lamp is turned off.	Moist Fan Baking - is turned on.	
The lamp does not work.	The lamp is burnt out.	
The Food sensor does not operate.	The plug of the Food sensor is fully inserted into the socket.	



#### **Error codes**

The display shows	Check if	
Err C2	You removed the Food sensor plug from the socket.	
Err C3	The appliance door is closed or the door lock is not broken.	
Err F102	The appliance door is closed.	
Err F102	The door lock is not broken.	
00:00	There was a power cut. Set the time of day.	

If the display shows an error code that is not in this table turn the house fuse off and on to restart the appliance. If the error code recurs contact an Authorised Service Centre.



#### Cleaning

oldaming				
Problem	Check if			
The water leaks out of the cavity embossment.	There is too much water in the cavity embossment.			

#### 12.2 Service data

If you cannot find a solution to the problem yourself, contact your dealer or an Authorised Service Centre.

The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of the appliance cavity. Do not remove the rating plate from the appliance cavity.

We recommend that you write the data here:		
Model (MOD.)		
Product number (PNC)		
Serial number (S.N.)		

## 13. TECHNICAL DATA

#### 13.1 Technical data

Voltage	230 V
Frequency	50 Hz

## 14. ENERGY EFFICIENCY

## 14.1 Product Information and Product Information Sheet according to EU **Ecodesign and Energy Labelling Regulations**

Supplier's name	AEG
Model identification	BBP6252B 944188793 BFP6252M 944188792 BFP6252W 944188794 BKB6P2B0 944188796 BKH6P2M0 944188795 BKH6P2W0 944188797 BXP6200B 944188799
Energy Efficiency Index	81.2
Energy efficiency class	A+
Energy consumption with a standard load, conventional mode	1.09 kWh/cycle
Energy consumption with a standard load, fan-forced mode	0.69 kWh/cycle
Number of cavities	1
Heat source	Electricity
Volume	71
Type of oven	Built-In Oven

	BBP6252B	35.5 kg
	BFP6252M	36.0 kg
	BFP6252W	35.5 kg
Mass	BKB6P2B0	35.5 kg
	BKH6P2M0	36.0 kg
	BKH6P2W0	35.5 kg
	BXP6200B	35.5 kg

IEC/EN 60350-1 - Household electric cooking appliances - Part 1: Ranges, ovens, steam ovens and grills - Methods for measuring performance.

## 14.2 Energy saving



The appliance has features which help you save energy during everyday cooking.

Make sure that the appliance door is closed when the appliance operates. Do not open the appliance door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position.

Use metal cookware to improve energy saving.

When possible, do not preheat the appliance before cooking.

Keep breaks between baking as short as possible when you prepare a few dishes at one time.

#### Cooking with fan

When possible, use the cooking functions with fan to save energy.

#### Residual heat

The fan and lamp continue to operate. When you turn off the appliance, the display shows

the residual heat. You can use that heat to keep the food warm.

When the cooking duration is longer than 30 min, reduce the appliance temperature to minimum 3 - 10 min before the end of cooking. The residual heat inside the appliance will continue to cook.

Use the residual heat to warm up other dishes.

#### Keep food warm

Choose the lowest possible temperature setting to use residual heat and keep a meal warm. The residual heat indicator or temperature appears on the display.

#### Cooking with the lamp off

Turn off the lamp during cooking. Turn it on only when you need it.

#### **Moist Fan Baking**

Function designed to save energy during cooking.

When you use this function the lamp automatically turns off after 30 sec. You may turn on the lamp again but this action will reduce the expected energy savings.

## 15. MENU STRUCTURE

#### 15.1 Menu

Step 1	Step 2	Step 3	Step 4	Step 5











- select to enter

Select the option from Menu structure and press OK.

Select the setting.

OK - press to confirm setting. Adjust the value and press OK.


Turn the knob for the heating functions to the off position to exit the Menu.


Menu structure							
	Assisted Cooking ** Cleaning m/		Settings <sup>(</sup> )				
	Settings						
01	Time of day	Change	02	Display brightness	1 - 5		
03	Key tones	1 - Beep 2 - Click 3 - Sound off	04	Buzzer volume	1 - 4		
05	Food Sensor Action	1 - Alarm and stop 2 - Alarm	06	Uptimer	On / Off		
07	Light	On / Off	08	Fast Heat Up	On / Off		
09	Cleaning Reminder	On / Off	10	Wi-Fi	On / Off		
11	Auto remote operation	On / Off	12	Forget network	Yes / No		
13	Demo mode	Activation code: 2468	14	Software version	Check		
15	Reset all settings	Yes / No					

## 16. ENVIRONMENTAL CONCERNS

Recycle materials with the symbol  $\circlearrowleft$ . Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of

appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.





## aeg.com



