
# Operation Guide

Before initial use, please carry out the initial operation procedure as per the INSTRUCTION MANUAL (see "Prior to initial use" section for full details). This guide does not replace the description in the INSTRUCTION MANUAL. Before you start, read and follow the "safety" chapter and observe the "Appliance parts" chapter. The **INSTRUCTION MANUAL** also contains further tips for correct handling, 9. Make sure the steam knob is on "OFF" position. cleaning and descaling, as well as a "Faults and rectification" section.

## Pre-heating the brewing system

In order to get the best coffee brewing temperature. Before brewing espresso each time, we recommend brewing coffee without coffee grounds once to preheat the machine and cup(s).






























filter holder.

brewing system, filter and



We recommend the grinding amount as below:

11-13 g for a single espresso

Automatic grinding

You can reset the auto-grinding time if needed.

Selecting the filter size

size filter if you want to make a double-cup espresso.

18-21 g for a double espresso

Setting the grind size


Here are some coffee beans we recommend: he grind size will affect the water flow rate through the coffee grounds in the filter basket and the flavo

The grind size selector has 15 grind settings.

he smaller the number, the finer the grind size;

he larger the number, the coarser the grind size.

We recommend you start with setting 8 and adjust as needed.



nsert the 1 CUP size filter or 2 CUP size filter into the filter holder. Choose the 1 CUP size filter if you want to make a single-cup espresso, and choose 2 CUP

> 1 CUP 2 CUP



01. Insert the filter holder into the bracket, push and hold the filter holder to engage the grinding

the machine will not set this grinding time as a new automatic grinding time.





the grinding process.



03. Your espresso machine will set this grinding time as the new auto-grinding time. When you grind the coffee bean next time, just push the portafilter once, and the grinder will start to grind, the grinding 1. LAVAZZA espresso Barista 2. LAVAZZA SUPER CREMA 3. STARBUCKS ESPRESSO ROAST

time is set to the last Manual Grinding Time. You can easily find these recommend coffee beans on Amazon!



# Grinding the coffee beans

O2. Insert the filter holder into the bracket, push the filter holder once to engage the grinding activation

O3. The grinder will grind for 14 seconds (default auto-grinding time), then stop automatically.

04. The automatic grinding process can be interrupted at any time by pushing and releasing the switch.

# Tamping the coffee grounds

## How to use mat?

on the edge of table or

5. It can also be used to knock

Why use the distributor?

the espresso puck out of the





the right triangle of the mat tamper and distributor on mat while tamping coffee so that it will fit well with the the mat.

During espresso brewing, it's common for an individual to tamp the loaded portafilter by pressing :

error of irregular compression, which causes channeling. Channeling may be described as uneven

evenly flowing through the entire bed. This channeling leads to improperly saturated grounds, and

poorly brewed espresso, resulting in an unpalatable and bitter flavor.

the countertop edge with an espresso tamper. The biggest problem with brewing espresso is the huma

ompression distributed throughout the filter. Water finds the path of the least resistance rather than



to even the surface of coffee grounds is now even, but the

How to use the distributor?

## How to tamp the coffee grounds?

Tamp down firmly using approx. 11-22lbs (5-10kg) of pressure.

The amount of pressure is not as critical as ensuring that consistent pressure is applied.

As a guide for the right amount of coffee grounds, the top edge of the metal cap on the tamper sl level with the top of the filter after the coffee grounds have been tamped, and the amount of the coff

## How to tamp the coffee grounds?

grounds after tamping should reach the MAX line.

1. Tamp down firmly using 2. The amount of the coffee 3. Wipe edges to remove any

Note: Wipe edges to remove any residual conce ground difficult to lock in or water may leak from the filter holder while brewing coffee.

approx 11-22lbs (5-10kg) of grounds after tamping should residual coffee grounds.

Wipe edges to remove any residual coffee grounds. Otherwise, the filter holder may be

inside of the coffee grounds

insert it into the group head. right.

20 bar Italian pump.

Making espresso


Volume of 1 CUP espresso: approx. 1-1.5oz (30-45ml)

Volume of 2 CUP espresso: approx. 2-2.5oz (60-75ml)

Ensure the steam volume regulator is switched to the OFF position before making espresso.

Press the 1 CUP button to make a single-cup espresso or the 2 CUP button to make a double-cup espress


Note: The amount of espresso extracted into the cup will vary depending on your grind size, a mount of coffee grounds used, and tamping pressure.







11. Wash all parts with warm water DON'T USE A DISHWASHER


## Start frothing milk While the machine is making espresso, a pumping noise can be heard, this is a normal operation of the







































You can watch the Instructional Video here: https://m.media-amazon.com/images/I/F102ReWauyL.mp4

Tip just below the milk surface. Wand half way in the milk.



15. Remove the Pitcher from 16. Tap the Pitcher to release If the steam wand cannot produce steam normally, it is likely that the steam wand is clogged by milk

"PRE-HEAT" position.

The steam indicator stops

flashing and is fully

illuminated = Ready.

procedure.







residues. Please remove the head of the steam wand and clean it with a cleaning needle.

Steam Wand Maintenance Tips

After frothing milk, it is recommended to flush the residual milk from the steam wand.



2. Turn the Steam Knob to 3. Let the steam flush out the 4. Turn Steam Knob to

residual milk.



to clean the tip hole of the back on the steam wand.

To resolve this: Our machines are equipped with an automatic pressure relief function. After using the steam system, there will be a huge pressure buildup inside the machine, and the 01. Select a finer grind setting.

machine will release steam from the drip tray to achieve the purpose of pressure relief. Please don't worry if you notice steam coming out of the drip tray. It means that the machine is starting a pressure relief

## Espresso Pressure Gauge High pressure zone

# Ideal Espresso Zone

The gauge needle indicates the extraction pressure. When it is positioned anywhere within 5-12 zone uring extraction, it means that the espresso has been extracted at the ideal pressure.





# Low pressure zone

When the gauge needle is in the 0-5 zone during extraction, it indicates that the espresso has been extracted with insufficient pressure.







- 02. Increase the amount of coffee grounds.
- 03. Increase the tamping pressure.
- 04. Check if the coffee beans used are fresh or use the recommend coffee beans.

## When the gauge needle is in the 12-20 zone during extraction, it indicates that the espresso has been extracted with too much pressure.



Clean and assemble the grinder


extraction. Please follow the steps below to clean and assemble the grinder.

To resolve this:

03. Decrease the tamping pressure.




- 01. Select a coarser grind setting. 02. Decrease the amount of coffee grounds.
- 04. Check if the coffee beans used are over-roasted. Please use the recommend coffee beans.



successfully.







with the cleaning brush. with the cleaning brush. the cleaning brush.



in place, you will hear a "click"

sound and feel it tight in place.

distributor anti-clockwise t assemble it to the grinder









and double buttons








any residual coffee grounds. the group head.

simultaneously for 5 seconds. and double espresso buttons




illuminate and the single button to brew.




























3. Once the amount of coffee 14. Press the corresponding 15. Wait until no more coffee 16. Press the HOT-WATER single or double button again. is dripping into the cup before button to complete the setup.

and turn the grinder clockwise sound and feel the grinder is clockwise to release it from unlocked, pull it out a in the grinder. downward direction.