



# 8DO (Digital Output) Board

1. Connect board to power transformer.
2. Connect 8DO to the RS485 I/O Network.
3. Use the rotary dials S1 & S2 to set the board number. Use switch S1 to set the "tens" portion of the board number, and S2 as the "ones" portion of the board number.  
Example: to set the board as 8DO #1, set S1 to zero and S2 to one.
4. Set RS485 termination jumpers UP if at either end of a daisy chain. Otherwise, set jumpers DOWN.

**NOTE:** If you change any dip switch settings while the board is powered, disconnect the power and repower the board to reset.





**NOTE:** This sheet is intended for use as a quick reference only. All installation technicians should read the installation and operation manuals for complete information.

Visit our website at [copeland.com/en-us/products/controls-monitoring-systems](https://copeland.com/en-us/products/controls-monitoring-systems) for the latest technical documentation and updates.  
For Technical Support call 833-409-7505 or email [ColdChain.TechnicalServices@Copeland.com](mailto:ColdChain.TechnicalServices@Copeland.com)