

Laresar

CORDLESS VACUUM CLEANER

USER MANUAL



Model: Elite 2

CONTENTS

1	IMPORTANT SAFETY WARNING	01
	1.1 Precautions When Using	01
	1.2 Notes on the Battery Pack	01
	1.3 Notes on Charging	02
	1.4 Storage and Maintenance Precautions	02
2	PACKAGE CONTENT	03
3	OVERVIEW & ACCESSORIES	03
	3.1 Overview	04
	3.2 Digital Display Screen	05
	3.3 Accessories	05
4	ASSEMBLING & WALL MOUNTING	06
	4.1 Product Assembling	06
	4.2 Wall-Mount Plate	08
5	HOW TO USE	08
	5.1 Power On/Off	08
	5.2 Select Cleaning Mode	09
6	CHARGING METHODS	09
	6.1 Charging Methods	09
	6.2 Battery Indicator	10
7	MAINTENANCE	11
	7.1 Main Body Cleaning	11
	7.2 Dust Cup Cleaning	11
	7.3 Filter Cleaning	12
	7.4 Brush Roller Cleaning	13
8	SPECIFICATION	14
9	TROUBLESHOOTING	14
10	WARRANTY	15
11	DISPOSAL	16

1. IMPORTANT SAFETY WARNING

 **ATTENTION:** Before using this machine, please read all instructions in the manual and cautionary markings on the machine carefully.

1.1 Precautions When Using

- ① This Laesar machine is not intended for use by persons (including children) with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the machine by a person responsible for their safety.
- ② Use only as described in this Laesar Operating Manual. If the machine is not working as it should, if it has received a sharp blow, if it has been dropped, damaged, left outdoors, or dropped into water, do not use and contact the Laesar Support Team.
- ③ Suitable for dry locations **ONLY**. Do not install, charge or use this machine outdoors, in a bathroom or within 10 feet (3 meters) of a pool. Do not use on wet surfaces and do not expose to moisture, rain or snow.
- ④ When using this machine, please keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts. Do not point the hose, aluminium alloy tube or other accessories at your eyes or ears or put them in your mouth.
- ⑤ Do not use to pick up hard objects, such as glass slag, needles, nails, etc.
- ⑥ Do not touch the charger with wet hands to avoid electric shock. 
- ⑦ Use only Laesar recommended accessories and replacement parts.
- ⑧ Do not use without the dust cup and filter(s) in place.
- ⑨ When removing or replacing a motorized brush bar, be careful not to pull the power button until the cleaner head has been reassembled.
- ⑩ Do not water or spill liquid onto the vacuum cleaner. If that happens, it will increase the risk of electric shock. 
- ⑪ Use extra care when cleaning on stairs.

1.2 Notes on the Battery Pack

- ① Do not throw the battery pack away, and it should be safely disposed in accordance with local regulations.
- ② Do not use a battery pack or machine that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury. 
- ③ Do not incinerate batteries or expose to high temperatures, as they may explode. 
- ④ The battery is a sealed unit and under normal circumstances poses no safety concerns. In the unlikely event that liquid leaks from the battery, do not touch the liquid as it may cause irritation or burns, and observe the following precautions: 
 - Skin contact – can cause irritation. Wash with soap and water.
 - Inhalation – can cause respiratory irritation. Expose to fresh air and seek medical advice.
 - Eye contact – can cause irritation. Immediately flush eyes thoroughly with water for at least 15 minutes. Seek medical attention.

- Disposal – wear gloves to handle the battery and dispose of immediately, following local ordinances or regulations.
- ⑤ When the battery pack is not in use, keep it away from paper clips, coins, keys, nails, screws or other small metal objects that could make a connection from one terminal to another.

1.3 Notes on Charging

- ① Before use, check the charger cord for signs of damage or ageing. A damaged or entangled charger cord increases the risk of fire and electric shock. 
- ② Never modify the charger in any way.
- ③ The charger has been designed for a specific voltage. Always check that the mains voltage is the same as that stated on the rating plate.
- ④ Unplug the charger when not in use for extended periods.
- ⑤ When your vacuum cleaner is fully charged, needs to be cleaned or repaired, please unplug the charger in time and do not pull the power cord directly.
- ⑥ Do not pull the cord to disconnect from a socket, grasp the plug and pull to disconnect.
- ⑦ Don't wrap the cord around the charger when storing.
- ⑧ Please fully recharge the battery, when first used or used after long time storage. If the product is not used for long time, please make sure the battery is recharged and used each three months at least.
- ⑨ If smoke or fire occurs during charging, unplug the charger immediately, and use a fire extinguisher to put out the fire. Do not use water to extinguish the fire, it will increase the risk of electric shock. 
- ⑩ Follow all charging instructions and do not charge the battery pack or the machine outside of the temperature range specified in the instructions. Charging improperly or at a temperature outside of the specified range may damage the battery and increase the risk of fire. To ensure maximum battery life, Laresar recommends the following: 
 - When not in use the machine should be stored at room temperature. Recommended range: 64°F (18°C) to 82°F (28°C).
 - The ambient temperature range for operation and charging should be 50°F (8°C) to 86°F (35°C).

1.4 Storage and Maintenance Precautions

- ① Please store the product under cool and dry environment. Please avoid long-time sunshine on the product.
- ② The charger must be removed from the socket before removing the battery, cleaning or maintaining the appliance.
- ③ Please use dry cloth to clean the vacuum cleaner. Please do not use gas or liquid that can make the surface cracked or color faded.
- ④ Do not apply any fragrance or scented product to the filter(s) of this machine. The chemicals in such products are known to be flammable and can cause the machine to catch fire.
- ⑤ Do not carry out any maintenance other than that shown in this manual, or advised by the Laresar Support Team.
- ⑥ Do not disassemble the machine as incorrect reassembly may result in an electric shock or fire. Contact the Laresar Support Team when a service or repair is required.

SAVE THESE INSTRUCTIONS



Do not use near open flames.



Do not store near heat sources.



Do not pick up water or liquids.



Do not pick up burning objects.



Do not put hands near the brush bar when the machine is in use.



Do not place on or near the cooker.

2. PACKAGE CONTENT

Please check and confirm the accessories and parts according to the following sheet before using.


Part Name	Quantity
Main Body	1
Foldable Extension Tube	1
Motorized Brush Head	1
Hardwood Roller	1
Long Crevice Nozzle	1
2 in 1 Upholstery Brush	1
Hair Cleaning Tool	1
Filter Replacement	1


Wall Mount Plate	1
Charger	1
Battery Pack	1
User Manual	1

3. OVERVIEW & ACCESSORIES


3.1 Overview

- ① Battery Pack
- ② Dust Cup
- ③ Foldable Extension Tube
- ④ Tube Folding Button
- ⑤ Motorized Brush Head Release Button
- ⑥ Motorized Brush Head
- ⑦ LED Light
- ⑧ Main Body Release Button
- ⑨ Digital Display Screen
- ⑩ Hardwood Roller






3.2 Digital Display Screen



3.3 Accessories


① 2 in 1 Upholstery Brush

Brush retractable design can help you remove dust and hair from both upholstered furniture and hard surface furniture.



② Long Crevice Nozzle

Remove dust on hard to reach area like windows, bed feet, gaps between tables and chairs, etc.




③ Hardwood Roller

Remove dust, debris and hair from hard floors and carpets.



④ Wall Mount Plate

Hold the vacuum on wall-mount plate for easy storage and battery charging.



⑤ Hair Cleaning Tool


Remove hair, rubbish and micro dust on the brush shaft to keep the brush head clean.



4. ASSEMBLING & WALL MOUNTING


4.1 Product Assembling

4.1.1 Install the Battery Pack




4.1.2 Install the Foldable Tube


- Connect the foldable tube with the main body until you hear of the sound of “click” of the main body release button.




- The tube can be folded by pressing the tube folding button so that you can easily clean the bottom of the bed and furniture without bending over and squatting.



4.1.3 Install Desired Cleaning Accessory



4.1.4 Install the Rolling Brushes




4.2 Wall-Mounted Dock

The vacuum cleaner cannot stand on its own. Fix the Wall-mount plate to the wall securely with the screws provided by Laresar.


WARNING

- Please make sure there is no gas, water or electrical cables and wires behind the mounting area.
- To avoid the dock dropping down, please make sure it must be installed firmly.

①



②



5. HOW TO USE




Before use, make sure that

- The battery is fully charged, and fixed in place.
- The dust cup and filters are cleaned, dried, and fixed in place.


5.1 Power On / Off

Press the switch button, the appliance will start to work. Press the button again to shut down the appliance.



5.2 Select Cleaning Mode

- The appliance is activated in Standard Cleaning Mode by default.
- Press the suction adjustment button once to switch to Strong Cleaning Mode. Press the button again to switch back to Standard Cleaning Mode.




x1 Strong Suction Mode
x2 Standard Suction Mode


6. CHARGING METHODS

6.1 Charging Methods


- ① Remove the Battery Pack and Charge it Separately



② Connect the Main Body to Charge




③ Hang on the Wall Mount to Charge



6.2 Battery Indicator

6.2.1 Charging Indicator

The battery indicator light will be flashing in red when being charged and turn blue when the battery is fully charged.



Red light flashing (Charging)
Blue light (Fully Charged)

6.2.2 Low Battery Level Indicator

When the battery level is under 20%, the battery indicator on the screen will start to flash in red. The appliance should be charged soon.




7. MAINTENANCE

Please clean it regularly to prolong the service life of the vacuum cleaner.

7.1 Main Body Cleaning


- Turn off the power before cleaning the body.
- Please use a neutral detergent, wipe the body with half-wet cloth.
- Please avoid sun exposure and store in a cool and dry place.



7.2 Dust Cup Cleaning

7.2.1 Empty the Dust Cup



- Press the dust cup release button to empty the dust.
- When using, if the garbage in the dust cup exceeds MAX Line, please empty it in time.



①




②



7.2.2 Clean the Dust Cup


- Press the dust cup release button and turn the dust cup in clockwise direction.
- Take out the dust cup, take out the filter sponge and the stainless steel filter in turn.



7.3 Filter Cleaning

⚠ Note: Wash the filters with cold water at least once every month.


- Filter sponge can be rinsed with water to remove dust.
- Please ensure the filters are completely dry before reassembly.




7.4 Brush Roller Cleaning

 **Note:** After long periods of use, the bristle may be jammed by hair or similar build-up. It's recommended to clean the brush roller periodically to ensure efficient operation and maintain suction.


- Remove the brush roller, gently clean the motored brush window and suction mouth.



- Remove the debris wrapped around the roller with Laresar Hair Cleaning Tool, then flush with water.



- Insert the brush roller into the motored brush window, push down the cover until it securely in place. (Please make sure the brush roller is completely dry before using.)



8. SPECIFICATION

Product	Cordless Vacuum Cleaner
Model	Elite 2
Rated Voltage	DC 22.2V
Battery Type	Li-ion
Power Adapter Input	100-240V~50-60Hz
Power Adapter Output	26.5V 0.5A
Cleaning Modes	Standard, Strong

9. TROUBLESHOOTING

ISSUE	CAUSE	SOLUTION
The vacuum cleaner can not work	(1) Out of power (2) Battery Pack not installed in place (3) The Motorized Brush Head is blocked with hair and other debris (4) Auto protection for overheating Switch Button can not work	(1) Charge the vacuum cleaner (2) Battery Pack installed in place (3) Clean the Motorized Brush Head (4) Restart after cooling down (5) Contact Laresar Support for replacement
Weak suction	(1) Dust Cup is full of garbage (2) Dust baffle misaligned (3) Filter are clogged or not installed in place (4) Filter not dry (5) Motorized Brush Head is blocked with hair or other debris (6) Low power	(1) Empty the Dust Cup (2) Align the dust baffle to correct hole (3) Clean or change the Filter (4) Dry out Filter (5) Clean the Motorized Brush Head (6) Charge the vacuum cleaner

Charging indicator does not light up or flash abnormally	(1) Battery Pack is dead or broken (2) Charger is not correctly connected (3) Charger is wrong	(1) Change the Battery Pack (2) Make sure the Charger are fully plugged in socket and Battery Pack (3) Use the Charger provided by Laresar
Insufficient running time after charging	(1) Insufficient charging time (2) Battery aging (3) Motorized Brush Head or is blocked with hair or other debris (4) Charger is wrong	(1) Vacuum cleaner fully charged (2) Change the Battery (3) Clean the Motorized Brush Head (4) Use the Charger provided by Laresar
Motorized Brush Head does not rotate	(1) Brush Roller are blocked with hair, pebbles or other debris (2) Dust Cup is full of dust	(1) Clean the Brush Roller (2) Avoid picking up large rubbish, such as pebbles (3) Empty the Dust Cup (4) Contact Laresar Support for replacement

10. WARRANTY

The 2-Year Limited Warranty

- Your Laresar machine has a 2-year warranty against original defects in material and workmanship, when used for private household purposes in accordance with the Laresar Instruction Manual.
- This warranty provides, at no extra cost to you, all labor and parts necessary to ensure your machine is in proper operating condition during the warranty period.

WHAT IS COVERED?

According to the requirements outlined in this instruction manual, subject to the following conditions and exclusions.

Only applies to purchases made from authorized retailers of Laresar.

This warranty will only be valid if the machine is used in the country in which it was sold.

WHAT IS NOT COVERED?

Laresar shall not be liable for costs, damages or repairs incurred as a result of:

- Machines purchased from an unauthorized dealer.

- Careless operation or handling, misuse, abuse and/or lack of maintenance or use not in accordance with the Laresar Instruction Manual.
- The machines are used for commercial or rental purposes in addition to normal domestic use.
- Use of parts not in accordance with the Laresar Instruction Manual.
- Use of parts and accessories other than those produced or recommended by Laresar.
- External factors unrelated to product quality and use, like accidental water damage.
- Repairs or alterations carried out by unauthorized parties or agents.
- Normal wear and tear, including Dust Cup, Belt, Filter, HEPA, Brush Roller, and Power Cord (or where external damage or abuse is diagnosed), carpet or floor damage due to use not in accordance with manufacturer's instructions or failure to turn the brush roller off when necessary.
- Reduction in battery discharge time due to battery age or use.

HOW TO CLAIM?

Please keep your proof of purchase. To make a claim under our Limited Warranty, you need to provide your original purchase receipt with the purchase date and order number on it.

All work will be carried out by Laresar or its authorized agency.

Any replaced defective parts will become the property of Laresar.

Service under this warranty will not extend the period of this warranty.

If your machine is not functioning properly, or you still have any questions after reading this manual carefully, please feel free to contact us, we will try our best to provide you with a satisfactory solution.



Email our Customer Service:
support@laresar.us



Laresar is here to help and we are glad to serve you.

11. DISPOSAL

This product must not be disposed of as household waste. Dispose of the device at an authorized collection point for the recycling of electrical appliances.



NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Correct Disposal of this product:

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Declaration of Conformity:

We (Manufacturer is responsible for this declaration)

Ekoo Electronic Co.,Ltd.

(Company name)

B09,block B,f2,bldg.b,runfeng Pioneer Park,no.973, minzhi Avenue, Minzhi St., Longhua, Shenzhen, CN

(Company address)

declare under our sole responsibility that the product

Trade name: **Laresar**

Equipment: **Vacuum Cleaner**

Model No. : **Elite 2**

to which this declaration relates is in conformity with the essential requirement set out in the Council Directive on the Approximation of the laws of the Member States relating to **LVD Directive(2014/35/EU) & EMC Directive(2014/30/EU) & RoHS(2011/65/EU)** product is responsible to affix CE marking, the following standards were applied:

EN 60335-2-2:2010+A11:2012+A1:2013

EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A14:2019+A2:2019

EN 62233:2008

EN 55014-1:2021

EN 55014-2:2021

EN IEC 61000-3-2:2019+A1:2021

EN 61000-3-3:2013+A2019

IEC62321-3-1:2013

IEC62321-4:2013

IEC62321-5:2013

IEC62321-6:2015

IEC62321-7-1:2015

IEC62321-7-2:2017

IEC62321-8:2017

Full Name: George.wang

Position: Approbation Manager

Signature: George.wang

Place/Date: Shenzhen,China/Oct.27-2021"