

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Technical Bulletin

EXD-HP1/2 are stand-alone universal superheat and/ or economizer controllers for heat pumps, heating units, air conditioning and precision cooling such as telecom and shelter applications.

Features

- Self-adapting superheat/economizer control in conjunction with EMERSON stepper motor driven electronic expansion Valves EXM/EXL or EXN
- Discharge hot gas temperature control by wet refrigerant vapor/vapor injection to compressor
- EXD-HP1: Controller with one EXV output
- EXD-HP2: Controller with two independent EXV outputs
- Controllers as slave with Modbus (RTU) communication capability. All data (read/write) accessible by any third-party controller having modbus communication (RTU)
- Upload/download key (accessory) for transmission of parameter settings among controllers with the same setting
- Low pressure switch and freeze protection function
- Manual positioning of valve(s)
- Limitation of evaporating pressure (MOP)
- Low/high superheat alarm
- Monitoring of sensors and sensor wiring and detection of sensor and wiring failures
- Integrated display (3-digits LEDs) and key board
- Electrical connection via plug-in type screw terminals (included with controller)
- OEM product: Box order quantities: 20 pieces (Multi-pack)



EXD-HP2

Selection table

Type	Description	Part No.	
		Multipack	Single pack
Controllers			
EXD-HP1	with 1 EXV output	807836M	-
EXD-HP2	with 2 EXV outputs	807837M	-
Valves / Coils			
EXM-B0A	Electronic expansion valve	800399M	-
EXM-B0B		800400M	-
EXM-B0D		800401M	-
EXM-B0E		800402M	-
EXM-125	Coil 12 VDC	800403M	-
EXL-B1F	Electronic expansion valve	800405M	-
EXL-B1G		800406M	-
EXL-125	Coil 12 VDC	800407M	-
EXN-B2K	Electronic expansion valve (not selectable in conjunction with R290)	-	800421
EXN-B2L		-	800422
EXN-125	Coil 12 VDC	-	800420
Temperature sensor			
ECP-P30	Temperature sensor with 3 m cable	-	804495
Pressure sensors		Suction pressure	
PT5N-07M / PT5N-07T	-0.8...7 bar	805350M / 805380M	805350 / 805380
PT5N-10FLR	-0.8...10 bar	805391M	805391
PT5N-18M / PT5N-18T	0...18 bar	805351M / 805381M	805351 / 805381
PT5N-30M / PT5N-30T	0...30 bar	805352M / 805382M	805352 / 805382
Plug and cable assembly for pressure sensors			
PT4-M15	1.5 m cable length	804803M	804803
PT4-M30	3.0 m cable length	804804M	804804
PT4-M60	6.0 m cable length	804805M	804805
PT4-M60-FLR	6.0 m cable length, 2-wire, ATEX certified	-	804806

Note: For further details of EXM/EXL, EXN and PT5N: Please see separate Technical Bulletin.

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Alarm functions - List of alarms

Condition	Delay time	Alarm relay	Valve position	Reset type	Display alarm LED
Hardware errors (sensors)	-	Triggered	Fully close	Auto	ON
Hardware errors (Stepper motor)	-	Triggered	-	Auto	ON
Low superheat	Fix: 1 min.	Triggered	Fully close	Auto/Manual	ON/Blinking
Discharge hot gas above limit	30 sec.	Triggered	Operating	Auto	ON
High superheat	Adjustable	Triggered	Operating	Auto	ON
Low pressure	Adjustable	Triggered	Operating	Auto/Manual	ON/Blinking
Freezing	Adjustable	Triggered	Fully closed	Auto/Manual	ON/Blinking

Technical Data EXD-HP1/2


Supply voltage	24 VAC/DC $\pm 10\%$
Power consumption	EXD-HP1: Max. 15 VA EXD-HP2: Max. 20 VA
Digital inputs	EXD-HP1: Two, each potential free EXD-HP2: Three each potential free
Relay output	SPDT contacts, AgSnO Inductive (AC15) 24 VAC: 1 A Resistive: 24 VAC/DC: 4 A
Type of action	1B
Rated impulse voltage	0.5kV
Pollution Degree	2
Plug-in connector size	Removable screw version wire size 0.14...1.5 mm ²

Protection class	IP20
Housing	Self-extinguishing ABS
Mounting	DIN rail mounted
Temperatures	Storage -20...+65°C operating -10...+60°C
Relative humidity	0...85% RH non condensing
Applied directive	LVD, EMC, RoHS
Compliance with	DIN EN60335-1 DIN EN 55014-1, DIN EN 55014-2
Weight	175 g
Marking	

Input Sensors, Output Valves

Description	Specification												
Temperature input	ECP-P30 (3 meter cable length) Range: -30°C...+150°C												
Pressure sensor input	PT5N Signal: 4 ... 20 mA												
Electronic expansion valves (stepper motor) output	Note: The connection of two valves are permitted as below table: <table> <tr> <th>Circuit 1</th><th>Circuit 2</th></tr> <tr> <td>EXM</td><td>EXM</td></tr> <tr> <td>EXM</td><td>EXL</td></tr> <tr> <td>EXL</td><td>EXM</td></tr> <tr> <td>EXL</td><td>EXL</td></tr> <tr> <td>EXN</td><td>EXN</td></tr> </table> EXM/L series or EXN Series	Circuit 1	Circuit 2	EXM	EXM	EXM	EXL	EXL	EXM	EXL	EXL	EXN	EXN
Circuit 1	Circuit 2												
EXM	EXM												
EXM	EXL												
EXL	EXM												
EXL	EXL												
EXN	EXN												

Dimensions (mm)



EXD-HP1/2 Stand-alone Superheat / Economizer Controller

MOP Table & Functions


Refrigerant	Min.	Max.	Factory setting	Function	Refrigerant	Min.	Max.	Factory setting	Function
R22	-40 °C	+50 °C	+15 °C	Superheat control & Economizer control	R452A	-45 °C	+66 °C	+15 °C	Superheat control
R134a	-40 °C	+66 °C	+15 °C	Superheat control	R454A*	-57 °C	+66 °C	+10 °C	Superheat control
R410A	-40 °C	+45 °C	+15 °C	Superheat control	R454B*	-40 °C	+45 °C	+18 °C	Superheat control
R32	-40 °C	+30 °C	+15 °C	Superheat control & Economizer control	R454C*	-66 °C	+48 °C	+17 °C	Superheat control
R407C	-40 °C	+48 °C	+15 °C	Superheat control & Economizer control	R513A	-57 °C	+66 °C	+13 °C	Superheat control
R290*	-40 °C	+50 °C	+15 °C	Superheat control	R452B*	-45 °C	+66 °C	+25 °C	Superheat control
R448A	-57 °C	+66 °C	+12 °C	Superheat control	R1234ze*	-57 °C	+66 °C	+24 °C	Superheat control
R449A	-57 °C	+66 °C	+12 °C	Superheat control	R1234yf*	-52 °C	+66 °C	+15 °C	Superheat control

Note1: *) EXN not permitted


Note2: *)  **Warning -Flammable refrigerants:** EXD-HP1/2 has a potential ignition source and does not comply with ATEX requirements. Installation only in non-explosive environment. For flammable refrigerants only use valves and accessories approved for it!

Wiring Diagrams

EXD-HP1 and EXD-HP2 (Base board)



EXD-HP2 (Upper board)



Notes:

- Base board for superheat control or Economizer control.
- Alarm relay, dry contact. Relay coil is not energized at alarm condition or power off and energized during normal operation
- Hot gas discharge sensor input is mandatory only for economizer control function.
- Transformer shall be class 2

Notes:

- Upper board only for superheat control
- Upper board does not need to be wired if circuit 2 of EXD-HP2 is disabled


EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Communication ModBus (RTU) protocol details

The use of communication is not necessary/mandatory; however, the communication is available for connection to upper level of system controller (third party controller) in order to perform data and commands transfer as well as data logging.

EXD-HP1/2 act as slave and third-party controller is master. In case of several EXD-HP1/2 connections to master, each driver needs to be addressed for proper communication.

Bus topology



ModBus Specification

- The Mode: RTU
- Modbus slave address range: 1 to 127 (parameter **Adr**)
- Baud rate: 9600 bps, 19200 bps (parameter **br**)
- Start bit: 1
- Data bits: 8
- Parity: even (default), no parity (parameter **PAr**)
- Stop bits: 1
- Master response timeout: 500 ms

Transmission Details

Modbus register address ranges

- Read-only data: Starting address: 0x0100 (256)
- Writable data: Starting address: 0x0200 (512)
- Configuration data: Starting address: 0x0300 (768)

Read Data transmission

Available through Modbus Function code 03 (0x03) Read Holding Registers

Request

Function code	1 Byte	0x03
Starting Address	2 Bytes	0x0000 to 0xFFFF
Register count	2 Bytes	1 to 125 (0x7D)

Response

Function code	1 Byte	0x03
Byte count	1 Byte	2 x N*
Holding Registers	N* x 2 Bytes	

*N = Quantity of Input Registers

Error

Error code	1 Byte	0x83
Exception code	1 Byte	01 or 02 or 03

- 01 = Function code not supported
- 02 = Starting Address or register count out of range
- 03 = Register count out of range

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Write Data transmission (single register)

Available through Modbus Function code 06 (0x06) Write Holding Register

Request

Function code	1 Byte	0x06
Starting Address	2 Bytes	0x0000 to 0xFFFF
Value	2 Bytes	0x0000 to 0xFFFF

Response

Function code	1 Byte	0x06
Starting Address	2 Bytes	0x0000 to 0xFFFF
Value	2 Bytes	0x0000 to 0xFFFF

Error

Error code	1 Byte	0x86
Exception code	1 Byte	01 or 02

01 = Function code not supported

02 = Starting address out of range

Write Data transmission (multiple registers)

Available through Modbus Function code 16 (0x10) Write Holding Registers

Request

Function code	1 Byte	0x10
Start Address	2 Bytes	0x0000 to 0xFFFF
Register count	2 Bytes	0x0001 to 0x0078
Byte count	1 Byte	2 x N
Registers values	2 x N Bytes	Value

N = register count.

Response

Function code	1 Byte	0x10
Starting Address	2 Bytes	0x0000 to 0xFFFF
Register count	2 Bytes	0x0001 to 0x0078

Error

Error code	1 Byte	0x90
Exception code	1 Byte	01 or 02 or 03

01 = Function code not supported

02 = Register Address invalid

03 = Register Value out of range

Writable variables EXD-HP1/2

Modbus address dec. / hex.	Display code	Description	Units	Remarks
512 / 0x0200	1Ho	Manual mode Circuit 1		0 = OFF 1 = ON
513 / 0x0201	1HP	Manual valve opening Circuit 1	%	Only active while manual mode is ON
514 / 0x0202		Factory default (when DI1 is Off)		1 = on (Set all parameters setting to factory default setting)
515 / 0x0203		Digital outputs		0x0001 = Alarm relay
516 / 0x0204		Manual alarm reset command		1 = Clear the alarm
517 / 0x0205	2Ho	Manual mode Circuit 2 (only EXD-HP2)		0 = OFF 1 = ON
518 / 0x0206	2HP	Manual valve opening Circuit 2 (only EXD-HP2)	%	Only active while manual mode is ON
519 / 0x0207		Discharge temperature input	1/100°C	Source for discharge temperature if parameter 1EC (0x31B) = 1 Allowed temperature range 0...160°C Minimum update rate: 2 seconds
520 / 0x0208		Discharge temp. control		0 = Discharge Temp. Control enabled 1 = Discharge Temp. Control disabled
521 / 0x0209		Demand circuit 1		0 = No demand 1 = Demand
522 / 0x020A		Demand circuit 2		0 = No demand 1 = Demand
523 / 0x020B		Manual defrost circuit 1		0 = OFF 1 = ON
524 / 0x020C		Manual defrost opening circuit 1	%	Only active while Manual defrost circuit 1 = ON
525 / 0x020D		Manual defrost circuit 2		0 = OFF 1 = ON
526 / 0x020E		Manual defrost opening circuit 2	%	Only active while Manual defrost circuit 2 = ON

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Read-only variables EXD-HP1/2

Modbus address dec. / hex.	Description	Unit	Remarks
256 / 0x100	Valve opening - Circuit 1	1/100%	
257 / 0x101	Digital input - Circuit 1		0 = No demand 1 = Demand
258 / 0x102	Digital outputs		0x0001 = Alarm relay
259 / 0x103	Pressure sensor 1 - Circuit 1	1/100 bar	
260 / 0x104	Temperature sensor 1 - Circuit 1	1/100°C	
261 / 0x105	Temperature sensor 3 - Circuit 1	1/100°C	
262 / 0x106	Saturation temperature - Circuit 1	1/100°C	
263 / 0x107	Pressure sensor 1 failure - Circuit 1		0 = No failure 1 = Failure
264 / 0x108	Temperature sensor 1 failure - Circuit 1		0 = No failure 1 = Failure
265 / 0x109	Temperature sensor 3 failure - Circuit 1		0 = No failure 1 = Failure
266 / 0x10A	Functional alarm set Circuit 1		0x0001 = Low pressure 0x0002 = Low superheat 0x0004 = High superheat 0x0008 = Freeze protection
267 / 0x10B	Hardware alarm set		0x0001 = Valve 1 alarm 0x0002 = Valve 2 alarm (only EXD-HP2) 0x0004 = Pressure sensor 1 0x0008 = Pressure sensor 2 (only EXD-HP2) 0x0010 = Temp. sensor 1 0x0020 = Temp. sensor 2 (only EXD-HP2) 0x0040 = Temp. sensor 3
268 / 0x10C	General application state Circuit 1		0 = No demand 1 = Demand 2 = Superheat control 3 = MOP control 4 = Alarm state 5 = Discharge temperature control 6 = Manual mode
269 / 0x10D	Superheat set point - Circuit 1	1/100 K	
270 / 0x10E	Superheat measured/calculated - Circuit 1	1/100 K	
271 / 0x10F	Software revision (x104)		Hexadecimal format 1 hex digit for controller type: 1 = HP1, 2 = HP2 1 hex digit for major revision 2 hex digits for minor revision
272 / 0x110	Valve opening - Circuit 2	1/100 %	
273 / 0x111	Digital inputs - Circuit 2 (only EXD-HP2)		0 = No demand 1 = Demand
274 / 0x112	Pressure sensor 2 - Circuit 2	1/100 bar	
275 / 0x113	Temperature sensor 2 - Circuit 2	1/100 °C	
276 / 0x114	Saturation temperature 2	1/100 °C	
277 / 0x115	Pressure sensor 2 failure - Circuit 2 (only EXD-HP2)		0 = No failure 1 = Failure
278 / 0x116	Temperature sensor 2 failure - Circuit 2 (only EXD-HP2)		0 = No failure 1 = Failure
279 / 0x117	Superheat set point - Circuit 2	1/100 K	
280 / 0x118	Superheat measured/calculated - Circuit 2	1/100 K	
281 / 0x119	Digital input DI3		0 = no effect 1 = Only superheat control for economizer
282 / 0x11A	Functional alarm set Circuit 2		0x0001 = Low pressure 0x0002 = Low superheat 0x0004 = High superheat 0x0008 = Freeze protection
283 / 0x11B	General application state Circuit 2		0 = No demand 1 = Demand 2 = Superheat control 3 = MOP control 4 = Alarm state 5 = N/A 6 = Manual mode

Configuration parameters EXD-HP1/2

Modbus address dec. / hex.	Display code	Description	Unit	Default value	Range	Remarks
768 / 0x300	H5	Password		12	1 - 1999	
769 / 0x301	Adr	Modbus address		1	1 - 127	
770 / 0x302	br	Modbus baudrate		1	0 - 1	0 = 9600 baud 1 = 19200 baud
771 / 0x303	PAr	Modbus parity		0	0 - 1	0 = Parity even 1 = No parity
772 / 0x304	-C2	Circuit 2 disabled		0	0 - 1	0 = Circuit 2 enabled 1 = Circuit 2 disabled
773 / 0x306	-uC	Units conversion		0	0 - 1	0 = °C, K, barg 1 = °F, psig This parameter only affects the display on device. The units are SI-based internally as well as for MODBUS communication.
774 / 0x305	HP-	Display mode EXDHP1=0 or 1, EXDHP2=0, 1 or 2		1	0 - 2	0 = No display 1 = Circuit 1 2 = Circuit 2

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Configuration parameters EXD-HP1/2

Modbus address dec. / hex.	Display code	Description	Unit	Default value	Range	Remarks
Parameters Circuit 1						
775 / 0x307	1uE	Function		1	0 - 1	0 = Superheat control 1 = Economizer control (only R410A, R32, R407C)
776 / 0x308	1u4	Control mode circuit 1		0	0 - 4	0 = Standard control coil heat exchanger 1 = Slow control coil heat exchanger 2 = fixed PID 3 = fast control plate heat exchanger 4 = Standard plate heat exchanger
777 / 0x309	1u0	Refrigerant circuit 1		2	0 - 15	0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf * *) (EXN not permitted)
778 / 0x30A	1uP	Pressure sensor 1 - type		2	0 - 3	0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR
779 / 0x30B	1uu	Start opening valve1	%	20	10 - 100	
780 / 0x30C	1u9	Start opening duration valve 1	Sec.	5	1 - 30	
781 / 0x30D	1uL	Low superheat alarm mode circuit 1		1	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
782 / 0x30E	1u5	Superheat setpoint circuit 1	1/10 K	6		Range = 3-30K with 1uL = 1,2 Range = 0.5-30K with 1uL = 0
783 / 0x30F	1u2	MOP mode circuit 1		1	0 - 1	0 = Disabled 1 = Enabled
784 / 0x310	1u3	MOP sat. temp. limit circuit1		1/10°C		See MOP table
785 / 0x311	1P9	Low pressure alarm mode circuit1		0	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
786 / 0x312	1PA	Low pressure alarm cut-out circuit1	1/10 bar	0	-0.8 - 17.7	
787 / 0x313	1Pb	Low pressure alarm delay circuit1	Sec.	5	5 - 199	
788 / 0x314	1Pd	Low pressure alarm cut-in circuit1	1/10 bar	0.5	0.5 - 18	
789 / 0x315	1P4	Freeze alarm mode circuit1		0	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
790 / 0x316	1P2	Freeze alarm cut-out circuit1	1/10°C	0	-20 - 5	
791 / 0x317	1P5	Freeze alarm delay circuit1	Sec.	30	5 - 199	
792 / 0x318	1P-	Superheat control circuit1 fixed PID Kp factor	1/10	1.0	0.1 - 10	Display 1/10K
793 / 0x319	1i-	Superheat control circuit1 fixed PID Ti factor		100	1 - 350	
794 / 0x31A	1d-	Superheat control circuit1 fixed PID Td factor	1/10	3.0	0.1 - 30	Display 1/10K
795 / 0x31B	1EC	Discharge temp. source		0	0 - 1	0 = Hot Gas temperature input 1 = ModBus command
796 / 0x31C	1PE	Economizer control Circuit 1 fixed PID Kp	1/10	2.0	0.1 - 10	Display 1/10K
797 / 0x31D	1iE	Economizer control Circuit 1 fixed PID Ti		100	1 - 350	
798 / 0x31E	1dE	Economizer control Circuit 1 fixed PID Td	1/10	1.0	0.1 - 30	Display 1/10K
799 / 0x31F	1uH	High superheat alarm mode circuit 1		0	0 - 1	0 = Disabled 1 = Enabled auto-reset
800 / 0x320	1uA	High superheat alarm setpoint circuit 1	1/10 K	30	16 - 40	
801 / 0x321	1ud	High superheat alarm delay circuit 1	Min.	3	1-15	
802 / 0x322	1E2	Discharge Temp. correction	1/10 K	0	0 - 10	Positive correction to the discharge temperature to take the sensor location in account.

EXD-HP1/2 Stand-alone Superheat / Economizer Controller

Configuration parameters (only for EXD-HP2)

Modbus address dec. / hex.	Display code	Description	Unit	Default value	Range	Remarks
Parameters Circuit 2						
803 / 0x323	2u4	Control mode circuit 2		0	0 - 4	0 = Standard control coil heat exchanger 1 = Slow control coil heat exchanger 2 = fixed PID 3 = fast control plate heat exchanger 4 = Standard plate heat exchanger
804 / 0x324	2u0	Refrigerant circuit 2		2	0 - 15	0 = R22 1 = R134a 2 = R410A 3 = R32 4 = R407C 5 = R290* 6 = R448A 7 = R449A 8 = R452A 9 = R454A* 10 = R454B* 11 = R454C* 12 = R513A 13 = R452B* 14 = R1234ze* 15 = R1234yf * *) (EXN not permitted)
805 / 0x325	2uP	Pressure sensor 2: type		1	0 - 3	0 = PT5N-07... 1 = PT5N-18... 2 = PT5N-30... 3 = PT5N-10P-FLR
806 / 0x326	2uu	Start opening valve 2	%	20	10 - 100	
807 / 0x327	2u9	Start opening duration valve 2	Sec.	5	1 - 30	
808 / 0x328	2uL	Low superheat alarm mode circuit 2		1	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
809 / 0x329	2u5	Superheat setpoint circuit 2	1/10 K	6		Range = 3-30K with 2uL = 1,2 Range = 0.5-30K with 2uL = 0
810 / 0x32A	2u2	MOP mode circuit 2		1	0 - 1	0 = Disabled 1 = Enabled
811 / 0x32B	2u3	MOP sat. temp. circuit 2	1/10 °C			See MOP table
812 / 0x32C	2P9	Low pressure alarm mode circuit 2		0	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
813 / 0x32D	2PA	Low pressure alarm cut-out circuit 2	1/10 bar	0	-0.8 - 17.7	
814 / 0x32E	2Pb	Low pressure alarm delay circuit 2	Sec.	5	5 - 199	
815 / 0x32F	2Pd	Low pressure alarm cut-in circuit 2	1/10 bar	0.5	0.5 - 18	
816 / 0x330	2P4	Freeze alarm mode circuit 2		0	0 - 2	0 = Disabled 1 = Enabled auto-reset 2 = Enabled manual reset
817 / 0x331	2P2	Freeze alarm cut-out circuit 2	1/10 °C	0	-20 - 5	
818 / 0x332	2P5	Freeze alarm delay circuit 2	Sec.	30	5 - 199	
819 / 0x333	2P-	Superheat control circuit 2 fixed PID Kp factor	1/10	1.0	0.1 - 10	Display 1/10K
820 / 0x334	2i-	Superheat control circuit 2 fixed PID Ti factor		100	1 - 350	
821 / 0x335	2d-	Superheat control circuit 2 fixed PID Td factor	1/10	3.0	0.1 - 20	Display 1/10K
822 / 0x336	2uH	High superheat alarm mode circuit 2		0	0 - 1	0 = Disabled 1 = Enabled auto-reset
823 / 0x337	2uA	High superheat alarm setpoint circuit 2	1/10 K	30	16 - 40	
824 / 0x338	2ud	High superheat alarm delay circuit 2	Min.	3	1-15	

Configuration parameters EXD-HP1/2 & Discharge Temperature Control

Modbus address dec. / hex.	Display code	Description	Unit	Default value	Range	Remarks
825 / 0x339	Et	Valve type for HP1 & HP2	0-1		0	0 = EXM/L 1 = EXN (see notes page 2) EXD-HP2 can drive two similar valves i.e. both valves must be either EXM/EXL or EXN.
831 / 0x33F	1E3	Discharge Temperature Setpoint		85	70-140	Start Setpoint
832 / 0x340	1E4	Discharge Temperature Control band		20	2-25	
833 / 0x341	1E5	Discharge Temperature limit	100	120	100-150	

EXD-HP12_TB_EN_0321_R02.docx

Emerson Climate Technologies GmbH shall not be liable for errors in the stated capacities, dimensions, etc., as well as typographic errors. Products, specifications, designs and technical data contained in this document are subject to modification by us without prior notice. Illustrations are not binding.
The Emerson Climate Technologies logo is a trademark and service mark of Emerson Electric Co. Emerson Climate Technologies Inc. is a subsidiary of Emerson Electric Co.

EMERSON. CONSIDER IT SOLVED.