

User Manual

PV Grid-Connected Inverter

SG320HX / SG350HX



All Rights Reserved

All Rights Reserved

No part of this document can be reproduced in any form or by any means without the prior written permission of Sungrow Power Supply Co., Ltd (hereinafter "SUNGROW").

Trademarks

SUNGROW and other Sungrow trademarks used in this manual are owned by SUNGROW.

All other trademarks or registered trademarks mentioned in this manual are owned by their respective owners.

Software Licenses

- It is prohibited to use data contained in firmware or software developed by SUNGROW, in part or in full, for commercial purposes by any means.
- It is prohibited to perform reverse engineering, cracking, or any other operations that compromise the original program design of the software developed by SUNGROW.

About This Manual

The manual mainly contains the product information, as well as guidelines for installation, operation, and maintenance. The manual does not include complete information about the photovoltaic (PV) system. Readers can get additional information at **www.sungrowpower. com** or on the webpage of the respective component manufacturer.

Validity

This manual is valid for the following model of low-power grid-connected PV string inverters:

- SG320HX
- SG350HX

It will be referred to as "inverter" hereinafter unless otherwise specified.

Target Group

This manual is intended for professional technicians who are responsible for installation, operation, and maintenance of inverters, and users who need to check inverter parameters.

The inverter must only be installed by professional technicians. The professional technician is required to meet the following requirements:

- Know electronic, electrical wiring and mechanical expertise, and be familiar with electrical and mechanical schematics.
- Have received professional training related to the installation and commissioning of electrical equipment.
- Be able to quickly respond to hazards or emergencies that occur during installation and commissioning.
- Be familiar with local standards and relevant safety regulations of electrical systems.
- Read this manual thoroughly and understand the safety instructions related to operations.

How to Use This Manual

Please read this manual carefully before using the product and keep it properly at a place for easy access.

All contents, pictures, marks, and symbols in this manual are owned by SUNGROW. No part of this document may be reprinted by the non-internal staff of SUNGROW without written authorization.

Contents of this manual may be periodically updated or revised, and the actual product purchased shall prevail. Users can obtain the latest manual from **support.sungrowpower.com** or sales channels.

Symbols

This manual contains important safety instructions, which are highlighted with the following symbols, to ensure personal and property safety during usage, or to help optimize the product performance in an efficient way.

Please carefully understand the meaning of these warning symbols to better use the manual.

⚠ DANGER

Indicates high-risk potential hazards that, if not avoided, may lead to death or serious injury.

MARNING

Indicates moderate-risk potential hazards that, if not avoided, may lead to death or serious injury.

A CAUTION

Indicates low-risk potential hazards that, if not avoided, may lead to minor or moderate injury.

NOTICE

Indicates potential risks that, if not avoided, may lead to device malfunctions or financial losses.



"NOTE" indicates additional information, emphasized contents or tips that may be helpful, e.g., to help you solve problems or save time.

Contents

Αl	Il Rights Reserved	
Αŀ	bout This Manual	II
1	Safety Instructions	1
	1.1 Unpacking and Inspection	1
	1.2 Installation Safety	1
	1.3 Electrical Connection Safety	2
	1.4 Operation Safety	3
	1.5 Maintenance Safety	4
	1.6 Disposal Safety	4
2	Product Description	5
	2.1 System Introduction	5
	2.2 Product Introduction	6
	2.3 Symbols on the Product	8
	2.4 LED Indicator	9
	2.5 DC Switch	10
	2.6 Circuit Diagram	10
	2.7 Function Description	11
3	Unpacking and Storage	14
	3.1 Unpacking and Inspection	14
	3.2 Unpacking Steps	14
	3.3 Inverter Storage	16
4	Mechanical Mounting	17
	4.1 Safety during Mounting	17
	4.2 Location Requirements	17
	4.2.1 Environment Requirements	18
	4.2.2 Carrier Requirements	18
	4.2.3 Angle Requirements	19
	4.2.4 Clearance Requirements	20
	4.3 Installation Tools	22
	4.4 Moving the Inverter	23
	4.4.1 Manual Transport	23

	4.4.2 Hoisting Transport	24
	4.5 Installing the mounting-bracket	26
	4.5.1 Bracket-Mounted Installation	27
	4.5.2 Wall-Mounted Installation	29
	4.5.3 Pole-Mounting	32
	4.6 Installing the Inverter	34
5	Electrical Connection	36
	5.1 Safety Instructions	36
	5.2 Terminal Description	37
	5.3 Electrical Connection Overview	38
	5.4 Crimp OT / DT terminal	42
	5.5 External Grounding Connection	43
	5.5.1 External Grounding Requirements	43
	5.5.2 Connection Procedure	44
	5.6 AC Cable Connection	44
	5.6.1 AC Side Requirements	44
	5.6.2 Requirements for OT/DT Terminal	47
	5.6.3 Connection Procedure of One Wire per Phase with Multi-core	
	Cable	48
	5.6.4 Connection Procedure of Two Wires per Phase with Multi-core	
	Cable	53
	5.7 DC Cable Connection	57
	5.7.1 PV Input Configuration	58
	5.7.2 Assembling the PV Connectors	59
	5.7.3 Installing the PV Connector	61
	5.8 Wiring of Tracking System Power Cable (Optional)	62
	5.9 RS485 Connection(COM1)	64
	5.9.1 Interface Description	64
	5.9.2 RS485 Communication System	64
	5.9.3 Connection Procedure	65
	5.10 Dry Contact Connection(COM2)	69
	5.10.1 Interface Description	69
	5.10.2 Dry Contact Function	69
	5.10.3 Connection Procedure	71
	5.11 PLC Communication Connection	74

	6.1 Inspection before Commissioning	75
	6.2 Commissioning Procedure	75
7	iSolarCloud App	77
	7.1 Brief Introduction	77
	7.2 Installing the App	77
	7.3 Login	78
	7.3.1 Requirements	78
	7.3.2 Login Procedure	78
	7.4 Function Overview	81
	7.5 Home page	81
	7.6 Run Information	83
	7.7 Records	85
	7.8 More	87
	7.8.1 System Parameters	87
	7.8.2 Operation Parameters	87
	7.8.3 Power Regulation Parameters	
	7.8.4 Communication Parameters	93
	7.8.5 Firmware Update	94
	7.8.6 Password Changing	95
8	System Decommissioning	96
	8.1 Disconnecting the Inverter	96
	8.2 Dismantling the Inverter	96
	8.3 Disposal of the Inverter	97
9	Troubleshooting and Maintenance	98
	9.1 Troubleshooting	98
	9.2 Maintenance	106
	9.2.1 Maintenance Notices	106
	9.2.2 Routine Maintenance	107
	9.2.3 Cleaning Air Inlet and Outlet	108
	9.2.4 Fan Maintenance	108
1(0 Appendix	112
	10.1 Technical Data	112
	10.2 Wring Distance of DI Dry Contact	114
	10.3 Quality Assurance	115
	10.4 Contact Information	116

1 Safety Instructions

When installing, commissioning, operating, and maintaining the product, strictly observe the labels on the product and the safety requirements in the manual. Incorrect operation or work may cause:

- Injury or death to the operator or a third party.
- Damage to the product and other properties.
 - The safety instructions in this manual are only supplements and cannot cover all the precautions that should be followed. Perform operations considering actual onsite conditions.



- SUNGROW shall not be held liable for any damage caused by violation of general safety operation requirements, general safety standards, or any safety instruction in this manual.
- When installing, operating, and maintaining the product, comply with local laws and regulations. The safety precautions in this manual are only supplements to local laws and regulations.

1.1 Unpacking and Inspection

M WARNING

Check all safety signs, warning labels and nameplates on devices.

Ensure that the safety signs, warning labels and nameplates must be clearly visible and cannot be removed or covered before the device is decommissioned.

NOTICE

After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact SUNGROW in time.

1.2 Installation Safety

DANGER

Make sure there is no electrical connection before installation.

Before drilling, avoid the water and electricity wiring in the wall.

1 Safety Instructions User Manual

A CAUTION

Improper installation may cause personal injury!

• If the product supports hoisting transport and is hoisted by hoisting tools, no one is allowed to stay under the product.

 When moving the product, be aware of the product weight and keep the balance to prevent it from tilting or falling.

NOTICE

Before operating the product, must check and ensure that tools to be used have been maintained regularly.

1.3 Electrical Connection Safety

A DANGER

Before electrical connections, please make sure that the inverter is not damaged, otherwise it may cause danger!

Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!

▲ DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.
- The inverter must not be connected to a PV string that requires positive or negative grounding.

⚠ DANGER

Danger to life due to a high voltage inside the inverter!

- Be sure to use special insulation tools during cable connections.
- Note and observe the warning labels on the product, and perform operations strictly following the safety instructions.
- Respect all safety instructions listed in this manual and other pertinent documents.

User Manual 1 Safety Instructions

MARNING

Damage to the product caused by incorrect wiring is not covered by the warranty.

- · Electrical connection must be performed by professionals.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned.

MARNING

Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.

During the installation and operation of the inverter, please ensure that the positive or negative poles of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.

NOTICE

Comply with the safety instructions related to PV strings and the regulations related to the local grid.

1.4 Operation Safety

▲ DANGER

- When the inverter is running, do not touch its enclosure.
- When the inverter is running, it is strictly forbidden to plug and unplug any connector on the inverter.
- When the inverter is running, do not touch any wiring terminal of the inverter.
 Otherwise, electric shock may occur.
- When the inverter is running, do not disassemble any parts of the inverter. Otherwise, electric shock may occur.
- When the inverter is running, it is strictly forbidden to touch any hot parts of the inverter (such as the heat sink). Otherwise, it may cause burns.
- If the inverter is equipped with a DC switch, do not operate it when the inverter is running. Otherwise, device damage or personal injury may occur.

1 Safety Instructions User Manual

1.5 Maintenance Safety

A DANGER

Risk of inverter damage or personal injury due to incorrect service!

 Before any service work, first disconnect the grid-side AC circuit breaker and check the inverter status. If the inverter indicator is off, please wait until night to disconnect the DC switch. If the inverter indicator is on, directly disconnect the DC switch.

- After the inverter is powered off for 25 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

A DANGER

Touching the power grid or the contact points and terminals on the inverter connected to the power grid may lead to electric shock!

The power grid side may generate voltage. Always use a standard voltmeter to ensure that there is no voltage before touching.

A CAUTION

To prevent misuse or accidents caused by unrelated personnel: Post prominent warning signs or demarcate safety warning areas around the inverter to prevent accidents caused by misuse.

NOTICE

To avoid the risk of electric shock, do not perform any other maintenance operations beyond this manual. If necessary, contact SUNGROW for maintenance. Otherwise, the losses caused is not covered by the warranty.

1.6 Disposal Safety

MARNING

Please scrap the product in accordance with relevant local regulations and standards to avoid property losses or casualties.

2 Product Description

2.1 System Introduction

The inverter is a transformerless 3-phase PV grid-connected inverter. As an integral component in the PV power system, the inverter is designed to convert the direct current power generated from the PV modules into grid-compatible AC current and to feed the AC current into the utility grid.

The intended usage of the inverter is illustrated in the following figure.




figure 2-1 Inverter Application in PV Power System

M WARNING


Do not connect any local load between the inverter and the AC circuit breaker except for the tracking axis.

NOTICE

The inverter is only applicable to the scenarios described in the manual and cannot be used in other situations.

Item	Description	Note
^	DV strings	Monocrystalline silicon, polycrystalline silicon and thin-film
A PV strings	FV stilligs	without grounding.
В	Inverter	SG320HX / SG350HX
C Tra	T (Raises the output voltage of the inverter to a level that meets
	Transformer	the requirements of the grid.
D	Utility grid	The grid forms supported by the inverter are shown in the fig-
		ure below.

2 Product Description User Manual






Make sure the inverter is applied to an IT system before enabling the Anti-PID function.

2.2 Product Introduction

Model Description

The model description is as follows (take SG350HX as an example).



Appearance

The following figure shows the appearance of the inverter.

User Manual 2 Product Description




figure 2-2 Appearance

The image shown here is for reference only. The actual product received may differ.

No.	Name	Description
1	LED indicator	To indicate the current working state of the inverter.
2	AC Wire Box	To connect AC cable and tracking system power cable in this area.
3	External ground- ing terminals	2, use at least one of them to ground the inverter.
4	Bottom handles	2, used to move the inverter.
5	Mounting ears	4, used to hang the inverter onto the mounting-bracket.
6	Wiring area	DC switches, DC terminals, and communication terminals.
		For details, refer to "5.2 Terminal Description".
7	Labels	To clearly identify the product, including nameplate, warning symbols and QR code.

Dimensions

The following figure shows the dimensions of the inverter.

2 Product Description User Manual




figure 2-3 Dimensions of the Inverter(in mm)

Weight

Model	Weight
SG320HX / SG350HX	≤ 116 kg

2.3 Symbols on the Product

Symbol	Explanation
X	Do not dispose of the inverter together with household waste.
	Read the user manual before maintenance!
TO SECOND	TUV mark of conformity.
C€	CE mark of conformity.
6	EU/EEA Importer
UK	UKCA mark of conformity.
CA	The height of the label should not exceed 5 mm.
Λ	Disconnect the inverter from all the external power sources be-
<u> </u>	fore maintenance!
	Burn danger due to the hot surface that may exceed 60°C.

User Manual 2 Product Description

Symbol	Explanation	
	Danger to life due to high voltages!	
1 (2) 25min	Do not touch live parts for 25 minutes after disconnection from	
	the power sources.	
	Only qualified personnel can open and maintain the inverter.	
	External grounding point.	

2.4 LED Indicator

The LED indicator on the front of the inverter indicates the working state of the inverter.

table 2-1 State description of the LED indicator

LED color	State	Definition
	On	The device is connected to the grid and operating
		normally.
	Fast blink	The Bluetooth communication is connected and there
	(Period: 0.2s)	is data communication.
		No system fault occurs.
	Slow blink	
	(Period: 2s)	The device is in standby or startup state (not feeding
Blue	00000	power into the grid).
Diue	Slow blink	
	once, fast	The inverter is performing DID receivery
	blink three	The inverter is performing PID recovery.
	times	
	On	A fault occurs and the device cannot connect to the
		grid.
		The Bluetooth connection is established, data commu-
	Twinkling	nication in process, and a system fault occurs.
Red		
	OFF	Poth the AC and DC sides are newered down
	OFF	Both the AC and DC sides are powered down.
Gray		


2 Product Description User Manual

M WARNING

Voltage may still be present in AC side circuits after the indicator is off. Pay attention to the electricity safety during operating.

2.5 DC Switch

The inverter is equipped with four DC switches which can safely disconnect it from PV strings. Each switch controls the circuits corresponding to DC terminals in the area where the switch is located.



2.6 Circuit Diagram

The following figure shows the main circuit of the inverter.




figure 2-4 Circuit Diagram

- DC switches can safely disconnect the PV input when necessary to ensure the safe operation of the inverter and the safety of personnel.
- The DC SPD provides a discharge circuit for the DC side over-voltage power to prevent it from damaging the internal circuits of the inverter.
- EMI filters can filter out the electromagnetic interference inside the inverter to ensure that the inverter meets the requirements of electromagnetic compatibility standards.
- The MPPT is utilized for DC input to ensure the maximum power from the PV array at different PV input conditions.

User Manual 2 Product Description

• The inverter circuit converts the DC power into grid-compliant AC power and feeds it into the grid.

- The AC filter filters the output AC component of high frequency to ensure that the output current meets the grid requirements.
- The AC relay isolates the AC output of the inverter from the grid, making the inverter safe from the grid in case of inverter failure or grid failure.
- The AC SPD provides a discharge circuit for the AC side over-voltage power to prevent it from damaging the internal circuits of the inverter.

2.7 Function Description

The inverter is equipped with the following functions:

Conversion Function

The inverter converts the DC current into grid-compatible AC current and feeds the AC current into the grid.

Data Storage

The inverter logs running information, error records, etc.

Parameter Configuration

The inverter provides various settable parameters. Users can set parameters via the App to meet the requirements and optimize the performance.

Communication Interface

The inverter is designed with standard RS485 communication interfaces.

The standard RS485 communication interfaces are used to establish communication connection with monitoring devices and upload monitoring data by using communication cables. After communication connection is established, users can view inverter information or set inverter parameters through the iSolarCloud.

Protection Function

The protective functions are integrated in the inverter, including anti-island protection, LVRT, DC reverse connection protection, AC short circuit protection, leakage current protection, surge protection, etc.

Potential Induced Degradation (PID) (Optional)

The PID effect (Potential Induced Degradation) of PV modules will cause serious damage to PV yield. Through enabling the Anti-PID function, the PID can be suppressed, and this function applies to the grid-connected operation of the inverter during the day or the reactive power generation at night is enabled. Through enabling the PID recovery function, the adverse effects caused by PID can be recovered, and this function only works when the DC side of the inverter is voltage-free.


Anti-PID function and PID recovery function works differently when applied to P-type and N-type panels.

2 Product Description User Manual

P-type panel


When the anti-PID function is enabled, the inverter rises the potential of the negative pole of PV array of P-type panels to close to the ground potential through PID module to suppress PID effect.

When the PID recovery function is enabled, the inverter rises the potential between the negative pole of PV array of P-type panels and the ground to 500Vdc through PID module, to repair the PID effect.




N-type panel

The electric power engineering company and the user should confirm with the PV panel manufacturer the compensation voltage direction against PID of the selected panel when designing the plant.



Make sure the inverter is applied to an IT system before enabling the anti-PID function.





- After PID recovery is enabled, it only works when the DC side of the inverter is voltage-free.
- After the PID recovery function is enabled, the voltage of the PV string to ground is 500Vdc by default.

User Manual 2 Product Description

NOTICE

Before enabling the anti-PID function or PID recovery function, make sure the
voltage polarity of the PV modules to ground meets requirement. If there are
any questions, contact the PV module manufacturer or read the corresponding
user manual.

- If the voltage scheme for the anti-PID function or PID recovery function does not meet the requirement of corresponding PV modules, the PID will not work as expected or even damage the PV modules.
- When the PID recovery works (the indicator blinks blue once at long intervals and three times at short intervals), disable the PID recovery function on iSolar-Cloud App before manually powering on and maintaining the inverter.



3 Unpacking and Storage

3.1 Unpacking and Inspection

The product is thoroughly tested and strictly inspected before delivery. Nonetheless, damage may still occur during shipping. For this reason, please conduct a thorough inspection after receiving the product.

- · Check the packing case for any visible damage.
- · Check the scope of delivery for completeness according to the packing list.
- Check the inner contents for damage after unpacking.

Contact SUNGROW or the transport company in case of any damage or incompleteness, and provide photos to facilitate services.

Do not dispose of the original packing case. It is recommended to store the device in the original packing case when the product is decommissioned.

NOTICE

After receiving the product, check whether the appearance and structural parts of the device are damaged, and check whether the packing list is consistent with the actual ordered product. If there are problems with the above inspection items, do not install the device and contact your distributor first. If the problem persists, contact SUNGROW in time.


If any tool is used for unpacking, be careful not to damage the product.

3.2 Unpacking Steps


step 1 Use a utility knife to cut the packing tape. Remove horizontal and vertical paper angle beads.




User Manual 3 Unpacking and Storage



step 2 Remove the packing box upwards.




step 3 Remove the surrounding paper angle beads.



step 4 Remove the upper cushion.

3 Unpacking and Storage User Manual



--End

3.3 Inverter Storage

Proper storage is required if the inverter is not installed immediately.

- · Store the inverter in the original packing case with the desiccant inside.
- The storage temperature must be always between -40°C and +70°C, and the storage relative humidity must be always between 0 and 95 %, non-condensing.
- In case of stacking storage, the number of stacking layers should never exceed the limit marked on the outer side of the packing case.
- · The packing case should be upright.
- If the inverter needs to be transported again, pack it strictly before loading and transporting it.
- Do not store the inverter in places susceptible to direct sunlight, rain, and strong electric field.
- Do not place the inverter in places with items that may affect or damage the inverter.
- Store the inverter in a clean and dry place to prevent dust and water vapor from eroding.
- Do not store the inverter in places with corrosive substances or susceptible to rodents and insects.
- Carry out periodic inspections. Inspection shall be conducted at least once every six months. If any insect or rodent bites are found, replace the packaging materials in time.
- If the inverter has been stored for more than a year, inspection and testing by professionals are required before it can be put into operation.

NOTICE

Please store the inverter according to the storage requirements. Product damage caused by failure to meet the storage requirements is not covered by the warranty.

4 Mechanical Mounting

M WARNING

Respect all local standards and requirements during mechanical installation.

4.1 Safety during Mounting

A DANGER

Make sure there is no electrical connection before installation.

Before drilling, avoid the water and electricity wiring in the wall.

⚠ WARNING

Poor installation environment will affect system performance!

- · Install the inverter in a well-ventilated place.
- Ensure that the heat dissipation system or vent is not blocked.
- Do not install the inverter in an environment with flammable and explosive objects or smoke.

A CAUTION

Improper handling may cause personal injury!

- When moving the inverter, be aware of its weight and keep the balance to prevent it from tilting or falling.
- · Wear proper protective equipment before performing operations on the inverter.
- The bottom terminals and interfaces of the inverter cannot directly contact the ground or other supports. The inverter cannot be directly placed on the ground.


4.2 Location Requirements

Select an optimal mounting location for safe operation, long service life and expected performance.

- The inverter with protection rating IP66 can be installed both indoors and outdoors.
- Install the inverter at a place convenient for electrical connection, operation, and maintenance.

4 Mechanical Mounting User Manual





4.2.1 Environment Requirements

- The installation environment must be free of inflammable or explosive materials.
- The location should be not accessible to children.
- The ambient temperature and relative humidity must meet the following requirements.







- Please consult SUNGROW before installing inverters outdoors in salt stress areas. Salt stress areas mainly refer to coastal areas that are within 500 meters from the coast. The deposition of salt fog varies largely with nearby seawater characteristics, sea wind, precipitation, relative humidity, terrain, and forest coverage.
- Inverters free from direct sunlight, direct rain and snow have longer service life. Consider sheltered places as the installation location.
- The inverter should be well ventilated. Ensure air circulation.
- The inverter generates noise during operation and is not recommended to be installed in living areas.
- The inverter is installed more than 30 m away from third-party wireless communication facilities and living environment.

4.2.2 Carrier Requirements

The mounting structure where the inverter is installed must comply with local/national standards and guidelines. Ensure that the installation surface is solid enough to bear four times the weight of the inverter and is suitable for the dimensions of the inverter (e.g. cement walls, plasterboard walls, etc.).

User Manual 4 Mechanical Mounting



4.2.3 Angle Requirements


Install the inverter vertically or tilt backwards. Do not install the inverter horizontally, forward, excessively backward, sideways, or upside down.


Inverters in floating plants cannot be installed at a back tilt.
















4 Mechanical Mounting User Manual

In case the installation site is a level surface, mount the inverter to the bracket to meet the mounting angle requirements, as shown in the figure below.






Take the following items into account when designing the bracket scheme:

- Consider onsite climate conditions and take anti-snow and anti-rain measures if necessary.
- Ensure that the waterproof connectors are at least 300 mm higher than the ground surface.
- Bind the cables at the positions 300~350 mm away from the DC connector, AC waterproof terminal, and communication waterproof terminal.
- The various waterproof terminals should be tightened in accordance with the torque requirements in this manual to ensure that they are tight and sealed.

Contact SUNGORW if you have any question.


4.2.4 Clearance Requirements

Reserve enough clearance around the inverter to ensure sufficient space for heat dissipation.



^{*} In case this distance is less than the distance in the diagram, move the inverter from the mounting-bracket or wall before maintaining fans.

User Manual 4 Mechanical Mounting




In case of multiple inverters, reserve specific clearance between the inverters.



Back-to-Back Installation

When installing inverters back-to-back, the distance between every two inverters should be at least 600 mm (recommended).

If the on-site distance is shorter than the recommended clearance, add a baffle between every two inverters to form a heat dissipation channel (not recommended). The baffle plate should be placed horizontally between two inverters and should not block the air outlet of inverters.



4 Mechanical Mounting User Manual

4.3 Installation Tools

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.

table 4-1 Tool specification



User Manual 4 Mechanical Mounting



4.4 Moving the Inverter

Move the inverters by carrying them manually or using a hoisting tool based on site conditions.

A CAUTION


Improper handling may cause personal injury!

- Arrange an appropriate number of personnel to carry the inverter according to its weight, and installation personnel should wear protective equipment such as anti-impact shoes and gloves.
- Attention must be paid to the center of gravity of the inverter to avoid tilting during handling.
- Placing the inverter directly on a hard ground may cause damage to its metal enclosure. Protective materials such as sponge pad or foam cushion should be placed underneath the inverter.
- Move the inverter by holding the handles on it. Do not move the inverter by holding the terminals.

4.4.1 Manual Transport

Attach the four screw-in handles provided to the inverter lugs and base. Lift and move the inverter to its destination by means of the bottom handle and the four installed handles.

4 Mechanical Mounting User Manual



NOTICE

When handling the inverter, do not remove the cushion in the red circle to avoid damage to the housing or bottom terminals.


4.4.2 Hoisting Transport

Tools

Device Name	Requirement	Source
Crane	Load bearing capacity ≥ 180 kg	Not included in the scope of delivery
Lifting ring	2, M12, load bearing capacity of a single ring ≥ 260 kg	Not included in the scope of delivery
Sling	1, length ≥ 2.5 m, load bearing capacity of a sin- gle sling ≥ 600 kg	Not included in the scope of delivery

step 1 Release the sealing screws on the mounting ears and store them properly. Anchor two M12 thread lifting rings to the hangers of the inverter.

User Manual 4 Mechanical Mounting




NOTICE

When handling the inverter, do not remove the cushion in the red circle to avoid damage to the housing or bottom terminals.

- step 2 Lead the sling through the two lifting rings and fasten the tie-down strap.
- step 3 Hoist the inverter, and stop to check for safety when the inverter is 100 mm above the ground. Continue hoisting the device to the destination after ensuring the safety.

4 Mechanical Mounting User Manual



step 4 Remove the lifting rings and reassemble the sealing screws released in Step 1.

▲ CAUTION

Keep the inverter balanced throughout the hoisting process and avoid collisions with walls or other objects. Stop hoisting in the event of severe weather, such as heavy rain, thick fog, or strong wind.



The lifting rings and the sling are not within the delivery scope.

- - End

4.5 Installing the mounting-bracket

Inverter is installed on the wall and bracket by means of mounting bracket.


Dimensions of the assembled mounting-bracket are as follows.

User Manual 4 Mechanical Mounting



figure 4-1 Dimensions of mounting-bracket

Install the inverter to the mounting-bracket, and dimensions after installation are as follows.



4.5.1 Bracket-Mounted Installation

Tools


4 Mechanical Mounting User Manual

Item	Specification
Phillips screwdriver	M4
Marker	-
Level	-
Electric drill	Drill bit: φ12
Wrench	Opening: 16 mm


Spare parts

Item	Quantity	Specification	Source
Grub screw	2	M4×10	Delivery scope
Bolt assembly	4	M10	Delivery scope

step 1 Assemble the mounting-bracket by using the connecting bar.




step 2 Place the assembled mounting-bracket onto the PV bracket with the distance between the mounting-bracket and the ground shown in the figure. Adjust the angle with a level and mark positions for drilling holes. Drill the holes by using a electric drill.



step 3 Secure the mounting-bracket with bolts.

User Manual 4 Mechanical Mounting



- (A) Mounting-bracket (B) Full threaded bolt
- (C) Metal bracket

- (D) Flat washer
- (E) Spring washer
- (F) Hex nuts

- - End

4.5.2 Wall-Mounted Installation

Tools


Item	Specification
Phillips screwdriver / electric	M4
screw driver	
Marker	-
Level	-
Hammer drill	Drill bit: φ12
Wrench	Opening: 16 mm

Spare parts


Item	Quantity	Specification	Source
Grub screw	2	M4×10	Delivery scope
Expansion bolt	11	M10×95	Self-prepared
		(Recommended)	
Baffle plate	3	_	Self-prepared

step 1 Assemble the mounting-bracket by using the connecting bar.


4 Mechanical Mounting User Manual



step 2 Level the assembled mounting-bracket by using the level, and mark the positions for drilling holes on the installation site.




step 3 Drill the holes by using a hammer drill. Insert the expansion bolts into the holes and secure them with a rubber hammer. Fasten the nut with a wrench to expand the bolt. Remove the nut, spring washer, and flat washer, and store them properly.



step 4 Fix the mounting-bracket with the expansion bolts.

User Manual 4 Mechanical Mounting



step 5 Fix the baffle plate to the wall with the expansion bolts.




figure 4-3 Relative distance between baffle plate and mounting-bracket (mm)

- - End

4 Mechanical Mounting User Manual

4.5.3 Pole-Mounting

Tools

Item	Specification
Phillips screwdriver	M4
Marker	_
Level	_
Electric drill *	Drill bit: φ12
Wrench	Opening: 16 mm

^{*} Confirm the need for other sizes of tools based on the bolts of the matching clamps.

Spare parts


Item	Quantity	Specification	Source
Grub screw	2	M4×10	Delivery scope
Bolt assembly	4	M10	Delivery scope
Nut assembly	4	M10	Self-prepared
U-shaped steel	2	_	Self-prepared
Clamp	0	Determined by column	Calf propagad
Clamp	2	specifications	Self-prepared

step 1 Bury the column into the installation site.




Please skip this step if you need to install the inverter on a concrete post, PV bracket, etc. by holding the post.

step 2 Assemble the mounting-bracket by using the connecting bar.




step 3 Mark and punch holes in the U-beam according to the dimensions shown below.

User Manual 4 Mechanical Mounting




step 4 Use bolts and clamps to fix the U-beam to the column.



step 5 Use bolts to secure the pegboard to the U-beam.

4 Mechanical Mounting User Manual



--End

4.6 Installing the Inverter

Tools

Item	Specification
Phillips screwdriver	M6

Spare parts


Item	Quantity	Specification	Source
Grub screw	2	M6×65	Delivery scope

- step 1 Hoist the inverter to the installation position when necessary (refer to "4.4.2 Hoisting Transport"). If the installation position is not high enough, skip this step.
- step 2 Remove the bottom cushion and lift the inverter onto the mounting-bracket, making sure that the mounting ears fit well into the grooves of the mounting bracket.



step 3 Fix the inverter with screws.

User Manual 4 Mechanical Mounting



NOTICE

It is necessary to secure the left and right sides of the inverter to the mountingbracket with screws, otherwise the inverter may become unstable.

- - End

5 Electrical Connection

5.1 Safety Instructions

A DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

- Operators must wear proper personal protective equipment during electrical connections.
- Must ensure that cables are voltage-free with a measuring instrument before touching DC cables.
- Respect all safety instructions listed in relevant documents about PV strings.

A DANGER

- Before electrical connections, please make sure that the inverter switch and all switches connected to the inverter are set to "OFF", otherwise electric shock may occur!
- Ensure that the inverter is undamaged and all cables are voltage free before performing electrical work.
- Do not close the AC circuit breaker until the electrical connection is complete.

⚠ WARNING

Damage to the product caused by incorrect wiring is not covered by the warranty.

- · Electrical connection must be performed by professionals.
- Operators must wear proper personal protective equipment during electrical connections.
- All cables used in the PV generation system must be firmly attached, properly insulated, and adequately dimensioned.

NOTICE

All electrical connections must comply with local and national / regional electrical standards.

- Cables used by the user shall comply with the requirements of local laws and regulations.
- Only with the permission of the national / regional grid department, the inverter can be connected to the grid.

NOTICE

• All vacant terminals must be covered with waterproof covers to prevent affecting the protection rating.

- When the wiring is completed, seal the gap of cable inlet and outlet holes with fireproof / waterproof materials such as fireproof mud to prevent foreign matter or moisture from entering and affecting the long-term normal operation of the inverter.
- Comply with the safety instructions related to PV strings and the regulations related to the utility grid.



The cable colors in figures in this manual are for reference only. Please select cables according to local cable standards.

5.2 Terminal Description

All electrical terminals are located at the side and bottom of the inverter.




figure 5-1 Terminal Description (One Wire per Phase with Multi-core Cable)




figure 5-2 Terminal Description (Two Wires per Phase with Multi-core Cable)

* The image shown here is for reference only. The actual product received may differ.

Item	Terminal	Mark	Note	
Α	PV terminals	+/-	24 / 28 / 32, PV connector ¹	
В	AC wiring		Used for AC output cable connection.	
	terminal		Osed for AC output cable connection.	
	Standby			
С	grounding ter-	_	Used for internal grounding.	
	minal ²			
Б	Tracker		Used for internal Tracker , Tracker power wir-	
D	terminal	_	ing to power the Tracker.	
_	Communica-	COMA	For DS 195 communication wiring	
E	tion terminal	COM1	For RS485 communication wiring.	
_	Communica-	OOMO 2	Optional, digital input / output DI / DO and CAN	
F	tion terminal	COM2 ³	wiring, etc.	
	External		For reliable grounding	
G	grounding	(I	2, use at least one of them to ground the	
	terminal		inverter.	

⁽¹⁾ The number of PV terminals varies, subject to actual product received.

5.3 Electrical Connection Overview

Electrical connection in the PV system includes external grounding connection, AC connection, and PV string connection.

⁽²⁾ If the PE cable is an independent single-core cable, it should be inserted into the AC junction box through the standby grounding terminal.

⁽³⁾ Communication terminal COM2 is optional, subject to actual product received.




table 5-1 Cable Requirements

			Specification	
No.	Cable	Туре	Cable Diame- ter(mm)	Cross-sectional Area(mm²)
1	DC cable	PV cable complying with 1,500V standard	4.7 ~ 6.4	4~6
2	Tracking system power cable	Outdoor double- core copper wire cable	8 ~ 18	0.5 ~ 10 (Recommended 4 ~ 6)
3	External ground- ing cable	Outdoor single- core copper wire cable	/	The same as that of the PE wire in the AC cable
4	Commu- nication cable	Shielded twisted pair	4 ~ 11	0.2 ~ 1.3

The AC cable sealing plate delivered with the inverter varies. The actual product received shall prevail.

The sealing plate and the required AC cables are as follows.



figure 5-3 Sealing Plate for One Wire per Phase with Multi-core Cable

table 5-2 AC Cable Requirements(One Wire per Phase with Multi-core Cable)

		Specification		
No.	Туре	Cable Diameter(mm)	Cross-sectional Area (mm²)	
1	Outdoor four-core cop- per wire cable	40 ~ 75	L1, L2, L3 wire: 70 ~ 185	
2	Outdoor three-core cop- per wire cable Outdoor PE cable	L1, L2, L3 wire: 40 ~ 75 PE wire: 15 ~ 32	PE wire: refer to "table 5-4 PE Wire Requirements"	
3	Outdoor four-core aluminum wire cable ⁽¹⁾	40 ~ 75	L1, L2, L3 wire: 70 ~ 400	
4	Outdoor three-core alu- minum wire cable ⁽¹⁾ Outdoor PE cable	L1, L2, L3 wire: 40 ~ 75 PE wire: 15 ~ 32	PE wire: refer to "table 5-4 PE Wire Requirements"	

⁽¹⁾ A copper to aluminum adapter terminal is required when an aluminum cable is used. For details, refer to " Aluminium Cable Requirements".




figure 5-4 Sealing Plate for Two Wires per Phase with Multi-core Cable

table 5-3 AC Cable Requirements(Two Wires per Phase with Multi-core Cable)

	Туре	Specification		
No.		Cable Diameter(mm)	Cross-sectional Area (mm²)	
1	Outdoor three-core cop- per wire cable Outdoor PE cable	L1, L2, L3 wire: 47 ~ 59 PE wire: 10 ~ 30	L1, L2, L3 wire: 120 ~ 185 PE wire: refer to "table 5- 4 PE Wire Requirements"	
2	Outdoor three-core aluminum wire cable ⁽¹⁾ Outdoor PE cable	L1, L2, L3 wire: 47 ~ 59 PE wire: 10 ~ 30	L1, L2, L3 wire: 120 ~ 185 PE wire: refer to "table 5- 4 PE Wire Requirements"	


⁽¹⁾ A copper to aluminum adapter terminal is required when an aluminum cable is used. For details, refer to " Aluminium Cable Requirements".

table 5-4 PE Wire Requirements

PE Wire Cross Section	Note
S/2 (S: Phase wire cross-section S)	The specifications are valid only when the phase wire
	and PE wire use the same material. If otherwise, en-
	sure that the cross section of the PE wire produces a
	conductance equivalent to that of the wire specified in
	the table.

5.4 Crimp OT / DT terminal

Crimp OT / DT terminal



1. Heat shrink tubing

2. OT DT terminal

3. Hydraulic pliers

4. Heat gun

Aluminium Cable Requirements

If an aluminium cable is selected, use a copper to aluminium adapter terminal to avoid direct contact between the copper bar and the aluminium cable.




figure 5-5 Aluminium cable terminal connection sequence

- 1. Copper to Aluminium adapter terminal
- 2. Flange nut
- 3. Aluminium cable

NOTICE

Ensure that the selected terminal can directly contact with the copper bar. If there are any problems, contact the terminal manufacturer.

Ensure that the copper bar is not in direct contact with the aluminum wire. Otherwise, electrochemical corrosion may occur, impairing the reliability of electrical connection.

5.5 External Grounding Connection

▲ DANGER

Electric shock!

 Make sure that the ground cable is connected reliably. Otherwise, it may cause electric shock.

⚠ WARNING

- Since the inverter is not equipped with a transformer, neither the negative electrode nor the positive electrode of the PV string can be grounded. Otherwise, the inverter will not operate normally.
- Connect the grounding terminal to the protective grounding point before AC cable connection, PV string connection, and communication cable connection.

MARNING

The external protective grounding terminal must meet at least one of the following requirements.

- The cross-sectional area of the AC side grounding cable is not less than 10 mm² for copper wire or 16 mm² for aluminum wire. It is recommended that both the external protective grounding terminal and the AC side grounding terminal be reliably grounded.
- If the cross-sectional area of the AC side grounding cable is less than 10 mm² for copper wire or 16 mm² for aluminum wire, ensure that both the external protective grounding terminal and the AC side grounding terminal are reliably grounded.

The grounding connection can be made by other means if they are in accordance with the local standards and regulations, and SUNGROW shall not be held liable for the possible consequences.

5.5.1 External Grounding Requirements


All non-current carrying metal parts and device enclosures in the PV power system should be grounded, for example, brackets of PV modules and inverter enclosure.

When there is only one inverter in the PV system, connect the external grounding cable to a nearby grounding point.

When there are multiple inverters in the PV system, connect grounding points of all inverters and the PV array frames to the equipotential cable (according to the onsite conditions) to implement an equipotential connection.

5.5.2 Connection Procedure

- step 1 Prepare the cable and OT / DT terminal, refer to " Crimp OT / DT terminal".
- step 2 Remove the screw on the grounding terminal and fasten the cable with a screwdriver.



step 3 Apply paint to the grounding terminal to ensure corrosion resistance.



The grounding screws have been anchored to the side of the inverter before delivery, and do not need to be prepared.

There are two grounding terminals. Use one of them to ground the inverter.

--End

5.6 AC Cable Connection

5.6.1 AC Side Requirements



Only with the permission of the local grid department, the inverter can be connected to the grid.

Before connecting the inverter to the grid, ensure the grid voltage and frequency comply with requirements, for which, refer to **"Technical Data"**. Otherwise, contact the electric power company for help.

AC Circuit Breaker

MARNING

Over-current protection devices, such as AC circuit breakers and fuses, must be installed on the AC side of the inverter and the grid side to ensure safe disconnection between the inverter and the grid.

- Do not connect any local load between the inverter and the AC circuit breaker except for the tracking axis.
- · Multiple inverters cannot share one AC circuit breaker.

table 5-5 Recommended specifications of AC circuit breaker

Inverter Model	Recommended rated voltage	Recommended rated current
SG320 / 350HX	800 V	400 A

Multiple Inverters in Parallel Connection

When multiple inverters are connected to the grid in parallel, ensure that the maximum number of inverters connected in parallel to a single winding of the box-type substation is 15. Otherwise, please contact SUNGROW for technical scheme.

MV Transformer


The MV transformer used together with the inverter should meet the following requirements:

- The transformer may be a distribution transformer, and it must be designed for the typical cyclical loads of a PV system (load in the day and no load at night).
- The transformer may be of the liquid-immersed type or dry type, and shield winding is not necessary.
- The line-to-line voltage on the LV side of the transformer should endure the output voltage of inverter. When the transformer is connected to the IT grid, to-ground withstanding voltage of the LV winding of the transformer, the LV side AC cables, and the LV side secondary equipment (including the relay protection device, detection & measuring device, and other related auxiliary devices) should not be lower than 1,500V.
- The line-to-line voltage on the HV side of the transformer should comply with the local power grid voltage.
- A transformer with a tap changer on the HV side is recommended in order to keep consistent with the grid voltage.
- At an ambient temperature of 30°C, the transformer can run in 1.1 times of load for long time.
- A transformer with a rated capacity of 3200kVA and a short-circuit impedance equal to 7% (permissible tolerance: ±10%), or the one with a rated capacity of 4480kVA and a short-circuit impedance equal to 8% (permissible tolerance: ±10%) is recommended.
- The voltage drop of system cable is no more than 3%.
- The DC component that the transformer can withstand is 1% of the fundamental current at rated power.

 For thermal rating, the load curve of the transformer and environment conditions should be taken into account.

- The apparent power of the inverter should never exceed the power of the transformer.
 The maximum AC current of all inverters connected in parallel must be taken into account. If more than 15 inverters are connected to the grid, contact SUNGROW.
- · The transformer must be protected against overloading and short circuit.
- The transformer is an important part of grid-connected PV generation system. The fault tolerance capacity of the transformer should be taken into account at all times. The fault include: system short circuit, grounding fault, voltage drop, etc.
- Take ambient temperature, relative humidity, altitude, air quality, and other environmental conditions into account when selecting and installing the transformer.
- The overall technical requirements of the box-type LV cabinet are as follows:
 - The breaking capacity of the branch molded case circuit breaker (MCCB) and air circuit breaker (ACB) of the box-type LV cabinet should be greater than the short circuit current at the LV side of the transformer. For example, the LV side short-circuit current of a boost transformer with a rated capacity of 3200 kVA and a short-circuit resistance of 7% can be calculated in the following way: I = 3200 *1.1/0.8/1.732/0.07 = 36.29 kA. Thus the MCCB Icu of the LV cabinet branch circuit should be no less than 36.29 kA at 880Vac. The LV side short-circuit current of a boost transformer with a rated capacity of 4480kVA and a short-circuit impedance of 8% can be calculated in the following way: I = 4480 * 1.1 / 0.8 / 1.732 / 0.08 = 44.46 kA. Thus the MCCB Icu of the LV cabinet branch circuit should be no less than 44.46kA at 880Vac.
 - The temperature and altitude derating should be taken into account when a circuit breaker is working, and a LV cabinet temperature rise test report is required.
 - When designing a LV cabinet, must pay attention to the impact of the diffused MCCB electric arc on the cabinet and other branch circuit MCCBs, thus the interior of the cabinet needs to be insulated. A third-party test report of the circuit-breaking performance of the whole machine in an event of a short-circuit on the LV side is also required. It is recommended to adopt graduated protection to ensure that in an event of a single short-circuit fault on the LV side of the box, the corresponding branch MCCB trips normally while the general ACB does not trip.
 - When PLC communication is adopted, the box-type LV power distribution room needs to be equipped with a fuse switch disconnector or a circuit breaker. The recommended specification of the cable connecting to the EMU200 is 4 mm² - 10 mm², the cable voltage specification is 1.8 / 3 kV, and the cable distance from the EMU200 to the box's LV bus should be no more than 10 m.
- When Anti-PID is enabled, the AC output common mode voltage of the inverter is 906V, and the following requirements should be met:
 - The LV side winding of the transformer, AC cables, and secondary devices (including protective relay, detection and measurement instruments, and related auxiliary devices) must withstand the voltage to ground of at least 906 V.
 - If the LV side winding is in Y shape, neutral point grounding is prohibited.

 Surge protective devices (SPD) for the AC combiner box and on the LV side of the transformer are recommended to be connected in the "3+1" manner, as shown in the figure below. The Min. continuous operating voltages of M1 - M4 are 680 Vac.




 The string serial communication box EMU200 requires an external power supply of 220 Vac, so a power supply port and an input port (including switches) should be reserved in the LV power distribution room of the boost transformer.

5.6.2 Requirements for OT/DT Terminal

OT/DT terminals (not included in the delivery scope) are required for fixing AC cables to the terminal block. Purchase the OT/DT terminals according to the following requirements.


OT/DT Terminals of Phase Wire (One Wire per Phase with Multi-core Cable)

Specification: M12



OT/DT Terminals of Phase Wire (Two Wires per Phase with Multi-core Cable)

Specification: M12



OT/DT Terminal of PE Wire


Specification: M12

5.6.3 Connection Procedure of One Wire per Phase with Multi-core Cable



This section introduces the connection steps with four-core cable as an example, and the wiring method for three-core cable is the same.


- step 1 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.
- step 2 Loosen the two screws on the front cover of the junction box with the hexagon socket wrench provided. Open the junction box. During the wiring process, the limit rod attached to the cover keeps the junction box open.





The screws on the front cover of the junction box are captive screws, which will remain on the front cover when the cover is open to avoid screw loss.


step 3 Loosen the screws on the bottom sealing plate with the hexagon socket wrench provided and remove the bottom sealing plate.






The screws on the sealing plate are captive screws, which will remain on the sealing plate when the sealing plate is removed to avoid screw loss.


step 4 Cut off excess sealing ring according to the outer diameter of the cable.




step 5 Lead the cable with the protective layer removed through the sealing ring and fix the screws on the bottom sealing plate.




step 6 Open the protection cover.




step 7 Fix cables with crimped OT/DT terminals to corresponding terminals.






step 8 Close the protection cover.




step 9 Remove the limit rod and place it in place. Close the junction block and tighten the two screws on its front cover with the hexagon socket wrench provided.




- - End

When a separate single-core cable is used as the PE cable, lead it into the junction box through the external grounding terminal.



5.6.4 Connection Procedure of Two Wires per Phase with Multi-core Cable


- step 1 Disconnect the AC-side circuit breaker and prevent it from inadvertent reconnection.
- step 2 Loosen the two screws on the front cover of the junction box with the hexagon socket wrench provided. Open the junction box. During the wiring process, the limit rod attached to the cover keeps the junction box open.





The screws on the front cover of the junction box are captive screws, which will remain on the front cover when the cover is open to avoid screw loss.


step 3 Loosen the screws on the bottom sealing plate with the hexagon socket wrench provided and remove the bottom sealing plate.






The screws on the sealing plate are captive screws, which will remain on the sealing plate when the sealing plate is removed to avoid screw loss.

step 4 Cut off excess sealing ring according to the outer diameter of the cable.




step 5 Lead the cable with the protective layer removed through the sealing ring and fix the screws on the bottom sealing plate.




step 6 Open the protection cover.




step 7 $\,$ Fix cables with crimped OT/DT terminals to corresponding terminals.






step 8 Close the protection cover after fixing all cables to corresponding terminals.



step 9 Remove the limit rod and place it in place. Close the junction block and tighten the two screws on its front cover with the hexagon socket wrench provided.



- - End

5.7 DC Cable Connection

▲ DANGER

The PV string will generate lethal high voltage when exposed to sunlight.

Respect all safety instructions listed in relevant documents about PV strings.

▲ WARNING

 Make sure the PV array is well insulated to ground before connecting it to the inverter.

- Make sure the maximum DC voltage and the maximum short circuit current of any string never exceed inverter permitted values specified in "Technical Data".
- Check the positive and negative polarity of the PV strings, and connect the PV connectors to corresponding terminals only after ensuring polarity correctness.
- During the installation and operation of the inverter, please ensure that the positive or negative electrodes of PV strings do not short-circuit to the ground. Otherwise, an AC or DC short-circuit may occur, resulting in equipment damage. The damage caused by this is not covered by the warranty.
- Electric arc or contactor over-temperature may occur if the PV connectors are not firmly in place, and SUNGROW shall not be held liable for any damage caused.
- If the DC input cables are reversely connected or the positive and negative terminals of different MPPT are shorted to ground at the same time, while the DC switch is in the "ON" position, do not operate immediately. Otherwise, the inverter may be damaged. Please turn the DC switch to "OFF" and remove the DC connector to adjust the polarity of the strings when the string current is lower than 0.5 A.

NOTICE

The following requirements about PV string connection must be met. Otherwise, it may cause irreversible damage to the inverter, which is not covered by the warranty.

 Mixed use of different brand or model of PV modules in one MPPT circuit, or PV modules of different orientation or angles in a string may not damage inverter but will cause system bad performance!

5.7.1 PV Input Configuration

- As shown in the figure below, the inverter is provided with multiple PV inputs, each PV input is designed with an MPP tracker.
- Each PV input operates independently and has its own MPPT. In this way, string structures of each PV input may differ from each other, including number of PV modules in each string, angle of tilt, and installation orientation.
- Each PV input includes two PV strings. In order to fully utilize the input power of PV panels, the PV strings of each PV input should have the same structure, including the same type, the same number, the same tilt, and the same orientation.




figure 5-6 PV Input Configuratioon

Prior to connecting the inverter to PV inputs, the specifications in the following table should be met:

Open-circuit Voltage Limit	Max. Current For Input Connector
4500.1/	30 A (SG350HX)
1500 V	40 A (SG320HX)

5.7.2 Assembling the PV Connectors

A DANGER


High voltage may be present in the inverter!

- Ensure all cables are voltage-free before performing electrical operations.
- Do not connect the AC circuit breaker before finishing electrical connection.




SUNGROW provides corresponding PV connectors in the scope of delivery for quick connection of PV inputs. To ensure IP66 protection, use only the supplied connector or the connector with the same ingress of protection.

step 1 Strip the insulation from each DC cable by 8 mm ~ 10 mm.



step 2 Assemble the cable ends with the crimping pliers.




1: Positive crimp contact

2 : Negative crimp contact

step 3 Lead the cable through cable gland, and insert the crimp contact into the insulator until it snaps into place. Gently pull the cable backward to ensure firm connection.



step 4 Tighten the cable gland and the insulator.



step 5 Check for polarity correctness.


NOTICE

If the PV polarity is reversed, the inverter will be in a fault or alarm state and will not operate normally.

--End

5.7.3 Installing the PV Connector

step 1 Ensure that the DC switch is in "OFF" position. Otherwise, manually turn it to "OFF".




step 2 Check the cable connection of the PV string for polarity correctness and ensure that the open circuit voltage in any case does not exceed the inverter input limit of 1,500 V.



NOTICE

The range of the multimeter shall be greater than 1500 V. If the measured voltage is less than 0, adjust the cable polarity. If the measured voltage is greater than 1500 V, reduce the number of PV modules.

step 3 Connect the PV connectors to corresponding terminals until there is an audible click.



- step 4 Follow the foregoing steps to connect PV connectors of other PV strings.
- step 5 Seal any unused PV terminal with a terminal cap.

--End


5.8 Wiring of Tracking System Power Cable (Optional)

- step 1 Refer to step 1 to step 2 described in 5.6.3 Connection Procedure of One Wire per Phase with Multi-core Cable".
- step 2 Cut off excess sealing ring according to the outer diameter of the cable.




step 3 Lead the cable with the protective layer removed through the sealing ring. Retain 50mm of cable with the protective layer in the AC junction box.

User Manual 5 Electrical Connection



step 4 Stack the OT terminals on the OT/DT terminal of the AC cables, and fix the cables to corresponding terminals.



0

The tracking power cable can be installed in any two phases of L1/L2/L3.

step 5 Close the protection cover. Close the wiring compartment and tighten the two screws on its front cover with supplied Allen wrench.

- - End

5 Electrical Connection User Manual



Protection devices required between the inverter and the tracking system control box: disconnector switch (≥ 800 Vac) + fuse (16A, gM).

Length of the cable connecting the internal wiring terminal of the inverter and the fuse should be less than 2.5 m.

5.9 RS485 Connection(COM1)

5.9.1 Interface Description

The inverter communication terminal COM1 is located at the bottom of the inverter, as shown in the figure below.




table 5-6 Communication terminal COM1 definition


Port	PIN	Definition	Description
	1	RS485A IN, RS485 differential sig-	
		nal+	
	2	RS485A IN, RS485 differential sig-	Used for cascading in-
D0405 4		nal+	verters or connecting to
RS485_1	3	RS485B OUT, RS485 differential	devices such as the Da-
		signal-	ta Logger.
	4	RS485B OUT, RS485 differential	
		signal-	
DE	5	PE, shielding ground	
PE	6	PE, shielding ground	
RS485_2	7	RS485A, RS485 differential signal	Communication device for connection to the tracking system
		+	
	8	RS485B, RS485 differential	
		signal-	

5.9.2 RS485 Communication System

Single-inverter Communication System


In case of a single inverter, communication cable connection requires only one RS485 cable.

User Manual 5 Electrical Connection



Multi-inverter Communication System

In case of multiple inverters, all the inverters can be connected via RS485 cables in the daisy chain manner. The communication cable of the tracking system can be connected to the port RS485_2 of any inverter in the daisy chain.



The length of the RS485 cable should be no longer than 1,200 m.




If multiple inverters are connected to the data logger, the number of permissible daisy chains and the number of devices allowed to be connected should meet the requirements (refer to the user manual for the data logger).


5.9.3 Connection Procedure

step 1 Unscrew the swivel nut from the communication terminal and take out the seal.

5 Electrical Connection User Manual




step 2 Press the snap on both sides of the connector to remove the on-site making of wire parts.




S000-E068

step 3 Select a seal according to the cable outer diameter. Lead the cable through the swivel nut, seal and on-site making of wire parts.




step 4 Strip the cable of appropriate lengths of protective and insulating layers.


User Manual 5 Electrical Connection



step 5 Secure the wires to corresponding terminals.




step 6 Pull cables outwards to confirm whether they are fastened firmly, then tighten the swivel nut with appropriate torque.




step 7 Remove the waterproof lid from the communication terminal COM1.


5 Electrical Connection User Manual



step 8 Insert the connector into the communication terminal.



step 9 Seal the vacant connector seal with a waterproof plug.



- - End

User Manual 5 Electrical Connection

5.10 Dry Contact Connection(COM2)



Communication terminal COM2 is optional, subject to actual product received.

5.10.1 Interface Description

The inverter communication terminal COM2 is located at the bottom of the inverter, as shown in the figure below.




table 5-7 Communication terminal COM2 definition

Port	PIN	Definition	Description	
1	1	1		
1	2	1		
DI	3	DI	- emergency stop dry contact	
DI	4	PGND		
	5	COM		
D0	6	NC	fault output dry contact	
	7	NO		
1	8	1		

5.10.2 Dry Contact Function

DI terminal (emergency stop dry contact): the dry contact can be configured to be an emergency stop contact.

When the DI contact and PGND contact are shorted by external controlled switch (The external switch can be configured as normally open contact or normally closed contact), the inverter will immediately stop.



The dry contacts only support passive switch signal input.

The following figure shows the typical application of emergency stop dry contact.

5 Electrical Connection User Manual




figure 5-7 Local stop contact

When wiring DI dry contacts, ensure that the maximum wiring distance meet the requirements in "10.2 Wring Distance of DI Dry Contact".

DO terminal (fault output dry contact): the relay can be set to fault alarm output, and user can configure it to be a normal open contact (COM & NO) or a normal close contact (COM & NC).

The relay is initially at the NC terminal, and it will trip to another contact when a fault occurs. Use LED indicators or other equipment to indicate whether the inverter is in the faulty state.




figure 5-8 Normal open contact




figure 5-9 Normal close contact

Devices connected to the relay should comply with related requirements:

User Manual 5 Electrical Connection


AC-Side Requirements	DC-Side Requirements
Max. voltage: 230 Vac	Max. voltage: 30Vdc
Max. current: 3A	Max. current: 3A

5.10.3 Connection Procedure

step 1 Unscrew the swivel nut from the communication terminal and take out the seal.




step 2 Press the snap on both sides of the connector to remove the on-site making of wire parts.




S000-E068

step 3 Select a seal according to the cable outer diameter. Lead the cable through the swivel nut, seal and on-site making of wire parts.


5 Electrical Connection User Manual



step 4 Strip the cable of appropriate lengths of protective and insulating layers.




step 5 Secure the wires to corresponding terminals.




step 6 Pull cables outwards to confirm whether they are fastened firmly, then tighten the swivel nut with appropriate torque.


User Manual 5 Electrical Connection



step 7 Remove the waterproof lid from the communication terminal COM2.




step 8 Insert the connector into the communication terminal.



step 9 Seal the vacant connector seal with a waterproof plug.

5 Electrical Connection User Manual



--End

5.11 PLC Communication Connection

With a PLC communication module built inside, the inverter can communicate with the Data Logger provided by SUNGROW. For specific wiring method, refer to the user manual for the data logger.

The maximum PLC communication distance from the box-type substation to the inverter is:

- If there is one cable per phase, with single-core cable, the maximum communication distance is 800 m. Bind three-phase cables with cable ties every 1m.
- If there are two cables per phase, with single-core cable, the maximum communication
 distance is 800 m. Bind three-phase cables with cable ties every 1m. The distance between two bundles of AC cables should be more than 15 cm. The length of the two AC
 cables should be the same. If not, the length difference must be smaller than 2m.
- If there is one wire per phase, with multi-core cable, the maximum communication distance is 1000 m.
- If there are two wires per phase, with multi-core cable, the maximum communication distance is 1000 m. The distance between two AC cables should be more than 15 cm. The length of the two AC cables should be the same. If not, the length difference must be smaller than 2m.
 - The Data Logger is an optional device that can be ordered from SUNGROW.



The Data Logger conducts data communication by directly using the AC output
cable of the inverter and thus saves the trouble to lay and maintain the special
communication cables. The RS-485 port of the Data Logger supports the
transparent transmission of the MODBUS-RTU and is completely compatible
with the monitoring devices and software of the original RS-485 communication method.

6 Commissioning

6.1 Inspection before Commissioning

Check the following items before starting the inverter:

- · All equipment has been reliably installed.
- DC switch(es) and AC circuit breaker are in the "OFF" position.
- · The ground cable is properly and reliably connected.
- The AC cable is properly and reliably connected.
- The DC cable is properly and reliably connected.
- The communication cable is properly and reliably connected.
- · The vacant terminals are sealed.
- No foreign items, such as tools, are left on the top of the machine or in the junction box (if there is).
- The AC circuit breaker is selected in accordance with the requirements of this manual and local standards.
- All warning signs & labels are intact and legible.

6.2 Commissioning Procedure

If all of the items mentioned above meet the requirements, proceed as follows to start up the inverter for the first time.

step 1 Rotate one DC switch of the inverter to the "ON" position. When the indicator blinks blue slowly, turn the other DC switches to the "ON" position.

NOTICE

The indicator is red if there is no power supply from the grid. Report the grid power failure (the fault information can be viewed on the iSolarCloud App, see "Records" for details). The fault is automatically cleared when the AC circuit breaker between the inverter and the grid is closed.

- step 2 Close the AC circuit breaker between the inverter and the grid.
- step 3 Install the iSolarCloud App, see "7.2 Installing the App" for details.
- step 4 Set initial protection parameters via the iSolarCloud App when the inverter is connected to the grid for the first time (see Step 4 in "7.3.2 Login Procedure" for details). If the irradiation and grid conditions meet requirements, the inverter normally operates.

6 Commissioning User Manual

step 5 The home page is automatically displayed when the initialization is completed. The indicator is steady blue, and the inverter is in grid-connected operation.

--End

7 iSolarCloud App

7.1 Brief Introduction

The iSolarCloud App can establish communication connection to the inverter via the Bluetooth, thereby achieving near-end maintenance on the inverter. Users can use the App to view basic information, alarms, and events, set parameters, or download logs, etc.



Screenshots in this manual are based on the Android system V2.1.6, and the actual interfaces may differ.

7.2 Installing the App

Method 1

Download and install the App through the following application stores:

- MyApp (Android, mainland China users)
- Google Play (Android, users other than mainland China ones)
- App Store (iOS)

Method 2

Scan the following QR code to download and install the App according to the prompt information.



The App icon appears on the home screen after installation.



7.3 Login

7.3.1 Requirements

The following requirements should be met:

- The AC or DC side of the inverter is powered-on.
- The mobile phone is within 5 meters away from the inverter and there are no obstructions in between.
- The Bluetooth function of the mobile phone is enabled.



The inverter can only pair with one phone at a time through Bluetooth.

7.3.2 Login Procedure

- step 1 Open the App to enter the login page, tap **Local Access** at the bottom of the page to go to the next page.
- step 2 Scan the QR code on the side of the inverter for Bluetooth connection. Or tap MANUAL CONNECTION at the bottom of the interface and select Others, the Bluetooth search interface will automatically appear. Select the inverter to be connected according to the serial number on the nameplate on the side of the inverter, or tap to scan the QR code on the side of the inverter for Bluetooth connection. The connection is successfully established if the LED indicator blinks blue.




figure 7-1 Bluetooth Connection

step 3 Enter the identity verification screen after the Bluetooth connection is established.



figure 7-2 Login

The Account is "user", and the initial password is "pw1111" or "111111" which should be changed for the consideration of account security.



To set inverter parameters related to grid protection and grid support, contact your distributor to obtain the advanced account and corresponding password. If the distributor is unable to provide the required information, contact SUNGROW.

step 4 If the inverter is not initialized, you will enter the quick setting screen of initializing protection parameter.




figure 7-3 Initialization Protection Parameter

NOTICE

The Country/Region must be set to the country where the inverter is installed at. Otherwise, the inverter may report errors.

- step 5 After finishing the settings, tap **TUNR ON DEVICE** at the upper right corner and the device will be initialized. The App will send start instructions and the device will start and operate.
- step 6 If the inverter is initialized, the App automatically turns to its home page.

- - End

7.4 Function Overview

The App provides parameter viewing and setting functions, as shown in the following figure.




figure 7-4 App function tree map

7.5 Home page

After login, the home page is as follows:



figure 7-5 Home page

table 7-1 Home Page Description

No.	Designation	Description	
1	Date and time	System date and time of the inverter	
2	Inverter state	Present operation state of the inverter For details, refer to	
	inverter state	"table 7-2 Description of Inverter State".	
2	PID function state	Present state of the PID function For details, refer to "table	
3	PID function state	7-3 Description of PID Function State"	
		Display the PV power generation power, feed-in power, etc.	
4	Power flow chart	The line with an arrow indicates energy flow between con-	
7	1 OWEI HOW CHAIL	nected devices, and the arrow pointing indicates energy	
		flow direction.	
5	Real-time power	Output power of the inverter	
6	6 Power generation	Today power yield and accumulative power yield of the	
	1 ower generation	inverter	
		Curve showing change of power between 5 am and 23 pm	
7	Dower ounce	every day	
7	Power curve	(Each point on the curve represents the percentage of	
		present inverter power to rated power)	
8	Navigation bar	Including Home, Run-info, His-record, and More	

table 7-2 Description of Inverter State

State	Description
	After being energized, inverter tracks the PV arrays' maximum power
Run	point (MPP) and converts the DC power into AC power. This is the nor-
	mal operation mode.
Stop	Inverter is stopped.
Koy eten	Inverter will stop operation by manually "stop" via app. In this way, inver-
Key-stop	ter internal DSP stops. To restart the inverter, manually start via app.
Standby	Inverter enters standby mode when DC side input is insufficient. In this
Standby	mode inverter will wait within the standby duration.
Initial standby	The inverter is in the initial power-on standby state.
Starting	The inverter is initializing and synchronizing with the grid.
Warning	Warning information is detected.
Derating	The inverter derates actively due to environmental factors such as tem-
running	perature or altitude
Scheduling	The inverter runs according to the scheduling instructions received from
running	the monitoring background
	If a fault occurs, inverter will automatically stop operation, and discon-
Fault	nect the AC relay. The fault information will be displayed in the app.
Fault	Once the fault is removed in recovery time, inverter will automatically re-
	sume running.

table 7-3 Description of PID Function State

State	Description	
PID recovery	The inventors newform DID receives estimate	
running	The inverters perform PID recovery actively.	
DID abnormity	It is detected that the ISO impedance is abnormal or the PID function	
PID abnormity	cannot work normally after the PID function enabled.	

If the inverter is running abnormally, the alarm or fault icon will be displayed in the lower right corner of the inverter icon in power flow chart. The user can tap this icon to enter the alarm or fault screen to view detailed information and corrective measures.

7.6 Run Information

Tap **Run Information** in the navigation bar to enter the corresponding interface. Swipe upward to view details.

The run information includes the PV information, the inverter information, and input and output information.

table 7-4 Run information

Classifica-	Parameter name	Description	
PV	String n Voltage	The input voltage of the n	
Information	String n Current	The input current of the n	
	Total grid-connected runtime	1	
	Daily grid-connected runtime	1	
	Negative to ground voltage	Inverter DC side negative to ground voltage value	
	Bus voltage	Voltage between the positive and negative poles of the DC side of the inverter	
Inverter Information	Internal air temperature	1	
	Array insulation impedance	Insulation resistance value of the input side to the protection ground	
	Country Information	1	
	Power Limitation Mode	1	
	Reactive Power Mode	1	
	Total DC Power	DC side total input power	
Input	MPPT x Voltage	The input voltage of MPPT x	
	MPPT x Current	The input current of MPPT x	
	Daily yield	1	
	Monthly yield	1	
	Annual yield	1	
	Total active power	Current active power value of the inverter	
	Total reactive power	Current reactive power value of the inverter	
	Total apparent power	Current apparent power value of the inverter	
Output	Total power factor	Power factor of the AC side of the inverter	
Cutput	Grid Frequency	Frequency of the AC side of the inverter	
	A-B Line Voltage		
	B-C Line Voltage	Line Voltage	
	C-A Line Voltage	-	
	A-Phase Current	_	
	B-Phase Current	Phase Current	
	C-Phase Current		

7.7 Records

Tap **Records** on the navigation bar to enter the screen showing event records, as shown in the following figure.



figure 7-6 Records

Fault Alarm Record

Tap Fault Alarm Record to enter the screen, as shown in the following figure.



figure 7-7 Fault Alarm Record



Click to select a time segment and view corresponding records.

The inverter can record up to 400 latest entries.

Select one of the records in the list and click the record, to view the detailed fault info as shown in following figure.



figure 7-8 Detailed Fault Alarm Information

Yield Record

Tap **Yield Record** to enter the screen showing daily power generation , as shown in the following figure.



figure 7-9 Power Curve

The App displays power generation records in a variety of forms, including daily power generation graph, monthly power generation histogram, annual power generation histogram and total power generation histogram.

table 7-5 Explanation of power yields records

Parameter	Description	
	Show the power output from 5 am to 11 pm in a single day. Each	
Power curve	point in the curve is the percentage of present power and nominal	
	power.	
Daily energy	Channe the manual and the device the managed manuals	
histogram	Shows the power output every day in the present month.	
Monthly energy	Channe the management area with in a reason	
histogram	Shows the power output every month in a year.	
Annual energy	Shows the power output every year.	
histogram		

Tap the time baron the top of the screen to select a time segment and view the corresponding power curve.

Swipe left to check the power yields histogram.

Event Record

Tap **Event Record**to view event record list.



Click to select a time segment and view corresponding records.

The inverter can at most record the latest 400 events.

7.8 More

Tap **More** on the navigation bar to enter the corresponding screen, as shown in the following figure.



figure 7-10 More

7.8.1 System Parameters

Tap **Settings**→**System Parameters** to enter the corresponding screen, as shown in the following figure.



figure 7-11 System Parameters

Boot/Shutdown

Tap **Boot/Shutdown** to send the boot/shutdown instruction to the inverter.

Date Setting/Time Setting

The correct system time is very important. Wrong system time will directly affect the data logging and power generation value. The clock is in 24-hour format.

Software Version

Version information of the current firmware.

7.8.2 Operation Parameters

Running Time

Tap **Settings**→**Operation Parameters**→**Running Time** to enter the corresponding screen, on which you can set "Running Time".

^{*} The image shown here is for reference only.



figure 7-12 Running Time

PID Parameters

Tap **Settings**→**Operation Parameters**→**PID Parameters** to enter the corresponding screen, on which you can set "PID Parameters".



figure 7-13 PID Setting

table 7-6 PID Parameter Description

Parameter	Description	
Availability of Q at Night during PID Recovery	If this switch is turned on, PID recovery and Q at night can be enabled at the same time, but can not work at the same time.	
PID Recovery*	Set enabling/disabling of the PID night recovery function. PID night recovery functions between 22:00 pm and 5:00 am by default.	
Anti PID	Enable this function of the inverter to protect PV modules from PID effect during the daytime	
Clear PID Alarm	If ISO impedance abnormality or PID function exception is detected during running of the PID function, the inverter reports a PID false alarm and reminds the user to take corresponding measures. After processing, clear the alarm via this parameter.	
PID Scheme	Apply negative or positive voltage.	
Full-Day PID Suppression	Enable this function to enable both PID recovery and anti PID.	

^{*:}Please enable both "Availability of Q at Night during PID Recovery" and "PID Recovery" to turn on the PID recovery.

NOTICE

Please ensure that the inverter is equipped with DC PID before setting PID parameters. If it is equipped with AC PID, please refer to the EMU200A user manual for PID parameter settings. The PID type of the inverter is subject to the actually received inverter.

7.8.3 Power Regulation Parameters

Active Power Regulation

Tap **Settings**→**Power Regulation Parameters**→**Active Power Regulation** to enter the screen, as shown in the following figure.




figure 7-14 Active Power Regulation

table 7-7 Active Power Regulation

Parameter	Definition/Setting Description	Range
Active power soft start after fault	The switch for enabling/dis- abling the soft start function after a fault occurs.	Enable/Disable
Active power soft start time after fault	Time that the soft start takes to raise the power from 0 to 100% rated power.	1s~1200s
Active power gradient control	Switch for enabling/disabling the active power rate settable function.	Enable/Disable
Active power decline gradient	The decline rate of inverter active power per minute.	1%/min~6000%/min

Parameter	Definition/Setting Description	Range
Active power rising gradient	The rise rate of inverter active power per minute.	1%/min~6000%/min
Active power setting persistence	Switch for enabling/disabling the function of saving output limited power.	Enable/Disable
Active power limit	The switch for limiting output power.	Enable/Disable
Active power limit ratio	The ratio of limiting output power to rated power in percentage.	0%~110%
Shutdown when active power limit to 0%	Switch used to determine whether the inverter is in stop state when the limited power reaches 0.	Enable/Disable
100% Scheduling to achieve active overload	Switch used to ensure that the inverter operates at the maximum active power when PV power limit ratio is set over 100%.	Enable/Disable

The inverter provides the reactive power regulation function. Enable this function under **Reactive Power Regulation Mode** and select the appropriate mode.

table 7-8 Descriptions of reactive power regulation mode:

Mode	Descriptions
Off	The PF is fixed at +1.000.
PF	The reactive power can be regulated by the parameter PF (Power Factor).
Qt	The reactive power can be regulated by the parameter Q-Var limits (in %).
Q(P)	The PF changes with the output power of the inverter.
Q(U)	The reactive power changes with the grid voltage.

"Off" Mode

The reactive power regulation function is disabled. The PF is limited to ± 1.000 .

"PF" Mode

The power factor is fixed and reactive power setpoint is calculated according to the current power. The range of PF is (-1.0 to -0.8) and (+0.8 to +1.0).

Leading: the inverter is sourcing reactive power to the grid.

Lagging: the inverter is injecting reactive power into the grid.

"Qt" Mode

In the Qt mode, system rated reactive power is fixed, and the system injects reactive power according to the delivered reactive power ratio. The **Reactive Power Ratio** is set through the App.

The setting range of the reactive power ratio is 0~100% or 0~-100%, corresponding to the ranges of inductive and capacitive reactive power regulation respectively.

"Q(P)" Mode

The PF of the inverter output varies in response to the output power of the inverter.

table 7-9 "Q(P)" Mode Parameter Descriptions:

Parameter	Explanation	Range	
Reactive	Switch for enabling/disabling reactive		
response	response	Enable/Disable	
Reactive re-	Completion times of mostive management	0.1s~600.0s	
sponse time	Completion time of reactive response		
Q(P) Curve	Select corresponding curve according to	A, B, C*	
Q(I) Oulve	local regulations		
QP_P1	Output power at P1 on the Q(P) mode	0 ~ 100%	
	curve (in percentage)		
OP P2	Output power at P2 on the Q(P) mode	20% ~ 100%	
QP_P2	curve (in percentage)		
QP_P3	Output power at P3 on the Q(P) mode	20% ~ 100%	
	curve (in percentage)		
QP_K1	Power factor at P1 on the Q(P) mode		
QP_K1	curve	Curve A/C: 0.8 ~ 1	
QP_K2	Power factor at P2 on the Q(P) mode	Curve B: [-0.600~0.600]	
QF_K2	curve	*Active Overload Rate/	
QP_K3	Power factor at P3 on the Q(P) mode	1000	
	curve		
QP_	Voltage percentage for Q(P) function	100% ~ 110%	
EnterVoltage	erVoltage activation		
QP_ExitVoltage	Voltage percentage for Q(P) function	90% ~ 100%	
	deactivation		
QP_ExitPower	Power percentage for Q(P) function	1% ~ 100%	
	deactivation		
QP_EnableMode	Unconditional activation/deactivation of Q	Yes / No	
	(P) function		

^{*} Curve C is reserved and consistent with Curve A currently.




figure 7-15 Q(P) Curve

"Q(U)" Mode

table 7-10 "Q(U)" Mode Parameter Descriptions:

Parameter	Explanation	Range
Reactive response	Switch for enabling/disabling reactive response	Enable/Disable
Reactive response time	Completion time of reactive response	0.1s~600.0s
Q(U) curve	Select corresponding curve according to lo- cal regulations	A, B, C*
Hysteresis Ratio	Voltage hysteresis ratio on the Q(U) mode curve	0 ~ 5%
QU_V1	Grid voltage limit at P1 on the Q(U) mode curve	80% ~ 100%
QU_Q1	Value of Q/Sn at P1 on the Q(U) mode curve	[-60.0%-0]* Over- load Rate/ 1000
QU_V2	Grid voltage limit at P2 on the Q(U) mode curve	80% ~ 100%
QU_Q2	Value of Q/Sn at P2 on the Q(U) mode curve	[-60.0%-60.0%]* Overload Rate/ 1000
QU_V3	Grid voltage limit at P3 on the Q(U) mode curve	100% ~ 120%
QU_Q3	Value of Q/Sn at P3 on the Q(U) mode curve	[-60.0%-60.0%]* Overload Rate/ 1000
QU_V4	Grid voltage limit at P4 on the Q(U) mode curve	100% ~ 120%
QU_Q4	Value of Q/Sn at P4 on the Q(U) mode curve	[0-60.0%]* Over- load Rate/ 1000
QU_EnterPower	Active power for Q(U) function activation	20% ~ 100%

Parameter	Explanation	Range
QU_ExitPower	Active power for Q(U) function deactivation	1% ~ 20%
QU_EnableMode	Unconditional activation/deactivation of Q	Yes / No / Yes,
	(U) function	Limited by PF
QU_Limited PF	DE value for O/LI) function activation	0~1.00
Value	PF value for Q(U) function activation	

^{*} Curve C is reserved and consistent with Curve A currently.




figure 7-16 Q(U) Curve

7.8.4 Communication Parameters

Serial Port Parameters

Tap Settings—Communication Parameters—Serial Port Parameters to enter the corresponding interface, as shown in the following figure.



figure 7-17 Serial Port Parameters

table 7-11 Serial Port Parameters

Parameter	Range
Device Address	1–246

MPLC Parameters

Tap **Settings** → **Communication Parameters** → **MPLC Parameters** to enter the corresponding interface, as shown in the following figure.



figure 7-18 MPLC Parameters

table 7-12 MPLC Parameters

Parameter	Range
Band Num	Band1, Band2
Array ID	1–255
Winding ID	1–10

7.8.5 Firmware Update

To avoid download failure due to poor on-site network signal, it is recommended to download the firmware package to the mobile device in advance.

- step 1 Enable the "Mobile data" of the mobile device.
- step 2 Open the App, enter the account and password on the login screen. Tap **Login** to enter the home screen.
- step 3 Tap **More**→**Firmware Download** to enter corresponding screen on which you can view the device list.
- step 4 Select the device model before downloading the firmware. Tap the device name in the device list to enter the firmware upgrade package detail interface, and tap behind the firmware upgrade package to download it.



- step 5 Return to the **Firmware Download** screen, tap <u>in</u> the upper right corner of the screen to view the downloaded firmware upgrade package.
- step 6 Login the App via local access mode. Refer to "7.3 Login".
- step 7 Tap More on the App home screen and then tap Firmware Update.
- step 8 Tap the upgrade package file, a prompt box will pop up asking you to upgrade the firmware with the file, tap **CONFIRM** to perform the firmware upgrade.



step 9 Wait for the file to be uploaded. When the upgrade is finished, the interface will inform you of the upgrade completion. Tap **Complete** to end the upgrade.



--End

7.8.6 Password Changing

Tap **Modify Password** to enter the modify password screen, as shown in the following figure.



figure 7-19 Change Password

The password shall consisit of 8–20 digits, including letters and numbers.

8 System Decommissioning

8.1 Disconnecting the Inverter

A CAUTION

Danger of burns!

Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

For maintenance or other service work, the inverter must be switched off.

Proceed as follows to disconnect the inverter from the AC and DC power sources. Lethal voltages or damage to the inverter will follow if otherwise.

- step 1 Disconnect the external AC circuit breaker and secure it against reconnection.
- step 2 Rotate the DC switch to the "OFF" position for disconnecting all of the PV string inputs.
- step 3 Wait about 25 minutes until the capacitors inside the inverter completely discharge.
- step 4 Ensure that the DC cable is current-free via a current clamp.
 - - End

8.2 Dismantling the Inverter

A CAUTION

Risk of burn injuries and electric shock!


After the inverter is powered off for 25 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.



Before dismantling the inverter, disconnect both AC and DC connections.

If there are more than two layers of inverter DC terminals, dismantle the outer DC connectors before dismantling the inner ones.

step 1 Refer to "5 Electrical Connection", for the inverter disconnection of all cables in reverse steps. In particular, when removing the DC connector, use an MC4-Evo2 wrench to loosen the locking parts and install waterproof plugs.



- step 2 Refer to "4 Mechanical Mounting", to dismantle the inverter in reverse steps.
- step 3 If necessary, remove the wall-mounting bracket from the wall.
- step 4 If the inverter will be used again in the future, please refer to "3.3 Inverter Storage" for a proper conservation.
 - --End

8.3 Disposal of the Inverter

Users take the responsibility for the disposal of the inverter.

M WARNING

Please scrap the inverter in accordance with relevant local regulations and standards to avoid property losses or casualties.

NOTICE

Some parts of the inverter may cause environmental pollution. Please dispose of them in accordance with the disposal regulations for electronic waste applicable at the installation site.



9 Troubleshooting and Maintenance

9.1 Troubleshooting

Once the inverter fails, the fault information can be displayed on the App interface. If the inverter is equipped with an LCD screen, the fault information can be viewed on it.

The fault codes and troubleshooting methods of all PV inverters are detailed in the table below. The device you purchase may only contain some of the fault information, and when the inverter fails, you can check the corresponding information through the fault codes from the mobile app.

Fault code	Fault name	Corrective measures
		Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
	Grid Overvoltage	1. Measure the actual grid voltage, and contact
		the local electric power company for solutions if
2 2 14 15		the grid voltage is higher than the set value.
2, 3, 14, 15		2. Check whether the protection parameters are
		appropriately set via the App or the LCD. Modify
		the overvoltage protection values with the con-
		sent of the local electric power operator.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		Generally, the inverter will be reconnected to the
	Grid Undervoltage	grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		1. Measure the actual grid voltage, and contact
		the local electric power company for solutions if
4, 5		the grid voltage is lower than the set value.
		2. Check whether the protection parameters are
		appropriately set via the App or the LCD.
		3. Check whether the AC cable is firmly in place.
		4. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.

Fault code	Fault name	Corrective measures	
i-auit code	Grid	Generally, the inverter will be reconnected to the	
8	Overfrequency	grid after the grid returns to normal. If the fault oc-	
9	Overnequency	curs repeatedly:	
	Grid Underfrequency	1. Measure the actual grid frequency, and contact the local electric power company for solutions if the grid frequency is beyond the set range. 2. Check whether the protection parameters are	
	Onderfrequency	appropriately set via the App or the LCD.	
		3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.	
		Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:	
		1. Check whether the grid supplies power reliably.	
		2. Check whether the AC cable is firmly in place.	
	Grid Power	3. Check whether the AC cable is connected to	
10	Outage	the correct terminal (whether the live wire and	
		the N wire are correctly in place).	
		Check whether the AC circuit breaker is connected.	
		5. Contact Sungrow Customer Service if the pre-	
		ceding causes are ruled out and the fault persists.	
40	Excess Leakage	1. The fault can be caused by poor sunlight or damp environment, and generally the inverter will be reconnected to the grid after the environment is improved.	
12	Current	2. If the environment is normal, check whether	
		the AC and DC cables are well insulated.	
		Contact Sungrow Customer Service if the pre- ceding causes are ruled out and the fault persists.	
13		Generally, the inverter will be reconnected to the grid after the grid returns to normal. If the fault occurs repeatedly:	
	Grid Abnormal	Measure the actual grid, and contact the local electric power company for solutions if the grid parameter exceeds the set range.	
		2. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.	



Fault code	Fault name	Corrective measures
Tault Coue	i auit iidille	Generally, the inverter will be reconnected to the
		grid after the grid returns to normal. If the fault oc-
		curs repeatedly:
		Measure the actual grid voltage. If grid phase
		voltages differ greatly, contact the electric power
	Grid Voltage	company for solutions.
17	Imbalance	2. If the voltage difference between phases is
		within the permissible range of the local power
		company, modify the grid voltage imbalance pa-
		rameter through the App or the LCD.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		1. Check whether the corresponding string is of
		reverse polarity. If so, disconnect the DC switch
		and adjust the polarity when the string current
		drops below 0.5 A.
28, 29, 208,	PV Reserve Con-	2. Contact Sungrow Customer Service if the pre-
212, 448-479	nection Fault	ceding causes are ruled out and the fault persists.
		*The code 28 to code 29 are corresponding to
		PV1 to PV2 respectively.
		*The code 448 to code 479 are corresponding to
		string 1 to string 32 respectively.
		Check whether the corresponding string is of
		reverse polarity. If so, disconnect the DC switch
		and adjust the polarity when the string current
		drops below 0.5 A.
532-547, 564-	PV Reverse Con-	2. Contact Sungrow Customer Service if the pre-
579	nection Alarm	ceding causes are ruled out and the alarm
		persists.
		*The code 532 to code 547 are corresponding to string 1 to string 16 respectively.
		*The code 564 to code 579 are corresponding to
		string 17 to string 32 respectively.



Fault code	Fault name	Corrective measures	
		Check whether the voltage and current of the in-	
		verter is abnormal to determine the cause of the alarm.	
		1. Check whether the corresponding module is	
		sheltered. If so, remove the shelter and ensure module cleanness.	
		2. Check whether the battery board wiring is	
		loose, if so, make it reliably connected.	
548-563, 580- 595	PV Abnormal Alarm	3. Check if the DC fuse is damaged. If so, replace the fuse.	
		Contact Sungrow Customer Service if the preceding causes are ruled out and the alarm persists.	
		*The code 548 to code 563 are corresponding to	
		string 1 to string 16 respectively.	
		*The code 580 to code 595 are corresponding to	
		string 17 to string 32 respectively.	
		Generally, the inverter will resume operation	
	Excessively High Ambient Temperature	when the internal or module temperature returns	
		to normal. If the fault persists:	
		 Check whether the ambient temperature of the inverter is too high; 	
		Check whether the inverter is in a well-ventilated place;	
37		 Check whether the inverter is exposed to di- rect sunlight. Shield it if so; 	
		4. Check whether the fan is running properly. Re-	
		place the fan if not;	
		5. Contact Sungrow Power Customer Service if	
		the fault is due to other causes and the fault	
		persists.	
	Excessively Low	Stop and disconnect the inverter. Restart the in-	
43	Ambient	verter when the ambient temperature rises within	
	Temperature	the operation temperature range.	



Fault code	Fault name	Corrective measures
		Wait for the inverter to return to normal. If the
		fault occurs repeatedly:
		Check whether the ISO resistance protection value is excessively high via the app or the LCD, and ensure that it complies with the local regulations.
		2. Check the resistance to ground of the string and DC cable. Take corrective measures in case of short circuit or damaged insulation layer.
39	Low System Insulation Resistance	3. If the cable is normal and the fault occurs on rainy days, check it again when the weather turns fine.
		4. If there are batteries, check whether battery cables are damaged and whether terminals are loose or in poor contact. If so, replace the damaged cable and secure terminals to ensure a reliable connection.
		5. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.
		Check whether the AC cable is correctly connected.
106	Grounding Cable Fault	Check whether the insulation between the ground cable and the live wire is normal.
		3. Contact Sungrow Customer Service if the preceding causes are ruled out and the fault persists.
88	Electric Arc Fault	1. Disconnect the DC power supply, and check whether any DC cable is damaged, the connection terminal or fuse is loose or there is a weak contact. If so, replace the damaged cable, fasten the terminal or fuse, and replace the burnt component. 2. After performing step 1, reconnect the DC power supply, and clear the electric arc fault via the App or the LCD, after that the inverter will return to normal.
		Contact Sungrow Customer Service if the fault persists.



Fault code	Fault name	Corrective measures
		Check if the meter is wrongly connected.
	Reverse Connec-	2. Check if the input and output wiring of the me-
84	tion Alarm of the	ter is reversed.
	Meter/CT	3. If the existing system is enabled, please check
		if the rated power setting of the existing inverter
		is correct.
		Check whether the communication cable and the terminals are abnormal. If so, correct them to
		ensure reliable connection.
	Meter Communi-	2. Reconnect the communication cable of the
514	cation Abnormal	meter.
	Alarm	3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the alarm
		persists.
	Grid Confrontation	1. Check whether the output port is connected to
323		actual grid. Disconnect it from the grid if so.
323		2. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		1. Check whether the communication cable and
		the terminals are abnormal. If so, correct them to
	Inverter Parallel	ensure reliable connection.
75	Communication Alarm	2. Reconnect the communication cable of the
7.5		meter.
		3. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the alarm
		persists.



Fault code	Fault name	Corrective measures
7, 11, 16, 19–		
25, 30–34, 36,		
38, 40–42, 44–		
50, 52–58, 60–		
69, 85, 87, 92,		Wait for the inverter to return to normal.
93, 100–105,		2. Disconnect the AC and DC switches, and dis-
107–114, 116–		connect the battery side switches if there are bat-
124, 200–211,	System Fault	teries. Close the AC and DC switches in turn 15
248–255, 300–	Cystem r duit	minutes later and restart the system.
322, 324–328,		
401–412, 600–		3. Contact Sungrow Customer Service if the pre-
603, 605, 608,		ceding causes are ruled out and the fault persists.
612, 616, 620,		
622–624, 800,		
802, 804, 807,		
1096–1122		
59, 70–74, 76–		1. The inverter can continue running.
83, 89, 216–		2. Check whether the related wiring and terminal
218, 220–233,		are abnormal, check whether there are any for-
432–434, 500–	System Alarm	eign materials or other environmental abnormal-
513, 515–518,	Cystem / tam	ities, and take corresponding corrective
635–638, 900,		measures when necessary.
901, 910, 911,		3. If the fault persists, please contact Sungrow
996		Power Customer Service.
		1. Check whether the corresponding string is of
		reverse polarity. If so, disconnect the DC switch
		and adjust the polarity when the string current
	MPPT Reverse	drops below 0.5 A.
264-283	Connection	2. Contact Sungrow Customer Service if the pre-
		ceding causes are ruled out and the fault persists.
		*The code 264 to code 279 are corresponding to
		string 1 to string 20 respectively.



Fault code	Fault name	Corrective measures	
		1. The inverter can continue running.	
		2. Check whether the related wiring and termi-	
		nals are abnormal, check whether there are any	
332-363	Boost Capacitor	foreign materials or other environmental abnor-	
332-303	Overvoltage Alarm	malities, and take corresponding corrective	
		measures when necessary.	
		If the fault persists, please contact Sungrow	
,		Power Customer Service.	
		1. Disconnect the AC and DC switches, and dis-	
		connect the battery side switches if there are bat-	
364-395	Boost Capacitor	teries. Close the AC and DC switches in turn 15	
304-395	Overvoltage Fault	minutes later and restart the system.	
		2. If the fault persists, please contact Sungrow	
		Power Customer Service.	
		1. Check whether the number of PV modules of	
		the corresponding string is less than other strings.	
		If so, disconnect the DC switch and adjust the PV	
		module configuration when the string current	
		drops below 0.5 A.	
1548-1579	String Current	2. Check whether the PV module is shaded;	
1548-1579	Reflux	3. Disconnect the DC switch to check whether	
		the open circuit voltage is normal when the string	
		current drops below 0.5 A. If so, check the wiring	
		and configuration of the PV module,	
		4. Check whether the orientation of the PV mod-	
		ule is abnormal.	



Fault code	Fault name	Corrective measures	
1600 - 1615, 1632 - 1655	PV Grounding Fault	 When the fault occurs, it is forbidden to directly disconnect the DC switch and unplug PV terminals when the direct current is greater than 0.5 A; Wait until the direct current of the inverter falls below 0.5 A, then disconnect the DC switch and unplug the faulty strings; Do not reinsert the faulty strings before the grounding fault is cleared; If the fault is not caused by the foregoing reasons and still exists, contact Sungrow Customer Service. 	
1616	System Hardware Fault	 It is prohibited to disconnect the DC switch when the DC current is greater than 0.5 A when the fault occurs. Disconnect the DC switch only when the inverter DC side current drops below 0.5 A. It is prohibited to power up the inverter again. Please contact Sungrow Customer Service. 	

9.2 Maintenance

9.2.1 Maintenance Notices

A DANGER

Risk of inverter damage or personal injury due to incorrect service!

- Be sure to use special insulation tools when perform high-voltage operations.
- Before any service work, first disconnect the grid-side AC circuit breaker and check the inverter status. If the inverter indicator is off, please wait until night to disconnect the DC switch. If the inverter indicator is on, directly disconnect the DC switch.
- After the inverter is powered off for 25 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter
- Even if the inverter is shut down, it may still be hot and cause burns. Wear protective gloves before operating the inverter after it cools down.

A CAUTION

To prevent misuse or accidents caused by unrelated personnel: Post prominent warning signs or demarcate safety warning areas around the inverter to prevent accidents caused by misuse.

NOTICE

Restart the inverter only after removing the fault that impairs safety performance. As the inverter contains no component parts that can be maintained, never open the enclosure, or replace any internal components.

To avoid the risk of electric shock, do not perform any other maintenance operations beyond this manual. If necessary, contact SUNGROW for maintenance. Otherwise, the losses caused is not covered by the warranty.

NOTICE

Touching the PCB or other static sensitive components may cause damage to the device.

- · Do not touch the circuit board unnecessarily.
- Observe the regulations to protect against electrostatic and wear an anti-static wrist strap.

9.2.2 Routine Maintenance

Item	Method	Period	
	Check the temperature and dust of	Six months to a year (de-	
	the inverter. Clean the inverter enclo-		
System aloon	sure if necessary.		
System clean	Check if the air inlet and outlet are	pend on the dust contents	
	in air.) normal. Clean the air inlet and outlet,		
	if necessary.		
	Check whether there is fan warning		
	using App.		
_	Check whether there is any abnormal	Once a year	
Fans	noise when the fan is turning.		
	Clean or replace the fans if necessary		
	(see the following section).		



Item	Method	Period
	Check whether the cable entry is in-	
Cable ontry	sufficiently sealed or the gap is exces-	0
Cable entry	Sively large, and reseal the entry	
	when necessary.	
	Check whether all cable are firmly	
Florence	connected in place.	
Electrical	Check whether a cable is damaged,	Six months to a year
Connection	especially the part contacting the met-	
	al enclosure.	

9.2.3 Cleaning Air Inlet and Outlet

A significant amount of heat is generated when the inverter is working.

In order to maintain good ventilation, please check to make sure the air inlet and outlet are not blocked.

Clean the air inlet and outlet with soft brush or vacuum cleaner if necessary.


9.2.4 Fan Maintenance

A DANGER


- Power off the inverter and disconnect it from all power supplies before maintaining fans.
- After the inverter is powered off for 25 minutes, measure the voltage and current with professional instrument. Only when there is no voltage nor current can operators who wear protective equipment operate and maintain the inverter.
- Fan maintenance must be performed by professionals.

Fans inside the inverter are used to cool the inverter during operation. If the fans do not operate normally, the inverter may not be cooled down and inverter efficiency may decrease. Therefore, it is necessary to clean dirty fans and replace the broken fans in a timely manner. The operation procedure is as follows:


- step 1 Stop the inverter (see "8.1 Disconnecting the Inverter").
- step 2 Loosen the screw on the sealing plate of the fan module.




step 3 Press the tab of the latch hook, unplug the cable connection joint outwards, and loosen the screw on the fan holder.



step 4 Loosen screws on the sides of fans.



step 5 Pull out the fans. Clean them with a soft brush or vacuum cleaner, and replace them when necessary.





If there is not enough space, pull out part of the fans and remove the screws between the two fans.

- - End

10 Appendix

10.1 Technical Data

Parameters	SG320HX	SG350HX
Input (DC)		_
Max. PV input voltage	1500 V	
Min. PV input voltage /	500.1/	1550.)/
Startup input voltage	500 V	/ 550 V
Nominal PV input voltage	108	80 V
MPP voltage range	500 V -	- 1500 V
No. of independent MPP inputs	12 (optional: 16)	12 (optional: 14/16)
Max. number of PV strings per MPPT		2
Max. PV input current per MPPT	40 A (optional: 30 A for 16 MPPT inputs)	-
Max. PV input current	_	12 * 40 A (Optional: 14 * 30 A / 16 * 30 A)
Max. DC short-circuit cur- rent per MPPT	60 A	
Output (AC)		
AC output power	352 kVA @ 30 °C / 320 kVA @ 40 °C / 295 kVA @ 50 °C	
Max. AC output current	25	64 A
Nominal AC voltage	3 / PE	, 800 V
AC voltage range	640 -	- 920V
Nominal grid frequency /	50 Hz / 45 – 55 Hz, 60 Hz /	50 Hz / 45 – 55 Hz, 60 Hz /
Grid frequency range	57 – 63 Hz	55 – 65 Hz
THD	< 3 % (at nominal power)	
DC current injection	< 0.5 % In	
Power factor at nominal		
power / Adjustable power	> 0.99 / 0.8 leading – 0.8 lagging	
factor		
Feed-in phases / Connec-		/3
tion phases	573	
Efficiency		

User Manual 10 Appendix

Parameters	SG320HX	SG350HX	
Max. efficiency / European			
efficiency/CEC efficiency	99.02 % / 98.8 %/-	99.02 % / 98.8 % / 98.5%	
Protection			
DC reverse connection	V		
protection	Yes		
AC short circuit protection	Yes		
Leakage current protection	Ye	es	
Grid monitoring	Ye	es	
Ground fault monitoring	Ye	es	
DC switch / AC switch	Yes	/ No	
PV string current monitoring	Ye	es	
Q at night function	Ye	es	
Anti-PID and PID recovery	Opti	onal	
function	Οριι	uliai	
Surge protection	DC Type II /	AC Type II	
General Data			
Dimensions (W*H*D)	1136*870*361 mm	1136*870*361 mm (44.7" *	
	1100 070 001 111111	34.3" * 14.2")	
Weight	≤116 kg	≤116 kg(≤255.7 lbs)	
Isolation method	Transfor	merless	
Degree of protection	IP66	IP66 (NEMA 4X)	
Power consumption at night	< 6	W	
Operating ambient temper-	-30 to 60 °C	-30 to 60°C(-22 to 140 °F)	
ature range	-50 to 00 '0		
Allowable relative humidity	0 – 1	00 %	
range	0 - 100 76		
Cooling method	Smart forced air cooling		
		4000 m (> 3000 m derating)	
Max. operating altitude	4000 m (> 3000 m derating)	/ 13123 ft (> 9843 ft	
		derating)	
Display	LED, Bluetooth+App		
Communication	RS485 / PLC		
	MC4-Evo2 (Max. 6 mm², optional 10mm²)	MC4-Evo2 (Max. 6 mm²,	
DC connection type		optional 10mm² /Max.	
		10AWG, optional 8AWG)	

10 Appendix User Manual

Parameters	SG320HX	SG350HX
AC connection type	Support OT/DT terminal	Support OT/DT terminal
AC connection type	(Max. 400 mm²)	(Max. 400 mm²/ 789 Kcmil)
	Q at night function, LVRT, HVRT,active & reactive power control and	Q at night function, LVRT,
Grid Support		HVRT,active & reactive
		power control and power
	power ramp rate control	ramp rate control, Q-U con-
		trol, P-f control

^{*:} Only compatible with Sungrow logger and iSolarCloud

10.2 Wring Distance of DI Dry Contact

The maximum wiring distance of DC dry contact must meet the requirements in the Table below. The wiring distance L is the total length of all DI signal cables.

$$L = 2\sum_{k=1}^{n} L_k$$

 L_K refers to the cable length in one direction between the DI dry contact terminal of the k^{th} inverter and the corresponding terminal of the $(k-1)^{th}$ inverter.

table 10-1 Correspondence between number of inverters and maximum wiring distance

Number of	Maximum wiring distance(unit:m)		
inverter	16AWG / 1.31mm ²	17AWG / 1.026mm ²	
1	13030	10552	
2	6515	5276	
3	4343	3517	
4	3258	2638	
5	2606	2110	
6	2172	1759	
7	1861	1507	
8	1629	1319	
9	1448	1172	
10	1303	1055	
11	1185	959	
12	1086	879	
13	1002	812	
14	931	754	

User Manual 10 Appendix

Number of	Maximum wiring distance(unit:m)		
inverter	16AWG / 1.31mm ²	17AWG / 1.026mm ²	
15	869	703	
16	814	660	
17	766	621	
18	724	586	
19	686	555	
20	652	528	
21	620	502	
22	592	480	
23	567	459	
24	543	440	
25	521	422	

NOTICE

In case the specification of the cable used is not included in the Table above, when there is only one inverter, ensure that the line impedance of the input node is less than 300Ω ; and when there are multiple inverters connected in the daisy chain, ensure that the impedance is less than $300\Omega/number$ of inverter.

10.3 Quality Assurance

When product faults occur during the warranty period, SUNGROW will provide free service or replace the product with a new one.

Evidence

During the warranty period, the customer shall provide the product purchase invoice and date. In addition, the trademark on the product shall be undamaged and legible. Otherwise, SUNGROW has the right to refuse to honor the quality guarantee.

Conditions

- After replacement, unqualified products shall be processed by SUNGROW.
- The customer shall give SUNGROW a reasonable period to repair the faulty device.

Exclusion of Liability

In the following circumstances, SUNGROW has the right to refuse to honor the quality guarantee:

• The free warranty period for the whole machine/components has expired.

10 Appendix User Manual

- The device is damaged during transport.
- The device is incorrectly installed, refitted, or used.
- The device operates in harsh conditions beyond those described in this manual.
- The fault or damage is caused by installation, repairs, modification, or disassembly performed by a service provider or personnel not from SUNGROW.
- The fault or damage is caused by the use of non-standard or non-SUNGROW components or software.
- The installation and use range are beyond stipulations of relevant international standards.
- The damage is caused by unexpected natural factors.

For faulty products in any of above cases, if the customer requests maintenance, paid maintenance service may be provided based on the judgment of SUNGROW.

10.4 Contact Information

In case of questions about this product, please contact us.

We need the following information to provide you the best assistance:

- · Model of the device
- · Serial number of the device
- Fault code/name
- · Brief description of the problem

For detailed contact information, please visit: https://en.sungrowpower.com/contactUS.

