


VIHALS



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






1




10077982

4x



151707

10x



151708

10x




10051660

10102154


10107001

16x




10093081

6x



10093082

6x




10005905

10099750

10106990

2x




10061178

10100254


10107020

6x




100092

1x




2




4x

150521
192164
10100431




4x

192157
192165
10100439




2x

192160
192168
10107466



2x

192159
192167
10107465




20x

192158
192166
10100430




4x

146114




4x

109535
116560




1x

100049



2x

192161
192169
10100429




2x

10078838
10099766
10106966





24



2x


157976
10100089
10108121



2x



157975
10100091
10108120






327495


1





2




3




4




5




6




7





8





9







10







11




12



13



14






www.IKEA.com/secure-it




www.IKEA.cn/secure-it



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")



1





2








3









↕
15







⇅
15





16










17
















20





21




22












25







26



27





16x