



Cool knight®

INSTRUCTION MANUAL



COOL KNIGHT Personal Blender

Model: TB10

Rated voltage: 120V 60HZ

Rated power: 500W



IMPORTANT SAFEGUARD:

Before using the electrical appliance, the following basic precaution should always be followed including the following.

1. Read all instructions first.
2. Before use, check that the voltage of your wall outlet correspond to the rated voltage manner.
3. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. If you find any damage, please stop using it and contact the company's customer service department in time. Do not disassemble and repair by yourself. So as not to affect product performance or accidents.
4. To protect against risk of electrical shock do not put in water or other liquid.
5. Do not let cord hang over edge of table or counter or touch hot surface.
6. To reduce the risk of electric shock, never operate this product with wet hands, spill liquid in the product or submerge it in water or any other liquid.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with or touch the appliance.
9. Pay more attention on the running appliance , never leave appliance unattended
10. Do not place an appliance on or near a hot gas or on a heated oven.

11. Do not use outdoors, household use only.
12. Never operate the product when the cup is empty and do not remove the cup lid before the blades come to a complete stop.
13. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
14. Avoid contacting moving parts
15. Warning: misuse may cause serious injury.
Care is needed when handling cutting blades, especially when removing the blade from the bottle, emptying the bottle and during cleaning.
16. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender.
17. DBlades are sharp. Handle carefully.
18. To reduce the risk of injury, never place cutter-assembly blades on base without jar properly attached.
19. Always operate blender with cover in place.
20. Always operate appliance on a flat surface.
21. Never use any attachments which are not listed on the instruction book .The use of attachments, including canning jars, etc, not recommended by the manufacturer may cause a risk of injury to persons
22. Do not blend hot liquids.

USAGE FOR 570ML SPORT BOTTLE



1.



2. Fixed



3. Together



4.

Blending



5. Closed



- ▶ 1. Fill the bottle with your favorite ingredients , all the ingredient must be filled below the bottle max level mark, and with liquid like water, milk.
- ▶ 2. Fasten the blade base on the open end of the bottle.
- ▶ 3. Turn the bottle upside down, put the bottle and blade base together on the blender base.
- ▶ 4. Turn the bottle clockwise and lock the bottle in the base, the machine will start to blending. Turn the bottle anticlockwise, the machine will stop.
- ▶ 5. Turn the bottle over and place on a flat surface, take out the blade base, put the drinking lid on.



Notes

1. The appliance is only permitted to use 60 s continuously maximum. Before it's used again, it must cool down enough.
2. Parts and unit are not dishwasher safe.
3. Do not use for ice crushing, if blend with ice, must come with liquid together
4. Only for liquid and soft fruits. Cut fruit first in pieces. Don't use dry grind purpose
5. When overload, motor will automatically stop, please unplug, empty cup, wait for 45 minutes to cool down motor, after can use again.



LEMON SQUEEZER

1. Open the sports water kettle.
2. Fixed the lemon squeezer to the open end of the bottle.
3. Squeeze lemons or oranges into a mixing cup.
4. Take off the lemon squeezer and covered the drinking lid.

1. Open



2. Fixed



3. Squeeze



4. Closed





COOLER ETICK

1. Open the sports water kettle
2. put the frozen finished Cooler Stick into the cup (When adding water to the cooling rod, Do not exceed the maximum liquid level mark)
3. covered the drinking lid.



CLEANING



1. Unplug the appliance from wall outlet before cleaning.
2. After use, clean the main body with wet towel and dry it with dry towel. Absolutely keep away from water or high humidity.
3. Wash the cup and blade part in running water.
4. Keep children away from the combined cup and blade.
5. Don't clean it with "thinner" or "benzene" etc.
6. Keep away from direct sunlight and damp place.
7. Never immerse the Base (Motor unit) or power cord into water for cleaning.