

Product Model

POW-HVM6_2KP



POWMr

HYBRID SOLAR INVERTER

User Manual

Table of Contents

1 About This Manual	1
1.1 Purpose	1
1.2 Scope	1
2 Safety Instructions.....	1
3 Introduction	3
3.1 Features.....	3
3.2 Basic System Architecture	4
3.3 Product Overview	5
4 INSTALLATION.....	7
4.1 Unpacking and Inspection	7
4.2 Preparation	7
4.3 Mounting the Unit	7
4.4 Battery Connection	9
4.5 AC Input/Output Connection.....	11
4.6 PV Connection	14
4.7 Final Assembly	15
5 OPERATION.....	16
5.1 Power ON/OFF.....	16
5.2 Operation and Display Panel	17
5.3 LCD Display Icons	18
5.4 LCD Setting	20
5.5 LCD Display	32
5.6 Operating Mode Description	36
5.7 Communication	39
5.8 Dry Contact Signal	39
5.9 Battery Equalization Description.....	40
5.10 Fault and alarm description.....	42
6 Technical datasheet.....	45
7 Trouble Shooting	47

8 Appendix I: Parallel function.....	49
8.1 Mounting the unit.....	49
8.2 Wiring Connection.....	49
8.3 PV Connection.....	61
8.4 LCD setting and display	62
8.5 Commissioning	64

1 About This Manual

1.1 Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations, Keep manual for future reference.

1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

2 Safety Instructions

WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
2. **CAUTION-** To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION-**Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals, please refer to INSTALLATION section of this manual for the details.

10. One piece of 150A fuse is provided as over-current protection for the battery supply.
11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounder wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

3 Introduction

This is a multi-function Inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

3.1 Features

- Pure sine wave inverter
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload/Over temperature/short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function
- The maximum number of parallel units is 9

3.2 Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.





Figure 1 Hybrid Power System

3.3 Product Overview

3.3.1 LCD Screen



1	LCD display	5	ESC
2	Status indicator	6	UP
3	Charging indicator	7	DOWN
4	Fault indicator	8	ENTER

3.3.2 Back Panel



Dual Output Back Panel



1	AC Input	8	Power ON/OFF Switch
2	AC Main&Second Output	9	PV Input
3	RS232 Communication Port	10	Input Breaker
4	BMS/RS485 Communication Port	11	Fan
5	Dry Contact	12	Battery Terminal Positive
6	Parallel Connection	13	Battery Terminal Negative
7	Battery Port		

4 INSTALLATION

4.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged.

You should have received the following items inside of package:

- The unit x 1
- Parallel communication cable x 1
- User manual x 1
- Share current wires x 1


4.2 Preparation

Before connecting all please take off bottom cover by removing four screws.

4.3 Mounting the Unit

Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- The ambient temperature should be between -10°C and 50°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.



SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing three screws.

- Use M6*80mm expansion bolts for suspending and securing the equipment from above.
- Use M4 or M5 screws to secure the equipment from below inside the terminal cover, as shown in the figure below.



4.4 Battery Connection

Recommended battery cable and terminal size:

Rated Capacity	Typical Amperage	Battery Capacity	Wire Size	Ring Terminal			Torque Value
				Cable(mm²)	Dimensions		
					D(mm)	L(mm)	
6.2KVA	124A	200Ah	1*2AWG	38	8.4	39.2	5 Nm
			2*4AWG	25	8.4	33.2	


CAUTION

- For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to over-current protection installed. Please refer to typical amperage in the above table as required fuse or breaker size.

WARNING


- All wiring must be performed by qualified personnel.
- It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size.

Ring terminal:



Please follow below steps to implement battery connection:

- Assemble battery ring terminal based on recommended battery cable and terminal size.



- Insert the battery wires flatly into battery connectors of inverter and make sure the bolts are tightened with torque of 2 Nm in clockwise direction. Make sure polarity at both the battery

and the inverter/charge is correctly connected and conductors are tightly screwed into the battery terminals.



WARNING: Shock Hazard

- Installation must be performed with care due to high battery voltage in series.

CAUTION

- Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

4.5 AC Input/Output Connection

Suggested cable requirement for AC wires

Rated Capacity	Gauge	Torque Value
6.2KW	10 AWG	1.4~1.6 Nm

CAUTION

- Before connecting to AC input power source, please Install a separate AC breaker between inverter and AC input power source. This will ensure the Inverter can be disconnected during maintenance and fully protected from over current of AC input. The recommended spec of breaker is 63A for 48V system.
- There are two terminal blocks with " IN " and " OUT " markings. Please do NOT mis-connect input and output connectors.

WARNING

- All wiring must be performed by qualified personnel.
- It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size.

Please follow below steps to implement AC input/ output connection:

1. Before making AC input/output connection be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and N conductor N3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⏏) first.

⏏→Ground(yellow-green); L→LINE(brown or black); N→Neutral (blue)



WARNING

- Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Insert AC main output wires according to polarities indicated on terminal block and tighten terminal screws.

L→LINE(brown or black); N→Neutral (blue)



5. Insert AC second output wires according to polarities indicated on terminal block and tighten terminal screws.

L→LINE(brown or black); N→Neutral (blue)



6. Make sure the wires are securely connected.

CAUTION

- Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/ charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

4.6 PV Connection

Rated Capacity	Typical Amperage	Gauge	Torque Value
6.2KW	30A	12 AWG	1.4~1.6 Nm

CAUTION

- Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

WARNING

- All wiring must be performed by a qualified personnel.
- It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size.

PV module selection:

When choosing the right PV module, be sure to first consider the following requirements:

The open circuit voltage (Voc) of the PV modules does not exceed the maximum PV array open circuit voltage of the inverter. The maximum supply voltage of the PV modules should be close to the optimal PV access voltage range of the inverter for best performance. If one PV module cannot meet this requirement, it is necessary to connect multiple PV modules in series.

Model	6.2KVA
PV Charging Mode	MPPT
MAX.PV Input Power	8500W
MPPT Tracking Range	60~500Vdc
Operating voltage	360~430V
MAX.PV Input Voltage	500Vdc
PV max input current	27A
MAX.PV Charging Current	120A
MAX.AC Charging Current	100A
MAX. Charging Current	120A

PV Module Wire Connection

Please follow below steps to implement PV modules connection:

- Step 1. Removing insulation sleeve 10 mm for positive and negative conductors
- Step 2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.
- Step 3. Insert PV input wires according to polarities indicated on terminal block and tighten the terminal screws.
- Step 4. Check correct polarity of wire from PV modules and PV input connectors. Then, connect positive pole (+) of connection wire to positive pole (+) of PV input connector. Connect negative pole (-) of connection wire to negative pole (-) of PV input connector.



4.7 Final Assembly

After connecting all wirings, please install bottom cover back by screwing four screws.

5 OPERATION

5.1 Power ON/OFF



Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the button of the case) to turn on the unit.

5.1.1 Steps to start up

Connect the battery that meets the requirements (battery voltage needs to be beyond 46V) or AC (AC needs to confirm the suitable input range depends on the output mode), then you can start up the inverter.

➤ Mains power on

Connect to normal AC power, press the switch, the system will automatically turn on. If you set AC output power priority, after waiting for a period of time, the panel will display AC mode that represents turn on the machine successfully, then will enter the AC mode.

➤ Battery boot

Connect to battery, press the power-on button to establish a working power source.


The system will automatically turn on, after waiting for a period of time, the panel will display battery mode that represents turn on the machine successfully, then will enter the battery mode.

5.1.2 Shutdown steps

When the system is in battery mode or AC mode output, press the switch again, then the system will be turned off.

5.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.




➤ Function Keys

Function Key	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

➤ LED Indicator

LED Indicator			Messages
	Green	Solid On	Output is powered by utility in Line mode.
		Flashing	Output is powered by battery or PV in battery mode.
	Yellow	Solid On	Battery is fully charged.
		Flashing	Battery is charging.
	Red	Solid On	Fault occurs in the inverter.
		Flashing	Warning condition occurs in the inverter.

5.3 LCD Display Icons



Icon	Function
Input source information	
	Indicates the AC input
	Indicates the PV panel input
Left digital display information	
	Indicate input voltage, input frequency, battery voltage, PV voltage, charger current.
Middle digital display information	
	Indicates the setting programs.
	Indicates the warning and fault codes.
	Warning: Flashing with warning code
	Fault: display with fault code
Right digital display information	
	Indicate the output voltage, output frequency, load percent, load VA, load W, PV charger power, DC discharging current.
Battery information	
	Indicates battery level by 0-24%, 25-49%, 50-74%, 75-100% and charging status.



AGM FLD USER	Indicates the battery type: AGM, Flooded or User-defined battery.			
Load information				
OVERLOAD	Indicates overload.			
 100% 25%	Indicates the load level by 0~24%, 25~50%, 50~74% and 75%~100%.			
	0~25%	25%~50%	50%~75%	75%~100%
				
Mode operation information				
	Indicates unit connects to the mains.			
PV1 	Indicates unit connects to the PV panel.			
	Indicates the solar charger is working.			
	Indicates the DC/AC inverter circuit is working.			
Mute operation				
	Indicates unit alarm is disabled.			



5.4 LCD Setting



After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or "ESC" button exit.


Setting Programs:



NO.	Description	Selectable option	
00	Exit setting mode	Escape 	
01	Output source priority selection	SUB priority(default) 	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, Utility energy will supply power to the loads at the same time.
		SBU priority 	Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12 or solar and battery is not sufficient.
02	Maximum charging current: To configure total charging current for solar and utility chargers.	60A(default) 	Setting range is from 10A to maximum charging current. Increment of each click is 10A.



	(Max. charging current = utility charging current + solar charging current)		
03	AC input voltage range	Appliances (default) 	If selected, acceptable AC input voltage range will be within 90- 280VAC.
		UPS 	If selected, acceptable AC input voltage range will be within 170-280VAC.
05	Battery type	AGM(default) 	Flooded 
		User-Defined 	If "User-Defined" is selected, battery charge voltage, low DC cut-off voltage and dual cut-off voltage can be set up in program 24, 26, 27, 29 and 61.
		LIA-protocol compatible battery 	If selected, program of 24, 26, 27 and 29 will be automatically set up. No need for further setting.
		Pylontech battery 	
		Techfine battery 	
		Growatt battery 	

		LIB-protocol compatible battery 	Select "LIB" if using Lithium battery compatible to Lib protocol. If selected, programs of 26,27 and 29 will be automatically set up. NO need for further setting.
		3 rd party lithium battery 	If selected, programs of 26,27 and 29 will be automatically set up. NO need for further setting. Please contact the battery supplier for installation procedure.
06	Auto restart when overload occurs	Restart disable(default) 	Restart enable 
07	Auto restart when over temperature occurs	Restart disable (default) 	Restart enable 
08	ECO function: System will temporarily stop when the load is low in battery mode.	Disable(default) 	
		Enable 	
09	Output frequency	50Hz(default) 	60Hz 
10	Output voltage	220V 	230V(default) 
		240V 	




11	Maximum utility charging current Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging current from program 02 for utility charger.	30A(default) 	Setting range is 2A, then from 10A to max.AC charging current. Increment of each click is 10A.
12	Setting voltage point back to utility source when selecting "SBU priority" in program 01	46V(default) 	Setting range is from 44V to 51 V. Increment of each click is 1V.
13	Setting voltage point back to battery mode when selecting "SBU priority" in program 01.	Battery fully charged 	54V(default)  Setting range is from 48V to 58V. Increment of each click is 1V.
16	Charger source priority: To configure charger source priority.	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar first 	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
		Solar and Utility(default) 	Solar energy and utility will charge battery at the same time.
		Only Solar 	Solar energy will be the only charger source no matter utility is available or not.
		If this inverter/charger is working in Battery mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	

18	Alarm control	Alarm on (default) 	Alarm off 
19	Auto return to default display screen	Return to default display screen (default) 	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage / output voltage) after no button is pressed for 1 minute.
		Stay at latest screen 	If selected, the display screen will stay at latest screen user finally switches.
20	Backlight control	Backlight on (default) 	Backlight off 
22	Beeps while primary source is interrupted	Alarm on (default) 	Alarm off 
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) 	Bypass enable 
24	Battery low voltage ● If battery power is only power source available inverter will alarm	Battery low voltage 44.0V 	
		Setting range is from 40.0V-54.0V for 48V system	
25	Record Fault code	Record enable (default) 	Record disable 

26	Bulk charging voltage (C.V voltage)	48V system default setting:56.4V 	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 60.0V for 48V system model. Increment of each click is 0.1V.	
27	Floating charging voltage	48V system default setting:54.0V 	
28	Reset factory setting	Turn off(default) 	
		Turn on 	
29	Low DC cut-off voltage: ● If battery power is only power source available inverter will shut down. ● If PV energy and battery power are available, inverter will charge battery without AC output.	48V system default setting:42.0V 	
		If self-defined is selected in program 5, this program can be set up. Setting range is from 40.0V to 52.0V for 48V system model. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.	
30	Battery equalization	Battery equalization 	Battery equalization disable (default) 
		If "Flooded" or "User Defined" is selected in program 05, this program can be set up.	

31	Battery equalization voltage	48V system default setting:58.4V 	
		Setting range is from 48.0V to 60.0 V for 48V system model. Increment of each click is 0.1V.	
33	Battery equalized time	60min (default) 	Setting range is from 5min to 900min. Increment of each click is 5min.
34	Battery equalized timeout	120min (default) 	Setting range is from 5min to 900min. Increment of each click is 5min.
35	Equalization interval	30days (default) 	Setting range is from 0 to 90 days. Increment of each click is 1 day.
36	Equalization activated immediately	Enable 	Disable(default) 
		If equalization function is enabled in program 30, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows "E9", If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 35 setting. At this time, "E9" will not be shown in LCD main page.	
37	BMS Function Switch	Off(default) 	Whether to enable the BMS communication function
		On 	
38	Bat Soc Under Lock	10%(default) 	If any type of lithium battery is selected in program 5.

			BMS low voltage SOC value, if the BMS SOC value is lower than the set value, the inverter will shut down to protect the battery.
39	Bat Soc Turn to AC	20%(default) 	If any type of lithium battery is selected in program 5. When the working mode of the inverter is set to the battery priority mode, the inverter will be forced to enter the mains charging when the SOC of the BMS is lower than the set value.
40	Bat Soc Turn to DC	95%(default) 	If any type of lithium battery is selected in program 5. When the working mode of the inverter is set to the battery priority mode, the inverter resumes the DC working mode when the SOC of the BMS is higher than the set value.
41	Bat Restart Soc	50%(default) 	If any type of lithium battery is selected in program 5. When the inverter is turned on, the SOC must be higher than the set value to work normally.
43	Solar supply priority	Default 	When solar energy is available, it will prioritize charging the battery. Excess solar power will then be used to power the loads.
			When solar energy is available, it will prioritize powering the loads. Excess solar power will then be used to charge the battery.

44	Solar energy feed to grid configuration	Disable(default) 	Solar energy feed to grid disable.
		Enable 	Solar energy feed to grid enable (Compliance with local regulations is required for grid connection.)
45	Reset PV energy storage	Not reset(default) 	Reset 
46	Start charging time for AC charger	00:00(default)  The setting range of start charging time for AC charger is from 00:00 to 23:00, increment of each click is 1 hour.	
47	Stop charging time for AC charger	00: 00(default)  The setting range of scheduled time for AC output off is from 00: 00 to 23:00, increment of each click is 1 hour.	
48	Scheduled time for AC output on	00: 00(default)  The setting range of scheduled time for AC output on is from 00: 00 to 23:00, increment of each click is 1 hour.	
49	Scheduled time for AC output off	00: 00(default)  The setting range of scheduled time for AC output off is from 00: 00 to 23:00, increment of each click is 1 hour.	
50	Set country customized regulations	Mode 1 	If selected, acceptable feed-in grid voltage range will be 195.5~253VAC. Acceptable

			feed-in grid frequency range will be 49~51 Hz.
		Mode 2 	If selected, acceptable feed-in grid voltage range will be 184~264.5VAC. Acceptable feed-in grid frequency range will be 47.5~51.5Hz.
		Mode 3 	If selected, acceptable feed-in grid voltage range will be 184~264.5VAC. Acceptable feed-in grid frequency range will be 57~62Hz.
		Mode 4(default) 	If selected, acceptable feed-in grid voltage range will be 170~264.5VAC. Acceptable feed-in grid frequency range will be 47.5~51.5Hz.
51	Time setting-Minute		For minute setting, the range is from 00 to 59.
52	Time setting-Hour		For hour setting, the range is from 00 to 23.
53	Time setting-Day		For day setting, the range is from 00 to 31.
54	Time setting-Month		For month setting, the range is from 1 to 12.
55	Time setting-Year		For year setting, the range is from 16 to 99.





56	GRID-tie current	10A 56 10	Increment of each click is 1A.
60	Dual output	Disable(default) 60 L2F	Use 60 L20
61	Enter the dual output functional voltage point	Default setting: 44.0V 61 44.0	If battery voltage lower than inverter setting, second output will be cutted off, Increment of each click is 0.1V.
62	Enter the dual output functional SOC point	62 52 15	If any type of lithium battery is selected in program 5. If BMS capacity lower than SOC setting, second output will be cutted off.
63	Dual battery voltage receiver	63 52 520	Default 52V, if the battery voltage is higher than the inverter setting, the dual will be restored.
64	Dual battery SOC Receiver	64 54 95	If any type of lithium battery is selected in program 5. Default 50%, if the BMS capacity is higher than the SOC setting, the second output will be restored.
65	Setting discharge time on the second output	Disable(default) 65 55 55	Setting range is disable and then from 0 min to 990 min. Increment of each click is 5 min. *If the battery discharge time achieves the setting point in program 61 and the program 60 function is not triggered, the output will be turned off.





66	Dual Recover Delay Time		The value ranges from 0-60min.
67	Output Open Time		The value ranges from 0 to 23.
68	Output Stop Time		The value ranges from 0 to 23.





5.5 LCD Display

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, charging current, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DC discharging current, main board firmware version and SCC firmware version.




Select item	LCD display
Input voltage and output voltage (Default Display Screen)	Input voltage=230V, Output voltage=230V
Input frequency and output frequency	Input frequency=50.0Hz, output frequency=50.0Hz
Battery voltage and output voltage	Battery voltage=48.0V, output voltage=230V

Battery voltage and load percentage	Battery voltage=48.0V, load percentage=68% 
Battery voltage and load in VA	Battery Voltage=48.0V, load in VA=1.08kVA 
Battery voltage and load in Watt	Battery Voltage=48.0V, load in Watt=1.88kW 
PV1 voltage and PV1 charger power	PV1 voltage=360V, charger power=1.58kW 






Charger current and DC discharging current	Charging current=30A, discharging current=0A 
PV energy generated today	Today energy=6.3kWh 
PV energy generated this month	This month energy=358kWh 
PV energy generated this year	This year energy=8.32MWh 

PV energy generated totally	Total energy=13.9MWh 
Real date	Real date Nov 28, 2016 
Real time	Real time 13:20 
Main board firmware version	Version 00001.00 

5.6 Operating Mode Description

Operating mode	Description	LCD display
Standby mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output power, solar or utility charger available	Battery is charged by utility. 
		Battery is charged by PV energy. 
		Battery is charged by utility and PV energy. 
		Battery is charged by PV energy and feed PV energy grid. 
		No charging 

Line mode	Output power from utility. Charger available	Utility charges battery and provides power to load.
		Utility and battery power provide power to load.
		PV energy, battery power and utility provide power to load.
		PV energy and utility charge battery, and utility provides power to load.
		PV energy charges battery, utility and PV energy provide power to the load.

		PV energy charges battery, PV energy provides power to the load and feeds remaining energy to the grid. 
Battery mode	Output power from battery or PV	PV energy and battery energy supply power to the load. 
		PV energy charges battery, PV energy supply power to the load. 
		Battery provides power to the load. 
Only PV mode	Output power from PV	PV provides power to the load. 

5.7 Communication

5.7.1 Communication Connection

Please use a dedicated RJ45-to-DB9 communication cable (to be purchased separately) to connect the inverter to the host computer. Install the monitoring software to enable remote viewing or modification of the inverter's operating program via the host computer.

5.7.2 BMS/RS485 communication

When the BMS/RS485 communication interface is externally connected, as shown in the following figure:



RJ45(Control board signal interface):

NO	SYMBOL	DESCRIPTION
1/7/8	NC	No Connected
2	+12V	+Power
3	RS232_TXD	RS232 Transmit Data
4/5	GND	Ground
6	RS232_RXD	RS232 Receive Data

5.8 Dry Contact Signal

There is one dry contact(3A/250VAC) available on the rear panel. It could be used to deliver signal to external device when battery voltage reaches warning level.

Unit Status	Condition			Dry contact port: 	
				NC & C	NC & C
Power Off	Unit is off and no output is powered.			Close	Open
Power On	Output is powered from battery or solar.	Normal mode	Battery voltage< Low DC warning voltage	Open	Close
			Battery voltage>Float charging voltage	Close	Open
		Solar first mode	Battery voltage< Solar to AC voltage	Open	Close
			Battery voltage> AC to DC voltage	Close	Open

5.9 Battery Equalization Description

Equalization function is added into charge controller, It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.


● How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:

1. Setting equalization interval in program 35.
2. Active equalization immediately in program 36.


● When to Equalize

In stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




● Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



5.10 Fault and alarm description

5.10.1 Faults Descriptions

- **Fault:** The inverter enters the fault mode, the red LED light is always on and the LCD displays the fault code.

Fault Reference Code

Fault Code	Fault Event	Icon
01	Fan is locked when inverter is off.	
02	Over temperature or NTC is not connected well.	
03	Battery voltage is too high.	
04	Battery voltage is too low.	
05	Output short circuited or over temperature is detected by internal converter components.	
06	Output voltage is too high.	
07	Overload time out.	
08	Bus voltage is too high	
09	Bus soft start failed	
51	Over currents or surge	
52	Bus voltage is too low	

53	Inverter soft start failed	
55	Over DC voltage in AC output	
57	Current sensor failed	
58	Output voltage is too low	
59	PV voltage is over limitation	

5.10.2 Warning Descriptions

➤ **Alarm:** The red LED flashes, and the LCD displays an alarm code, the inverter does not enter the failure mode

Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
02	Over temperature	None	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	
15	PV energy is low.	Beep twice every 3 seconds	

16	High AC input (>280VAC) during BUS soft start	None	
E9	Battery equalization	None	
bP	Battery is not connected	None	

5.10.3 Code Reference

Related information code will be displayed on LCD screen. Please check inverter LCD screen for the operation.

Code	Description
60 	If battery status is not allowed to charge and discharge after the communication between the inverter and battery is successful, it will show code 60 to stop charging and discharging battery.
61 	Communication lost - After battery is connected, communication signal is not detected for 1 minutes, buzzer will beep. - Communication lost occurs after the inverter and battery is connected successfully, buzzer beeps immediately.
69 	If battery status is not allowed to charge after the communication between the inverter and battery is successful, it will show code 69 to stop charging battery.
70 	If battery status must to charge after the communication between the inverter and battery is successful, it will show code 70 to charge battery.
71 	If battery status is not allowed to discharge after the communication between the inverter and battery is successful, it will show code 71 to stop discharge battery.

6 Technical datasheet

Model		6.2KVA
AC Input		
Input Sources		L+N+PE
Rated Input Voltage		220/230/240VAC
Voltage Range		90-280VAC $\pm$ 3V(APL Mode) ; 170-280VAC $\pm$ 3V(UPS Mode)
Frequency		50Hz/60Hz(Auto Adaptive)
Inverter Output		
Rated power	The Battery Inverter	6200W
	Photovoltaic Inverter	6500W
Output Voltage		220/230/240VAC $\pm$ 5%
Output Frequency		50Hz/60Hz $\pm$ 0.1%
Waveform		Pure Sine Wave
Transfer Time (Adjustable)		Computers(UPS Mode)10ms, Appliance(APL Mode)20ms
Peak Power		12400VA
Overload Capacity		Battery mode: 11s@105%~150%Load; 2s@150%~200%Load; 400ms@>200%Load
Grid-Connected Operation		
Output Voltage		220/230/240VAC $\pm$ 5%
Feed Into the Grid Voltage Range		170-265VA
Feed Into the Grid Frequency Range		49-51 $\pm$ 1Hz/59-61 $\pm$ 1Hz
Nominal Output Current		26.9A
Power Factor Range		>0.99
Maximum Conversion Efficiency (DC/AC)		98%
Battery		
Battery Voltage		48Vdc

Constant Charging Voltage (Adjustable)	56.4Vdc
Float Charging Voltage (Adjustable)	54Vdc
PV Input	
PV Charging Mode	MPPT
MAX. PV Input Power	8500W
MPPT Tracking Range	60~500Vdc
Operating Voltage	360~430V
MAX. PV Input Voltage	500Vdc
PV Max Input Current	27A
MAX. PV Charging Current	120A
MAX. AC Charging Current	100A
MAX. Charging Current	120A
Display	
LCD Interface	CAN display running mode/load/input/output, etc.
Interface	
RS232	Baud Rate 2400
Extend the Socket Communication Interface	Lithium Battery BMS Communication Card, WiFi Card, Dry Contact
Parallel Machine Interface	Parallel Machine(network) function
General Specifications	
Operating Temperature	-10°C~50°C
Humidity	20%~95%(Non-condensing)
Storage Temperature	-15°C~60°C
Altitude	Altitude Not Over 1000m, Derating over 1000m, Max 4000m, Refer to IEC62040
Noise	≤50db
Standards and Certification	EN-IEC 60335-1, EN IEC 60335-2-29, IEC 62109-1

7 Trouble Shooting


Problem	LCD/LED/Buzzer	Explanation/Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 seconds and then complete off.	The battery voltage is too low (<1.91 V/Cell)	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication	1. The battery voltage is far too low. (<1.4V/Cell) 2. Internal fuse tripped.	1. Contact repair center for replacing the fuse. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	Green LED is flashing	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct(UPS→Appliance)
	Green LED is flashing	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.
Buzzer beeps continuously and red LED is on.	Fault code 07	Overload error. The inverter is overload 105% and time is up.	Reduce the connected load by switching off some equipment.

		If PV input voltage is higher than specification, the output power will be derated. At this time, if connected loads is higher than derated output power, it will cause overload.	Reduce the number of PV modules in series or the connected load.
Fault code 05		Output short circuited.	Check if wiring is connected well and remove abnormal load.
		Temperature internal converter component is over 120°C.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
Fault code 02		Internal temperature of inverter component is over 100°C	
Fault code 03		Battery is over-charged	Return to repair center.
		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.
Fault code 01		Fan fault	Replace the fan.
Fault code 06/58		Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	1. Reduce the connected load. 2. Return to repair center
Fault code 08/09/53/57		Internal components failed.	Return to repair center.
Fault code 51		Over current or surge.	Restart the unit, if the error happens again, please return to repair center.
Fault code 52		Bus voltage is too low.	
Fault code 55		Output voltage is unbalanced.	
Fault code 59		PV input voltage is beyond these specification.	Reduce the number of PV modules in series.

8 Appendix I: Parallel function

8.1 Mounting the unit

When installing multiple units, please follow below chart.



NOTE: For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit, Be sure to install each unit in the same level.

8.2 Wiring Connection

NOTICE: It's requested to connect to battery for parallel operation.

The cable size of each inverter is shown as below:

Recommended battery cable and terminal:

Ring terminal:



Rated Capacity	Wire Size	Ring Terminal			Torque Value
		Cable (mm ²)	Dimensions		
			D(mm)	L(mm)	
6.2KW	1*2AWG	38	8.4	39.2	2-3Nm

WARNING

- Be sure the length of all battery cables is the same. Otherwise, there will be voltage difference between inverter and battery to cause parallel inverters not working.

Recommended AC input and output cable size for each inverter:

Rated Capacity	AWG no.	Torque
6.2KW	10AWG	1.2~1.6Nm

You need to connect the cables of each inverter together. Take the battery cables for example: You need to use a connector or bus-bar as a joint to connect the battery cables together, and then connect to the battery terminal. The cable size used from joint to battery should be X times cable size in the tables above. "X" indicates the number of inverters connected in parallel.

Regarding AC input and output, please also follow the same principle.

WARNING

- Make sure all output N wires of each inverter must be connected all the time. Otherwise, it will cause inverter fault in error code #72.

CAUTION

- Please install the breaker at the battery and AC input side. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of battery or AC input.

Recommended breaker specification of battery for each inverter:

Rated Capacity	1 unit*
6.2KW	150A/70VDC

*If you want to use only one breaker at the battery side for the whole system, the rating of the breaker should be X times current of 1 unit. "X" indicates the number of inverters connected in parallel.

Recommended breaker specification of AC input with single phase:

Rated Capacity	2 units	3 units	4 units	5 units	6 units	7 units	8 units	9 units
6.2KW	80A/ 230VAC	120A/ 230VAC	160A/ 230VAC	200A/ 230VAC	240A/ 230VAC	280A/ 230VAC	320A/ 230VAC	360A/ 230VAC

Note 1: Also, a circuit breaker should be installed at the AC input of each inverter, and the selection of the circuit breaker should refer to the AC input current of the machine nameplate.

Note2: Regarding three-phase system, you can use 4-pole breaker directly and the rating of the breaker should be compatible with the phase current limitation from the phase with maximum units.

Recommended battery capacity

Inverter parallel numbers	2	3	4	5	6	7	8	9
Battery Capacity for 6.2KW	400AH	600AH	800AH	1000AH	1200AH	1400AH	1600AH	1800AH


WARNING

- Be sure that all inverters will share the same battery bank. Otherwise, the inverters will transfer to fault mode.

8.2.1 Parallel operation in single phase

Two inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection




Three inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)



Communication Connection



Four inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Five inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




Six inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)



Communication Connection



Seven inverters in parallel:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)



Communication Connection

➤ Seven inverters in parallel



➤ Eight inverters in parallel



➤ Night inverters in parallel




8.2.2 Support 3-phase equipment


WARNING: Do not connect the current sharing cable between the inverters which are in different phases. Otherwise, it may damage the inverters.

One inverter in each phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Two inverters in one phase and only one inverter for the remaining phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Two inverters in two phase and only one inverter for the remaining phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection




Three inverters in one phase and only one inverter for the remaining two phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Two inverters in each phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Three inverters in one phase, two inverters in second phase and one inverters for the third phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Four inverters in one phase and one inverter for the other two phases:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Three inverters in one phase, two inverters in second phase and two inverters for the third phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Three inverters in one phase, three inverters in second phase and two inverters for the third phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)




Communication Connection



Three inverters in each phase:

Power Connection (Each photovoltaic panel needs to be connected to an independent system)



Communication Connection




8.3 PV Connection

Note

- Each inverter should be connected to an independent photovoltaic array. Multiple inverters must not share the same photovoltaic array, as this may cause irreversible damage to the inverters.

Please refer to the schematic diagram below and combine it with the photovoltaic wiring guidelines in the wiring section to complete the connection of the photovoltaic array in parallel operation mode.



8.4 LCD setting and display

Setting Program:

Program	Description	Selectable option	
04	AC output mode *This setting is only available when the inverter is in standby mode (Switch off)	Single: 	When the units are used in parallel with single phase, please select "PAL" in program 4.
		Parallel: 	It is required to have at least 3 inverters or maximum 9 inverters to support three-phase equipment. It's required to have at least one inverter in each phase or it's up to four inverters in one phase please-2 for detailed information. Please select
		L1 phase: 	"3P1 " in program 4 for the inverters connected to phase, "3P2" in program 4 for the inverters connected to L2 phase and "3P3" in program 4 for the inverters connected to L3 phase.
		L2 phase: 	Be sure to connect share current cable to units which are on the same phase. Do NOT connect share current cable between units on different phases. Besides, power saving function will be automatically disabled.
		L3 phase: 	

Fault code display

Fault Code	Fault Event	Icon on
60	Power feedback protection	
71	Firmware version inconsistent	
72	Current sharing fault	
80	CAN fault	
81	Host loss	
82	Synchronization loss	
83	Battery voltage detected different	
84	AC input voltage and frequency detected different	
85	AC output current unbalance	
86	AC output mode setting is different	

8.5 Commissioning

Parallel in single phase

Step 1: Check the following requirements before commissioning:

- Correct wire connection
- Ensure all breakers in Line wires of load side are open each Neutral wires of each unit are connected together.

Step 2: Turn on each unit and set "PAL" in LCD setting program 4 of each unit. And then shut down all units.

NOET: It's necessary to turn off switch when setting LCD program. Otherwise, the setting can not be programmed.

Step 3: Turn on each unit.

LCD display in Master unit	LCD display in Slave unit
	

NOTE: Master and slave units are randomly defined.

POWMr

SHENZHEN HEHEJIN INDUSTRIAL CO.,LTD

Tel/Fax: +86 755-28219903

Email: support@powmr.com

Web: www.powmr.com

Add: Henggang Street, Longgang District, Shenzhen, Guangdong, China