
PELONIS

OWNER'S MANUAL

18" Stand Fan MODEL:FS45-19M



READ AND SAVE THESE INSTRUCTIONS

Attention: Pictures in the IM are for reference only.



IMPORTANT SATETY INSTRUCTIONS

CAUTION

Read Rules for Safe Operation and Instructions Carefully.

WARNING

- 1. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- 2. WARNING To reduce the risk of fire or electric shock, Do not use this fan with any solid-state speed control device.
- 3. Do not leave the fan running unattended.
- Keep electrical appliances out of reach from Children or infirm persons. Do not let them use the appliances without supervision.
- 5. If the supply cord is damaged, it must be replaced by manufacturer or its serviceagent or a similarly qualified person in order to avoid a hazard.
- 6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety Young children should be supervised to ensure that they do not play with the appliance.


- 7. When the fan was assembled, the rotor blade guard shall not be taken off anymore
 - Prior cleaning unplug the fan.
 - The rotor guard shall not be dissembled/opened to clean the rotor blades.
 - Wipe the fan enclosure and rotor blade guard with a slightly damp cloth.
- 8. This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
 - a) "Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair."
 - b) "Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over."

RULES FOR SAFE OPERATION

- 1. Never insert fingers, pencils, or any other object through the grille when fan is running.
- 2. Disconnect fan when moving from one location to another.
- 3. Be sure fan is on a stable surface when operating to avoid overturning.
- 4. DO NOT use fan in window, rain may create electrical hazard.
- 5. Household use only.

INSTALLATION INSTRUCTIONS


Name of components




Considerate Hint: Remove parts from the component before performing installation.


Front and Rear Guard Installation

1. Place the Front Guard upright, with the Positioning Clip aligned with the Rear Guard as illustrated.



2. Press down all the Buckles to fasten the Front Guard with the Rear Guard.






Lock nut of grill

 Screw the lock nut of grill clockwise, and in the meantime, fix the rear grill.


INSTRUCTIONS FOR USE

Instructions for operation of body



USER SERVICING INSTRUCTIONS

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
- c) Removefuse carefully. Insert the tip of your tool into fuse slot (close with theterminal), then prize the fuse gradually and slowly, but not overexert. If youfeel tight, you can try it at several times and prize the fuse little bylittle. When one side of the fuse has been prized, then you can get the fuseout entirely



- d) Risk of fire. Replace fuse only with 2.5 Amp, 125 Volt fuse.
- e) Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
- f) Risk of fire. Do notreplace attachment plug. Contains a safety device (fuse) that should not beremoved. Discard product if the attachment plug is damaged.

Notice:

- When you replace the fuse, please don't operate suddenly or overexert, or else the product will be damage or cause accident.
- 2. When you feel it hard to be operated, please make sure you have got the right way.

CLEANING

- 1. Be sure to unplug from the electrical supply source before cleaning.
- 2. Plastic parts should be cleaned with mild soap and a damp cloth or sponge.
 - Thoroughly to remove soap film with clean water.
- 3. Be sure not to make water or other liquid enter inside of motor.

SERVICE AND SUPPORT

In the event of a warranty claim or if service is required for this product, please contact us at the following:

Toll Free: 1-866-646-4332

For questions or comments, please write to:

Midea America Corporation Customer Care Center

5 Sylvan Way Parsippany, NJ 07054

DATE OF DUDCHASE.

For your records, staple your sales receipt to this manual and record the following:

Difficult of Torchitable	
PLACE OF PURCHASE:	

(STAPLE SALES RECEIPT HERE)

NOTE: PROOF OF PURCHASE IS REQUIRED FOR ALL WARRANTY CLAIMS

PRINTED IN CHINA

ONE (1) YEAR LIMITED WARRANTY

Please read all instructions before attempting to use this product.

Midea America Corporation warrants as limited herein to the original purchaser of retail thateach new Fan, shall be free of defects in material and workmanship for aperiod of one (1) year from the date of original purchase. This one (1) year warranty is limited to the Motor and Electric Element.

In the event of malfunctions or failure of your Fan, simply deliver or send the Fan, postage prepaid along with PROOF OF PURCHASE, within the warranty period of one (1) year, to Midea America Corporation. Midea America Corporation reserves the right to inspect the claimed defective part or parts to determine if the defect or malfunction complaint is covered by this warranty. Midea America Corporation shall, within sixty(60)days after receipt of the product, at its option, repair and/or replace the defective part or parts free of charge. This warranty shall only cover defect arising from normal usage. Midea America Corporation assumes no responsibility whatsoever if the Fan should fail during the warranty period by reason of:

- Misuse, negligence, physical damage or accidents.
- Lack of maintenance (see instructions for proper maintenance).
- Repair by any unauthorized party during the warranty period.
- Damage caused by connection to an improper input voltage (see specification label on your Fan).

Midea America Corporation makes no further warranties or representations, express or implied except those contained herein. No representative or dealer is authorized to assume any other liability regarding the Fan. The duration of the implied warranty granted under State law, including warranties of merchantability and fitness for particular purpose are limited in duration should the duration of the express warranty grant it hereunder. Midea America Corporation shall in no event be liable for direct, indirect, special or consequential damages.

Some states do not allow limitations on how long an implied warranty lasts, and/or the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.