






Index


Components diagram	3
Usage	
■ Reset	4
■ Raise / lower the surface	4
■ Setting memory positions	4
■ Lock / Unlock keypad	4
Error Codes	
■ Error Codes / Troubleshooting	5
Settings	
■ Setting buttons & menu overview	6
■ Units	6
■ Screen brightness	6
■ Sound («beep»)	6
■ Obstacle sensitivity sensor	7
■ Vibration sensitivity sensor	7
■ Customized height display / Minimum & maximum height range	8
■ Button push modes	8
■ Timer	9
■ Bounce travel	9
■ Factory settings	9
■ Demo mode	10
About the Warranty	10

Components Diagram

Two Columns



Three Columns



Technical Specifications

1. Power input	110-240VAC
2. Power output	24VDC
3. Load capacity	1400N (2 columns) / 1600N (3 columns)
4. Speed	30 mm/s
5. Stroke	546 mm
6. Min install dimension	600 mm
7. Operation temperature	0-40 degrees celcius
8. Duty cycle	Max.10% (or 2 minutes ON / 18 minutes OFF)

Reset and Memory Settings



■ Reset (Initialization)

Clear any obstructions below the surface. **Press and hold** the DOWN button on the keypad until the table **reaches its lowest height, stops, and rises slightly again**. The display will momentarily indicate "rES" and then indicate the actual height. The table has been reset and is now ready to use.

■ Procedure to raise or lower the work surface

After reset, press and hold the UP button, lifting column will rise, release to stop at the desired height.

After reset, press and hold the DOWN button, lifting column will lower, release to stop at the desired height.

■ Setting memory positions

Position the work surface using the UP/DOWN button to desired height, press **M** button first, then press button 1, 2, 3 or 4.



When setting the memory positions, ensure there is at least a 1" (25 mm) space left between the work surface and any obstacle (such as chair armrests).

To raise or lower the work surface to a programmed position, press one of the four previously programmed positions (1, 2, 3 or 4). The work surface will raise or lower to the programmed position.

■ Lock/Unlock Keypad

Lock: Press simultaneously the UP and DOWN buttons for 5 seconds; keypad will lock and **Loc** will be displayed (flashing).

Unlock: Keep pressing simultaneously the UP and DOWN buttons for 5 seconds, to unlock the keypad. Keypad will display current height

Error Codes / Troubleshooting

If the LCD Controller displays error codes when raising or lowering the work surface, a reset will be required.

E01, E02, E03, E04 - Motor error

Control box can not detect motor halt plate signal or Control box detects one lifting column is overloaded. This is a safety protection.

Please remove any large loads from the work surface and reset the controller. If the error code still appears, make sure the Patch Cord (see Componentd Diagram, page 3) is properly connected (unplug and reconnect the wire) and perform the reset procedure again. If the error code is still there, please contact our customer service department for technical assistance.

HOT - Control box temperature protection

This indicates that the control box temperature is above 75° celcius or the system has been in continuous use for 2 minutes or more. The lifting columns are locked out for up to 18 minutes as a safety precaution (to lower the system's temperature). For an urgent reset, unplug & replug the power cord.

E06 - Asynchronous protection

Lifting columns are at different heights, more than 10mm, reset required.

E07 - Overload protection

Desk load in excess of 113 kg, user needs to reduce load, then wait for 3 seconds (the Reset procedure can also be done).

E08 - Low voltage protection

Power voltage is too low for the controller. This is a safety cut out protection, system will recover as soon as voltage returns to normal.

E09 - High voltage protection

Power voltage is too high for the controller. This is a safety cut out protection, system will recover as soon as voltage returns to normal

E10 - Control Box or Keypad issue

If error code E10 appears and remains even after having done the Reset procedure, it is possible the Control Box or the Keypad is defective, please contact our customer service department.

Also check if the problem is due to a damaged **Patch Cord** by plugging both lifting column cables directly into the Control Box.

Settings

Setting buttons

"1" – Return to previous menu

"UP/DOWN" arrows – Menu select

"M" – Confirm



Menu

- Units (1Un)
- Screen Brightness (2Br)
- Sound (3bE)
- Upward Sensitivity (4Fu)
- Downward Sensitivity (5Fd)
- Vibration Sensitivity (6FS)
- Lowest Height Display & Height Range (7SH)
- Button Push Modes (8Hc)
- Timer (9St)
- Bounce Travel (10H)
- Restore Factory Settings (11r)
- Demo Mode (12d)

Units: Metric (cm) or Imperial (inches) - 1Un

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **1Un** appears. Press «M» button to enter; screen will display **In** (inches) by default. Press "M" button to preserve imperial (inches) display or press the «Up/Down» button to switch to metric (cm) units so the screen displays **SI**. Press «M» button to preserve the metric (cm) display.

Screen Brightness - 2br

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **2br** appears. Press «M» button to enter. Using the UP/DOWN buttons, toggle between **l/n/h** (low, normal or high brightness) and press the «M» button to confirm selection.

Sound ("beep") - 3bE

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **3be** appears. Press «M» button to enter. Using the UP/DOWN buttons, toggle between **OFF/On** and press the «M» button to confirm selection.

Settings (cont'd)

Upward Obstacle Sensitivity - 4Fu

The upward sensor allows the surface to detect resistance (obstacles) as it moves upward.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **4Fu** appears. Press «M» button to enter. Default setting is **L3**, which is just under mid-level sensitivity. Use the UP/DOWN buttons to toggle between levels **L1** (most sensitive) to **L9** (least sensitive), **L0** deactivates the sensor (not recommended). Press the «M» button to confirm selection.

Downward Obstacle Sensitivity - 5Fd

The downward sensor allows the surface to detect resistance (obstacles) as it moves downward.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **5Fd** appears. Press «M» button to enter. Default setting is **L3**, which is just under mid-level sensitivity. Using the UP/DOWN buttons to toggle between levels **L1** (most sensitive) to **L9** (least sensitive), **L0** deactivates the sensor (not recommended). Press the «M» button to confirm selection.

Vibration Sensitivity - 6FS

The vibration sensor causes the table to stop moving if it detects, for example, that someone bumped it up during its travel or that there is a large weight off-center on the surface.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **6FS** appears. Press «M» button to enter. Default setting is **L5**, which represents mid-level sensitivity. Use the UP/DOWN buttons to toggle between levels **L1** (most sensitive) to **L9** (least sensitive) and press the «M» button to confirm selection.

Settings (cont'd)

Customized Height Display / Minimum & Maximum Height Range - 7SH

The HiB function allows you to customize the height of the surface displayed, for example, if the table is placed on an elevated base or has a surface thicker than 1".

*The "LiL" function allows you to define the **minimum** height that the surface can reach. The "LiH" function is used to define the **maximum** height that the surface can reach. These functions allow, for example, to limit the movement of the surface in order not to come into contact with an obstacle in place.*

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **7SH** appears. Press «M» button to enter. The screen will, by default, display **Hib**. To select the mode (Hib, LiL or LiH), use the up/down arrows and press M to select.

***HiB**: when selected, the screen will display the current height of the surface. Use the arrows to define the desired height (customized) to display and press M to confirm.

***LiL**: when selected, the screen will display the current minimum height of the surface. Use the arrows to define the new minimum height desired and press M to confirm.

***LiH**: when selected, the screen will show the current maximum height of the surface. Use the arrows to define the new maximum height desired and press M to confirm.

Button Push Modes - 8Hc

In mode «001», you need to continuously hold the UP/DOWN buttons to move the work surface. Mode «002» allows you to only press the UP/DOWN button once to move the work surface. Press any button to stop the motion in mode «002».

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **8Hc** appears. Press «M» button to enter; screen will display **001**. Use the UP/DOWN buttons to select mode and press the «M» button to confirm selection.

Settings (cont'd) & Warranty

Timer - 9St

The timer makes it possible to define the period of time for the same surface position. This is to stimulate the change from sitting to standing position.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, release the «M» button and press the «up» arrow until code **9St** appears. Press «M» button to enter; screen will display **0.0H** (hours.minutes). Press the UP/DOWN buttons to adjust timer with 0.5 H (30 minutes) increments, and press the «M» button to activate timer. Note: When the timer expires, the keypad will emit a «beep» sound and reposition the surface to the height it was before setting the timer.

Bounce Travel - 10H

The Bounce Travel is the distance the surface moves back when it hits an obstacle while raising or lowering.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **10H** appears. Press «M» button to enter, screen will display the current bounce travel. Using the UP/DOWN buttons, select bounce travel and press the «M» button to confirm selection.

Restore Factory Settings - 11r

Warning: this mode can erase all the parameters that have been previously adjusted for your program.

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **11r** appears. Press «M» button to enter, screen will display **Fr** (flashing). Press «M» button to confirm & exit. Screen will display **rES**, execute the Reset Procedure (page 3) to finalize Factory Settings Restoration.

Settings (cont'd) & Warranty

Demo Mode (for showrooms) - 12d

Activate keypad by pressing any button. Press «M» button for 3 seconds, screen will display **S--**, then release the «M» button and press the «up» arrow until code **12d** appears. Press «M» button to enter, screen will display **Pb_**.

There are five demo modes:

OFF: Demo mode not activated

51: Continuous demo (2 minutes activated / 18 minutes paused)

52: Complete cycle (raise/lower) followed by 4-minute pause.

53: Complete cycle (raise/lower) followed by 6-minute pause.

54: Complete cycle (raise/lower) followed by 10-minute pause.

Using the UP/DOWN buttons, select demo mode and press the «M» button to confirm selection.

About the Warranty

1. This product must be used under the correct technical parameters.
2. Keep away from liquids, corrosives, gases and dusty environments.
3. Do not open any of the components, doing so will void any and all service support and manufactures warranties.