

SAMSUNG

Simple User Guide



AH81-17454X-01

HW-LS60D



You can access the User guide on Samsung's on-line customer support center by scanning the QR code on the left. To see the manual on your PC or mobile device, download the manual in document format from Samsung's website. (<http://www.samsung.com/support>)

© 2024 Samsung Electronics Co., Ltd. All rights reserved.

QUESTIONS OR COMMENTS?

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care Centre.

Country/Region	Samsung Service Center ☎	Web Site
SINGAPORE	1800 7267864 1800-SAMSUNG	www.samsung.com/sg/support
AUSTRALIA	1300 362 603	www.samsung.com/au/support
NEW ZEALAND	0800 726 7864 (All Products) 0800 726 786 (All products) both numbers are linked with same line	www.samsung.com/nz/support
VIETNAM		www.samsung.com/vn/support
THAILAND	Hotline no : 1282 1800-29-3232 (Toll free for all product)	www.samsung.com/th/support
MYANMAR	+95-1-2399-888	www.samsung.com/mm/support
CAMBODIA	1800-20-3232 (Toll free)	www.samsung.com/th/support
LAOS	+856-214-17333	
MALAYSIA	1800-88-9999 +603-7713 7420 (Overseas contact)	www.samsung.com/my/support
INDONESIA	021-5699-7777 0800-112-8888 (All Product, Toll Free) 0800-112-7777 (All Product, Toll Free)	www.samsung.com/id/support
PHILIPPINES	1-800-10-7267864 [PLDT - Toll Free] 1-800-8-7267864 [Globe - Toll Free] 84222111 [Landline]	www.samsung.com/ph/support
INDIA	1800 5 SAMSUNG (1800 5 7267864) (Toll-Free) 1800 40 SAMSUNG (1800 40 7267864) (Toll-Free)	www.samsung.com/in/support
NEPAL	16600172667 (Toll Free for NTC Only) 9801572667 (Toll Free for Ncell users)	
SRI LANKA	011 SAMSUNG (011 7267864)	
BANGLADESH	08000-300-300 (Toll free) 09612-300-300	www.samsung.com/bd/support

SAFETY INFORMATION

SAFETY WARNINGS

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. Refer to the table below for an explanation of symbols which may be on your Samsung product.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
	This symbol indicates that high voltage is present inside. It is dangerous to make any kind of contact with any internal part of this product.	
	This symbol indicates that this product has included important literature concerning operation and maintenance.	
	Class II product : This symbol indicates that a safety connection to electrical earth (ground) is not required. If this symbol is not present on a product with a power cord, the product MUST have a reliable connection to protective earth (ground).	
	AC voltage : Rated voltage marked with this symbol is AC voltage.	
	DC voltage : Rated voltage marked with this symbol is DC voltage.	
	Caution. Consult Instructions for use : This symbol instructs the user to consult the user manual for further safety related information.	

WARNING

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.
- Do not use liquid fumigators containing chemicals, such as mosquito repellent or air freshener, around the product. If steam comes in contact with the product surface or enters the product, it may cause stains or malfunction.

CAUTION

- TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.
- Do not expose this apparatus to dripping or splashing. Do not put objects filled with liquids, such as vases, on the apparatus.

- To turn this apparatus off completely, you must pull the power plug out of the wall socket. Consequently, the power plug must be easily and readily accessible at all times

PRECAUTIONS

- Ensure that the AC power supply in your house complies with the power requirements listed on the identification sticker located on the bottom of your product. Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7~10 cm). Make sure the ventilation slots are not covered. Do not place the unit on amplifiers or other equipment which may become hot. This unit is designed for continuous use.
To fully turn off the unit, disconnect the AC plug from the wall outlet. Unplug the unit if you intend to leave it unused for a long period of time.
- During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage the unit.
- Do not expose the unit to direct sunlight or other heat sources. This could lead to overheating and cause the unit to malfunction.
- Protect the product from moisture (i.e. vases), and excess heat (e.g. a fireplace) or equipment creating strong magnetic or electric fields. Unplug the power cable from the AC wall socket if the unit malfunctions. Your product is not intended for industrial use. It is for personal use only. Condensation may occur if your product has been stored in cold temperatures. If transporting the unit during the winter, wait approximately 2 hours until the unit has reached room temperature before using.
- Make sure to rest the AC/DC Adapter flat on a table or the floor. If you place the AC/DC Adapter so that it is hanging with the AC cord input facing upwards, water or other foreign substances could enter the Adapter and cause the Adapter to malfunction.

01 CHECKING THE COMPONENTS


- Wireless Speaker main unit
- Stand
- AC/DC Adapter
- Power Cord
- Photo Frame
- Component for Art Panel (sold separately)
 - Holder-Plate x 4
 - Holder-Guide x 1
- Wallmount Component
 - Wallmount Guide
 - Bracket-Wall Rear x 1
 - Screw (M5 X L55) x 2
 - Anchor x 2
 - Holder-Screw x 1
 - Spacer x 2

NOTE

- To purchase additional components or optional cables, contact a Samsung Service Center or Samsung Customer Care.


02 PRODUCT OVERVIEW

Front



	(Multi Function) Button In standby mode, press the  (Multi Function) button to turn on the Wireless Speaker. Press the  (Multi Function) button to change the mode.
	(Mic On/Off) Button Press the button to turn the microphone on or off. When the microphone is off, the LED indicator will light red. To switch to Bluetooth Pairing state, press and hold the  (Mic On/Off) button on the side of the Wireless Speaker for more than 5 seconds.
	LED indicator The LED Indicator flashes, glows, or changes color depending on the Wireless Speaker's current mode or status.


Rear



D. IN (OPTICAL)
Connect to the digital (optical) output of an external device.
SMARTTHINGS DONGLE
Connect the SmartThings dongle(Purchase separately) to use the SmartThings Hub function.
DC 19V
Connect the AC/DC power adapter. (Power Supply In)

03 CONNECTING THE POWER

Connecting the power and units



- For more information about the required electrical power and power consumption, refer to the label attached to the product. (Label: Rear of the Wireless Speaker Main Unit)

04 CONNECTING THE SMARTTHINGS APP

1 - Installation

- The SmartThings app allows you to control the functionality of and adjust the settings of the Wireless Speaker.
- Download the SmartThings app from the app store of your mobile device, or simply scan the provided QR code and download the app.
- QR 1: Video Guide for SmartThings App Connection
- QR 2: Download SmartThings App




2 - Device registration

- Run the SmartThings app on your mobile device.
 - Follow the on screen instructions and add the product to your mobile device.
- If the automatic pop-up window does not appear, press () on the Home screen to register the product.

3 - Control with SmartThings

- With the SmartThings app open on your device, select the Wireless Speaker that you have added.
 - The settings menu of the Wireless Speaker appears, where you can adjust the various settings including volume, sound mode or fine-tuning.
- For other users who want to control the **Music Frame**, tap Menu () on the SmartThing app of their mobile device and go to 'How to use' > 'Share control of devices' for reference.

NOTE
The illustration below may differ with the app version.



05 CONNECTING VIA WIFI WITH TV

- Wi-Fi connection is available only on Samsung TV.
 - The TV and Wireless Speaker must be connected to the same wireless network (Wi-Fi).
 - The menus may differ depending on the year of manufacture, refer to your TV manual.
1. Change the input source of the TV by using the Audio menu to Wireless Speaker.
 - Samsung TVs released in 2017 or later : (⚙️) → Sound → Sound Output → Music Frame (Wi-Fi)


06 USING THE Q-SYMPHONY FUNCTION

- This function is supported only when both the wireless speaker and the TV are connected to the same Wi-Fi network.
- It is available with new Samsung TV models to be released 2024.

When the Wireless Speaker connects to a Samsung TV that supports the Q-Symphony function, you can play the sound simultaneously through the Wireless Speaker and the TV. If you use the Q-Symphony function, the surround sound played on the Wireless speaker allows you to enjoy a richer, more three-dimensional surround sound effect.

When the Wireless Speaker is connected, “Q-Symphony” menu appears on the TV. (The message displayed may differ with the TV model.)
(Settings (⚙️) → All Settings (⚙️) → Sound → Sound Output)


07 CONNECTING VIA BLUETOOTH WITH MOBILE



1. Press **⏻ (Mic On/Off)** button for 5 seconds for pairing.
 - It is also available to pair by pressing [**Ⓜ**] on the SmartThings App screen of your mobile device.



2. Search for the Bluetooth device on your mobile device.
 - TV can be connected in the same way.



- NOTE**
- If asked for a PIN code when connecting a Bluetooth device, enter <0000>.

08 TROUBLESHOOTING

Before seeking assistance, check the following.

Wireless Speaker does not turn on.

- Check whether the power cord of the Wireless Speaker is correctly inserted into the outlet.

Wireless Speaker works erratically.

- After removing the power cord, insert it again.
- Try again after initializing the product.
- If there is no signal, the Wireless Speaker automatically turns off after a certain period of time. Turn on the power.

The red LED indicator light on the Wireless Speaker stays on.

- The microphone is turned off. Turn on the microphone.

LED indicator	
○ ○ ● ○ ○	Mic Off
- Red On	
○ ○ ○ ○ ○	Mic On

Sound is not output from the Wireless Speaker.

- The volume of the Wireless Speaker is too low or muted. Adjust the volume.
- When any external device (STB, Bluetooth device, mobile device, etc.) is connected, adjust the volume of the external device.
- For sound output of the TV, select Wireless Speaker. (Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Sound → Sound Output → Select Wireless Speaker)
- Remove the cable from the Wireless Speaker and then reconnect it.

Wireless Speaker will not connect via Bluetooth.

- When connecting a new device, switch to “BT PAIRING” for connection. (Press the **⏻ (Mic On/Off)** button on the body for at least 5 seconds.)
- Reconnect it after removing the Bluetooth speaker list on the device to connect. (Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Sound → Sound Output → Bluetooth Speaker List)

09 IMPORTANT NOTES ABOUT SERVICE

Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

10 SPECIFICATIONS AND GUIDE

Model Name : HW-LS60D
Weight : Without Stand : 4.2 kg With Stand : 4.6 kg
Dimensions (W x H x D) : Without Stand 353.0 x 353.8 x 54.2 mm With Stand 353.0 x 364.8 x 143.4 mm
Operating Temperature Range : +10 °C to +40 °C Operating Humidity Range : 10 % to 80 %, non-condensing Storage Temperature Range : -20 °C to +45 °C Storage Humidity Range : 5 % to 95 %, non-condensing
Supported play formats Dolby 5.1ch / Dolby Digital Plus / Dolby ATMOS (Dolby Digital Plus) / LPCM 2ch

NOTE

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.

To activate/deactivate Wi-Fi connection

Press and hold the **⏻ (Mic On/Off)** button and the - button on the side panel simultaneously for more than 30 seconds. This will turn on or off the Wi-Fi connection.

To activate/deactivate Bluetooth connection

Press and hold the **⏻ (Mic On/Off)** button and the + button on the side panel simultaneously for more than 30 seconds. This will turn on or off the Bluetooth connection.

Precaution : The Wireless speaker will restart automatically if you turn on/turn off Wi-Fi or Bluetooth.



[ENERGY STAR]

ENERGY STAR qualified model only

- Your Samsung product is ENERGY STAR qualified in its factory default setting. Change to certain features, settings and functionality in this product can change the power consumption, possibly beyond the limits required for ENERGY STAR qualification.
- Environmental Protection Agency and Department of Energy. ENERGY STAR is a joint program of the Government agencies, designed to promote energy efficient products and practices.

Refer to www.energystar.gov for more information of the ENERGY STAR Program.

ENERGY STAR qualified model only (The other models)

- As an ENERGY STAR Partner, Samsung has determined that this product or product models meets the ENERGY STAR guideline for energy efficiency.

Sound drops out when connected via Bluetooth.

- Some devices can cause radio interference if they are located too close to the Wireless Speaker. e. g. microwaves, wireless routers, etc.
- If your device that is connected via Bluetooth moves too far away from the Wireless Speaker, it may cause the sound to drop out. Move the device closer to the Wireless Speaker.
- If a part of your body is in contact with the Bluetooth transceiver or the product is installed on metal furniture, the sound may drop out. Check the installation environment and conditions for use.

Wireless Speaker will not connect to Wi-Fi.

- Make sure the wireless router is turned on and then reconnect the wireless router after rebooting.
- The Wireless Speaker will not connect if the wireless signal is too weak. Try moving the router closer to the Wireless Speaker, or eliminating any obstacles that are between the Wireless Speaker and the router, if possible.

The Wireless Speaker does not turn on automatically with the TV.

- When you turn off the Wireless Speaker while watching TV, power synchronization with the TV is disabled. First turn off the TV.

For India Only

This product is RoHS compliant



This marking on the product, accessories or literature indicates that the product and its electronic accessories (e. g. charger, headset, and USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or the human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. For more information on safe disposal and recycling visit our website. www.samsung.com/in/support or contact our Helpline numbers-
1800 40 SAMSUNG(7267864)
1800 5 SAMSUNG(7267864)