



Upgrading Field-Programmable Device

An FPD is a field programmable logic device which contains non-volatile, re-programmable memory to define its internal wiring and functionality. The contents of this non-volatile memory are called the FPD image or FPD firmware. Over the lifespan of an FPD, FPD firmware images may need upgrades for bug fixes or functionality improvements. These upgrades are performed in the field with minimum system impact.

- [Overview of FPD Image Upgrade , on page 1](#)
- [Restrictions for FPD Upgrade , on page 1](#)
- [Types of FPD Upgrade Service, on page 2](#)
- [How to Upgrade FPD Images, on page 4](#)
- [Automatic Line Card Reload on FPD Upgrade, on page 10](#)
- [Power Module Upgrades, on page 10](#)
- [Upgrading FPD for PSU, on page 12](#)

Overview of FPD Image Upgrade

An FPD image is used to upgrade the software on an FPD.

Whenever a new IOS XR version is released, the software package includes FPD images. However ,generally the FPD image isn't automatically upgraded. You must manually upgrade the FPD image when you upgrade the Cisco IOS XR software image.

FPD versions must be compatible with the Cisco IOS XR software that is running on the router; if an incompatibility exists between an FPD version and the Cisco IOS XR software, the device with the FPGA may not operate properly until the incompatibility is resolved.

Restrictions for FPD Upgrade

The Optics FPD Upgrade Service is not available using the **upgrade hw-module fpd** command.

You can upgrade Optics FPD using the **upgrade optics port filename /harddisk:/cl1.bin location** command.

For more information on optics FPD upgrade, see *Upgrade QDD Optical Modules* in Upgrade the Router Chapter in Cisco IOS XR Setup and Upgrade Guide for Cisco 8000 Series Routers.

Restrictions For Automatic FPD Upgrade

The following FPDs do not support Auto FPD Upgrade:

- Optics FPDs
- Power Module FPDs
- Timing FPDs

Types of FPD Upgrade Service

An FPD image package is used to upgrade FPD images. The **install activate** command is used to place the FPD binary files into the expected location on the boot devices.

Supported Upgrade Methods

Method	Remarks
Manual Upgrade	Upgrade using CLI, force upgrade supported.
Auto Upgrade	Upgrade using install SMU activation or during image upgrade. User can enable/disable auto upgrade feature.

Manual FPD upgrade

Manual FPD upgrade is performed using the **upgrade hw-module fpd** command. All cards or all FPGA in a card can be upgraded. If reload is required to activate FPD, the upgrade should be complete. Line-cards, fabric cards and RP cardsInterface module (IMs) and RSPs can't be reloaded during the process of the FPD upgrade.

FPD upgrade is transaction-based:

- Each fpd upgrade CLI execution is one transaction.
- Only one transaction is allowed at any given time.
- One transaction may include one or many FPD upgrades.

Once the upgrade is complete, the router/the card (on which the FPD is upgraded) must be reloaded.

The **force** option can be used to forcibly upgrade the FPD (regardless of whether it's required or not). It triggers all FPDs to be upgraded or downgraded. The **force** option can also be used to downgrade or upgrade the FPGAs even after the version check. However, the **force** option must be used cautiously and only to recover a component from a failed upgrade.



Note

- Sometimes, FPDs can have primary and backup images.
- The use of the **force** option when performing an FPD upgrade isn't recommended except under explicit direction from Cisco engineering or TAC for a one-time purpose only.
- A new FPD upgrade should be issued only when previous FPD upgrades have been completed on the same FPD with the following syslog message:

```
RP/0/RP0/CPU0:May 10 10:11:44.414 UTC: fpd-serv[205]: %INFRA-FPD_Manager-1-UPGRADE_ALERT
: FPD Upgrade Completed (use "show hw-module fpd" to check upgrade status)
```

Automatic FPD Upgrade

FPD auto-upgrade is enabled by default. To ensure that the FPD image is automatically upgraded, you should not disable this feature. If you need to disable the automatic upgrade of the FPD image running on the Field Replaceable Unit (FRU), you can manually apply the configuration **fpd auto-upgrade disable** in administration configuration mode.

With FPD auto-upgrade enabled, FPD images are automatically updated in the following instances:

- Software upgrade is carried out.
- Field Replaceable Unit(FRU) such as Line cards, RSPs, Fan Trays or alarm cards are added to an existing router or reloaded.

For the automatic FPD upgrade to work on a system upgrade, the following conditions must be met:

- The FPD package installation envelope (PIE) must be installed on the router.
- The FPD PIE must be activated together with the new Cisco IOS XR image.

For the automatic FPD upgrade to work on a FRU Insertion or reload , the following conditions must be met:

- The FPD package installation envelope (PIE) must be installed and activated on the router.



Note Although the FPD upgrade is performed during the install operation, there is no install commit performed. Therefore, once the FPD has been upgraded, if the image is rolled back to the original version, the FPD version is not downgraded to the previous version.

The automatic FPD upgrade is not performed in the following instances:

- Line cards or other cards or alarm cards are added to an existing router.
- A line card chassis is added to an existing router.
- A non-reload software maintenance upgrade (SMU) or PIE installation is performed, even where the FPD image version changes. Since a non-reload installation is, by definition, not supposed to reload the router, and an FPD upgrade requires a router reload, the automatic FPD upgrade is repressed.



Note In all cases where the automatic FPD upgrade is not performed, you must perform a manual FPD upgrade using the **upgrade hw-module fpd** command.

FPD auto-upgrade can be enabled and disabled. When auto FPD is enabled, it automatically updates FPDs when a SMU or image changes, including an updated firmware revision. Use the **fpd auto-upgrade** command to disable or enable auto-fpd.

YANG Data Models for Auto FPD Upgrade

YANG is a data modeling language that helps to create configurations, retrieve operational data and execute actions. The router acts on the data definition when these operations are requested using NETCONF RPCs. The data model handles the following types of requirements on the routers for FPD:

Operational Data	Native Data Model	CLI Commands
Auto Upgrade: Enabling or disabling of automatic upgrade of FPD.	Cisco-IOS-XR-fpd-infra-cfg.yang	<ul style="list-style-type: none"> • fpd auto-upgrade enable • fpd auto-upgrade disable
Auto Reload: Enabling or disabling of automatic reload of FPD.	Cisco-IOS-XR-fpd-infra-cfg.yang	<ul style="list-style-type: none"> • fpd auto-reload enable • fpd auto-reload disable

You can access the data models from the [Github](#) repository. To learn more about the data models and put them to use, see the *Programmability Configuration Guide for Cisco 8000 Series Routers*.

How to Upgrade FPD Images

The main tasks of the FPD upgrade service are:

- Check FPD image version to decide if a specific firmware image needs an upgrade or not.
You can determine if an FPD image upgrade is needed using the **show hw-module fpd** command and perform the upgrade, if needed, under the following circumstances:
 - Migrate the software to a later Cisco IOS XR software release.
 - Swap line cards from a system running a different Cisco IOS XR software release.
 - Insert a new line card.
- Automatic FPD Image Upgrade (if enabled) Or Manual FPD Image Upgrade using the **upgrade hw-module fpd** command.
- Invoke the appropriate device driver with a name of the new image to load.

Guidelines for Upgrading FPD

The following are some of the important guidelines to be taken into consideration for upgrading FPD:

- Upgrades to the Cisco IOS XR software might result in an FPD incompatibility. Ensure that you perform the FPD upgrade procedure and resolve all incompatibilities, for the cards to function properly.
- The use of the **force** option when performing a FPD upgrade is not recommended except under explicit direction from Cisco engineering or TAC for a one-time purpose only.
- If your card supports multiple FPD images, you can use the **show fpd package** admin command to determine what specific image to upgrade in the **upgrade hw-module fpd** command.
- A message is displayed when router modules cannot get upgraded during upgrade with **location all** option indicating that the FPGA is intentionally skipped during upgrade. To upgrade such FPGAs, you can use the CLI command with a particular location explicitly specified. For example, **upgrade hw-module fpd all location 0/3/1**.
- It is recommended to upgrade all FPGAs on a given node using the **upgrade hw-module fpd all location {all | node-id}** command. Do not upgrade the FPGA on a node using the **upgrade hw-module fpd individual-fpd location {all | node-id}** as it may cause errors in booting the card.

Before you begin

- Before performing the manual upgrading the FPD on your router using the **upgrade hw-module FPD**, you must install and activate the `fpd.pie` and `fpd.rpm` package.
- The FPD upgrade procedure is performed while the card is online. At the end of the procedure the card must be reloaded before the FPD upgrade is complete. To reload the card, you can use the **hw-module location location reload** command in Config mode, during the next maintenance window. The upgrade procedure is not complete until the card is reloaded.
- During the FPD upgrade, you *must not* do the following:
 - Reload, perform an online insertion and removal (OIR) of a line card (LC), or power down the chassis. Doing so may cause the node to enter an unusable state.
 - Press **Ctrl-C** if the console appears to hang without any output. Doing so may abort the upgrade.
- If you are not sure whether a card requires an FPD upgrade, you can install the card and use the **show hw-module fpd** command to determine if the FPD image on the card is compatible with the currently running Cisco IOS XR software release.

Procedure**Step 1** **show hw-module fpd location {all | node-id}****Example:**

```
Router#show hw-module fpd location all
```

or

```
Router#show hw-module fpd location 0/4/cpu0
```

Displays the current FPD image versions for the specified card or all cards installed in the router. Use this command to determine if you must upgrade the FPD image on your card.

In the event of an FPD incompatibility with your card, you might receive the following error message:

```
LC/0/0/CPU0:Jul 5 03:00:18.929 UTC: optics_driver[220]: %L2-OPTICS-3-BAD_FPGA_IMAGE : Detected bad MI FPGA image programmed in MI FPGA SPI flash in 0/0/CPU0 location: Failed to validate meta data CRC
```

```
LC/0/0/CPU0:Jul 5 03:00:19.019 UTC: optics_driver[220]: %L2-OPTICS-3-BACKUP_FPGA_LOADED : Detected Backup FPGA image running on 0/0/CPU0 - primary image corrupted (@0x8c = 0x44)
RRouter:Jul 5 03:00:48.987 UTC: fpd-serv[301]: %PKT_INFRA-FM-3-FAULT_MAJOR : ALARM_MAJOR
:FPD-NEED-UPGRADE :DECLARE :0/0:
```

Step 2 (Optional) **show fpd package****Example:**

The following example shows a sample output from the **show fpd package** command:

```
Router#show fpd package
```

```
=====
Field Programmable Device Package
=====
Card Type          FPD Description          Req   SW   Min Req  Min Req
                      Reload  Ver   SW Ver   Board Ver
```

Slot	FPD Name	Supported	Current Version	Minimum Version	Minimum Version (0.0)
8201	Bios	YES	1.23	1.23	0.0
	BiosGolden	YES	1.23	1.15	0.0
	IoFpga	YES	1.11	1.11	0.1
	IoFpgaGolden	YES	1.11	0.48	0.1
	SsdIntelS3520	YES	1.21	1.21	0.0
	SsdIntelS4510	YES	11.32	11.32	0.0
	SsdMicron5100	YES	7.01	7.01	0.0
	SsdMicron5300	YES	0.01	0.01	0.0
	x86Fpga	YES	1.05	1.05	0.0
	x86FpgaGolden	YES	1.05	0.48	0.0
	x86TamFw	YES	5.13	5.13	0.0
	x86TamFwGolden	YES	5.13	5.05	0.0
8201-ON	Bios	YES	1.208	1.208	0.0
	BiosGolden	YES	1.208	1.207	0.0
	IoFpga	YES	1.11	1.11	0.1
	IoFpgaGolden	YES	1.11	0.48	0.1
	SsdIntelS3520	YES	1.21	1.21	0.0
	SsdIntelS4510	YES	11.32	11.32	0.0
	SsdMicron5100	YES	7.01	7.01	0.0
	SsdMicron5300	YES	0.01	0.01	0.0
	x86Fpga	YES	1.05	1.05	0.0
	x86FpgaGolden	YES	1.05	0.48	0.0
	x86TamFw	YES	5.13	5.13	0.0
	x86TamFwGolden	YES	5.13	5.05	0.0
8201-SYS	Bios	YES	1.23	1.23	0.0
	BiosGolden	YES	1.23	1.15	0.0

Displays which cards are supported with your current Cisco IOS XR software release, which FPD image you need for each card, and what the minimum hardware requirements are for the various modules. (A minimum hardware requirement version of 0.0 indicates that all hardware can support this FPD image version.)

If there are multiple FPD images for your card, use this command to determine which FPD image to use if you want to upgrade only a specific FPD type.

The FPD name used in the FPD Description column of the output of the **show fpd package** command includes the last ten characters of DCO-PID. Depending on the slot and port numbers, the FPD name is appended with DCO_0, DCO_1, or DCO_2. For example, the FPD names for CFP2-WDM-D-1HL in port 0 and port 1 are -WDM-D-1HL_DCO_0 and WDM-D-1HL_DCO_1 respectively.

Step 3 **upgrade hw-module fpd {all | fpga-type} [force] location [all | node-id]**

Example:

```
Router#upgrade hw-module fpd
all location 0/3/1
.
.
.
Successfully upgraded 1 FPD for SPA-2XOC48POS/RPR
on location 0/3/1

Router#upgrade hw-module location 0/RP0/CPU0 fpd all
upgrade command issued (use "show hw-module fpd" to check upgrade status)
Router: %SECURITY-SSHD_SYSLOG_PRX-6-INFO_GENERAL : sshd[29745]: Accepted authentication for cisco
from 223.255.254.249 port 39510 ssh2
upgrade hw-module location 0/RP0/CPU0 fpd all RRouter: ssh_syslog_proxy[1223]:
%SECURITY-SSHD_SYSLOG_PRX-6-INFO_GENERAL : sshd[29803]: Accepted authentication for cisco from
223.255.254.249 port 39524 ssh2
```

```

Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : Upgrade for the following FPDs has been
committed:
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : Location          FPD name
Force
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT :
=====
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      x86FpgaGolden
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      x86Fpga
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      SsdMicron5300
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      IoFpgaGolden
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      IoFpga
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      DbIoFpgaGolden
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      DbIoFpga
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      BiosGolden
FALSE
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : 0/RP0/CPU0      Bios
FALSE
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
x86FpgaGolden@0/RP0/CPU0: Image not upgradable
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
x86TamFwGolden@0/RP0/CPU0: Image not upgradable
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
x86FpgaGolden@0/RP0/CPU0: A dependent FPD upgrade is skipped
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
IoFpgaGolden@0/RP0/CPU0: Upgrade not required
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
DbIoFpgaGolden@0/RP0/CPU0: Upgrade not required
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
BiosGolden@0/RP0/CPU0: Image not upgradable
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_SKIPPED : FPD upgrade skipped for
SsdMicron5300@0/RP0/CPU0: Upgrade not required as it is current

Router#fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_COMPLETE : FPD upgrade complete for
Bios@0/RP0/CPU0 [image upgraded to version 254.00]
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_COMPLETE : FPD upgrade complete for
x86TamFw@0/RP0/CPU0 [image upgraded to version 7.10]
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_COMPLETE : FPD upgrade complete for
DbIoFpga@0/RP0/CPU0 [image upgraded to version 14.00]
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_COMPLETE : FPD upgrade complete for
IoFpga@0/RP0/CPU0 [image upgraded to version 14.00]
Router:fpd_client[385]: %PLATFORM-FPD_CLIENT-1-UPGRADE_COMPLETE : FPD upgrade complete for
x86Fpga@0/RP0/CPU0 [image upgraded to version 254.00]
Router:shelfmgr[459]: %PLATFORM-SHELFMGR-6-INFO_LOG : 0/RP0/CPU0 is operational
Router:fpd-serv[265]: %INFRA-FPD_Manager-1-UPGRADE_ALERT : FPD Upgrade Completed (use "show hw-module
fpd" to check upgrade status)

```

Upgrades all the current FPD images that must be upgraded on the specified card with new images.

Before continuing to the next step, wait for confirmation that the FPD upgrade has successfully completed. Status messages, similar to these, are displayed to the screen until the FPD upgrade is completed:

```

FPD upgrade started.
FPD upgrade in progress..
FPD upgrade in progress..
FPD upgrade sent to location xxxx
FPD upgrade sent to location yyyy

```

```

FPD upgrade in progress..
FPD upgrade finished for location xxx
FPD upgrade in progress..
FPD upgrade finished for location yyyy
FPD upgrade completed.

```

The “FPD upgrade in progress.” message is printed every minute. These logs are information logs, and as such, are displayed if the **logging console informational** command is configured.

If Ctrl-C is pressed while the FPD upgrade is in progress, the following warning message is displayed:

```

FPD upgrade in progress on some hardware,
aborting now is not recommended as it might
cause HW programming failure and result in
RMA of the hardware.
Do you want to continue? [Confirm(y/n)]

```

If you confirm that you want to abort the FPD upgrade procedure, this message is displayed:

```

FPD upgrade process has been aborted, please
check the status of the hardware and reissue
the upgrade command if required.

```

Note

- If your card supports multiple FPD images, you can use the **show fpd package** admin command to determine what specific image to upgrade in the **upgrade hw-module fpd** command.
- A message is displayed when router modules cannot get upgraded during upgrade with **location all** option indicating that the FPGA is intentionally skipped during upgrade. To upgrade such FPGAs, you can use the CLI command with a particular location explicitly specified. For example, **upgrade hw-module fpd all location 0/3/1**.
- It is recommended to upgrade all FPGAs on a given node using the **upgrade hw-module fpd all location {all | node-id}** command. Do not upgrade the FPGA on a node using the **upgrade hw-module fpd <individual-fpd> location {all | node-id}** as it may cause errors in booting the card.

Step 4 **hw-module location { node-id | all } reload**

Use the **hw-module location reload** command to reload a line card.

```
Router:ios(config)# hw-module location 0/3 reload
```

Step 5 **exit**

Step 6 **show hw-module fpd**

Verifies that the FPD image on the card has been successfully upgraded by displaying the status of all FPDs in the system.

Example:

```

Router# show hw-module fpd
Auto-upgrade:Disabled
Attribute codes: B golden, P protect, S secure, A Anti Theft aware

```

Location	Card type	HWver	FPD device	ATR Status	FPD Versions		Reload Loc
					Running	Programd	
0/RP0/CPU0	8201	0.30	Bios	NEED UPGD	7.01	7.01	0/RP0/CPU0
0/RP0/CPU0	8201	0.30	BiosGolden	B NEED UPGD		7.01	0/RP0/CPU0

0/RP0/CPU0 8201	0.30	IoFpga	NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	IoFpgaGolden	B NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	SsdIntelS3520	NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	x86Fpga	NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	x86FpgaGolden	B NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	x86TamFw	NEED UPGD	7.01	7.01	0/RP0
0/RP0/CPU0 8201	0.30	x86TamFwGolden	B NEED UPGD	7.01	7.01	0/RP0
0/PM0 PSU2KW-ACPI	0.0	PO-PrimMCU	NEED UPGD	7.01	7.01	NOT REQ
0/PM1 PSU2KW-ACPI	0.0	PO-PrimMCU	NEED UPGD	7.01	7.01	NOT REQ

If the cards in the system do not meet the minimum requirements, the output contains a “NOTES” section that states how to upgrade the FPD image.

Table 1: show hw-module fpd Field Descriptions

Field	Description
Card Type	Module part number.
HW Version	Hardware model version for the module.
Type	Hardware type. <ul style="list-style-type: none"> lc—Line card
Subtype	FPD type. Can be one of the following types: <ul style="list-style-type: none"> Bios - Basic Input/Output System BiosGolden - Golden BIOS image IoFpga - Input/Output Field-Programmable Gate Array IoFpgaGolden - Golden IoFpga SsdIntelS3520 - Solid State Drive, made by Intel, of the model series S3520 x86Fpga - Field-Programmable Gate Array designed to work with x86-based systems x86FpgaGolden - Golden image of x86Fpga x86TamFw - x86 Tam firmware x86TamFwGolden - Golden image of x86TamFw PO-PrimMCU - Primary microcontroller unit associated with a 'PO'
Inst	FPD instance. The FPD instance uniquely identifies an FPD and is used by the FPD process to register an FPD.
Current SW Version	Currently running FPD image version.
Upg/Dng?	Specifies whether an FPD upgrade or downgrade is required. A downgrade is required in rare cases when the version of the FPD image has a higher major revision than the version of the FPD image in the current Cisco IOS XR software package.

Automatic Line Card Reload on FPD Upgrade

This feature automatically reloads a newly inserted line card (LC) after a successful FPD upgrade. The prior auto FPD upgrade process did not reload the line card automatically, the user had to manually reload the LC.

Restrictions for Automatic Line Card Reload on FPD Upgrade

The following restriction must be considered while configuring automatic line card reload on FPD upgrade:

- If the FPD upgrade fails on a line card then the automatic line card reload feature (if enabled) stops the LC from reloading.

Configure Automatic Line Card Reload on FPD Upgrade

The following sample shows how to configure auto-reload feature:

```
Router# config
Router(config) #fpd auto-upgrade enable
Router(config) #fpd auto-reload enable
Router(config) #commit
```

The auto-reload feature is only supported on line cards.



Note During the FPD upgrade process, the linecard may display IOS XR RUN state before triggering auto-reload.

Power Module Upgrades

In Cisco IOS XR Routers, Field Programmable Device (FPD) upgrades for power modules are used to update the firmware or hardware logic of power entry modules (PEMs) within the router. These upgrades ensure that power modules operate effectively with the latest enhancements and bug fixes. Follow the [Manual Power Module FPD Upgrade](#) procedure to upgrade the FPD on PEMs.

Manual Power Module FPD Upgrade

Manual Power modules FPD upgrades are supported on Cisco Routers and should be performed in Config mode only. This feature lets you perform FPD upgrades on individual PEMs.

Only power modules that support FPD upgrades can be upgraded manually.



Note Power module upgrades are time consuming and can't be implicitly upgraded or as a part of automatic FPD upgrades. These modules must be upgraded independent of the other fpga upgrades.

To determine which PEMs requires upgrade, use **show hw-module location all fpd**.

PEMs requiring upgrade are in **UPGD SKIP** status.

```
Router#show hw-module location all fpd
```

```
Auto-upgrade:Disabled
```

```
Attribute codes: B golden, P protect, S secure, A Anti Theft aware
```

Location Reload Loc	Card type	HWver	FPD device	ATR Status	FPD Versions =====	
					Running	Programd
0/RP0/CPU0 8201		0.30	Bios	NEED UPGD	7.01	7.01
0/RP0/CPU0						
0/RP0/CPU0 8201		0.30	BiosGolden	B NEED UPGD		7.01
0/RP0/CPU0						
0/RP0/CPU0 8201		0.30	IoFpga	NEED UPGD	7.01	7.01
0/RP0						
0/RP0/CPU0 8201		0.30	IoFpgaGolden	B NEED UPGD		7.01
0/RP0						
0/RP0/CPU0 8201		0.30	SsdIntelS3520	NEED UPGD	7.01	7.01
0/RP0						
0/RP0/CPU0 8201		0.30	x86Fpga	NEED UPGD	7.01	7.01
0/RP0						
0/RP0/CPU0 8201		0.30	x86FpgaGolden	B NEED UPGD		7.01
0/RP0						
0/RP0/CPU0 8201		0.30	x86TamFw	NEED UPGD	7.01	7.01
0/RP0						
0/RP0/CPU0 8201		0.30	x86TamFwGolden	B NEED UPGD		7.01
0/RP0						
0/PM0	PSU2KW-ACPI	0.0	PO-PrimMCU	NEED UPGD	7.01	7.01
NOT REQ						
0/PM1	PSU2KW-ACPI	0.0	PO-PrimMCU	NEED UPGD	7.01	7.01
NOT REQ						

To upgrade the power modules manually, use **[admin] upgrade hw-module location 0/PTlocation fpd <fpd_device>**.

```
Router# admin
```

```
Router(admin)# upgrade hw-module location 0/PT0 fpd PM0-DT-Pri0MCU
```

To force a power module upgrade, use **upgrade hw-module fpd all force location pm-all** command in **Admin** mode.

Upgrading FPD for PSU

Table 2: Feature History Table

Feature Name	Release Information	Feature Description
Optimized PSU FPD Upgrade	Release 7.8.1	<p>We have optimized the upgrade process of Field-Programmable Devices (FPDs) associated with the Power Supply Unit (PSUs) on the router. During the installation and PSU insertion process on the router, the FPDs associated with the PSUs are automatically upgraded. Starting this release, the PSU FPDs are grouped in the form of a parent FPD and its related child FPDs, and the upgrade image is downloaded only once. The upgrade is then triggered on the parent FPD PSU and replicated to the child FPD PSUs.</p> <p>In earlier releases, you downloaded the FPD image for each FPD associated with that PSU, and the upgrade process was then triggered sequentially. This process was time-consuming.</p> <p>The feature is supported on the following PSUs:</p> <ul style="list-style-type: none">• PSU2KW-ACPI• PSU2KW-HVPI• PSU3KW-HVPI• PSU4.8KW-DC100



Note You must disable **auto FPD upgrade** for PSUs before upgrading the router to Cisco IOS XR Software Release 7.9.1 or later if your router uses any of the following PSUs:

- PSU2KW-ACPI
- PSU2KW-ACPE
- PSU2KW-HVPI
- PSU4.8KW-DC100

To disable auto FPD upgrade, use the following command:

fpd auto-upgrade exclude pm

```
RP/0/RSP0/CPU0:ios# show running-config fpd auto-upgrade
RP/0/RP0/CPU0:ios(config)# fpd auto-upgrade exclude pm
RP/0/RP0/CPU0:ios(config)# commit
RP/0/RP0/CPU0:ios#
```

Automatic FPD Upgrade for PSU

Feature Name	Release Information	Feature Description
Automatic FPD upgrade for PSU	Release 7.5.2	Automatic FPD upgrade for PSUs is now enabled. In earlier releases, automatic upgrades did not apply to FPDs associated with the PSUs.

During the Power Supply Unit (PSU) insertion and installation process, the routers can now automatically upgrade the Field-Programmable Devices (FPD) associated with the PSUs.

Starting with Cisco IOS-XR Release 7.5.2, the automatic FPD upgrade includes the FPDs associated with the PSUs by default. This means that when automatic FPD upgrade is enabled, the FPDs associated with the PSUs will also be upgraded. The upgrades for the PSUs will occur sequentially, so the FPD upgrades for the PSUs will take longer than for other components.

You can choose to exclude PSUs from the automatic upgrade process to reduce the time taken for FPD automatic upgrade by preventing them from being upgraded upon insertion or during a system upgrade using the **fpd auto-upgrade exclude pm** command.

Configuration example for excluding PSUs from automatic FPD upgrade:

Configuration

```
Router# config
Router(config)# fpd auto-upgrade enable
Router(config)# fpd auto-upgrade exclude pm
Router(config)# commit
```

Show Running Configuration

```
Router# show running-config fpd auto-upgrade
fpd auto-upgrade enable
fpd auto-upgrade include pm
```

Exclude the Default PSU Upgrade from the Automatic FPD Upgrade

Table 3: Feature History Table

Feature Name	Release Information	Feature Description
Exclude the Default PSU Upgrade from the Automatic FPD Upgrade	Release 24.3.1	<p>Introduced in this release on: Fixed Systems (8200 [ASIC: Q200, P100], 8700 [ASIC: P100], Centralized Systems (8600 [ASIC:Q200]); Modular Systems (8800 [LC ASIC: Q100, Q200, P100])</p> <p>To make the automatic FPD upgrade process more time efficient, we have decreased the default time needed for FPD automatic upgrades by excluding PSUs from the automatic upgrade process. This is because the PSU upgrades are carried out one after the other, and on a fully loaded router, the process could take more than an hour to complete. We have also added an option to include the PSU in the automatic FPD upgrade. Previously, the PSU upgrade was included by default in the automatic FPD upgrade.</p> <p>The feature introduces the following change:</p> <p>CLI:</p> <ul style="list-style-type: none"> The include pm keyword is introduced in the fpd auto-upgrade command.

The routers automatically upgrade the Field-Programmable Devices (FPDs) associated with the Power Supply Unit (PSU) by default during the PSU insertion and installation process.

Starting with Cisco IOS-XR Release 24.3.1, the automatic FPD upgrade excludes the FPDs associated with the PSUs by default. This means that when the automatic FPD upgrade is enabled, the FPDs associated with the PSUs will not be upgraded by default to avoid the FPD automatic upgrade taking longer. The PSU upgrade exclusion is because the PSU upgrades will occur sequentially, and the FPD upgrades for the PSUs will take longer for a fully loaded router.

You can include the PSU upgrade to the FPD automatic upgrade process using the **fpd auto-upgrade include pm** command.

Include PSUs to Automatic FPD Upgrade

To include the PSU upgrade to FPD automatic upgrade process, do the following:

Procedure

Step 1 Enable the FPD automatic upgrade.

Example:

```
Router# config
Router(config)# fpd auto-upgrade enable
Router(config)# commit
```

Step 2 Include PSU upgrade in the FPD automatic upgrade.

Example:

```
Router# config
Router(config)# fpd auto-upgrade include pm
Router(config)# commit
```

Step 3 Verify the FPD and PSU automatic upgrade configurations.

Example:

```
Router# show running-config fpd auto-upgrade
fpd auto-upgrade enable
fpd auto-upgrade include pm
```

Step 4 View the status of PSU auto upgrade.

Example:

```
Router# show hw-module fpd
```

```
Auto-upgrade:Disabled
```

```
Auto-upgrade PM:Disabled
```

```
Attribute codes: B golden, P protect, S secure, A Anti Theft aware
```

Auto upgrade support for SC/MPA

In Cisco 8000 Series Routers, the auto upgrade on bootup path is being supported for new CPU less cards SC and MPA.

The RP and SC cards together form a domain in Active and Standby nodes. The respective domain lead (RP) is responsible to trigger the auto upgrade of respective SC cards.

