

Curtis 1515

This sheet is provided to aid in the installation of your remanufactured CURTIS controller. Upon installation, you may encounter problems that may, or may not, be due to a faulty controller. The following steps must be taken to help diagnose a possible cart fault or faulty controller. An analog or digital volt ohm meter (VOM) will be needed to perform these checks.



WARRANTY WILL BE VOID **If These Steps are Not Performed Before Installing The Control**

➡ STEPS TO PERFORM ***BEFORE*** CONTROL INSTALLATION ⬅

CHECK MOTOR WINDINGS:

- ☐ Set your VOM to RESISTANCE (Ω).
- ☐ With your motor disconnected, measure A1 to A2. This must measure BETWEEN $.3\Omega$ and 1Ω .
- ☐ With your motor disconnected, measure F1 to F2. This must measure BETWEEN 1Ω and 2Ω .
- ☐ With your motor disconnected, measure A1 to F1. This must measure OPEN.
- ☐ With your motor disconnected, measure F1 to motor case. This must measure greater than $5M\Omega$.

CHECK MAIN SOLENOID:


- ☐ Disconnect all wires from the main solenoid.
- ☐ Set your VOM to RESISTANCE (Ω).
- ☐ Measure the solenoid coil. This must measure NO LESS than 100Ω .
- ☐ Connect VOM leads to the main solenoid lugs.
- ☐ Attach jumpers from main battery positive and negative to the coil (small terminals).
- ☐ Meter must jump from infinity to LESS THAN $.3\Omega$.
- ☐ Remove jumpers and reconnect solenoid wiring from the harness. (If suppression diode is present, The non-banded side must go to the blue/white wire – pin 12 from controller.)

CHECK THE CART WIRE HARNESS:

- ☐ Check the connectors on the wire harness for corrosion, loose, broken, burnt or missing pins.
- ☐ Repair or replace pins as necessary.

**IF ANY OF THE ABOVE ITEMS ARE NOT WITHIN THE SPECIFIED RANGES THE CONTROLLER WILL FAIL.
THESE ITEMS MUST BE CORRECTED BEFORE THE CONTROLLER IS INSTALLED OR WARRANTY WILL BE VOID.**

It is recommended to replace your solenoid at the time of controller replacement. FSIP now stocks popular replacement White Rodgers solenoids for your convenience.



Club Car Precedent Excel Troubleshooting Sequence

FOR SAFETY, ALWAYS LIFT THE DRIVE WHEELS OFF THE GROUND WHEN TROUBLESHOOTING!

ALL TESTS ARE CONDUCTED WITH RUN-TOW/MAINTENANCE SWITCH IN THE RUN. ALSO, THE CONNECTOR MUST BE ATTACHED TO THE CONTROLLER WHEN MAKING THESE CHECKS. YOU WILL NEED TO 'BACK PROBE' THE PINS FROM THE WIRE SIDE OF THE CONNECTOR. USE A PAPERCLIP IF NECESSARY.

Attach voltmeter negative (-) lead to main battery – for the following tests

Use the following sequence when checking individual pins **(don't skip steps)**. If you find a fault, do not move on to the next step until the fault is corrected:

- ☐ Measure the voltage at the main battery positive post (let's call it Pack Voltage)
- ☐ **Pin 5** **With the Charger disconnected**, must be greater than 30V **(if less than 30V this control will be dead)**
 - If not, your OBC may be in sleep mode. Put your cart on charge for 1 minute, disconnect then recheck. If you still do not have more than 30V at this pin, you may have an OBC issue.
- ☐ **Pin 9** Must be equal to Pack Voltage
 - If not Pack Voltage, check wiring, Sense Diode (if present), Run-Tow/Maintenance Switch or Fuse.
- ☐ **Pin 8** **With F/R Switch in Forward**, must equal Pack Voltage
 - If not Pack Voltage, check wiring and F/R Switch for an open condition.
- ☐ **Pin 16** **With F/R Switch in Reverse**, must equal Pack Voltage and Reverse Alarm should sound
 - If not Pack Voltage, check wiring and F/R Switch for an open condition.
- ☐ **Pin 7** **With F/R Switch in Reverse**, must equal 0V and Reverse Alarm should sound
 - If not 0V, check wiring and Reverse Alarm for an open condition.
- ☐ **Pin 10** **With Key On**, must equal Pack Voltage
 - If not Pack Voltage, check Key Switch for open condition.
- ☐ **Pin 12** Must equal Pack Voltage
 - If not Pack Voltage, check wiring and Main Solenoid Coil for an open condition
- ☐ **Pin 6** **With Pedal Up**, must equal 0V
 - If not 0V, check wiring and Pedal Switch for a shorted condition.
- ☐ **Pin 6** **With Pedal Down**, must equal Pack Voltage
 - If not Pack Voltage, check wiring and Pedal Switch for an open condition.
- ☐ **Pin 12** **With Pedal Down**, should equal approximately 0V
 - If not approximately 0V, check wiring and Main Solenoid Coil.
- ☐ **Pin 1** Must equal 5V
 - If not 5V, check wiring and check with MCOR removed – if voltage goes to 5V, replace MCOR.
- ☐ **Pin 3** Must equal 0V
 - If not 0V, harness and/or harness connector is defective, check wiring.
- ☐ **Pin 2** **With Pedal Up**, must approximately 0.3 volts
 - If not 0.3 volts, check wiring and MCOR
- ☐ **Pin 2** **With Pedal fully depressed**, must equal 4.15 to 4.45 volts
 - If not, check wiring and MCOR
- ☐ **Pin 15** Approximately 15-16 volts
 - If not, check wiring and check with Speed Sensor removed – if voltage goes to 15 volts, replace Speed Sensor
- ☐ **Pin 14** **While slowly turning the drive wheel**, must toggle between 0 and approx. 5 volts as Motor rotates.
 - If not toggling, check wiring and if necessary, replace Speed Sensor
- ☐ **Pin 4** Brake Pot Input (If equipped) **Approx. 0 – 5V** as brake pedal depressed
 - If not, check wiring and Brake Pot (if equipped)

TROUBLESHOOTING FAULT CODES

Fault	Causes/Resolutions	Fault	Causes/Resolutions
HW Failsafe	Internal Failure.	Overvoltage	Voltage is >68.4 - 75.6V. Faulty Batteries or shorted component to frame of cart. <i>Check batteries and for loose connection.</i>
Throttle Fault	Throttle Wiper < 0.2V or > 4.8V. Faulty wiring or MCOR. <i>Test MCOR.</i>		
Speed Sensor	Speed Sensor pulses not detected. <i>Test Speed Sensor.</i>	Low Battery	Voltage is <34V. Faulty Batteries or wiring. <i>Check batteries and for loose connection.</i>
Main Welded	Main contacts are welded closed. Possible shorted contactor or external B+ short. <i>Test Main Contactor.</i>	Thermal Cutback	Controller Heatsink > 85C. Possible brakes dragging, car under extreme loads or tire pressure issues. <i>Check for non-stock modifications and mechanical issues.</i>
Main Driver On	Main contacts detected closed when not commanded. Possible shorted contactor or external B+ short. <i>Test Main Contactor/controller.</i>	Motor Stall	Motor Current is high with no travel detected. Faulty motor or motor wiring. <i>Check motor, wiring and speed sensor.</i>
Main Driver Off	Main contacts detected open when commanded closed. Possible faulty contactor. <i>Test Main Contactor/controller.</i>	Main Dropout (1 and 2)	Main contacts opened when traveling. <i>Check Main Solenoid and wiring.</i>
Main Coil Open	Main Solenoid Coil not closing. Possible wiring issue, a defective solenoid coil or faulty suppression diode. <i>Test Main Contactor or wiring.</i>	Current Sense Fault	Motor Armature Current issue. <i>Check motor, wiring and speed sensor.</i>
Field Missing	Field current detected by controller is less than expected. Possible faulty Motor or Motor wiring. <i>Test Motor and wiring. Test controller.</i>	Main Driver Overcurrent	Current at Main Coil detected high. Faulty Solenoid Coil, wiring issue or incorrect solenoid. <i>Test Main Solenoid.</i>
HPD (High Pedal Disable)	Pedal is already depressed when key is turned ON. Faulty pedal switch or wiring. <i>Test pedal switch.</i>	M- Shorted	Voltage detected at M- Post of controller is lower than expected. Faulty motor, wiring or possible shorted controller. <i>Check motor Armature for open/short and motor wiring. Test controller.</i>

FSIP Electronics also offers the following Technical Support options ...



Troubleshooting Manuals / Codes
www.shop.fsip.biz/en/content/technical-documents

Live Tech Support Chat
www.shop.fsip.biz



Technical Support Forum
fsip.websitetoolbox.com

**PRE-INSTALLATION
INSTRUCTIONS MUST BE
FOLLOWED OR
WARRANTY WILL BE VOID**

IMPORTANT!

1515

**TROUBLESHOOTING INFORMATION
INCLUDED IN THIS PACKET**