



PRODUCT ACCESSORIES

(Not Included with TV)

Programming Remote	PD108-420
Patient Remote	PD108-421
100mm VESA Wall Mount	PD168-103
¼" to 6-Pin Jumper Cable	PD106-416
¼" to 6-Pin Jumper Cable	PD106-417

NOTE TO CABLE TV INSTALLER

This reminder is provided to call the cable TV systems installer's attention to Article 820-40 of the National Electrical Code. The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

WARNINGS



CAUTION: To reduce the risk of electric shock do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

This symbol is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This symbol is intended to alert the user of the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

OVERHEAD FALLING HAZARD



TV can pose a striking hazard when mounted at an elevated position. Use only PDI mounting brackets, support arms, and appropriate hardware to assure TV will not fall from the mounted position. Failure to do so may cause injury or death.

RAIN AND MOISTURE



WARNING: To avoid the hazards of fire or electrical shock, DO NOT expose this television to rain or moisture.

OXYGEN ENVIRONMENT



WARNING: Do not use in any oxygen tent or oxygen chamber. Such use may cause a fire hazard.

WET LOCATION



Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential or commercial installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MAINTENANCE AND SERVICING

Never remove the back cover of the TV; this can expose you to high voltage and other hazards. If the TV does not operate properly, unplug it and call an authorized service center or PDI.

CLEANING AND DISINFECTION

Clean the exterior of this television by removing dust with a lint-free cloth. CAUTION: To avoid damage to the surface of the television, do not use abrasive or chemical cleaning agents. Spot test a new disinfectant by applying a test cleaning a non-obvious small spot on the TV's back cabinet, keypad, and LCD panel. Allow the disinfectant to soak per its instructions and then wipe clean. Do not use the disinfectant if the TV's surfaces show any sign of discoloration or softening.

SERVICE INSTRUCTIONS

CAUTION: These servicing instructions are for use by qualified service personnel only.

To reduce the risk of electric shock, do not perform any servicing other than contained in the operating instructions unless you are qualified to do so.

PRODUCT MODIFICATION

Do not attempt to modify this product in any way without written authorization. Unauthorized modification could void the user's authority to operate this product.

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential or commercial installation. If this equipment does cause harmful interference to radio or TV reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Copyright

PDI Communication Systems, Inc. claims proprietary right to the material disclosed in this user manual. This manual is issued for user information only and may not be used to manufacture anything shown herein. Copyright 2009 by PDI Communication Systems, Inc. All rights reserved.

Disclaimer

The author and publisher have used their best efforts in preparing this manual. PDI Communication Systems, Inc. makes no representation or warranties with respect to the accuracy or completeness of the contents of this manual and specifically disclaim any implied warranties or merchantability or fitness for any particular purpose and shall in no event be liable for any loss of profit or any other damages. The information contained herein is believed to be accurate, but is not warranted, and is subject to change without notice or obligation.

Trademarks

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. All other brand names and product names used in this manual are trademarks, registered trademarks, or trade names of their respective holders. PDI and Better Solutions Are Within Reach are registered trademarks of PDI Communication Systems, Inc., Springboro, Ohio.

NOTE TO CABLE TV INSTALLER

This reminder is provided to call the cable TV systems installer's attention to Article 820-40 of the National Electrical Code. The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.

LOCATION GUIDELINES

The model PDI-P23LCDD Hospital Grade LCD TV is a specialized LCD TV. This TV is intended for entertainment and educational purposes for use in a hospital, a nursing home, a medical-care center, or a similar health-care facility in which installation is limited to a non-hazardous area in accordance with the National Electrical Code, ANSI/NFPA 70. The PDI-P23LCDD is designed for mounting to PDI manufactured mounts. Installation of the TV on any other mount is not recommended.



WARNING: The TV's VESA mounting holes are designed for M4 metric screws only. Use of a non-PDI approved mount or SAE hardware could result in a condition where the TV could unexpectedly fall and cause injury or death.

The PDI-P23LCDD TV mounts to the wall typically at the foot of a patient's bed with the supplied bracket. Select a location that is near an AC wall outlet and that does not expose the TV to bright room lights or sunlight if possible. The LCD TV also requires connection of both CATV cable signal and across-room wiring for the pillow speaker.

OSHPD (State of California Only)

The combined weight of the PDI-P23LCDD TV and PDI wall mount is less than 20 pounds. At the time of this writing, the involvement of a written, submitted, reviewed, and approved plan by OSHPD is not required to install the PDI-P23LCDD TV in the state of California.

Energy Star

The PDI-P23LCDD TV is ENERGY STAR qualified in its factory default setting. PDI Communication, an Energy Star Partner, has determined that this product meets energy efficiency guidelines. Changes to certain features, settings, and functionalities of the TV can change the amount of power it consumes. The changes could possibly set the amount of power consumption beyond the limits required for ENERGY STAR qualification.



Wall Mounting

NOTE: Across-Room Wiring may need to be completed before mounting the TV. (See Across-Room Wiring diagram on page 4)

1. Refer to Figure 1. Select a location on the wall approximately 7 ½ inches below the ceiling.

NOTE: DO NOT locate AC, Across-Room Wiring, and CATV Signal outlets below the Wall Bracket's location as it will cause clearance issues and interfere with the TV's cabinet when mounted to the bracket. Position the Wall Bracket and locate two mounting holes. Secure the bracket to the wall (mounting hardware is not included).

2. Refer to Figure 2. Position the Back Mount on the LCD TV cabinet. Attach with four M4 screws provided.
3. Mate the Back Mount to the Wall Bracket making sure the pivot pins are retained in the "U" shaped slot. Using the pilfer security driver packed with the hardware, secure with two 10x32 pilfer screws.
4. Connect the AC line cord, Pillow Speaker Jumper Cable, and CATV Coax Cable.
5. The TV's tilt can be adjusted by loosening both Pilfer Screws, adjusting tilt, and then tightening the screws.






Figure 1

Figure 2



Across-Room Wiring

A ¼" stereo style pillow speaker (pendant control) jack is located on the TV's connector panel on the backside. This TV is designed to work with either a digital pillow speaker that generates digital style control codes or a single-button analog (switch-style) pillow speaker. A rear panel mounted switch allows use of different brands of pillow speakers and supports the major brands: Zenith, Philips, and RCA.



CAUTION: Confirm the pillow speaker type and set the side switch appropriately BEFORE connecting the pillow speaker to the TV. Failure to follow this procedure could result in damage to the pillow speaker or cause improper operation of the TV.

Pillow Speakers

The pillow speaker (pendant control) jack is located on the TV's connector panel. Control of the TV using an externally wired pillow speaker is possible.

1. Select the appropriate brand of digital pillow speaker using the recess slide switch next to the PILLOW jack.

CZ for Zenith®

CP for Philips®

CR for RCA®

OFF to disable the pillow speaker


For analog style pillow speakers set the switch to CZ, CP, or CR.

NOTE: The TV is shipped from the factory with the switch in the OFF position.

2. Connect the pillow speaker to the PILLOW jack.

3. Operate the pillow speaker and verify correct control.

Antenna “ANT” Connection



Hospital Coax Cable



CAUTION: Some hospital cable systems provide power voltage on the coaxial cable. This TV is **NOT** designed to be powered via a coaxial cable. DO NOT connect to a powered coaxial cable. Damage will result to the TV.

Connections



1 AC INPUT

AC power cord connection.

2 A/V IN

Connect these outputs to the Audio/Video inputs of external equipment.

NOTE: Connections are color-coded.

3 S-VIDEO IN

If the external equipment you are connecting has an S-VIDEO jack, you can use an S-VIDEO cable for improved picture quality.

NOTE: Audio connections are color-coded.

4 COMPONENT2 IN and 5 COMPONENT1 IN

The TV supports two inputs for devices, such as a DVD that offer Component type signals.

NOTE: Some device's Y/Pb/Pr connections might be labeled as Y/Cb/Cr or Y/B-Y/R-Y. Connections are color-coded.

6 ANT

Connection to Cable TV Coax.

NOTE: See page 11

7 SVC

Service port.

8 PC ANALOG IN (D-SUB)

Connection to the video output jack on your PC. See resolutions in Appendix on page 42.

9 SPDIF

Provides a digital audio output signal for connecting to an external digital audio device.

10 AUDIO OUT

Connection for external audio amplifier or speakers.

11 HDMI1 IN and 12 HDMI2 IN

Connection for HDMI devices.

13 USB PORT

Firmware upgrading and cloning purposes.

NOTE: See firmware updating and cloning instructions starting on page 37.

14 MTI

Used to connect to LodgeNet

15 CCI

16 PILLLOW

Pillow speaker port.

NOTE: See page 11 before connecting

Programming

A programming remote control is required to perform all setup operations for the TV. The programming remote (Part Number: PD108-420) is NOT packaged with the TV and must be ordered separately. The following instructions assume you have a programming remote, have correctly mounted the TV, wired an external pillow speaker, and connected an RF coax cable signal.

TV Setup

The first step in configuring the P23 is to set up the channels. There also are several sound settings that need to be verified or changed.

Channels

The TV offers three different programmable channel banks or Service Levels. Only one Service Level is usable at a time.

Setup			Channels		
■ Service Level		Free	■ Signal		Cable STD
■ Picture		▶	■ Auto Program		▶
■ Sound		▶	■ Add/Delete Channels		▶
■ Channels		▶	■ Clear Service Level		▶
■ Features		▶	■ Copy Service Level		▶
■ OSD Language		English	■ Parental Control		▶
■ Sources		▶	■ Power on Channel		▶
■ FM RADIO		▶	■ Channel Lock		Disabled
			■ Channel Memory Override		Enabled
Position: ▲ ▼			Position: ▲ ▼		
Exit: SETUP			Exit: SETUP		
Next: ◀ ▶			Next: ◀ ▶		

Four different tuning types are available depending upon the healthcare facilities' signal style. Selection of the correct signal type is required for the TV to recognize all possible channels and before any channel programming can begin.

1. Press the SETUP button to display the Setup menu.
2. Press the ▲ or ▼ button to highlight Channels.
3. Press ▶ to select it.
4. Press the ▲ or ▼ button to highlight Signal.
5. Press ◀ or ▶ to select Air, Cable STD, Cable IRC or Cable HRC.

NOTE: Most hospitals use the Cable STD signal style.

Sound

Most hospital installations utilize a remotely wired pillow speaker. The following instructions customize the sound to the attached pillow speaker.

Internal Speaker Enable

The speaker's inside the TV's cabinet are normally silenced and sound is routed externally to the attached pillow speaker.

Sound	
■ Balance	25
■ Minimum Volume	100
■ Maximum Volume	100
■ Power on Volume	Last
■ Internal Speaker Enable	▶
■ HDMI 1 Audio Port	HDMI 1
■ HDMI 2 Audio Port	HDMI 2
■ Composite/S-Video Sound Mode	L+R
Position: ▲ ▼	
Exit: SETUP	
Next: ◀ ▶	

Internal Speaker Enable	
■ TV Free Service Level	Enabled
■ TV Basic Service Level	Enabled
■ TV Premium Service Level	Enabled
■ Composite Video	Enabled
■ S-VIDEO	Enabled
■ Component 1	Enabled
■ Component 2	Enabled
■ HDMI 1	Enabled
■ HDMI 2	Enabled
■ PC-ANALOG	Enabled
■ FM RADIO	Enabled
Position: ▲ ▼	
Exit: SETUP	
Next: ◀ ▶	

1. Press the ▲ or ▼ button to highlight Sound. (Sound is in the main Setup menu. If you are not in the main Setup menu, press SETUP on the remote.)
2. Press ▶ to select it.
3. Press ▲ or ▼ to highlight Internal Speaker Enable.
4. Press ▶ to select it.
5. Press ▲ or ▼ to highlight the desired Service Level (Free, Basic, or Premium).
6. Press ◀ or ▶ to select Disabled and turn off the TV's internal speakers.
7. Press the SETUP button to return to the preceding menu.

Minimum Volume

For pillow speakers with an adjustment thumbwheel volume control, always set a minimum volume level for the TV. Setting this level to any value other than 0 guarantees that some level of sound will always be heard when the TV is operating. A minimum volume setting is usually not required for pillow speakers with dedicated Volume up and down buttons.

1. In the Sound menu, press ▲ or ▼ to highlight Minimum Volume.
2. Press ◀ or ▶ to select your preferred minimum volume the TV is allowed to reach. (0-100)
3. Press the SETUP button to return to the preceding menu.

Power On Volume

Sets the initial volume the TV starts upon powering on. Once the TV is on, the volume can be set to any allowable level.

1. In Sound menu, press the ▲ or ▼ button to select Power on Volume.
2. Press ◀ or ▶ button to set the volume when the TV turns on.

NOTE: Setting the level to LAST causes the TV to revert to the last volume level prior to the TV turning off.

3. Press the SETUP button to return to the preceding menu.

Cloning



If you want to program multiple P23 TVs the same way, cloning is the quickest way of doing this. The cloning operation involves first downloading setup information from a programmed host TV to a USB thumb drive and then uploading the setup information to another TV. Cloning can also be used to re-program a programmed TV.

Save Settings to USB

1. Using a computer, create a folder called "PDITDF" on a USB thumb drive.
2. Turn on the TV.
3. Insert the USB thumb drive into the cloning port in the back of the TV. A Cloning Main Menu will appear on the TV screen.



4. Press ▲ or ▼ to highlight Save Settings to USB.
5. Press ► to display the Save Settings to USB menu.





6. If you want to rename the file, press the ▲ or ▼ to highlight the file name. Otherwise go to step 7.
 - a. Press ◀ or ▶ to highlight each character.
 - b. Press ▲ or ▼ to change each character.
 - c. Repeat this process until you have the desired file name. Up to 8 characters may be used.
 - d. When done, press ◀ until the characters are no longer highlighted.
7. Press ▲ or ▼ to highlight Save.
8. Press ► to download the TV's setup to the USB thumb drive. A progress screen will be displayed.



9. Press ◀ to return to the Cloning Main Menu.
10. Remove the USB drive to return to normal TV operation.

Restore Setting to TV



1. Press ▲ or ▼ to highlight Restore Settings to TV.
2. Press ▶ to display a list of previously stored TV setups on the USB thumb drive.
3. Press ▲ or ▼ to highlight the desired setup file.
4. Press ▶ to select it.
5. A confirmation screen will appear. Press ▲ to restore the selected setup file or press ◀ to return to the previous menu without restoring. A progress screen will appear as the settings are restored.
6. The TV will return to the Cloning Main Menu after restoring is complete.
7. Remove the USB thumb drive.

Additional Information

Additional information is available in the user manual. Please request document number: PD196-158.

CLEANING AND DISINFECTION

Clean the exterior of this television by removing dust with a lint-free cloth. **CAUTION:** To avoid damage to the surface of the television, do not use abrasive or chemical cleaning agents. Spot test a new disinfectant by applying a test cleaning a non-obvious small spot on the TV's back cabinet, keypad, and LCD panel. Allow the disinfectant to soak per its instructions and then wipe clean. Do not use the disinfectant if the TV's surfaces show any sign of discoloration or softening.

SERVICE INSTRUCTIONS

CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than contained in the operating instructions unless you are qualified to do so.

PRODUCT MODIFICATION

Do not attempt to modify this product in any way without written authorization. Unauthorized modification could void the user's authority to operate this product.

Important Safety Instructions

Important safeguards for you and your new product.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat source such as radiators, heat registers, stove, or other apparatus (including amplifiers) that produces heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long period of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. *Use only PDI mounts and appropriate hardware. Failure to do so could cause the set to fall and subsequent injury or death.*

