Display Use & Maintenance


SW-LCD display

OPEN:Mode/M 1.5 seconds long press.

CLOSE:In standby mode, long press Mode/M for 3 seconds

SETTING: After booting, press UP+DOWN for 2.5 seconds(exit in the same way)

The detailed settings are as follows:(on the boot state)




Wheel Diameter Setting:

1. UP or DOWN

2.16-28inch (Default 26inch)


3. Select, Mode Confirm



Speed Setting:

1. UP or DOWN 2.12-45 KM/H


3. Select, Mode Confirm



Light Setting:

1. UP or DOWN

2.1-3 (Brightness) 3. Select, Mode Confirm



MPH/KM Setting:

1.UP or DOWN

2.MPH or KM/H


3. Select, Mode Confirm

SPEED Setting:

1.UP or DOWN For 3 seconds 1.PRESS Mode/M

2.MAX/AVG/NOW


3.Select, Mode Confirm



RANGE Setting:

2.Riding mileage / accumulat-

ed total mileage



Front Light Open:

1.Exit Settings 2.UP FOR 3 Seconds

4.Default: 1

3.Front lamp will work

Power Shift Setting:

1.Exit Settings 2.UP/DOWN 3.1-5 (Power)

4.Default: 1

Cruise Mode Setting:

1.Exit Settings

2.PRESS DOWN FOR 3 Seconds


3.Default: 6KM/H

4. Pushing state, non riding

- Ride your bike in a safe way. Don't hit or knock the display.
- Keep away from the bad environments when use, such as downpour, large snowflakes and solarization.
- Try not to use in under-voltage condition.
- The screen will gets dark along with the temperature reduction when temperature below -10°C. The screen will return to normal when the temperature rises again.

— 4 **—**

Controller Use & Maintenance



- 1) Battery negative connection line
- ② Battery positive connection line
- 3 Phase line EROR 23
- 4 Tail light wire
- ⑤ Integrated main line
- 6 Power sensor line
- Motor Hall plug wire
- 1. Please be careful not to get water into the controller box
- 2. When the bike does not work: 1) Check the connection of controller cables;
- 2) Try to restart or Replace the controller; 3)Contact us with email

Motor Maintenance





- 1. Please check the integrity of motor blocking piece regularly.
- 2. Please check the integrity of cable before and after riding.
- 3. Please check the integrity of motor shell before and after riding.
- 4. Please do not use the motor in extreme environments, and do not let the motor work in water.
- 5. When you find the motor power is insufficient, please get out of the bike and not force it.

FAQ

- Is there a power usage or battery gauge on the bike?
- Yes, there is a full screen LCD display. There is also an additional LED battery gauge on the side of the battery pack. 2x the info!
- Is there a switch to prevent accidental starting?
 - Yes, there is an on/off button on the battery pack. The brake levers also come standard with a safety power stop switch built in.
- How do I lock it up and what can I do to help minimize the chance of it being stolen?

AOSTIRMOTOR Bike has some great anti-theft features, including a locking battery rack with keys to keep bike safe, and rear wheel which is bolted down reduce the chances to be stolen.

Most standard U-locks and cable locks work fine on our AOSTIRMOTOR Ebike.

Does it work in the rain?

The components are all waterproof and work very well in wet conditions, But we do not suggest to use our ebike in a rain day.

We suggest that you should keep your bike parked indoors and keep him in a dry situation.

— 5 —

AUSTIRMOTOR

Manual

750W



POWER BRINGS JOY

www.AOSTIRMOTOR.com aostirmotor@gmail.com

