

Installation Guide

Electronic controller **MCX08M2** with TTL







General features:

MCX08M2 is an electronic controller that holds all the typical functionalities of MCX controllers in the compact size of 8 DIN modules: programmability, connection to the CANbus local network, Modbus RS485 serial communication interface.

MCX08M2 with TTL version is moreover available in the version with display and power supply $110-230\ V$ AC.

	MCX08M2 with TTL
ANALOG INPUTS	
NTC, 0/1 V, 0/5 V, 0/10 V, PT1000, selectable via software	4
Universal NTC, Pt1000, 0/1 V, 0/5 V, 0/10 V, ON/OFF, 0/20 mA, 4/20 mA, selectable via software	4
Total number	8
DIGITAL INPUTS	
Voltage free contact	8
Total number	8
ANALOG OUTPUTS	
0/10 V DC optoinsulated	2
0/10 V DC, PWM, PPM selectable via software	2
Total number	4
DIGITAL OUTPUTS	
SPST relay 16 A (normally open contacts)	2
SPST relay 8 A (normally open contacts)	2
SPDT relay 8 A (changeover contacts)	4
Total number	8
OTHERS	
Power supply 110 V / 230 V AC	•
Connection for programming key	•
Connection for remote display and keyboard	•
Buzzer	•
CANbus	•
RTC clock	•
Modbus RS485 serial interface	•
Serial TTL	•
Dimensions (DIN modules)	8
Mounting	DIN rail





General features and warnings

Plastic housing features

- DIN rail mounting complying with EN 60715
- Self extinguishing V0 according to IEC 60695-11-10 and glowing/hot wire test at 960 °C according to IEC 60695-2-12
- Ball test: 125 °C according to IEC 60730-1. Leakage current: ≥ 250 V according to IEC 60112

Other features

- Operating conditions CE: -20T60 / UL: 0T55, 90% RH non-condensing
- Storage conditions: -30T80, 90% RH non-condensing
- To be integrated in Class I and/or II appliances
- Index of protection: IP40 only on the front cover
- Period of electric stress across insulating parts: long
- Suitable for use in environments with degree of pollution 2
- · Category of resistance to heat and fire: D
- Immunity against voltage surges: category II
- · Software class and structure: class A

Compliance

This product is designed to comply with the following EU standards:

- Low voltage directive LVD 2014/35/EU:
 - EN60730-1: 2011 (Automatic electrical control for household and similar use. General requirements)
 - EN60730-2-9: 2010 (Particular Requirements for Temperature Sensing Controls)
- Electromagnetic compatibility EMC directive 2014/30/EU:
 - EN 61000-6-3: 2007 +A1: 2011 (Emission standard for residential, commercial and light-industrial environments)
 - EN 61000-6-2: 2005 (Immunity for industrial environments)
- RoHS directive 2011/65/EU and 2015/863/EU:
 - EN50581: 2012

UL approval:

UL file E31024

General warnings

- · Every use that is not described in this manual is considered incorrect and is not authorised by the manufacturer
- Verify that the installation and operating conditions of the device respect the ones specified in the manual, specially concerning the supply voltage and environmental conditions
- This device contains live electrical components therefore all the service and maintenance operations must be performed by qualified personnel
- The device can't be used as a safety device
- Liability for injury or damage caused by the incorrect use of the device lies solely with the user

Installation warnings

- Mounting position recommended: vertical
- The installation must be executed according the local standards and legislation of the country
- · Always operate on the electrical connections with the device disconnected from the main power supply
- Before carrying out any maintenance operations on the device, disconnect all the electrical connections
- For safety reasons the appliance must be fitted inside an electrical panel with no live parts accessible
- Don't expose the device to continuous water sprays or to relative humidity greater than 90%. Avoid exposure to corrosive or pollutant gases, natural elements, environments where explosives or mixes of flammable gases are present, dust, strong vibrations or chock, large and rapid fluctuations in ambient temperature that in combination with high humidity can condensate, strong magnetic and/or radio interference (e.g. transmitting antennae)
- When connecting loads beware of the maximum current for each relay and connector
- Use cable ends suitable for the corresponding connectors. After tightening the screws of connectors, slightly tug the cables to check their tightness
- Use appropriate data communication cables. Refer to the Fieldbus Installation Guide for the kind of cable to be used and setup recommendations
- Reduce the path of the probe and digital inputs cables as much as possible, and avoid spiral paths enclosing power devices. Separate from inductive loads and power cables to avoid possible electromagnetic noises
- Avoid touching or nearly touching the electronic components fitted on the board to avoid electrostatic discharges

DISCLAIMER: Professional Use Only

This product is not subject to the UK PSTI regulation, as it is for supply to and use only by professionals with the necessary expertise and qualifications. Any misuse or improper handling may result in unintended consequences. By purchasing or using this product, you acknowledge and accept the professional-use-only nature of its application. Danfoss does not assume any liability for damages, injuries, or adverse consequences ("damage") resulting from the incorrect or improper use of the product and you agree to indemnify Danfoss for any such damage resulting from your incorrect or improper use of the product.



Disposal instruction

Equipment containing electrical components may not be disposed together with domestic waste. It must be separately collected with electrical and electronic waste according to local and valid legislation.




Technical specifications

Power supply

- 85 265 V AC, 50/60 Hz. Maximum power consumption: 20 VA. Insulation between power supply and the extra-low voltage: reinforced
- 20-60 V DC e 24 V AC \pm 15% 50/60 Hz SELV. Maximum power consumption: 10 W, 17 VA. Insulation between power supply and the extra-low voltage: functional

I/O	ТҮРЕ	NUM	SPECIFICATIONS		
Analog inputs	NTC 0 / 1V 0 / 10V PT1000	4	AI5, AI6, AI7, AI8 Analog inputs selectable via software between: • $0/1 \text{ V}$, $0/5 \text{ V}$, $0/10 \text{ V}$: impedance is greater than $1\text{M}\ \Omega$ • NTC ($10\text{ k}\Omega$ at 25 °C) • Pt1000		
	Universal	4	 Al1, Al2, Al3, Al4 Universal analog inputs selectable via software between: ON/OFF (current: 20 mA) 0/1 V, 0/5 V, 0/10 V: impedance is greater than 1M Ω 0/20 mA, 4/20 mA NTC (10 kΩ at 25 °C) Pt1000 12 V+ power supply 12 V DC, 120 mA max for 4/20 mA transmitter (total on all outputs) 5 V+ power supply 5 V DC, 100 mA max for 0/5 V transmitter (total on all outputs) 		
Digital input	Voltage free contact	8	DI1, DI2, DI3, DI4, DI5, DI6, DI7, DI8 Current consumption: 10 mA		
Analog outputs	0 / 10 V DC optoins	2	AO3, AO4 • Analog outputs optoinsulated 0/10 V DC minimum load 1K Ω (10 mA) for each output		
	PWM PPM 0/10VDC	2	 AO1, AO2 Analog outputs selectable via software between: 0/10 V dc minimum load 1K Ω (10 mA) for each output pulsing output, synchronous with the line, at modulation of impulse position (PPM) or modulation of impulse width (PWM) pulsing output, at modulation of impulse position (PPM) with range 20 Hz to 1 KHz: open circuit voltage: 6.8 V 		
Digital output	Relay	8	Insulation between relay: functional Insulation between relays and the extra-low voltage parts: reinforced Total current load limit: 32 A C1-NO1, C2-NO2 High inrush current (80 A - 20 ms) normally open contact relays 16 A Characteristics of each relay: 10 A 250 V AC for resistive loads - 100.000 cycles 3.5 A 230 V AC for inductive loads - 230.000 cycles with cos(phi) = 0.5 C5-NO5, C6-NO6 Normally open contact relays 8 A Characteristics of each relay: 6 A 250 V AC for resistive loads - 100.000 cycles 4 A 250 V AC for inductive loads - 100.000 cycles with cos(phi) = 0.6 C3-NO3-NC3, C4-NO4-NC4, C7-NO7-NC7, C8-NO8-NC8 Changeover contacts relay 8 A Characteristics of each relay: 6 A 250 V AC for resistive loads - 100.000 cycles 4 A 250 V AC for resistive loads - 100.000 cycles 4 A 250 V AC for inductive loads - 100.000 cycles 4 A 250 V AC for inductive loads - 100.000 cycles with cos(phi) = 0.6		







Connection

Connectors	Туре	Dimensions
Top Board		
Analog output 1-4 connector	7 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Analog input 1-4 connector	11 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Digital input 1-8 connector	10 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Analog input 5-8 connector	5 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
TTL connector (only for 080G0335)	5 way spring plug-in connector type	 pitch 2.5 mm section cable 0.2 – 2.5 mm²
Bottom Board		
Power supply connector	2 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
CAN connector	4 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
CAN-RJ connector	6/6 way telephone RJ12 plug type	
RS485 connector	3 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Digital output 1-2 connector	4 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Digital output 3-4 connector	6 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Digital output 5-6 connector	4 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²
Digital output 7-8 connector	6 way screw plug-in connector type	 pitch 5 mm section cable 0.2 – 2.5 mm²

User interface

LCD Display

Display mode: STN blue transmissive

Backlight: white LED backlight adjustable via software

Display format: 128 x 64 dots Active visible area: 58 x 29 mm Contrast: adjustable via software

Keyboard


Number of keys: 6

Keys function is settled by the application software

Display settings adjustment

Setting of the LCD display like contrast and brightness might need to be adjusted due to external ambient factors. Press and release simultaneously the Enter and X key after power ON to access the BIOS menu and select the DISPLAY menu. Use UP and DOWN arrow keys to adjust the contrast or the brightness of the display at the desired level.

Dimensions





Product part numbers

Description	Code No.
MCX08M2, 230 V, LCD, RS485, TTL, Single Pack	080G0335

Accessories part numbers

Description	Code No.
MCX08M CONNECTORS KIT	080G0180

Via San Giuseppe 38/G 31015 Conegliano

(TV) Italy Tel: +39 0438 336611 Fax: +39 0438 336699 in fo.mcx@dan foss.comwww.danfoss.com

Danfoss A/S

Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.