

DVR 620v2 Digital Video Camera

User Manual



© 2010 Sakar International, Inc. All rights reserved.

Windows and the Windows logo are registered trademarks of Microsoft Corporation.

All other trademarks are the property of their respective companies.

Contents

Introduction	2
What Your Camera Includes.....	2
Parts of the Camera	3
Initial Camera Setup.....	4
Main Camera Modes	5
Camera Technical Specifications.....	7
Computer System Requirements – Windows.....	8
Computer System Requirements – Macintosh	8
Using Your Digital Camera	9
Changing Camera Mode	9
Navigating the Menus.....	10
Video Capture Mode	11
Video Playback Mode.....	13
Photo Capture Mode	17
Photo Playback Mode	19
Connecting the Camera to a TV	23
Installing the Software	24
Connecting the Camera to the Computer.....	25
Getting Photos and Videos from your Camera to Your Computer	26
Get started!.....	27
Transfer media from my camera to my computer manually (Using Windows).....	27
Transfer media from my camera to my computer manually (Using Macintosh).....	28
Camera Maintenance	28
Sakar Warranty Card.....	29
Technical Support.....	30
Troubleshooting.....	30

Introduction

Thank you for purchasing this camera. Everything you need to take quality digital photos and videos is included with your camera.

Vivitar makes capturing those special moments as easy as possible.

Note: Your camera needs an SD Memory card (up to 16GB) for normal use.

SD Memory cards are not included and need to be purchased separately.

Please read this manual carefully first in order to get the most out of your digital camera.

What Your Camera Includes

1. Digital Video Camera
2. AV Cable
3. Vivitar Experience Image Manager software Installation CD
4. Wrist Strap



Note: SD Memory Card not included

Parts of the Camera




- | | |
|------------------|-------------------|
| 1. Power Button | 12. USB Connector |
| 2. Delete | 13. TV Out Port |
| 3. Menu | 14. Strap Hole |
| 4. Mode | 15. Tripod socket |
| 5. Shutter | 16. USB ejector |
| 6. Up/Zoom In | 17. LED Light |
| 7. Down/Zoom Out | 18. Lens |
| 8. Left | 19. Speaker |
| 9. Right | 20. Microphone |
| 10. LCD Screen | 21. Battery Cover |
| 11. SD Card Slot | |

Initial Camera Setup

Installing the Batteries



Installing the Memory Card



Turning On the Camera




Using the Camera



When powering the camera ON **for the first time** the camera will take you through the initial camera setup.

Powering the Camera ON

- 1) Make sure the batteries have been inserted properly into your digital camera.
- 2) Make sure an SD card has been inserted into your camera.
- 3) Press the POWER  button to turn on the camera.

Setting the Camera Language

- 1) You will first be prompted to select a language for the camera. The Language selection menu will appear. Select the language of your choice and press the **Shutter/OK** button to confirm the selection.
- 2) After selecting a language, you will be asked if you would like to continue with the initial camera setup. A message will appear: “Continue with Camera Setup?” Select “Yes” to continue or “No” to exit the setup.

Note: If you select “No” and decide to leave the camera setup, the camera will be set to its default settings. These settings can be adjusted at any time manually through the menus in the camera.

Main Camera Modes

Your camera has different modes for the various camera functions.

You can switch modes by pressing the **MODE** button on your camera after the camera has been powered ON.



Video Capture Mode

Use this mode to capture videos with your digital camera.

This is the default mode when the camera is powered ON.

To take a video, aim your camera as desired and press the **Shutter** button to start the record. A red record indicator will appear on the LCD screen while record is in progress. To stop the record, press the **Shutter** button again. The video will be automatically saved to your camera's memory card.

To access the various menus for the Video Capture mode, press the **Menu** button while in the Video Capture mode.



Photo Capture Mode

Use this mode to capture pictures with your camera.

After turning on your camera, press the **MODE** button once to open the Photo Capture mode.

To take a picture, aim your camera as desired and press the **Shutter** button.

The picture will be automatically saved to your camera's memory card.

To access the various menus for the Photo Capture mode, press the **Menu** button while in the Photo Capture mode.



Playback Mode (Photos & Videos)

Use this mode to view and manage the photos and videos on your camera.

After turning on your camera, press the **MODE** button twice to open the Playback mode for photos and videos. You can scroll through the photos and videos that you've previously taken to view and delete them as desired.

To access the various menus for the Playback mode for photos and videos, press the **Menu** button while in the Playback mode.

Camera Technical Specifications

Image Sensor	CMOS Sensor
Image Resolution	(5M) 2592x1944 pixels, (3M) 2048x1536 pixels
Video Resolution	640X480pixels (30fps), 320X240pixels (30 fps)
File Format	JPEG/AVI
External Memory	SD Card (up to 16GB) – SD Card not included
LCD Display	1.8 Inch TFT ; the LCD screen opens up 180 degree
Lens	f=3.0mm F2.8
Zoom	4X Digital Zoom
Scene	Auto
Image Quality	Normal
White Balance	Auto
Color Effect	Standard
Light Exposure	Auto
ISO	Auto
Frequency	60 Hz
Auto Power Off	3 minutes
Metering	Center
Language	English, French
Microphone	Yes
Speaker	Yes
Interface	USB 2.0 (HS)
System Requirements	Windows XP and above / Mac OSX 10.5 and above
Battery	2 x AA alkaline batteries
Working Temperature	0~40 °C

Computer System Requirements – Windows

To be able to download photos and videos to your PC, you will need the following minimum configuration:

- Pentium 4 processor or above with Windows XP service pack 2, Windows Vista or Windows 7
- 512 MB RAM, with 100MB of free disk space
- 1024 x 768 Recommended screen resolution
- 16-bit color or higher display adaptor
- CD-ROM Drive
- QuickTime 6 or higher
- Microsoft Internet Explorer 7 or higher
- Windows Media Player 10 or higher
- Internet connection required

Computer System Requirements – Macintosh


Macintosh with Intel processor running Mac OS X v10.5 or later

- 256 MB RAM, 100 MB free disk space
- Display: 1024 x 768 or higher-resolution monitor
- QuickTime 6 or higher
- Internet connection required


Using Your Digital Camera

- Make sure the batteries have been inserted properly into your digital camera.
- If your camera comes with a rechargeable lithium battery, make sure it is fully charged before the first use.
- Make sure an SD card has been inserted into your camera.
(SD card up to 16GB - SD Card not included)

Powering the camera ON

Press the Power button  to turn your camera ON. The camera will be in Video Capture mode to start.

Powering the camera OFF

While the camera is on, you can press the Power button  again at any point to turn your camera OFF. You will see a “Goodbye” splash screen and then the camera will power off completely.

Note: When there is insufficient battery power, a “Low Battery” message will appear on the LCD screen. The camcorder will automatically power off a few moments later.

Auto Power Saving

Your digital camera has an Auto Power Off feature that will automatically turn off the camera if it has not been in use after 3 minutes.

Changing Camera Mode

Your camera has three main modes:

- 1) **Video Capture Mode** - Use this mode to capture videos with your camera.
- 2) **Photo Capture Mode** - Use this mode to capture photos with your camera.
- 3) **Playback Mode (for photos and videos)** - Use this mode to view the photos and videos you have already taken with your camera.

When the camera is first powered ON, the Video Capture Mode will be active. The icons that appear on the LCD screen are the best default settings so that you can begin to capture and enjoy clear quality videos and photos.

To change the active camera mode, make sure the camera is powered ON and press the **MODE** button.



When in Video Capture Mode, this icon will display on the top-left corner of the LCD display




When in Photo Capture Mode, this icon will display on the top-left corner of the LCD display



When in Playback Mode, this icon will display on the top-left corner of the LCD display


Navigating the Menus

Each camera mode has a set of menus specific to that mode.


- 1) Press the **MENU** button to open the menus for the current mode.
- 2) Press the **LEFT** or **RIGHT** direction control buttons to scroll between the various menus for the current mode.
- 3) Press the **UP** or **DOWN** direction control buttons to highlight the desired menu selection.
- 4) Press the **Shutter/OK** button to confirm and select the highlighted menu option.
- 5) If the selection can be remembered by the camera, a  selection icon will appear to the right of the selected menu option. Changes made to these options will remain as is until you decide to change them again at a later time.
- 6) Some menu options are single-use functions that are not remembered by the camera and do not display this icon when selected.
- 7) At any time you can press the **MODE** button to exit the menus and return to the previous screen.

Video Capture Mode

The Video Capture Mode allows you to capture videos with your digital camera. When the camera is first powered ON, the camera will display by default.







Taking a Video

- 1) While in Video Capture Mode use the LCD display to direct the camera at the scene you would like to capture.
- 2) Click the **UP - Zoom In** and **Down - Zoom Out** buttons to better set the camera display if desired.
- 3)  Press the **Shutter** button to start the video capture.
- 4) The elapsed time will begin to appear on the top right corner of the LCD screen and a red indicator will appear in place of the video icon on the screen.
- 5) To stop the video record, press the **Shutter** button again.
- 6) The video will automatically be saved to the camera's SD card.
- 7) You can also capture your videos using the Flip Screen. The LCD screen opens 180 degrees to allow Self Portrait image capture. When you would like to quickly and easily include yourself in the video, simply flip the LCD display out and hold out the front of camera facing towards you. Make sure you can see yourself within the scene on the LCD screen and click the **Shutter** button to begin the recording. It's as easy as twist and shoot!

Video Capture Mode Quick Function Buttons

Your digital camera has a four-directional pad and additional buttons that functions as Quick Function buttons.

Button	Function
 LEFT	-
 UP	Zooms in
 RIGHT	-
 Down	Zooms out
Shutter/OK	Starts and stops your video capture
Delete	<ul style="list-style-type: none">- Allows you to delete last video taken by opening the 'Delete This Video' option- Allows you to select the Language when holding down the button for 2 seconds
Menu	Opens the Video Menu options

Video Capture Mode Menus

The following are the menus that appear in your camera's Video Capture Mode:





Image Resolution Menu


The Image Resolution menu allows you to choose the desired size of the images taken by your camera. Keep in mind that images with a larger size will also take up more of your camera's memory.

- 1) Press the **MENU** button to open the menus for the current mode.

- 2) Press the **LEFT** or **RIGHT** direction control buttons to scroll and select the chosen menu.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) Press the **Shutter/OK** button to select the desired option.
- 5) A  selected option icon will appear on the selected item.
- 6) Press the **LEFT** or **RIGHT** button to select the next menu item.
- 7) Press the **MODE** button to exit the menu and return to your previous mode.
- 8) An icon reflecting your selection will display on the LCD screen.
- 9) Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.


Language Menu

You can select your camera's language setting by selecting the desired language from the Language menu.

- 1) Press the **MENU** button to open the menus for the current mode.
- 2) Press the **LEFT** or **RIGHT** direction control buttons to scroll and select the chosen menu.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) Press the **Shutter/OK** button to select the desired option.
- 5) A  selected option icon will appear on the selected item.
- 6) Press the **LEFT** or **RIGHT** button to select the next menu item.
- 7) Press the **MODE** button to exit the menu and return to your previous mode.
- 8) Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.


Video Playback Mode

When you first turn on the camera, the camera will be in Video Capture mode by default. Press the **MODE** button twice to open the **Playback** Mode. The Playback mode will allow you to review and delete photos and videos that you've already taken with you camera.





The Playback screen appears with the Playback  icon appearing on the top left corner of the screen.



Playing Captured Videos on Your Camera

- 1) Press the **LEFT/Right** buttons to select the image you wish to view.
- 2) A **Video** file appears with a Video icon  on the bottom left corner of the LCD.
- 3) Press the **Shutter** button to play and stop playing your selected video.

Video Playback Mode Quick Function Buttons

Button	Function
 LEFT	<ul style="list-style-type: none"> - Displays the PREVIOUS image - Scrolls through your Thumbnail images
 UP	<ul style="list-style-type: none"> - Increases Volume (while playing back your video) - Scrolls through your Thumbnail images
 RIGHT	<ul style="list-style-type: none"> - Displays the NEXT image - Scrolls through your Thumbnail images
 DOWN	<ul style="list-style-type: none"> - Decreases Volume (while playing back your video) - Opens the Thumbnail display. - Scrolls through your Thumbnail images
Shutter/OK	<ul style="list-style-type: none"> - Plays the selected video file. - Stops the selected playing video. - Opens selected image from the Thumbnail display.
Delete	Allows you to delete your selected video or all of your images (photos and videos)
Menu	Opens the Video Playback Menu options

Thumbnail View

Easily navigate and select the image you wish to view by using the Thumbnail View.

The images on your camera will be displayed in a 3 X 3 matrix where you can use the direction buttons to scroll and select images from the thumbnails.

- 1) Press the **DOWN** button for the images to appear.
- 2) Press the **UP/DOWN/LEFT/RIGHT** direction buttons to navigate the thumbnails to select the image you wish to view.
- 3) Press the **Shutter/OK** button for the image to appear in full screen.
- 4) Navigate by pressing the **UP/DOWN/LEFT/RIGHT** buttons to scroll around the enlarged photo.

Note: You can know from the thumbnail what type of image file:

- AVI files have a **V** appear on the thumbnail image
- JPEG files do not have any icons on the thumbnail image

Delete Images with the Delete Button

While in the Playback mode, you can delete videos from your camera by pressing the **Delete** button. You can choose to either delete the selected image or you can delete all the images.

Delete Current Image:

- 1) Select the image you wish to delete.
- 2) Press the **Delete** button once.
- 3) A "Delete Current?" message appears on the LCD.
- 4) Press the **Shutter/OK** button to delete the image.
Press the **RIGHT** button to cancel the delete and select the next image.
- 5) The selected image is deleted.

Delete All Images:


- 1) Press the **Delete** button twice.
- 2) A "Delete All?" message appears on the LCD.
- 3) Press the Shutter button to delete all the images.
Press the **RIGHT** button to cancel the delete and select the next image.

- 4) All the images captured with the camcorder are irreversibly deleted.

Caution: Please use this Delete feature with care. Once all the images are deleted they are wiped off the SD card. Please make sure that you only use this feature once you have downloaded and saved all the images you wish to your computer.

Video Playback Mode Menus

The following is the menu that appear in your camera's Video Playback Mode:



Delete Menu

While in the Playback mode, you can delete videos from your camera through the delete menu.


- 1) View the image you would like to delete.
- 2) Press the **MENU** button to open the menus for the current mode.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) To delete this one video, select "Delete This Video".
- 5) To delete all the images (including all unlocked photos and videos) on your camera's memory card, select "Delete All Images".
- 6) Press the **Shutter/OK** button to select the desired option.
- 7) You will be asked to confirm your selection.
- 8) The videos will be deleted as desired.

Photo Capture Mode


The Photo Capture mode allows you to capture pictures with your digital camera.

When the camera is first powered ON, the camera will be in Video Capture Mode by default.

Press the **MODE** button once enter the Photo Capture mode.



Taking a Picture

- 1) While in Photo Capture mode, use the LCD display to direct the camera at the scene you would like to capture.
- 2) The  camera icon will appear on the top left corner of the LCD.
- 3) Press the **UP** button to Zoom In and the **DOWN** button to Zoom Out of the object.
- 4) Press the **Shutter** button to capture and save your photo to the memory card.
- 5) You can also capture your photos using the Flip Screen. The LCD screen opens 180 degrees to allow Self Portrait image capture. When you would like to quickly and easily include yourself in the photo, simply flip the LCD display out and hold out the front of camera facing towards you. Make sure you can see yourself within the scene on the LCD screen and click the **Shutter** button to capture the moment. It's as easy as twist and shoot!

Note: The lower the resolution setting the more photos can be taken. However lower resolution photos are of less quality than photos taken at higher resolution.

Photo Capture Mode Quick Function Buttons

Your digital camera has a four-directional pad and additional buttons that functions as Quick Function buttons.





Button	Function
 LEFT	-
 UP	Zooms in
 RIGHT	-
 Down	Zooms out
Shutter	Captures your Photo
Delete	- Allows you to delete last photo taken by opening the 'Delete This Photo' option - Allows you to select the Language when holding down the button for 2 seconds
Menu	Opens the Photo Menu options

Photo Capture Mode Menus


The following are the menus that appear in your camera's Photo Capture Mode:



Image Resolution Menu

The Image Resolution menu allows you to choose the desired size of the images taken by your camera. Keep in mind that images with a higher resolution will also take up more of your camera's memory.

- 1) Press the **MENU** button to open the menus for the current mode.
- 2) Press the **LEFT** or **RIGHT** direction control buttons to scroll and select the chosen menu.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) Press the **Shutter/OK** button to select the desired option.

- 5) A  selected option icon will appear on the selected item.
- 6) Press the **LEFT** or **RIGHT** button to select the next menu item.
- 7) Press the **MODE** button to exit the menu and return to your previous mode.
- 8) An icon reflecting your selection will display on the LCD screen.
- 9) Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.

Language Menu

You can select your camera's language setting by selecting the desired language from the Language menu.



- 1) Press the **MENU** button to open the menus for the current mode.
- 2) Press the **LEFT** or **RIGHT** direction control buttons to scroll and select the chosen menu.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) Press the **Shutter/OK** button to select the desired option.
- 5) A  selected option icon will appear on the selected item.
- 6) Press the **LEFT** or **RIGHT** button to select the next menu item.
- 7) Press the **MODE** button to exit the menu and return to your previous mode.

Photo Playback Mode

When you first turn on the camera, the camera will be in Video Capture mode by default. Press the **MODE** button twice to open the **Playback** Mode. The Playback mode will allow you to review and delete photos and videos that you've already taken with you camera.

The Playback screen appears with the Playback  icon appearing on the top left corner of the screen.



Viewing Captured Photos on Your Camera

Once in the Playback mode, press the **LEFT** or **RIGHT** direction buttons to scroll through the images on your camera's memory card.






All photo files appears with the jpeg  icon appearing in the bottom left corner of the LCD.

Photo Playback Mode Quick Function Buttons

Button	Function
 LEFT	<ul style="list-style-type: none"> - Displays the PREVIOUS image. - Scrolls through your Thumbnail images. - Moves image to the left in the Zoomed In selected Thumbnail image view.
 UP	<ul style="list-style-type: none"> - Scrolls through your Thumbnail images. - Zooms In to your selected Thumbnail image. - Moves image up in the Zoomed In selected Thumbnail image view.
 RIGHT	<ul style="list-style-type: none"> - Displays the NEXT image. - Scrolls through your Thumbnail images. - Moves image to the right in the Zoomed In selected Thumbnail image view.
 DOWN	<ul style="list-style-type: none"> - Opens the Thumbnail display. - Scrolls through your Thumbnail display images. - Zooms Out of your selected image. - Moves image down in the Zoomed In selected Thumbnail image view.
Shutter/OK	Opens selected image from the Thumbnail display.
Delete	Allows you to delete your selected photo or all of your images (photos and videos)
Menu	Opens the Photo Playback Menu options

Thumbnail View

Easily navigate and select the image you wish to view by using the Thumbnail View.

The images on your camera will be displayed in a 3 X 3 matrix where you can use the direction buttons to scroll and select images from the thumbnails.

- 1) Press the **DOWN** button for the images to appear.
- 2) Press the **UP/DOWN/LEFT/RIGHT** direction buttons to navigate the thumbnails to select the image you wish to view.
- 3) Press the **Shutter/OK** button for the image to appear in full screen.
- 4) **Zooming Into the Image:**
Once in full screen display mode, you can press the **UP** or **DOWN** buttons to Zoom In and Zoom Out of the photo.
- 5) Navigate by pressing the **UP/DOWN/LEFT/RIGHT** buttons to scroll around the enlarged photo.

Note: You can know from the thumbnail what type of image file:

- AVI files have a **V** appear on the thumbnail image
- JPEG files do not have any icons on the thumbnail image

Delete Images with the Delete Button

While in the Playback mode, you can delete images from your camera by pressing the **Delete** button. You can choose to either delete the selected image or you can delete all the images.

Delete Current Image:

- 1) Select the image you wish to delete.
- 2) Press the **Delete** button once.
- 3) A “Delete Current?” message appears on the LCD.
- 4) Press the **Shutter/OK** button to delete the image.
Press the **RIGHT** button to cancel the delete and select the next image.
- 5) The selected image is deleted.

Delete All Images:


- 1) Press the **Delete** button twice.

- 2) A “Delete All?” message appears on the LCD.
- 3) Press the Shutter button to delete all the images.
Press the **RIGHT** button to cancel the delete and select the next image.
- 4) All the images captured with the camcorder are irreversibly deleted.

Caution: Please use this Delete feature with care. Once all the images are deleted they are wiped off the SD card. Please make sure that you only use this feature once you have downloaded and saved all the images you wish to your computer.

Photo Playback Mode Menus

The following is the menu that appear in your camera’s Video Playback Mode:



Delete Menu 🗑️

While in the Playback mode, you can delete videos from your camera through the delete menu.

- 1) View the image you would like to delete.
- 2) Press the **MENU** button to open the menus for the current mode.
- 3) Press the **UP** or **DOWN** direction control buttons to scroll through the menu options.
- 4) To delete this one video, select “Delete This Video”.
- 5) To delete all the images (including all unlocked photos and videos) on your camera’s memory card, select “Delete All Images”.
- 6) Press the **Shutter/OK** button to select the desired option.
- 7) You will be asked to confirm your selection.
- 8) The videos will be deleted as desired.

Connecting the Camera to a TV

Your camera has an AV port to use your larger TV screen in place of the camera's LCD screen. On plugging the TV Cable (supplied) to the the camera's AV slot and to the TV, the LCD screen turns blank. Use the camera as you would to capture and playback photos and videos. The images will appear on the TV instead of on the LCD screen.

Note: The only limitation of using the TV screen is that the camera is now not portable.

- 1) Connect the video camcorder to a TV via the TV-out cable (supplied). The TV slot is situated next to the USB slot at the top of the camcorder.
- 2) Connect the end with double-connectors to the video (yellow) and to the audio (red or white) input jack on the TV.
- 3) Turn on the TV and the video camcorder, and then set the TV to "AV" mode.
- 4) When the video camcorder is set to record, capture or playback mode, you can preview the images you want to record on the TV screen.
- 5) When the video camcorder is set to Playback mode, you can review all the pictures and videos stored on the SD card inserted in the video camcorder on the TV.

Installing the Software

You must be connected to the internet to install and run the Vivitar Experience Image Manager software.

- 1) Insert the installation CD into your CD-ROM drive. The installation screen should automatically open.



- 2) On PC: The Vivitar Experience Image Manager Installer window appears. If the window does not appear, open the application's CD/DVD drive and click on "Setup.exe" to launch the installer.
- 3) On Macintosh: Click the icon that appears on the desktop to install the Vivitar Experience Image Manager.
- 4) If you do not have internet access at the time of inserting the CD-ROM, connect to the internet and then click the "Install Vivitar Experience Image Manager" button to begin the installation.



Note: If you do not have internet access, you can still download media from the camera. Click the "How to transfer photos and videos from my camera to my computer" button for instructions.

- 5) If you have internet access, the “Choose your language” window opens, choose your language and click “Next” to open the next window.
- 6) Select your camera model from the list and click “Next” to open the next window.
- 7) Click “Next” to confirm your camera model selection and to install the application.
- 8) Please wait while the application is being installed on your computer.
- 9) Please review the license terms.
On PC and Macintosh: Click the “I accept the terms of this license agreement” and then click “Next” to continue.
- 10) On PC only: Let the “Vivitar Experience Image Manager” installer create the folder to where the program will be installed, and then click “Install”.
- 11) Please wait while the application continues the installation process on your computer.
- 12) On PC: Click the “Close” button when the installation is complete.
Click the “Launch Vivitar Experience Image Manager” to open the application.
- 13) On Macintosh: Click the “Quit” button when the installation is complete.
Click the “Launch Vivitar Experience Image Manager” to open the application.
- 14) If you close the application you can run the Vivitar Experience Image Manager from the Programs (PC) or Applications (Mac) menu on your computer.



Connecting the Camera to the Computer

- 1) Push the USB lever on the side of the camcorder to reveal the retractable built-in USB connector.
- 2) Plug the USB connector into an available USB port on your computer.
- 3) Power the camera ON.
- 4) The first time you connect the device to the computer you will have to wait a few seconds until the computer recognizes the device.

- 5) As your camera is a mass storage device “MSDC” will appear on the LCD, indicating that your camera is in Mass Storage Mode.

Getting Photos and Videos from your Camera to Your Computer

An SD card needs to be inserted. Do not disconnect the cable during transfer. Doing so will cancel the transfer of any files on their way to your computer.

- 1) Select the “Get Images” button from the Main menu.



- 2) The “Get Images from device” window opens.
- 3) You can select to download photos, videos or both.
- 4) Select your camera (removable disk) from the device window. If your camera is the only USB device connected then it will be selected automatically.
- 5) Select a location on the computer where to place the new photo and video files.
- 6) Add the new photo and video files to albums if desired.
- 7) Select to remove the media files from the selected device (removable disk) after the import.
- 8) Click the “Get Images” button to transfer the photos and videos from your camera to your computer.
- 9) A media download progress bar appears on the bottom left showing the number of media files downloading to your computer. A message appears when the download is complete.
- 10) The photo and video files that you selected are now downloaded to your computer to the selected folder and albums ready for your use.

Get started!

Using the Vivitar Experience Image Manager, you can:

- Upload and manage photos and videos to and from the most popular photo sharing and social networking sites - Facebook, Flickr, Picasa, MySpace, Photobucket, Twitpic, Twitgoo and YouTube
- Seamlessly transfer photos and videos from one social network to another
- Organize your images by creating offline and online albums
- Edit images using automatic and manual tools
- Use automatic “Geotagging” with built in Google Maps

For more details on how to use the Vivitar Experience Image Manager open the Help file or click the “Take the Tour” button on the application’s Home page.

Transfer media from my camera to my computer manually (Using Windows)

- 1) Use the USB cable to connect your camera to your computer.
- 2) MSDC appears on the LCD.
- 3) A window appears with a list of options, select “Open folder to view files” and click OK.
- 4) Open the DCIM folder and the folder inside to view the media files.
- 5) Select the media and copy the files from this folder into your computer. Optionally, select the files and choose Copy from the Edit menu. Then select a folder and choose Paste from the Edit menu.
- 6) We recommend that you copy the images into the Pictures/My Pictures folder and the videos into the Videos/My Videos folder.
- 7) Do not disconnect the cable during transfer. Doing so will cancel the transfer of any files on their way to your computer.

Transfer media from my camera to my computer manually (Using Macintosh)

- 1) Use the USB cable to connect your camera to your computer.
- 2) MSDC appears on the LCD.
- 3) The camera's device icon appears on the desktop.
- 4) Click on the device icon and open the DCIM folder and the folder inside to view the media files.
- 5) Select the files and drag them into your computer. Optionally, select the files and choose Copy from the Finder's Edit menu. Then select a folder and choose Paste from the Edit menu.
- 6) We recommend that you copy the images into the Pictures folder and the videos into the Movies folder.
- 7) Do not disconnect the cable during transfer. Doing so will cancel the transfer of any files on their way to your computer.

Camera Maintenance

The digital camera is a delicate device. Please handle your camera with care to avoid damaging it.

Do not expose your camera to heat sources.

Do not use your camera in wet or moist conditions.

Sakar Warranty Card

This warranty covers for the original consumer purchaser only and is not transferable. Products that fail to function properly **UNDER NORMAL USAGE**, due to defects in material or workmanship will be repaired at no charge for parts or labor for a period of one year from the time of purchase.

What Is Not Covered By Warranty:

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

What To Do When Service Is Required:

When returning your defective product (postage pre-paid) for service, your package should include:

- 1) Copy of **original** bill of sale
- 2) A detailed written description of the problem.
- 3) Your return address and telephone number (Daytime)

MAIL TO ADDRESS BELOW:

<u>Sakar US</u>	<u>Sakar UK/Europe</u>	<u>Sakar Australia</u>
Sakar International Attention: Service Department 195 Carter Drive Edison, NJ 08817	Attention: Service Department 2D, Siskin Parkway East 4020 Middlemarch Business Park Coventry, CV3 4PE	Return faulty camera to the Refund Counter at the store where purchased

Technical Support

For technical support issues please visit our website at **www.vivitar.com**. You can find manuals, software and FAQ's at the website. Can't find what you are looking for? E-mail us at **support@vivitar.com** and one of our technical support team members will answer your questions. For phone support in the US please call 1-800-592-9541, in the UK call 0800 917 4831, in Australia call 1800-006-614. If you would like to call from anywhere else, please visit **www.vivitar.com** for your local toll free number.

Troubleshooting

Q: I have taken photos and selected the "Get Images" button. I get a message that the images were successfully transferred but the photos do not appear on my computer.

What do I do?

First ensure that you have in fact taken photos. Press the Shutter button to take some sample photos and then try downloading them again.

With test photos if the camera powers off before you upload them to the computer the photos are not stored in the camera's memory. These photos should be uploaded quickly before the camera powers off. If the photos are saved to the SD memory card then all the photos should appear.

Q: How do I make sure I don't lose important pictures?

This camera requires an SD card for normal use. If the camera powers off nothing will happen to the images stored on the SD memory card. We recommend always downloading your photos to your computer as soon as possible to prevent unintentional data loss.

Q: I deleted images using the Vivitar Experience Image Manager. The images were also deleted from my computer. How do I recover images that I accidentally deleted?

All images deleted using the Vivitar Experience Image Manager are sent to your computer's Recycle or Trash Bin and can be retrieved from there.