

Poly Sync 60 Series

Bluetooth and USB Conference Room Speakerphone


User Guide

Contents

Controls	3
LEDs	4
Be safe	4
Set up, power and pair	5
Power	5
Corded setup	5
Mobile setup	6
Video camera setup	7
Load software	8
Update firmware	8
Daily Use	9
Answer or end a call	9
Mute/Unmute	9
Volume	9
Voice assistant (smartphone feature)	9
Launch Microsoft Teams (Teams model only)	9
Customize your speakerphone	9
Charge your mobile phone	9
Link speakerphones (daisy chain audio)	10
Linked speakerphone audio settings	10
Troubleshoot	11
What's in the box	12
Support	13

Controls

A conference room speakerphone with mobile and corded connectivity.



NFC	Near Field Communication
Bluetooth icon	Bluetooth pairing
Microsoft Teams icon	Press to interact with Microsoft Teams (Teams model only, desktop application required)
Volume down icon	Volume down
Mute/unmute icon	Mute/unmute
Volume up icon	Volume up
Call/Siri/Google Assistant icon	Call answer/end
Siri, Google Assistant	Default voice assistant (smartphone feature)
USB icon	USB phone charge ports
Link icon	Link 2 speakerphones (smartphone feature)
Media icon	Pause/play media (default). Customize feature in Poly Lens App

LEDs


LED bar	What lights mean
Crossing blue pattern	Pairing mode
Solid blue	Pairing successful (connected)
Flashing green	Incoming call
Solid green	In a call
Solid red	Mute active
Crossing white pattern	Linking mode (daisy chain audio)
2 white blinks	Linking successful

NOTE LEDs do not illuminate in standby mode.

Be safe

Please read the safety guide for important safety, charging, battery and regulatory information before using your new speakerphone.

Set up, power and pair




Ports on speakerphone's reverse side

- | | |
|--|-------------------------|
| | Computer USB-C port |
| | Video camera USB-A port |
| | Power port |


Power

The speakerphone is powered on when the power cable is connected to an outlet. The power port is on the reverse side of the speakerphone.



Corded setup

Connect the USB cable from the speakerphone to your computer's USB-A or USB-C port.




NOTE The USB cable connects to the computer port on the reverse side of the speakerphone.

NOTE Ensure that the USB-C-only connector is plugged into the speakerphone. Corded mode may not function if the USB-A to USB-C adapter is connected to the speakerphone.

Mobile setup

- 1 With your speakerphone powered on, press the Bluetooth  button for 2 seconds. You hear "pairing" and the LED flashes a crossing blue pattern.



- 2 Activate Bluetooth on your mobile device and set it to search new devices. Select "Poly Sync 60."
- 3 Pairing is successful when you hear "pairing successful" and the LED flashes blue.

NFC pairing

Your speakerphone supports NFC pairing to your mobile device. NFC pairing may not function if two devices are already paired to your speakerphone.

- 1 Ensure NFC is enabled on your mobile device and the display is unlocked. (Mobile device NFC capability may vary.)
- 2 With the speakerphone powered on, bring mobile device's NFC tag within range of the speakerphone's NFC tag until pairing completes. If necessary, accept the connection.


Secure Connection (mobile)

The Secure Connection feature provides extra security for Bluetooth calls in a conference room.


When enabled, your paired device disconnects after each mobile call, ensuring that device audio does not play through the speakerphone when not intended. Manage in Poly Lens App.

NOTE Enabling Secure Connection disconnects previously paired devices.

- 1 With your speakerphone powered on and Secure Connection enabled in Poly Lens App, press the Bluetooth  button for 2 seconds. You hear "pairing" and the LED flashes a crossing blue pattern.
- 2 Activate Bluetooth on your device and set it to search new devices. Select "Poly Sync 60."




- 3 Pairing is successful when you hear "pairing successful" and the LED flashes blue.




- 4 Make or take a mobile call or play music via Bluetooth.
- 5 After the end of a call, continue the mobile connection by pressing any button within 30 seconds. When no action is taken, the mobile connection ends and the Bluetooth button is no longer illuminated.

Video camera setup

- 1 Your speakerphone ships with the video camera  port covered. It is on the reverse side of the speakerphone. Access the port by removing the cover with the provided torx tool.



- 2 Connect your compatible video camera's cable to the USB-A camera  port on the speakerphone.



NOTE Video camera cable not provided.

Load software

Customize your device behavior through advanced settings and options with Poly Lens Desktop App. Some softphones require the installation of Poly software to enable device call control (answer/end and mute) functionality. Download: poly.com/lens.

NOTE *Device settings are also available in Plantronics Hub Desktop App.*

Update firmware

Keep your firmware up-to-date to improve performance and add new features to your Poly device.

Update your firmware using your computer with Poly Lens App. Download at poly.com/lens.

While updating firmware:

- Do not use your Poly device until the update is complete.
- Disconnect your Poly device from paired devices such as phones, tablets and computers.
- Do not start a second update from a second device.
- Do not stream media.
- Do not answer or place a call.

Daily Use

Answer or end a call

Press the Call  button to answer or end a call.

Mute/Unmute

During an active call, press the Mute  button to mute or unmute the microphones. Manage mute settings in Poly Lens App.

Volume

Press the Volume up (+) or down (-) buttons to increase or decrease volume.

Adjust speakerphone microphone volume

Place a test softphone call and adjust softphone volume and PC sound volume accordingly.

Voice assistant (smartphone feature)

Siri, Google Assistant, Cortana Press and hold the Call button for 2 seconds to activate your phone's default voice assistant. Wait for the phone prompt to activate voice dialing, search, and other smartphone voice controls.

Launch Microsoft Teams (Teams model only)

Your device has a Teams  button to quickly view and use the Microsoft Teams desktop app. The Teams button pulses when you have a meeting or notification.

- When not on a call, tap the Teams  button to view Microsoft Teams app on your computer.
 - When the Teams button LED pulses purple, tap to view your Teams notifications or meeting.
- NOTE** Teams model and open Teams desktop application required. Teams mobile application is not supported.

Customize your speakerphone


Customize your Rocket  button feature in Poly Lens App. Play/pause media is the default feature when you tap the Rocket  button.

Choose from:

- Play/pause audio (default)
- Device status check
- Clear trusted device list
- **Mobile calls only:** Default voice assistant (Siri, Google Assistant)
- Redial
- Hold/resume call (varies by softphone)

Charge your mobile phone

With the speakerphone powered on, charge up to 2 phones. Connect phone charge cable to one of 2 USB-A charging ports (cables not provided).



NOTE Connection provides power only.


Link speakerphones (daisy chain audio)

Use two Poly Sync speakerphones with your Bluetooth-paired mobile device.


IMPORTANT Linking mode is available with Bluetooth mobile device connection only. This feature is not available when your speakerphone is connected to a computer with USB cable.

NOTE Linking mode can be entered when both speakerphones are inactive (not in a call or streaming media).

- 1 Power on both speakerphones.
- 2 Ensure that the speakerphones are unplugged from any computer.
- 3 Wirelessly link by pressing both Link  buttons for 2 seconds. You hear "connecting" and the LEDs pulse white. Linking is successful when you hear "connection successful" and the LED flashes white on both speakerphones.



- 4 Pair one speakerphone to your idle mobile device. You hear "phone connected" when successfully paired.
NOTE You may pair your mobile device before or after linking speakerphones.



- 5 Control the system from either speakerphone to play audio or make calls.
- 6 End linking mode by pressing both Link  buttons for 2 seconds. You hear "device disconnected."

Linked speakerphone
audio settings

Manage daisy chain audio settings in Poly Lens App.

Troubleshoot

The speakerphone doesn't play audio when connected to my computer in corded mode.

- Ensure that the speakerphone is powered on by connecting the power cable to an outlet.
- The computer USB cable may be inserted backwards. Ensure that the USB-C-only end of the cable is inserted into the speakerphone. The end of the cable with USB-A connector (and attached USB-C adapter) inserts into your computer.
- Do not connect the USB cable to a phone charging  port on the speakerphone's side. Connect to the USB-C  port on reverse side of the speakerphone.

(Teams model only) How do I interact with Microsoft Teams?

- Tap the Teams  button to quickly open and use Microsoft Teams.
- Teams model is compatible with Microsoft Teams desktop app. Teams mobile app is not supported.

-
- How do I manage my speakerphone using Poly software?
 - My speakerphone isn't recognized by Poly Lens Mobile App or Plantronics Hub Mobile App.

- Your speakerphone is supported by Poly desktop applications: Poly Lens Desktop App and Plantronics Hub Desktop App. Download: poly.com/lens.
- Your speakerphone is not supported by Poly mobile apps.

How do I use the Secure Connection feature with my mobile calls?

- The Secure Connection feature provides extra security for Bluetooth calls in a conference room.
- Activate Secure Connection in Poly Lens Desktop App.
- Automatically disconnects your paired mobile device from the speakerphone after a call.
- Continue the mobile connection by pressing any button on the speakerphone within 30 seconds after the end of a call.

How do I customize the Rocket  button feature?


- Ensure Poly Lens Desktop App is loaded on your computer.
- Customize your Rocket  button feature in Poly Lens Desktop App.
- Play/pause media is the default feature when you tap the Rocket  button. Play/pause feature is not compatible with some web-based apps.

I want to connect a video camera to my speakerphone.

- Your speakerphone ships with the USB-A video camera  port covered. Access the port by removing the cover with the provided tool.
 - Connect your compatible video camera's cable to the USB-A camera  port on the speakerphone.
-

What's in the box


Contents may vary by product.



Speakerphone



Combined USB-A/USB-C
cable



Power supply and plug
adapters



Torx tool (for video camera
port)



Quick start guide

Support

NEED MORE HELP?

poly.com/support

Manufacturer:

Plantronics, Inc.	Plantronics B.V.
345 Encinal Street	Scorpius 171
Santa Cruz, CA 95060	2132 LR Hoofddorp
United States	Netherlands

© 2021 Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. Bluetooth is a registered trademark of Bluetooth SIG, Inc. and any use by Plantronics, Inc. is under license. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.

Model ID: SY60/SY60-M.

218941-06 04.21