



ROBOTICS

Product specification

Robot user documentation, OmniCore
with RobotWare 7



Trace back information:
Workspace Main version a524
Checked in 2023-06-29
Skribenta version 5.5.019

Product specification
Robot user documentation, OmniCore with RobotWare 7
23B/RobotWare 7.10

Document ID: 3HAC065042-001
Revision: P

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

Table of contents

Overview of this specification	7
1 Introduction	9
1.1 Easy-to-use information products	9
1.2 Types of manuals	10
1.3 Available languages	12
2 Application equipment & accessories	13
3 OmniCore controllers	15
3.1 Controller variants	15
3.2 Software and options	17
4 Robots	19
5 Software products	25
5.1 Application software	25
5.2 Design, programming & configuration software	26
6 For all products	27

This page is intentionally left blank

Overview of this specification

About this product specification

This specification lists all active user documentation for ABB Robotics global products with OmniCore and RobotWare 7.

Revisions

Revision	Description
A	First release.
B	Released in December 2019.
C	Released in March 2020. Added links to all documents in myABB.
D	Released in June 2020.
E	Released in October 2020.
F	Released in December 2020.
G	Released in April 2021.
H	Released in December 2021.
J	Released in March 2022.
K	Released in June 2022. The structure is updated to reflect the product tree.
L	Released in September 2022.
M	Released in December 2022.
N	Released in March 2023.
P	Released in June 2023.

This page is intentionally left blank

1 Introduction

1.1 Easy-to-use information products

Introduction to robot user documentation

The robot user documentation is aimed at all robot users, providing easy to use information and guidelines as well as in-depth descriptions and detailed reference literature. There is a robot user document for each stage of use, from installation and commissioning, through programming, operation and maintenance, to troubleshooting and decommissioning of your robot system.

ABB's group of skilled editors provide professional user documentation, ensuring efficient communication of robot expertise, from our engineers to your personnel.

Key benefits

- Easy-to-use user documentation
- In-depth reference information
- Detailed product information
- Maintenance and service procedures

User documentation offer

The documentation offer includes the user documentation for all standard robotics products. The robot user documentation that is safety related is translated into 18 languages. Other translations are available depending on market. Documents that are not translated are available in English.

Updates of the documentation are released at every major product change (manipulators, controllers, and RobotWare).

The robot user documentation is available for all customers in myABB business portal (www.abb.com/myabb), using ABB Library.



Note

For some of the documentation, you must be logged in to myABB business portal (www.abb.com/myabb) to access the links. ABB internal users must be logged into ABB download center.

1 Introduction

1.2 Types of manuals

1.2 Types of manuals

Operating manuals

The *operating manuals* are directed to persons with first hand contact with the robot system, that is production operators, programmers, and service personnel.

Technical reference manuals

The *technical reference manuals* include reference information for the products. The technical reference manuals for RAPID and system parameters describe the controller software. The manuals include syntax and detailed information on instructions, functions, and data types in the RAPID language and on system parameters.

Application manuals

The *application manuals* describe hardware options as well as RobotWare base functionality and options, directed to specific applications, such as RobotWare Arc, Spot, Dispense, Integrated Vision. The content includes:

- Purpose of the option: For what is the option intended?
- What is included in the option, for example RAPID instructions, system parameters.
- Which hardware is required, for example cables and I/O boards.
- Setup, programming, and configuration examples.
- Hardware descriptions and technical data.

Product manuals

There is a *product manual* for each manipulator and controller. The content includes:

- Safety information
- Technical data
- Installation and commissioning
- Maintenance (maintenance schedules and preventive maintenance routines)
- Repair (lists of spare parts and repair procedures)
- Calibration procedures
- Troubleshooting
- Decommissioning procedures
- Reference information
- Part list or reference to separate spare part list

Safety manuals

The safety information in the product manuals is also combined into a general safety manual, which is translated to the same languages as the operating manual for the robot controller.

Continues on next page

Product specifications

There is a *product specification* for each product. The content varies depending type of product but usually includes:

- Description of the product, including technical data
- Variants and options

1 Introduction

1.3 Available languages

1.3 Available languages

Available languages

The number of available languages is limited during the introduction period of the OmniCore platform. More translations will be made available over the coming years.

Language codes

The manuals are available in the following languages (with matching subnumber).

Language	Language code	Subnumber	
English	en	1	001
Swedish	sv	2	002
German	de	3	003
French	fr	4	004
Spanish	es	5	005
Portuguese (Brazilian)	pt or pt-br	6	006
Italian	it	7	007
Danish	da	8	008
Dutch	nl	9	009
Chinese (simplified)	zh or zh-cn	10	010
Korean	ko	11	011
Japanese	ja	12	012
Finnish	fi	13	013
Czech	cs or cz	14	014
Polish	pl	15	015
Russian	ru	16	016
Hungarian	hu	17	017
Turkish	tr	18	018
Slovenian	sl	19	019

2 Application equipment & accessories

DressPack

Title	Article number
Product manual - DressPack IRB 5710 (English , German , French , Spanish , Italian , Chinese)	3HAC082052-001
Product manual - DressPack IRB 5720 (English , German , French , Spanish , Italian , Chinese)	3HAC082053-001
Circuit diagram - DressPack IRB 5710 / IRB 5720 (English)	3HAC081433-001
Product manual - DressPack/SpotPack IRB 6650S (English , German , French , Spanish , Italian)	3HAC055424-001
Circuit diagram - DressPack 6650S/7600 (English)	3HAC026209-001
Circuit diagram - DressPack 6650S/7600 LeanID (English)	3HAC022327-002
Product manual - DressPack/SpotPack IRB 6700 (English , German , French , Spanish , Italian)	3HAC044270-001
Circuit diagram - DressPack 6700 (English)	3HAC044246-002
Product manual - DressPack IRB 6710 ⁱ	3HAC088410-001
Product manual - IRB DressPack IRB 6720 ⁱ	3HAC088411-001
Product manual - DressPack IRB 6730 ⁱ	3HAC088412-001
Product manual - DressPack IRB 6740 ⁱ	3HAC088413-001
Circuit diagram - DressPack IRB 6710 / IRB 6720 / IRB 6730 / IRB 6740 ⁱ	3HAC087933-001

ⁱ This document is not released yet at the time of publishing this specification.

Vision systems

Title	Article number
Application manual - Integrated Vision (English , German , French , Spanish , Chinese)	3HAC067707-001
Product specification - Integrated Vision (English)	3HAC073385-001

This page is intentionally left blank

3 OmniCore controllers

3.1 Controller variants

OmniCore C line

Title	Article number
Product manual - OmniCore C30 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Czech , Polish , Russian)	3HAC060860-001
Product manual - OmniCore C90XT (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Czech , Polish , Russian)	3HAC073706-001
Product specification - OmniCore C line (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC065034-001
Circuit diagram - OmniCore C30 (English)	3HAC059896-009
Circuit diagram - OmniCore C30 for IRB 14050 (English)	3HAC063898-009
Circuit diagram - OmniCore C30 for CRB 15000 (English)	3HAC072448-009
Circuit diagram - OmniCore C90XT (English)	3HAC065464-009

OmniCore E line

Title	Article number
Product manual - OmniCore E10 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Czech , Polish , Russian)	3HAC079399-001
Product specification - OmniCore E line (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC079823-001
Circuit diagram - OmniCore E10 (English)	3HAC076810-008

OmniCore V line

Title	Article number
Product manual - OmniCore V250XT Type A (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Czech , Polish , Russian)	3HAC084692-001
Product manual - OmniCore V250XT (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Czech , Polish , Russian)	3HAC073447-001
Product specification - OmniCore V line (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC074671-001

Continues on next page

3 OmniCore controllers

3.1 Controller variants

Continued

Title	Article number
<i>Circuit diagram - OmniCore V250XT</i> (English)	<i>3HAC074000-008</i>

3.2 Software and options

Base functionality

Title	Article number
Operating manual - OmniCore (English , German , French , Spanish , Chinese , Korean , Slovenian)	3HAC065036-001
Operating manual - Integrator's guide OmniCore (English , German , French , Spanish , Chinese , Korean , Slovenian)	3HAC065037-001
Technical reference manual - Event logs for RobotWare 7 (English , German , French , Spanish , Portuguese , Italian , Danish , Dutch , Chinese , Korean , Japanese , Finnish , Czech , Polish , Russian , Turkish , Slovenian)	3HAC066553-001

RAPID and system parameters

Title	Article number
Technical reference manual - Event logs for RobotWare 7 (English , German , French , Spanish , Chinese , Korean)	3HAC066553-001
Technical reference manual - RAPID Instructions, Functions and Data types (English , German , French , Spanish , Italian , Chinese , Czech)	3HAC065038-001
Technical reference manual - RAPID kernel (English , Chinese , Czech)	3HAC065039-001
Technical reference manual - RAPID Overview (English , German , French , Spanish , Italian , Chinese , Czech)	3HAC065040-001
Technical reference manual - System parameters (English , German , French , Spanish , Italian , Chinese)	3HAC065041-001

Options

Title	Article number
Application manual - Additional axes for OmniCore (English , German , Chinese)	3HAC082287-001
Application manual - I/O Engineering (English , German , Chinese , Korean)	3HAC082346-001
Application manual - CC-Link IE Field Basic (English , Chinese , Korean)	3HAC082295-001
Application manual - DeviceNet Master/Slave (English , German , Chinese)	3HAC066562-001
Application manual - EtherNet/IP Scanner/Adapter (English , German , Chinese)	3HAC066565-001
Application manual - Functional safety and SafeMove (English , German , French , Spanish , Italian , Chinese)	3HAC066559-001
Application manual - PROFINET Controller/Device (English , German , Chinese)	3HAC066558-001

Continues on next page

3 OmniCore controllers

3.2 Software and options

Continued

Title	Article number
Application manual - Scalable I/O (English , German , French , Spanish , Italian , Chinese)	3HAC070208-001

RobotWare options

Title	Article number
Application manual - Continuous Application Platform (English)	3HAC083246-001
Application manual - Controller software OmniCore (English , German , Chinese)	3HAC066554-001
Application manual - Conveyor tracking (English , German , Chinese)	3HAC066561-001
Application manual - Discrete Application Protocol (English)	3HAC083266-001
Application manual - Externally Guided Motion (English , German , Chinese)	3HAC073318-001
Application manual - Force control with software and hardware (English)	3HAC070206-001
Application manual - Force control Standard for GoFa (English)	3HAC083267-001
Application manual - Production Framework (English)	3HAC085600-001
Application manual - RobotWare add-ins (English)	3HAC070207-001
Application manual - SoftMove (English)	3HAC066560-001

4 Robots

Generic documents

Title	Article number
Product specification - Robot stopping distances according to ISO 10218-1 (English)	3HAC048645-001
Technical reference manual - Lubrication in gearboxes (English , German , French)	3HAC042927-001

Articulated robots

Title	Article number
Product manual - IRB 460 (English , German , French , Spanish , Italian , Chinese)	3HAC039842-001
Product manual, spare parts - IRB 460 (English)	3HAC040628-001
Product specification - IRB 460 (English , German , French , Spanish , Italian , Chinese)	3HAC081954-001
Circuit diagram - IRB 460 (English)	3HAC036446-005
Product manual - IRB 660 (English , German , French , Spanish , Italian , Russian)	3HAC025755-001
Product manual, spare parts - IRB 660 (English)	3HAC049102-001
Product specification - IRB 660 (English , German , French , Spanish , Italian)	3HAC081955-001
Circuit diagram - IRB 660 (English)	3HAC025691-001
Product manual - IRB 1010 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC081964-001
Product manual, spare parts - IRB 1010 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC081965-001
Product specification - IRB 1010 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC081966-001
Circuit diagram - IRB 1010 (English)	3HAC080051-003
Product manual - IRB 1100 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC064992-001
Product manual, spare parts - IRB 1100 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC064994-001

Continues on next page

4 Robots

Continued

Title	Article number
Product specification - IRB 1100 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC064993-001
Circuit diagram - IRB 1100 (English)	3HAC066314-009
Product manual - IRB 1200 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC046983-001
Product manual, spare parts - IRB 1200 (English)	3HAC046984-001
Product specification - IRB 1200 (English , German , French , Spanish , Italian , Chinese)	3HAC081417-001
Circuit diagram - IRB 1200 (English)	3HAC046307-003
Product manual - IRB 1300 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC070390-001
Product manual, spare parts - IRB 1300 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC070392-001
Product specification - IRB 1300 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC070393-001
Circuit diagram - IRB 1300 (English)	3HAC068887-003
Product manual - IRB 2600 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC035504-001
Product manual, spare parts - IRB 2600 (English , Chinese)	3HAC049106-001
Product specification - IRB 2600 (English , German , French , Spanish , Italian , Japanese)	3HAC085909-001
Circuit diagram - IRB 2600 (English)	3HAC029570-007
Product manual - IRB 4600 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC033453-001
Product manual - IRB 4600 Foundry Prime (English , German , French , Spanish , Italian)	3HAC040585-001
Product manual, spare parts - IRB 4600 (English , Chinese)	3HAC049108-001
Product specification - IRB 4600 (English , German , French , Spanish , Italian , Japanese)	3HAC080366-001
Circuit diagram - IRB 4600 (English)	3HAC029038-003

Continues on next page

Title	Article number
Product manual - IRB 5710 (English , German , French , Spanish , Italian , Chinese)	3HAC075184-001
Product manual, spare parts - IRB 5710 (English , German , French , Spanish , Italian , Chinese)	3HAC079891-001
Product specification - IRB 5710 (English , German , French , Spanish , Italian , Chinese)	3HAC075188-001
Circuit diagram - IRB 5710/IRB 5720 (English)	3HAC080367-001
Product manual - IRB 5720 (English , German , French , Spanish , Italian , Chinese)	3HAC079195-001
Product manual - IRB (English , German , French , Spanish , Italian , Chinese)	3HAC079196-001
Product specification - IRB 5720 (English , German , French , Spanish , Italian , Chinese)	3HAC079197-001
Circuit diagram - IRB 5710/IRB 5720 (English)	3HAC080367-001
Product manual - IRB 6650S (English , German , French , Spanish , Italian , Japanese , Polish)	3HAC020993-001
Product manual, spare parts - IRB 6650S (English)	3HAC049111-001
Product specification - IRB 6650S (English , German , French , Spanish , Italian)	3HAC081956-001
Circuit diagram - IRB 6650S (English)	3HAC13347-1
Product manual - IRB 6700 (English , German , French , Spanish , Italian , Chinese , Polish , Russian)	3HAC044266-001
Product manual - IRB 6700Inv / IRB 6700I (English , German , French , Spanish , Italian , Chinese)	3HAC058254-001
Product manual, spare parts - IRB 6700/IRB 6700Inv (English , German , French , Spanish , Italian , Chinese , Polish , Russian)	3HAC044268-001
Product specification - IRB 6700 (English , German , French , Spanish , Italian , Russian)	3HAC080365-001
Circuit diagram - IRB 6700 / IRB 6790 (English)	3HAC043446-005
Product manual - IRB 6710 (English , German , French , Spanish , Italian , Chinese)	3HAC085695-001
Product manual, spare parts - IRB 6710 (English , German , French , Spanish , Italian , Chinese)	3HAC085696-001
Product specification - IRB 6710 (English , German , French , Spanish , Italian , Chinese)	3HAC085703-001
Product manual - IRB 6720 (English , German , French , Spanish , Italian , Chinese)	3HAC085697-001

Continues on next page

4 Robots

Continued

Title	Article number
Product manual, spare parts - IRB 6720 (English , German , French , Spanish , Italian , Chinese)	3HAC085698-001
Product specification - IRB 6720 (English , German , French , Spanish , Italian , Chinese)	3HAC085704-001
Product manual - IRB 6730 (English , German , French , Spanish , Italian , Chinese)	3HAC085699-001
Product manual, spare parts - IRB 6730 (English , German , French , Spanish , Italian , Chinese)	3HAC085700-001
Product specification - IRB 6730 (English , German , French , Spanish , Italian , Chinese)	3HAC085705-001
Product manual - IRB 6740 (English , German , French , Spanish , Italian , Chinese)	3HAC085701-001
Product manual, spare parts - IRB 6740 (English , German , French , Spanish , Italian , Chinese)	3HAC085702-001
Product specification - IRB 6740 (English , German , French , Spanish , Italian , Chinese)	3HAC085706-001
Circuit diagram 6710-6720-6730-6740	

Collaborative robots

Title	Article number
Product manual - IRB 1100 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Russian)	3HAC064992-001
Product manual, spare parts - CRB 1100 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Russian)	3HAC078009-001
Product specification - CRB 1100 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC082108-001
Circuit diagram - CRB 1100 (English)	3HAC076518-003
Product manual - CRB 1300 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC083111-001
Product manual, spare parts - CRB 1300 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC083112-001
Product specification - CRB 1300 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC083113-001
Circuit diagram - CRB 1300 (English)	3HAC080868-003
Product manual - IRB 14050 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC064625-001

Continues on next page

Title	Article number
Product manual, spare parts - IRB 14050 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC064628-001
Product manual - Grippers for IRB 14050 (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC064626-001
Product specification - IRB 14050 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC064627-001
Circuit diagram - IRB 14050 (English)	3HAC064375-009
Product manual - CRB 15000 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Russian)	3HAC077389-001
Product manual, spare parts - CRB 15000 (English , German , French , Spanish , Italian , Chinese , Japanese , Russian)	3HAC079469-001
Product specification - CRB 15000 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese , Russian)	3HAC077390-001
Circuit diagram - CRB 15000 (English)	3HAC074304-003

Delta robots

Title	Article number
Product manual - IRB 360 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC030005-001
Product manual, spare parts - IRB 360 (English)	3HAC049101-001
Product specification - IRB 360 (English , German , French , Spanish , Italian , Japanese)	3HAC079010-001
Circuit diagram - IRB 360 (English)	3HAC028647-009
Product manual - IRB 365 (English , German , French , Spanish , Italian , Chinese , Korean)	3HAC079185-001
Product manual spare parts - IRB 365 (English , German , French , Spanish , Italian , Chinese , Korean)	3HAC083099-001
Product specification - IRB 365 (English , German , French , Spanish , Italian , Chinese , Korean)	3HAC079184-001
Circuit diagram - IRB 365 (English)	3HAC079349-003

Continues on next page

SCARA robots

Title	Article number
Product manual - IRB 910INV (English , German , French , Spanish , Italian , Chinese)	3HAC068055-001
Product manual, spare parts - IRB 910INV (English , German , French , Spanish , Italian , Chinese)	Document.ID-1
Product specification - IRB 910INV (English , German , French , Spanish , Italian , Chinese)	3HAC068057-001
Circuit diagram - IRB 910INV (English)	3HAC061899-011
Product manual - IRB 920 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC075721-001
Product manual, spare parts - IRB 920 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC075722-001
Product specification - IRB 920 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC075723-001
Circuit diagram - IRB 920 (English)	3HAC075152-014
Product manual - IRB 930 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC086009-001
Product manual, spare parts - IRB 930 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC086010-001
Product specification - IRB 930 (English , German , French , Spanish , Italian , Chinese , Korean , Japanese)	3HAC086011-001
Circuit diagram IRB 930	

5 Software products

5.1 Application software

Assembly software

Title	Article number
<i>Operating manual - Visual Servoing</i> (English , Chinese)	3HAC081083-001

Packaging software

Title	Article number
<i>Application manual - PickMaster® Twin - Operator</i> (English)	3HAC069977-001
<i>Application manual - PickMaster® Twin - PowerPac</i> (English)	3HAC080435-001
<i>Application manual - PickMaster® Twin - PowerPac</i> (English)	3HAC073650-001
<i>Product specification - PickMaster® Twin</i> (English)	3HAC073650-001
<i>Circuit diagram - PickMaster Twin</i> (English)	3HAC024480-020

Spotwelding software

Title	Article number
<i>Application manual - Servo Gun Setup</i> (English)	3HAC086084-001
<i>Application manual - SpotWare</i> (English , German)	3HAC078759-001

5 Software products

5.2 Design, programming & configuration software

5.2 Design, programming & configuration software

RobotStudio

Title	Article number
<i>Operating manual - RobotStudio</i> (English , German , French , Spanish , Italian , Chinese , Japanese)	3HAC032104-001
<i>Product specification - RobotStudio</i> (English)	3HAC026932-001

6 For all products



Note

For some of the documentation, you must be logged in to myABB business portal (www.abb.com/myabb) to access the links. ABB internal users must be logged into ABB download center.

Safety manuals

Title	Article number
Safety manual for robot - Manipulator and IRC5 or OmniCore controller (English , Swedish , German , French , Spanish , Portuguese , Italian , Danish , Dutch , Chinese , Korean , Japanese , Finnish , Czech , Polish , Russian , Turkish , Slovenian)	3HAC031045-001
Operating manual - Emergency safety information (English , Swedish , German , French , Spanish , Portuguese , Italian , Danish , Dutch , Chinese , Korean , Japanese , Finnish , Czech , Polish , Russian , Hungarian , Turkish , Slovenian)	3HAC027098-001
Product specification - Robot stopping distances according to ISO 10218-1 (English)	3HAC048645-001

**ABB AB****Robotics & Discrete Automation**

S-721 68 VÄSTERÅS, Sweden

Telephone +46 10-732 50 00

ABB AS**Robotics & Discrete Automation**

Nordlysvegen 7, N-4340 BRYNE, Norway

Box 265, N-4349 BRYNE, Norway

Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.

Robotics & Discrete Automation

No. 4528 Kangxin Highway

PuDong New District

SHANGHAI 201319, China

Telephone: +86 21 6105 6666

ABB Inc.**Robotics & Discrete Automation**

1250 Brown Road

Auburn Hills, MI 48326

USA

Telephone: +1 248 391 9000

abb.com/robotics