




Gas Powered Leaf Mulcher Operator's Manual



WARNING:

Read carefully and understand all INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury. Save these instructions in a safe place and on hand so that they can be read when required. Keep these instructions to assist in future servicing.



WARNING SYMBOL



WARNING: This is the warning symbol to get your high attention for the instruction notice, which should be followed to avoid the potential serious personal injury. Anyone to use this equipment should read all the instructions of this manual. Keep this instruction manual for future reference.

1. Do not allow children to operate this leaf mulcher. Keep children away from the area while leaf mulcher is in use. Adults should review the manual completely prior to operating the Leaf Mulcher Product.
2. You must comply with all safety and operating instructions in this manual before attempting to setup and operate your Leaf Mulcher.
3. Failure to comply with all safety and operating instructions can result in loss of machine control, serious personal injury to you and/or bystanders, and risk of equipment and property damage. Triangle Symbols in the text signifies important cautions or warnings which must be followed.
4. Engine exhaust, wood dust, and gasoline vapors from this product contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.

Intended Use

This is a gas engine-powered Leaf Mulcher that breaks up leaves and wooded pieces such as small tree branches, brush, and small limbs into mulch via a high-speed rotor containing chipping blades and shredding hammers. Operators understand and agree that it shall not be used for any other purpose.

TECHNICAL SPECIFICATIONS

Chipping Capacity	Max. 1"
Chipping Knives	6
Shredder Hammer	2 HAMMERS
Hopper Dimensions (IN)	17.3x14.5x23.8
Wheel Size (IN)	10x3
Wheel Material	PU
Wheel Type	SOLID
Net Weight (LB)	77
Gross Weight (LB)	90
Assembled Dimension (IN)	25.4x27.1x38.8
Packing Dimension (IN)	23.2x21.9x19.4

ENGINE SPECIFICATIONS

Engine Brand	Alphaworks
Engine Type	OHV
Displacement	145CC
Starting	Recoil
RPM	3600
Fuel Capacity	0.21Gal.
Oil	0.08~0.13Gal.
EPA Approval	YES
CARB Approval	YES

GENERAL OPERATING SAFETY

1. Read, understand, and follow all instructions in the manual and all warning labels on the unit before starting.
2. Position the Leaf Mulcher on a flat, level, sturdy surface that support the weight of the Leaf Mulcher and any additional tools and equipment.
3. Do not attempt to use the machine on a slope or slick or wet surface.
4. Dress appropriately in suitable PPE (Personal Protective Equipment) when operating the Leaf Mulcher. Sturdy footwear, gloves, durable clothing, ear protection and safety goggles should be worn while operating your Leaf Mulcher. Never wear sandals, sneakers or open toed shoes, and never operate the Leaf Mulcher while bare foot. Do not wear loose clothing that might get caught in moving parts.
5. Never place your hands, fingers, feet, or any other part of your body close to the Discharge Opening while the Leaf Mulcher is in operation.
6. Do not look into the Hopper, Chipper Chute or Discharge Opening when the machine is running.
7. Only allow responsible adults, who are familiar with the proper usage and operation of this product, to utilize the unit. Keep children away from the equipment, especially while it is in operation.
8. Be sure the area is clear of other people before turning on the unit. Stop the unit if anyone enters your working zone.
9. Always maintain secure footing and solid balance while starting or operating the Leaf Mulcher. Never lean on the machine.
10. Operate the machine only in daylight or under good lighting conditions.
11. Do not operate the unit while under the influence of alcohol or drugs.
12. Always wear proper safety/protection equipment when operating this unit.
13. The operator shall take full responsibility for any accidents or injuries caused by improper operation.
14. Never operate the machine without assembling proper guards, plates, or other safety protective devices in right place.
15. Thoroughly inspect the area around equipment before starting up used and remove all foreign objects.
16. Extreme caution when operating on or crossing compacted earth, gravel drives, walks or any road that have loose debris. Stay alert for hidden hazards or traffic conditions that may make the operation of this product unsafe.

PRODUCT SPECIFIC SAFETY

WARNING

The Leaf Mulcher has spinning blades that can amputate hands and feet. Do not place hands or feet in the hopper or chipper cone, or discharge chute.

WARNING

This unit discharges debris at high speeds. Always wear appropriate protective gear, including but not limited to gloves and goggles and do not operate without the debris bag in place.

Do not allow anyone in your working zone while the unit is running. If someone does enter the area, shut the unit off immediately until they leave. Organize the work area prior to starting work.

1. Do not operate without the debris bag in place because this unit discharges debris at high speeds. If the unit is operated on hard ground, asphalt, concrete, or other hard surfaces without the collection bag in place, material can ricochet off by the hard surface and cause an unsafe condition for both users and bystanders.
2. Never leave the machine running while unattended. Always turn off the engine, wait for the rotor to come to a complete stop, and disconnect the spark plug before leaving the area.

Always move the unit to a safe storage area when not in use.

3. Never direct discharge material toward anyone. Avoid discharging material against a wall or obstruction. Material may ricochet back towards the operator.
4. Always stand to the side of the chipper cone when feeding tree limbs and branches into the unit, as tree limbs, branches, and harder woods may kick back while being chipped.
5. Always keep hands out of the chipper cone and shredder hopper when feeding materials. Never wrap fingers tightly around branches as you are feeding them into the unit, as a sudden inward surge could pull your hands and arms into the unit.
6. Never allow material to accumulate in the discharge area or shredding chamber, as this may cause new material being fed into the machine to kickback with strong force to injure you or other bystanders.
7. Never allow material to accumulate around the engine during Leaf Mulcher operation. This could result in a fire hazard, or overheating of the engine.
8. Never attempt to reposition or move the Leaf Mulcher unit while it is running. Doing so could cause the machine to tip over, and reaching to steady the unit could result in accidental insertion of your hands into the chipper cone or shredder hopper areas.
9. Never continue to operate the machine if it starts making unusual noise or vibration. Shut the engine off immediately, allow the rotor to stop, disconnect the spark plug wire and secure the wire away from the spark plug. Inspect the unit for any signs of damage or foreign material in the chipping or shredding areas. Remove any solid material that may be preventing the unit from operating properly.
10. Never attempt to clear material from the chipper cone, shredder hopper or discharge chute while the unit is running. Always shut the engine off, allow the rotor to come to a complete stop, and disconnect the spark plug wire before removing excess materials.
11. Never attempt to perform any maintenance, repairs, or attachment of accessories while the unit is running. Always shut the unit off, allow the rotor to stop, and remove the spark plug wire before beginning these activities.
12. Always make sure that the shredding chamber, shredder hopper, and chipper cone are empty before starting the unit. Attempting to start the unit with material in these areas could cause the engine starting cord to stop suddenly, injuring your hand and fingers, or toppling the unit over. Vibration is generally warning sign of trouble.
13. Use only attachments and accessories approved of by the manufacturer.
14. Make sure chipper shredder is free of debris before starting the engine.
15. Never attempt to make any adjustments while the engine is running.
16. After striking a foreign object, stop the engine, remove spark plug wire, and wait for all moving parts to come to a complete stop. Thoroughly inspect the machine for any damage, repair the damage before restarting and operating the machine.

ENGINE SPECIFIC SAFETY

Before cleaning, repairing, or inspecting, shut off the engine and make certain that all moving parts have come to a complete stop. Disconnect the spark plug wire and secure the wire away from the spark plug to prevent accidental starting.

WARNING

1. Engines give off carbon monoxide, an odorless, colorless, poison gas. Carbon monoxide may be present even if you do not smell or see any engine exhaust. Breathing carbon monoxide can cause nausea, fainting or death, in addition to drowsiness, dizziness and confusion. If you experience any of these symptoms, seek fresh air and medical attention immediately.
2. If your machine comes with a separate engine manual, be sure to read and follow all safety and warning precautions outlined there and this manual this manual.

Handle fuel with care, it is highly flammable.

- a. Use only approved fuel containers.
- b. Never add fuel to a running engine or hot engine.
- c. Fill fuel tank outdoors with extreme care. Never fill fuel tank indoors.
- d. Replace gasoline cap securely and clean up spilled fuel before restarting.

Preventing Carbon Monoxide Poisoning

1. Always start and run engine outdoors. Do not start or run engine in an enclosed area, even if doors or windows are open.
2. Never ventilate engine exhaust indoors. Carbon monoxide can reach dangerous levels very quickly.
3. Never run engine outdoors where exhaust fumes may be pulled into a building.
4. Never run engine outdoors in a poorly ventilated area where the exhaust fumes may be trapped and not easily taken away. (Examples include: in a large hole or areas where hills surround your working area.)
5. Never run engine in an enclosed or partially enclosed area. (Examples include: buildings that are enclosed on one or more sides, under tents, car ports or basements.)
6. Always run the engine with the exhaust and muffler pointed in the direction away from the operator.
7. Never point the exhaust muffler towards anyone. People should always remain a safe distance away from the operation of the engine and its attachments.
8. Do not change the engine governor settings or over-speed of the engine.

Gasoline Fires and Handling Fuel Safely

Use extra care in handling gasoline and other fuels. They are flammable and vapors are explosive.

1. When storing extra fuel be sure that it is in an appropriate container and away from any fire hazards.
2. Prevent fire and explosion caused by static electric discharge. Use only nonmetal, portable fuel containers approved by the Underwriter's Laboratory (U.L.) or the American Society for Testing & Materials.
3. Always fill fuel tank outside in a well ventilated area. Never fill your fuel tank with fuel indoors. (Examples include: basement, garage, barn, shed, house, porch, etc.) Never fill tank near appliances with pilot lights such as heaters, boilers, or other ignition sources. If the fuel has to be drained, this should be done outdoors. The drained fuel should be stored in a container specifically designed for fuel storage or it should be disposed of carefully.
4. Never remove the fuel cap or add fuel with the engine running. Stop engine and allow to cool before filling.
5. Do not smoke while refueling or operating engine.
6. Always wipe up excess (spilled) fuel from engine before starting. Clean up spilled fuel immediately. If fuel is spilled, do not start the engine but move machine and fuel container from area. Clean up spilled fuel and allow to evaporate and dry after wiping and before starting.
7. Allow fuel fumes/vapors to escape from the area before starting engine.
8. Test the fuel cap for proper installation before starting and using engine.
9. Always run the engine with fuel cap properly installed on the engine.
10. During storage, keep machine so gas cap is up.
11. Never siphon fuel by mouth to drain fuel tank.
12. Always have an adult fill the fuel tank and never allow children to fill the engine.
13. Never allow an adult or anyone under the influence of drugs or alcohol to fill engine.
14. When storing gasoline or equipment with fuel in the tank, store away from furnaces, stoves, water heaters or other appliances that have a pilot light or other ignition source because they can ignite gasoline vapors.

15. Never fill containers inside a vehicle or on a truck bed with a plastic bed liner. Always place containers on the ground away from your vehicle before filling.
16. Remove gas-powered equipment from the truck or trailer and refuel it on the ground. If this is not possible, then refuel such equipment on a trailer with a portable container, rather than from a gasoline dispenser nozzle.

Burns and Fires

The muffler, muffler guard and other parts of the engine become extremely hot during the operation of the engine.

These parts remain extremely hot after the engine has stopped.

Prevention of Burns and Fires

1. Never remove the muffler guard from the engine.
2. Never touch the muffler guard because it is extremely hot and will cause severe burns.
3. Never touch parts of the engine that become hot after operation.
4. Always keep materials and debris away from muffler guard and other hot parts of the engine to avoid fires.

Children and Bystanders

Tragic accidents can occur if the operator is not alert to the presence of children and/or bystanders. Never assume that others will remain where you last saw them.

1. Keep the area of operation clear of all persons, especially children and pets. Keep children under the watchful care of a responsible adult.
2. Be alert and turn the machine off if children enter the area.
3. Before and while moving backwards, look behind and down for children.
4. Never allow children to operate the machine

ASSEMBLY

Assemble support of engine (See Figure 1)

Use 2pcs M8*40 Hexagon flange bolts(C), and 2pcs M8 Hexagon flange nuts (B) to fix supporting.




Figure 1

Assemble supporting leg (See Figure2)

Use 2pcs M8 Hexagon flange nuts (B) to fix leg (A) to blade housing (C)




Figure 2

Assemble Wheels (See Figure 3)

Use one split pin 2.8x30 (A) and one flat washer $\phi 16$ (B) to fix wheel (C) to wheel bracket (D).




Figure 3

Assemble Outlet guide plate (See Figure 4)

Use 4pcs M8*100 Hexagon bolts (C), and 3pcs M8 Hexagon flange nuts (A), to fix outlet guide plate (B) to blade housing (D)




Figure 4

Assemble bottom hopper kit (See Figure 5)

Use 2pcs M8X16 Hexagon flange nuts (B) and 4pcs M8 Hexagon flange nuts (C), to fix bottom hopper (A) to blade housing (D)




Figure 5

Assemble upper hopper (See Figure 6)

Use 8pcs M6 Hexagon flange nuts to fix hopper left plate (A), hopper right plate (C), hopper front plate (B) and hopper rear plate (D) together.




Figure 6

Assemble plastic baffle (See Figure7)

Use 3pcs M8X16 Hexagon flange nuts(B) and 3pcs M6 Hexagon flange nuts (C), to fix plastic baffle (A) to hopper (D).




Figure 7

Assemble hopper (See Figure 8)

Use 8pcs M8X16 Hexagon flange nuts (C) and 8 pcs M8 Hexagon flange nuts (B) , to fix upper hopper (A) to bottom hopper (D).




Figure 8

Assemble handle (See Figure 9)

Use 4pcs M8X16 Hexagon flange nuts (B) and 4pcs M8 Hexagon flange nuts (C) , to fix handle (A) to hopper.




Figure 9

Assemble Throttle control (See Figure 10)

Use M5x25 cross head bolt (B) to fix throttle (A) to handle, fix clip (C) to hopper, and then insert throttle wire into clip.




Figure 10

GENERAL OPERATION

1. Be sure to read all information in the Safety and Operation sections before attempting to operate this unit. Be familiar with all of the controls and how to stop the unit.
2. Check all hardware (bolts, screws, etc) before every use to be sure machine is in safe working order.
3. Overloading the equipment will shorten its life and can cause mechanical failures.

Shredder Operation

The shredder is designed to shred light brush, leaves, and other soft but bulky organic waste. It is not suitable for shredding branches or long fiber plants which bigger than 1".

As material (no larger than 1 inch in diameter) is loaded into the shredder hopper, it is pulled into the path of the hammers by air flow.

Since occasional kick-backs may occur, always stand off to the side of the unit. Allow the self-feeding action of the unit to draw in the material. Do not force material into the unit.

Chipper Operation

The chipper is designed to handle tree limbs and branches up to approximately 1" in diameter. The chipping knives also permit the processing of course organic matter like corn stalks. Tree branches must be inserted large-end first into the chipper cone.

Since occasional kick-backs may occur, always stand off to the side of the unit. Allow the self-feeding action of the unit to draw in the material.

Do not force material into the unit.

Operating Location

1. Select an area with firm, level ground, covered by dirt or grass.
2. Do not operate on wet or slick surfaces, or near bystanders.
3. Locate and organize the materials to be processed so that you don't have to walk in front of the inlet or discharge openings, and so you have adequate room to work safely.

Adding Oil

Refer to engine manual for information on adding oil.

WARNING

1. The exhaust from this product contains carbon monoxide gas. Carbon monoxide is a colorless, odorless and tasteless gas that can cause dizziness, nausea, unconsciousness or even brain damage and death if inhaled for prolonged periods.
2. Operate the unit outdoors in a well ventilated location only. Keep children, pets and bystanders away.
3. Failure to follow these instructions may result in serious injury or death.

WARNING

1. Gasoline is highly flammable and must be handled with care. Never fill the tank when the engine is still hot from recent operation.
2. Do not allow open flame, smoking or matches in the area. Avoid over-filling and wipe up any spills.

WARNING

To avoid serious personal injury from rotating cutting blades, keep hands out of inlet while machine is running.

Do Not Use Gasoline Containing Methanol, Gasohol containing more than 10% Ethanol, Gasoline Additives or White Gas because Engine/fuel System Damage Could Result.

Engine is shipped from factory without oil. You must add engine oil before starting the engine.

ADDING FUEL

To add fuel:

1. Remove the fuel cap.
2. Fill the tank. Do not overfill. Leave room in the tank for fuel expansion. Refer to your engine manual for specific fuel recommendations.
3. Install and hand tighten the fuel cap.

Starting the Engine

1. See engine manual for starting up instructions.
2. Ensure engine is running full throttle before beginning chipping operation. On some engines, the throttle may not be adjustable.

Stopping the Engine

1. See engine manual for shut down procedure.
2. Stopping the engine is the only way to stop the rotor from turning. With engines equipped with an adjustable throttle, move the throttle to the SLOW position and wait for engine to be running a slow RPM. Then switch to STOP ENGINE as shown in the engine manual.

TRANSPORTING AND STORAGE

1. Always observe safe refueling and fuel handling practices when fueling the unit after transportation or storage.
2. Never store the unit (with fuel) in an enclosed poorly ventilated structure. Fuel vapors can travel to an ignition source (such as a furnace, water heater, etc.) and cause an explosion. Fuel vapor is also toxic to humans and animals.
3. Always use the hopper handle and built-in wheels to move the chipper shredder. Never lift the unit using the fuel tank for support. If the unit must be lifted , always use at least two people, and always grip the unit securely using the front leg and hopper handle.
4. Always follow the engine manual instructions for storage preparations before storing the unit for both short and long term periods.
5. Always follow the engine manual instructions for proper start-up procedures when returning the unit to service.
6. Never store the unit or fuel container inside where there is an open flame or pilot light, such as in a water heater. Allow unit to cool before storing.

Storage

Perform engine maintenance and storage measures listed in the engine owner's manual. This includes draining the fuel system, or adding stabilizer to the fuel. **NOTE: Do not store a fueled unit in an enclosed structure. (SEE GASOLINE FIRES AND HANDLING FUEL SAFETY)**

Before starting the unit after it has been stored:

1. Check all fluid levels. Check all maintenance items.
2. Perform all recommended checks and procedures found in the engine owner's manual.
3. Allow the engine to warm up for several minutes before use.

MAINTENANCE

Schedule & Procedures

The following schedule should be followed for normal care of your unit.

SAFETY ITEMS	BEFORE EACH USE	EVERY 5 HOURS	EVERY 25 HOURS	EVERY 100 HOURS	EVERY 250 HOURS	SPRING & FALL
Check for loose hardware		X				X
Check all safety labels						X
Inspect cone, hopper, and guards	X					X
CHIPPER MAINTENANCE ITEMS						
Clean debris from engine and chipper	X					
Inspect/Rotate Shredding Hammers			X			
Inspect/Rotate Chipping Knives			X			

Engine Maintenance

Refer to the engine manual included in your package for information on engine maintenance. Your engine manual provides information and a maintenance schedule for performing the following tasks:

1. Always check oil level before starting engine. Refer to engine manual for capacity and type of oil to use.
2. Change oil after first 5-8 hours of operation. Change oil while engine is warm. Refill with new oil of recommended grade.
3. Check spark plug yearly or every 50 hours of operation.
4. Service air cleaner.
5. Keep engine and parts clean.
6. Check engine and equipment often for loose nuts and bolts, keep these items tightened.

Check for Loose Hardware

1. Service Interval: Every 5 hours; every spring and fall.
2. Inspect the unit, checking for loose hardware or components.
3. Pay special attention to the hardware attaching the chipper cone, hopper, axle, and front leg.

Check Safety Labels

1. Service Interval: Every spring and fall.
2. Check that the safety labels are in place and undamaged.

Inspect Cone, Hopper, & Guards

1. Service Interval: Every spring and fall.
2. Check that the chipper cone, shredder hopper, and discharge guards are in place, undamaged, and secure.
3. Replace any damaged or missing parts.

Clean Debris from Engine & Chipper

1. Service Interval: Before each use and every 100 hours.
2. The engine requires air flow to cool itself and for combustion.
3. Before each use, clean any debris from the unit especially from around the air shroud intake, air filter, and muffler. Every 100 hours, remove the engine air shroud and clean out any debris from the engine cooling fins.

We recommend having this service performed by an authorized dealer.

WARNING

Engine is shipped from factory without oil. You must add engine oil before starting engine.

WARNING

1. For the safety of the user, and to maximize the life of the engine, it is crucial to take time to check the condition of the engine.
2. Problems must be corrected before operating.
3. Avoid injury! Engine oil is hazardous to your health. Dispose of oil appropriately as an appropriate recycling center.

TROUBLESHOOTING CHART

1. Normal care and regular maintenance will extend the life of your equipment, prolonged or constant use will eventually require that service be performed to allow it to continue operating properly.
2. The troubleshooting guide below lists the most common problems, their causes, and remedies.
3. See the information on the following pages for instructions on how to perform most of these minor adjustments and repairs.


WARNING

1. To avoid serious injury, perform maintenance on the unit only when the engine is stopped.
2. Always disconnect the spark plug wire and fasten it away from the plug before beginning the maintenance, to prevent accidental starting of the engine.

Problem(s)	Possible Cause	Solution
Engine won't start	1. No fuel. 2. Choke not in START position. 3. Low quality or deteriorated, old gasoline. 4. Dirty fuel passageways. 5. Spark plug cap not connected securely. 6. Spark plug fouled. 7. No compressions. Problem after long storage periods. 8. Low engine oil.	1. Add fuel. 2. Turn choke to START position. 3. Use fresh unleaded gasoline. 4. Clean out passageways using fuel additive. Heavy deposits may require further cleaning. 5. Connect spark plug cap properly. 6. Remove spark plug. Clean/replace as recommended in engine manual. 7. Lubricate the cylinder, pour tablespoon of oil into spark plug hole. Crank engine a few times and try to start again. 8. Add engine oil to proper level.
Engine exhaust is black	1. Dirty air filter. 2. Choke closed.	1. Replace air filter. 2. Open choke.
Engine stops suddenly	1. Fuel tank empty or full of impure or low quality gasoline. 2. Low oil shutdown. 3. Disconnected or improperly connected spark plug cap. 4. The limb is too long.	1. Add fuel tank with fresh unleaded gasoline. 2. Fill engine oil to proper level. 3. Secure spark plug cap. 4. If the limb diameter for the side chute in 2"-3" and the length over 31" long, suggest the operator should help the limb feeding by lightly holding to keep the feed speed consistent.
Engine runs but no material is discharged	1. Discharge chute clogged. 2. Engine not running at full speed.	1. Clean out debris. 2. Set throttle control to FAST if equipped.
Chipping action slow, or engine stalling	1. Branch diameter is too thick. 2. Throttle set is too slow. 3. Tree limbs are extremely hard or dried out.	1. Do not process branches over 3" diameter. 2. Adjust throttle to increase engine speed. 3. Material is not suitable for chipping.
Unusual noise or vibration when chipping material	1. Rotor overloaded with material. 2. Hammers are broken, bent, or loose. 3. Hammers frozen in place.	1. Allow unit to clear itself before adding more material to the hopper. 2. Check assembly. Tighten or replace as necessary. 3. Check for obstructions and debris. Repair or replace as necessary.

Problem(s)	Possible Cause	Solution
Vacuum not working.	1. Hopper gate not closed. 2. Cone cover not installed. 3. Hose not attached properly. 4. Engine not running at full RPM.	1. Slide gate to closed position. 2. Allow material to dry. 3. Clear blockage or replace. 4. Set throttle control to FAST if equipped.

PARTS LIST



Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	M6x16 Hexagon flange bolts	6	16	Base plate	1
2	Upper rear hopper plate	1	17	Blade plate	1
3	Bending plate	1	18	Supporting block	4
4	Plastic baffle	1	19	Pin 2.8x30	2
5	Handle	1	20	Washer	2
6	M6 Hexagon flange nuts	14	21	Rubber block	1
7	Upper left hopper plate	1	22	Supporting leg	1
8	Throttle control knob	1	23	M8x20 Hexagon flange nuts	20
9	Upper front hopper plate	1	24	M8x100 Hexagon bolt	3
10	Bottom hopper	1	25	Outlet guide plate	1
11	R145 engine	1	26	Clip	2
12	Blade housing	1	27	M8x30 Hexagon flange nuts	6
13	Wheel	2	28	Upper right hopper	1
14	M8x40 Hexagon flange nuts	2	29	M8 Hexagon flange nuts	32
15	Supporting bar	1	30	Clamping plate	1



Great Circle USA
Support Line: 1-866-493-0524
help@greatcircleus.com
www.greatcircleus.com