



INTRODUCTION

This Technical Service Manual has been compiled to provide the most recent technical service information. This information enables the service technician to troubleshoot and diagnose malfunctions, perform necessary repairs and return the appliance to proper operational condition.

The service technician should read the complete instructions contained in this service manual before initiating any repairs on a Wolf Appliance.

For installation information see **Induction and Electric Cooktops Installation Guide** available at <http://www.subzero-wolf.com/trade-resources/product-specifications>.

For Use and Care information see **Use & Care Guide: Induction Cooktops** available at <http://www.subzero-wolf.com/trade-resources/product-specifications>.

IMPORTANT SAFETY INFORMATION

Below are the Product Safety Labels used in this manual. The "Signal Words" used are **WARNING** and **CAUTION**.

Please note that these safety labels are placed in areas where awareness of personal safety and product safety should be taken and lists the precautions to be taken when the signal word is observed.

WARNING

INDICATES THAT HAZARDOUS OR UNSAFE PRACTICES COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.

CAUTION

Indicates that hazardous or unsafe practices could result in minor personal injury or product and/or property damage

In addition, please pay attention to the signal word **"NOTE"**, which highlights especially important information within each section.

TECHNICAL ASSISTANCE

If you should have any questions regarding the appliance and/or this manual, please contact:

*Wolf Appliance, Inc.
ATTN: Service Department
P.O. Box 44988
Madison, WI 53744 - 4988*

*Customer Care
Phone #: (800) 332 - 9513
Facsimile #: (608) 441 - 5887*

*Technical Assistance
(For Technicians in Customer's Homes Only)
Phone #: (800) 919 - 8324*

*Warranty Claims
Phone #: (800) 404 - 7820
Facsimile #: (608) 441 - 5886*

*Service Department e-mail Address:
customerservice@wolfappliance.com*

*Main Office Hours:
8:00 AM to 5:00 PM Central Time
Monday through Friday
(24/7 Phone Coverage)*

This manual is designed to be used by Certified Service Personnel only. Wolf Appliance, Inc. assumes no responsibility for any repairs made to Wolf appliances by anyone other than Certified Service Technicians.

The information and images are the copyright property of Wolf Appliance, Inc., an affiliate of Sub-Zero Group, Inc. Neither this manual nor any information or images contained herein may be copied or used in whole or in part without the express written permission of Wolf Appliance, Inc., an affiliate of Sub-Zero Group, Inc. © Wolf Appliance, Inc., all rights reserved.



TABLE OF CONTENTS

	Page #		Page #
Section 1 - General Information		Section 2 - Electronics - continued	
Introduction	1-2	Display States in Operational Mode	2-9
Important Safety Information	1-2	All Off	2-9
Technical Assistance	1-2	Error Mode	2-9
Table of Contents	1-3	Showroom Mode	
Warranty Information	1-5	Notes and Restrictions in Showroom Mode	2-9
Rating Plate Example	1-5	Entering Showroom Mode	2-9
Rating Plate Location	1-5	Exiting Showroom Mode	2-9
Model Number Key	1-6	Operation of Showroom Mode	2-9
Cooktop Features	1-6	Diagnostic Mode	
CI Series Configurations - Transitional	1-7	Entering Diagnostic Mode	2-10
CI Series Configurations - Contemporary	1-8	Diagnostic Mode Procedures	2-10
		LED Test	2-10
Section 2 - Electronics		Generator Reconfiguration	2-10
Touch Pads	2-2	Control Temperature Readout	2-10
Annunciator	2-2	Heat Sink Temperature Test	2-10
HOT Surface Display	2-2	Heat Sink Performance Notes	2-11
Frequency Duration and Selection Chart	2-3	Coil Temperature Test	2-11
CI Series Coil Assembly Wattage and Layout		Coil Temperature Performance Impact	2-11
CI152	2-3	Coil Assembly Locations	2-11
CI243	2-4	Error Code Indicator	2-12
CI304	2-4	Showroom Mode	2-12
CI365	2-5	Software Version Indicator	2-12
Timer		User Options Mode	
General Information	2-5	Entering Users Options Mode	2-13
Starting the Timer	2-5	User Options	
Ending the Timer	2-6	Annunciator Volume	2-13
Display States of the Timer	2-6	Annunciator Frequency	2-13
Fans	2-6	Auto-Lock	2-13
Modes			
Power Up Mode	2-6	Section 3 - Component Removal	
Lock Mode		Important Warning and Caution	3-2
Entering Lock Mode	2-6	Tools Needed	3-2
Exiting Lock Mode	2-6	Glass Top	3-3
Valid Key Presses in Lock Mode	2-7	Control Board	3-3
Display States in Lock Mode	2-7	Coil Assembly	3-4
Idle Mode		Generator Plate	3-4
Valid Key Presses in Idle Mode	2-7	Comm Harness	3-5
Display States in Idle Mode	2-7	Fan Assembly	3-5
Wake-Up Mode		Generator Assembly (except 36" models)	3-6
Entering Wake-Up Mode	2-7	Generator Assembly (36" models)	3-6
Valid Key Presses in Wake-Up Mode	2-7	Intake Gasket	3-7
Notes and Restrictions in Wake-Up Mode	2-7	Support Spring, Mounting Pin, or Washer	3-7
Display States in Wake-Up Mode	2-7		
Operational Mode			
Entering Operational Mode from Wake-Up Mode	2-8		
Exiting Operational Mode	2-8		
Valid Key Presses in Operational Mode	2-8		
Bridge and Coil Assembly Operational Mode Notes	2-8		
Boost Operational Mode Notes	2-8		



Page

Section 4 - Troubleshooting

Troubleshooting	4-2
Induction	4-2
Warning and Caution	4-2
Diagnostic Mode	
Entering Diagnostic Mode	4-3
Diagnostic Mode Procedures	4-3
LED Test	4-3
Generator Reconfiguration	4-3
Control Temperature Readout	4-3
Heat Sink Temperature Test	4-3
Heat Sink Performance Notes	4-4
Coil Temperature Test	4-4
Coil Temperature Performance Impact	4-4
Coil Assembly Locations	4-4
Error Code Indicator	4-5
Showroom Mode	4-5
Software Version Indicator	4-5
General Errors Table	4-6
Cooking Zone Specific Errors	4-7
Fan Test	4-8
HOT Indicator Stays On	4-8
No Pan Detection	4-8

Section 5 - Technical Data

Power Requirements	5-2
Power Rating and Electrical Service	5-2
Induction Power Level Charts	
15" Induction Power Level	5-3
24" Induction Power Level	5-3
30" Induction Power Level	5-4
36" Induction Power Level	5-4

Section 6 - Wiring Diagrams

Wiring Diagram Model: CI15	6-2
Wiring Diagram Model: CI24	6-3
Wiring Diagram Model: CI30	6-4
Wiring Diagram Model: CI36	6-5



WARRANTY INFORMATION

This page contains a summary of the 2 & 5 Year Warranty that is supplied with every Wolf product, followed by a Non-Residential Warranty Summary and then notes about the warranties.

2 & 5 Year Warranty Summary:

- 2 Year Total Product Warranty, parts and labor.
- 3-5 Year Limited Parts Only Warranty.

Details:

- Warranty applies to products installed in United States or Canada, for residential use only.
- Warranty begins at time of unit's initial installation.
- Warranty does not cover Wolf Appliances installed in a demonstration kitchen, test kitchen, culinary school kitchen, or similar installations. (See Special Warranty below)
- Warranty and service information collected by Wolf Appliance, Inc. is arranged and stored under unit serial number and/or customer's name. Wolf Appliance, Inc. requests that you have model and serial number available whenever contacting factory or parts distributor.
- 3-5 Year Limited Parts Only Warranty applies to the control board, generator(s), and coil assemblies.

Special Warranty Summary

2 Year Total Product Warranty, parts and labor.

Details:

- This Warranty applies to products installed in United States or Canada, for use in a demonstration kitchen, test kitchen, culinary school kitchen, and similar installations that help promote Wolf Appliance brand and its products.
- Warranty begins at time of unit's initial installation.
- Warranty and Service information collected by Wolf Appliance, Inc. is arranged and stored under unit serial number and/or customer's name. Wolf Appliance, Inc. requests that you have model and serial number available whenever contacting factory or parts distributor.

NOTE: "ICB" appliances carry no factory warranty. The product distributor or appliance dealer may offer their own warranty.




Figure 1-1. Typical Rating Plate Layout




Figure 1-2. The rating plate is located beneath the cooktop.

**MODEL NUMBER KEY**

Refer to this key for an example of the model numbers.

Model:	ICB	CI	36	5	T / S
International Designation	_____	_____	_____	_____	_____
Product Configuration	_____	_____	_____	_____	_____
Size	_____	_____	_____	_____	_____
Number of Coil Assemblies	_____	_____	_____	_____	_____
Unit Style	_____	_____	_____	_____	_____
Edge Style	_____	_____	_____	_____	_____

Product Configuration

CI = Cooktop Induction

Size

15 = 15 - inch wide unit

24 = 24 - inch wide unit

30 = 30 - inch wide unit

36 = 36 - inch wide unit

Number of Coil Assemblies

2 = Two coil assembly unit

3 = Three coil assembly unit

4 = Four coil assembly unit

5 = Five coil assembly unit

Unit Style

T = Transitional

C = Contemporary

Edge Style

S = Stainless Steel Frame

B = Black Unframed

COOKTOP FEATURES


- Two styles
 - Transitional Series - stainless steel trim.
 - Contemporary Series - black unframed.
- Ceran glass-ceramic surface for scratch resistance and easy cleaning.
- Induction elements heat iron and other magnetic cookware instantly, while cooktop surface stays cool.
- Cookware sensing - elements can not be energized without an induction-compatible pan on the cooktop.
- Bridge zone connects two or more coil assemblies to increase the cooking area.
- Boost mode boosts power by diverting power from an adjacent coil assembly.
- Wolf exclusive melt setting for gentle heat, and true simmer setting prevents scorching.
- Touch controls display an intuitive power scale for precise control.
- Indicators including boost mode, illuminate on the control panel.
- Control panel lock.
- Independent timer up to 99 minutes.



CI SERIES CONFIGURATIONS

Transitional Cooktops


15" Two Coil Assemblies - Transitional



Model Number: CI152T/S

Description: Cooktop Induction, 15", Two Coil Assemblies, Transitional / Stainless steel


30" Four Coil Assemblies - Transitional



Model Number: CI304T/S

Description: Cooktop Induction, 30", Four Coil Assemblies, Transitional / Stainless steel

36" Five Coil Assemblies - Transitional




Model Number: CI365T/S


Description: Cooktop Induction, 36", Five Coil Assemblies, Transitional / Stainless steel

Contemporary Cooktops


24" Three Coil Assemblies - Contemporary


**Model Number:** CI243C/B**Description:** Cooktop Induction, 24", Three Coil Assemblies, Contemporary / Black unframed

30" Four Coil Assemblies - Contemporary

**Model Number:** CI304C/B**Description:** Cooktop Induction, 30", Four Coil Assemblies, Contemporary / Black unframed

36" Five Coil Assemblies - Contemporary

**Model Number:** CI365C/B**Description:** Cooktop Induction, 36", Five Coil Assemblies, Contemporary / Black unframed



ELECTRONICS

This section describes the basic operation of the CI Series electronics and how the touch pad responds to input commands. The control board receives touch sensitive input and triggers a command in the generator(s). The generator(s) uses Insulated Gate Bipolar Transistors (IGBTs) to maintain the correct power at the coil assembly. Temperature is monitored at heat sinks and at the coil assemblies by a special type of thermistor called a Negative Temperature Coefficient (NTC) thermistor.

Touch Pads

Global Touch Pads

- **LOCK** - Locks or unlocks the entire cooktop. Touch and hold for 3 seconds. Acceptance beep when state changes. Padlock is displayed when locked.
- **ALL OFF** - Disables entire cooktop. Red circle displayed when any coil assembly is energized.
- **“+”** - Adds time to the count down timer. Valid Selection beep to acknowledge touch.
- **“-”** - Decreases time to the count down timer. Valid Selection beep to acknowledge touch.
- **TIMER** - Activate and deactivate the timer. Valid Selection beep to acknowledge touch.

Control Zone Pads:

- **ON/OFF** - Enables or disables individual control zone.
- **SIM** - sets power to level 1.
- **MLT** - sets power to level 1.
- **HI** - sets power to level 10.
- **BOOST** - sets power to Boost and adjusts adjacent power levels as required by the induction power sharing scheme. Toggles Boost off if already engaged.
- **BRIDGE** - Activates vertically adjacent coil assemblies to same power level.
- **BRG** - Activates horizontally adjacent coil assemblies to same power level.
- **ALL BRIDGE** - Activates the four adjacent coil assemblies on the left side of the 36" model.
- **“ ”** - Sets power to levels 2 through 9.

Annunciator:

- Adjust annunciator volume and frequency in user options mode. See Frequency Duration and Selection Chart on the next page.
- Cooktop must be in idle mode to adjust annunciator.
- Factory default setting for volume is medium.
- Factory default setting for frequency is medium.
- Low frequency is 1.5 kHz. Medium frequency is 2.0 kHz. High Frequency is 2.5 kHz.

HOT Surface Display:

- LED is on when the cooktop glass temperature at any coil assembly (NTC reading) is greater than 149° F.
- LED turns off when the glass temperature is below 122° F.
- Independent of any control zone activation or the cooktop being in lock or showroom mode.