

Contents

Accessory List

Safety Instructions

Introduction FAQ **EcoFlow App** Community After-sales How It Works Policy Overview Installation > Introduction Power On/Off EcoFlow DELTA Pro Ultra is a residential power backup system designed for **Power Your Appliances** > both extended outages and daily use. With an unrivaled capacity of 6kWh, **Charging Your Power Station** 7.2kW output, and 5.6kW solar input, a single unit can run your entire home. With EcoFlow Smart Home Panel 2, get an uninterrupted power backup **UPS** and X-Fusion > experience with automatic switch-over, energy consumption monitoring, and lower electricity bills. **App Settings** > **Troubleshooting** Home Backup Maintenance The DELTA Pro Ultra can either be used as a stand-alone unit using various What's in the Box

Continuous Power

>

With EcoFlow DELTA Pro Ultra's UPS technology, you'll get impeccable, uninterrupted power flow, EcoFlow DELTA Pro Ultra safeguards your vulnerable electronic equipment round-the-clock. For extended outages, you don't want to hear your backup in the background, so for low draws under 2000W, it's completely silent. With a whisper-quiet 0 dB, your nights remain undisturbed as it powers your devices.

recharging options (low/high voltage solar systems, generators, EV chargers,

etc.) or forms a whole home backup system to ensure that your home can be

powered 24/7 without any influence from power outage.

Expandable Capacity



The rated capacity of one battery is 6kWh. To expand capacity for powering your appliances (see **Overview** or **Power Your Appliances**) or backing up your whole home (see **Backup System**), one can connect up to 5 batteries to an inverter or up to 15 batteries to 3 sets of inverters, which makes the total capacity add up to about 30kWh to 90kWh.

Specifications

EcoFlow DELTA Pro Ultra Inverter



General	
Model	EFYJ751-PCS-US
Net Weight	31.7 kg (70 lb)
Dimensions	690 × 481 × 214 mm (27.2 × 18.9 × 8.4 in.)
Wi-Fi	Frequency range: 2,412-2,462MHz/2,422-2,452MHz Maximum output power: 0.3597W
Bluetooth	Frequency range: 2,402-2,480MHz Maximum output power: 0.0109W
Output	
AC Output	Discharging: Pure sine, 7,200W total, 120V/240V~ 60Hz Bypass: 100-120V~30A total, 50Hz/60Hz
USB Ports	USB-A (× 2): 5V=2.4A, 12W max per port, total 24W USB-C (× 2): 5/9/12/15/20V=5A, 100W max per port, total 200W
DC Output	12.6V30A, 378W max

Input		
AC Input	Charging: 100-120V~15A; 200-240V~12.5A, 50/60Hz Bypass: 100-120V~15A, 50/60Hz (duration < 3hrs when the current exceeds 12A)	
Power Input/Output	100-120~30A; 200-240V~30A, 50/60Hz	
High-PV	80-450V15A max, 4,000W max	
Low-PV	30-150V15A max, 1,600W max	
Other		
Temperature	Discharging temp: -20°C to 45°C (-4°F to 113°F) Charging temp: -20°C to 45°C (-4°F to 113°F) Storage temp: -20°C to 45°C (-4°F to 113°F) (optimum: -20°C to 45°C(68°C to 86°F))	
Altitude	≤3,000 m (9,842 ft.)	
IP Rating	IP54	
Noise Level	<30 dB	
UPS	Backup UPS <20 ms; online UPS 0 ms	
Communication Method	Bluetooth & Wi-Fi & 4G	

EcoFlow DELTA Pro Ultra Battery



General	
Model	EFYJ751-BP
Name	Rechargeable Li-ion battery pack
Net Weight	52.7 kg (116.4 lb)
Dimensions	660 × 455 × 204 mm (26 × 18 × 8 in.)
Capacity	102.4V60A, 6,144Wh
Battery	
Cell Material	LFP
Cycle Life	The battery maintains 80%+ SOH (state of health) after 3,500 cycles at 0.5C/0.5C at 25°C (77°F)

Protection type	Overvoltage protection, overload protection, overtemperature protection, short circuit protection, low temperature protection, low voltage protection, overcurrent protection
Other	
Temperature	Discharging temp: -20°C to 45°C (-4°F to 113°F) Charging temp: -20°C to 45°C (-4°F to 113°F) Storage temp: -20°C to 45°C (-4°F to 113°F) (optimum: -20°C to 45°C(68°C to 86°F))
Altitude	≤3,000 m (9,842 ft.)
IP Rating	IP54

NOTICE

- Specifications and notes herein may change without notification. EcoFlow reserves the right to modify the document due to product update.
- The IP rating is IP54 when the product is not in use.
- For most scenarios, noise level of the product is less than 30 dB.
- When the ambient temperature exceeds 40°C (104°F), the charging and discharging power are recommended to be equal to or less than 5,000W when charging and discharging the product at the same time.
- Whether the product can be charged or discharged depends on the actual temperature of the battery.
- The battery will automatically start self-heating if the temperature is lower than 0 °C (32 °F). To disable this, please set it in the app.

How It Works

Supported Appliances

Appliance Compatibility

Refer to the information below to ensure that your appliances are compatible with DELTA Pro Ultra. If you choose to proceed with incompatible appliances, DELTA Pro Ultra may not be able to provide backup power effectively. To avoid this, please check the following specifications carefully.

Compressor-based Appliances

For any compressor-based appliance, please ensure that the RLA (Rated Load Amps) and LRA (Locked Rotor Amps) of your appliances are compatible with the corresponding specs of the inverter. Compressor-based appliances include air conditioners, heat pumps, fridges, etc.

Max combined appliance rating per DELTA Pro Ultra

≤120A LRA or ≤20A RLA per DELTA Pro Ultra

	CTORY (HARGED	Value of	R410	A	15-73
	6	.75	LB2	3.0		1000
				G 16	,	
PO	HER SU	PPLY	208-	530 hor.	IS HC	
100			PH	THE RESERVE THE PERSON NAMED IN COLUMN TWO	HZ	
				E AT UNIT		1. 152.00
		253	MAX	197	MIN	200
	SU	ITABLE	FOR OUT	DOOR USE	170	Sec. C.
	OMPRES	SOR	208	1530 AOF.	TS AC	100
III.	199		PH	60	HZ	-
■1		14.1	RLA	77.0	LRA	
- 1			.208	1530 AOF	15 HC	
-1		1	PH	60	HZ	
_\		1/12	HP	0.50	FLA	
				SSURE GAGE		
		450	PSI	3103	KPA	
-	LO	250	PSI		KPA	
				NG PRESSUR	STORES NO.	
		UM CIRCL		4826		
	A THE REPORT OF THE PARTY OF THE PARTY.				30 A	
		30 A			-	
	Short C		nt:5kA rm	s,symmetrical,	230 U	
		MAMM				
	11	MODEL	IIMRED		GROOD	
	1	HODEL I	CHIDER	HEIST COLORS	UDANA.	

Resistive-based Appliances

Resistive-based appliances include tank water heaters, tankless water heaters, etc.

Maximum combined rating	Compatibility
7.2kW, 10.8kW peak	1 set of DELTA Pro Ultra
14.4kW, 21.6kW peak	2 sets of DELTA Pro Ultra

Backup System

Introduction

The DELTA Pro Ultra can be used to create a whole home backup system that stores power for your appliances using several schemes. You can check daily/monthly/yearly figures or configure settings via the EcoFlow app. You will enjoy an outage-free life after installing this whole home backup system, which is specifically suitable for emergency backup during hurricane seasons, power outage, peak power demand, and so on.

A

CAUTION

• The installation should be performed by a licensed electrician. Improper installation may result in death or serious injury and property damage.

• This section is for reference purpose ONLY and does not constitute legal advice. Please consult the local licensed electrician for detail.

Connection Schemes

EcoFlow Smart Home Panel 2

EcoFlow Smart Home Panel 2 connects up to 3 sets of DELTA Pro Ultra (1 inverter supports up to 5 batteries) and serves as an auxiliary distribution point for electricity from the main panel and provides extra breakers for your backup loads

- A. DELTA Pro Ultra (x3 sets max)
- B. EcoFlow Smart Home Panel 2 (sub panel)
- C. Main Panel
- D. Meter



Transfer Switch

Scheme 1


The EcoFlow 50 amp hub links up to two sets of DELTA Pro Ultra and acts as a power transfer center between DELTA Pro Ultra and the 50 amp transfer switch.

- A. EcoFlow DELTA Pro Ultra (x2 sets max)
- C. Main Panel
- D. Meter
- E. 50 Amp Transfer Switch
- F. EcoFlow 50 Amp Hub



Scheme 2

- A. EcoFlow DELTA Pro Ultra (×1 set)
- C. Main Panel
- D. Meter
- E. 30 Amp Transfer Switch



0

NOTICE

• For any transfer switch that does not include inlet box function, please connect an inlet box to DELTA Pro Ultra and the transfer switch.

Overview

Ports and Buttons

EcoFlow DELTA Pro Ultra Inverter



1	USB-C output port (100W)	Supports USB-C powered appliances with maximum 100W output.
2	AC power button	 Press once to enable or disable the corresponding AC ports. Press and hold for 10 seconds to switch the AC output frequency.
3	Main power button	 Long press for 1 second to power on. Press & hold for 2-3 seconds to power off. Press once to turn on/off the LCD screen. Press and hold for 5 seconds to reset Bluetooth when the product is turned off.
4	DC power button	Press once to enable/disable the corresnponding DC ports.
5	USB-A output port	Supports USB-A powered appliances.
6	DC output port	Supports cig lighters and other appliances.
7	Low-PV input port	Connect the inverter to solar panels for charging, with the total voltage between 30V and 150V.
8	PV switch	Turns on/off the PV switch to enable/disable solar charging.
9	4G dongle port	Insert the EcoFlow 4G Dongle PPS (NA) into this port to establish communication between the device and EcoFlow web portal.
10	AC output socket (120V 20A max. per port) - Backup UPS	Supports 120V 20A max output and 20 ms UPS per port.

Supports 120V 20A max output and 0 ms UPS per

AC output socket

11 (120V 20A max. per

	port) - Online UPS	port.
12	AC output socket (120V 30A max.) - Online UPS	Supports 120V 30A max output and 0 ms UPS.
13	AC output socket (120V/240V 30A max.) - Backup UPS	Supports 120V/240V 30A max output and 20 ms UPS.
14	Ground screw	Grounds the product in case of potential electric shock.
15	AC charging input port	① Connects the device to a wall outlet for charging.② Connects the device to a generator for charging.
16	AC charging speed switch	Adjusts the recharging speed of AC charging.
17	High-PV input port	Connects to solar panels for recharging with the total voltage between 80V and 450V.
18	Lock hole	Locks the lock hole (lock is not included in the package) to prevent accidental startup.
19	Power input/output port	① Connects to a generator for charging.② Connects to an EV charger for charging.
20	Battery port	Connects the inverter to the battery.


EcoFlow DELTA Pro Ultra Battery



1	Battery port	Connects the inverter to the battery.
2	Main power button	 ① Long press for 1 second to power on. ② Press & hold for 2-3 seconds to power off. ③ Press once to turn on/off the LCD screen. ④ Press and hold for 5 seconds to reset Bluetooth when the

3 LED indicator Displays status of power-on/off, and charging/discharging.

LCD Screen



1	4G connection	17	Output indicator
2	Wi-Fi connection	18	Total output power (apparent power) *
3	Bluetooth Connection	19	Power output
4	Backup mode	20	DC output
5	TOU mode	21	USB-A output
6	Low-temp warning	22	USB-C output
7	High-temp warning	23	Remaining battery percentage
8	Self-consumption mode	24	Remaining charging/discharging time
9	Battery failure warning	25	Number of batteries
10	Error report	26	Low-PV input
11	Error code	27	High-PV input
12	Ventilation fan	28	Power input
13	Charging limit	29	AC charging input
14	Timer	30	Total input power
15	Charging/discharging level	31	Input indicator

16 AC output frequency

* Apparent power


• The apparent power in the LCD screen displays the power supplied by the

power station to the appliances for the overall operation, generally higher than the power(active power) consumed by the appliances at work. The conversion is: active power = apparent power \times power factor (PF).

• Please check the power factor (PF) in [Device Homepage] - [Settings] - [Lab Feature] in the EcoFlow app.

See "LCD Screen Icons" for more details.

LED Indicator



Status	Description
Power on	LED 1 to 5 sequentially lights up
Power off	LED 5 to 1 sequentially shuts down
Discharging	81%~100%: LED 1 to 5 solid 61%~80%: LED 1 to 4 solid 41%~60%: LED 1 to 3 solid 21%~40%: LED 1 to 2 solid 1%~20%: LED 1 solid 0%: LED 1 to LED 5 blinking
Charging	0~20%: LED 1 blinks 21~40%: LED 1 remains solid, LED 2 starts to blink 41~60%: LED 1 to 2 remain solid, LED 3 blinks 61~80%: LED 1~3 solid, LED 4 blinks 81~99%: LED 1~4 solid, LED 5 blinks 100%: LED 1 to LED 5 remain solid

Installation




CAUTION


 Please ensure that the product is installed in a well-ventilated place and do not block the ventilation fans during operation. Insufficient ventilation may damage the equipment.

Mounting On Portable Stand

1. Install the portable stand, the battery and the inverter in sequence with the battery ports of both the inverter and battery installed on the same side, and ensure that the inverter and the battery are properly installed into the corresponding grooves.



2. Open the protective covers and connect the battery connection cable.



3. An inverter supports up to 5 batteries. During installation, please note that battery connection cables should be installed in the right sequence as in the illustration. If you connect more than 3 batteries, lock the brakes of the mount casters after installation.




CAUTION

- To avoid accidental unplugging, we recommend that you lock the battery cable. After you mount the battery cable, you can lock the cable with a flathead screwdriver; when you need to remove the cable, remember to unlock it first.
- For long-time use, do not move the whole set of products if you connect the
 inverter to three or more batteries and lock casters by flicking the brake
 down, so that the product can't be moved anymore. If you need to move the
 product, flick the brake up to unlock the casters.
- We suggest that you fix the whole set of products with fixing metal tabs if you connect 3 or more batteries to the inverter. The fixing metal tabs are installed on the battery directly under the inverter. The recommended installation distance from the wall is 5cm for the purpose of heat dissipation.




Find out more

- As the product is very heavy, we recommend that two people carry it to avoid potential personal injury.
- The portable stand needs to be installed on a hard, flat surface instead of soft surfaces (for example, dirt or sand). Do not place the portable stand on a tilted surface as it may cause the product to topple over, potentially resulting in personal injury or product damage.



Mounting Two Sets Of Units

If you have 2 sets of products, you can put one set on top of the other set. Be noted that the top set should be installed with supporting legs instead of casters.





CAUTION

- For this installation option, one can connect up to two batteries to an inverter.
- The EcoFlow Fixing Metal Tabs need to be fixed to the battery under the top inverter.

Mounting On A Shelf


If you plan to put the inverter and the battery in different places (for example on a shelf, on the ground, etc.), you can connect them with a 0.75-meter long battery connection cable.



Find out more

Mounting On The Trolley

To easily move the product, you can also mount the set on the trolley, but please note that you can only mount one inverter and one battery on the trolley.



Find out more

Power On/Off

Long press the main power button of the inverter or the battery for 1 second to turn on the device. Press and hold for 2-3 seconds to turn off the device.



Status	Description
Power on	long press for 1 second
LCD screen on/off	press once
Power off	press and hold for 2-3 seconds

NOTICE

- If the device is turned off, it will automatically turn on when you connect the product to a wall outlet.
- When the device is turned on, the LCD screen will light up; pressing the main power button again will turn off the LCD screen but will not turn off the product.
- If the inverter is connected to more than one battery, you can press & hold the main power button of any battery to turn on the product.
- The device will go into standby mode, with the LCD screen shut down, if it hasn't been used for 5 minutes. When you start to use the product again, the LCD screen will turn on automatically.
- The default standby time of the product is 2 hours. The device will automatically shut down if output power buttons are turned off or no loads are connected for 2 hours.
- Press and hold the main power button for 10 seconds to reset the Bluetooth connection.

Power Your Appliances

AC/DC Output

Press the AC power button to enable AC output ports, and press again to disable them.



Press the DC power button to enable DC output ports, and press again to disable them.




- Ensure that the product is turned on (see "Power On/Off" for more details)
 before enabling DC/AC output.
- Ensure that the total power of all loads is less than the rated power of the product.
- After 12 hours of no load for the AC output ports, the AC power button will turn off automatically.

EcoFlow 50 Amp Hub

You can connect one or two sets of DELTA Pro Ultra to the EcoFlow 50 Amp Hub for recharging your car or other NEMA 14-50 plug-based appliances. To successfully link one or two sets of DELTA Pro Ultra, follows steps below:


- 1. Connect one or two sets of DELTA Pro Ultra to the EcoFlow 50 Amp Hub.
- 2. Tap the main power button to power on DELTA Pro Ultra
- 3. Press the AC on/off button of the 50 Amp hub to link.



Charging Your Power Station

Charging From The Wall Outlet

You can recharge the product by connecting the supplied AC charging cable to the fast charging input port of the product and a wall outlet. To adjust the charging speed, you can either flick the AC charging speed switch or set it up in the EcoFlow app.



Adjust The AC Charging Speed

The charging speed can be adjusted via the AC charging speed switch. Turn the switch to the left, the charging speed will be at its peak; turn the switch to the right, and the charging speed will return to the default value. You can set the charging speed in the app.

A


CAUTION

• Keep the AC power button off while recharging the product through a high-voltage wall outlet.

Charging From The EV Charger

Connect your EV charger to the product to enable charging via the EV charger. If you are unsure how to connect your EV charger to the product, refer to the user manual for EV charger or contact the manufacturer for details. To enable EV charging, please follow steps as follows:


- 1. Connect one side of the EV adapter to the power input/output port and the other side to the EV charger.
- 2. Turn on main power button of DELTA Pro Ultra.



Charging From The Generator

Connect your generator to the product to enable charging via the generator. If you are unsure how to connect your generator to the product, refer to the user manual for generator or contact the manufacturer for details.

Ensure that the power of the product is lower than that of your generator, and then connect one side of the generator to the power input/output port or AC charging input port and the other side to the generator.



1 DELTA Pro Ultra supports conventional generators with THD less than or equal to 10%.

Charging From Solar Panels

▲ DANGER

- To securely connect this product to the PV system circuit, we recommend that you consult qualified personnel for installation and other details.
- Solar panels and high-PV input charging cables are not included in the box; please purchase them on the EcoFlow official website and ensure that solar connectors of solar panels are compatible with high-PV input ports.
- The total output of the solar panels and the sunlight intensity determine the duration of the solar charging.
- When connecting solar panels in series, ensure that the maximum voltage output of all panels is within 30V-150V for the low-PV input port, and 80V-450V for the high-PV input port (you can choose either low-PV or high-PV if the maximum voltage output of all panels is between 80V and 150V).
- To avoid product damage, ensure that the solar panels are properly connected to the low-voltage PV or high-voltage PV input port.
- If you connect the EcoFlow DELTA Pro Ultra to PV system circuits installed on or in buildings, according to NEC regulation, the system shall include a rapid shutdown function to ensure the safety of operation and reduce shock hazard for emergency responders.
- If you wish to connect the EcoFlow DELTA Pro Ultra to PV system circuits, the consultation before purchase and the installation must be done by a qualified electrician or installer.
- To connect two or more solar panels to the inverter, please ensure that you use the same type of solar panels.

A

WARNING

- Keep the PV switch "OFF" when connecting solar panels to the product.
- Whether you connect the solar panels to the low-PV input port or high-PV input port, you need to turn on the PV switch to enable solar charging once the solar panels are connected.



NOTICE


When the product connected to PV modules is put inside the building, it needs to be grounded to reduce the risk of electric shock. Before using the ground terminal, consult a qualified electrician, electrical inspector, or local agency having jurisdiction for local codes or ordinances that apply to the intended use of the product.



Connect to solar panels


- 1. Connect in series
- Low-PV input

Voltage range: 30V < total solar input < 150V




High-PV input

Voltage range: 80V < total solar input < 450V



• Low-PV input + high-PV input




2. Connect in parallel

We do not recommend that you connect solar panels to the device in parallel because the maximum current of high-PV and low-PV input ports is 15A; but if you need to, please ensure that total current input of solar panels does not exceed 15A.

Remove solar charging cables

To remove solar charging cables, especially cables connected to the high-PV input ports, follow steps below:

- 1. Turn off the PV switch.
- 2. Align the d/a tool with solar connectors and detach them manually once they have dislodged off from the high-PV input ports.



- Please refer to the following specs for more details if you are uncertain about the number of EcoFlow solar panels (Portable solar panels and Mountable solar panels) required for low-PV or high-PV input port.
- When the ambient temperature falls below 0°C (32°F), the input voltage of solar panels may increase, potentially exceeding the voltage range of DELTA Pro Ultra, which may lead to invalid input. Therefore, it is not advisable to connect 6, 8, or 10 panels in series with 220W portable panel, 400W portable panel, and 400W rigid panel at a low temperature.

EcoFlow 220W Bifacial Portable Solar Panel (series)




Quantity	Total Voltage (V)	Total Power (W)	Input Port
2	43.6	440	Low-PV
3	65.4	660	Low-PV
4	87.2	880	Low-PV
5	109	1100	Low-PV / High-PV
6	130.8	1320	Low-PV / High-PV

EcoFlow 400W Portable Solar Panel (series)



Quantity	Input Voltage (V)	Total Power (W)	Input Port
2	96	800	Low-PV / High-PV
3	144	1200	High-PV
4	192	1600	High-PV
5	240	2000	High-PV
6	288	2400	High-PV
7	336	2800	High-PV
8	384	3200	High-PV

EcoFlow 400W Rigid Solar Panel (series)




Quantity	Input Voltage (V)	Total Power (W)	Input Port
2	74.2	800	Low-PV
3	111.3	1200	Low-PV / High-PV

4	148.4	1600	High-PV	
5	185.5	2000	High-PV	
6	222.6	2400	High-PV	
7	259.7	2800	High-PV	
8	296.8	3200	High-PV	
9	333.9	3600	High-PV	
10	371	4000	High-PV	

Combined Charging


Solar charging + AC charging

Connect the product to solar panels and a wall outlet at the same time.



Solar charging + generator

Connect the product to solar panels and a generator at the same time.




NOTICE

• When both AC charging input port and power input/output port are

- connected to the product, the power input/output port will be preferably chosen for charging whereas AC charging will not be able to work
- When you connect the product to more than one option for recharging, you
 can either connect to low-PV or high-PV input ports only, or both low- and
 high-PV input ports.

UPS and X-Fusion


UPS: Power In Blackouts



UPS (Uninterruptible Power Supply) is a device or a system that provides continual power supply and protects your appliances from damage if the incoming power is interrupted.

DELTA Pro Ultra supports two types of UPS: online UPS and backup UPS. Connect the device to a wall outlet (see "Charging from the wall outlet") using the supplied AC charging cable and to your appliances at the same time, your appliances will receive power from the grid but not from the product. Once there is a power outage, the device will automatically power up your appliances with the stored power; if your appliances require 0 ms switching, we recommend that you connect your appliances to AC output sockets (online UPS) for uninterrupted power supply.

X-Fusion: Optimal Power Capacity




X-Fusion is an advanced technology that ensures all AC output sockets provide optimal output when the product is in bypass mode (when you recharge and discharge the device simultaneously, the device enables bypass mode automatically), in terms of wattage and amp. In the fast charging mode, the output will always be 7.2kW no matter how much the input is.

App Settings

1. App Download

The EcoFlow app provides an all-in-one experience for you to control, monitor, or customize your EcoFlow DELTA Pro Ultra from afar. To get started, you can download the EcoFlow app at the top of this page or search "EcoFlow" in App Store or Google Play Store.

2. Linking With Your Station



After registration, you will be notified by the app to "add" the device. If you can't receive this pop-up notice, then please add the device manually. To add the device manually, please follow steps below:

- 1. Click "Add" or the plus sign in the upper right corner.
- 2. Wait for the app to scan the available device and then click the product


icon.

3. Internet Setup

There are few ways to connect to DELTA Pro Ultra: Bluetooth, IoT and 4G.

- Bluetooth: Generally, you are notified to turn on Bluetooth when you bond
 the app with the device. Once the Bluetooth connection has been
 established between the app and the device, you can check the device's
 operating status and control/manage the device wirelessly via the app.
- IoT: After connecting to Bluetooth, select the icon next to Bluetooth and enter the correct password. Once connected, the device will switch to IoT mode.

4. General Setting



Rename

The default name for the product is its SN number. You can modify the product name in the general setting.

Device sharing

Enter the person's e-mail and wait for them to accept the invitation, then you'll be able to co-configure the device.

Timeout

There are four types of timeout: unit timeout (default time: 24 hours), screen timeout (default time: 5 minutes), AC timeout (default time: 12 hours), 12V DC timeout (default time: 12 hours)


- Unit timeout: if the device is not operating or has no load, it will automatically turn off once the preset timeout duration has lapsed.
- Screen timeout: If the device is under no operation, the screen will automatically shut off once the preset timeout duration has lapsed.
- AC timeout: If AC output is not operating or has no load, the AC power button will automatically shut off once the preset timeout duration has lapsed.

• 12V DC timeout: If DC output is not operating or has no load, the DC output button will automatically shut off once the preset timeout duration has lapsed.

Timezone

You can either allow the app to automatically track your time zone or manually select it.

5. Setting Your Power Station



Input Settings

In the input setting, you can adjust the charging speed of both the AC charging input port and power input/output port.

For AC charging, please remember to flick the "AC charging speed switch" to the right, check "AC Charging" in this online manual for details.)

Energy strategy

Automation (timer)

You can set a time or a period of time to charge or discharge DELTA Pro Ultra. The following modes are currently available: AC charging, AC discharging, and DC discharging.

Energy management

• Charging/Discharging level

You can set the charging and discharging level in energy management, the charging level range is 50%-100% and the discharging level is 0%-30%. Once settings are done, the device will stop charging or discharging at the preset levels.

You can set the charging and discharging level on this page, with a range of 0-30% for discharging level and 50-100% for charging level according to your preference. After the setting, the device will stop charging or discharging at the preset levels. After the levels are set, the icon of Charging/discharging level will show up in the upper right corner of the LCD screen.

Backup Reserve

You can enable the backup reserve feature by tapping the enabling/disabling button on the right. A higher backup reserve level will allow you to have a larger power reserve during power outages, whereas a lower backup reserve level will allow you to make better use of solar power. When the battery level is higher than the backup reserve level, DELTA Pro Ultra will be powered through solar charging and the AC input will be disabled; when the battery is lower than the backup reserve level, the device will start charging from AC charging.

Battery setting

You can set the battery to self-heat automatically by enabling the "battery preconditioning" in the battery setting.

Charging heating

Charging heating is automatically activated when ambient temperature is below 0°C (32°F) and the battery will be in charging mode. The activation sequence is as follows:

- Charging heating requires charging input ≥ 250 W. When the battery internal temperature rises above 5°C (41°F), the battery will start heating as well as charging process.
- 2. When the battery internal temperature rises above 10°C (50°F), charging heating stops, and battery charging continues.
- 3. The charging heating function works in a temperature range of $-20^{\circ}\text{C}\sim0^{\circ}\text{C}$ ($-4^{\circ}\text{F}\sim32^{\circ}\text{F}$).

Discharging heating

The capacity of the battery can be significantly reduced when discharging at high power at low temperatures. In the following ambient temperature conditions, the discharging heating feature will automatically start when the battery is discharging. The details are as follows.

- 1. When the temperature is below -10°C (14°F) and the remaining battery percentage is above 80%, the discharging heating will automatically turn off
- 2. When the temperature is below -5°C (23°F) and the remaining battery percentage is below 80% and above 60%, the discharging heating feature will automatically turn off.
- 3. When the temperature is below 0°C (32°F) and the remaining battery percentage is below 60% and above 30%, the discharging heating feature will automatically turn off.
- 4. If the battery level is less than 30%, the discharging heating feature will not turn off automatically.

6. TOU Mode



The TOU (Time-of-Use) mode is designed to help you save money on a fluctuating rate plan. It charges your battery when the electricity rate is low and discharges it when the rate is high.

Under normal circumstances, the TOU mode efficiently utilizes solar energy to prevent waste. Here's how it works: When solar energy is available, the TOU mode intelligently allocates the portions of the battery capacity to be charged from solar and the grid ahead of time. If plenty of solar energy is expected for the day, the grid won't be used to charge the battery unless the actual solar generation falls short. However, in cases where there's excess solar energy and the battery is already fully charged, some of that solar energy may go unused if the solar output doesn't meet the load power requirement.

Why doesn't my TOU schedule work?

Here are a few reasons that causes your TOU schedule to not work:

- The battery has reached its charging level.
- The battery level has dropped below the backup reserve level.
- Storm Guard has been activated due to severe weather conditions."

How do I set my electricity rate?

There are two options for setting the electricity rate:

- Go to the device settings page and find "Electricity rate settings".
- Alternatively, on the Operating mode page, you'll find a shortcut to electricity rate settings within the TOU mode section.

For more info, please che...

Troubleshooting

Both error code and error report icons usually show up together when there is any product fault, the error code icon shows a number and the error report icon starts blinking.

Error Error

code	description	Cause	Suggestion
66	Communciation failure with EcoFlow Smart Home Panel 2	Internal communication failure	Contact after-sales service if a forced shutdown doesn't work
94	Communication failure	The EV charger hasn't received data from DELTA Pro Ultra after 5 seconds	Plug in the EV X-Stream adapter againPlease contact after-sales service if the problem persists
103	DC output port overcurrent	DC output port short-circuit or overload.	 Check if the DC output port is short-circuited or check the spec of the load connected to the port (12.6V/30A). Re-enable the DC output. Contact the after-sales service if a forced shutdown doesn't work.
171	Low-PV input overvoltage	The supply voltage of connected solar panels is too high	Ensure that solar panels are in good condition
177	Weak sunlight protection for Low-PV input	The connected solar panel(s) has/have insufficient power	When there is sufficient sunlight, re-connect the solar panels
274	AC charging input port overcurrent	Power of loads higher than specifications	Lower the output load and plug in the AC charging cable again
297	L2 bypass overload	Power of loads higher than specifications	Lower the output load and plug in the AC charging cable again
402~408	AC output socket 1-7 overload	AC output socket overload	Ensure the loads connected to the ports meet the specs
433	Current overload	Overcurrent at the output port of the EcoFlow 50 Amp	Replace with loads of lower power or reduce the number of loads
457	Weak sunlight failure	Insufficient sunlight	 Ensure that solar panels are in good condition and there is sufficient sunlight Plug solar panels in the high-PV input port again or reboot the device
509	High discharging temperature	The battery temperature is too high	Charging can be resumed automatically after the battery temperature cools down

510	Low discharging temperature	The battery temperature is too low	Charging can be resumed automatically after the battery temperature rises
511	High charging temperature	The battery temperature is too high	Charging can be resumed automatically after the battery temperature cools down
512	Low charging temperature	The battery temperature is too low	Charging can be resumed automatically after the battery temperature rises
523	Charging level protection		
524	Discharging level protection		

If you encounter other error codes, please contact after-sales service for details.

Maintenance

EcoFlow DELTA Pro Ultra Inverter

Ask qualified personnel to check or maintain the product, and replace the original components with identical replacements.

Use clean and dry cloth or paper to clean dirt or stains off the ports. Do not clean the product with chemicals or corrosive materials.

For safety reasons, turn off the product before maintenance to avoid the risk of electric shock.

Check the product regularly according to the following checklist:

Item	Method	Maintenance Interval
Heat dissipation	Check periodically that vents are free from obstacles and dust.	Every 3 months
Dirt cleaning	If there is any stain/dirt, use a dry, soft cloth to wipe it off. Please don't use any abrasives or chemical liquids to clean the product.	Every 3 months
System running status	1. Check that the product is not damaged or deformed. 2. Ensure the product operates with no abnormal sound.	Every 3 months
Cable connection	Ensure all cables are intact and securely connected.	Every 3 months

EcoFlow DELTA Pro Ultra Battery

- 1. If the ambient environment is higher than 45°C (113°F), we recommend that you stop using the battery for at least 20 hours for heat dissipation between two charging/discharging cycles.
- 2. After setting the charging and discharging levels, the battery will be fully charged automatically for calibration if it is not fully charged after a month or 30 cycles. After calibration, the battery will continuously work at the preset charging and discharging levels.
- 3. We recommend that you should use and store the battery at an ambient temperature of 20°C to 45°C. Keep the battery away from humid places (water, rain, etc), heat sources, and metals.
- 4. For a long-term storage, please discharge the battery every three months (firstly discharge it to 0%, then fully recharge it, and lastly discharge it to 60%); the battery will not be covered by the warranty if it is not charged or discharged for more than 6 months.
- 5. For battery safety and lifespan, do not store the battery at the temperature above 45°C or below -20°C.
- 6. If the battery level drops below 1%, charge the battery to 60% before storing it. Storing the battery for a long time may cause serious damage and shorten the usage cycle.
- 7. If the battery is stored for a long period of time with significantly low battery level, it will go into deep sleep mode and must be charged and released from deep sleep mode before use again.

What's in the Box

EcoFlow DELTA Pro Ultra Inverter



- EcoFlow DELTA Pro Ultra Inverter (×1)
- EcoFlow Portable Stand (×1)
- EcoFlow Supporting Leg (×4)
- M6*20 (×4)
- EcoFlow Side Mount Caster (×4)
- EcoFlow Disassembly and Assembly Tool (×1)
- EcoFlow Solar to Low-PV Port Charging Cable (×1)
- EcoFlow AC Charging Cable (x1)
- User Manual & Warranty Card

NOTICE

The EcoFlow DELTA Pro Ultra Inverter must be used together with at least one EcoFlow DELTA Pro Ultra Battery as a whole set.

EcoFlow DELTA Pro Ultra Battery



Accessory List

Find out more

Safety Instructions

Symbol Explanations

These are safety warning symbols. Such safety information alerts you to hazards that can be lethal to you and others, and that can cause damage to the equipment. All safety information is preceded by safety warning symbols and hazard words, including: "DANGER", "WARNING", "CAUTION", and "NOTICE". The "DANGER", "WARNING", "CAUTION", and "NOTICE" statements in this manual do not cover all the safety instructions. They are only supplements to safety instructions.



Very high risk. If not avoided, it could lead to severe injury or even death.



Moderate risk. If not avoided, it could lead to severe injury or even death.



Lower risk. If not avoided, it may result in minor or moderate injury.



Potentially hazardous. If not avoided, it could result in equipment damage, data loss, performance deterioration, or unanticipated results.

Disclaimer

Please read this document and ensure you understand it fully before using the product. Please keep this document properly for future reference. In addition, in this document and other related documents, EcoFlow DELTA Pro Ultra is referred to as DELTA Pro Ultra, EcoFlow DELTA Pro Ultra Inverter is referred to as the inverter, and EcoFlow DELTA Pro Ultra Battery is referred to as the battery. Failure to properly operate this product could cause serious injury to yourself or others, or cause damage to this product and other property. By using this product, you are deemed to have understood, acknowledged and accepted all terms and contents of this document. Individual users are responsible for their actions and the consequences of those actions. EcoFlow hereby disclaims any liability for any losses due to the user's failure to use the

product in accordance with the document.

In compliance with laws and regulations, EcoFlow reserves the right to final interpretation of this document and all documents related to the product. This document is subject to changes (updates, revisions, or termination) without prior notice. Please visit EcoFlow's official website to obtain the latest product information.

Warning

SAVE THESE INSTRUCTIONS – This online manual contains important instructions for model EFYJ751-PCS-US and EFYJ751-BP that shall be followed during installation and maintenance.

- 1. Before installing, using and maintaining the product, please read carefully the safety instructions in this manual. EcoFlow is not responsible for any problems caused by improper handling of the product in installation and maintenance procedures.
- 2. Do not use parts or accessories that are not officially supplied. Use of third-party accessories may result in risks such as fire and electric shock. If parts or accessories are necessary, please visit EcoFlow's official sales channel for purchase information. EcoFlow is not responsible for product problems caused by the use of cables and other accessories produced by third-party manufacturers.
- 3. Keep this product out of the reach of children and pets and close attention is required to prevent potential hazards when children or pets are close to the device.
- 4. Strictly comply with the ambient temperature in this User Manual when using this product. If the temperature is too high, the battery may catch fire or explode. If the temperature is too low, the product may not work normally.
- 5. Do not disassemble, modify or replace this device (including internal and external parts), if necessary, please contact qualified professionals or contact EcoFlow after-sales service for handling.
- 6. Do not place other heavy objects (except the inverter and batteries) on the device during use or storage.
- 7. Avoid impacts, falling, dropping or strong vibrations. In the case of severe external impact, please turn off the power immediately and stop using the product. Ensure the product is well fastened during transportation to avoid vibrations and impacts.
- 8. If the product falls into water accidentally during use, place it in a safe open area and stay away from it until it is completely dry. The dried product should not be reused and should be disposed of properly as described in the "Disposal" section below. If the product catches fire, please use a fire extinguisher or fire-fighting equipment in the following recommended order: water or mist, sand, fire blanket, dry powder, and carbon dioxide fire extinguisher.
- 9. Handle this product with care to prevent it from being damaged due to overturning. If the product is badly damaged after overturning, please turn off the power immediately, place the battery in an open area away from combustible materials or people, and properly dispose of it according to the requirements of local laws and regulations.
- 10. Electromagnetic fields created by this product may affect the normal functioning of medical implants or personal medical devices, such as

pacemakers, cochlear implants, hearing aids, defibrillators and so on. If you are using these medical devices, please consult the manufacturers about the restrictions on the use of relevant devices to ensure that a safe distance is maintained between this product and the implanted medical devices (such as pacemakers, cochlear implants, hearing aids, defibrillators and so on) during operation.

- 11. When the power supply is connected in normal mode to a refrigerator, power fluctuations of the refrigerator may cause the device to automatically shut down. Therefore, when the device is connected to a refrigerator that stores medicine, vaccines or other valuable items, it is recommended to set the AC output to "Always On" in the app in order to guarantee continuous power supply, and please pay attention to the power consumption of the device.
- 12. After the installation is completed, clean up the items in time, such as cartons, foam, plastic, cable ties, etc.

Environmental Requirements

- 1. Ensure that the device is installed in a ventilated environment, and do not block the vents when the device is in operation. Inadequate ventilation may damage the device.
- 2. Do not use this product near heat sources or high temperatures (e.g. fire sources or hot stoves). To prolong the battery life, it is recommended to use or store this product at 20°C to 30°C.
- 3. When installing or using the product in an environment near fumes, smoke, heat, steam or dust, it is necessary to use a protective cover to prevent the risk of fire.
- 4. The installation environment should be hard flat ground. Due to the large mass of the device, it is necessary to ensure that the installation environment of the device is stable and that the equipment does not tilt to avoid personal injury or product damage.
- 5. Keep the product away from humid environments, do not immerse it in water or get it wet. If the product is installed or placed near the sea or any waterways, we recommend using moisture barrier bags to prevent the product from getting soaked, otherwise, it may cause a risk of fire. If water is found inside the product, please turn off the product and stop using it again. Take anti-electric shock measures before touching the product, and put it immediately in a safe, waterproof and open area. Contact qualified personnel or EcoFlow after-sales service if necessary.

Safety Requirements

- 1. Do not stand, lean or sit on the device.
- 2. If the product will not be used for a long period of time, make sure that it is unplugged from the outlet and turned off.
- 3. Do not connect this device with damaged cables. Use of damaged cables may affect the normal operation of the device or lead to potential risks.
- 4. Do not put your hands or foreign objects into the device ports or vents.

Disposal Requirements

EcoFlow DELTA Pro Ultra Inverter

If the inverter can not work anymore, dispose of it according to the local disposal requirements for electrical equipment waste. The inverter cannot be disposed of together with household waste.

- 1. Power off the inverter before removing it, for details, check **Power On/Off** in the online manual.
- 2. Sequentially disconnect the fast charging input cable, PV input cables, battery cables, and all the other modules connecting to the inverter.
- 3. Remove the inverter and the battery from the portable stand.
- 4. Pack and store the inverter properly.

EcoFlow DELTA Pro Ultra Battery

- If conditions permit, make sure that the battery is fully discharged before
 disposing it in a designated battery recycling bin. The product contains
 batteries with potentially dangerous chemicals, so it is strictly prohibited to
 dispose of it in ordinary trash cans. For more details, please follow the local
 laws and regulations on battery recycling and disposal.
- 2. If the battery cannot be fully discharged due to a product failure, please do not dispose of the battery directly in the battery recycling box. In such case, you should contact a professional battery recycling company for further processing.
- 3. Please dispose of over-discharged batteries that can not be recharged.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

IC Warning

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil nedoit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.