

OPEN EAR HEADPHONES FOR KIDS



User's Guide and Warranty


Operating Instructions and Warranty description

Illustration of the keys



List of accessories

1. Ear protection bluetooth headset
2. Magnetic charging data cable
3. Instruction manual



Microphone

volume +

volume -

List of accessories

1. Ear protection bluetooth headset
2. Magnetic charging data cable
3. Instruction manual

Magnetic charging port

Operating instructions

serial number	function	How-to	state
1	Boot	Press and hold the "+" button for 3 seconds in shutdown state	The blue light is on, and the voice prompt is turned on
2	Pairing status	-----	Red and blue lights flash alternately
3	The connection is successful	-----	The lights go out
4	Bluetooth is disconnected	Turn off device Bluetooth or move out of the range, Bluetooth will be disconnected	Red and blue lights flashing alternately, voice Prompt to disconnect
5	Shutdown	Press and hold the "+" button for 3 seconds during the power-on state	The lights are off and the voice prompt is turned off
6	Automatic reconnect	The machine automatically returns to the last connection of Bluetooth devices	-----
7	Disconnect and shut down	No connection for 5 minutes, automatic shutdown	The lights are off and the voice prompt is turned off
8	Clear the pairing record	When the device is not connected to the power-on, press and hold the volume-Key 5S Clear pairing record	Knock knock
9	Volume+	Click the "+" key to increase the volume by one stop	When the volume is at its highest, the drip prompts
10	Volume-	Click the "-" key and the volume is reduced by one stop	-----
11	Pause/Play	In the music playback status, double-tap the + keys to switch Pause/Play	-----

Operating instructions

Serial number	Function	How-to	State
13	Next song	Long press 15 to lift the next song	-----
14	Reject the call	Press the "+" button for 1 second for incoming calls	-----
15	There is telephone access	You have incomistry "+" Doodle...	-----
16	Answer the phone	When a call comes, click the "+" key	The lights go out
17	Hang up	While on a call, press and hold the "+" button for 1 second	-----
18	Charging	Link the Type-C charging cable to enter the charging mode, it automatically shuts down when charging	The red light is on
19	Charging complete	The battery is fully charged and charged as soon as it is charged	The blue light stays on
20	Low battery alarm	Notification tone Low battery Please charge	Every 5 seconds
21	Intelligent voice mode	In the Bluetooth connection status, press and hold the - button for 1 second, Raise your hand to enter voice mode	-----
22	TF memory mode	In the power-on state, double-click the - key to switch Memory/Bluetooth mode	-----
23	Memory download	Connect the headphones to the computer via a magnetic cable Eject the USB flash drive	-----

Feature tips

Bluetooth pairing: in the shutdown state, press and hold the "+" button for 3 seconds to turn on, the indicator light enters the red and blue light flashing state, enter at this time. Enter the pairing status, turn on the Bluetooth (mobile phone/computer/tablet) on the device, search for the device name "X12 Pro", and click Set Prepare "X12 Pro" pairing connection, and it can be used after the connection is successful.

Bluetooth/MP3 mode switching: double-click the "+" key to switch Bluetooth and memory mode (boot default Bluetooth mode)

Two music mode switching: long press the volume "-" key to switch the volume mode, boot the default child mode (low volume)

Product specifications

Model ----- X12 Pro

BT version ----- 5.3

Standby time ----- 10 days

Charging time ----- 2 hours

Music playback time ----- 10 hours

Protocols: A2DP, AVRCP, HSP, HFP

Waterproof level: IPX5

Horn impedance ----- 32 ohms

The microphone sensitivity ----- 38dB

Product weight ----- about 29g

Connection distance ----- 10 meters

Battery ----- 160mA

Music formats: MP3, WMA, WAV, APE, FLAC

Troubleshooting

Unable to power on

Check if the headphones are fully charged, if the keys are not misoperated, and if charging is active simultaneously.

Unable to connect via Bluetooth

If the headphone indicator is alternating between red and blue flashing or if it's turned off or flashing blue, it indicates that the headphones are not in pairing mode. In this case, please ensure that no other devices are connected, and disconnect any currently connected devices."

Unable to connect back

Check if the front end (e.g., Bluetooth phone) is powered on properly.

The headphone volume is low

Adjust the earphone volume, verify the correct wearing style, and ensure that the headphone is not set to a children's volume mode.



Customer support

Thank you for choosing our headphones.

We are a professional factory specializing in headphones and are the supplier of many big brand owners. The Kids' Open-ear Headphones are one of the mature products in our factory.

We stand by our commitment to provide a lifetime of after-sales service to our valued customers. Your satisfaction is our top priority. If you have any inquiries about the product or require assistance in its usage, please don't hesitate to reach out to us.

You can contact us via Amazon chat or email, and our dedicated support team will promptly address your concerns and ensure your complete satisfaction.

Email: support@foley-us.com

We look forward to assisting you with any needs you may have.