



DESIGNERS GUIDE

RoofSafe™ Anchors

Always read and follow the warnings and instructions for use

© Copyright Capital Safety Systems Ltd 2013



THE ULTIMATE IN FALL PROTECTION

RoofSafe™ Anchor

Contents



1.0 FOREWORD

2.0 GENERAL

- 2.1 Authorised Installers
- 2.2 Conformity
- 2.3 Work Restraint & Fall Arrest
- 2.4 Free Fall Space Calculator

3.0 SITE ASSESSMENT

- 3.1 Reviewing the Task
- 3.2 Typical System Layout
- 3.3 Specifying Your Anchor
 - 3.4.1 Wood Deck (Built up)
 - 3.4.2 Metal Deck (Built up / Composite)
 - 3.4.3 Solid Concrete (Built up)
 - 3.4.4 Hollow Concrete (Built up)
 - 3.4.5 Trapezoidal Insulated Panel
 - 3.4.6 Standing Seam
- 3.5 Sealing Details
- 3.6 Aggressive & Hazardous Environments
- 3.7 Rescue Planning

4.0 ROOFSAFE™ ANCHOR PERFORMANCE

- 4.1 Anchorage Strength
- 4.2 Forces on the SpiraTech™ Anchor
- 4.3 Forces on a Tip Over Anchor
- 4.4 Thermal Bridging

5.0 ANNUAL MAINTENANCE

- 5.1 Testing the Roof Anchor
- 5.2 Testing the Swages
- 5.3 Cleaning the Anchor

6.0 REFERENCE DOCUMENTS

- 6.1 Abbreviations and Definitions
- 6.2 Standards Table
- 6.3 Markings Explained
- 6.4 Inspection log.

1.0 FOREWORD

It is important that this guide is read and fully understood before the RoofSafe™ Anchors or RoofSafe™ Cable system is installed or serviced. The RoofSafe™ Anchor has been designed to prevent or minimise the risk of injury from falls. Incorrect design, installation or servicing through failure to adhere to these instructions could result in serious consequences.

This guide outlines applications for each anchor and each typical roof type that the designer may encounter including recommended fixing types and methods. It explains the forces on the anchor and the system and how this relates to the forces transferred to the roof structure.

Information on the anchors performance, details of standards to which the anchors conform and testing which has been carried out by Capital Safety are given for reference to ensure that the correct product is being used for each specific application.

It is important that management ensure that personnel who they direct to install or service the RoofSafe™ Anchor products are trained to the standards expected by Capital Safety.

This guide is an essential reference document for designing a RoofSafe™ Anchor and RoofSafe™ Cable System.

RoofSafe™ Anchor

2.0 General



2.0 GENERAL

2.1 AUTHORISED INSTALLERS

Only competent installers certified by Capital Safety are allowed to install and service the RoofSafe™ Anchor or RoofSafe™ Cable System.

2.2 CONFORMITY

The RoofSafe™ Anchor System is a roof top anchorage system which is tested and where appropriate certified in accordance with the requirements of various national and international standards and codes of practice. Details can be found in standards table, Section 6.2.

Components or parts are not to be altered, modified, dismantled or be replaced with items not supplied or manufactured by Capital Safety, such action will invalidate any certification and could result in serious or fatal consequences.

Parts or components not supplied by Capital Safety may be of inferior specification and may cause incorrect operation of the system.

2.3 WORK RESTRAINT & FALL ARREST

The RoofSafe™ Anchor is a complete fall protection system. It has been designed to solve problems relating to falls from a height. All Anchors for all structure's must be designed for fall arrest, although it is best to restrain the user to prevent a fall occurring.

WORK RESTRAINT

The advantages with work-restraint are that:

- Workers do not have to be subjected to the abrupt impact of an arrest as would be the case in a fall-arrest system, or risk falling into a hazard e.g. water or a hazardous substance.
- The user can not be injured from swing-fall incidents.
- There is no need for any rescue provision.
- Personnel require less training.

RoofSafe™ Anchor

2.0 General



In a work restraint system, to prevent the worker from entering an area where they could fall, there are two dimensions which need to be strictly controlled:

- The lanyard length A (Fig 1)
- The distance from the Anchor to the fall hazard B (Fig 1)

A scale drawing should be made to ensure that the lanyard (including connectors) will always prevent the user from entering a fall arrest situation. If the position of the fall hazard relative to the Anchor varies this analysis should be performed at various points along the length of the system.

Work Restraint Orientation




FIG 1

Fall Arrest Orientation




FIG 2

FALL ARREST

Where a work restraint system cannot be employed, a fall-arrest system has to be used. The disadvantage is that a worker has to fall before the system can operate (Fig 2) and arrest the fall. This is achieved by applying a braking force to the worker for a few hundredths of a second. The RoofSafe™ Anchor and RoofSafe™ Cable systems ensure that the braking force is always kept below a safe load, providing that the worker is wearing a full body harness and an energy-absorbing lanyard certified to the appropriate national standard.

When designing the roof safety system, be aware of falls through fragile elements as well as falls from exposed edges.

In a fall arrest situation appropriate rescue procedures must be in place to return the worker to safety as soon as possible. Refer to the Rescue planning section of this guide (Section 3.7).

IMPORTANT NOTE

Whilst all horizontal lifeline systems must be designed for Fall Arrest in case of accidental misuse, it is recommended that system should be designed for Work Restraint. This design enables a user to access their work area whilst being prevented from being exposed to a fall hazard. This design will reduce risk and mitigate the consequences of a fall.

RoofSafe™ Anchor

2.0 General



2.4 FREE FALL SPACE CALCULATOR

Capital Safety provides a calculation tool which helps the designer to assess the recommended free space required below the system to ensure that the system is safe to use. The calculation tool and information on how to use it is available from Capital Safety separately from this guide.

Below is a picture of the calculation sheet (Fig 3)

Free Fall Space Calculator



RoofSafe™ Anchors
RoofSafe™ Cable

Using the input boxes below, change the values to suit the length of your RoofSafe Cable & Anchor system.
Note: Calculations are based on maximum span widths (12m) with the fall occurring in the midspan of the system.

Project Name		Date	
--------------	--	------	--

Inputs

Title	Character	Units	Values	Description
Lanyard Length	L	m		Total length of lanyard
Edge Distance	E	m		Distance from the edge of the roof to the system
Number of Users	U	#		Total number of users per span
D-Ring Height	D	m		Height from roof surface to the user connection point
System Length	S	m		Total length of system (or section of system)



Outputs

Title	Character	Units	Value
Fall potential	FP	m	
Fall factor (fall potential / lanyard length)	FF	m	
Minimum distance required below platform level	MD	m	
Maximum end loads	ML	kN	



Issue No: 01

Issue Date:
05/03/2012

FIG 3

Issue Date: 10/05/13

Issue No: 2

6

3.0 SITE ASSESSMENT

3.1 REVIEWING THE TASK

Only installers certified by Capital Safety are allowed to install and service the RoofSafe™ Anchors and RoofSafe™ Anchor Cable Systems.

SITE SURVEY

At the start of each job a site survey should be carried out to assess the type and location of the system required. Accurate measurements should be taken to make sure that the system will fit the required area correctly.

During a site survey the following information should be gathered:

- The purpose of the system / Task to be performed
- The maximum No. of people that will be using the system at any one time.
- The specification and manufacturer of the roof to which the system will be fitted, including critical dimensions such as seam/crown centres and insulation thickness
- Scale drawings of the structure or building (in digital format if available)
- The exact path of the system
- Any special requirements from the architect or the customer such as; a specific type of bracket, or particular considerations for historical buildings.
- The risks to the installers so that suitable risk controls during installation can be planned.

When seeking technical support on a specific job, the Capital Safety sales team will be able to help you more quickly if you have the above information available as a minimum.

METHOD STATEMENTS

Before work begins a method statement should be written by the installer, agreed with the client and signed by both the parties. This is a detailed step by step guide of how the work is to be carried out by the installer.

The method statement protects both the client and the installer in the event of the work not being carried out in a safe manner, and can be used to ensure that the workers are adhering to safe and suitable working practices while carrying out the work.

VERIFYING THE ROOF STRUCTURE

The strength of the roof structure should be verified before the system is fitted to ensure that the fixings are strong enough to hold the anchor onto the roof. This can be done by calculation or through roofing approvals. Contact Capital Safety for any specific roof testing that may be relevant to the roof profile


Where these methods can not be used to verify the strength of the structure and the fixings, a sample fixing should be installed, and pull tested. The fixings should withstand as a minimum the forces given in the RoofSafe™ Anchor Forces Calculation Sheet.

RoofSafe™ Anchor

3.0 Site Assessment



3.2 TYPICAL SYSTEM LAYOUT



KEY:

- A - SpiraTech™ Anchor as System end post
- B - SpiraTech™ Anchor as Corner post
- C - Tip Over Anchor as Intermediate post
- D - SpiraTech™ Anchor as System t-joint, with RA throw plate
- E - SpiraTech™ Anchor as Variable post for roof hips

GAINING ACCESS TO THE ANCHOR

The entry point is defined as the point where the user can attach to the system. The exit point is defined as the point where the user can detach from the system. The entry point and the exit point can be at the same position. It is important to remember that the user is not fully protected from a fall until the safety lanyard and harness are attached and secured to the attachment eye or Unigrab, via a carabiner. Consideration should always be given to the positioning of the Anchor in regards to the above. The entry point should always be in a safe area, i.e. free from fall hazards. Where this cannot be achieved, a secondary means of fall protection needs to be installed to give protection whilst bridging the gap between the access route and the Anchor. The same consideration needs to be made in respect to the exit point, should it be in a different position to the entry point.

SWING FALLS

Swing falls can be fatal when working near a gable end. Fig 8 shows a worker using a rope and grab at maximum extension near a gable end. In this case the flank length exceeds the ridge height so if the user falls they have inadequate clearance to ground level. Another risk is the slicing effect of the edge of the roof on the rope or lanyard as the user falls. This situation must be avoided. Installation of edge protection to the end elevation and installing the Anchor inboard of the roof eaves can help to alleviate this issue.




FIG 8




FIG 9.1




FIG 9.2

Fig 9.1 shows the potential swing fall and the inaccessible areas. Fig 9.2 shows how the swing fall potential can be limited when using a manually adjustable lanyard and an single point anchor as an anti swing fall post. Further information can be found in BS7883:2005.

RoofSafe™ Anchor

3.0 Site Assessment



3.3 SPECIFYING YOUR ANCHOR

The RoofSafe™ Anchor provides a secure anchor point for a worker at height, close to an exposed edge or other fall hazards, when used in conjunction with associated PPE, such as a full body harness and a energy absorbing lanyard.

The RoofSafe™ Anchor is designed to re-orientate and deploy an energy absorber in the event of a fall, thereby reducing the load transferred to the user and the roofing system. The Anchor can be used for both fall arrest and work restraint applications.

There are two types of Anchors within the range. The SpiraTech™ Anchor and the Tip Over Anchor. Both anchors are modular in design allowing for speed of fitting and use.

Both Anchors allow the user to walk 360 degrees around the anchor without needing to reorientate the lanyard or connectors. The Anchor allows full weather sealing to prevent water ingress, and allows different roof membranes to be fitted and sealed around the anchor for true weather proofing.

The modular design allows the designer to chose and purchase the baseplate, module and top attachment separately. This gives true flexibility for application to any roof type or membrane.



FIG 10.1 BASE PLATE

+



FIG 10.2 SPIRATECH™ OR TIP OVER MODULE

+



FIG 10.3 ATTACHMENT EYE




FIG 11.1 ASSEMBLED SPIRATECH™ ANCHOR

Can be used as a single point anchor for up to two users




FIG 11.2 ASSEMBLED TIP OVER ANCHOR

Can be used as a single point anchor for one user.

RoofSafe™ Anchor

3.0 Site Assessment



BASE PLATES

The base plate designs incorporate several fixing holes to allow the same plate to be fitted on dissimilar roof types. The base plates also accommodate common roof pitch centres, allowing the baseplates to be used in two orientations. There are two blank base plate sizes for roofs that do not have typical centres (not shown).




FIG 12.1

RA Baseplate 405mm X 405mm

Available with holes or blank




FIG 12.2

RA Baseplate 350mm X 440mm

Available with holes or blank




FIG 12.3

RA Baseplate 550mm X 450mm


PITCH MATRIX

Roof Type	Pitches (mm)														
	Trapezoidal												Standing Seam		
Base Plates	200	250	275	300	304	333	334	347	350	367	400	500	200	300	400
RA Base Plate 405x405 Holes 7241136	X	X	X	X	X		X	X		X					
RA Base Plate 405x405 Blank 7241137	X	X	X	X	X	X	X	X	X	X			X	X	
RA Base Plate 350x440 Holes 7241138											X		X	X	X
RA Base Plate 350x440 Blank 7241139	X	X	X	X	X	X	X	X	X	X	X		X	X	X
RA Base Plate 550x450 Blank 7241140	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X

NOTE: This table assumes the baseplate can only be fitted on the centre of the crown of the trapezoidal roof sheet, if the fixings do not have to be central to the crowns the plates will fit sizes other than those stated. Always check with the roof manufacturer for guidance


PITCHES FOR TOGGLE FIXING

The RA Baseplate 405x405 H (7241136) incorporates hole centres for the toggle fixings. The holes are set at two pitches of 333 and 200. Capital Safety have done extensive research to ensure that these fixing centres are suitable for as many styles and pitches of roof deck as possible. If you find that the standard holes are not suitable for a particular roof type, the blank baseplates can be drilled with the correct hole type in alternative locations. If you have any queries contact Capital Safety.



3.4 ROOF TYPES AND ANCHORS

Images of anchors in this section are for indicative purposes only



3.4.1 WOOD DECK, (BUILT UP)


Built up roof type with rigid insulation and wooden roof deck. The deck must be a minimum thickness of 18mm

Fixings:

RoofSafe™ Anchor Toggle Fix 150mm x 4 (7241182)

RoofSafe™ Anchor Toggle Fix 300mm x 4 (7241183)

FIG 13.1



3.4.2 METAL DECK, (BUILT UP / COMPOSITE)


Built up or composite panel roof with rigid insulation and a Trapezoidal metal deck.

Fixings:

RoofSafe™ Anchor Toggle Fix 150mm x 4 (7241182)

RoofSafe™ Anchor Toggle Fix 300mm x 4 (7241183)

FIG 13.2



3.4.3 SOLID CONCRETE, (BUILT UP)

Warm solid concrete roof with rigid insulation.

Fixings:


RoofSafe™ Anchor Concrete Fix 150mm x 4 (7241180)

RoofSafe™ Anchor Concrete Fix 300mm x 4 (7241181)

FIG 13.3

RoofSafe™ Anchor

3.0 Site Assessment



3.4.4 HOLLOW CONCRETE, (BUILT UP)


Warm hollow concrete roof with rigid insulation.

Fixings:

RoofSafe™ Anchor Concrete Fix 150mm x 4 (7241180)

RoofSafe™ Anchor Concrete Fix 300mm x 4 (7241181)

FIG 13.4



3.4.5 TRAPEZOIDAL INSULATED PANEL


Pre-insulated/

Built up metal roof panels.

Fixings:

RoofSafe™ 7.7 Rivet (7234005)

FIG 13.5



3.4.6 STANDING SEAM

Standing seam roof, Aluminium Steel or Stainless Steel. Posts can be fitted to a range of seam profiles and roof sheet materials, see details on page 14.

FIG 13.6

RoofSafe™ Anchor


3.0 Site Assessment



STANDING SEAM ROOFING SYSTEMS

When Specifying a RoofSafe™ Anchor for a standing seam consideration should first be given to the Standing Seam profile and the type of clamps that will be required to secure the anchors to the roof

Capital Safety provides a range of fixing clamps to fit to varying roof seam profiles. Details on individual clamp compatibility can be provided by Technical Services.



The baseplate selection will be based on the roofing centres, see the matrix on page 11 for more detail.

IMPORTANT NOTE:


It is recommended to avoid fitting clamps directly over halter clips as this will affect the performance of the clamp and the roof. Always refer to the roofing manufacturer for guidance.

RoofSafe™ Anchor

3.0 Site Assessment




3.5 SEALING DETAILS



PVC MEMBRANE

- A PVC bonded onto the weather shroud up to the ridge
- B RA weather shroud PVC
- C Baseplate
- D Toggle fixing sealed in under the membrane


RA Module PVC SpiraTech™ / Tip Over



BITUMEN MEMBRANE

- A Bitumen sealed onto the weather shroud up to the ridge
- B RA weather shroud
- C Baseplate
- D Toggle fixing sealed in under the bitumen


RA Module BIT SpiraTech™ / Tip Over



OTHER MEMBRANES

- A Membrane sealed over the baseplate and up to the top of the can
- B RA Weather Cap
- C Baseplate
- D Toggle fixing sealed in under the membrane
- E RA Seal Ring

RA Module All Mem SpiraTech™ / Tip Over



RIVET FIX AND STANDING SEAM

- A RA Seal Ring
- B RA Can
- C Baseplate
- D Fixings with Seals or Clamps which do not penetrate the roof.

RA Module Top Fix SpiraTech™ / Tip Over

Information in this section is given as a guide only, always refer to the roofing manufacturers information for their specifications.

3.6 AGGRESSIVE AND HAZARDOUS ENVIRONMENTS

CORROSIVE ENVIRONMENTS

The RoofSafe™ Anchor has been tested in saline environments that exceed those specified in all National Standards. All components that are continuously exposed to the atmospheric conditions are made from Aluminium or Stainless Steel.

Aluminium components are anodized to AA11 (11 microns thick) as a minimum and 316 stainless steel components are polished to remove any surface impurities.

The SpiraTech™ coil and associated steel components are coated in a Zinc inorganic coating which has a minimum saline performance of 1000 Hrs.

In an aggressive or saline environment a RoofSafe™ Anchor and RoofSafe™ Cable System will require more frequent inspections and servicing to assure corrosion damage is not affecting the performance of the product. A appropriate inspection plan should be implemented based on the environmental conditions and agreed with the customer.

CHEMICAL HAZARDS

Solutions containing acids, alkali, or other caustic chemicals, especially at elevated temperatures may cause damage to this equipment. Consult Capital Safety if doubts exists concerning installing this equipment where chemical hazards are present.

ELECTRICAL HAZARDS

Do not install the RoofSafe™ Anchor where either the anchor, cable or user can come into contact with electrical power lines. Always allow a safe working distance between the user and power lines.

If you are uncertain about a particular application please contact your local energy infrastructure provider or health and safety advisory service for information on safe working practices.

3.7 RESCUE PLANNING

Employers have a responsibility to make specific provisions for emergency planning. Work should be appropriately planned and provisions should be made for emergency situations. The need for rapid and appropriate response following a fall should not be ignored.

In any situation where a fall could occur it is essential that appropriate rescue equipment is available for rapid deployment by trained personnel. Failure to have correctly trained personnel and equipment in place to respond to a fall scenario may result in serious injury or death.

Capital Safety has a range of rescue equipment appropriate for different scenarios and can advise on specification and use. Capital Safety also has facilities to provide training which is essential for the safe and correct use of rescue and evacuation equipment.

RoofSafe™ Anchor

4.0 Roof Anchor Performance



4.0 ROOF ANCHOR PERFORMANCE

4.1 ANCHORAGE STRENGTH

The anchor has been designed to withstand the loads generated when a person falls from height while attached to the anchor. The range of Roof Anchors are designed with internal supports which enable the post to maintain correct system tension as well as allowing for annual testing of the strength of the fixings (section 5.1). The internal supports break away at less than 3kN allowing the energy absorbing element to take the full force of the fall.

Once the anchor has been deployed the energy absorbing elements reduce the load on the user and the roof to safe levels, so that the anchorage remains safely attached to the roof structure, and the user is brought comfortably to a post fall resting position.

The RoofSafe™ Anchor can then withstand a minimum static load of twice the peak arrest load for 3 mins as required by EN795.

4.2 FORCES ON THE SPIRATECH™ ANCHOR




FIG 15.1




FIG 15.2

Fig 15.2 shows a horizontal load applied to the anchor connector. The highest stress areas can be seen around the narrowest section of the pin where it is designed to break.




FIG 16

Fig 16 shows the coil deployed, it can be seen that the stress is taken up by the middle section of the coil. (The rest of the assembly is not shown for clarity)


RoofSafe™ Anchor

4.0 Roof Anchor Performance



The SpiraTech™ Force management technology, absorbs much of the impact energy returning a low peak load as shown in the traces below Fig 17a/17b.

EN 795 - Dynamic 100kg, 2.5m




Peak 5,2kN

Equivalent of a single user fall on a SpiraTech™ Anchor

FIG 17A

ACR - Dynamic 200kg, 1.5m



Peak 6,1kN

Equivalent of a two user fall on a SpiraTech™ Anchor

FIG 17B

In a system the load is transmitted to the ends and the corners. Therefore ends and corners should be secured by means of a SpiraTech™ anchor rather than a Tip Over anchor. Tip Over anchors can be used as intermediate posts as they see less load. A system consisting of 2 SpiraTech™ anchors (Fig 18) will return a peak load of approximately 4.6kN (Fig 19).




FIG 18




FIG 19

However if a second user was to fall on the system after the anchor had already been deployed the peak load would increase to approximately 5.7kN (Fig 19)

Equivalent of a single user fall on a RoofSafe™ Cable system SpiraTech™ posts

RoofSafe™ Anchor

4.0 Roof Anchor Performance



4.3 FORCES TIP OVER ANCHOR




FIG 20.1




FIG 20.2

Fig 20.2 shows a horizontal load applied to the anchor connector. The highest stress areas can be seen around the top and bottom of the support strap where it is designed to break.




FIG 21

Fig 21 Shows the deformation of the wire form under a horizontal load, It can be seen that wire orientates the load and absorbs energy from the fall.




FIG 22

The Single Point Anchor absorbs much of the impact energy returning a peak load of approximately 7.1kN as shown on the trace in Fig 22.

RoofSafe™ Anchor

4.0 Roof Anchor Performance



4.4 THERMAL BRIDGING

Loss of heat from a building is a concern on insulated built up roof types where the toggle fixings penetrate through the roof (Fig 23.1). This can create a thermal bridge through the central bolt. The RoofSafe™ anchor toggles minimise the affect by insulating the area around the toggle bolt (Fig 23.2). In common toggle fixings the area around the bolt is open allowing convection around the bolt as well as conduction through the bolt.




FIG 23.1

Uninsulated Toggle Fixing




FIG 23.2

Insulated Toggle Fixing




FIG 24

RoofSafe™ Anchor Toggle Fixing

RoofSafe™ Anchor

4.0 Roof Anchor Performance



Testing has been carried out to show the heat transfer through the toggle fixings (Fig25/26). Uninsulated fixings show a temperature increase of 7°C at the fixing which is also transferred to baseplate (Red areas Fig25). The Insulated RoofSafe™ Anchor toggle fixings show a temperature increase of just 4°C, isolated to the top of the fixings.




FIG 25

The temperature range on a post with typical uninsulated toggle fixings 7°C increase and heating of baseplate.




FIG 26

The temperature range on a RoofSafe™ Anchor post with insulated toggle fixings. 4°C localised increase and limited heating of the baseplate.




FIG 27

The temperature range on a solid post fixed directly to the structure through the insulation. 15°C increase in temperature around the post.

Test conditions:

All tests were brought up to temperature and then allowed to equalise with the surrounding environment to ensure comparable test readings. Temperature below the insulation 60°C , Air Temperature around the post 20°C.

5.0 ANNUAL MAINTENANCE

5.1 TESTING THE ROOF ANCHOR

Anchors can be vertically pull tested up to 5kN. Pulling the anchor can be used as a way of testing the integrity of the fixings, where the post has been sealed in and they are not accessible. Components such as end or intermediate brackets and connection eyes should be removed before the test, and the load should be applied to the top thread.

For details of pull testing posts see the technical work instruction.

5.2 TESTING THE SWAGES

Swages as part of cable system should always be inspected to ensure that the cable is attached securely.

Capital Safety provide guidance on the swaging method and inspection of swages. Please refer to the RoofSafe™ Anchor installations instructions.

5.2 CLEANING THE ANCHOR

All of the exposed materials in the anchor have been specified as naturally corrosion resistant, or have been coated with sacrificial coatings to prevent oxidation of the base material.

It is important to consider that in some environments the anchors may need to be cleaned to gain the best possible life expectancy from the materials. Poorly maintained RoofSafe™ Anchor systems can become unusable or become unsafe and in extreme cases may have to be replaced.

Details on best practice for the maintaining the system can be found in the User Instruction Manual.

6.0 REFERENCE DOCUMENTS

6.1 ABBREVIATIONS AND DEFINITIONS

The following is a list of terms and their meanings as used in this publication

(Further standards are listed in section 7.2 of this guide):

BS EN 795 The European Standard for protection against falls from a height concerning anchor device requirements and testing

BS EN 354 The European Standard for protection against falls from a height concerning lanyards

BS EN 355 The European Standard for protection against falls from a height concerning energy absorbers

BS EN 361 The European Standard for protection against falls from a height concerning full body harnesses

BS EN 362 The European Standard for protection against falls from a height concerning connectors

BS EN 363 The European Standard for protection against falls from a height concerning fall arrest systems

BS EN 365 The European Standard for protection against falls from a height concerning instructions for use and markings

BS 7883 Code of Practice for the application and use of anchor devices conforming to BS EN 795

89/686/EEC EC Directive relating to Personal Protective Equipment design and test

SI 3139 Statutory Instrument 3139 The Personal Protective Equipment (EC Directive) Regulations 1992 - the transposition of 89/686/EEC into UK National Law

ACR[M]002:2009 - (Part2) Testing of Roof Anchors on Roof Systems

RoofSafe™ Anchor

6.0 Reference Documents



6.2 STANDARDS TABLE

European Standards	Standards Description	Synopsis	Test Data Available * /Documents
EN 795:1996	Protection against falls from a height- anchor devices- requirements and testing	Class A1: Comprises of structural anchor designs to be secured to a vertical, horizontal and inclined surfaces. Class A2: Comprises of structural anchors designed to be secured to inclined roofs Class C: Comprises anchor devices employing horizontal flexible lines. A horizontal which deviates from the horizontal by not more than 15°	Declaration of Conformity. Test Reports for primary roof types
ACR Advisory Committee for Roof work	ACR[M]002:2009 - (Part2) Testing of Roof Anchors on Roof Systems	Best practice guide based on sound technical knowledge and many years' collective experience of roof work. The documentation produced provides a bench mark for testing and overall performance of horizontal safety lines being installed on different roof types.	Declaration of Conformity. Test Reports for primary roof types and for some specific manufacturers
US Standards			
OSHA 1926.502M (d) (15) (i)	Fall protection systems criteria and practices.	(a) "General." This appendix serves as a non-mandatory guideline to assist employers comply with the requirements in 1926.502(d). Paragraphs (b), (c), (d) and (e) of this Appendix describe test procedures which may be used to determine compliance with the requirements in 1926.502 (d)(16). As noted in Appendix D of this subpart, the test methods listed here in Appendix C can also be used to assist employers comply with the requirements in 1926.502(e) (3) and (4) for positioning device systems.	Declaration of Conformity. Test Reports
Australian/ New Zealand Standards			
AS/NZS 1891.2.2001	Industrial fall-arrest systems and devices Part 2: Horizontal lifeline and rail systems AS/NZS	This Standard specifies design and performance requirements for systems and associated component hardware for horizontal lifelines and rails used for fall-arrest purposes. The Standard covers systems using either rigid rails or flexible lines.	Declaration of Conformity. Test Reports
* If copies of the test certificates are required please contact Capital Safety and quote certificate number.			

RoofSafe™ Anchor


6.0 Reference Documents



6.3 MARKINGS EXPLAINED

Anchor Sticker

- 1 Standards to which the Anchor conforms.
- 2 Read Instruction for use
- 3 Product Type
- 4 Web Address
- 5 Brand Logo
- 6 Product Technology



System Tag

- 1 Standards to which system conforms
- 2 Read Instruction for use
- 3 Web Address
- 4 Brand Logo
- 5 Product Family
- 6 System information to be filled in by installer
- 7 isafe tag (where used)

The system tag form includes the following sections:

- 1**: Standards to which system conforms (EN795:1996 Class C OSHA COMPLIANT AS/NZS 1891.2).
- 2**: Read Instruction for use (represented by an open book icon).
- 3**: Web Address (www.capitalsafety.com).
- 4**: Brand Logo (DBI SALA).
- 5**: Product Family (roofsafe anchors).
- 6**: System information to be filled in by installer (includes fields for Installation Date, Contact Number, Min. Ground Clearance, Max. Users Per System, Max. Users Per Span, Next Service Date, and System Serial No.).
- 7**: isafe tag (where used) (represented by a diagram of the tag).

capital

S A F E T Y

EUROPE, MIDDLE EAST & AFRICA

France

Le Broc Center
Z.I. 1re Avenue – BP15
06511 Carros Le Broc Cedex
FRANCE

t: +33 (0)4 97 10 00 10
f: +33 (0)4 93 08 79 70

United Kingdom

5a Merse Road
North Moons Moat
Redditch, Worcestershire
B98 9HL UK

t: +44 (0) 1527 548 000
f: +44 (0) 1527 591 000

Dubai

ME Branch Office
PO Box 17789
JAFZA, Dubai – U.A.E

Germany

t: +49 (0)2 76 18 33 82 29

Spain / Portugal

t: +33 (0)4 97 10 21 06

Italy

t: +33 (0)4 97 10 21 08

Scandinavia

t: +33 (0)4 97 10 21 01



10 Holt Place, Harewood
PO Box 39048, Harewood
Christchurch 8545, NZ
Free Phone: 0800 357 003
P: +64 3 357 0093
E: pbi@pbiheightsafety.com
www.pbiheightsafety.com

information@capitalsafety.com
www.capitalsafety.com

CAPITAL SAFETY IS THE GLOBAL LEADER IN FALL PROTECTION EQUIPMENT, SYSTEMS AND ANCHORS.

Capital Safety est le leader mondial en matière d'équipement, de systèmes et d'ancrages de protections antichute.

Capital Safety ist weltweit führend auf dem Gebiet von Absturzsicherungs-ausrüstung, -systemen und Anschlagmöglichkeiten.

Capital Safety es el líder mundial en equipos, sistemas y anclajes de protección contra caídas.

Capital Safety is wereldleider in valbeveiligingsapparatuur, -systemen en verankeringen.

Capital Safety è leader globale nell'anticaduta per dispositivi di protezione individuale, sistemi e ancoraggi.

Capital Safety är globala inom utrustning, system och förankringar för fallskydd.

