

About the Buttons on the Samsung SolarCell Remote (Samsung Smart Remote)

The Accessibility Shortcuts button on your remote provides easy access to the accessibility features on your TV.

Press and hold the volume button to display the Accessibility Shortcuts menu.

For the best viewing go to callEncyclopedia; email 1-800-402-6957

CCAD works the same as CCAD. The marked name can be changed to CCAD.

SolarCell
Exposure to light when the remote is not in use. This will extend the remote's operating time.

USB port (C-type) for charging. Use the supplied charging cable. The LED will light when charging. When the battery is fully charged, the LED will turn off.
+ The USB Cable is not provided.

NOTE: The remote control vary depend of model: The buttons on remote control may have a different name or location than the remote control shows in this manual.

SAMSUNG

-
- Fire or explosion may occur, resulting in damage to the remote control or personal injury.

 - Do not apply shock to the remote control.
 - Be careful not to let flammable substances such as metal, liquid, or dust come in contact with the charging terminal of the remote control.
 - When the remote control is damaged or you smell smoke or burning fumes, immediately stop operation and then repair it.
 - Do not arbitrarily disassemble the remote control.
 - Be careful not to let infants or pets suck or bite the remote control. Fire or explosion may occur, resulting in damage to the remote control or personal injury.

Button	Description
	Press to turn the TV on or off. For the Frame model: When watching TV, press to switch to Art mode. In Art mode, press to switch to watching TV. Press and hold the of the TV remotely. For the Voice Assistant, Press and hold the (say out loud), and then release the button to activate Assistant.
	• The supported Voice Assistant's languages and features may differ by geographical region. Keep the remote more than 0.5 inches (1.25 cm) from your face when using and speaking to Voice Assistant through the microphone mode.
	Each time you press this button, the colored button's window and the related numerical pad are displayed alternately. • Use this button to access additional options that are specific to the feature in use. • Press and hold up the white button to use on the screen. Use the numeric key pad to enter numeric values. Select numbers and the Done to enter a numeric value. Use to change the channel, enter a PIN, enter a ZIP code, etc.
	Press the button to directly enter the Multi View function.
	Use to navigate the menu or move the focus to highlight items on the Home screen.
	Selects or runs a focused item. When pressed while you are watching a broadcast, provides details, program information, etc. (peers).
	Press to return to the previous menu. When pressed for 2 second or more, the running function is terminated. When pressed while you are watching a program, the selected channel appears.
	Press to return to the Home Screen.
	When pressed, the playback controls appear. Using these controls, you can control the media content that is playing. To use Game Bar, press and hold the button in Game Mode. • Game Bar may not be supported depending on the model or geographical area.
	Move the button up or down to adjust the volume. To mute the sound, press the button.
	Move the button up or down to change the channel. To see the Guide screen, press the button. Press and hold the button up or down to quickly change the channel.
	Launch the app indicated by the button.
	If the Samsung Smart Remote does not pair to the TV automatically, point at the front of the TV, and then press and hold the and buttons simultaneously for 7 seconds or more.

Use the Samsung Smart Remote less than 20 feet (6 m) from the TV. The usable distance may vary with the wireless environment and fans.

The images, buttons and functions of the Samsung Smart Remote may differ with the model or geographical area.

The Universal Remote function operates normally only when you use the Samsung Smart Remote that comes with the TV.

It is recommended to use an original Samsung charger. Otherwise, it may cause performance degradation or failure of the product. In this case, the warranty service is not applicable.

- When the remote control does not work, you can better recharge it by using the USB-C cable and 1

Using Accessibility Functions (may differ with model)

Accessing your TV's accessibility functions

The Accessibility Shortcuts button on your remote provides easy access to the accessibility functions on your TV.

- Press and hold the Accessibility Shortcuts button.
- Some functions may not appear depending on the access method.

Voice Guide Settings

You can activate voice guides that describe the menu options aloud to aid the visually impaired. To activate this function, see Voice Guide on the Q&A/Voice Guide on the TV provides voice guides for channel changes, volume adjust, information on menu, and homecoming programs, etc. when viewing on the TV. It is easy to know what to do. For example, when in Search, you can manage the volume, speed, pitch, and level of the Voice Guide.

- The Voice Guide is provided in the language that is specified on the Language option. English is always supported. However, some languages are not supported by Voice Guide even though they are listed in the Language screen.

TV Background Volume

By default, the volume of the broadcast content is set to be low so that you can hear the voice guide clearly. When the content volume is too low while the voice guide is coming out, you can adjust the content volume.

Picture Off

Turn on the TV screen and provide only sound to reduce overall power consumption. When you press any button on the remote control while the screen of the TV is turned on, the screen returns to normal.

Graphic Zoom

Enlarge the screen to make the picture appear bigger. You can adjust the zoom level to make the screen area.

Audio (Video) Description

You can watch an audio guide that provides descriptions of video scenes for the visually impaired. This function is only available with broadcasts that provide this service.

High Contrast

You can change major text colors to white text on a black background and change the transparency of TV menus to appear so that text contents are clearly read. To activate this function, set High Contrast to On.

Grayscale

You can change the color of the TV screen to grayscale. The function supports the edges of some images to show gray levels.

- If Grayscale is On, some Accessibility functions are not available.
- This function may not be supported depending on the model or geographical area.

Color Inversion

You can invert the colors of the text and background for the setting menus displayed on the TV screen to make it easier to read them.

- If Color Inversion is On, some Accessibility menus are not available.
- This function may not be supported depending on the model or geographical area.

Enlarge

You can enlarge the size of the text on the screen. To activate, set Enlarge On.

Learn TV Remote

This function helps individuals with a visual impairment to learn the positions of the buttons on the remote control. When this function is activated, you can press a button on the remote control and the TV will tell you its name. Press the (Learn) button twice to exit Learn TV Remote.

Learn Menu Screen

Learn the menu on the TV screen. Once enabled, your TV will tell you the structure and features of the menu as you select.

Caption Settings

Set Caption to On to watch programs with the captions displayed.

- Captions are not displayed by programs that do not support captions.
- This function has no relationship with the features for controlling subtitles of DVD or Blu-ray players. To control DVD or Blu-ray subtitles, use the subtitle feature of the DVD or Blu-ray player and the player's remote control.

Separate Closed Caption

- You can display the caption in the area separated from the broadcast screen.

Caption Mode

- Default / CCI - CCI / Text1 - Text4
Operates in the User analog TV channel mode or when a signal is supplied from an external device to the TV. (Depending on the broadcast signal, the analog caption function may or may not occur with digital channels.)
- Default / Service1 - Service4 / CCI - CCI / Text1 - Text4
Works with digital channels. These functions may not be available in digital channel mode depending on the broadcast.

Digital Caption Options

You can change the text color, background color, size settings, and position, etc.

- The background and background colors and opacity settings cannot be the same.
- The Position function is activated only for programs that support broadcast captions.

Multi-output Audio

You can turn on the TV speaker and a Bluetooth device at the same time. When it is turned on, you can set the volume of the Bluetooth device higher than the volume of the TV speaker.

- This function may not be supported depending on the model or geographical area.

Sign Language Zoom Settings

You can zoom in the sign language screen when the program you are watching provides it. First, set Sign Language Zoom to On, and then select Edit Sign Language Zoom to change the position and magnification of the sign language screen.

Remote Button Repeat Settings

You can configure the operation speed of the remote control buttons so that they slow down when you can usually press and hold them. First, set Slow Button Repeat to On, and then adjust the operation speed in Repeat Interval.

Licences

Dolby Audio

HEVC Advanced

QUICKSET

rovi guide


HDMI

The terms HDMI and HDMI High Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

804006631


[illegible]

	(A)	(B)	(C)	(D)	(E)	(F)	(G)	(H)	(I)
2002-03	42.00 lakhs ₹42,00,000	26.00 lakhs ₹26,00,000	21.00 lakhs ₹21,00,000	16.00 lakhs ₹16,00,000	12.00 lakhs ₹12,00,000	9.00 lakhs ₹9,00,000	6.00 lakhs ₹6,00,000	3.00 lakhs ₹3,00,000	2.00 lakhs ₹2,00,000
2003-04	42.00 lakhs ₹42,00,000	26.00 lakhs ₹26,00,000	21.00 lakhs ₹21,00,000	16.00 lakhs ₹16,00,000	12.00 lakhs ₹12,00,000	9.00 lakhs ₹9,00,000	6.00 lakhs ₹6,00,000	3.00 lakhs ₹3,00,000	2.00 lakhs ₹2,00,000




$$0 = 0^2 = 2 \cdot \frac{0}{2} = \frac{0}{1}$$


	400 × 400 × 100	400 × 400 × 100	400 × 400 × 100	400 × 400 × 100	400 × 400 × 100	400 × 400 × 100	400 × 400 × 100
CSP9C9-4	400 × 400	36-28	36	1.5	2.2	1.5	1.5
CSP9C9-4	300 × 400	25-27			1.5	1.5	1.5


1992



NOTE: The image shown here is for illustrative purposes only and may be subject to change. The actual number of ports and their locations may vary depending on the model. Accessory type, appearance and quantity may vary depending on the model.



NOTE: The image shown here is for illustrative purposes only and may be subject to change.



PRINTED IN MEXICO/ SC:10.13.2021
obpn:BN68-11569A-02
shnmdl: QN85Q8DAAFXZA - Pags:1P elbr:m.c.

804006631

