

LandStar 8 User Manual



Copyright

31 October 2023; LandStar8_UserManual_r0510.docx

Copyright © 2023 iGage Mapping Corporation. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of iGage Mapping Corporation.

iGage and 'iGage Mapping Corporation' are Trademarks of iGage Mapping Corporation of Salt Lake City Utah, USA.

LandStar 8 is a Trademark of CHCNav.

All product and brand names mentioned in this publication are trademarks of their respective holders.

Acknowledgements

This User Manual was written by Mark Silver and Pengfei (Tony) Han.

If you have questions or manual suggestions, contact us:



iGage Mapping Corporation

1545 South 1100 East Suite 1

Salt Lake City UT 84105 USA

+1-801-412-0011

email: landstar@igage.com

Your input is extremely valuable, and we will listen to your suggestions!

Using this Manual: Begin reading here!

Don't let this User Manual's size intimidate you. It is not bad as it might first appear!

Start out by reading these very short sections. They will save time and confusion when first using LandStar:

Operating System Optimizations	13
Keyboard tricks	13
Entering distances	14
Entering Azimuths/Bearings	14

General System and program settings like display formats, units, significant decimal places, GNSS survey and stakeout default settings:

LandStar 8 System settings	19
----------------------------	----

While the **Tool tray** icons meanings are not obvious, they are important for many survey functions like offset staking and hidden point measurements:

Tool tray	43
-----------	----

Next read the task oriented **How To** Quick Guides in the back:

How to: Install, Update and Provision LandStar	223
How to: Moving data to the data collector	227
How to: GNSS Network Rover Internal Cell Modem	229
How To: GNSS Network Rover PDA Modem	234
How to: GNSS Internal UHF Base	238
How to: GNSS Internal UHF Rover	242

Detailed references for the four **Main menu** tabs are color coded:

Project	63
Survey	95
Config	167
Tools	183

These functions are often needed, but hard to find:

Plot Deed enter a metes-and-bounds survey description convert to points and lines:

Details: Tools (tab): Plot Deed	201
---------------------------------	-----

CORS and **Base shift** functions adjust autonomously surveyed points to an **OPUS solution**:

Details: Survey (tab): Base shift and CORS shift	151
--	-----

Backup everything (settings, profiles, projects, geoids) to a single file, **transfer** to new device:

Deployment backup and restore	20
-------------------------------	----

Table of Contents

Copyright	2
Acknowledgements	2
Using this Manual: Begin reading here!	3
Table of Contents	4
Installing and Activating LandStar8.....	6
Downloading and Deployment	6
LandStar 8 Licensing	7
Activating a Permanent Registration code	9
Self Service demo activation	9
Transferring a registration code license to another device.....	10
Operating System Optimizations	13
Keyboard tricks	13
3-button navigation	14
Entering distances	14
Entering Azimuths/Bearings.....	14
Direction from Existing Points	15
Entering / Viewing Geographic and Projected Coordinates.....	15
LandStar 8 Program folders	19
LandStar 8 System settings	19
Side-bar details	19
Deployment backup and restore	20
Interface style	22
Audio prompt.....	22
Warn if Base changes	23
My cloud disk	23
Collaborative functions in LandStar 8	23
Collaborative work Group using CHC Cloud	25
Upload position to CHC Cloud	25
Localization packages	25
Record track.....	26
Video Help, show video help button	27
Feedback	27
Remote support	27
Activate software / About	27
Software settings	28
Keyboard shortcut.....	28
Share method.....	28
Auto Ok.....	28
Units.....	29
Decimals	32
Coordinates	32
GNSS settings	33
Survey (tab of GNSS settings).....	34
Topographic point survey settings	34
Continuous survey settings.....	37
Control point survey settings	37
Common GNSS Survey settings	38
Stakeout (tab of GNSS settings)	39
Display settings	41
CAD settings	42

Tool tray.....	43
Add text to map.....	43
Attributes	43
CAD view	43
Center GPS position	43
Delete.....	43
Delete last point	43
Edit last point.....	44
Enter a point (to stakeout).....	44
Point stakeout	44
Line stakeout	44
Roading Stakeout	44
Quick access.....	45
Explode Block.....	45
Export DXF	45
Export Surface staked report.....	45
Follow (rotate).....	45
Full view	45
Import DXF.....	45
Invert line direction	45
Layers	45
Nodes list	45
Online map	46
Region list	46
Snap.....	46
Offset stakeout	46
Offset survey (hidden point survey)	46
Open road (project) file	47
Pan to (center map at)	47
Panel (surface stakeout)	47
Point list	47
Point Survey.....	47
Redraw	48
Regions.....	48
Reverse line	48
Save object.....	48
Survey boundary	48
Zoom In	48
Zoom Out.....	48
IMU settings and status	48
Work layers, Map files, Online map	49
Instrument Select & Status information	49
Instrument select	49
Instrument status.....	49
Instrument information	50
Sky Plot and Satellites information.....	50
Quality.....	51
GNSS Base information	51
Main menus and program functions.....	52
Project (tab)	53
Survey (tab)	55
Config (tab).....	58

Tools (tab)	59	Real-time plot	122
Function Details.....	63	Start / stop measurements	122
Details: Project (tab) > Projects	63	Information panel.....	122
Sharing Projects.....	63	Details: Survey (tab): Point Stakeout	123
Project backups	64	Storing the results of the Stakeout.....	124
Details: Project (tab) > Coordinate system.....	64	Auto description for staked points	125
Coordinate system utilities	67	Visual Stakeout.....	126
Details: Project (tab) > Single point localization	68	Additional methods to begin staking out a point	127
Details: Project (tab) > Point list	70	Offset Staking a Point	130
3-dot button	73	Details: Survey (tab): Line/Arc stakeout	131
Switch list style	77	Line / arc stakeout settings	134
Point properties and attributes	77	Station and Offset.....	134
Details: Project (tab) > Point list > Points to stake (tab) ..	78	To line.....	135
Details: Project (tab) > Codes.....	80	Node.....	136
Edit or Delete an existing code	81	Details: Survey (tab): Surface stakeout.....	137
Create a New Code	81	Details: Survey (tab): Area survey	139
Code library functions	82	Details: Survey (tab): CAD View	142
Details: Project (tab) > Layers > Work layers, Map files,		Details: Survey (tab): Site calibration	146
Online map	82	Details: Survey (tab): Base shift and CORS shift	151
Work layers (tab)	83	Base shift.....	152
Map files (tab)	83	Removing Base shift	154
Online map (tab)	84	CORS shift	154
Details: Project (tab) > Import	85	Details: Survey (tab): Sideslope stakeout	155
Details: Project (tab) > Export	86	Details: Survey (tab): Foundation stakeout	157
Details: Project (tab) > Surfaces.....	90	Details: Survey (tab): Continuous survey.....	160
Details: Survey (tab) > Map Survey.....	95	Details: Survey (tab) Cross-section survey.....	162
Back.....	95	Getting Started with Cross-section Surveying	162
Status	95	Details: Config (tab): Instruments profile	167
Point Names	95	Details: Config (tab): Connect to instruments.....	169
Antenna Height	96	Details: Config (tab): GNSS rover	171
Point Code	96	Details: Config (tab): GNSS base	174
Point / Line.....	96	Base setup procedure.....	177
Quick code panel.....	97	Details: Config (tab): GNSS static observation recording	
Sharing CODES and Quick Code buttons assignments..	97	178
Survey mode.....	97	Details: Config (tab): Instrument info	179
Start measurement	98	Details: Config (tab): Activate instrument	179
Information panel	98	Details: Config (tab): Update	180
Offset survey (hidden point survey)	99	Details: Config (tab): Advanced.....	180
Point survey: Distance + Azimuth.....	100	Details: Config (tab): NFC / Wi-Fi	182
Point survey: Alignment Offset.....	101	Details: Tools (tab): Map adjustment	183
Point survey: Distance-Distance Intersection	103	Details: Tools (tab): Volume computation.....	185
Point Survey: Turned angle + distance (with skew).....	105	Details: Tools (tab): Area computation.....	188
Point survey: $\Delta X + \Delta Y + \Delta Z$	107	Details: Tools (tab): Inverse	190
Details: Survey (tab) > Point (text) Survey.....	108	Details: Tools (tab): Angle conversion (DMS.s \leftrightarrow D.ddd	
Details: Survey (tab): Visual survey.....	108	\leftrightarrow GON).....	190
Details: Survey (tab): Control survey	113	Details: Tools (tab): Parameter calculation, 3 or 7-	
Control survey operation	113	parameter.....	191
Details: Survey (tab): Verified survey.....	115	Details: Tools (tab): Point to line distance	193
Verified survey operation.....	116	Details: Tools (tab): Offset distance	193
Adding additional measurement groups to a Verified		Details: Tools (tab): Deflection	195
survey.....	120	Details: Tools (tab): Rotation.....	195
Verified survey screen details	121	Details: Tools (tab): Intersection	196
Back.....	121	Details: Tools (tab): Bisect angle	198
Status	121	Details: Tools (tab): Divide line.....	199
Point Names	121	Details: Tools (tab): Point average	200
Antenna Height	121	Details: Tools (tab): Plot Deed	201
Point Code	121	Plotting deed descriptions, a complicated example....	204
		Details: Tools (tab): Transformation	210

Align matching points	211	How to: Moving data to the data collector	227
Manual Entry	213	How to: GNSS Network Rover Internal Cell Modem	229
Details: Tools (tab): Area subdivision	216	Retransmit correction data.....	233
Details: Tools (tab): Calculator	217	How To: GNSS Network Rover PDA Modem	234
Details: Tools (tab): Ruler	218	How to: GNSS Internal UHF Base	238
Building GIS Datasets in LandStar	219	Start from Point list or Previous position	241
How to: Install, Update and Provision LandStar	223	How to: GNSS Internal UHF Rover	242
Direct download from iGage.com	223		

Installing and Activating LandStar8

LandStar 8 is a 64-bit Android application.

It should run on any Android device with Operating System Android version 7 or higher, however users may be disappointed with Android OS versions older than version 10.

The LandStar application should automatically adjust to most screen sizes.

For use with a visual receiver, like the CHC i89 and i93, verify Visual Survey operation prior to deployment with a new device or use dealer recommended hardware. Visual survey functions require 5 GHz Wi-Fi and are enhanced by high resolution displays and high-speed processors.

Downloading and Deployment

LandStar 8 is too large to distribute in Google Play.

A distribution manager is used to distribute LandStar. The distribution manager will also update LandStar to the latest version.

It is also possible to download the program APK from a trusted source. See [Direct download from iGage.com] on Page 223 for an example.

In Google Play, search for [CHCNav](#). Look for the [CHCNav Installation Manager](#):



The publisher's name will be 'Shanghai Huace Navigation Technology Ltd.'

Once the manager is installed, open the [CHCNAV Installation Manager](#):



Click on the LandStar **Install** button and follow the onscreen instructions.

If LandStar is already installed but a newer version is available, an update to the latest version will be suggested.

Once the download and installation has completed, start LandStar. The desktop icon:



Should be available on one of the device screens. If not, swipe up, find LandStar, click-and-hold then place a shortcut anywhere on the device desktop.

When LandStar runs the first time, the following permissions may be requested:

Camera	needed to read QR codes containing projection information. Required to take pictures to attach to points as media.
Files	needed to store projects, import/export files.
Location	needed to use the internal data controller GPS for position.
Music, audio	needed to voice information during collection (Fixed, Float, Connection lost).
Nearby devices	needed to connect to GNSS receivers by Bluetooth and Wi-Fi.
Notifications	needed to notify when running in the background.
Phone	the IMEI number of the cellular radio is used for device identification.
Photos, Videos	needed to store and attach media to measurements.

LandStar may not be able to run if any of the requested permissions are denied.


When LandStar runs the first time, it will notify you that there are no localization files in use. Click on the appropriate package (in the USA select 'United States') to download and install one. The localization packages include projections and Geoids.


LandStar 8 Licensing

LandStar 8 will run in demo mode until it is activated. Most functions other than connection to a GNSS receiver or Total Station are available in the unlicensed Demo mode. It is possible to use an unlicensed demo copy to process Visual surveys and import and export work products.

30-day trial licenses are also available by self-service, see [Self Service demo activation] on Page 9 for step-by-step instructions.

To permanently activate LandStar 8, buy a [Registration Code](#) (formally called a [Precode](#)) from an authorized dealer. The [Registration Code](#) can only be used on one device at a time. A [Registration Code](#) can only be deployed on a lifetime total of 5 devices; however, the code can be freely transferred between these 5 devices an unlimited number of times. The Deployment Backup and Restore tool [Deployment backup and restore] described on Page 20 makes transferring entire deployments by a single file possible.

Click on the profile head  at the top-left corner to display the [System settings](#) panel. Drag the panel up and click on [Activate software/About](#) at the bottom of the left menu:




Click on the [Inactive](#) link:



If you have an existing account, click on [Existing account](#) at the screen bottom, you need only enter your email address there is no need to fill in details.

If LandStar has not previously been registered, click on [Activate by email](#), fill the requested information, then click on [Register](#):



← 20230718103707-Register

Name

Company email


Country

Company name

Phone number

Existing account Register

If registering a new account, after clicking on [Register](#):



Check your email, click on the link in the email to complete the account activation process.

An [email](#) address is needed so that notices of license transfers can be sent when a license is released. [Your Company name](#) and [Phone number](#) are needed to aid in troubleshooting license transfer issues.

Activating a Permanent Registration code

After activating by email, enter the [Registration Code](#) (previously called [PreCode](#)):


Click on the [Apply](#) button to the right of [Permanent registration code](#):



Permanent code

Apply

Then enter the [Registration code](#):



Enter a permanent registration
code

Cancel OK

Click [OK](#). If the code is not installed on another device, LandStar will be activated.

Self Service demo activation

LandStar8 Demos expire after 30-days.

After activating by email, click the apply button to the right of Temporary code:



Temporary code

Apply

LandStar will contact the server and bind a 30-day demo code for your device.

Don't neglect evaluating the demo as it is VERY difficult to extend a demo on a device and it is difficult to do multiple demos associated with the same email address.

Transferring a registration code license to another device


A LandStar license can only be activated on one device at a time. A purchased license can be transferred to a total of 5 (five) devices over the registration code's lifetime. Please be careful when using transfers to not needlessly waste them, only five are possible.

Consider using a demo code to evaluate new devices.

IMPORTANT

Before transferring LandStar to a new device, consider backing up EVERYTHING to a single Deployment backup file. These Deployment backups include all settings, instrument profiles, existing jobs. See [Deployment backup and restore] on Page 20.

To transfer a license to a new device, on the device that currently holds the license, verify that it has internet connectivity, then go to the side menu by sliding the menus all the way to the right:



Click on [Activate software/About](#)



Click on Activated. The license dialog is shown:



Click on the [Unbind license](#) button, then wait.

After a few seconds you will see [Unbind successful](#).





The license server will send an email with a copy of the [Registration code](#), verifying that the license is available to move to another device. The [Registration code](#) can now be transferred to another device.

If a device is destroyed or lost while a [Registration code](#) is bound to the device, get a picture of the damaged device showing the device's serial number, and a copy of a police report if available. Then contact your dealer. You will need to fill out a certification that the device is lost, retired and will never be in service again. The factory will need the original [Registration code](#) and the email it was associated with. It may take a day or two for the license to be released.


Operating System Optimizations

After installing LandStar, make the following operating system changes to prevent LandStar from freezing or losing permissions when running in the background, or after a few weeks of non-use.

Click and hold on the program icon on the desktop, then click the  **App info** [App info](#) button:



Under [Permissions](#), disable [Pause app activity if unused](#):



This will prevent the operating system from automatically removing permissions and cached files if LandStar is not used regularly. The removal of some permissions may result in LandStar being unable to start.

Under [Mobile data & Wi-Fi](#) enable background usage of mobile [Background data](#) and [Unrestricted data usage](#):




Under [App battery usage](#) change battery usage to [Unrestricted](#). This allows LandStar to continue to communicate with receivers and devices when another application is opened or while using the phone:



Keyboard tricks

The Google keyboard [GBoard](#) is highly recommended for use with LandStar. [GBoard](#) can be downloaded and installed from the Google PlayStore if the device has GMS (Google Mobile Services).

When entering a field that is primarily numeric, a numeric keyboard like this may be shown:



If you need to click a letter (like 'm' to switch a measurement to Meters), click on the space button:



and the keyboard will expand to alphanumeric entry:



Unit override is commonly required when the [Project Horizontal distance](#) units are set to Feet to enter a metric survey rod height like "2m".

3-button navigation

Enabling soft buttons on the bottom of the screen:



will help navigation through large entry forms as there will be a dedicated key to collapse the keyboard.

Turn on the bottom navigation buttons from the Android setup by searching for [3-button navigation](#) which is under [System](#) > [Gestures](#) > [System navigation](#).

Entering distances

A project always has current [Horizontal](#) and [Vertical distance unit](#) settings. (Some USA states define [Horizontal distance](#) as US Survey Feet and [Vertical distance](#) as International Feet.)

Override the current default units by appending a letter to a distance:

2642.54i	force International Feet
2642.54f	force US Survey Feet
2.06m	meters
20.14c	20 chains 14 links

Distance can also be entered as the inverse horizontal distance between two points. For example:

1001,1002	the distance from point 1001 to 1002
1001,1002/4	¼ the distance from point 1001 to 1002

Entering Azimuths/Bearings

In the USA, for both rectangular and metes-and-bounds surveys it is common to describe courses by [Quadrant Bearing](#) angle and distance.

Because it is difficult to compute the reciprocal of azimuth angles in Deg-Min-Sec.sss, [Quadrant Bearings](#) are commonly used where the angle is described as the angle **East or West of North or South**. This has the benefit of just exchanging the N/S and E/W to describe a line 'going the other way.'



The blue vector above describes a course:

336 5 36.11 degrees 423.542 feet

In the United States this course is described as:

N 023:54:23.89 W 423.542 feet

Reversing the direction is simple, just exchange the first direction N with S and the trailing W with E:

S 023:54:23.89 E 423.542 feet

Note: most users specify bearings to the nearest arc-second; however, when working with long distances or many courses, many significant digits of seconds will be needed to carry angular resolution to exactly match distant coordinates.

If **Bearing** is selected under **Software settings**, then **Quadrant Shortcuts** can be used:

NE = 1 SE = 2 SW = 3 NW = 4

to enter a bearing. For example:

entering: 423.542389 results in: N 023:54:23.89000 W

The first character "4" is the quadrant shortcut.

If **Bearings** are selected in the **System Settings** for direction entry, you can override bearing entry with an **Azimuth** by adding an 'a' for azimuth:

274.4512a => N 085:14:48.0000 W

Direction from Existing Points

When entering an Azimuth or Bearing, use any two points as a direction reference by putting a ',' comma between the point numbers:

1001,1002 bearing from PN 1001 to PN 1002

It is also possible to include simple math operators * / + - to build angular equations:

1001,1002+90 add a right-angle turn right to the bearing from 1001 to 1002

1001,1002-90 add a right-angle turn left to the bearing from 1001 to 1002

Entering / Viewing Geographic and Projected Coordinates

The following discussion is intended for users in the United States of America. It will have limited application to users in other regions.

Geographic coordinates are unprojected coordinates, typically expressed in **Latitude Longitude Height** or **Earth-centered-earth-fixed** (ECEF) coordinates. Coordinates also have a reference frame realization with an EPOCH date.

NAD83 2010.0000 is a plate fixed realization for North America. For NAD83 we express a point's Geographic coordinates as the point's position on a specific date (EPOCH January 1, 2010) which is in the past. Even if the point moves because of crustal motion, the position is constant because it is expressed on a date before the motion occurred.

WGS84 is a general grouping of several realizations. ITRF 2014 (EPOCH:xxxx.xxxx) is the current realization of WGS84 used in the USA and is generally expressed with a fractional year measurement-date making the coordinates dynamic. In other words: WGS84 / ITRF dynamic coordinates change slightly every day.

An example of a fractional year EPOCH date is *August 19, 2023 12:40* which translates to 2023.6315.

Prior to the NGS using ITRF2014, IGS08 was a commonly used realization in the USA. There have been many other reference frames in widespread use over the years and by different geospatial communities.

There is a variable offset between ITRF2014 and NAD83 based on location and time. In the USA, the NGS tool HTDP (Horizontal Time Dependent Position) tool is used to approximate the difference at a location, for a specific time. (See <https://geodesy.noaa.gov/TOOLS/Htdp/HTDP-user-guide.pdf> for additional information on HTDP.)

You have probably seen both Latitude-Longitude-Height and Earth-center-earth-fixed coordinates, with both fixed plate NAD83 coordinates and dynamic ITRF coordinates on NGS OPUS solution reports. Here is an example:

REF FRAME: NAD_83(2011)(EPOCH:2010.0000)				ITRF2014 (EPOCH:2023.6315)			
X:	-1587260.290(m)	0.004(m)		-1587261.270(m)	0.004(m)		
Y:	-4561961.646(m)	0.014(m)		-4561960.346(m)	0.014(m)		
Z:	4153956.508(m)	0.000(m)		4153956.384(m)	0.000(m)		
LAT:	40 53 8.48450	0.008(m)		40 53 8.50067	0.008(m)		
E LON:	250 48 55.76674	0.008(m)		250 48 55.70899	0.008(m)		
W LON:	109 11 4.23326	0.008(m)		109 11 4.29101	0.008(m)		
EL HGT:	1714.481(m)	0.010(m)		1713.716(m)	0.010(m)		
ORTHO HGT:	1728.614(m)	0.065(m)	[NAVD88 (Computed using GEOID18)]				

The left-hand column has NAD83 plate fixed coordinates, the right-hand column has ITRF2014 EPOCH 2023.6315 dynamic WGS84 coordinates. The top 3-lines have ECEF coordinates, the bottom 4-lines have Latitude-Longitude Height coordinates.

Two heights are shown for the NAD83 position: an **Ellipsoid** Height and an **Orthometric** Height. Only an Ellipsoid height is shown for the right-hand column ITRF2014 coordinate. **Ellipsoid heights** are generally combined with Latitude Longitude coordinates. GNSS receivers measure and report Ellipsoid heights.

Orthometric heights are derived from GNSS collected Ellipsoid heights using a GEOID separation file. Orthometric heights also have an associated vertical datum. In the example above **GEOID18** was used to compute the Orthometric height and the result is a **NAVD88** approximation.

It is important to remember that in Ellipsoid space, water does not necessarily flow downhill. The GEOID separation file includes the effects of gravity so that in Orthometric space, water will flow downhill.

In LandStar, projected coordinates (Northing and Eastings) are always entered, grouped, and shown with Orthometric heights:

Format: Local N/E/Elev (Projec)

North (N): 3490674.769 USft

East (E): 2280688.733 USft

Elevation: 5672.108 USft

Geographic coordinates (Latitude and Longitude) are always entered and shown with Ellipsoid heights:

Format: Local Lat/Lon/H

Local Lat: 40-53-09.14850 N

Local Lon: 109-11-02.82270 W

Local H (ellipsoid): 5625.742 USft

GNSS Base receivers are always loaded with the Ellipsoid height of the antenna L1 phase center.

Because the transformation between Ellipsoid and Orthometric heights requires a Geoid difference, LandStar will request that a Geoid file be selected if an attempt to load a coordinate system is made without a Geoid:

Geoid

Do you want to select a geoid file now?

Geoid file: Geoid2018US.CGT

Buttons: Cancel, OK

When presented with this question, always pick the current GEOID file applicable to the project location (GEOID18). **Do not** proceed without loading a GEOID or LandStar will be unable to convert from Orthometric heights to Ellipsoid heights and Orthometric heights will be replaced by the Ellipsoid value. No additional warning will be given.

In the USA, because CORS Servers and local bases are nearly always configured with NAD83 2010.0 coordinates, there is no difference between WGS84 and NAD83 Local coordinates.

There is no 'built-in' datum transformation in any of the USA predefined coordinate systems:



In other (non-USA) locations, there may be 7-parameter or Helmert translations defined in the coordinate system definitions. For these areas, GNSS Bases are initialized with WGS84 coordinates, and the coordinate definition includes a transformation to place the Rover coordinates on a local datum or reference frame.

When using LandStar in the USA, there is no difference between the Local and WGS84 coordinates. Thus, [WGS84 Lat/Lon/H](#) coordinates will **EXACTLY** match the [Local Lat/Lon/H](#) coordinates.

When looking at a surveyed point or entering a base position several possible formats are available:



WGS84 Lat/Lon/H	Ellipsoid Height
WGS84 ECEF X/Y/Z	Ellipsoid Height
Local Lat/Lon/H	Ellipsoid Height
Local ECEF X/Y/Z	Ellipsoid Height
Local N/E/Elev	Orthometric Height

Normally [Local Northing](#), [Easting](#), [Orthometric](#) elevations will be best for Storing and Staking points:



GNSS bases are best configured with Local [Latitude](#), [Longitude](#), [Ellipsoid](#) Height coordinates.

Using OPUS Solution positions to start a Base

If starting from a NGS OPUS solution, favor a Geodetic (Latitude, Longitude, Ellipsoid Height) position:

REF FRAME: NAD_83(2011) (EPOCH: 2010.0000)				IT
X:	-1587260.768(m)	0.011(m)	-1587	
Y:	-4561961.616(m)	0.015(m)	-4561	
Z:	4153956.649(m)	0.016(m)	4153	
LAT:	40 53 8.48522	0.002(m) (a)	40 53	
E LON:	250 48 55.74704	0.005(m)	250 48 5	
W LON:	109 11 4.25296	0.005(m) (b)	109 11	
EL HGT:	(c) 1714.671(m)	0.023(m)	1	
ORTHO HGT:	1728.804(m)	0.079(m)	[NAVD88 (Compu	

The best measurement entry format is:

← 3446-Start on a known point

Add the point to the point list

Antenna type

CHC003 NONE

Antenna height

6.562 USFT

Type

Vertical H

Slant H

Select point

Name

B_OPUS

Coordinate format

Lat/Lon/H

Local Lat

40 53 08.48522 N (a)

Local Lon

109 11 04.25296 W (b)

Local H (ellipsoid)

1714.671M (c)

OK

If working in US Feet or International Feet be sure to enter an “M” after the Ellipsoid Height, as shown above, [Elevations](#) are always in [Meters](#) on an NGS OPUS solution.

LandStar 8 Program folders

LandStar stores program data in two places on the Android device. The primary folders are:

- \Internal shared storage\CHCNAV
- \Internal shared storage\system_prj_backup

Within these folders there are several additional folders:

\Internal shared storage\CHCNAV


- .\Cache OEM, Mainboard firmware for GNSS devices
- .\Config Fonts, Codes, Geoids, Prisms, Working modes, Coordinate systems
- .\Download files downloaded from the Cloud
- .\Projects Projects, each project is stored in a folder


Projects can be continuously backed up to the folder:

\Internal shared storage\system_prj_backup

within this folder there will be a separate folder for each job. Within the job folder there may be multiple ZIP files containing snapshots of the job. These previous versions can be restored from the [Project menu](#). See [Project backups] on Page 64 for additional information on [Project backups](#).

LandStar 8 System settings


From the [Main menu](#) click on the [Side bar](#)  button in the upper-left corner. This shortcut button allows quick access to [System](#) and [Software Settings](#) from any of the main menu tabs.



It is also possible to directly view the [Side-bar](#) by clicking the [Tool tray](#)  [Quick access](#) button allowing access to [System settings](#) without leaving most survey menus.

The [System settings](#) panel provides access to [Software settings](#) (a sub-set of the [System settings](#)), interface styles and program defaults.

Side-bar details



See [Software settings] on Page 28 for details on [Software settings](#).

Deployment backup and restore




Deployment backup archives all the:

- project groups
- projects
- LandStar settings
- Device and Instrument profiles
- Menu item positions
- Import and Export profiles
- GEOID Files
- defaults
- map tiles
- pictures
- Visual survey jobs
- **Plus everything else...**

to a single compressed file. This single file can then be moved to a different device and restored.

If provisioning a new device, read about License transfer here [Transferring a registration code license to another device] on Page 10.

From the **Side-Bar** click on **Deployment backup and restore**.



The **Backup list** of existing deployment backups will be shown:




Click New to build a new backup:



Give the backup a descriptive [Name](#), choose to [Backup application settings](#), choose to [Backup projects](#).

Then click [Next](#).




Check all of the [Project groups](#) to backup or [Select all](#) to include all [Project groups](#).

Finally click [Start backup](#):



Depending on the size of the projects the compression could take a long time (over five minutes.)

After the backup completes, it will be listed in the [Backup list](#):



Slide the backup entry to the right:



to reveal: Delete, Information, Cloud, Share, Restore.

When the backup is complete, the resulting file will be placed in the folder:

`.\Internal shared storage\system_prj_backup`

It will be named:

settings07212023-20230921125156-Config-Projects.szip

the entered Name followed by a hyphen and the date, time and included components. The file will have an .szip extension, however it is a standard ZIP compressed file.

Use the Restore from file button to open a backup that has been transferred to a random location on the device, typically the Download folder.

Interface style



LandStar has two interface styles:



Classic



Simple


The **Classic style** has 4 tabs: **Project**, **Survey**, **Config** and **Tools**. Menu buttons can be hidden under the **More** button. The **Simple style** has one primary menu which expands primary functions to lists of functions. Both menu styles can be further customized by modifying button positions and hiding entire functions.

This **User Manual** shows only the **Classic style** interface.

Audio prompt



Audio prompts for events like [Fix](#), [Float](#), [Autonomous](#), [Connection](#), [Disconnection](#), [Receiving NTRIP data](#) can be disabled, announced with a Ding or Voiced:



Warn if Base changes



Enable to issue a warning if the broadcast position of the current Base changes. This can happen if there are two bases on the same UHF frequency, or if the network generates a new base after a GNSS rover makes a substantial location change.


My cloud disk



Collaborative functions in LandStar 8

The [CHC Cloud](#) is a cloud based, collaborative work group and storage function. Operation relies on communication with a selectable server based in Europe or Asia. The services are SSL encrypted; however unencrypted files are stored on the endpoint servers. For this reason, cloud services may not be suitable for confidential work.


If LandStar is not currently logged into the CHC Cloud, clicking on any collaborative function:



will request a login to the cloud service:



Click on Change server:




Change the server to the European server. Then click **OK**.

Click to [Login](#) and use [Cloud services](#).


Storage

The following predefined storage locations are available from the CHC Cloud:



Web interface to CHC Cloud

Login to the CHC Cloud web interface for access to files from a desktop:



Crew mapping:



Collaborative work Group using CHC Cloud



Once logged into the cloud, **LandStar Workgroups** can be created or joined.

Workgroups share a common file repository where Projects, imported files, exported files, custom Coordinate systems, Code libraries, Roading files, and Base / Rover configuration files can be stored and shared.

Workgroups are assigned a unique **Group ID** by the server when they are created and are protected by a Password:

A 'Join in' dialog box with two input fields: 'Enter group ID' and 'Password'. At the bottom, there are two buttons: 'No' and 'Yes'.

Upload position to CHC Cloud



Uploads GNSS position **By Distance** or **By Time** to the CHC Cloud:

An 'Upload position' dialog box. It has a toggle switch for 'Upload position' which is turned on. Below it, there are two radio buttons: 'By time' (selected) and 'By distance'. Underneath, there is an 'Interval' field with '10 Second' entered. At the bottom, there are 'Cancel' and 'OK' buttons.


The uploaded position can be viewed in real-time via the web interface.

LandStar must be logged into the CHC Cloud to use this functionality.

Localization packages





Localization packages can hold region specific Geoids, profiles, and projections.



For the USA:



Click on the  Download button, then confirm **YES**:



Depending on the speed of the internet connection it could take a while for the download to complete:




When the download is complete, the package file will automatically be decompressed and installed.

Record track



Enable to continuously record the GNSS position to the local device:



A .CSV file named with the year, month day, hour, minute:

YYYY-MM-DD HH-MM-SS.csv

is created in the project folder:


/storage/emulated/0/CHCNav/Projects/_projectname_/

Each line entry includes:

no., latitude, longitude, H, East, North, elevation, time

The first line of the file includes a header description of the file contents.

Video Help, show video help button



In some regional markets, extensive recorded video collections are available for context sensitive video help.

When [Show video help for float button](#) is enabled, one of these icons will be shown on most screens:



Feedback



Click on Feedback to send suggestions directly to the LandStar developers:



Remote support



Allows access to the built-in remote support application.


Activate software / About



Displays the current software version and allows access to the licensing activation and transfer tools. See [LandStar 8 Licensing] on Page 7 for more information.

Software settings


Click on [Software settings](#). The device settings menu is shown:



Each of these setting items is described below.

After making changes to the settings, click [Save as default](#) if you would like the modified settings to be used when new projects are created.


Keyboard shortcut



If a device has hardware buttons, functions can be assigned to them. The assignable buttons will be a subset of these:

NONE, Enter/OK, Volume Up, Volume Down, Left, Right

Share method



Set the [Share method](#) to [Share by Android system function](#) unless the [CHC Cloud](#) will be used.

See [Collaborative functions in LandStar 8] on Page 23 for additional information.

Auto Ok



Enable [Auto Ok](#) to save keystrokes as you use LandStar. If you have difficulties with accidental tapping, or want to manually approve all changes, disable [Auto Ok](#).


Units

Controls the display, accepted input and units used in LandStar:



Angle


Sets the display of Angle values:



Set to **dd:mm:ss.ssssss** for operation in the USA. The **GONS** alternative is used in Europe.

Azimuth display mode


Set the method for directional display. When set to **Bearing** allows the use of **Quadrant bearings**.



Set to **Bearing** = Quadrant **Bearings** (USA and Canada); **Normal** = **Azimuth**.

Azimuth input mode

Set the method for directional inputs:



dd.mmsssss (USA) allows quick entry with a single decimal point. If Azimuth display mode = Bearing, then also accepts Quadrant shortcuts. See [Entering Azimuths/Bearings] on Page 14.

Lat/Lon input mode


Determines the required entry type for Latitude and Longitude:



Use `dd.mmssssss` (USA), `DD:MM:SS.ssss` requires the inclusion of ':' separators.

Lat/Lon display mode


Set the method for display of Latitude and Longitude:



Either `dd°mm'ss.ssss"` or `dd:mm:ss.sss` are typical in the USA.

Horizontal Distance

Sets the default units for horizontal distance measurements:



When entering distances, the default units can be overridden with:

- i international feet
- f US Survey feet
- m meters
- c chains

Vertical Distance

Sets the default units for vertical distance measurements.



Note: Many US States use US Survey feet for Horizontal and International feet for Vertical distances.

Area unit

Sets the default units for area measurements:



Typically, Acres or Square Yards for the USA.

Volume unit

Sets the default units for volume measurements:



Typically, Cubic Feet, Cubic Yards or Acre-feet are used in the US.

Note: the difference between cubic International Feet and cubic US Feet is very small:

10,000.000 cubic Meters =	353.144.55 cubic USFeet =	13,079.428 cubic USYards =
	353,146.67 cubic iFeet =	13,079.506 cubic iYards

Station

Sets the default display for alignment **stationing**, sometimes called '**chainage**':



Where the **Format** can be:



In the USA, stationing is typically shown as 100-foot increments with format K+00.00:
12,345.67 feet is shown as: K123+45.67

Decimals



These settings control the number of decimal places used to display values. The settings shown above should be reasonable for most applications in the US.

Coordinates



Set the **Coordinate order** to **North, East** for use in the US and Canada.
Most other countries and most CAD packages use **East (E), North (N)**.

GNSS settings

Survey Stakeout Surface stakeout R

Survey method
Topographic point survey

Accuracy check

Horizontal tolerance (HRMS)
0.328 ft

Vertical tolerance (VRMS)
0.492 USft

DIFF age
10 Second


MAX PDOP
6.000

Store fixed solutions only ☒

Store

Auto increment name interval
1

Measurements

These [GNSS settings](#) are also accessible from most of the survey menus by clicking the  **Setup** button. There are separate settings for [Topographic point survey](#), [Continuous survey](#), [Control point survey](#) and [Verified survey](#).

The available tabs are dependent on the survey method from where [Settings](#) is launched from. For example, if you enter from [Map survey](#) then these tabs are available:

Survey Display Tools IMU E-Bubble

while when entering from [Point stakeout](#) an additional [Stakeout](#) tab is available:

Survey Stakeout Display Tools IMU E-Bubble

entering [Settings](#) from [Surface stakeout](#) adds an additional [Surface stakeout](#) tab:

Survey Stakeout Surface stakeout Display Tools IMU E-Bubble

finally, entering from the [Side menu](#), [Software settings](#), [GNSS](#):

Survey Stakeout Surface stakeout Road Cross-section survey

Settings are organized on tabs.

Survey (tab of GNSS settings)

Topographic point survey settings

The screenshot shows the 'Survey' settings screen for a 'Topographic point survey'. The screen is titled 'job-20231029082446-Settings' and has tabs for 'Survey', 'Stakeout', 'Surface stakeout', and 'Road'. The 'Survey' tab is selected. The settings are organized into sections: 'Survey method' (Topographic point survey), 'Accuracy check' (Horizontal tolerance (HRMS) 0.098 USH, Vertical tolerance (Vrms) 0.154 USH, DIFF age 10 Second, MAX PDOP 5.000, Minimum Used SVs 4), 'Store fixed solutions only' (checked), 'Show' (Auto increment name interval 1, Measurements 5 Second, Pole stability warning checked, Pole movement tolerance 0.320 USH, Confirm before saving unchecked), 'Code' (Use quick codes unchecked, Add matching CAD layer when a new code is entered checked, Prompt when using a new line code checked), 'PVC' (Log RPK data unchecked), 'Miscellaneous' (Show average report after measure unchecked, Log epoch coordinate checked, Geometry factor 5, Show E bubble unchecked, Automatic photographing checked, Record GNSS Vector checked).

Topographic points are non-critical GNSS measurements. Typically, speed of acquisition is favored over long averages.

[Control survey](#) and [Verified survey](#) methods provide for long averages with multiple device resets to generate high confidence coordinates. See [Details: Survey (tab): Control survey] on Page 113, and [Details: Survey (tab): Verified survey] on Page 115 for additional information for taking critical GNSS measurements.

LandStar8 has two topographic modes: [Quick](#) (1 epoch) and [Topographic](#) (length set by Measurements) controlled by the [Survey type](#) button on the survey screen. The [Quick](#) mode shares tolerance settings with the [Topographic](#) mode, except for the [Measurements](#) time.

[Horizontal tolerance \(HRMS\)](#): the highest receiver reported HRMS that is allowed to be stored without user override.

Vertical tolerance (VRMS): the highest receiver reported VRMS that is allowed to be stored without user override.

Diff age: the longest allowed correction latency allowed without operator override. Normally the latency will be 1 or 2 seconds for UHF and network servers. Values higher than 10 indicate that the communication link is down.

MAX PDOP: the highest allowed PDOP. Usually PDOP's are less than 2.5, PDOP higher than 3 is worrisome.

Store fixed solutions only: only allow FIXED RTK solutions. Reject FLOAT, DGPS and Autonomous solutions.

Auto increment name interval: after a topographic measurement is made, the point name increments by this value. Usually, 1 or 10.

Measurements: sets the measurement averaging time in seconds for Topographic mode, typically 5-seconds. **Quick** mode is 1-epoch.

Pole stability warning: while measurements epochs are collected, if the horizontal range of measurements exceeds this tolerance, the user will be given a warning and the opportunity to escape and not store the measurement.

Confirm before saving: a measurement summary will be shown at the conclusion of averaging. The user can confirm and store or escape without storing the measurement.

Use quick codes enables/ disables the Quick code portion of the surveying and stakeout menus.

Quick codes disabled:



Quick codes enabled with 6 Quick code pages:



Results in this Survey screen with room for 54 code buttons:



Long-press and hold on a Code button to assign a code. Then click on a quick code button to automatically set the Code and take a measurement. See [Quick code panel] on Page 97 for additional information.

Add matching CAD layer when a new code is entered: when enabled creates a new CAD layer with a matching name to the new Code, assigned to the measurement.

Prompt when using a new line code will confirm when the code assigned to a line is changed to the previous line code:



Log PPK data when enabled assigns start and stop flags at the beginning and end of RTK average measurements, with the RTK point name, in recorded observation files (RINEX) for subsequent post-processing.

Show average report after measure displays a measurement report after each measurement that averages more than one epoch of data:




Log epoch coordinate adds detailed epoch data for all averaged measurements to the file **average-result.avr** located in the Project folder.

Show E-Bubble displays the receiver’s electronic bubble on survey screens. This is only applicable to receivers with an e-Bubble or an IMU like the i50, i80, i70, i90, i93, i73, i70, i83, iG8 or iG9.

Automatic photographing records a forward-facing photograph and downward-facing photograph using the built-in cameras on the Visual receiver for every measurement (Survey and Stakeout) attaching the photographs to the stored point as Multimedia:



Depending on the [Multimedia settings] see Page 78; the stored photographs will include the Name, Latitude, Longitude, Northing, Easting, Date and Time superimposed on the lower right corner of the image:



Automatic photographing is only available on Visual receivers like the i89 and i93. The Visual receiver must be connected by Wi-Fi to the Android device.

Record GNSS Vector adds ECEF Base to Rover deltas, variances, and covariances to stored measurements when enabled. Enabled this option if you plan to export Trimble .JXL files or RW5 files. Enabling this option may result in slightly increased power consumption on the Android device.

Continuous survey settings

Survey Stakeout Surface stakeout H

Survey method
Continuous survey

Accuracy check

Store fixed solutions only ☒

Store

Auto increment name interval
1

Mode
Time

Time interval
1.0 Second

Continuous surveying stores measurements continuously based on time interval or distance traveled. This can be useful for storing the centerline of a road from a moving vehicle.

Store fixed solutions only: only allow FIXED RTK solutions. Reject FLOAT, DGPS and Autonomous solutions.

Auto increment name interval: after a topographic measurement is made, the point name increments by this value. Usually, 1 is used for continuous surveying.

Mode: the trigger condition for taking another measurement.

Time: time interval in seconds.

Distance 2D: Horizontal distance of travel.

Distance 3D: 3D distance of travel.

Distance 2D or delta H: 2D horizontal or delta H triggers.

Control point survey settings

Survey Display Tools IMU E-Sub

Survey method
Control point survey

Accuracy check

Number passing measurement
5

Points per measurement group
10

Number of epochs per point
10 Second

Group horizontal range tolerance
0.066 USft

Group vertical range tolerance
0.066 ft

Epoch maximum HRMS
0.066 USft

Epoch maximum VRMS
0.096 ft

Wait after Read
15 Second

Max PDOP
4.000

Percent of pass (%)
80

The **Control point survey** takes repeated measurements averages, resetting the receiver between groups, waiting for a new fixed solution. If HRMS/VRMS and group range tolerances are not met, the control survey waits for better conditions. See [Details: Survey (tab): Control survey] on Page 113 for more information on **Control point** surveying.

Control point survey is intended to be used in open canopy on important points. A tripod or bipod **must** be used for a control survey as the measurement acquisition will not finish if the receiver moves during the relatively long acquisition period.

Verified point survey is like the **Control point survey**, except the **Verified survey** will continue to run when tolerances are not met and points can be observed during multiple sessions, on multiple days. The **Verified survey** allows the user to reject averaged groups after collection, while **Control survey** requires that all groups meeting the tolerance limits be included in the results. See [Details: Survey (tab): Verified survey] on Page 115 for more information on Verified point surveying.

A measurement group is comprised of several point averages that are themselves averaged epochs.

Number of passing measurements: measurement groups will continue to be collected until this number of groups passes all tolerance settings.

Points per measurement group: the number of multi-epoch averaged points per group.

Number of epochs per point: the number of epochs averaged to make a point in the group.

Group horizontal range tolerance: the horizontal range of multi-epoch points in a group must be less than this tolerance.

Group vertical range tolerance: the vertical range of multi-epoch points in a group must be less than this tolerance.

Epoch maximum HRMS: the receiver reported HRMS must be less than this tolerance for epochs to be accumulated.

Epoch maximum VRMS: the receiver reported VRMS must be less than this tolerance for epochs to be accumulated.

Wait after fixed: the receiver's OEM engine will be reset between each group. The survey will wait for the receiver to fix, plus this additional time for the receiver to settle down. A minimum of 15 seconds is recommended.

Max PDOP: epochs will not be stored if this PDOP is exceeded. Normal PDOP's are less than 2.5, so a setting of 3 may be reasonable.

Percent of Pass: the minimum number of passing points.

Common GNSS Survey settings

All of the GNSS Survey methods share these additional settings.



Auto increment name interval: after a topographic measurement is made, the point name increments by this value. Usually, 1 or 10.

Create a new code with the same name layer: if the user types in a new code and stores a measurement with the code, enabling this option will create a matching layer and place the point on the layer.

Log PPK data: write Time Tagging data (the point name) into the static observation file that is being recorded in the receiver's memory.

Show E-Bubble: enables the E-Bubble on the display screen. This is only applicable to receivers with an e-Bubble or an IMU like the i50, i80, i70, i90, i93, i73, i70, i83, iG8 or iG9.

Stakeout (tab of GNSS settings)




The settings on the [Stakeout](#) tab of [GNSS](#) settings control the operation of the stakeout screens: [Point stakeout](#), [Line/Arc stakeout](#), [Surface stakeout](#), [Road stakeout](#), [Sideslope stakeout](#).

Point name prefix: prepended to the staked point name. For example, when staking a point name 1001, the stored measurement after staking the default name for the new point will be "STK1001". See [Auto description for staked points] on Page 125 for additional information.

Target station as a point name: if staking a line or polyline, use the station along the line as the point name: "K1+12.345"

Display point name, code input box: disable to hide the point Name and Code boxes from the map screen. This results in a larger map area.

Stakeout tolerance 1, 2, 3: There are three circles displayed around the staked point:



The outside ring is tolerance 3, the middle ring is tolerance 2 and the solid inside ring is tolerance 1. When storing a staked measurement, if the current position is outside of the center ring (tolerance 1) a warning message is displayed.

Distance to switch to Visual Stakeout (Near): using a receiver with visual stakeout cameras (for example the i93), when staking a feature, when closer than the **Near** tolerance, visual stakeout will automatically switch to the bottom camera on the receiver.

Distance to switch to Visual Stakeout (Far): using a receiver with visual stakeout cameras (for example the i93), when staking a feature, when within the **Far** tolerance, but further than the **Near** tolerance, visual stakeout will automatically switch to the forward-facing camera on the receiver.




Auto zoom: the map image will automatically zoom in closer as the measurement approaches the staked point.

Use PDA compass: uses the internal compass of the PDA (tablet) to compute the direction to the target point when enabled. If disabled, use the GPS track to determine the direction to the target point.

Remove staked points from list after staking: When staking points, it is possible to stake from the **Points to stake** list, which is the right-hand column of the **Point list**:



Enable **Remove staked points from list after staking** to automatically remove points from the **Points to stake** list so that they are only staked once.

Previous/Next skip staked points: all the points in the **Point list** have an internal *Staked* attribute. When you stake a point, the point is marked as *staked*. Enabling this option will skip *staked* points when using the **Next**, **Last** and **Auto nearest** buttons:   . You can still select *staked* points by manually typing in the point name or selecting from the **Point list**.


Stakeout survey points: when disabled only points in the **Points to stake** may be staked. When enabled all points are eligible for staking.

Search for the nearest point from the stakeout list only: when enabled, only points in the **Points to stake** list are considered when looking for the nearest point. Disable to consider all known points.

Navigation text size: select the smallest size that is comfortable to read, this will maximize the remaining screen available for map display.

Use auto description controls automatically populated descriptions for staked points. See [Auto description for staked points] on Page 125 for additional information.

Display settings



These settings are found under **Software settings: Display settings**:

Snap Settings: enable snap modes for picking points, lines, centers. These snaps are used in CAD, storing and staking points from survey menus:

- Node**: snap to a point
- End**: snap to the end of a line or vertices of a polyline.
- Midpoint**: snap to the middle of a line segment.
- Center**: snap to the center of a circle.
- Intersection**: snap to the intersection of two lines.
- Nearest**: snap to the nearest point on a line.
- Perpendicular**: The point at a 90-degree angle.
- Any**: allows snapping to an open location anywhere on the map.

The  tool is useful for picking with the **Any** snap. Click-and-hold on the  tool to quickly modify the **Snap settings**. See [Snap] on Page 46.

CAD settings

Background color: choose dark or light background colors on the CAD and map staking screens.

Display line width: when enabled the layer or drawing's line width is honored. If disabled, lines are drawn 1-pixel wide.

Display line style: when enabled the layer or drawing's line style is honored. if disabled, lines are drawn solid.

Display line nodes: enable to show polyline vertices.

Layers: click on the line to view the Layer list. Additional information is available in the next section.

Display surveyed points: uncheck to hide measured points.

Display entered points: uncheck to hide points that have no GNSS or TS measurement data. These are typically imported, hand entered or calculated points.

Display points to be staked: disable to hide points in the Stake list.

Points size (without code): display size for points that do not have a known code.

Points color (without code): display color for points that do not have a known code.

Point name: show point names in CAD and map survey. Click the color box to set the color.

Point elevation: show point elevation in CAD and map survey. Click the color box to set the color.


Point code: show point codes in CAD and map survey. Click the color box to set the color.

Line name: show Line names in CAD and map survey. Click the color box to set the color.


Text size: the size of text in Text boxes drawn on maps and CAD.

Display coordinates after point selection: show the N, E, Z of points when they are selected in CAD or for stakeout:


Disabled:



Enabled



GNSS position symbol and color: choose the symbol type, size and color. Click on the symbol to select from these symbols and sizes:




Click on the color bar to select a color for the GNSS position display.



Tool tray

The [Map survey](#), [Point survey](#), [Control survey](#), [Verified survey](#), [Point stakeout](#), [Surface stakeout](#), [Sideslope stakeout](#), [Area survey](#) and [Hydro survey](#) all have a user defined tool tray that aligns to the left side of the map panel:




The tools in the [Tool tray](#) and the tool ordering are fully programmable by the user.



The only permanent tool is the [Setup button](#) .

Clicking the bottom tray button  collapses the tray to the top of the map area. Once collapsed, clicking  restores the tool tray.

If the tray has more tools than can be displayed, drag the tool tray up or down to view hidden tools.

To configure the tray, click on the [Setup button](#)  then select the [Tools](#) tab:



To add an [Unselected](#) tool, click on it in the left [Unselected](#) tray, then click the  button to move it to the [Selected](#) tray. The  button will move the highlighted icon from the [Selected](#) tray to the [Unselected](#) tray.

The tools in the [Selected](#) tray can be reordered by click-holding and dragging them up or down.

Not all the tools are available in all the survey menus, and some of the tools are always shown when in specific survey methods.

Add text to map



Click on the map, then enter a text screen to add a text note on the map. The size of the added text is dependent on the zoom level when the text is added.

Attributes



View the attributes of the currently selected object (point, line, polyline, alignment.)

CAD view



Switch directly to the [CAD view](#). This is the same action as clicking the [CAD view](#) main [Survey menu](#) icon:



After using [CAD view](#), clicking back will return to the previous survey menu.

Center GPS position



Continuously centers the map at the current GPS position, when enabled (orange colored.)


Delete



Delete the currently selected object from the map.

Delete last point



Delete the last measurement. This is useful for quickly removing the last measured point and perhaps replacing it with a new measurement.  might also be useful for just changing a few attributes of the last measurement.


Edit last point



Allows direct editing of the last surveyed point’s properties:

Useful for adding Multimedia (Pictures, Video, Audio) resources to measurements. See also [Point properties and attributes] on Page 77 for additional information.

Enter a point (to stakeout)



This tool is available in both [Point](#), [Line/Arc stakeout](#) and [Road stakeout](#).

Point stakeout

Enter a new point, then stake it out. Optionally add the newly staked point to the [Point list](#).

Check [Save to Point list](#) to add the newly entered point into the [Point list](#). The point is not added to the [Stakeout list](#).

Line stakeout

When staking a line or polyline from [Line/Arc stakeout](#), click the [Enter point](#) tool to stake a station along the current line.


Roading Stakeout

When staking a line from [Road stakeout](#), clicking the Insert point tool allows manually entering or staking a random point, or to enter/stakeout a station and offset from the current centerline.


Entering a point with coordinates:

Entering a point at a Station + Offset:

Quick access



Opens the side panel for [Quick access](#) to [Software settings](#) and [system settings](#)



Click the [Quick access](#) button again to collapse back to [Map survey](#).

The [Quick access](#) button and the staking from survey ability makes it possible to use LandStar as a single menu application.

Explode Block



If an imported DXF with blocks exists [Explode](#) will break every block into the original, ungrouped entities.

Export DXF



Exports all the points, lines, objects in the current project to a DXF file.

Export Surface staked report



Export surface staked report

This tool is automatically added to the Tool tray when in Surface stakeout mode. Clicking it writes two files:

.csv containing: Name, Northing, Easting, Design elevation, elevation, DeltaH, Date_time

.txt containing: Name, Northing, Easting, Design elevation, elevation, DeltaH, Date_time

Follow (rotate)



Continuously rotate the map alignment to match the PDA's internal compass direction. When disabled, grid North is always up.

Full view



Zoom to the full extent of the drawing and points.

Import DXF



Import a DXF drawing into the current project. The drawing should have the same projected coordinate system and units as the current project. Also available from the Project (Main menu tab) > Import function.

Invert line direction



Invert the direction of the selected line.

Layers



Displays the [Layers](#) dialog. See [Work layers, Map files, Online map] on Page 49 for additional information.

Nodes list



Available from the Line/Arc stakeout menu, lists the nodes of the currently staked line/polyline. Each segment endpoint and center are listed.




Select a node then click Stakeout to immediately stake the node.

Select a node then click Save to save the node or all nodes.

Online map



Control the map screen background map:



Read about the [Map files](#) and [Online map](#) tools in the [Layer manager](#). See [Work layers (tab)] on Page 82.

It is possible to download project map coverage for offline use and control the map transparency for better visibility.

See [Online map (tab)] on Page 84 for details.

Region list



Region list

Always added to the [Tool tray](#) when using the [Area survey](#). Allows deletion and export of defined areas and regions. See [Details: Survey (tab): Area survey] on Page 139 for additional information.


Snap



Allows selection of points, object endpoints, midpoints, random locations by using the large circle to move the arrow using your fingertip, with the small arrow point picking features that would be difficult to click on directly with your finger.



Long press on the [Snap tool](#) (on the Toolbar) to directly display the [Snap to object](#) menu:



[Snap settings](#) are also available from [Settings > Display](#):



Offset stakeout



Available from [Point stakeout](#). Allows the stakeout of a location that is not in the [Point list](#), but that can be described by an offset from an existing point or object.

See the Point stakeout section of this manual for details on [Offset stakeout](#).

Offset survey (hidden point survey)



Available in [Map Survey](#) and [Point survey](#). Allows storing a measurement that cannot directly occupied.

See [Map survey](#) for additional information.


Open road (project) file



Open a saved roading project.

Pan to (center map at)



Center the map at a position from the [Point list](#) , or a manually entered Northing and Easting.




Panel (surface stakeout)



Displays a large balloon window with the Cut/Fill to the current stakeout surface. Available in [Surface stakeout](#). See [Details: Survey (tab): Surface stakeout] on Page 137 for additional information.





Fill, within Surface Stakeout Tolerance



Fill, outside of Surface Stakeout Tolerance

The background color will be green for **FILL** and red for **CUT**.

The bar color will be  red if the [Surface stakeout](#) > [Tolerance](#) is exceeded and  white if the tolerance is met.

Point list




Switch to the [Point List](#):



Select a point in the list, then slide it right to reveal [Delete](#), [Map](#), [Stakeout](#) and [Edit](#) functions:



Click on the stake button:  to begin a stake operation on the selected point.

See [Details: Project (tab) > Point list] on Page 70 for additional information.

Point Survey



Switch directly to the text-based [Point Survey](#) tool. This is the same action as clicking the [Point survey](#) main [Survey](#) menu icon:



Redraw



Regenerate the current map view.


Regions



Shows the list of regions in the current project. Part of the **Area survey** tool. Regions can be defined by taking a series of measurements around an area feature. The 2D & 3D area, 2D & 3D perimeter and a description of the area are shown in the region with a colored boundary and transparent interior color.

Reverse line



Clicking  reverses the direction of the active line, this tool is automatically added to the **Tool tray** when staking a **Line, arc or polyline**.

Save object



Select a drawing line or polyline object, save it to the Line list with a name. Selecting a point, then **Save object** will duplicate it to a new point.

Survey boundary




Allows the description of a polyline boundary around the project.
Once defined, a voice warning will announce when the receiver leaves the project boundary.

Zoom In



Zooms in to 50% of the current map coverage at the center location.

Zoom Out




Zooms out to double the coverage at the center location.

IMU settings and status

On survey screens that have a possibility of using IMU Tilt correction, if the connected receiver supports IMU an IMU Settings screen will be available.



Use IMU enables and disables the **IMU (Tilt correction)**. The **IMU (Tilt Correction)** is always disabled for the **Control survey** and **Verified survey** method. The **IMU** adds additional measurement uncertainty, and it is reasonable to disable the **IMU** when storing and staking important boundary or control monuments for higher accuracy.

Show IMU button turns the survey menu screen IMU control button:  on an off.

Frequency of output will be automatically set to the highest frequency supported by the receiver and the connection method.

The Info section includes detailed information on the tilt, tilt direction and the compensated Pole-tip location in Lat/Lon/Ellipsoid height and Northing/Easting which is derived from:

Receiver Phase Center + L1 offset + Instrument Height + Tilt + Direction


Work layers, Map files, Online map


Controls Layer visibility, color, fill, line type; background map layers, online maps, downloads cached maps from online sources.

See [Work layers, Map files, Online map] on Page 49 for more information.

Instrument Select & Status information

A Status line is included at the top of most LandStar screens:



The  **Instrument select** button allows quick instrument selection.

Each of the other icons is clickable and links to additional detailed instrument status information.

Instrument select

The top line of most menus and functions includes the **Instrument select** button:



Click the  **Instrument select** button:




Then choose from **GNSS Rover**, **GNSS base** or **TPS** (Total Station).

Finally select the desired Instrument profile from the profile list and click **Accept**.

Instrument status






Clicking icons on the top receiver information bar

 displays status information about the currently connected receiver. Each of these screens are also available from the main menu **Config** (tab) > **Instrument info** tool.

Instrument information

Click  to display detailed instrument information:





- These icons link to additional functions:
-  add registration information to the receiver.
 -  update the receiver or OEM board firmware.
 -  link to the receiver configuration menu.

Sky Plot and Satellites information



This icon continuously displays the number of satellites **In Use / Tracked**.

Click  to show the detailed Sky Plot information screen:





Each constellation is shown on separate tabs at the bottom with colored bars indicating relative signal to noise values. Higher is better. The color mapping for each constellation is:

	GPS	GLONASS	BDS	Galileo	QZSS
BLUE	L1	L1	B1	E1	L1
GREEN	L2	L2	B2	E2	L2
RED	L5	L3	B3	E5	L5

Click the next **Satellites** column to display the satellite information in table format:

	Quality	Sky plot	Satellites	GNSS base
GPS	3	L1C: 47.0 Angle: 49	L2W: 46.0 Azimuth: 190	L3Q: 88.0 Locked: Yes
GPS	4	L1C: 49.0 Angle: 78	L2W: 50.0 Azimuth: 200	L3Q: 52.0 Locked: Yes
GPS	7	L1C: 48.0 Angle: 21	L2W: 38.2 Azimuth: 250	L3Q: 0.0 Locked: Yes
GPS	9	L1C: 47.0 Angle: 47	L2W: 48.0 Azimuth: 210	L3Q: 90.0 Locked: Yes
GPS	16	L1C: 48.0 Angle: 60	L2W: 45.0 Azimuth: 91	L3Q: 0.0 Locked: Yes
GPS	26	L1C: 48.0 Angle: 40	L2W: 47.0 Azimuth: 23	L3Q: 01.0 Locked: Yes
GPS	27	L1C: 37.0 Angle: 10	L2W: 40.0 Azimuth: 127	L3Q: 40.0 Locked: Yes
GPS	31	L1C: 33.0 Angle: 19	L2W: 29.0 Azimuth: 52	L3Q: 0.0 Locked: Yes
GLONASS	8	L1C: 40.0 Angle: 52	L2W: 0.0 Azimuth: 137	L3Q: 0.0 Locked: No
GLONASS	7	L1C: 52.0 Angle: 70	L2W: 50.0 Azimuth: 220	L3Q: 0.0 Locked: No

Quality

Click  or  to display the receiver solution quality status:

Instrument info		Quality	Sky plot	Satellites
Current position				
Solution Fix				
Loc: 109 11 03.895532... East(E): 228636.17%				
Loc: 049 52 08.296785... North(N): 349047.7%				
H: 5622.741 USF		Elevation: 5685.108 USF		
Satellites				
GPS: 8/8	GLONASS: 6/4			
GDOP: 7/7	GDOP: 3/5			
GDOP: 11/3	GDOP: 0/0			
Accuracy				
H: 0.045 USF		V: 0.075 USF		
DOPs				
HDOP: 0.622	VDOP: 1.019	PDOP: 1.196		
TDOP: 1.777	GDOP: 2.140			
Data link				
Internal radio		DIFF age: 1.55second		

H is the ellipsoid height. **Elevation** is the projected orthometric height (assuming a GEOID is loaded).

Accuracy is a computed mathematical 1-sigma error estimation for the **Horizontal** and **Vertical** positions.

DIFF age is the age of received corrections and typically should be 0, 1 or 2 seconds.

GNSS Base information

Click the **GNSS base** GNSS base tab to show the current position of the base in use.

Quality	Sky plot	Satellites	GNSS base
Position			
Distance: 33.863 USF Data H: 4910.140 USF			
Bearing(Coord North): 199.0822.842			
Loc: 109 11 04.2720... E: 5206305.844			
Loc: 49 52 08.4790 N Y: 14963405.826			
H: 509.448		Z: 13625188.228	
Others			
Name:			
Remaining battery power of GNSS base: 50.0%			

Main menus and program functions

LandStar has many functions grouped into four tabs of **Main menu** items:

:





Project menu tab

Survey menu tab

Configuration menu tab


Tools (COGO) menu tab:

Click and hold on function buttons, then drag them to change the button positions and order.


Not all the functions will be needed for most users. Hide the unneeded functions under the  **More** button by clicking-and-holding the unneeded function button until red minus signs  appear in the function button corners.

Then click the minus circles of all the functions you want to hide:



To add the hidden function buttons back to the main menu tab, click the  More button:



Then click the  button of the functions to move them back to the primary screen.

Each of the available functions is summarized in the following section with links to additional, detailed information.

Project (tab)

The main menu **Project** tab holds the project data related functions.



Projects

Open an existing project or make a [New project](#). Existing projects can be used as a [Reference](#) base for [Coordinate system](#), [Codes library](#), [Project settings](#), [Control points](#), [Entered points](#), and [Stakeout points](#). See [Details: Project (tab) > Projects] on Page 63.



Coordinate system

Select or modify the [Coordinate system](#) that is used to convert Lat/Lon/Ellipsoid Height to projected Northing, Easting and Orthometric heights. The coordinate system includes the [Ellipsoid](#), [Projection type](#) and [parameters](#), [Transformation](#) (7-parameters, 3-parameters, Hemert, Datum Grid), [Horizontal adjustment](#) (Plane, Single point), and a [Vertical adjustment](#) (GEOID + Constand, Surface or Inclined plane.) LandStar includes predefined coordinate systems for 1,000's of worldwide projections or you can enter a new projection manually.

See [Details: Project (tab) > Coordinate system] on Page 64.



Single point localization

Allows projected coordinates at the [Grid](#) base elevation to be moved up to [Ground](#) using a [Combined Scale Factor](#) comprised of a [Projection Grid Scale Factor](#) and [Ellipsoidal reduction factor](#) and a rotation about a base [Reference point](#). Arbitrary [Ground](#) coordinates (like 10,000, 10,000) can be associated with the base point. The resulting basis-of-bearings can match the underlying coordinate system (State Plane Coordinates), align the reference axis with Geodetic (True) North, or be manually set to an arbitrary alignment.

See [Details: Project (tab) > Single point localization] on Page 68.



Displays the **Point list** which itemizes all **Entered**, **Control**, **Reference points** in the project. The **Points to stake** list is an itemized list of points that need to be staked.
See Details: Project (tab) > Point list] on Page 70.



Manage the **Code list**. **Codes** are used to classify points and include a **Code Name**; **Type**: Point, Line; **Description**; **Display symbol**, **size**; **Layer**; **Line type**, **width**, **fill**, and **transparency**. **Codes** are intertwined with **Layers** and new **Codes** can optionally generate a matching **Layer**. **Codes** can have specific drawing attributes or inherit the attributes from their associated **Layer**. Tools are available to import, save and share the **Code list**.
See [Details: Project (tab) > Codes] on Page 80.



Manage the drawing layers. **Points**, lines and other objects are all associated with a drawing **Layer**. **Layers** can be ON-visible or OFF-hidden, which allows the **CAD view** to be simplified for specific tasks. Layers attributes include **Color**, **Line width**, **Fill color**, **Opacity**, and Line type. The **Layer manager** also includes the stack of background maps (**Map files**) and the **Online map** manager. See [Details: Project (tab) > Layers > Work layers, Map files, Online map] on Page 82.



Import data in a variety of formats (Text, DXF, DWG, SHP, KML, KMZ, TIFF, MBTILES (Global Mapper), Jmtiles (CHCNav), WFSDB (CHCNav), JPG, INS) to the **Entered Point list**, **Control point list**, **Points to stake list** and the **CAD view**.
The Text file importer allows the generation of custom file formats containing: Name, Code, Northing, Easting, (orthometric) Elevation, Longitude, Latitude, (ellipsoid) Height, Description, and skipped items. The text file importer understands: .CSV, .TXT, .DAT, .XLS and .XLSX file formats with comma, semicolon, space and multi-space delimiters.
The format 'USA: P,N,E,Z,D' is the correct format for 99% of applications in the USA.
See [Details: Project (tab) > Import] on Page 85 for details.



Export data writes output files in text or standard formats in a variety of styles. The formats 'USA FULL: P,N,E,Z,C,D' or 'USA: P,N,E,Z,D' are the correct format for 99% of applications in the USA.
See [Details: Project (tab) > Export] on Page 86 for details.




Surfaces can be used in Volume calculations and staked for Cut/Fill. The **Surfaces manager** allows direct import from CASS triangulation files, HC triangulations files, 3D DXF (.dxf) files and LandXML (.xml) files or surfaces can be created from a single point or a list of points that define a surface. Breaklines and boundaries are also supported for developed surfaces. The Surface manager allows granular control of the triangle networks used to approximate a surface. See [Details: Project (tab) > Surfaces] on Page 90 for detailed information.
Once a surface is defined or imported, use the Survey: **Stake surface** tool to stake them. See [Details: Survey (tab): Surface stakeout] on Page 137 for more information.



The **Features list** shows all **Points**, **Lines** and **Polygons** in the current project that have **GIS attributes**. Assign **GIS features** to a **Code**, then when a point or line is collected with the matching **Code**, attribute

entry will be enforced. The [Features list](#) allows editing the associated data, directly from the listing. See [Building GIS Datasets in LandStar] on Page 219 for help adding GIS features to Codes.



Lines / Arc list shows all the named lines and polylines in the current project. Stake these objects by sliding the line to the right, then clicking on the  [blue stake](#) button. Editing an object will display starting + ending coordinates, 2D + 3D length, ▲ Elevation, bearing/azimuth, and slope. Manually enter line segments using the [Add](#) button at the bottom of the list.



This is a list of the recorded [Visual survey](#) tasks. Use this function to process the images and to snap additional target points.
See the [Visual survey Images list] section on Page 112.



The [Roads tool](#) allows import of Centerline and Cross-section definitions. [Roads list](#) catalogs the available [Roads](#) and allows one road file to be activated. Each [Road](#) can have [Station numbering equations](#), [Horizontal alignments](#), [Vertical alignments](#), [Cross-section templates](#), [Cross-section template positions](#), [Super-elevations](#), [Width lists](#), [Side slope templates](#), and [Side slope template positions](#). Roads is covered in a separate User Manual.

Survey (tab)

The main menu [Survey](#) tab organizes survey related tasks.



[Survey](#) (store) Point locations with direct or offset measurements and includes mapping backgrounds. Optionally group Points into Line, Polyline and Arc objects.
See [Details: Survey (tab) > Map Survey] on Page 95.



[Point survey](#) is like [Survey point](#); however, the interface is greatly simplified for a text-based representation. Fewer [Tools](#) are available.
See [Details: Survey (tab) > Point (text) Survey] on Page 108



[Visual survey](#) records pictures with the camera built into a receiver while moving along a path. The resulting pictures can be processed in the data collector, then points can be picked and stored from the images. A vision enabled receiver like the i93 is required.
See [Details: Survey (tab): Visual survey] on Page 108



The [Control survey](#) tool automates acquiring multiple groups-of-averages, automatically resetting the GNSS engine between groups, and performing statistical combination of the measured epochs.
See [Details: Survey (tab): Control survey] on Page 113.



The [Verified survey](#) tool automates acquiring multiple groups-of-averages, automatically resetting the GNSS engine between groups, performing statistical and graphical analysis of the results to reject bad-

FIX and average good-FIXED measurements.

The intended use of the Verified survey tool is to acquire very reliable coordinates under extremely heavy canopy where the receiver is expected to encounter many bad fixes.

See [Details: Survey (tab): Verified survey] on Page 115.



‘Staking out a point’: using assisted navigation to move to a point’s known coordinates so the location can be marked by a stake, flagging, paint, whiskers, or other monument. **Point stakeout** provides a horizontal position and the deviation (cut/fill) to a target elevation. After setting a monument, typically the ‘set’ location is stored as an ‘as staked’ position for verification.

Offset staking allows staking a point that is offset from the selected point.

Visual staking displays the target point superimposed on a live picture from the receiver.

See [Details: Survey (tab): Point Stakeout] on Page 123.



Line/Arc stakeout allows the selection of a line, arc, polyline, object to stake. The line can then be staked to the nearest point on the line, endpoints, node points, random and even stations along the staked object. Offsets can be added by Left, Right, Ahead, and Behind. Visual staking is supported for receivers with internal cameras (like the i93.)

See [Details: Survey (tab): Line/Arc stakeout] on Page 131.



Surface stakeout accepts a surface to stake, then displays the cut or fill required to move the receiver up or down to the design surface. The delta is updated continuously as the receiver moves around. Surfaces can be defined by a single point; by three or more points (technically two-points would work, however an unintentional tilted-plane will result); importing a CASS triangulation file, a 3D DXF File or a LandXML file.

See [Details: Survey (tab): Surface stakeout] on Page 137 for additional details.



Area survey allows the collection of polygons representing the edges of a region. During collection either 2D or 3D area and 2D or 3D perimeter length are displayed. Once a region is complete, it will be displayed with 2D/3D area and perimeter. The areas can be exported to a PDF report showing the area and DXF drawing file.

See [Details: Survey (tab): Area survey] on Page 139 for additional information.



CAD View switches to a CAD style interface with a rich set of drawing, editing and measuring functions. Also available from the **Tool tray** and called by viewing shortcuts throughout the LandStar program.

See [Details: Survey (tab): CAD View] on Page 142 for additional details.



Road stakeout is covered in a separate User Manual.




Site calibration allows modification of the underlying coordinate system so that Measurements (**GNSS points**) best match record (**Known point**) data. Horizontal and vertical calibrations can be combined or

handled separately. [Site calibration](#) makes the GPS receiver use local coordinates. See [Details: Survey (tab): Site calibration] on Page 146 for additional information.



Base shift



CORS shift

[Base shift](#) and [CORS shift](#) are nearly identical functions. While [Base shift](#) works for a single base while [CORS shift](#) works for all future bases and is targeted towards CORS network corrections where the BaseID will change over time and distance.

See [Details: Survey (tab): Base shift and CORS shift] on Page 151 for additional information.



Sideslope stakeout

Automates staking a vertical profile perpendicular along a centerline (line or polyline). The profile can have multiple profile strings (segments with varying slope and width) and is mirrored on both sides of the centerline. The centerline might also be used to grade a slope against a building foundation.

See [Details: Survey (tab): Sideslope stakeout] on Page 155 for additional information.



Foundation stakeout


Foundation stakeout automates the design and staking of sloped pit walls around a foundation. At an offset distance, a sloping surface is defined which intersects with the undisturbed ground surface. The top edge of pit, wall slopes and building bottom can then be staked and excavated.

See [Details: Survey (tab): Foundation stakeout] on Page 157 for additional information.



Hydro survey

[Hydro survey](#) is a map survey method that shows the current position with a [Waypoint plan](#) detailing the desired hydrographic survey route. An [Echosounder](#) (Hydrolite DFX, Hydrolite TM, NMEA DPT, NMEA DBT are supported) provides [Depth](#) which is combined with the receiver position and [HI](#) vertical offset from the receiver to the sonar transponder to store derived bottom surface elevations at regular intervals.



Continuous survey

[Continuous survey](#) allows automatic collection of measurements based on traveled distance or incremental time. Measurements can be triggered by Time, 2D distance traveled, 3D distance travel or 2D delta and height delta.

See [Details: Survey (tab): Continuous survey] on Page 160 for additional information.




Cross-section survey

[Cross-section survey](#) allows quick point survey at evenly or randomly spaced cross sections along a centerline alignment. This survey tool displays the location relative to a cross-section station enabling quick navigation to the left, centerline, and right offset points. Extra measurements along the cross-section lines may also be stored.

In addition to the stored points, Station and offset information is available for all measurements collected using the Cross-section survey, including points stored at random stations, along with a DXF file that details every cross-section measurement.


See [Details: Survey (tab) Cross-section survey] on Page 162 for details.


Config (tab)



Instruments profile

Instruments profile combines the Bluetooth/Wi-Fi **Connection** (Connect to instruments) with a Rover, Base, TS/RTS instrument configuration (GNSS Rover, GNSS Base) to form a complete instrument definition.

Instrument profiles can be quickly selected and applied using the  **Instrument select** button. See [Details: Config (tab): Instruments profile] on Page 167 for more information.



Connect to instruments

LandStar connects to **GNSS receivers**, **Total stations** and **Peripherals** (Laser Rangefinder, Pipeline detectors, Echosounders) by Bluetooth. Most modern **GNSS receivers** also support a Wi-Fi connection. See [Details: Config (tab): Connect to instruments] on Page 169 for details.



GNSS rover

GNSS Rover configures the connected device as a Rover and includes the UHF Radio / Internal modem / PDA connection settings to provide RTK corrections. See [Details: Config (tab): GNSS rover] on Page 171 for details.




GNSS base

GNSS Base configures the connected device as a Base and includes Internal UHF Radio / External Radio / Receiver Cell Network settings to provide RTK corrections. Also does the **Base setup** putting a coordinate in the receiver. See [Details: Config (tab): GNSS base] on Page 174 for details.



GNSS static recording

Receivers can store static observation data for processing in desktop tools like CGO2, online tools like NGS OPUS and be used for UAV post-processing. GNSS static recording allows control of the receiver's recording settings. See [Details: Config (tab): GNSS static observation recording] on Page 178 for details.



Instrument info

The **Instrument info** tool provides extensive information about the currently connected receiver. See [Details: Config (tab): Instrument info] on Page 179 for details.



Activate instrument

Receivers can be temporarily activated or be geofenced with different options based on location. **Activate instrument** allows the user to enter a new activation code. See [Details: Config (tab): Activate instrument] on Page 179 for details.



Update

Receivers have firmware sets for the main board, the OEM GNSS engine, the cellular modem, and the UHF radio. It may be possible to automatically update a receiver using online resources. See [Details: Config (tab): Update] on Page 180 for details.



Advanced

The **Advanced** functions include: configuring the **NMEA output** for the Bluetooth channel, the RS232 Serial port and a special Raw TELNET port (1212) accessible via the Wi-Fi port; the receiver **Elevation mask** setting, the **Position output frequency**, an **OEM GNSS engine reset**, the APN for the cellular modem and a NFC/Wi-Fi function that may allow connection to some receivers by Wi-Fi or Bluetooth more easily.

See [Details: Config (tab): Advanced] on Page 180 for details.



NFC/Wi-Fi

Some receivers include **NFC** transponders. It may be possible to read the Bluetooth ID, MAC and PIN and the Wi-Fi SSID, MAC and password via NFC.

See [Details: Config (tab): NFC / Wi-Fi] on Page 182 for details.

Tools (tab)



Map adjustment

Map adjustment allows vector maps (DXF, DWG, SHP, KML and KMZ, WFSDB files) to be georeferenced with multiple affine points. This function will not adjust raster images.

See [Details: Tools (tab): Map adjustment] on Page 183 for details.



Volumes

Compute the **Volume**, **Surface area** and cut/fill balance of two surfaces or a surface and a reference elevation, then and create a **Volume report**

See [Details: Tools (tab): Volume computation] on Page 185 for details.



Area

Area accepts an ordered list of points and computes the area enclosed by them. The points can be selected from the **Point list**, from the **Map** or entered as a range of points.

See [Details: Tools (tab): Area computation] on Page 188 for details.



Inverse

The **Inverse** tool computes distance and bearing between two points or a series of points (Traverse style).

See [Details: Tools (tab): Inverse] on Page 190 for details.



Angle conversion

The **Angle conversion** tool is useful for converting Degrees Minutes Seconds to decimal degrees, decimal minutes, decimal seconds, radians and Gons; and vice-versa.


See [] on Page 190 for details.



Parameter calculation

Parameter calculation accepts matched sets of **GNSS points** (with underlying Lat/Lon/Height data) and **Known points** (projected values). After selecting a transformation style, verify residuals, and compute best-fit translation coefficients, the translation can be entered into the current project's coordinate system.

See [Details: Tools (tab): Parameter calculation, 3 or 7- parameter] on Page 191 for details.



Point to line
dist.

Computes the nearest point on a line to a specified point. Returns the **Station**, the **Offset distance** left or right, the nearest point can be saved to the **Point list** or directly staked out.
See [Details: Tools (tab): Point to line distance] on Page 193 for details.




Offset distance

Compute the angle of a point offset from the endpoint of a line to the line.
See [Details: Tools (tab): Offset distance] on Page 193 for details.



Deflection

Compute the **Deflection** angle of a point offset from the endpoint of a line to the line.
See [Details: Tools (tab): Deflection] on Page 195 for details.




Rotation

Rotate a point around another point, a specified angle. Create a new point at the new location.
See [Details: Tools (tab): Rotation] on Page 195 for details.



Intersection

Intersection accepts point pairs defining two lines, the intersection of the lines between these points are computed. If there is no direct intersection, the lines are extended.
See [Details: Tools (tab): Intersection] on Page 196 for details.



Bisect angle

Place a point on the line bisecting an existing angle, specifying the offset from the center vertices.
See [Details: Tools (tab): Bisect angle] on Page 198 for details.



Divide line

Divide line will divide the distance between two points into even segment lengths (**By distance**) or a whole number of segments (**By segments**). Point protection can automatically **Skip points that already exist at the same location** as the calculated points.
See [Details: Tools (tab): Divide line] on Page 199 for details.



Point average

Choose several existing points to average. Show the residuals for each added point and allow adding and removing points from the average before storing a new **Point average**.
See [Details: Tools (tab): Point average] on Page 200 for details.




Plot deed

Directly enter a Metes and Bounds survey or a Bearing Distance traverse with lines and arcs. **Plot deeds** from legal descriptions. Includes a Curve Calculator and provisions for arc tangent bearings or cord bearings.
See [Details: Tools (tab): Plot Deed] on Page 201 for additional information.



Transformation

Translate, rotate, scale points and objects based on a multi-point alignment or manually entered offset, rotation and scaling information.
See [Details: Tools (tab): Transformation] on Page 210 for additional information.



Area
subdivision

Subdivide an existing closed polygon into two parcels. Supports: parallel by two-points, perpendicular by two-points and hinge-point.
See [Details: Tools (tab): Area subdivision] on Page 216 for additional information.



Calculator

A simple [Calculator](#) for simple computations.
See [Details: Tools (tab): Calculator] on Page 215 for details.



Ruler


Displays a ruler that shows centimeters only.
See [Details: Tools (tab): Ruler] on Page 218 for details.

Function Details

Details: Project (tab) > Projects

Open an existing project from the [Project list](#) or make a new project.


Available from the [Project](#) (tab) > [Projects](#) button:




Click on [Time ↓](#) [Time ascending](#) and [Time ↑](#) [Time descending](#) to sort by the time the project was last used, not the creation time.

Click on [🔍](#) to search for projects by name.

Initially new projects will be placed in the [Default Project group](#) folder. Click on



to make a new [Project group](#) or select another group:




Sharing Projects

From the Project list, slide a project entry to the right:




Click the [🔍](#) [Share project](#) button. If the project has Visual survey images, image inclusion will be prompted:



Check [Share visual survey images](#) to include image sets. Enabling image inclusion will generate very large projects. The current project will be compressed to a single ZIP file. Share the file, typically by email or Google Drive if images are included, to another device or user.

On the receiving device, use the **3-Dot** button in the project list:




Then click **Load from file** to browse for the project file and restore it as a local project.

Project backups


LandStar automatically backs up projects at a defined interval and optionally each time you exit. These backups are ZIP compressed collections of project data and settings, they are stored in a separate folder from the primary project (to help protect against inadvertent deletion.)

Click the **3-Dot** button to change the automatic **Backup settings** or to **Restore** a project:



Load from file allows browsing device memory for a shared project file.

Backup settings:




sets the automatic project backup interval. Backups are not deleted, even if the job they are protecting is deleted, so if you inadvertently delete a job, the backup should/will remain. **Restore project from local** will restore a backup into the currently selected project folder.

By default, project backups are stored in the root folder:

/system_prj_backup


outside of the normal CHCNav folder hierarchy. Within the project backup folder there will be a subfolder for each job, within the job subfolder there will be one or two compressed .ZIP files holding the project's files.

When making a **New project**:



Enter a project **Name** and assign an **Operator** name.

Optionally pick a **Reference project** to inherit the **Coordinate System**, **Code library** and **Project settings**, **Control points**, **Entered points**, **Stakeout points** from:



If a **Reference project** is not used, select a **Coordinate system** for the new project. See the following entry [Details: Project (tab) > Coordinate system] for more **Coordinate system** details.

Details: Project (tab) > Coordinate system

Select or modify the **Coordinate system** that is used to convert Lat/Lon/Ellipsoid Height to projected Northing, Easting and Orthometric heights.

From the main menu **Project** (tab) click on the **Coordinate system** button:



The **Coordinate system** dialog is shown with these 5 tabs:



Ellipsoid

Projection

Datum trans


Horz. Adjustment

Vert. adjustment


LandStar has thousands of predefined coordinate systems. There are too many to pick from a single list. Instead LandStar maintains a [Common coordinate system](#) list that you can copy systems to from the giant [Pre-defined coordinate systems list](#). You can also add [User defined](#) systems to the Common coordinate system list.

The predefined coordinate systems fully implement the State Plane systems; however, they do not specify a Geoid. When you copy a predefined system to the Common list, you should always specify the correct Geoid.

Click on [From lib](#) [From lib](#) to access the Common coordinate system list. Initially there will be no systems listed:



Click on [Pre defined](#) [Pre defined](#) then set the [Region](#) to [United States](#).




The default [Area](#) will be NAD83(2011):



If you are looking for a special County zone, change the [Area](#):



A list of Area specific zones will be shown.



Drag the list down and select the correct SPC Zone for the Project area:



Finally click [Select](#).

If additional zones are regularly used, repeat as needed to add them into the Common coordinate list:



To add a Geoid into an existing Common coordinate system list entry, highlight one projection then click [Select](#):



Select the **Vert adjustment** tab:



then use the dropdown to choose a Geoid file to use. Currently **Geoid2018US** is appropriate for the continental United States. If the Geoid you need is not available make sure you have installed the localization package. See [Localization packages] on Page 25.

Change the **Name** of the system to include the Geoid:




Click on **Save to lib** **Save to lib** to save the coordinate system with the Geoid included as a Common coordinate system.

Finally click **Accept** **Accept**.



The zone will be available, with the Geoid applied in the Common coordinate system list:



To delete a **Common coordinate system**, slide the **Common coordinate system** to the right,



then click on the **Delete** button to remove it.

Coordinate system utilities


From the coordinate definition screen, click on the **More** button:



then **Create QR code** to display a QR code:




Which can be scanned by other devices using the [Scan QR code](#) tool:



[Use broadcast RTCM](#) will wait for the next RTCM transformation parameters broadcast as Message Type 1021 – 1028 and build a coordinate system. This option is extremely uncommon.

Click [Lock](#) to freeze the coordinate system and password protect it from inadvertent changes:



[Export](#) writes the current coordinate system to a Trimble .dc file. Most field software programs import Trimble .dc files directly.

[Load from file](#) will import:

- Trimble DC (.dc)
- Trimble JXL (.jxl)
- Trimble CAL (.cal)
- Leica LOC (.loc)

coordinate system definition files.


Details: Project (tab) > Single point localization

Allows projected coordinates at the [Grid](#) base elevation to be moved up to [Ground](#) using a [Combined Scale Factor](#) comprised of a [Projection Grid Scale Factor](#) and [Ellipsoidal reduction factor](#) and a [Rotation](#) about a base [Reference point](#). Arbitrary [Ground](#) coordinates (like 10,000, 10,000) can be associated with the base point. The resulting basis-of-bearings can match the underlying coordinate system (State Plane Coordinates), align the reference axis with Geodetic (True) North, or be manually set to an arbitrary alignment.




Begin from the [Project](#) (tab) > [Projects](#) button:





Slide the Use single point localization to the right:



A single menu will be shown:


Define the **Project BNSS Base Point** by picking from CAD with the  **CAD** button, making a new measurement at the current position with the  **Begin measurement** button, or select an existing GNSS measurement  from the **Point list**.

Next enter the **Project Base Local Coordinate** that the receiver should read when placed at the **GNSS Base Point**. Either type the coordinate in, select a **Known point** from  **CAD** or, select a **Known point** from the  **Point List**.

Choose a **Basis of Bearings** from **Geodetic (True North)**, **Grid North** (matches the current Coordinate system projected grid), or **Manual** entry.

If manual **Rotation** entry is used, extreme precision is required to match distant coordinates. The:

> button can be used to match the exact bearing between two existing points in the project.

Click the  **Calculate** button to automatically compute the **Elevation Scale Factor**, the **Grid Scale Factor** at the **GNSS Base Point**, a **Combined Scale** Factor and an appropriate **Rotation**.

Click  **Accept**,

then **Apply** to install the results into the current **Coordinate system**.


Check-in on the **GNSS Base point** using **Stake point**, the receiver's coordinates should exactly match the **Known point** entry.


The resulting **Horizontal adjustment** will be fully described on the **Project > Coordinate system > Horizontal adjustment** (tab);:

The computed Vertical adjustment will be fully described on the **Project > Coordinate system > Vertical adjustment**

(tab):



Clicking the  button from the **Coordinate system** allows sharing, Locking, Exporting and Loading the complete system:



To disable the Single point localization, return to the menu and slide the Use single point localization slider to the left:



When the coordinate system is changed, all projected coordinates of points with underlying GNSS values will automatically be updated.

Details: Project (tab) > Point list

Available from the **Project** (tab) > **Projects** button:



The **Point list** organizes 3 types of points:











- Survey** points that are measured with GNSS or TS/RTS.
- Enter** points that are imported, or hand entered.
- Control** points that are treated as high precision control points.
- Base** points that are associated with Base locations.

When entering the **Point list** screen, the **Project name** is shown at the top with the total number of points in parentheses (19). There are two tabs, the **Points** tab contains all the points in the project, the **Points to stake** tab contains a list of points to be staked. While it is not necessary to use the **Points to stake list**, it does help keep design points separate from surveyed points.




It is possible to drag-over rows in the Point list to select ranges of points. Click on the top or bottom item to select, hold, then drag up or down.

The left-hand column has an icon representing the type of point:

-  Entered
-  Averaged
-  Base
-  Rover
-  Imported
-  Entered **Control point**
-  Surveyed **Control point**
-  Staked
-  **COGO** computation result.
-  **Verified point survey**, multiple measurement survey.


	Name	Code	Description	North (m)	East (m)	Height (m)	Type	2D Area (m²)	3D Area (m³)	Time
	Base_1			3490004.825	2280076.234	56.7801	Base	67.845	68.258	2023-08-29 16:18:36
	1001			3440005.567	2280002.769	56.6935	Survey	0.004	0.015	2023-08-29 16:18:36

The width of the list is usually wider than the screen, drag/slide it left and right to view all the columns.

Click the  **3-dot** button in the upper right corner, then select Switch list style to change to the paragraph display


style for points:



Click the  **3-dot** button in the upper right corner to change the displayed columns and their order. The default columns are:

Name	The point Name or Number, names can contain spaces.
Code	The Code associated with the point. Codes can be coupled to Layers and automatic drawing automation.
Description	Descriptions can be any length. Most survey screens do not have a dedicated Description entry box, enter a Code followed by a question mark '?' (the Code escape character' and whatever follows the '?' will be placed into the Description .
North	The point Northing in the project units. Can be modified by 3-dot > Coordinate type .
East	The point Easting in the project units. Can be modified by 3-dot > Coordinate type .
Elevation	The point orthometric Elevation in the project units. Can be modified by 3-dot > Coordinate type .
Type	The type of point: Base , Survey , Entered , or Control .
2D dist	The horizontal distance from the current point to the next point in the grid.
3D dist	The 3D distance from the current point to the next point in the grid.
Time	The Date - Time the point was entered or acquired.
































The following columns are also available for display:

Solution	Fixed, Float, DGPS, Autonomous
Antenna Height	The Vertical HI of the GNSS receiver or prism.
 Elevation	The elevation change, from the current point to the next point in the list.


Satellites	The number of satellite vehicles used for the measurement.
PDOP	The PDOP while the measurement was acquired.
Picture	Displays the name of the picture.
Bearing	The azimuth or bearing from the current point to the next point in the list.

When a line is slid to the left, additional options are shown depending on the type of point:

Base


3-dot button

At the top right corner of the screen there is a  3-dot button (the [kebab](#) menu):



The items on the [3-dot](#) menu are:


Coordinate type

Click the  3-dot button, select [Coordinate type](#)



Change between Coordinate display types for the grid. See [[Entering / Viewing Geographic and Projected Coordinates](#)] on Page 15 for additional information.


Multi-select

Click the  3-dot button, select [Multi-select](#) to add checkboxes to the left of every line, allowing multiple points to be selected at once for [Deletion](#) or to [Reset](#)

[stakeout state](#) (see the 3-Dot button):




Recycle bin

Click the  3-dot button, select [Recycle bin](#) to view the deleted points. When points are deleted, they are moved to the [Recycle bin](#):



It is easy to restore the points in the [Recycle bin](#), or to permanently delete them.


Custom Display

Click the  **3-dot** button, select **Custom display** to select the Point list columns and reorder them for display:



Highlight an item, then use the **Up** and **Down** buttons to move it up and down in the list.

Set point(s) elevation

Click the  **3-dot** button, select Set point elevation to select one, or more, or all points to set the elevation of:




Click **Next**:




After a **Surveyed point's** elevation is edited, it will change to an **Entered point**.

Adjust point(s) elevations

Click the  **3-dot** button, select **Set point elevation** to select one, or more, or all points to adjust the elevation of:





Click **Next**:



After a **Surveyed point's** elevation is edited, it will change to an **Entered point**.

Set code to points

Click the  **3-dot** button, select **Set code to points** to add checkboxes to each point, check the points to assign a **Code** to:





Click **Next**:



Select a new **Code**, then click **OK** to set the **Code** of the highlighted points.

Set antenna height

Click the  **3-dot** button, select **Set antenna height** to add checkboxes to each point, check the points to change the antenna height of:




Click [Next](#):

A dialog box titled "Set antenna height". It contains a label "Antenna type" with a dropdown menu showing "CHC93 NONE" and a right arrow button. Below it is a label "Antenna height" with a text input field. At the bottom are "Cancel" and "OK" buttons.




Edit the [Antenna type](#) and the vertical [Antenna height](#) (H). Click OK, the antenna parameters are updated, and a new point elevation is applied to the selected points.

Shift GNSS base

Click the  [3-dot](#) button, select [Shift GNSS base](#).

A screen titled "Set16-Shift GNSS base". It has a "Parameters" section with "GNSS base" (dropdown "base_1"), "Antenna type" (dropdown "CHC93 NONE"), and "Antenna height" (text input "6.582"). Below is a "Known point" section with "Coordinate format" (dropdown "Local N/E/Elev"), "North (N)" (text input), "East (E)" (text input), and "Elevation" (text input). At the bottom is an "Accept" button.

Use the drop-down list to choose the [Base to move](#). It is also possible to change the Base [Antenna type](#) and [Antenna height](#) along with the new base position.


The new [Known point](#) for the selected base can be retrieved from  [CAD](#), making a new measurement at the current GNSS  [Start measurement](#), picking from another point in the  [Point list](#) or hand entering a new point. To hand enter, choose the position type:

A small dialog box with two options: "Local N/E/Elev" and "WGS84 Lat/Lon/H".

Local Northing, Easting, orthometric Height:


A form with a "Coordinate format" dropdown set to "Local N/E/Elev". It has three text input fields labeled "North (N)", "East (E)", and "Elevation".


or Latitude, Longitude, Ellipsoid Height:


A form with a "Coordinate format" dropdown set to "WGS84 Lat/Lon/H". It has three text input fields labeled "WGS84 Lat", "WGS84 Lon", and "WGS84 H".

Click on [Accept](#) to apply the new Base parameters which will shift all the GNSS points that were collected with the selected base.

Show / Hide GNSS base points.


If the GNSS Bases are shown in the [Point list](#), Click the  [3-dot](#) button, select [Hide GNSS base points](#) to remove them.


A screenshot of the "Points" screen. The "Points to stake" list shows a table with columns "Name", "Code", "Description", and "Type". The first row is "base_1" with code "1001" and description "Shift_S09".

If the GNSS Bases are not shown in the [Point list](#), Click the  [3-dot](#) button, select [Show GNSS base points](#) to add them to the list them.


A screenshot of the "Points" screen. The "Points to stake" list shows a table with columns "Name", "Code", "Description", and "Type". The first row is "base_1" with code "1001" and description "Shift_S09".

Sort newest to top/bottom


By default, the point list order is first to last click the  [3-dot](#) button, select [Sort newest to top](#) to reverse the list.

If the newest point is sorted to the top, click the  [3-dot](#) button, select [Sort first to top](#) to reverse the order.

Reset stakeout state


Click the  [3-dot](#) button, select [Reset stakeout state](#) to mark all points as un-staked. This makes them eligible for staking with [Stake nearest](#) operations which automatically exclude previously staked points.

Data statistics

Click the  **3-dot** button, select Data statistics to show a short summary of the [Points list](#):

Data statistics	
Total points:	38
GNSS base points:	1
Survey points:	17
Control points:	2
Enter points:	19

Switch list style

Click the  **3-dot** button in the upper right corner, then select Switch list style to toggle between the line display style and the paragraph display style for points.

Line display style:

AE	Name	Enter & search item
None	Code	Description
	base_1	
	1001	5669.356

Paragraph style:

Points		Points to stake
AE	Name	Enter & search item
	base_1	Base
	N: 3490604.825	
	E: 2280576.234	Description
	Elev: 5678.091	T: 2023-09-03 19:54:46
	1001	Enter
	N: 0.000	Code: 5669.356
	E: 3490608.567	Description
	Elev: 2280602.765	T: 2023-09-04 16:09:42

Point properties and attributes

Points in the **Point list** can have several attributes besides position, **Code**, **Name** and **Description**. An **Enter point** type will have simple properties, while a **Surveyed GNSS point** will have many additional **Survey properties** and **Quality properties**.

NormalAttributesMultimedia

Survey info

Name

1001

Code

>

Type

Enter

>

Format

Local N/E/Elev (Projection:grid)

North (N)

0.000 USR

East (E)

3490608.567 USR

Elevation

2280602.765 USR

Description

Survey time

2023-09-04 16:09:42

Save

Entered point

NormalQualityAttributesMultimedia

Survey info

Name

129

Code

>

Format

Local N/E/Elev (Project)

>

North (N)

3490669.792 USR

East (E)

2280667.593 USR

Elevation

5673.009 USR

Antenna type

CHCN3 NONE

Measure to

Vertical H

>

Antenna height

0.562 USR

Description

Type

Survey

Base info

Name

base_1

Format

Local N/E/Elev (Project)

>

North (N)

3490604.825 USR

East (E)

2280576.234 USR

Elevation

5678.091 USR

Distance

128.925 USR

Other info

Coordinate file

volume.pdf

>

Auto survey

No

Survey method

Quick

Survey time

2023-09-03 19:54:46

Save

GNSS Surveyed point

Normal	Quality	Attributes	Multimedia
Solution	Fix		
Observer count	1		
Tracked satellites (2S)	GPS 8 GLONASS 6 BDS 7 GALILEO 5		
Used satellites (2S)	GPS 7 GLONASS 6 BDS 7 GALILEO 5		
H precision	0.045 USM		
V precision	0.063 USM		
HDOP	0.571		
VDOP	0.850		
PDOP	1.024		
GDOP	1.736		
RMS error	0.053 USM		
X error	0.032 USM		
Y error	0.032 USM		
Elevation mask	10.000		
Worst correction age	1.000		
Best correction age	1.000		
Save			

Additional Quality properties for a GNSS point

It is possible to assign GIS Fields, **Attributes** and assign **Values** in the field based on the point's **Code**:

Normal	Quality	Attributes	Multimedia
[Associated info FH]			
TagNumber	H-65121.2018		
Color	Red		
NumPorts	2		
Port1Size	4		
Port2Size	4		
Port3Size			
From previous From point			
Save			

See [Building GIS Datasets in LandStar] on Page 219 for information on **GIS Point Attributes**.

Multimedia (Pictures, Video and Sound Recording) can also be attached to any point:

Normal	Quality	Attributes	Multimedia
Picture Take Select			
11_20230904181333.jpg			
Video Capture Select			
Audio Record Select			
Save			

Click the Multimedia settings button and check all the photo description checkboxes:

	Point name
	Point Lat/Lon
	Point N/E
	Point time

to automatically label photos with the Name, Latitude (B), Longitude (L), Northing (N), Easting (E) and timestamp information:



Details: Project (tab) > Point list > Points to stake (tab)

The right-hand tab of the **Point list** holds a 2nd list of points: **Points to stake**. These points might be selected points from

the left-hand **Point list**. They might be **Imported** from a separate file, or they might be snapped from line work in

CAD.







Once an important list has been generated, [Export](#) it for future use. The Export function:



Allows filtering exported points by measurement [Time](#), [Name](#), [Code](#) and [Description](#).

Drag an entry to the right:




Then click on the  Stakeout button, to directly enter the [Stake point](#) routine. Once the point is stored, or the  [Auto returned](#)  [Next](#) / [Last](#) button is pressed, the point will be marked as Staked in the [Stakeout count](#)

column:

Stakeout count	Code	Stakeout count
5824.316	CE	Stakeout times: 0
5771.399	CE	Stakeout times: 0

Then the next un-staked point in the [Points to stake](#) list will be targeted.

The  [3-dot](#) button in the upper right corner accesses these settings:



Coordinate type

Changes between Coordinate display types for the displayed values. See [[Entering / Viewing Geographic and Projected Coordinates](#)] on Page 15 for additional information.

Multi-select

Allows multiple points or all points to be selected and subsequently deleted. Also allows drag-over-past selection of multiple items.

Sort

Allows reordering of the [Points to stake](#) entries:



Highlight one or more lines, then use the [Up](#) and [Down](#) button to change the staking order. Click on the [Back](#) button to exit [Sort](#).

Switch list style

Toggle between one row per point and one paragraph per point displays:

Point * Enter a search term

	Name	Point # (NAD 83)	Dist. (m)
▶	18	3496450.520	2270024.521
▶	17	3496394.303	2270178.291
▶	16	3496293.067	2270095.578
▶	15	3491731.146	2270001.792
▶	14	3491791.490	2270860.873
▶	13	3491833.300	2270348.117
▶	12	3491650.528	2275615.525
▶	11	3490114.066	2279477.280

Line list style

Point * Enter a search term

▶	18	Stakeout Item: 0
N	3496450.520	Code: CS
E	2270024.521	Description:
Dist	1824.216	T: 2023-09-30 16:22:33
▶	17	Stakeout Item: 0
N	3496394.303	Code: CS
E	2270178.291	Description:
Dist	1771.398	T: 2023-09-30 16:22:33
▶	16	Stakeout Item: 0
N	3496293.067	Code: QW
E	2270095.578	Description:
Dist	8856.242	T: 2023-09-30 16:22:33

Paragraph list style

Reset stakeout state

Sets the Stakeout count back to 0 (zero), which makes the points eligible for stakeout again.

Details: Project (tab) > Codes

Codes are used to classify points and include a **Code Name**; **Type**: Point, Line; **Description**; **Display symbol, size**; **Layer**; **Line type, width, fill**, and **transparency**. **Codes** are intertwined with **Layers** and the entry of a new **Codes** can optionally generate a name-matching **Layer**.

Codes have specific drawing attributes or inherit the attributes from their associated **Layer**.


Codes can be organized into multiple **Groups** (Categories).


Tools are available to import, save and share the **Code list**. The Quick code button assignments are also stored with the Code list: see [Quick code panel] on Page 97 for information about the **Quick code panel**; see [Sharing CODES and Quick Code buttons assignments] on Page 97 for information on sharing code lists with the Quick code panel assignments.

To manage the available **Code list**, from the **Project tab** click on **Codes**:



An empty Code list will be shown:



From this menu it is possible to delete codes, edit codes, create new codes. The  button on the upper right corner allows

Importing Code libraries.

Loading code libraries from text files, Carlson FCL files, Trimble FXL files.

Saving Code libraries for reuse in other projects.



Sharing Code libraries by email, Google Drive or other sharing methods with other users.


When **Importing** or **Saving** code libraries, the **Quick code panel** layout is included in the library file.

Edit or Delete an existing code


Click on or slide-right an existing Code row:




Item options to  Delete or  Edit the Code will appear on the left of the row:



Click  Delete, then confirm:




to delete a single Code.

Click  Edit to change the properties of a Code.

Create a New Code

Click the **New** button to create a new **Code**. A matching Layer can be built with the new code:



New Code with new Layer

Or a new Code can be created without a matching Layer, possibly referencing an existing layer:



New Code without Layer

Enter a unique **Name** for the new Code.


Drawing type can be **Point** or **Line**.

The **Description** is a text prompt for the Code.

The **Symbol** can be selected by clicking on the **Symbol box** then choosing from one of the 100's of included symbols,

or imported from a .dxf file. The **Symbol size** ranges from 1 to 9.

if Color by layer is enabled, then the symbol color is inherited from the Layer. Otherwise, the symbol color can be chosen from a color wheel.

If  **Create a layer with the same name** is checked then the **Line type**, **Line width**, **Fill color** and **Transparency** can be entered and a new **Layer** with the following properties and the same name as the **Code** will be created:

There are several possible **Line types**: **Continuous**, **Dashed**, **Dot**, **Center**, **Arrow_Continuous**. Possible **Line width**: **Normal**, **Thin**, **bold**.

The **Fill color** and **Transparency** is for closed polygons built with **Line** attributes.

GIS Attributes allow features (like a serial number, diameter, invert) to be recorded and associated with objects when acquired. See [Building GIS Datasets in LandStar] on Page 219 for detailed additional information.

Code library functions


Click the  button on the upper right corner:



Import from code library will import an existing LandStar code library.

Load from file imports a **Code list** from a custom .csv file, a Carlson FCL (.fcl) file or a Trimble FXL (.fxl) code list.

The custom file can include any of these field types, in the listed order:



Save code library saves the current Code library to a named file.

To cloud pushes a copy of the current Code library to the CHCNav cloud.

Share sends a copy of the current Code library to any of the device sharing options, for example as an attachment to email.

Details: Project (tab) > Layers > Work layers, Map files, Online map

The **Layers** menu has three tab sections:

Work layers associated with objects: points, lines, polylines, ...

Map files: DXF, DWG, SHP, KML, KMZ, TIFF, MBTiles, JMTiles, WFSDB, JPG

Online Maps: Google satellite, Bing satellite, OSM and others

The **Online Maps** selection allows downloading map tiles covering the entire project area for offline use. Downloaded maps are added to the **Map files** tab and the transparency can be adjusted to make the image more compatible with overlaying survey plotting.

You can also reach the **Layers** menu from:

Project > Layers

Software settings > Display settings > Layers



side-bar button optionally available in many survey screens

Available from the **Project (tab) > Projects** button:



Work layers (tab)



This tab allows you to edit the properties of all the layers associated with features.

button allows you to select multiple layers for deletion.

click to toggle the layer visibility (show/hide)


Click on the symbol to slide the layer to the right allowing deletion and editing:



It may be safer to just click on the line which only displays the edit tool:



Then click on the pencil to edit the properties of the selected layer.



These **Layer** properties can be modified:

Name: the name of the layer.

Layer color: the color of the layer.

Line width: Normal, thin, and bold are available.

Fill color: if a closed shape (polygon) is defined on the layer, it will be filled with this color.

Transparency: change the opacity of the polygon fill to allow other elements to be seen.

Line type: select a simple line style: continuous, dashed, dotted, center line-dot, line with arrows.


Map files (tab)


Use the **Map files** tab to attach both vector drawings and raster images from several sources to a project:

DXF/DWG	CAD drawings
SHP	shapefiles
KML/KMZ	Google line and point files
TIFF	GeoTIFF raster images
MBTILES	Mapbox tile sets often exported by QGIS
JMTILES	Map cache tiles downloaded from online sources.
WFSDDB	Downloading WFS maps generates WFSDDB tiles.
JPG	JPG image files with JGW world file.
INS	polylines

Once a map file is attached to your project, it is possible to change the opacity of the image. Click on a **Map file**, slide it to the right:





Click on the transparency button  to set the layer transparency:




then click OK.

Click on the  button to view the layer:



75% transparent




0 % transparent

Online map (tab)

The **Online map** tab allows control of the live online map backgrounds available from several sources. Selecting a source will automatically download map tiles as needed to create background coverage for your visible area and zoom level.

Once downloaded, the map tiles are kept with the project forever.

From this menu, it is simple to download background maps onto your device to eliminate the need for internet data while surveying.



Click on a map source, then slide it to the right:



then click on the **download** button 




Adjust the map coverage, then click [Download](#).



Select a reasonable [layer name](#), [Min level](#) and [Max level](#). Click [OK](#) to begin downloading tiles. Converted tiles are stored in the JMTiles format.



Wait for the download to complete. Before you leave the [Online map](#) tab, uncheck the downloaded map layer:



The Online map is displayed on top of the downloaded map and will occlude any transparency settings you make. The downloaded map will now be listed on the Map files tab:



Details: Project (tab) > Import

[Import](#) data in a variety of formats (Text, DXF, DWG, SHP, KML, KMZ, TIFF, MBTILES (Global Mapper), Jmtitles (CHCNav), WFSDB (CHCNav), JPG, INS) to the [Entered Point list](#), [Control point list](#), [Points to stake list](#) and the [CAD view](#).

The Text file importer allows the generation of custom file formats containing: Name, Code, Northing, Easting, (orthometric) Elevation, Longitude, Latitude, (ellipsoid) Height, Description, and skipped items. The text file importer understands: .CSV, .TXT, .DAT, .XLS and .XLSX file formats with comma, semicolon, space and multi-space delimiters.

The format 'USA: P,N,E,Z,D' is the correct format for 99% of applications in the USA.

Available from the [Project](#) (tab) > [Projects](#) tab:



There are two tabs: [Text file](#) and [Other formats](#). Choose [Other formats](#) for .DXF/.DWG, .SHP, .KML/.KMZ, .TIFF, MBTiles, Jmtitles, WFSDB, JPG and .INS files.

The most common file type is .TXT with the format:

PointName, Northing, Easting, Elevation, Code, Description

It is possible to build import file profiles for any text file.



First choose the [Point type](#) to import. [Entered points](#) are design points, [Control points](#) are typically site control points

and **Points to stake** are placed in the **Points to stake** list as staking targets:



There are several default **Format** types:



Or you can use **Add format** to define custom profiles.

Default file **Extensions** include:



Clicking on **Add format** presents a list builder:



The **Selected** column defines the expected fields and order. If you attempt to import points with **Point names** that already exist, LandStar will prompt with replacement **Point names** or you can choose to **Override** (replace) the existing points:




Details: Project (tab) > Export

Export data writes output files in text or standard formats in a variety of styles. The formats 'USA FULL: P,N,E,Z,C,D' or 'USA: P,N,E,Z,D' are the correct format for 99% of applications in the USA.

Available from the **Project** (tab) > **Projects** tab:



Use the  **Format** button to choose or define (see the **Import** function above) an export **Format** and filetype.

It is possible to choose the types of points to export:

- Survey** surveyed measurements.
- Enter** entered, imported and COGO result points.
- Control** entered or measured Control points.
- Base** Base points that were used during the project.

Filter - Measurement time allows a sub-set of points by acquisition date to be exported. For example, only points measured **Today** can be selected for output.


 A screenshot of a mobile application screen titled 'volume-Export'. At the top, there are two tabs: 'Text file' (selected) and 'Other formats'. Below the tabs is a 'Format' section with a dropdown menu showing 'USA FULL: PNAME.ZCD (*.shx)' and a right-pointing arrow. Underneath is a 'Filter Type' section with four checkboxes: 'Survey' (checked), 'Enter' (unchecked), 'Control' (unchecked), and 'Base' (unchecked). Below that is a 'Filter Measurement time' section with three buttons: 'Today' (selected), '1 Week', and 'All'. There are also 'Start date' and 'End date' input fields. Further down is a 'Filter Keyword' section with a toggle switch that is currently turned off. Below that is an 'Export GNSS info' section with a toggle switch that is also turned off. At the bottom of the screen is a large orange button labeled 'Next'.

Enabling **Filter - Keyword**:

 A screenshot of the 'Filter Keyword' section of the application. The toggle switch at the top is now turned on (orange). Below the toggle are four text input fields labeled 'Name', 'Code', 'Description', and 'GNSS Base'. The 'GNSS Base' field has a dropdown arrow on its right side.

allows selection by matching **Name**, **Code**, **Description** or just the points measured with a particular **Base**. Setting a few characters for **Name** will match any **Name** that starts with the entered characters. For example: **Name** = 'P' will match P12, P101, P240, and Pnt100.


Click [Next](#) to choose a directory location to place, and a [Name](#) for the exported file:



Enabling [Share](#):



will prompt for an Operating System share method:



which allows sharing by email, text messages, Google Drive and other supported methods.

[OS Sharing](#) is controlled by the [Share method](#) setting, see [[Share method](#)] on Page 28 for additional information.

Other formats Export

LandStar directly exports projects to these additional formats:

DXF	CAD Drawing Exchange Files
DWG	CAD Drawing files
SHP	GIS Shape file
KML	Keyhole Markup Language: exports projects directly into Google Maps
KMZ	Compressed KML, useful for embedding pictures with point and line objects.

Detailed result	CSV text formatted file containing detailed measurement point information with all attributes like coordinates, estimated errors, GNSS related information.
Survey report (HTML)	HTML formatted file containing detailed measurement point information with all attributes like coordinates, estimated errors, GNSS related information.
Point stakeout result	Includes target points, measured points, and stakeout errors.
Attribute data	CSV text formatted report containing measured points, line coordinates, and user-defined GIS attributes.
Attributes data (Excel)	Attribute data report in Excel format.
Pipeline survey report	Pipeline survey report, including the location and burial depth of the pipeline.
Hydro survey report	Hydro survey report, including measurement coordinates and water depth.
Polish	Cadastral survey reports used in Poland.
RAW	A GPS measurement data exchange file format used in Turkey.
MosGoGeo-Raw	A GPS measurement data exchange file format used in Russia.
Measurement report	Point survey report for averaged points
Area report	Area survey report, includes both a PDF file and a DXF file.
Verified survey report	Lists Verified points with all measurement group's tabulated data.
Star*Net report (.dat)	.DAT style StarNet import data file.
Star*Net report (.GPS)	.GPS style StarNet data file.
Trimble JXL (.jxl)	Trimble style XML data file with GNSS vectors for importing into TBC.

If exporting StarNet or .JXL files, it is best to enable **Record GNSS Vector** under **Settings > Survey**:



Details: Project (tab) > Surfaces

Surfaces can be used in Volume calculations and staked for Cut/Fill. The **Surfaces manager** allows direct import from CASS triangulation files, HC triangulations files, 3D DXF (.dxf) files and LandXML (.xml) files or surfaces can be created from a single point or a list of points that define a surface. Breaklines and boundaries are also supported for developed surfaces. The Surface manager allows granular control of the triangle networks used to approximate a surface.

Once a surface is defined or imported, use the Survey: **Stake surface** tool to stake them. See [Details: Survey (tab): Surface stakeout] on Page 137 for more information.

The Surface manger is launched from:



If no surfaces have been defined yet, the manager list will be empty:




Click [Open](#) to import an existing surface file:




[CASS triangulation files](#) are generated by the South Surveying CASS tool. [HC triangulation files](#) (.hctx) are LandStar exported surfaces. [3D DXF](#) are standard .dxf files with 3D points from which surfaces are built, [LandXML](#) are .xml files with developed surfaces.

Click [New](#) to generate a new surface from points available in the Points list:



By default, generated triangles are optimized. You can change this behavior by clicking the  3-Dot button on the upper right, then [Disable triangle-optimization](#):



Leaving it enabled is reasonable for most point sets.

Give the new surface a descriptive [Name](#). Points can be selected by:



[Selecting from the Point list](#) by checkbox, selecting from the [CAD view](#) map, or by specifying a [Range points](#):




If you specify a range of points, you must enter `<space><hyphen><space>` as the name separator. LandStar names can include the hyphen (minus-sign) character.

[Breaklines](#) can be specified by selecting existing lines from the [CAD view](#). [Boundaries](#) can be selected by choosing existing boundaries from the [CAD view](#). Typically, both will be left unspecified.

[Surface style](#) can be [Wireframe](#) (default) or [Shade](#). The surface color can be manually specified or automatically defaulted to the layer color for the first point.

Click **OK** to compute a triangular network from the included points, breaklines and boundaries:



The buttons in the Tool tray on the left allow editing of the developed surface:



2D, 3D or Map view. 3D allows tilting and spinning the surface.




Zoom to view the extents of the surface.



Automatically filter the points used in the network by side length ratio and internal angle ratio:

The **Minimum angle** and **Longest/shortest** ratio settings may change the resulting triangles.



Longest/shortest=10

Longest/shortest=20

The difference between automatic and manually optimized surfaces typically is very small.




Manually add a triangle between two points:



Manually delete a triangle.




Flip the triangle direction:




Manually add new triangles.



Switch from **Wireframe** to **Shaded** and choose the **Surface color**:








Toggle the Point name and Point elevation on and off:



Once a surface has been defined in the [Surface manager](#), drag the entry to the right:



to  Delete,  Share to CHCCloud,  Share to Gmail, Messages ...,  Change Wireframe/Shading options or  View.


Details: Survey (tab) > Map Survey

Available from the [Survey](#), [Map survey](#) button:



[Map Survey](#) provides point and line survey with an optional background map.




By utilizing the [Quick access](#) tool button  it is possible to perform nearly every survey and stakeout function from this single Map Survey screen.

Back

Clicking on the [Back](#) button  returns to the [Main Survey](#) menu.


Status

The top Status line:



Is described here: [[Instrument Select & Status information](#)] on Page 49.


Point Names

Points are collected and organized by [Point Name](#). The [Point Name](#) box:  holds the name for the next point that will be stored next. The Name automatically increments by the [Auto increment name interval](#) which can be found under [Settings: Survey \(tab\) | Store](#).


Some users prefer to use numeric names only: 1001, 1002, 1003. Some users prefer to use names like WTR1, WTR2, WTR3. Any format is fine. Names can include numbers, letters, and many symbols other than the space character.

Since it is possible to enter distances, azimuths and bearings using [Point Name Math](#): "1001,1002/3" (one third the distance from point 1001 to 1002) it may be simpler to keep Names simple.

Antenna Height


Clicking  opens the Antenna height menu:




You can enter alternate units, if your range pole is 2 meters and your project units are iFeet or USFeet, enter “2M” which will convert to “6.562 USft”. You may need to click the  button to switch from a numeric only keyboard to an alpha-numeric keyboard.

The Antenna height menu keeps the 10 most-recently-used antenna heights so that you can quickly switch between standard heights.

Point Code

Clicking in the **Code** area  allows you to use a keyboard to enter a point **Code**. Codes can include numbers, letters, spaces and these symbols “@#\$_&-+”; other symbols are not allowed. As you type a **Code**, matching **Codes** will be displayed in a picklist.

Clicking the down arrow  displays a list of known values from the current **Code list**.

You can use the question mark “?” to separate a **Code** and **Description**. For example, entering:



“RBC?Found rebar with cap”

results in a point with **Code** = “RBC” and a **Description** = “Found rebar with cap”.

If you enter a new Code, it will be added to the current Code list. Optionally you can automatically add a matching CAD Layer.

The complete project Code list can be maintained from the **Main Project: Codes** menu.

Point / Line

Click on  or  to toggle between storing a point or a line. Once points (vertices) are stored into a line feature the **Line Control** panel will be shown on the map screen:



Switch to the **Drawing manager** to switch between active lines.



Close the current line to make a closed polygon.



Break the current line, the next stored point will be on a new line.




Delete the last Point or Line segment.

If you are collecting one line or points, you can also switch to another existing line by clicking it on the Map.

Quick code panel

To enable the **Quick code panel**, click on  then **Code** and enable **Use quick codes**:




You can also set the number of **Quick code pages** which hold 9-codes per page. Click the **back** button to return to the survey screen.

Below the **Point Code** box, there is an expandable **Quick Code panel** area. Click, hold and drag the slider down:




to reveal the **Quick code panel**:




You can swipe the panel left and right to access multiple pages of codes. Click and hold on a button to change or delete the associated **Code**.

When you click on a **Quick code button** the code is applied, a measurement is immediately made using the currently selected method (Topographic, Quick or Corner). If **Confirm before saving** is enabled the measurement confirmation screen will be shown. The point number is automatically incremented after a **Quick code** measurement, leaving the controller ready to take another measurement.

Sharing CODES and Quick Code buttons assignments

From the Project: Codes function, click the  **3-dot** button (three dots upper right corner) and **Share**. This makes a .XML file and the file holds all of the current code library AND the **Quick Code** assignments. The share button also links to all of the system sharing options (like GMAIL or MESSAGES).

On the receiving end, you can use the same  **3-dot** button and **Import from Code Library** or you can manually pick the shared file when you make a new job.

The Code Library contains the **Quick Code assignments** in addition to the **CODES**.

Survey mode

Three **Survey modes** are selectable using the **Survey mode** button:



Topographic, usually a 5-second average



Quick survey, a 1-epoch measurement



Corner survey, only available for receivers with an e-bubble (i80,iG8,i50)

There are two additional dedicated survey types available from the main **Survey** menu:

Control survey useful for measuring important control points. Utilizes multiple dumps with multiple averages. Will abort if predetermined tolerances are not met.

Verified survey useful for measuring verified results in heavy canopy where bad fixes are expected. Uses multiple dumps, multiple averages, potentially spread over multiple occupations. Post-measurement control of used measurement averages with variable tolerances.

Start measurement

Click the **Start measurement** button to take a measurement as determined by the **Survey mode**.



Start measurement

At the end of the measurement, if **Confirm before saving is enabled** a screen that confirms and allows additional attributes to be entered will be shown.


Information panel

At the bottom of the map screen there is a small semi-circle with an up facing arrow:



Click and drag up on this panel to show the **Information panel**:



You can click on the small corner triangles  to choose the value shown in each panel. The available values are:



If you need additional map space, click on the **down arrow**:


to collapse the information panel.

Offset survey (hidden point survey)




Available in [Map Survey](#) and [Point survey](#). Allows the measurement of a location that cannot be directly occupied.

These 5 methods allow measuring a hidden point by occupying one or two points, with a variety of offset and direction methods:



Each method is described below.

Most of the offset methods allow you to take a temporary reference point. Clicking the  [GNSS acquire](#) button will display the [GNSS measure](#) dialog:



which allows you to choose an [Averaging period](#) and an [Antenna height](#), while showing the current [GNSS status](#) (FIX, Float, DGPS, Autonomous) and horizontal and vertical estimated measurement error.

Offset Distances can be manually entered or measured with a rangefinder .

[Elevations](#) of offset points can be entered by:

- [direct entry](#) of the target point elevation “5602.352”.
- [delta elevation](#) from the reference point “-2.342” at the target point.
- [Vertical angle](#) applied from the reference point towards the target point.
- [Zenith angle](#) applied from the reference point towards the target point.
- [Slope 1:N](#) (ratio) applied from the reference point.
- [Slope %](#) applied from the reference point.

Point survey: Distance + Azimuth



Measure a hidden point which is a known distance and known azimuth/bearing from the measured point.

Pick a **Reference point** by:



pick an existing point or object (with snap) from the **CAD view**.




take a GNSS measurement.



choose an existing point from the **Point list**.

Then specify:

Horizontal distance optionally use a laser  rangefinder.

Elevation by **direct entry**, **delta elevation** from the reference point, **Vertical angle**: applied from the reference point, **Zenith angle** from the reference point, or **Slope** (1:N or %) applied from the reference point.

Bearing/Azimuth the direction to offset.

After specifying the offset parameters, click on **Result**. A new point dialog with the next available point number selected as the **Name** will be displayed, click **Save** to accept the point and add it to the **Point list**.

Click **Result** to reach the new point dialog with the computed offset location:

Name

Code

North (N)

East (E)

Elevation

Desc

Save

The next available **Point Name** will automatically be assigned. Optionally, select a **Code** and enter a **Description**, finally press **Save** to add the computed offset point into the project **Point list**.

Point survey: Alignment Offset

Method
 Alignment offset

Start point
 North (N)
 East (E)
 Elevation

End point
 North (N)
 East (E)
 Elevation

Distance
 Reference
☒ Start point ☐ End point
 Horizontal distance
 Elevation
 0.000 USft

Offset
☒ Left ☐ Right
 Horizontal distance

Result

The **Alignment offset** method allows you to specify a line between two points. The **Reference point** determines which end of the line chainage starts at and can be either the **Start point** or the **End point** of the line. An offset right or offset left with a specified or offset elevation is then applied. (See the Turned angle distance for an arbitrary offset angle.)

You can use these methods to specify the **Start** and **End points**.



pick an existing point or object (with snap) from the **CAD view**.



take a GNSS measurement.



choose an existing point from the **Point list**.

Then specify:

Horizontal station: this is the distance from the Start point or End point along the line to an intermediate station.

(Optionally use a laser  rangefinder to set this distance.)

Elevation by **direct entry**, **delta elevation** from the reference point, **Vertical angle:** applied from the reference point, **Zenith angle** from the reference point, or **Slope** (1:N or %) applied from the reference point.

Offset **Left** or **Right**

Horizontal distance the distance to offset left or right.

After specifying the offset parameters, click on **Result**. A new point dialog with the next available point number selected as the **Name** will be displayed, click **Save** to accept the point and add it to the **Point list**.

*Note: the **Start** and **End points** do not need to be named points or in the **Point list**. They can be temporary measured points, as needed.*



Start point: 1001

End point: 1002

Horizontal Station: 247.77'

Offset Right

Offset distance: 69.16'

New **Point name:** 3

New **Point description:** Offset Point

Click [Result](#) to reach the new point dialog with the computed offset location:

Name
1

Code
[empty] [arrow]

North (N)
3490695.275 USft

East (E)
2280607.272 USft

Elevation
5670.860 USft

Desc
2do [gear]

Save

The next available [Point Name](#) will automatically be assigned. Optionally, select a [Code](#) and enter a [Description](#), finally press [Save](#) to add the computed offset point into the project [Point list](#).

Point survey: Distance-Distance Intersection

← t5-Offset survey

Method
Distance-distance intersection [dropdown]

Ref point 1 [plus] [minus] [list]

North (N)
[empty]

East (E)
[empty]

Elevation
[empty]

Distance
Horizontal distance [empty] [arrow]

Δ Elevation
0.000 USft [dropdown]

Ref point 2 [plus] [minus] [list]

North (N)
[empty]

East (E)
[empty]

Elevation
[empty]

Distance
Horizontal distance [empty] [arrow]

Δ Elevation
0.000 USft [dropdown]

Result

Distance-distance intersection allows the user to select two points, with a distance from each, to specify a 3rd hidden point.

You can use these methods to specify [Reference point 1](#) and [2](#):



pick an existing point or object (with snap) from the [CAD view](#).




take a GNSS measurement.



choose an existing point from the [Point list](#).

Note: [Reference points](#) do not need to be named points nor be in the [Point list](#). They can be temporary measured points.

Each Reference point has an offset (typically a hand-taped) [Horizontal distance](#). You can optionally use a laser  rangefinder to measure the [Horizontal distance](#) for each position.

The [Elevation](#) can be selected: by [direct entry](#), [delta elevation](#) from the reference point, [Vertical angle](#): applied from the reference point, [Zenith angle](#) from the reference point, or [Slope](#) (1:N or %) applied from the reference point.

Two projected elevations are derived, one from each [Reference point](#). The average of the two derived elevations will be used for the stored point.

Click [Result](#) to reach the new point dialog with the computed offset location:



The next available [Point Name](#) will automatically be assigned. Optionally, select a [Code](#) and enter a [Description](#), finally press [Save](#) to add the computed intersection point into the project [Point list](#).

Press the [Result](#) button to complete the intersection computation, a prevue of the two possible solutions will be shown:



click one of the Target points to select, the selected intersection will be highlighted red.

Click the  Green OK button.



Name
1

Code

North (N)
3490695.275 USft

East (E)
2280607.272 USft

Elevation
5670.860 USft

Desc
2do

Save

The next available **Point Name** will automatically be assigned. Optionally, select a **Code** and enter a **Description**, finally press **Save** to add the computed intersection point into the project **Point list**.

Point Survey: Turned angle + distance (with skew)

This hidden point procedure allows you to offset a new point, at a distance and azimuth/bearing from a measured point.



Method
Turned angle + Distance

Start point

North (N)

East (E)

Elevation

End point

North (N)

East (E)

Elevation

Offset

Reference
☒ Start point ☐ End point
☒ Left ☐ Right
Ahead 000:00:00.00000
(M) 000000000

Offset distance

ΔElevation
0.000 USft

Result

You can use these methods to specify the **Start** and **End points** of the alignment line:



pick an existing point or object (with snap) from the [CAD view](#).



take a GNSS measurement.



choose an existing point from the [Point list](#).

Note: these do not need to be named points nor be in the [Point list](#). They can be temporary, measured points.

Choose which end of the line ([Start Point](#) or [End Point](#)) to offset from.

The [Offset direction](#) can be [Left](#) or [Right](#) of the line, with respect to the direction ([Start](#) to [End](#)) of the line.


The offset angle can either be [Perpendicular](#) (90 degrees) or [Ahead](#) or [Behind](#) at a skew angle:



[Perpendicular](#) is equivalent to a 90 degree [Ahead](#) or [Behind](#) angle:



The skew angle is with respect to the direction of the line.

[Offset distance](#) is the distance from the endpoint. You can optionally use a laser  rangefinder to measure the [Offset distance](#).

The [Elevation](#) can be selected: by [direct entry](#), [delta elevation](#) from the reference point, [Vertical angle](#): applied from the reference point, [Zenith angle](#) from the reference point, or [Slope](#) (1:N or %) applied from the reference point.

Click [Result](#) to enter the new point dialog with the computed offset coordinates:

Name	1
Code	>
North (N)	3490695.275 USft
East (E)	2280667.272 USft
Elevation	5670.860 USft
Desc	2do
Save	

The next available [Point Name](#) will automatically be assigned. Optionally, select a [Code](#) and enter a [Description](#), finally press [Save](#) to add the computed offset point into the project [Point list](#).

Point survey: $\Delta X + \Delta Y + \Delta Z$

Store a hidden point by picking a Reference point, then offset from the point (in the projected coordinate system space) by fixed values.

You can use these methods to specify the [Reference point](#):



pick an existing point or object (with snap) from the [CAD view](#).




take a GNSS measurement.



choose an existing point from the [Point list](#).

Note: [Reference points](#) do not need to be named points nor be in the [Point list](#). They can be temporary measured points.

The X and Y offset (typically a hand-taped) [Horizontal distance](#) is manually entered. You can optionally use a laser  rangefinder to measure the X and Y distances.


The [Elevation](#) can be selected: by [direct entry](#), [delta elevation](#) from the reference point, [Vertical angle](#): applied from the reference point, [Zenith angle](#) from the reference point, or [Slope](#) (1:N or %) applied from the reference point.

Click results to reach the new point dialog.

The next available **Point Name** will automatically be assigned. Optionally, select a **Code** and enter a **Description**, finally press **Save** to add the computed offset point into the project **Point list**.

Details: Survey (tab) > Point (text) Survey


Available from the **Survey** (tab) > **Point survey** button:



The **Point survey** function is very similar to the **Map Survey** function (see [Details: Survey (tab) > Map Survey] on Page 95). However, **Point survey** has no background map:



Tools available for use with the **Point survey** - **Tool bar** are:



The **Map Survey Tool** can be **Selected** to quickly switch to the **Point Survey** (with background map) function.

Details: Survey (tab): Visual survey

Available from the **Survey** (tab) > **Visual survey** button:



This survey tool will capture 2 to 4 cm accurate N, E, Z positions for features that can be seen, but not physically occupied. A series of pictures are recorded, processed and then any number of features can be extracted. The processing and feature

extraction can be completed in the field or performed later. The vision tasks can be queried for features as needed even after the fieldwork has been completed.


Features further than 15 meters can be captured, however accuracy is best if the distance from the receiver camera to the object is less than 15-meters. The path of photo taking greatly contributes to the accuracy of the results. If features can be seen in oblique photos, just like an optical survey resection, the results will have a stronger solution.

A vision enabled receiver like the i93 is required to use [Visual survey](#).

Click the [Visual survey](#)  button from the main [Survey](#) menu to get started.



 or [Back](#) returns to the [Main Project Survey menu](#) tab.


The current GNSS receiver status is shown on the top receiver information bar . See [Status] on Page 95 for additional information about the Status bar.




shows the task name that the next [Visual survey](#) result set will be stored under. You can change the default name to better represent the feature.



The [Survey type](#) selects between [Visual Survey](#) which is processed on the data collector and [3D Modeling](#) which stores pictures in anticipation of processing in the cloud or in external software. Most users will use [Visual Survey](#).

It is important that the [Instrument height](#)  be entered correctly as an accurate IMU initialization is needed to stitch the acquired images together. See [Antenna Height] on Page 96.

Click the [Record](#) button , then a 3-second countdown will begin:



When the countdown completes, begin moving the receiver along the path that you want to record:




2-pictures per second are acquired. A minimum of 8 pictures are required to process a task. There is a 60-second maximum per task limit. A 5-second minimum recording time is enforced because the processing software may throw out pictures that are repeated or algorithmically determined to be defective. Features that you want to capture need to be common to at least 3 pictures, so it is best to start before the first feature you want to store and continue past the last feature of interest. There needs to be some high contrast features in each of the pictures, so images like sand on a beach won't normally process.


Hold the receiver pole upright while moving. If the tilt exceeds 30-degrees recording will terminate. Try not to catch the pole tip on the ground as you move, it will trip the receiver and recording will terminate. Try to move in a steady flow while acquiring pictures.




At the completion of acquisition, click the **Stop** recoding button. Visual survey will save the images to the new visual task, then ask:



Click **Later** if you want to process and select points from the images later, click **Now** to begin processing immediately. Processing will take 2 to 3 time the collection period depending on the speed of the field controller.



When image processing completes:



Click **Yes** to extract features now. If you click **No**, you can return to the Image list at any time to extract additional features.

The Measure dialog will be shown:




It is usually best to select the 3rd or higher image (on the top band), zoom into the image (by pinching), place the crosshairs on the feature you want to save:




Then click the [Select](#) button .



The coordinates, with the estimated horizontal error: [2D Q](#) will be shown. If the measurement is acceptable, click on [Save](#)  to add the measurement to the project [Point list](#):

Edit the [Name](#), optionally assign a [Code](#) and [Description](#), then click [OK](#).

Sometimes, you might pick a point to measure and receive a **Measure failed** message when you click the **Select** button:






When this happens, select another image that contains the same point. An orange line will indicate the plane of the point you are attempting to measure to assist in zooming in to the same spot on the new image. Click **Select** and the measure should be successfully captured. This procedure binds coordinates to the first image and makes additional locations on that image easier to capture.


All visual measurements will be shown on all the photos where they are visible:



Visual survey Images list




The  button on the Visual survey function is the same as clicking the  button from the main menu Project (tab) and displays the Images list. All the Project's **Visual survey** tasks are listed.

Click the **Delete** button  then check the tasks to delete to cleanup unneeded tasks.

You can reopen [Visual survey](#) tasks to measure additional points in them.

Tasks that have not been processed will be listed as [Unmeasurable](#). Click on the task, then click [Local Process](#)

 to prepare the task for point selection and make the task [Measurable](#).

Processing takes about two to three times as long as the recording time. A 15-second image task will take about 30 to 45-seconds to process.

Details: Survey (tab): Control survey

Available from the [Survey](#) (tab), [Control survey](#) button:



The [Control survey](#) tool automates acquiring multiple groups-of-averages, automatically resetting the GNSS engine between groups, and performing statistical combination of the measured epochs.


The intended use of the [Control survey](#) tool is to acquire very reliable coordinates under open canopy where the receiver is expected to **never** encounter a bad fix. The [Verified survey](#) is better suited for locations where bad fixes or the inability to fix may be encountered.

The [Control survey](#) function differs from the [Verified survey](#) function:


- [Control survey](#) is intended for use in open canopy where there will **never** be a 'bad FIX'.
- [Control survey](#) does not allow post collection group selection. If a bad-FIX is encountered, the entire control point must be recollected.
- [Verified survey](#) is intended for use in heavy-canopy where bad FIXs are expected.
- [Verified survey](#) will automatically pause if the constellation quality degrades or a bad-FIX is encountered. [Control survey](#) will stop and abort if the tolerance conditions are not met.

It is not possible to add additional measurement groups to a [Control survey](#), it is easy to add additional measurement groups to the Verified survey.

Control survey operation

Click the  button on the main survey menu:



When you first enter the [Control survey](#), first click the Options  button, the settings will be shown:



[Number of passing measurements](#) to acquire. Each group is separated by a GNSS engine reset and the [Wait after fixed](#) time.

Each group will include [Point per measurement group](#) points.

Each point will include [Number of epochs per point](#) epochs. (An average of averages is collected.)

Groups with a horizontal range greater than [Group horizontal range tolerance](#) will be remeasured automatically.

Groups with a vertical range greater than [Group vertical range tolerance](#) will not be remeasured automatically.

If the receiver reports a Hrms value higher than the [Epoch maximum Hrms](#), collection will wait for a lower Hrms.

If the receiver reports a Vrms value higher than the [Epoch maximum Vrms](#), collection will wait for a lower Vrms.


[Wait after fixed](#) is the time that collection waits after the receiver acquires a fixed solution after the receiver is reset.

[Max PDOP](#) is the maximum Position Dilution-of-Precision allowed before collection is paused.

Between each measurement group, the GNSS engine is reset. This forces the receiver to completely reacquire a new position. After the receiver reacquires satellite tracking, resolves ambiguities, receives corrections, and computes a FIXED solution, group collection waits an additional [Wait after fixed](#) time before starting to acquire epochs. This is intended to allow the receiver to further stabilize to a more accurate value.

[Percent of pass](#) is a confidence interval specification for the statistical reliability of the final result.

After configuring the [Control survey](#) specific settings, enter (or accept the default) [Point name](#) and [Code](#):



Double-check the [Instrument height](#):



The IMU is always disabled during a [Control survey](#).


At the bottom of the map screen there is a small semi-circle with an up facing arrow:




Click and drag up on this panel to show the [Information panel](#):



See [Information panel] on Page 98 for details on how to customize this panel.

Finally click the [Begin survey](#)  button to start acquiring measurement epochs. The [Control survey](#) will start following the rules established in settings. Information on the progress of the Control survey is updated continuously:



At the conclusion of the Control survey a detailed report on the measurements is saved to the job folder:

/storage/emulated/0/CHCNAV/LS7_Projects/_jobname_/Control report/pointname_yyyymmddhhmmss/

Two files are created. An .HTML report and a .CSV detailed result data file.

The completion dialog will be shown after the reports are saved:



Click [Open report](#) to view the report:



The report includes a list of every measurement with deviations from the final averaged coordinate in both projected (N,E,Z) and geographic (L,L,H) coordinates.

The final computed position is added to the [Point list](#) with a unique point icon:



Details: Survey (tab): Verified survey

Available from the [Survey](#) (tab), [Verified survey](#) button:



The **Verified survey** tool automates acquiring multiple groups-of-averages, automatically resetting the GNSS engine between groups, performing statistical and graphical analysis of the results to reject bad-FIX and average good-FIXED measurements.

The intended use of the **Verified survey** tool is to acquire very reliable coordinates under extremely heavy canopy where the receiver is **expected** to encounter many bad fixes.

The **Verified survey** function differs from the **Control survey** function:

Control survey is intended for use in open canopy where there will never be a 'bad FIX'.

Control survey does not allow post collection group selection. If a bad-FIX is encountered, the entire control point must be recollected.

Verified survey is intended for use in heavy canopy where many bad FIXs are expected.


Verified survey will automatically pause if the constellation quality degrades or a bad-FIX is encountered. **Control survey** will stop and abort if the tolerance conditions are not met.

Verified survey makes it easy to add additional groups later, perhaps over several days.


Verified survey allows inspection and post inclusion/rejection of groups.

Type	Group	H-Averaging	Vertical-Averaging	Horizontal-Averaging	Vertical-Averaging	Group	Group
2023-07-26 09:13:59	100	0.004	0.017	0.002	0.004	1.217	4.562
2023-07-26 09:06:51	100	0.008	0.021	0.005	0.006	1.566	4.562
2023-07-26 09:09:53	100	0.003	0.030	0.013	0.008	1.400	4.562
2023-07-26 09:12:50	100	0.004	0.023	0.007	0.040	1.690	4.562
2023-07-26 09:10:49	100	0.003	0.021	0.009	0.008	1.537	4.562

Verified survey generates real-time horizontal and vertical plots that show acquisition progress.



Plots are also available for post analysis of the included measurement groups.



Verified survey operation



Click the **verified survey** button on the main survey menu:



The **Verified survey** screen has a group summary area:

Group: 3/5	Points: 33/100
Hrms: 0.020 USft	Vrms: 0.038 USft
PDOP: 1.464	DIFF age: 1 Second
H σ: 0.007 USft	V σ: 0.015 USft
H Range: 0.044 USft	V Range: 0.090 USft
N: 3490669.303 USft	E: 2280607.555 USft
Elevation: 5668.664	

The drag bar at the bottom of the summary area can be moved up and down as needed to view the entire summary.

The **Group** shows **current group** / **initial number of groups**. The **current group** will be larger than the **initial number of groups** if you decide to collect additional measurements after the initial collection.

Points is the **current number of points** / **target point count**, for the current group.

Hrms Vrms are the current horizontal and vertical estimated errors reported by the receiver.

PDOP is the current Position Dilution-of-Precision reported by the receiver.

DIFF age is the correction latency (the number of seconds since a valid correction was received by the receiver) reported by the receiver. Typically, it will be less than 3-seconds.


H σ is the standard deviation of all the included horizontal epochs taken for the current point name.


V σ is the standard deviation of all the included vertical epochs taken for the current point name.

H Range is the horizontal range of included measurements taken for the current point name:



V Range is the vertical range of included measurements taken for the current point name:



When you first enter the [Verified survey](#), first click the  [Options](#) button, [Survey settings](#) will be shown:



Nominal [Number of measurement groups](#) to acquire. Each group is separated by a GNSS engine reset and the [Wait after fixed](#) time.

Each group will include [Point per measurement group](#) epochs.

If the receiver reports a Hrms value higher than the [Epoch maximum Hrms](#), collection will wait for a lower Hrms.

If the receiver reports a Vrms value higher than the [Epoch maximum Vrms](#), collection will wait for a lower Vrms.


[DIFF age](#) is the maximum correction latency allowed before collection is paused. Typically, GNSS measurements with higher differential age have lower accuracy.

Max PDOP is the maximum Position Dilution-of-Precision allowed before collection is paused.

Between each measurement group, the GNSS engine is reset. This forces the receiver to completely reacquire a new position. After the receiver reacquires satellite tracking, resolves ambiguities, receives corrections, and computes a FIXED solution, group collection waits an additional [Wait after fixed](#) time before starting to acquire epochs. This is intended to allow the receiver to further stabilize to a more accurate value.

Note: [Show E-Bubble](#): enables the E-Bubble on the display screen. This is only applicable to receivers with an [E-Bubble](#) or an [IMU](#) like the i50, i80, i70, i90, i93, i73, i83, iG8, iG9. The [E-bubble](#) is not related to the IMU which is forced inactive for [Verified survey](#).


After configuring the [Verified survey](#) specific settings, enter (or accept the default) [Point name](#) and [Code](#):




Double-check the [Instrument height](#):




The receiver IMU is always disabled for Verified survey, it is important to carefully level the receiver.

Finally click the  **Begin survey** button to start acquiring measurement epochs. The **Verified survey** will start following the rules established in settings:

Group: 3/5 Points: 33/100
 Hrms: 0.020 USft Vrms: 0.038 USft
 PDOP: 1.464 DIFF age: 1 Second
 H a: 0.007 USft V a: 0.015 USft
 H Range: 0.044 USft V Range: 0.090 USft
 N: 3490699.303 USft E: 2280607.555 USft
 Elevation: 5668.664...

Click the  button while points are collected to display scatter plots for the horizontal and vertical measurements:



At the conclusion of the last automatic group, click the Edit last point  button to display the results of the **Verified survey**:

Normal	Average	Attributes	Multimed
Survey info			
Name:	1007		
Code:	<input type="text"/>		
Type:	Verified survey point		
Format:	Grid (NEH)		
North (N):	3490699.303 USft		
East (E):	2280607.555 USft		
Elevation:	5668.667 USft		
Desc:	<input type="text"/>		
Survey time:	2023-07-28 10:17:30		
Save			

Select the 2nd tab **Average** to view the results of each collected group:



Drag the top section right and left to reveal the report columns for the measurement groups:


Time	Count	H	V	H Res	V Res	H Res	V Res	H Res	V Res
2023-07-28 09:02:58	100	0.004	0.017	0.002	0.004	1.227	8.582		
2023-07-28 09:06:01	100	0.004	0.021	0.007	0.009	1.886	8.562		
2023-07-28 09:09:01	100	0.003	0.030	0.011	0.004	1.433	8.062		
2023-07-28 09:12:58	100	0.004	0.029	0.007	0.040	1.699	8.560		
2023-07-28 09:15:48	100	0.002	0.021	0.006	0.004	1.127	8.562		

Enable and disable group contributions to the average by checking and unchecking the H and V . Use the **H Res** and **V Res** values to find bad FIXes and remove them from the final computed point.

Sort the groups by clicking on the sort icon at the top of each column.

The bottom portion of the Average tab has three panels.

Switch between the panels by swiping left and right:




These panels reflect only the included measurement groups, they automatically update as groups are included and excluded in the group table.


Adding additional measurement groups to a Verified survey

After a **Verified survey** operation successfully stores a result into the **Point list**, you can add additional measurement groups.

Reoccupy the mark, then return to the **Verified survey** screen and either type in the same **Point name** or click on an existing Verified survey point then click on **Begin**. LandStar will verify that you want to add to the existing point:



If you have already collected the **Number of measurement groups** specified in the **Verified survey** options but would like to automatically collect several additional observation groups, return to **Options** and set the **Number of measurement groups** to the new desired total.

When you click on  **Begin** automatic group collection will continue until the new desired number of groups has been reached.

Verified survey screen details



Back

Clicking on the **Back** button  returns to the **Main Survey** menu.

Status

See [Instrument status] on Page 49 for detailed information on the status and information screens.

Point Names


Verified survey points groups are collected and organized by **Point Name**. The **Point Name** box:  holds the name for the group that will be collected when the **Start measurement**  button is pressed.


Unlike other survey modes, the Name does not automatically increment, this facilitates collecting additional groups into an existing averaged point.

Antenna Height

Clicking  opens the Antenna height menu. See [Antenna Height] on Page 96 for additional information.

Point Code

Clicking in the **Code** area  allows you to use a keyboard to enter a point **Code**. Codes can include numbers, letters, spaces and these symbols “@#\$_&-+”; other symbols are not allowed. As you type a **Code**, matching **Codes** will be displayed in a picklist.

Clicking the down arrow  displays a list of known values from the current **Code list**.

You can use the question mark “?” to separate a **Code** and **Description**. For example, entering:

“RBC?Found rebar with cap”

results in a point with **Code** = “RBC” and a **Description** = “Found rebar with cap”.


If you enter a new Code, it will be added to the current Code list. Optionally you can automatically add a matching CAD Layer.


The complete project [Code list](#) can be maintained from the [Main Project: Codes](#) menu.


Real-time plot




While groups are being collected it is possible to display real-time result plots. These plots show all of the enabled measurement epochs. (You can disable groups in the Edit Point, Average tab.)

When showing the map screen, clicking the  button will switch to the combined horizontal and vertical scatter plots:



clicking the  button will switch to the vertical timeline plot:



then clicking the  will return to the point display map:



On these plots, the blue ellipse and background are 1-sigma, and the green ellipse and background are 2-sigma indicators.

Start / stop measurements

Click the [Start measurement](#) button to begin acquiring epochs for the next group.



[Begin measurements](#)

After measurements have started, the button changes to:



[Stop measurements](#)

Clicking [Stop measurements](#) aborts the current measurement group after a confirmation.

Information panel

See [Information panel] on Page 98 for additional information on the [Information panel](#):



Details: Survey (tab): Point Stakeout

'**Staking out** a point': using assisted navigation to move to a point's known coordinates so the location can be marked by a stake, flagging, paint, whiskers, or other monument. **Point stakeout** provides a horizontal position and the deviation (cut/fill) to a target elevation. After setting a monument, typically the 'set' location is stored as an 'as staked' position for verification.

Offset staking allows you to stake a point that is offset from the selected point. There are several methods to specify an offset in LandStar.


There are several ways to begin the stakeout process. From the **Survey** (tab), **Point stakeout** button:




Then manually click in the **Point to stake** box and select a point to stake. The **Stake point** menu has many of the same features and buttons as the **Point survey** menu.




Clicking on the **Back** button  returns to the **Main Survey** menu.

Clicking icons on the top receiver information bar  displays status information about the currently connected receiver. See [Status] on Page 95 for information on the receiver information bar links.

The **Point to stake** box  displays the **Name**, **Code** and **Description** of the point that is currently being staked. If the Name, Code and Description are too long to be shown in the box, click and hold inside the box to expand them:



Clicking on the  button displays the **Point list** or **Point to stake** list allowing an alternate target point selection.

Clicking  opens the **Antenna height** menu. See [Antenna Height] on Page 96 for details on entering and selecting the **Antenna height**.

The **Name** box displays the **Name** that will be assigned to the measurement that will be collected when the **Begin measurement** button is pressed. The default staked **Name** is controlled by **Settings: Stakeout** (tab): **Point name prefix**.

The **Code** box lists the **Code** that will be associated with the new measurement. Clicking displays the full **Code list**. Clicking the opens the keyboard and allows you to type in the first few characters of the desired **Code**. Clicking the button allows picking the code from the MRU (Most Recently Used) list.

The **Target Information panel** can be swiped left and right:



The left panel shows the distance forward/reverse and left/right based on the direction the Android device is facing. The right panel shows the North/South and East/West distance.

The **Staking control** buttons include:



Cancel stakeout operation.



North reference:



toggles the Navigation compass on and off:



The compass shows the current direction of travel, the target and a North reference.



Collapse the Staking control buttons.

A simple **Scale bar** is shown in the upper-right corner of the map.

The **Stake next**, **Auto-nearest**, and **Stake last** controls allow switching to the previous , next points from the Point list or Points to stake list. The **Auto nearest** toggle, when depressed, will automatically switch to continuously staking the nearest point to the current position.

The **Information panel** can be expanded to display real time coordinate information. See [Information panel] on Page 98 for details.

Storing the results of the Stakeout

Click on **Start measurement** button to measure a point at the current location.


The stored point will include the stakeout offsets and cut and fill value from design (Staked) point to the measured point.

Auto description for staked points

When you stake a point, the description of the new staked point can be automatically populated, or it can be left blank for the operator to manually fill out.

To control the [Auto description](#), go to [Software settings](#) > [GNSS](#) > [Stakeout](#) (tab) > [Auto description](#) >

Click on the > button:

Move the  slider to the right to enable [Automatic descriptions](#):


Item	On/Off	Prefix
Stake Pt Name	On	STK
Stake Pt Desc	On	
Station	On	STA
Distance	On	Dist
Offset Left	On	L
Offset Right	On	R
Cut	On	Cut
Fill	On	Fill


Stake Pt Name: STK Update

☒ On/Off


Up Down


Highlight an [Item](#) line, then use the  [Up](#) and  [Down](#) buttons to change the order of items.

Highlight an [Item](#) line, then use the entry box at the bottom to modify the [Prefix](#), click the  [Update](#) button to commit change.


The  [On/Off](#) [On/Off](#) checkbox enables / disables the highlighted item.


Visual Stakeout

If the current device is a visual receiver like the CHC i89 and i93, an AR (Augmented Reality) button  will be shown on the map screen. Click on this button to enter the AR mode.

Once activated the AR button will change color:  to indicate it is enabled.


Your data collector must be connected to the receiver by 5 GHz Wi-Fi (not Bluetooth or 2.4 GHz Wi-Fi) for the Visual survey and Stakeout functions to work.



In **Options**  on the **Stakeout** tab, under miscellaneous there are **Distance to switch to Visual Stakeout (Near)** and **Distance to switch to Visual Stakeout (Far)** settings. Setting the **Near** distance to 8 to 25 feet is reasonable. Setting the **Far** distance between 50 and 300 feet or more is reasonable. Your settings may depend on site terrain and personal preferences.

If you are further than the **Far** distance, LandStar will show the map screen with optional map backgrounds. If you are between the **Near** and **Far** distance, **LandStar** will show the front facing camera. Once you reach the Near distance from the stakeout point, the bottom facing camera will be shown. As you move closer to the point being staked, the view will automatically zoom in to better show the target point on the ground.

:



Map screen



Front Facing camera view



Bottom facing camera view


A virtual pole is overlaid on the image (usually on top of the data collector bracket and your hand) to assist visualizing where the pole point is. The number of blue arrows is proportional to the distance to the target.


The distance, cut fill along with the ΔX , ΔY or forward/left/right (depending on the panel settings on the map screen) are updated continuously:




When the pole tip is within the staking tolerance, a green target will be shown centered under the pole tip:



Click on  **Start measurement** button to measure a new point at the staked location.

Click on  **Close** (top right corner) to return to standard non-visual **Point stakeout**.

Click on the  **Back** button (top left corner) to return directly to the **Main menu**.

Additional methods to begin staking out a point

There are many other ways to initiate a point stakeout operation.

You can begin **Point stakeout** from the **Point list**.




Slide the point you want to stake to the right, then click the Stake button . The **Stakeout point** function begins immediately with the selected point as a target. **Next** and **Last** buttons will move through the list where stakeout was started.

You can build a **Points to stake** list:



The **Points to stake** list is on the right-hand tab of the **Point list**.

Points can be directly  **Import** and  **Exported** to the **Points to Stake list**.

Once staked, the stake icon  will disappear and the point won't be available for staking from this list.

This staked status can be reset using the  **Reset stakeout state** option at the top of the menu.

To import points, click  **Import**:



Points to stake: sets the destination for imported points.

Point type: where to import a file to (Points, Control points, Points to stake).

Format: normally choose the “USA FULL: PN,N,E,Z,C,D” format with .CSV extension, which includes the **Name**, **Code** and **Description** for each point. This format best matches the standard **Export** function.

Points to stake > **Export** file dialog:



Oftentimes the same points will need to be staked multiple times: pre grading, post grading, post compacting, post paving, post sealing. There may be a time savings by saving a **Points to stake** list using the **Export button** which allows future import.


You can specify the **Path** and **Filename** and file Suffix (extension).

The normal order for the USA matches the **USA FULL Import** format (above):

Name, North(N), East(E), Elevation, Code, Desc

Click the **Export** button to write the **Point to stake** list.

From the **CAD view** you can directly stakeout a point or object end, mid or intersection point:



From [CAD view](#), (1) click on a point/object to select it. Then (2) click on [Stakeout](#).

Offset Staking a Point

LandStar supplies several methods to offset-stake a point:



Distance + Azimuth: offset a distance in a specified grid direction.


Alignment Offset: offset at right angle (left or right) from a point, using a second point as alignment.


Turned angle + distance: offset at arbitrary angle (skew ahead, skew back), using a second point as alignment.

$\Delta X + \Delta Y + \Delta Z$: grid offsets from the reference point.

To begin [Point stakeout](#) with an offset, enter the [Point stakeout](#) menu.

If the  [Offset stakeout](#) tool is not available in the [Tool tray](#), click on [Setup](#) button , then on the [Tools](#) tab highlight and [Select](#) the [Offset stakeout](#) tool. Consider dragging it to the top of the tool tray if you plan to use it often. Click [Back](#) to return to the [Point stakeout](#) menu.

Click the  [Offset stakeout](#) button, then select the Method:



Distance + Azimuth

Alignment Offset

Turned angle + Distance

Delta X, Y, Z

Use one of these methods to specify the [Reference point](#):



pick an existing point or object (with snap) from the [CAD view](#).




take a GNSS measurement.



choose an existing point from the [Point list](#).

Note: [Reference points](#) do not need to be named points nor be in the [Point list](#). They can be temporary measured or Any snapped points.

Distances are entered directly, or you can optionally use a laser  rangefinder to measure them.

[Elevations](#) can be entered directly or as a Δ Delta elevation from the reference point, by [Vertical angle](#), [Zenith angle](#), [Slope \(1:N\) ratio](#) or [Slope \(%\) percentage](#):



Details: Survey (tab): Line/Arc stakeout

Available from the [Survey](#) (tab), [Line/Arc stakeout](#) button:






Line/Arc stakeout allows the selection of a line, arc, polyline, object to stake. The line can then be staked to the nearest point-on-line, endpoints, node-points, random and even stations along the staked object. **Offsets** can be added by Left, Right, Ahead, and Behind. **Visual staking** is supported for receivers with internal cameras (like the i89 and i93.)

A variety of **Tool buttons** can be customized on the left edge of the survey screen to allow for quick access to additional functions and settings.




To enter a Line/Arc stakeout without a selected line, there are a variety of selection methods.

Click on  to select a line from the **Line / Arcs** list .

Click within the **Line name** box:  to enter a **Named Line/Arc**. This will auto fill a pick-box with matching line/arcs.


Click directly on a displayed line on the map to select it:




Once you select a line to stake, additional Line / Arc stakeout functions and information will be shown:



The **Status bar** is described [Status] on Page 95.

The **Staked line** box  shows the name of the target line/arc for the current staking operation.

The **Instrument height** box  shows the current HI and can be clicked to modify. See [Antenna Height] on Page 96 for additional information.





The **Augmented reality**  button will enable and start the **Visual line stakeout** operation.








turns the **IMU Tilt** correction on and off.



stores a measurement at the current location.

When in the **Station and Offset staking**  mode, the   arrow keys move the target station forward and backwards along the current line using the **Station interval**. Click the  button to advance the target to the nearest station to your current location.

When in the If you are in the **Node staking**  mode, the   arrow keys move the target station forward and backwards through the **Node list**. Midpoints of line segments are included as nodes in addition to the endpoints of each segment. Click the  button to advance the target to the nearest node to your current location. The **Node list**  button displays a list of all nodes on the currently staked line.

When actively staking a line or arc, the **Line staking** menu will appear:



cancels the current line stakeout.




chooses the North reference for map and offset distances.




toggles the **Staking compass** on and off:




ON Dist



Tolerance




Off


Clicking  reverses the direction of the current line, arc or polyline.

When a target is active, select between four status display by swiping left and right:

Distance, target station, forward/back, left/right, cut/fill, current elevation:



Distance, target station, north/south, east/west, cut/fill, current elevation.




Distance, target station, offset (-left), cut/fill, current elevation:



Distance, target station, distance from start, distance to end, cut/fill:



Activating **Visual stakeout** results in the currently selected status display being shown overlayed on the real-time image.

The Station  shows the current station along the selected line/arc/polyline. Click it to directly enter a new target station. If you enter a non-even-station-interval value, clicking **Next** and **Last** will apply the station interval to the current value.

The **Line Stake method** button shows the current staking method. Click it to change the current line staking method:



Station and Offset Right/Left/Ahead/Behind.



To line with Offset Right or Left. Random or nearest point on a line.



Node (segment end and mid-points) with optional offset Right/Left/Ahead/Behind.

Line / arc stakeout settings

Station and Offset



Select the method from the 3 radio-buttons at the top.

Station & Offset runs through the line, arc or poly-line segment at specified **Station intervals**.

Start station is the chainage to apply to the beginning of the line. It typically is set to 0.

The **Station interval** is the chainage to move ahead or back along the selected alignment.

Offset can be **Left** or **Right** at a 90° (**Perpendicular**) or skewed **Ahead** or **Behind** the target point at an arbitrary angle referenced to the staked line.

The **Offset distance** can be entered using unit overrides.

The **Elevation** can be selected: by **direct entry**, **delta elevation** from the reference point, **Vertical angle**: applied from the reference point, **Zenith angle** from the reference point, or **Slope** (1:N or %) applied from the reference point.

To line



← back-1-Line/Arc stakeout

Station
☐ X&Offset ☒ To line ☐ X Node

Start station
 0.000 USft
Starting station, usually 0.

Offset
☒ Left ☐ Right

Offset distance
 0.000 USft

Elevation
 Δ Elevation
 0.000 USft

Cancel Stakeout

Select the method from the 3 radio-buttons at the top.

To line continuously adjusts the target location to the nearest point on the selected line, arc or polyline to the current position.

Start station is the chainage to apply to the beginning of the line. It typically is set to 0.

Offset can be **Left** or **Right** at a 90° angle referenced to the staked line.

The **Offset distance** can be entered using unit overrides.

The **Elevation** can be selected: by **direct entry**, **delta elevation** from the reference point, **Vertical angle**: applied from the reference point, **Zenith angle** from the reference point, or **Slope** (1:N or %) applied from the reference point.

Node



← back-1-Line/Arc stakeout

Station
☐ X&Offset ☐ To line ☒ X Node

Start station
 0.000 USft
Starting station, usually 0.

Offset
☒ Left ☐ Right

Perpendicular ☐ 000.00:00.00:00
(dd:mm:ss.ss)

Offset distance
 0.000 USft

Elevation
 Δ Elevation
 0.000 USft

Cancel Stakeout

Select the method from the 3 radio-buttons at the top.

Node runs through the line, arc or poly-line segment endpoints and midpoints.

Start station is the chainage to apply to the beginning of the line. It typically is set to 0.

Offset can be **Left** or **Right** at a 90° (**Perpendicular**) or skewed **Ahead** or **Behind** the target point at an arbitrary angle referenced to the staked line.

The **Offset distance** can be entered using unit overrides.

The **Elevation** can be selected: by **direct entry**, **delta elevation** from the reference point, **Vertical angle**: applied from the reference point, **Zenith angle** from the reference point, or **Slope** (1:N or %) applied from the reference point.

Details: Survey (tab): Surface stakeout

Available from the **Survey** (tab), **Surface stakeout** button:



Surface stakeout accepts a surface to stake, then displays the cut or fill required to move the receiver up or down to the design surface. The delta is updated continuously as the receiver moves around. Surfaces can be defined by a single point; by three or more points (technically two-points would work, however an unintentional tilted-plane will result); importing a CASS triangulation file, a 3D DXF File or a LandXML file.

You can either use the **Project > Surfaces** tool to predefine a named surface, or you can define the surface when **Surface stakeout** is initiated.

When you enter surface stakeout, if no surface has been previously selected, you will be prompted to **Open / import** an existing surface file or create a **New** surface. Clicking **New** will bring up the New surface dialog where you can Name the surface and choose one, three or more points to define a surface.

From the Surface stakeout list:



Click **Open** to open an existing surface:



Click **New**:



then selecting a single point:





For a Surface named **TargetSurface**:




Will show the surface stakeout map screen



The Status bar is described [Status] on Page 95.


The Staked surface box  shows the name of the target surface for the current staking operation. Click in the Name box  to manually enter a new surface name.

The Instrument height box  shows the current HI and can be clicked to modify. See [Antenna Height] on Page 96 for additional information.

The Surface stake status box:




Shows the current elevation, the design elevation and the cut or fill. **Fill** will have a green background, **Cut** will have a red background.

Click on the  **Panel button**, in the **Tool tray**, to display a large cut/fill panel:




See [Panel (surface stakeout)] on Page 47 for additional information.

Click on  **Begin** measurement to store a new measurement. Points stored from the Surface stakeout menu are collected in a surface staked list and can be

exported using the  **Export Surface staked report** button. Two files are written to a user selected folder:

.csv	containing: Name, Northing, Easting, Design elevation, Elevation, DeltaH, Date_time
.txt	containing: Name, Northing, Easting, Design elevation, Elevation, DeltaH, Date_time

Click the **Options**  button, then select the **Surface stakeout** (tab) to change the stakeout settings:



Voice (Sound) prompt enables a ding-ding-ding sound when the cut/fill delta is less than the **Tolerance**.

Tolerance determines when the sound is active.

Display cut/fill in fixed solution only disables cut/fill display when the receiver is not fixed. This prevents float, DGPS and Autonomous height measurements from being erroneously treated as valid heights.

Details: Survey (tab): Area survey

Available from the **Survey** (tab), **Area survey** button:



Area survey allows the collection of polygons representing the edges of a region. During collection either 2D or 3D area and 2D or 3D perimeter length are displayed. Once a region is complete, it will be displayed with 2D/3D area and perimeter. The areas can be exported to a PDF report showing the area and DXF drawing file.

When you enter the **Area survey** method, an area and length information bubble is shown at the top of the screen:






a toolbar with an **Undo** and **Accept region** button is added to the map screen:



and a **Region list** tool is added to the **Tool tray**:






Click the **Start measurement** button  to take a first point measurement using the averaging time determined by the **Survey mode**  Topographic or  Quick survey.


Continue taking measurements at the corners of the region until the last side is pending. On a rectangular building this will be after the 4th measurement:



As each corner is acquired and as you dynamically move, the information panel will update with the Area and Length.

The **Next point**  display shows the point count of the next vertices.

You can click on the **2D area**  or **2D length**  to switch between 2D and 3D.

The Undo button  will remove the previous vertices.

After storing the final vertices click the **Accept region**  button to complete the current region. The **Area properties** dialog will be shown:

The **Type** is always set to **3D polyline**.

You can set the **Name** as desired.

If you leave **Code** blank, then the **Border color**, **Line width**, **Fill color** and fill **Transparency** will control the default (blank) code and all regions will share the default selections.


If you specify a **Code** then the **Border color**, **Line width**, **Fill color** and fill **Transparency** are applied to all regions with the same **Code**.


Note that the default **Transparency** is 100% or **NO FILL**.

The checkboxes  determine which text labels appear in the center of the region.


The **Text** line is rendered under the last line of area/perimeter text.

Once you complete a region, it is not possible to edit or add points to the region.


You can edit these properties by clicking on the region boundary line, then clicking the **Properties**  button in the **Tool tray**.

Clicking the [Region list](#)  button in the [Tool tray](#) displays the [Regions](#) list:




You can [Delete](#) or [Export](#) selected regions from this list. Slide a region to the right and click on the  button to enter the [CAD view](#) and center the selected region on in view.

If you export a region or a group of regions, two files will be created. A .DXF with all selected regions as closed polyline:



and a .PDF with one region per page:






Details: Survey (tab): CAD View

Available from the [Survey](#) (tab), [CAD view](#) button and from the Tool tray of many survey methods:






CAD View switches to a CAD style interface with a rich set of drawing, editing and measuring functions. Also available from the Tool tray and called by viewing shortcuts throughout the LandStar program.




The  **Current position** cursor shows the current GNSS or prism position on the map. You can change this icon's style and color from **Settings** : **Miscellaneous: GNSS position symbol** and **color**.

The **CAD view Tool tray** is fixed and cannot be edited. The arrow points in the direction the PDA is pointed, not the receiver.

The imported **CAD Hide/Show** button  toggles the visibility of CAD objects that are imported by reference. The **DXF import** button  allows you to search the device for .DXF and .DWG CAD file types to import. You can list the attached files from **Layers > Map files** (tab) using the **Layers** button , see [Map files (tab)] on Page 83 for additional information.

The  **Hide / Show** button toggles all point and line work display on and off. This allows quick inspection of your current position over a background map or drawing.

The **Full view**  button zooms out to show all drawing elements.



regens and reindexes the drawing which may result in faster updates.




pan the map to place the current GNSS or prism location at the center of the display. Toggles ON and OFF when clicked.



Toggles **Follow** (rotate) ON and OFF. When ON the CAD drawing is rotated to match the direction of the PDA. This function uses the internal compass of the PDA.

Action bar

At the bottom of the screen is an **Action bar**. If there is no point, line or feature selection:



If a point, line or feature is selected (by clicking or with the  **Snap tool**) then the **Action bar** changes:



Action bar: Data

Clicking on  **Data**:



Delete: select one or more objects or a rectangular area to delete.



Export DXF: export the entire CAD drawing to a .DXF file.



Layers: display the layer manager.



Off other layers: click an object, it's layer will remain visible, all other layers will be hidden.



Layer off: select any object, its layer will be hidden.






Save point: click a DXF object; all points on the same layer will be saved to the point list.



Explode: all blocks loaded as DXF layers will be exploded.

Action bar: Draw

Before clicking  **Draw** on the Action bar, click and hold the  **Snap tool**:



and make sure the snaps are set to allow point selection. Then when you click on  **Draw**:



and choose a drawing action, you will be able to select the desired features.



Create a new **Point**. Click on an object endpoint, intersection as determined by Snap to create a new point.



Create a **Line** segment. Click on the first and second point or a pair of snappable features to create a single segment 3D line.

When a line is created, the Line dialog will be shown:

← volume-Properties

Info Attributes Multimedia

Line name
Line_1

Code

2D length
56.238 USH

3D length
56.254 USH

Δ Height
-1.314 USH

Bearing
N 27.5543 952 E

Slope
-2.34% (-42.80)

Display line dimension ☐

Save

Enable [Display line dimensions](#) and the new line will have Length and Bearing annotations added at the center:



The text annotations are not connected to the line, they are separate static text fields.



Create a [Polyline](#). Click on several (more than one) points or a series of snappable features to create a polyline.



3-point [Arc](#). Click on three points or snappable features to define an Arc.



Center + radius [Circle](#). Click on the center point, then enter a radius to draw a circle.



2-point [Circle](#). Click on two points to draw a circle.



3-point [Circle](#). Click on three points to draw a circle.




[Layout – plot deed](#). Select a starting point, then enter a series of metes-and-bounds descriptions to describe a traverse (typically around the perimeter of a parcel.) This function includes an advanced curve calculator and allows non-tangent arc descriptions. See [Details: Tools (tab): Plot Deed] on Page 201 for a detailed example.



Click to add [Text](#) (starting at the lower-left text corner) at any clickable point or snappable feature. The size of the text is proportional to the scale. If you zoom in and draw text, the text size will be small. If you zoom out and draw text, the text size will be large.


Action bar: Measure

Clicking on  **Measure:**



Allows measurements between clickable features and objects.



Inverse returns the distance and bearing between two points or a point and the { endpoint, midpoint, nearest point } on an object, like a line. Click and hold the  **Snap tool** to configure the object snaps to help choosing points.




Multi-inverse returns the distance and bearing between a series of points or clickable features. The results are presented in a table that lists the total length and the incremental traverse bearings and distances.



Angle computes the included and excluded angle between three points or clickable point features.



Area computes the included area enclosed by a series of points or clickable point features. After the last point is added, the total perimeter and enclosed area is displayed. Optionally, the selected region can be added to the **Area list** with a Name, Code and attributes which will be displayed on the map.

To edit the region, click on it, then select  Properties. Alternatively go to **Area survey**, click on the **Region list** button. Area regions can be exported using **Project > Export > Other formats** (tab) and choosing **Format = Area report**.

Details: Survey (tab): Site calibration

Available from the **Survey** (tab), **Site calibration**:



Site calibration allows modification of the underlying coordinate system so that Measurements (**GNSS points**) best match record (**Known point**) data. Horizontal and vertical calibrations can be combined or handled separately. **Site calibration** makes the GPS receiver use local coordinates.

Site calibration makes the GPS receiver display and use local coordinates instead of the default projected coordinates which are typically State Plane Coordinates. This allows following an existing survey honoring measured distances and bearings.



If there is only one point to calibrate on, it may be better to use **Project > Single point localization** to establish local coordinates, at ground. A single point localization can have a **Geodetic (True North)**, match the underlying State Plane Coordinate system (the **Projected system**) or have an arbitrary rotation. See [Details: Project (tab) > Single point localization] on Page 68.

Prior to performing a site calibration, you may want to enter points for the **Known point (Local)** positions. If you only have meets and bounds (distance and bearing calls); use the **Tools > Plot deed** tool to convert distance and bearings to **Known point (Local)** coordinates. Then you can associate some GNSS measurements with these **Known points** to build a Calibration.

A localization consists of a list of **Point pairs**. Each pair associates a **GNSS position** with the **Local Known Point Coordinate**. If the Known points are well represented by the GNSS locations, then a calibration with low residuals can be computed and activated.

Points don't need to be entered prior to performing the calibration, they can be entered while building a new calibration. GNSS measurements don't need to be stored prior to performing a calibration, they can be occupied while building the new calibration.

It is also possible to import calibrations from other field tools (.loc files) directly.

Click on [Site calibration](#) from the [Survey](#) menu to enter this menu:



If a calibration has already been defined, it will be recalled and displayed. If this is a new project, the empty calibration screen shown above will be shown.

Click [Add](#) to enter the first GNSS point – Known point pair:

The [GNSS location](#) is entered at the top, the [Known point \(Local\)](#) is entered at the bottom. Both values can be recalled from the [Point list](#) or hand entered. The [GNSS point](#) can be measured  using the current position of the connected GNSS receiver.

Clicking **Save & Continue** will save the current point pair and allow entry of another point pair. When you have entered the final point pair, click on **Save** to return to the Site calibration menu:



Each of the point pairs will be displayed with the **GNSS point** number, the **Known point** number, the **Horizontal residual** and the **Vertical residual**. Use the checkboxes to control each point pair's contribution to the **Horizontal** and **Vertical** solutions.

Slide a **Point pair** line to the right to **Edit** and **Delete** the pair:



LandStar allows three types of **Vertical adjustments**:



Inclined plane used when the polygon connecting all the calibration points fully encloses the entire project. DO NOT use the Inclined plane with fewer than 4 vertical control points. DO NOT use Inclined plane without a GEOID if the project is large enough to have significant GEOID separation changes over the project.

Constant Adjustment adjusts the vertical measurement plane (Ellipsoid if no GEOID is loaded, Orthometric if a GEOID is loaded) up or down to best fit the vertical calibration points.

Surface Fitting fits a Quadratic surface fitting with nodes at the entered calibration points. Typically used when many elevation calibration points are available spread over the entire project. Like the Inclined plane method, this is best used when there are calibration points that enclose the project.

Note that it generally is better to always include a GEOID file in your coordinate system and then allow the vertical calibration method to work with the GEOID adjusted, orthometric heights.

Click the  button at the top-right to:

Toggle between the **Guide mode** which provides more prompts for calibration point entry and the **Simple mode**.

Export the current calibration configuration to a file. This can be used to share a calibration with another job or another crew.

Import a complete calibration system. Carlson .LOC files are supported. Two points will be added to the project for each imported calibration point with the imported point names. The primary point (like

10002) will have the Lat/Lon/Ellipsoid Height from the localization file, the secondary point (like 10002_1) will have the local coordinates (Northing, Easting, Orthometric height).

Click the Graph view button  to display a preview of th:



Known points




GNSS points

The current calibration scale factor is shown at the bottom.

SP: 0.997723721471 Results >

This value depends on the underlying projection (typically a SPC Zone in the USA), Grid scale factor (location dependent), the Height above Ellipsoid and the precision of the known points. A [Scale Factor](#) lower than 0.999 or higher than 1.001 is an indication that something may be wrong.

Click [Results](#)  [Results](#) to view a summary of the resulting transformation:

← Site calibration results

Number of points
1

[Horizontal]

Scale factor
1.0000000000

Rotation
000:00:00.000

Max. H. Residual
0.000135ft

[Vertical]

Slope north (ppm)
0.00000000

Slope east (ppm)
0.00000000

Constant adjustment
830.477135ft

Max. V. Residual
0.000135ft

When you are satisfied with the calibration, click on [Accept](#), then [OK](#) the calibration:

Horz. adjust successful.
Vert. adjust successful.
Accept the new datum
transformation parameters
now?

No Yes

The resulting [Horizontal adjustment](#) will be fully described on the [Project > Coordinate system > Horizontal adjustment](#) (tab):

← Coordinate system

Name USA NAD83 Utah North

Return trans **Horz. adjustment** Vert. adjust

Type Plane

Origin N 651715.208

Origin E 304377.543

Translation N 2407200.246

Translation E 489.654

Rotation -600-06.10.0700042967
dd.mmmsssss

Scale Factor 0.997723721470818

Interpolation method Bi-linear

North grid file None

East grid file None

From file Save to file Accept

The computed Vertical adjustment will be fully described on the [Project > Coordinate system > Vertical adjustment](#) (tab):

← height002-Coordi

Name USA NAD83 Utah North

Use **Horz. adjustment** **Vert. adjustment**

Type Constant adjustment

A -1022.176452172364

Geoid file Geoid2018US.CG

Interpolation method Bi-linear

From file Save to file Accept

Clicking the button allows you to share, Lock, Export and Load the complete system:

Coordinate system

Create QR code

Scan QR code

Use broadcast RTCM

Lock

Load from file

Export

[Create QR code](#) displays a QR code that another user can scan to share the coordinate system:



[Scan QR code](#) activates a QR code scanner which will read the complete coordinate system.

You can add password protection to the Coordinate system. Choose [Lock](#):



then enter a password and click on [OK](#).

Once locked, the coordinate system parameters are hidden:



[Export](#) writes a [Trimble DC](#) type file which can be shared or [Loaded](#) as needed.

Details: Survey (tab): Base shift and CORS shift

Available from the [Survey](#) (tab), [Base shift](#) or [CORS shift](#):



And



Base shift and **CORS shift** are nearly identical functions. **Base shift** works for a single base while **CORS shift** works for all future bases and is targeted towards CORS network corrections where the BaseID may change over time, receiver initializations and traveled distance.

Base shift

Suppose that you return to a project on the second day, and it is not possible to deploy a Base at the same location as the first day. You can set it up at a new, random location using an autonomous position.

However, when checking in (using **Point stakeout**) on a previously surveyed point 1001, there is a substantial difference between the Rover's current reading and the previous reading:



Base shift is a simple way to fix this issue.

From the Survey (tab) click on Base shift, then click on the



With the receiver occupying point 1001, click the **Measure** button, then **Start** acquiring a GNSS position:



Click the **Point list** button and choose **Known point 1001**:

Click **OK** to accept this point pair.

The Base shift menu will be shown with the required base offset to match the previous measurement:

Click on the **Accept** button.

Confirm the base shift by clicking **YES**:

The new base location and any measurements that you have already made with the new base will automatically be shifted:

If you click on **YES** then the Point list will be displayed, otherwise you will return to the Survey tab of the main menu.

Now, with the Base shift active, if you stakeout the check point 1001:




the offset will be minimal.

If you have multiple rovers on the project, you can share the **Base shift** using QR codes. Click the **Base shift** button near the top right corner of the **Base shift** menu:

Click **Create QR** code to build a barcode that can be **Scan QR code** by other rovers.

Removing Base shift

You can remove the **Base shift** by setting the recorded shift to 0,0,0.

From the main menu **Project** (tab) > **Point list** slide the shifted base to the right, then click on  **Edit** pencil:



The **Edit Point** listing will show the **N shift**, **E shift** and **H shift** for the base:

The screenshot shows the 'XMove-Edit point' screen for 'base_2'. It displays the following values: N shift: 0.292 m, E shift: 0.061 m, H shift: -0.283 m. The 'Save' button is at the bottom.

Manually change the N, E, and H shifts to 0.0, then click **Save**.

CORS shift

CORS shift is nearly identical to **Base shift** however the shift is applied to all subsequent measurements made with any online server.

Because CORS Network connections don't generate individual bases in the **Point list**, a new Virtual CORS base is built and applies to all subsequent CORS based measurements:

The screenshot shows the 'XMove-CORS shift' screen. It displays the following values: N shift: 0.354, E shift: 0.092, H shift: -0.296. Below these, it says 'New Virtual Point Name that holds shift results' and shows 'CORS_1' in a red box.

this CORS base will be shown in the point list:

The screenshot shows the 'XMove-Points' interface with a list of points. The point 'CORS_1' is visible in the list.

and can be edited in the same fashion as the Base shift.

Details: Survey (tab): Sideslope stakeout


Automates staking a vertical profile perpendicular along a centerline (line or polyline). The profile can have multiple profile strings (segments with varying slope and width) and is mirrored on both sides of the centerline. The centerline might also be used to grade a slope against a building foundation.

To begin, first define a polyline in **CAD view** (not the **Lines/Arcs** manager on the **Project** tab). An existing polyline from a DXF design file can be used.


Start the **Sideslope stakeout** operation from the **Survey** (tab), **Sideslope stakeout**:




Landstar will prompt you to select the polyline:



Click on the polyline to stake. Select the **Sideslope profile** to use:



If the correct profile does not exist:



Click on New:




Name the new **Sideslope** profile, enter a **Horizontal** and **Vertical Offset** if needed, then click **Save&Continue**. Enter the first **string** segment of the profile:



Select **Up/Down/Horizontal**(flat), the desired **Slope** (if not **Horizontal**) and the applied **Width** or **Height**. Click

Save&Continue to enter another String:

Enter the **String**'s parameters, then click **Save** to complete **String segment** entry and visualize the **Sideslope profile**:




Click Back to return to Sideslope stakeout:

The navigation bubble shows:

To top: -0.474 USR Radial: 0.430 USR
Outward: 13.662 Station: KD+067.9...
Up: 0.430 USR Offset: -1.308 USR

To top distance up to match the top of the string profile.



Radial Cut distance to the profile elevation in the radial direction.

Outward horizontal distance out at the current elevation to intersect the profile target elevation.

Station the current centerline **Station**.


Up/Down distance to move **Up** or **Down** to meet the target profile height.


Offset **Offset** distance Left or Right from the centerline+offset.


Click  and  to toggle between **Profile** view:





And **Plan** view:



Click  **Stop Centerline staking** and select a new **Centerline** and **Profile** to stake.

Click  **Left/Right** to toggle the profile from the **Left** and **Right** centerline+offsets sides.

Click  **T** Text display to control the items shown on the Profile view:




The **Sideslope target** box:



Changes the staking target between:

- Slope:** the nearest point on the Sideslope profile.
- N-:** the *N*'th inflection point on the Sideslope profile. 1 is at the centerline offset by the **Horizontal** and **Vertical Offsets**.


Use the  **Start measurement** button to store a staked point at any time and place. If Auto Descriptions [See Auto description for staked points on Page 125] are enabled then the point description will include the station, offset and cut/fill to the profile line.

Details: Survey (tab): Foundation stakeout

Foundation stakeout automates the design and staking of sloped pit walls around a foundation base. At a distance offset from the foundation base, a sloping surface is defined which intersects with the undisturbed ground surface. The top edge of pit, wall slopes and building bottom can then be staked and excavated.

To begin, first build a surface that encompasses the entire working area, the surface should extend past the expected top edge of pit. Then build a closed polygon for the foundation exterior, typically this will be imported from a CAD drawing.

For the example below, the original ground surface has been generated from undisturbed, pre-excavation ground shots:



The example exterior foundation polygon is a 12 x 30 foot foundation wall, approximately 4 feet below existing grade.


From the **Survey** (tab) click on **Foundation stakeout**:



The current project will be shown:



Click on the **Select a foundation** prompt, or the **Foundation select** button:



The, likely empty, list of existing foundation definitions will be shown, click on **New** to create a new foundation

definition:




Name the new foundation description. Click on the foundation polyline (orange line), then select **Left** or **Right** so that the black offset line is on the outside of the orange foundation polyline. The **Left/Right** selection will depend on the design direction of the polyline.

Enter the default **Offset** and **Slope** for the excavated walls. Optionally adjust the foundation **Elevation** if needed. The **Offset** and **Slope** can be individually configured for each of the line segments in the next step.


The green diagonal lines are the inflection lines for the pit's wall sides.

Click **Next**:




If the [Surface](#) to use for the undisturbed ground level is specified, the top of excavation limit will be computed and shown. Click on each of the foundation polyline segments to highlight the segment red, then edit the [Slope](#) from that individual segment if needed.

Each segment can have a unique offset and slope:



Click on [Save](#), the Foundation is now available to stake:



Slide the Foundation to the right to edit it.



Check the Foundation then click [OK](#) to begin staking.

Click on a Foundation element for staking directions and information for that element. The selected design element will be highlighted in red:




Staking the top-of-excitation limit.



Staking inflection lines at the pit corners.




Staking the foundation base + offset line.

Clicking the  Store measurement button will store a point. The description will follow the Auto description rules set in settings. See [Auto description for staked points] on Page 125 for information on Auto descriptions.

Details: Survey (tab): Continuous survey


Available from the [Survey](#) (tab), [Continuous survey](#):



[Continuous survey](#) allows automatic collection of measurements based on traveled distance or incremental time. Measurements can be triggered by Time, 2D distance traveled, 3D distance traveled or 2D delta and height delta.

The Continuous survey method shares the same map-based collection tools as Map survey. See [Details: Survey (tab) > Map Survey] on Page 95 for a detailed description of the many survey method screen elements:



When you first enter [Continuous survey](#), first click the [Options](#)  button, these [Survey method](#) settings for [Continuous survey](#) will be shown:



The screenshot shows the 'Bas002-Settings' screen with tabs for Survey, Display, Tools, and IMU. The 'Survey' tab is active. Under 'Survey method', 'Continuous survey' is selected. There is an 'Accuracy check' section with a toggle for 'Store fixed solutions only' which is turned on. Below that is an 'Auto increment name interval' set to 1. The 'Mode' is set to 'Distance 3D' with a corresponding distance value of 15.000 USft.

The [Survey method](#) will automatically default to [Continuous survey](#). Typically, you will only want to [Store fixed solutions only](#), however it is possible to disable the [Accuracy check](#) to allow [FLOAT](#) and [DGPS](#) solutions to be stored.

The [Auto increment name interval](#) should usually be 1 which increments the [Point name](#) by 1 after every measurement. If a conflict with an existing point is encountered, LandStar will advance to the next available point number.

Four delta methods are available:



A list box showing four options: Time, Distance 2D, Distance 3D, and Distance 2D or delta H.

[Time](#) will store a measurement after the [Time interval](#) delay:



The screenshot shows the 'Time' mode selected. The 'Time interval' is set to 2.0 Second.

[Distance 2D](#) will store a measurement after the horizontal position changes by more than the specified distance:



The screenshot shows the 'Distance 2D' mode selected. The 'Distance 2D' is set to 16.404 USft.

[Distance 3D](#) will store a measurement after the horizontal + vertical (3D slope distance) position changes by more than the specified distance:





The screenshot shows the 'Distance 3D' mode selected. The 'Distance 3D' is set to 15.000 USft.

[Distance 2D or delta H](#) will store a measurement after the horizontal position or vertical height changes by more than the specified distance:




The screenshot shows the 'Distance 2D or delta H' mode selected. Both the 'Distance 2D' and 'Delta H' are set to 16.404 USft.

Click the  **Start measurement** button to immediately store the first measurement and start checking for movement or time to trigger additional measurements.

The **Start measurement** icon will change to  **Stop measuring** when measuring is active. It is not possible to leave the **Continuous survey** screen without stopping measurements. The **Back** buttons will not operate until measurement collection is stopped.

Details: Survey (tab) Cross-section survey

Available from the **Survey**, **Cross-section survey** button:



Cross-section survey allows you to quickly survey points at evenly or randomly spaced cross sections along a centerline alignment:



This measurement collection tool displays your location relative to cross-sections enabling you to quickly navigate to the left-offset, centerline and right-offset points at each station. Extra measurements on and off the cross-section lines may also be stored.

In addition to the stored points, station and offset information is available for all measurements collected using the **Cross-section** survey, including points stored at random stations:

```
BEGIN,428.000:1  
-38.000,1118.469  
-22.000,1118.627  
-17.918,1118.595  
-14.501,1118.863  
-11.879,1118.351  
-8.892,1118.886  
0.827,1118.433  
6.364,1117.139  
18.875,1111.525  
15.939,1111.699  
38.000,1113.809
```

along with a DXF file that details every cross-section.


Getting Started with Cross-section Surveying

First identify the centerline alignment you want to survey. It is possible to survey between two points, but it may be easier to visualize the centerline if you use the CAD view to add a line between the endpoints. You can also use a polyline, arc, circle, or alignment as the centerline.

From the **Survey** page, click on **Cross-section survey**, then click on the alignment selector:




The project list of Lines/Arcs will be shown, it may be empty:




Click on **Add**, then pick a centerline source:



If you have already defined a line, click on **From map**, then click on the correct line, then click on **OK**:



Enter a name for the line, or accept the default name:



then click **OK**.

If you have selected a line, you will have an opportunity to edit and approve the Start and End points:



Click on **Save**, you will return to the **Line/Arc** list.

Select the new line by clicking in the right-hand circle, then click **Next**:



You can now click the [option](#) button:



Select the [Cross-section survey](#) (tab):



To set the station interval and left and right cross-section width.

Use horizontal transition points: add a cross-section at each centerline node.

Station interval: the distance along the centerline to place cross-sections.

Along offset tolerance of cross-section: RED prompting when the station exceeds.

Left length of cross-section: width (offset left) on left side of centerline.

Right length of cross-section: width (offset right) on right side of centerline.

Midpoint tolerance of cross section: left-right tolerance for the middle point on centerline.

Real time station as point name: build the point name from the actual station "K0+000.048"

Target station as point name: build the point name from the ideal target station "K0+000.000"

Either [Real time station as point name](#), [Target station as point name](#) or standard station incrementing can be selected.

Click the [back](#) button to return to the Cross-section survey screen.



You can directly enter the station to stake or use the previous station < and next station > buttons at the screen bottom to move forward and backwards along the centerline by the entered [Station interval](#). Clicking the [Nearest](#) button will add a cross section on the centerline at the station nearest your current position without regard to the selected [Station interval](#).


Your current position will be shown as a blue circle with a black navigation line the nearest point on the selected cross section. The actual station (along the centerline) and the offset will be shown:





The left and right offsets are shown as an orange target line. Typically, you will use the [Start measurement](#) to store the left, right and the centerline points. If the centerline station has not yet been measured, you will be prompted:


Cross-section midpoint not measured

You may measure as many points as necessary at each cross-section.

The  button selects the stored point type: **Topographic** (typically 5-second average), **Quick** (typically 1-second) or **Corner**.

The  button allows you to measure a remote (hidden point) using offsets.

Once you have measured each cross-section line, you can use the  **Cross-section export** button to write a DXF file that has a cross-section detail showing each measurement, at each station:



and a .TXT file:

```
86638,420.000:1
-30.000,1118.469
-22.000,1118.627
-17.910,1118.595
-14.581,1118.863
-11.079,1118.351
-8.892,1118.086
0.427,1118.633
6.364,1117.139
10.075,1111.525
15.939,1111.699
30.000,1113.809
```

detailing every stored cross-section.

Details: Config (tab): Instruments profile

Instrument profiles



combines the Bluetooth/Wi-Fi [Connection](#) information:



with one of the Instrument configurations:



to form a complete instrument definition.

If the Instruments profile function is not shown, look under the function.

[Instrument profiles](#) can be quickly selected and applied using the [Instrument select](#) button at the top of most menus.

Depending on the application, a named Instrument profile may be more convenient than separate connection and profile operations. This is especially true when you have a Rover that is used both as NTRIP Network Rover and a UHF Rover.

From the [Config](#) tab of the main menu, click on [Instruments profile](#):



The existing, possibly empty, list of [Instrument profiles](#) is shown:



Click [New](#) to create a new [Instrument profile](#):




Select the correct instrument type. For this example, we will configure an NTRIP Rover using the PDA internet connection:



Configure the connection information, the instrument should be on and ready to pair by Bluetooth or Wi-Fi. This dialog is the same as [Details: Config (tab): Connect to instruments] on Page 169.

When the configuration is complete, click [Next](#).



Select the Rover type (NTRIP shown above). This is the same as [Details: Config (tab): GNSS rover] on Page 171.

Click [Next](#):



Enter the network configuration information. Click [Next](#) when complete:




Complete any additional configuration items.



Click [Save](#) [Save](#) to save the Instrument profile or click [Save & Accept](#) [Save & Accept](#) to save the profile and immediately apply it to the receiver.


Once profiles have been defined, from the Config tab of the main menu, click on [Instruments profile](#):



This list of Instrument profiles will be shown:



Select  check the desired profile, then click  to apply the profile to the instrument and begin operation.

You may also use the  **Instrument select** button to activate **Instrument profiles**. See [Instrument select] on Page 49 for additional information.

Details: Config (tab): Connect to instruments

LandStar supports a very large list of **RTK Instruments**, **Generic NMEA** receivers, the **Internal GPS** receiver in the PDA and a position **Simulator**.


This is partial list of devices:

CHC	M5, X900+, X91+, X6, iBase, E90, E91, M6, i50, i73+, i73, i70, i83, i80, i89, i90, i93
JY	i80, Z3, X91+
Champion	Pro
Prince	iBase, i90VR, i90, i80, i70T, i80Air, i80Pro, i50, i30, i30 IMU Tx, X91
ELMIZ	elNav, M3, i70, i70Pro
Horizon	Kronos C3
ComNav	G9GNSS, G7GNSS
TopoMap	T10, T20, T20 plus
iGage	iG3S, iG4, iG5, iG8, iG8a, iG9, iG9a, iGV
eGPS	M5, eGPSM6, eGPSM7, eGPS20T, eGPS20TL
Datronix	D1, D20
GeoGenie	NX, PRO

LandStar connects to **GNSS receivers**, **Total stations** and **Peripherals** (Laser Rangefinder, Pipeline detectors, Echosounders) by Bluetooth. Most modern **GNSS receivers** also support a Wi-Fi connection.

Visual receivers like the CHC i89 and i93 require a highspeed Wi-Fi connection to utilize the cameras.

From the Config tab of the main menu, click on **Connect to instruments**:






Slide an antenna definition to the right and click on edit to modify the standard definitions.

It is also possible to manually enter a new custom [Antenna definition](#), click on Add to make and edit a new entry. Antennas are defined in LandStar with the following convention.

Corresponding to an antenna definition:



Details: Config (tab): GNSS rover

[GNSS rover](#) configures the connected device as a Rover and includes the UHF Radio / Internal modem / PDA connection settings to provide RTK corrections.

From the [Config](#) tab of the main menu, click on



$\text{Radius} = \frac{1}{2} \text{Diameter} = 0.4436 / 2 = 0.222$

$\text{To phase center (SHMP to L1PC)} = 0.3740 - 0.2753 = 0.099$

$\text{To the bottom (SHMP to ARP)} = 0.275$

Target device: Bluetooth

If the [Connection type](#) is [Bluetooth](#), when you enter the [Connect instrument](#) menu, LandStar will automatically perform a Bluetooth search. If the automatic search is unsuccessful, click on [Search](#). Then use the device operating system's Bluetooth menu to look for the receiver and to pair with it. When you return to LandStar, the new device will be available.

Target device: Wi-Fi


If the Connection type is Wi-Fi, click on the current Wi-Fi connection:



then use the device operating system to connect to the GNSS receiver. The default password for most CHCNav receivers is "12345678" if a password is requested.

Connect

Once all of the connection settings have been made, click on the [Connect](#) button.



If the connection is successful, LandStar will return directly to the main menu and voice "Successfully connected".

If the connection is not successful, make sure the receiver is turned on. Only one controller can connect by Bluetooth to a receiver at a time. You may need to go to the operating system Bluetooth menu and 'Forget' the device and add it again.



The list of known configurations will be shown. You can check a known configuration, then click **Accept** and the receiver will be configured.

Slide an entry to the right



then click on **Edit** to modify an existing configuration. It is also possible to Delete, Load from Cloud, Share a configuration. If you receive a shared connection profile, put the .hcwm file in the system folder:

/storage/emulated/0/CHCNAV/Config/workMode/

and it will appear in the Profile list the next time you click on **GNSS Rover**.

There are 5 primary configuration types:



NTRIP is a network server that requires a Username and Password. **APIS** is the CHC cloud service for sharing corrections between network connected receivers. **Radio** uses the device's internal UHF radio. **TCP** is a network server that does not require a Username or Password, it is also known as DIP: Direct Internet Protocol. **PPP** is a satellite correction service like RTX, PPP activation is configured elsewhere.

Radio



Set the Name to a description of the radio profile. The **Name** is arbitrary. It is recommended to include the Protocol and Frequency in the profile name.


The **Radio configuration** includes the **Protocol**, **Channel bandwidth** (Step value), over-the-air **Baud** rate, radio **Channel**, **Frequency** (set the **Channel** programming in the receiver), **Sensitivity** (normally high for Rovers), the **FCC callsign**, and **FEC** (may not be available for all radio protocols.)

NTRIP



Set the **Name** to a meaningful description of the network. The **Name** is arbitrary.

Internet access can be:



If the GNSS receiver has an activated cellular SIM card inside the receiver, then **Receiver network** can be selected. Otherwise, use the internet connection of the **PDA network** (the PDA is the Android device that LandStar is running on.)

Domain/IP is the network address of the server. It can be entered as a name like “turn.utah.gov” or as a dotted IP address “165.245.87.9”

Port is the internet port that hosts the server. Typically, it is 2101, however other ports like 8000 are also in use.

It is possible to enter a list of Servers and pick the

Domain/IP and Port from the list. Click on **Select a server**. Select a server to view and edit the server list. Each entry in the list has these data items:



Mountpoint selects the type of correction to receive from the server. Click **Get Mountpoint** **Get Mountpoint** to

download the server’s unique list. Then use the



drop down list to select the best **Mountpoint**.

Username and **Password** are both case sensitive.


When all the settings have been entered, click on **Save** to save the profile or **Save & Accept** to Save the profile and immediately apply it to the connected receiver.

TCP



Set the **Name** to a description of the network. The **Name** is arbitrary.

Internet access can be:



If the GNSS receiver has an activated cellular SIM card, then **Receiver network** can be selected. Otherwise, use the internet connection of the **PDA network** (the PDA is the Android device that LandStar is running on.)

Domain/IP is the network address of the server. It can be entered as a name like “turn.utah.gov” or as a dotted IP address “165.245.87.9”

Port is the internet port that hosts the server. There is no standard port for TCP/DIP connections.

It is possible to enter a list of Servers and pick the

Domain/IP and Port from the list. Click on **Select a server**. Select a server to view and edit the server list. Each entry in

the list has these data items:



When all the settings have been entered, click on [Save](#) to save the profile or [Save & Accept](#) to Save the profile and immediately apply it to the connected receiver.

Details: Config (tab): GNSS base

GNSS base configures the currently connected device as a Base configuring Internal UHF Radio / External Radio / Receiver Cell Network profile settings and does the **Base setup** putting a coordinate in the receiver.

First connect to the Base receiver using [Config](#) (tab) > [Connect to instruments](#). It is important to have the actual device connected so that LandStar can interrogate the device and offer the correct radio and communication options.

Hint: Make sure you are connected to the Base and not the Rover when configuring the Base.

From the main menu, [Config](#) (tab) click on **GNSS base**:



If you have never configured a Base, an empty **Base profile list** will be shown:



Click on [New](#) to create a new **Base profile**. Choose a correction message transmission method:



Details on each of these methods follow.

Internal radio

Internal radio uses the radio built into the Base receiver to transmit corrections. LandStar will retrieve the current UHF Radio settings from the Base and use them as defaults.

Name the Base profile with a meaningful complete name. It will have greater future value if it is easy to pick from the list. Decimal points and spaces are not allowed in the profile name.

Set the Differential format to the highest protocol shared by the Base and Rover.


If both receivers have Trimble OEM boards, **SCMRx** is appropriate. If you have two CHC receivers like the i93 **CHC516** protocol may be best. Otherwise, favor **RTCM3.2**. None of the other protocols support all satellite systems and signal tracking, they should not be used.

The radio **Protocol** and **Step value** (channel bandwidth) should be set as desired, however SATEL_3AS is typically the only supported protocol that supports 9600 baud over-the-air in 12.5 KHz channel bandwidth which is a requirement of most USA FCC licenses.

Typically, the **Baud** rate is forced by the **Protocol** and **Step value** (channel bandwidth). Higher **Baud** rates are better and 9600 is the minimum that will dependably support full constellation correction streams like RTCM3.2.

Selecting a radio **Channel** will determine the **Frequency**. In the USA, end users are not allowed to edit the **Frequency**, they must choose a **Channel** from the list of pre-entered licensed frequencies.

Sensitivity is best set to Low.

Click the  button to the right of **Call Sign** to check your **FCC Call Sign**.

The FCC information is configured by your dealer and is stored in the receiver. **Status** should be ON, **15** is the minimum **Interval** in minutes, the **Message** should be set to your **FCC ID** using upper case letters. See the receiver's User Manual for instructions on setting the FCC information.

FEC (Forward Error Correction) is best turned **OFF** as it adds 30% additional overhead to every correction message.

Set the **Elevation mask** to a reasonable value like **5** (degrees).

Turn ON **Start at known position** unless you want to pick or enter a known location. Turn OFF **Start at known position** to automatically read an autonomous base position for every setup.

Clicking **Save** will save the **Base profile** and return to the **Profile list**. Clicking **Save & Accept** will save the **Base profile** and begin the **Base setup** procedure. See [Base setup procedure] on Page 177 to continue setup.

External radio

External radio sends correction messages out the receivers RS232 Serial Port.



Name the Base profile with a meaningful complete name. It will have greater future value if it is easy to pick from the list.

If both receivers have Trimble OEM boards, **sCMRx** is appropriate. If you have two CHC receivers like the i93 **CHC516** protocol may be best. Otherwise, favor **RTCM3.2**. None of the other protocols support all satellite systems and signal tracking and they should not be used.

Set the **Baud** rate to the highest speed supported by your external radio. This typically will be 115,200 baud. Slower speeds can significantly increase the radio latency and reduce the carry capacity of the radio. The RS232 protocol is fixed at 8-data bits, No parity, 2 Stop bits.

Set the **Elevation mask** to a reasonable value like 5 (degrees).

Turn ON **Start at known position** unless you want to pick or enter a known location. Turn OFF **Start at known position** to automatically read an autonomous base position for every setup.

Clicking **Save** will save the **Base profile** and return to the **Profile list**. Clicking **Save & Accept** will save the **Base profile** and begin the **Base setup** procedure. See [Base setup procedure] on Page 177 to continue setup.

Receiver Cell Network

A Base configured as Receiver cell network pushes the correction stream through the internal Cell modem to a specified Domain/IP Address and Port. The protocol is Raw Telnet. There is no security. The Base does not need a

Static, Public IP V4 address because the corrections are pushed to a remote static address.



Use the **APN** button to check the receiver's APN (Access Point Name). In the USA, if you change the APN, you must cycle the modem or receiver's power to reset the cellular network.

If both receivers have Trimble OEM boards, **sCMRx** is appropriate. If you have two CHC receivers like the i93 **CHC516** protocol may be best. Otherwise, favor **RTCM3.2**. None of the other protocols support all satellite systems and signal tracking and they should not be used.

The **Domain/IP** and **Port** must be correct.

Set the **Elevation mask** to a reasonable value like 5 (degrees).

Turn ON **Start at known position** unless you want to pick or enter a known location. Turn OFF **Start at known position** to automatically read an autonomous base position for every setup.

Clicking **Save** will save the **Base profile** and return to the **Profile list**. Clicking **Save & Accept** will save the **Base profile** and begin the **Base setup** procedure. See [Base setup procedure] on Page 177 to continue setup.

Receiver cell network and external radio

Receiver cell network and external radio is a combination of **Cell network** and **External radio** sending corrections simultaneously over both links.

Base setup procedure

After you have defined an appropriate **Base profile** in the **Profile list**:



Select the desired **Profile** and click **Accept**.



If **Start at known position** is **OFF**, then LandStar will do a short average and start the Base with an autonomous position.

If **Start at known position** is **ON**, then the **Start on a known position** dialog will be shown:



Always enable **Store the point into the Point list** unless the point already exists in the project's **Point list**.

Double check the **Antenna type** and the **Antenna height**. Consult your receiver's User Manual to determine the Slant Height Measurement Point if you choose **Type = Slant H**.

The **Base Coordinates** can be entered and displayed in several formats.

If starting from a NGS OPUS solution, favor a Geodetic (Latitude, Longitude, Ellipsoid Height) position:

REF FRAME: NAD_83(2011)(EPOCH:2010.0000)				IT
X:	-1587260.768(m)	0.011(m)	-1587	
Y:	-4561961.616(m)	0.015(m)	-4561	
Z:	4153956.649(m)	0.016(m)	4153	
LAT:	40 53 8.48522	0.002(m) (a)	40 53	
E LON:	250 48 55.74704	0.005(m)	250 48 5	
W LON:	109 11 4.25296	0.005(m) (b)	109 11	
EL HGT:	(c) 1714.671(m)	0.023(m)	1	
ORTHO HGT:	1728.804(m)	0.079(m)	[NAVD88 (Compu	

The best measurement entry format is:



If working in US Feet or International Feet be sure to enter an “M” after the Ellipsoid Height, as shown above, **Elevations** are always in **Meters** on an NGS OPUS solution. You can manually type in the point **Name** and **Coordinates**; use the **Point list** button to recall a point from the project **Point list**; use the **Start Measurement** button to read the current GPS location or pick a point from **CAD**. Set the **Description** to a meaningful note, finally click **OK**. LandStar will configure the Base and corrections will begin to be transmitted.

Details: Config (tab): GNSS static observation recording

Receivers can store static observation data for processing in desktop tools like CGO2, online tools like NGS OPUS and be used for UAV post-processing.

GNSS static recording allows control of the receiver’s recording settings.

From the main menu Config (tab):



Set **Start logging** to **ON**, if set to **OFF** it is not possible to configure any of the logging parameters.

Set **Data format** to **HCN**.

If you would like the receiver to automatically begin recording when it is turned on and is tracking satellites, set **Automatically log when the receiver is turned on** to **ON**.

Choose an appropriate logging **Interval**. 1-second is usually great for all applications. When using OPUS, the interval must be 30-seconds or less and divide into 30 seconds evenly: 1, 2, 5, 10, 15, 30 are all acceptable.

Elevation mask sets the minimum satellite height about the horizon to record data. 0 (zero) is a good choice for all static applications and is recommended by NGS for CORS station recording.

Logging duration sets the length of recording files. **1440** minutes equals 24-hours and will produce a new file every 24-hours. The file begins when the receiver is turned on, not at midnight.

Station name is included in the resulting HCN and RINEX files.

Antenna height is usually the distance from the receiver's ARP (the bottom of the receiver) to the GM (Ground Mark).

Antenna height measurement method can be **Vertical**, **Slant H** or **Antenna phase center**. For NGS OPUS and most other application **Vertical** is the best choice.

RINEX will write a **RINEX 2** or a **RINEX 3.0x** file, in addition to the HCN file. It is possible to convert an HCN file into either RINEX 2.11, RINEX 3.02, 3.03, 3.04, 3.05 or 4.00. It is not possible to convert a RINEX 2.11 file into any other format. There also may be a rate limitation when RINEX is enabled.

Details: Config (tab): Instrument info

The **Instrument info** tool provides extensive information about the currently connected receiver.

From the main menu **Config** (tab) click on **Instrument info**:



The **Instrument info**, **Quality**, **Sky plot**, **Satellites**, and **GNSS Base** tabs are duplicates of the [**Status**] screens described on Page 95.

Details: Config (tab): Activate instrument

Receivers can be activated with a permanent code, a temporary code that expires after an evaluation period or be geofenced with different options based on location. **Activate instrument** allows the user to enter a new activation code.

From the main menu **Config** (tab):




If you have a new **Activation code**, record the current code then enter the new code, click **Activate**.



Details: Config (tab): Update

Receivers have firmware sets for the main board, the OEM GNSS engine, the cellular modem, and the UHF radio. It may be possible to automatically update the receiver using online resources.

From the main menu **Config** (tab):



Details: Config (tab): Advanced

Advanced functions include:

NMEA output for the Bluetooth channel, the RS232 Serial port, and a special Raw TELNET port (1212) accessible via the Wi-Fi port.

Receiver **Elevation mask** setting.

Position output frequency.

OEM GNSS engine reset.

APN for the cellular modem.

NFC/Wi-Fi function that allows easier connection to some receivers by Wi-Fi or Bluetooth.


From the main menu **Config** (tab):





NMEA Output

Clicking **NMEA Output**:



Then choosing **Serial port**:



Elevation mask setting




Press **Get** to retrieve the current **Elevation mask setting** from the connected receiver. Modify, then click set to send to the receiver.

Position output frequency



Press **Get** to retrieve the current **Position output frequency** from the connected receiver. Modify, then click set to send to the receiver. This is the coordinate update rate from the OEM GNSS board and may not be supported for all equipment.

Reset GNSS Board



Click **YES** to clear the GNSS board's ephemeris and then reset the GNSS Board. This forces a full reacquisition of signals and position.

A reset may be beneficial when verifying solutions under heavy canopy and this sequence is automatically applied during the **Verified** and **Control survey** methods.

Cellular modem APN (Access Point Name)

This option allows you to change the cellular modem **APN** (Access Point Name), **Dialing number** string, SIM **Username**

and SIM **Password**:



In the USA, normally the **Dial number** is *99# and both the **Username** and **Password** are blank.

In many markets (like the US) it is necessary to power off the modem, wait 40 seconds then turn the modem back on after changing the **Access Point Name** (APN). Enable the **Cycle power...** option to automatically turn off the cellular modem, wait 40-seconds, then turn the modem back on again.


Details: Config (tab): NFC / Wi-Fi

Some receivers include **NFC** transponders. It may be possible to read the Bluetooth ID, MAC and PIN and the Wi-Fi SSID, MAC and password via NFC. It may also be possible to modify the Wi-Fi settings with this function.

From the main menu **Config** (tab):



LandStar prompts to hold the NFC reader on the PDA next to the NFC icon on the receiver:



If possible, the NFC transaction will download the Bluetooth ID, PIN and MAC; and the Wi-Fi SSID, Password and MAC.

On some devices it is also possible to modify the Wi-Fi SSID and Password.


Details: Tools (tab): Map adjustment

Map adjustment allows vector maps (DXF, DWG, SHP, KML and KMZ, WFSDB files) to be georeferenced with multiple affine points. This adjustment tool will not work with raster images like .TIF, .PNG or .JPG raster files.

From the main menu **Tools** (tab), click on **Map adjustment**:




Use the drop-down box to choose an imported **vector** file:



Add **control points** to associate **Map points** on the vector map with **Known points**, in the survey:



Once three or more control points have been entered, residuals will be shown:



The screenshot shows a mobile application interface titled "ToolsTest Map adjustment". It features a table with three columns: "Map point", "Ground point", and "Residual". The table contains three rows of data. Below the table, there are two orange buttons: "Add control points" and "Next".

Map point	Ground point	Residual
3496475.998 2270591.864	3496513.966 2270477.290	18.221
3501648.145 2270674.823	3501723.146 2270685.782	19.348
3496377.456 2270197.815	3496394.333 2270178.391	27.345

Finally, click [Next](#) to complete the [Map adjustment](#).

Details: Tools (tab): Volume computation

LandStar will compute the Volume, surface area and cut/fill balance of two surfaces or a surface and a reference elevation, then and create a **Volume report**:



From the Main menu, click on



A list of existing Volume calculations will be displayed:



Click on New to create a new calculation:

A screenshot of the 'VolumeDemo-F' form. It has a 'Name' field with the value 'Gravel1545'. Below that is a 'Cut swell factor' field with the value '1'. The 'Method' field is set to 'Surfaces difference'. There are 'Original Surface' and 'Final Surface' fields, both with a '1' in a box next to them. At the bottom is a 'Calculate' button.

Enter a unique **Name** for the **Volume calculation**. The calculation will be kept with the job. It won't be possible to edit the definition, however it is possible to change the Units and then view the results again as needed.

The **Cut swell factor** accounts for the increase in volume when compacted undisturbed soil is excavated and swells to fluff (air pockets) in the loose soil.

The **Original surface** (Base), typically the pile bottom or pit edge, can be defined by several methods:



Reference elevation A single elevation that is used as the **Original surface**.


Reference point The elevation of the single point specifies an **Original surface** elevation.

Reference level 3-Points used to manually define an **Original surface** plane.

Surfaces difference Manually define two surfaces: **Original surface** and **Final surface**. This provides the greatest computation control.

Stockpile/Pit Automatically computes an outside boundary of the specified surface which is used as the **Original surface**, then computes Cut/Fill from the remaining points in the surface. Ignores the volume between the boundary and the inside points.

For example, let's compute the pile volume for a gravel pile.




Points 101 through 113 define the perimeter and points 200 through 225 are randomly collected over the pile surface. The pile is about 55 feet wide and rises 3.5 feet in height at the center.

First, we define two Surfaces:




PileBottom includes 13-points around the edge of the gravel pile [See Details: Project (tab) > Surfaces on Page 90 for additional information on adding Surfaces.] **All** includes all the points, both the edge and center. Setting up the Volume computation:

Pile Bottom:



All surface:



Choose **Calculation direction** = **Original to final**, finally click on **Calculate** to compute the differential volume, build a differential surface. Click **Export Report** to write a PDF.

Results tabulation:

←

VolumeDemo-Result

Details

View

Project

VolumeDemo

Name

Grawel1545

Date

17-09-23 16:59:16

Method

Surfaces difference

Original Surface

PileBottom

Final Surface

A8

Cut swell factor

1.000

Cut

0.000 Cubic Yards

Fill

148.375 Cubic Yards

Surface area 2D

0.056 Acres

Surface area 3D

0.056 Acres

Cut area 2D

0.000 Acres

Cut area 3D

0.000 Acres

Fill area 2D

0.056 Acres

Fill area 3D


0.056 Acres

Export Report


Surface visualization:



Exported PDF:



Click on **2D** then switch to **3D**, use one-finger to tilt and rotate the image, two-fingers to move it:



Details: Tools (tab): Area computation

Area accepts an ordered list of points and computes the area enclosed by them. The points can be selected from the **Point list**, from the **Map** or entered as a range of points.

From the main menu **Tools** (tab), click on **Area**:



Enter coordinate

It is possible to hand enter points, one at a time, or in conjunction with other selection methods to build the area point list:



Select from library (Point list)

Select from library displays the **Point list** with checkboxes. Points are selected in the order they are checked:



Select from map

Select from map shows the CAD screen:



Then click on points, one at a time, in order, to select the area's perimeter:



Click on OK to complete the perimeter selection:



Range of points

Range of points accepts a comma separated list, or hyphen separated range of points to include in the **Area list**:



Because LandStar **Point names** can include the hyphen character, you must space separate the range hyphen from the point names:

11 - 18


NOT: 11-18

Comma separate point Names "11,13,15,17"

Once an ordered set of points for the Area list has been selected, click on OK:



The area summary results will be shown:



Modify the distance units:



And the area units:



as needed.

Details: Tools (tab): Inverse

The **Inverse** tool computes distance and bearing between two points or a series of points (Traverse style). Consider the corners and quarters around this section:



From the main menu **Tools** (tab), click on **Inverse**:



Invsering from 11 to 12:



The distance is shown in both USFeet and Chains.Links with State Plane Grid Bearing N 1 20 14 W.

Click the **Move up** button, and point 12 will move to the top line:



Then enter 16 as the B point and LandStar will compute the East Quarter to West Quarter distance:



It is also possible to Inverse in the **CAD View**, see [Action bar: Measure] on Page 146.

Details: Tools (tab): Angle conversion (DMS.s ⇔ D.ddd ⇔ GON)

The **Angle conversion** tool is useful for converting Degrees Minutes Seconds to decimal degrees, decimal minutes, decimal seconds, radians and Gons and vice-versa.

From the main menu **Tools** (tab) click on **Angle Conversion**:



Select **Degree**, **Minute**, **Second**, **Radian** or **Gon** as the primary secondary unit. Then enter an angle in **DMS** at the top or the secondary unit at the bottom. As any value is modified, all other values are recomputed:



Details: Tools (tab): Parameter calculation, 3 or 7- parameter

Parameter calculation accepts matched sets of **GNSS points** (with underlying Lat/Lon/Height data) and **Known points** (projected values). After selecting a transformation style, verifying residuals, and computing best-fit translation coefficients, the translation can be entered into the current project's coordinate system.

From the main menu **Tools** (tab), click on **Parameter calculation**:



The **Parameter calculation** dialog is shown:



Select the transformation type:

7-parameters

7-parameters (strict)

3-parameters

Then click on **Add** to create **GNSS Point – Known Point** pairs:

ToolsTest-Add

GNSS point

Name

Latitude (ll)

000.00:00.00000 N

dd mmssss

Longitude (L)

000.00:00.00000 E

dd mmssss

H (ellipsoid H)

Known point

Name

North (N)

East (E)

Save Sweep/Continue

At least one control point pair is required for **3-parameters** calculation, at least three control point pairs are required for **7-parameters** calculations.

meter calculation

Type

7-parameters

GNSS point Known point N Residual E Residual (ppm)

1 11 0.197 -0.168

2 STK_2 0.201 0.243

3 12 0.112 -0.087

Add Calculate

Click on **Calculate**:

Accept the new datum transformation parameters now?

Attribute	Value
Translation X (USft)	-14765568.079
Translation Y (USft)	-40197210.768
Translation Z (USft)	-9947863.575
Rotation X (Sec)	350490.441265948
Rotation Y (Sec)	-64252.446758675
Rotation Z (Sec)	-44223.161251970
Scale Factor (ppm)	865000
Scale Factor (ppm)	-1246884.7777534
	17

No Yes

If the translation is acceptable, click on **YES**. If LandStar is not happy with the residuals, a warning message will be displayed:

Horizontal residual exceeds
±0.066 USft;
Vertical residual exceeds
±0.098 USft.
Large residual. Accept anyway?

No Yes

Click **YES** to continue anyway. The transformation will be installed into the project's coordinate system. The adjustment can be viewed from the main menu **Project** (tab) > **Coordinate system** > **Datum transformation** (tab):

date system Tools

Name USA NAD83 Utah North QZ018

Projection Datum transformation Horiz. adjustment

Type 7-parameters

Translation X 131635.286

Translation Y 100342.681

Translation Z -135820.350

Rotation X (Sec) 369.149965584154360

Rotation Y (Sec) -217.666344658001840

Rotation Z (Sec) 3873.479931035607500


Scale Factor (ppm) 30327.74768835016

From file Save to file Accept

Details: Tools (tab): Point to line distance

Computes the nearest point on a line to a specified point. Returns the **Station**, the **Offset distance** left or right, the nearest point can be saved to the **Point list** or directly staked out.

From the main menu **Tools** (tab) click on **Point to line distance**:



Consider this section 16 with all corners and quarters found:



How far off the line from the southwest corner 17 to the northwest corner 15 is the west quarter 16?



Enter A: 17, B: 15, C: 16, then click **Calculate**:



The intersection point is computed with the **Description**:
"16 to line 17"-15 STA 2666.941 USft R 5.443 USft

Click **Save** to save the computed point to the **Point list**. Click **Stakeout** to stake it out directly.

Details: Tools (tab): Offset distance

Offset from an origin point at a Grid bearing, a specified horizontal and vertical distance. Compute a new point and add it to the **Point list** or stake it out directly.

From the main menu **Tools** (tab) click on **Offset distance**:



Consider this section 16 with all corners and quarters found:



Place a point at the midpoint between the south quarter 18 and the east quarter 12.



Enter point 18 as the Origin (A). The Horizontal distance should be $\frac{1}{2}$ the distance from point 18 to point 12. Enter "18,12/2":



when the cursor moves from the window it will compute the **Distance**:



Now enter the **Bearing** as the computed bearing from the south quarter 18 to the east quarter 12 "18,12":



when the cursor moves from the window it will compute the **Bearing**:



Set the Vertical distance to 0. Click the **Calculate** button:



Click **Save** to save the computed point to the **Point list**. Click **Stakeout** to stake it out directly.

Viewing the CAD map:



The calculated point COGO_2 is in the desired location.

Details: Tools (tab): Deflection

Compute the angle of a point offset from the endpoint of a line to the line.

From the main menu Tools (tab) click on Deflection:



Consider this section 16 with all corners and quarters found:



What is the angle of the line from the northwest corner 15 to the north quarter 14 from the line between the southwest corner 17 to the northwest corner 15?



The quarter is 44 minutes north of the perpendicular of 17 – 15.

Details: Tools (tab): Rotation

Rotate a point around another point, a specified angle. Create a point at the new location.

From the main menu Tools (tab) click on Rotation:



Consider this section 16 with all corners and quarters found:



Rotate point 16 around point 17 one half the bearing between 17 and 18.

Set A to the southwest corner 17, B to the west quarter 16:

Enter the rotation angle as $\frac{1}{2}$ the angle from the southwest corner 17 to the south quarter. Enter "17,18/2":

Tab out of the entry box and the effective rotation angle will be computed:

Click **Calculate**:

Click **Save** to save the computed point to the **Point list**. Click **Stakeout** to stake it out directly.

Checking the computed position on the map:



COGO_3 is in the expected location.

Details: Tools (tab): Intersection

Intersection accepts point pairs defining two lines, the intersection of the lines between these points are computed. If there is no direct intersection, the lines are extended.

From the main menu **Tools** (tab), click **Intersection**:



Compute the mid-section intersection of the north-south and east-west quarter lines:



Enter A - 16, B - 12 (east west quarter line); C - 14, D - 18 (north-south quarter line):

ToolsTest-Intersection

4 known points: 

Known: point A,B,C,D.
Calculate: Intersection of AB and CD.

A: 16

B: 12

C: 14

D: 18

Clear Calculate

Click [Calculate](#):

Result

Name: C000_1

Code:

North (N): 3499110.260 USR

East (E): 2272755.454 USR

Elevation: 0.000 USR

Description: Sec Corner Project

Cancel Save Statement

Then [Save](#):



Finally check the stored point.

Compare the projected northwest section corner determined by the extension of the lines from the southwest corner to the west quarter, and the northeast corner to the north quarter:



Enter A -16, B - 17; C - 13, D - 14:

ToolsTest-Intersection

4 known points: 

Known: point A,B,C,D.
Calculate: Intersection of AB and CD.

A: -16

B: 17

C: 13

D: 14

Clear Calculate

Click [Calculate](#):

Result

Name: C000_3

Code:

North (N): 3501737.937 USR

East (E): 2270013.484 USR

Elevation: 0.000 USR

Description: Project NW Corner

Cancel Save Statement

then [Save](#). Check the stored point:



Details: Tools (tab): Bisect angle

Place a point on the line bisecting an existing angle, specifying the offset from the center vertices.



Consider a power line with a series of poles (4, 5, 6, 7, 9) making a right turn:



Set an anchor 24' behind point 7 on the line that bisects 6, 7, 8.

From the main menu Tools (tab) click on Bisect angle. Enter A - 6, B - 7, C - 8. Since we want the anchor outside of the included angle, enter “-24” as the projected segment

length:



Click [Calculate](#):



Click [Save](#). Verify the projected point in the [CAD view](#):



Details: Tools (tab): Divide line

[Divide line](#) will divide the distance between two points into even segment lengths ([By distance](#)) or a whole number of segments ([By segments](#)). Point protection can automatically [Skip points that already exist at the same location](#) as the calculated points.



Given two existing points 1 and 2, divide the line between them into 14-equal length segments.



[first point name](#). Check [Skip points that already exist at the same location](#), even though there are no points between 1 and 2 to overwrite:



From the main menu [Tools](#) (tab) click on [Divide line](#). Set the [Start point](#) to 1 and the [End point](#) to 2, choose [By segments](#) and enter 13 as the [Number of segments](#). Choose P1 as [The](#)

Click [Calc & Save](#), then view the results in the [CAD view](#).



Details: Tools (tab): Point average

Choose several existing points to average. Show the residuals for each added point and allow adding and removing points from the average before storing a new [Point average](#).

From the main menu [Tools](#) (tab) click on [Point average](#)



The Point average screen is shown:




Click on Add:



Click [Select from library](#), then check all the points to average:



Click on **OK**:




The ranges for N, E and Z are quite high.

Click on the **H Res** button to sort the horizontal residuals from largest to smallest:




Uncheck the **H** and **V** checkboxes for the top three highest residuals. The **Range** drops to reasonable values for N, E and Z.

Slide the bottom panel right and left to view the stats:



Horizontal scatter plot:



Vertical range plot:



Click **OK** when the point selection is acceptable:

Result

Name: SC

Code: []

North (N): 3490688.562 USft

East (E): 2280602.763 USft

Elevation: 5669.575 USft

Description: Avg

Buttons: Cancel, Save, Stakeout

Enter a **Point name**, choose a **Code** if desired, enter a **Description** and click on **Save** to store into the **Point list**, or click on **Stakeout** to immediately stake the computed point.

Details: Tools (tab): Plot Deed

Plot deeds from legal descriptions. Directly enter a Metes and Bounds survey or a Bearing- Distance traverse using lines and curves (arcs). Includes a Curve Calculator and provisions for arc tangent bearings or cord bearings.

There are two ways to enter **Plot deed**:


1) From the main menu **Tools** (tab) click on **Plot deed**:



2) From the CAD view click on **Draw**, **Layout**:



Select the Layout mode:



Points and lines may be easier for visualizing a complex description. **Enable** elevation to keep a site elevation, disable **Elevation** to place the description at a design elevation of 0.0. This will cause issues when using a robot, so it may be best to hold an approximate site elevation.

Specify a starting point:



Click on any existing point, or enter a new point from the **Project > Point list > Add** prior to entering the **Deed Plot**

function:



to start at an assumed project position like 10,000, 10,000.

From the first point, specify the first call as a Line or an Arc:



by choosing the Drawing target:



Deed plot line entry

Select **Drawing line**:



Enter the **Bearing**, typically using **Quadrant bearing notation** see [Entering Azimuths/Bearings] on Page 14 or with the **Bearing** button:




The Bearing selector also includes +/- 90° option for turning right-angle corners.

Enter the Distance:



Override the default project horizontal units for a description with mixed units like Chains or Links. See [Entering distances] on Page 14 for examples.

Specify an **Elevation**:



The new line will be plotted on the CAD screen in **red**:



If the new segment looks correct, press the **Add** button.

Continue entering description calls until the boundary or layout is complete.

Deed plot curve (arc) entry

Select Drawing Arc:



Enter the tangent Bearing:



If the description specifies a non-tangent **Chord bearing**, click on the **NE** **Bearing selector**:



To change to **Chord bearing** entry:



The **Bearing selector** also includes +/- 90° option for turning right-angle corners.

Enter the arc **Angle**:



The **Curve calculator** will help convert the curve values found in the description to an **Angle + Radius**:

If there is a **Curve radius**, enter it first, then follow with the **Arc length** or **Chord length**. Only one is needed to compute the arc **Angle**. Click **OK** to save the **Radius** and computed arc **Angle**.

The new curve (arc) will be plotted on the CAD screen in **red**:



If the new segment looks correct, press the **Add** button.

Continue entering description calls until the boundary or layout is complete.

Plotting deed descriptions, a complicated example

The **Deed plot** function is best described with a complicated example:


A part of the Southeast Quarter of Section 23, Township 6 North, Range 1 East, Salt Lake Base and Meridian, U.S. Survey: Beginning at the East quarter corner of this Section 23, thence South 89°36' 25" West 1446.81 feet along the quarter section line, thence South 6°59' 51" East 565.86 feet, thence South 4°54'27" West 66.0 feet; thence Easterly along a curve to the left with a radius of 206.57 ft., an arc distance of 110 feet, a chord bearing of N. 79° 39' 08" E and a chord length of 108.70 feet to the True point of Beginning.

Thence Easterly along a curve to the left with a radius of 206.57 feet, an arc distance of 50.3 feet, a chord bearing of N. 57° 20' 25" E and a chord length of 50.13 feet; thence Northeasterly along a curve to the left with a radius of 2683.29 feet, an arc distance of 100 feet, a chord bearing of N. 49° 23' 04" E and a chord length of 99.99 feet; thence South 46°54' 35" East 225.64 feet to the Northerly line of Snow Basic Road; thence South 43° 05' 25" west 92.25 feet; thence Southerly along a curve to the left with a radius of 164.61 feet, an arc distance of 263.10 feet, a chord bearing of S. 02° 41' 56" E and a chord length of 235.98 feet, along said South line to the center of an existing road, thence two courses along the center of said road as follows: South 41° 30' 42" West 58.98 feet and South 11° 46' 15" West 211.33 feet; thence North 86° 17' 37" West 152.24 feet; thence North 0° 17' 53" East 606.33 feet to the place of beginning.

This description has a Point-of-Beginning (Initial Point or POB) at the East Quarter of Section 23, then 4 calls to the True-Point-of-Beginning (TPOB) followed by 9 calls that close back to the True-Point-of-Beginning.

Plotted over an orthophoto, this is the complete description:



It is usually best to plot the initial calls leading to the True-Point-of-Beginning as one connected polyline. Then build a second polyline, starting at the end of the initial calls; around the closed parcel. At the final course LandStar includes a  **Close** button which will add a (hopefully) small segment representing the closure-error needed to complete the polyline into a polygon area.

Because description calls are typically only specified to the nearest arc-second, there will always be a small closure error which represents the loss of precision. A closing segment of excessive length is an indication of an entry blunder or a ‘bad’ description.

Summarizing the calls from the description above into a table:

Course	Type	Bearing	Quadrant bearing	Length	Radius	Arc distance	Cord bearing	Cord quadrant bearing
Point of Beginning								
1	Line	S 89:36:25 W	389.3625	1446.81				
2	Line	S 06:59:51 E	206.5951	565.86				
3	Line	S 04:54:27 W	304.5427	66.00				
4	Arc				206.57	110.00	N 57:20:25 E	157.2025
True Point of Beginning								
1	Arc				206.57	50.30	N 57:20:25 E	157.2025
2	Arc				2683.29	100.00	N 49:23:04 E	149.2304
3	Line	S 46:54:35 E	246.5435	225.64				
4	Line	S 43:05:25 W	343.0525	92.25				
5	Arc				164.61	263.10	S 02:41:56 E	202.4156
6	Line	S 41:38:42 W	341.3842	58.98				
7	Line	S 11:46:15 W	311.4615	211.33				
8	Line	N 06:17:37 W	406.1737	152.24				
9	Line	N 00:17:53 E	100.1753	606.33	Closed to True Point of Beginning			

The quadrant bearing shortcut entries see [Entering Azimuths/Bearings] on Page 14 and distance entries required for curve entry are **bolded**.

Starting at an assumed position 10,000, 10,000. Step-by-step instructions for entering this description follow:

From the **Tools** menu, click on **Plot deed**:



Pick Point 1 by clicking on it:




Enter Course #1: Line S 89:36:25 W (**389.3625**) **1446.81**, set the **To point** as **101**:




Click the **Add** button, enter Course #2: Line S 06:59:51 E (**206.5951**) **565.86**:



Click the  **Add** button, enter Course #3: Line S 04:54:27 W (304.5427) 66.00:



Click the  **Add** button, switch to **Drawing Arc** with **Chord bearings**:






Enter Course #4: Arc: **206.57 110.00** N 57:20:25 E (157.2025); use the Curve calculator to compute an **arc-Angle** from the given **Radius** and **Arc Length**:



Click **OK**, then:



Click the  **Add** button, then click the  **Stop** button to end the initial calls at **Point 104**:



Click on **Point 104** then edit its properties, change the **Description** to **TPOB**:

Normal Attributes Multimedia

Survey info

Name: 104

Code: >

Type: Enter >

Format: local N/E/Elev (Projection grid)

North (N): 9382.197 USft

East (E): 8723.451 USft

Elevation: 5100.000 USft

Description: TPOB

Survey time: 2023-09-01 14:12:00

Save

Click [Save](#) to accept the change.

At the bottom of the CAD view, click on [Draw](#) **Draw**, then [Layout](#) **Layout**:

File Circle Circle 2P Circle 3P Layout Test

Data Draw Measure

Again, choose to [Save Points and lines](#):

Layout mode

☒ Save Points and lines

☐ Save only points

☐ Save only lines

Elevation: ☒

Cancel Next

Start entering Course #1 of the parcel boundary: Arc **206.57 50.30** N 57:20:25 E (**157.2025**). Choose [Arc](#) then click on the [Curve Calculator](#)

Curve Calculator

Radius: 206.570 USft

Length: 50.3 USft

Chord: 50.176 USft

Angle: 13:57:05.685

Cancel OK

Enter the Radius 206.57 and the Arc Length 50.3:

File Circle Circle 2P Circle 3P Layout Test

Data Draw Measure

Curve Calculator

Radius: 206.570 USft

Length: 50.3 USft

Chord: 50.176 USft

Angle: 13:57:05.685

Cancel OK

Click the [Add](#) **Add** button, enter Course #2: Arc **2683.29 100.00** N 49:23:04 E (**149.2304**):

Curve Calculator

Radius: 2683.290 USft

Length: 100 USft

Chord: 98.994 USft

Angle: 2:08:07.011

Cancel OK

File Circle Circle 2P Circle 3P Layout Test

Data Draw Measure

Curve Calculator


Radius: 2683.290 USft

Length: 100 USft


Chord: 98.994 USft

Angle: 2:08:07.011


Cancel OK

Click the  **Add** button, enter Course #3: Line S 46:54:35 E (246.5435) 225.64:




Click the  **Add** button, enter Course #4: Line S 43:05:25 W (343.0525) 92.25:




Click the  **Add** button, enter Course #5: Arc 164.61 263.10 S 02:41:56 E (202.4156):




Click the  **Add** button, enter Course #6: Line S 41:30:42 W (341.3042) 58.98:




Click the  **Add** button, enter Course #7: Line S 11:46:15 W (311.4615) 211.33:






Click the  **Add** button, enter Course #8: Line N 86:17:37 W (486.1737) 152.24:



Click the  **Add** button, enter Course #9: Line N 00:17:53 E (100.1753) 606.33:



Click the  **Add** button, finally click on the  **Close** button to draw an 'extra' line segment from the final Point 209 to the initial parcel Point 104. The length of this extra line represents the description's closing error:




With a polyline and point set that fully describes the property boundary, it is now possible to perform a [Site calibration](#) on a few points, or to move, rotate, scale the computed description to grid coordinates.

Details: Tools (tab): Transformation

Translate, rotate, scale points and objects based on a multi-point alignment or manually entered delta-offset, rotation and scaling values.


From the main menu **Tools** (tab) click on **Transformation**:



Choose the **Transformation mode**: If a fixed translation distance is known or can be computed as the distance as a vector between two points, **Manual entry** is applicable. If you have several points, perhaps a parcel boundary based at 10,000,

10,000 which you would like to align with a few found GNSS points, then [Align matching points](#) will probably be better suited.


Align:



Manual:



Align matching points

Click the [Add](#) button, then enter coordinate translation pairs with the [Source](#) on the top and the [Target](#) on the bottom. The [Target](#) coordinates can be directly measured by clicking the  [Start measurement](#) button:

Clicking **OK** will return to the **Transformation point list**, clicking **OK & Next** saves the current pair and readies for new pair entry.

LandStar will compute a best-fit transformation between all the transformation pairs. If less than 4-vertical control points are enabled, LandStar will use a Vertical Constant adjustment method. If more than 4-vertical control points are enabled an inclined plane adjustment is utilized. If you use an inclined plane, you should try to have point-pairs that surround all of the points in use. If you don't really care much about elevation, only leave one vertical point-pair selected.

Large residuals highlighted in red are an indication that the pairs are not well matched and an indication of blunder:

Method	Source	Target	H Resid.	V Resid.
<input checked="" type="checkbox"/> H	1	2	3.811	0.000
<input checked="" type="checkbox"/> V				
<input checked="" type="checkbox"/> H	1009	1004	50.051	-0.237
<input type="checkbox"/> V				
<input checked="" type="checkbox"/> H	11000	Map. 1	46.241	-2166.7
<input type="checkbox"/> V				

However, some applications like fitting a record 80 chain x 80 chain section to measured section corners; may be

expected to have higher residuals and be acceptable:

Method	Source	Target	H Resid.	V Resid.
<input checked="" type="checkbox"/> H	100	1001	13.990	0.000
<input checked="" type="checkbox"/> V				
<input checked="" type="checkbox"/> H	101	1002	9.915	-4.380
<input type="checkbox"/> V				
<input checked="" type="checkbox"/> H	102	1003	0.039	174.927
<input type="checkbox"/> V				
<input checked="" type="checkbox"/> H	103	1004	9.870	18.008
<input type="checkbox"/> V				

Point pairs can be held for Horizontal and/or Vertical by using the ☒ H ☒ V method checkboxes. When transformation pair entry is complete, click **Next** to view the resulting transformation:


A reasonable rotation angle, a scale factor that approximates the Grid-to-Ground scale factor, and a Translate Z equal to the average project elevation are an indication of a well-formed transformation. Click **Next** to continue, then choose **Library list** or **Objects from map** to select points/objects to move. If points have connecting

lines to move, choose [Select object from map](#):



Then click [Next](#).

Highlight the points and objects to transform:



If the selected area has points or objects that you don't want to include, click on them after the selection and they will deselect.

Click [OK](#) after selecting an area or points to transform. Choose to [Overwrite](#) or [Save as new points](#) with an optional name [Prefix](#):



Click [Next](#):




Once transformed, surveyed type points are converted to calculated COGO points. A summary count of transformed Points and Lines is shown. Click [OK](#) to return to the [Tools menu](#).

Manual Entry

Select Manual entry as the Transformation mode, then enter a base point for the [Rotation](#) and [Scale](#). Enter the [Rotation](#) directly or click the [Rotation calculator](#) button to Calculate the rotation based on an existing [Old](#)

azimuth and desired **New azimuth** to align to:




Click  to align the rotation with two existing or entered points:




If the Rotation is manually entered, preserve as much angular accuracy as possible to ensure that distant points align accurately.

Click **Next** to set the **Scale** value:



Click **Next** to set the **North**, **East** and **Elevation** deltas, click the large  **Delta computer** to compute the **Translate deltas** from two points:



Click  to compute the delta between two existing points:



The **Trs2-Translate** screen is divided into three sections: **From point**, **To point**, and **Results**. Each section has input fields for North (N), East (E), and Elevation. The **Results** section displays calculated values for ΔN , ΔE , and $\Delta Elevation$. An **Accept** button is at the bottom.


Click **Accept** when the deltas are correct.

Click **Next** to continue, then choose **Library list** or **Objects from map** to select points/objects to move:




The **Trs2-Transformation** screen has a **Select points/Objects** section with two radio buttons: **Select points from library** and **Select objects from map**. The **Select objects from map** option is selected. At the bottom are **Back** and **Next** buttons.

If points have connecting lines to move, choose **Select object from map**:



Then highlight the points and objects to transform.

Click **OK** after selecting the area or points to transform. Choose to **Overwrite** or **Save as new points** with an optional name **Prefix**:



This screen shows the **Save options** section with two checkboxes: **Overwrite points** (unchecked) and **Save as new points** (checked). Below is a **Prefix** field with the text "T_". At the bottom are **Back** and **Next** buttons.

Finally click **Next**. A summary count of transformed Points and Lines is shown:



Click **OK** to return to the **Tools menu**.

Details: Tools (tab): Area subdivision


Subdivide an existing closed polygon into two parcels. Supports: parallel by two-points, perpendicular by two-points and hinge-point.

If you are starting with points with no polygon, use the CAD function **Draw > Polyline** to click through the enclosing boundary corner points, then close the polygon with the **Close** option.

From the main menu **Tools** (tab) click on **Area subdivision**



The CAD view will be shown, pan/zoom to view the enclosed parcel, then click on the polyline to select the polygon:



The enclosed total parcel area will be computed and shown.

Click **Next**:




Choose the **Method**:

Parallel by 2 points: select two points and an adjustable trim line will move parallel to the line through the two points.


Perpendicular by 2-points: select two points and an adjustable trim line perpendicular to the line through the two points will be shown.

Hinge point: select a single point and then adjust a trim line through the point.

Then click [Next](#):




The selected parcel will be cut in half (two equal sub parcels) constrained by the selected Method. Click inside the sub parcel that you would like to specify the size of (parcel 2 above), then click [Next](#).



The resulting sub parcel size can be specified by direct [Value](#) input or [Percentage](#) of total [Area type](#). Enter the desired value, click on [Calculate](#) to display the result. When satisfied with the subdivision, click [Next](#).

The resulting split point will be computed:



It is possible to directly [Stakeout](#) the point or [Add](#) it to the project [Point list](#).

Details: Tools (tab): Calculator

A simple [Calculator](#) for simple computations.

From the main menu [Tools](#) (tab) click on [Calculator](#)





Notes:



root (not square root)
 $144 \sqrt{2} = 12.0$



power
 $4^3 = 64.$



toggles between Degrees and Radians

Details: Tools (tab): Ruler

Displays a ruler that shows centimeters only.



Notes:



Calibrate the Ruler by setting the length of 5 cm.

Building GIS Datasets in LandStar

GIS attributes can be assigned to **Codes**, and then the Codes are associated with **Points** at the time of collection. When a Point is stored with a Code that has GIS attributes, the user will be prompted to enter values for the GIS attributes.

After GIS data is collected, a standard Shapefile (.SHP, .SHX, .DBF, .PRJ file set) can be exported for use in other mapping products.

Begin by setting up a **Code** with associated GIS attributes. From the main menu **Project > Codes > New**:



The **Code** name is **FH** with a **Drawing type** of **Point**. The text **Description** is **Fire Hydrant**, which is only used as a prompt, it is not included in the data set. A **Symbol** with a display size and **Color** can also be specified. The **Layer** is used for CAD drawings and DXF output, it typically will match the **Code Name**.

Measurements that are collected with this **Code** will be grouped into a shapefile named FH_Point.

Click on **GIS Attributes**:



then click the **New** **New** attributes button:



Set the attribute **Name** to **TagNumber** (GIS attributes should not have spaces in the names for compatibility with external tools.)

The attribute can have these field **Types**:



The fire hydrant tags all begin with H-, so we can set the Type to Text, and set the Default value to H- to simplify the operator's data entry.

Enabling **Required**:



forces the operator to enter a **TagNumber** before they can continue storing the measurement.


Next enter a **Text** attribute named **Color**. We only expect to find **Red** or **Yellow** fire hydrants, but include an **Other** just in

case.

Also include an integer **NumPorts** (the number of holes that water comes out of) and three attributes to hold the sizes of the ports in inches:



Every **Code** in a Project can have a separate unique **Feature list**.

Now, when in any Survey function, the operator can select the **Code FH**:

then click the  **Start measurement** button, wait for the measurement to complete:



when the measurement is ready to be stored, the user must enter the information associated with the **FH Code**:

The  **From previous** button duplicates the attributes from the previous point. The  **From point** button allows attribute duplication from an existing point with the same code.

After the operator enters all information, and optionally adds **Multimedia** (Pictures, Videos, Sound recordings) they click **Save** to return to the Survey screen, ready to collect the next measurement.

A shape file set can be Exported from the Project at any time.

From the main menu > Project > Export menu, select the Other format tab:



Set the **Format** to **SHP**, choose **Coordinate format** from:



Adjust the **Filters**, then click **Next**:



Navigate to the destination folder for the Shapefile set. LandStar will made a new folder named:

Projectname_YYYY-MM-DD-HH-MM-SS

In the new folder:



there will be a .SHP, SHX, .PRJ file for each used Code in the project. All the points without associated codes will be combined into the Empty Code_Point.xxx files.

In addition to the defined attributes, each file holds extra columns. For this example:

PT_NAME	Point Name
PT_CODE	Point Code
PT_REMARK	Point Description
PT_LATITUD	Latitude in DD.dddddd
PT_LONGITU	Longitude in DDD.dddddd
PT_ALTITU	Ellipsoid Height in meters
MEDIA	photo, video, sound three

comma separated filenames

TagNumber	operator assigned fire hydrant
------------------	--------------------------------

tag number

Color	operator selected color
NumPorts	operator entered number of

ports

Port1Size	operator entered port sizes
Port2Size	
Port3Size	

How to: Install, Update and Provision LandStar

There are two methods to download the latest version of LandStar:

1. Install the CHCNav Installation Manager from the Google Play Store. See [Downloading and Deployment] on Page 6 for step-by-step instructions.
2. Directly download the latest version from the iGage website: www.iGage.com

Direct download from iGage.com

To directly download the latest iGage verified version, click on this link:

<https://igage.com/out/LandStarDistribution/LatestVersion/index.htm>

then download the .apk file in the directory listing.

You may also open a browser on the Android device and navigate to www.iGage.com:



Find the link to **Out** on the top tool bar and click on it:



Click the link **LandStarDistribution**:




Click the link **LatestVersion**:




The .apk file in this folder will be the latest version. Click on it.

The file will begin to download:



After the file downloads:




Click on **Open**.

If this message is displayed:



Click on **Settings**:



Slide the **Allow from this source** to the right.




Click **Install**. Then wait while LandStar is installed and deployed.





Finally, when the install completes:



Click on **Open**. Allow all requested permissions:





Wait while LandStar initializes:




The initial splash screen may take over a minute to complete.

Choose the menu structure:



While the [Simple style](#) is simple, it does not match any of the descriptions in this [User Manual](#). It might be best to use the [Classic style](#) while learning to navigate LandStar. Click the [Do not confirm next time](#) checkbox, then click [OK](#).


When prompted to download [localization package](#) files:




Click on [Yes](#).



Click on the appropriate country.




Confirm the package download, click Yes:



It will take several minutes to download the package. The package contains special projection zones, GEOIDS, local

settings.




After the download and installation is complete, a  green checkmark will display next to the package. Click Close (at the bottom) to continue.





Click the [Projects](#) button,



Click the New button at the bottom to create a new project:



Enter a Name for the first project, then click the  Coordinate system more button:



Click on [Pre defined](#) Pre defined:



Set [Region](#) = [United States](#) (or your local), [Area](#) = [NAD83\(2011\)](#), then drag up / down to find the appropriate zone for your project. Additional information on Coordinate systems can be found here [[Details: Project \(tab\) > Coordinate system](#)] on Page 64.

NOTE: If you are in a special state or county zone, click on:



then choose a specific special area:



With the correct zone selected:



Click [Next](#).

Drag over to the right-column [Vert. adjustment](#) and select a [Geoid](#) file:



Change the [Coordinate system Name](#) to include a reference to the selected [Geoid](#):



Click OK.



Click on [Project settings >](#) then [Units >](#):

← UHFSurvey1-1-Units

Angle
dd:mm:ss.ssssss v

Azimuth display mode
Bearing v

Azimuth input mode
dd:mm:sssss v

Lat/Lon input mode
dd:mm:sssss v

Lat/Lon display mode
dd:mm:sssss v

Horizontal distance
Feet (USSurvey) v

Vertical distance
Feet (USSurvey) v

Area unit
Acres v

Volume unit
Cubic Yards v

Station
K0+00.00 v

At a minimum, consider setting [Azimuth display mode](#) = [Bearing](#), [Horizontal](#) and [Vertical distance](#) = [iFeet/USFeet](#), [Area unit](#) = [Acres](#), [Volume unit](#) = [Cubic Yards](#), and [Station](#) = [K0+00.00](#).

Click [Back](#), then spend a few minutes looking through the [Decimals settings](#) and [GNSS settings](#). Additional information on Settings can be found here [[Software settings](#)] on Page 28. Configure as you would like the new job defaults to be, then click on: [Save as default](#) so future jobs will share these settings.

Finally, click [Back](#), then [OK](#). A new project is available to work on.

Activate LandStar using the licensing instructions found here [[LandStar 8 Licensing](#)] on Page 7.

How to: Moving data to the data collector

The easiest way to move data to the Android data collector may be to email it to the account associated with the device. In this example, we have a comma separated value text file SectionExterior.csv:





```
1001, 866349.305, 1907564.544, 4530.66, SW
1002, 871614.146, 1907634.252, 4521.90, NW
1003, 871569.611, 1912911.454, 4788.67, NE
1004, 866292.324, 1912866.852, 4726.18, SE
1005, 871591.788, 1910272.852, 4606.77, NQ
1006, 868930.964, 1912889.154, 4740.00, EQ
1007, 866320.724, 1910215.695, 4628.22, SQ
1008, 868981.721, 1907599.401, 4517.59, WQ
```

which has been sent to the Android device as a file attachment.

Open the email in the Android device's mail client:



Click on the  **Download** button to download the file into the **Download** folder on the Android device. When the file has been received there may be a completion notice:



In LandStar, on the Main menu **Project** (tab), click on **Points**:



The current Points list will be shown:



Click on the **Import** button at the bottom:




Click on **OK**:

Use the File selector to move to the **Download** folder, located under Internal storage:



Highlight the **SectionExterior.csv** file, then click **Open**, the import result will be shown:



Click **OK**, the imported points will be available in the **Point list** as INPUT type points:


Name	North (N)	East (E)	Elevation (Elev)
1000	86881.728	100789.431	4
1007	86832.775	100715.494	4
1006	86832.466	100788.532	4
1003	87184.787	100772.852	4
1004	86828.323	100786.825	4
1002	87184.432	100791.452	4
1005	87184.546	100784.282	4
1001	86834.384	100754.244	4

How to: GNSS Network Rover Internal Cell Modem

Step-by-step i93 Visual RTK receiver configuration as **Network Rover** using the GNSS receiver's internal Cell Modem, with a Wi-Fi connection from the Android device to the receiver.

The GNSS receiver connects directly to the cellular network and brokers corrections from the CORS server directly. Results are then passed to the data collector via Wi-Fi. The internet connection of the receiver may optionally be shared with the data collector.

Internal Cell Modem Method



Insert SIM card

Turn off the receiver.



Insert a cellular SIM card in the receiver:



Use a nano-SIM, gold contacts down, diagonal slot inserts first on left.

Turn the receiver ON. Wait for the receiver to fully boot.

From the **Main** menu, click on the **Config** (tab) then **Instrument profile**:



Click on **New** to create a new profile:



Click on **GNSS Rover**:

Configure the receiver:



Enter a unique profile **Name**. Select the **Brand**, **Type** and **Model**. **Antenna type** will automatically fill to the correct antenna based on the **Model**.

If the receiver is a Visual receiver, choose **Connection type** = **Wi-Fi** otherwise **Bluetooth** may be used.

If the Android device is not currently connected to the GNSS, click on the Target Wi-Fi device:



When the i93 device serial number appears as **GNSS-serialnumber**, click on the receiver entry to connect.

If the receiver is not listed or has been ON for more than 10-minutes without a Wi-Fi connection, click the receiver's left button twice to turn the receiver Wi-Fi back on.

After a few seconds, the PDA will connect to the head:




then:



Don't worry if a message noting that there is no internet connection is displayed:




Do **not** tap the 'Tap for options', let this Android warning box expire automatically.

Click the  **Back** button to return to LandStar from the Internet menu. The Target should now be the Rover receiver:



Click **Next**:

The device type dialog is shown:



Select **NTRIP**, then click **Next**:

If the CORS server is a **TCP** server (also known as **TCPIP**, **DIP**: Direct Internet Protocol, or **Point-to-Point**) use the **TCP** service profile. See [TCP] on Page 173 for additional information.

Configure the Network settings:



Set the **Network** = **Receiver network** to use the cellular modem in the i93 receiver.

Enter the **Domain/IP** for the network, either a domain name or a dotted IPV4 address can be entered.

Set the NTRIP **Port** (usually 2101.)

Click [APN](#) [APN](#) to set the [Access Point](#) name and SIM card connection values.:



Set the [Access point](#) name. The SIM card provider will supply you with this value. Some common values may be:

ATT	Broadband
Verizon	VZWINTERNET
T-Mobile	fast.t-mobile.com
Data Activation Center	dac.com.attz
US Cellular	internet
Union Wireless	SMART.COM

[Dial number](#) = [*99#](#) is correct for most markets. SIM card [Username](#) and [Password](#) are typically left blank.

In the USA, if the [APN](#) is changed, the Cell modem power must be cycled [OFF](#) then back [ON](#) to reset the local tower. Enable the [Cycle power...](#) option, then click on [Set](#).



Wait 40 seconds for the Cell modem to restart, LandStar will countdown to zero and return to the [Data link parameter](#) settings:



Click on [Get Mountpoint](#) [Get Mountpoint](#) to download the mount table from the configured server.

Wait (it should take 2 to 15 seconds) for the mount table to be downloaded:



The mount table will be displayed:



Select the desired mountpoint (typically a VRS RTCM32 or RTCM33 mountpoint will be best).

Enter the **Username** and **Password** for the NTRIP server:



Retransmit correction data will transmit the network corrections to the internal **UHF radio**, **Wi-Fi**, **Bluetooth** or via the Serial port. **Retransmit** is typically disabled. Additional information on Retransmit can be found in the next section [Retransmit correction data] below on Page 233.

Click **Next**:



Click **Save & Accept** to save this new profile and configure the receiver. After a moment, the receiver will be configured.



If the network **Username** and **Password** are valid then:




will be shown. Click **No** to return to the main menu.

See [Status] on Page 95 for additional information on the **Status bar**.

This Instrument profile can be selected in the future by clicking the Instrument select button:



Then selecting the desired profile from the GNSS Rover list:



And clicking the Accept button.

Retransmit correction data


When a Rover uses a NTRIP or TCPIP network correction source, it is possible to retransmit the correction stream from the Rover to other nearby Rovers which effectively shares a network subscription.

Many CORS network server agreements specifically prohibit sharing; however, it can be a simple method to utilize a receiver as a network repeater on top of a hill where there is good cell reception, then push corrections down into a valley to a working Rover via a UHF link.

Be sure to connect a UHF antenna to the receiver so the radio range will be maximized.



To retransmit via the internal UHF radio in the Rover, enable [Retransmit correction data](#):



Set the [To](#) = [Radio](#), choose a [Protocol](#), radio [Channel bandwidth](#), over-the-air [Baud](#) rate and the frequency [Channel](#) to use. Click [Save & Accept](#) to connect the Rover to the network and begin retransmitting.


How To: GNSS Network Rover PDA Modem

Step-by-step instructions for configuring the i93 Visual RTK receiver configuration as a Network Rover using the data connection of the PDA (the Android data collector.)

Because the Wi-Fi connection of the Data Collector will be used to connect to Visual receivers (like the i89 and i93) to utilize the highspeed cameras, the data collector needs to have a cellular connection.


This method is also known as DCI (Data Collector Internet).

The data collector connects directly to the cellular network and brokers corrections from the CORS server sending them via Bluetooth or Wi-Fi to the GNSS receiver.




Turn the receiver ON. Wait for the receiver to fully boot.


From the **Main** menu, click on the **Config** (tab) then **Instrument profile**:



The existing, possibly empty, list of Instrument profiles will be shown:



Click on **New** to create a new profile:



Click on **GNSS Rover**:

Configure the device connection:



Enter a unique profile **Name**. Select the **Brand**, **Type** and **Model**. **Antenna type** will automatically fill to the correct antenna based on the **Model**.

If the receiver is a Visual receiver, choose **Connection type** = **Wi-Fi** otherwise **Bluetooth** may be used.


If the Android device is not currently connected to the GNSS receiver, click on the Target Wi-Fi device:



When the device serial number appears as **GNSS-serialnumber**, click on the receiver entry to connect.

If the receiver is not listed or has been ON for more than 10-minutes without a Wi-Fi connection, click the receiver's left button twice to turn the receiver Wi-Fi back on.

After a few seconds, the PDA will connect to the head:



then:



Don't worry if a message noting that there is no internet connection is displayed:




Do **not** tap the 'Tap for options', let this Android warning box expire automatically.

Click the **Back** button to return to LandStar from the OS Internet menu:



Click **Next**:

The correction type selection will be shown:



Select **NTRIP**, then click **Next**:

If the CORS server is a **TCP** server (also known as **TCPIP**, **DIP**: Direct Internet Protocol, or **Point-to-Point**) use the **TCP** service profile. See [TCP] on Page 173 for additional information.



Set the **Network** = **PDA network** to use the cellular connection of the Android device.

Enter the **Domain/IP** for the network, either a domain name or a dotted IPV4 address can be entered.

Set the NTRIP **Port** (usually 2101.)

Click on [Get Mountpoint](#) **Get Mountpoint** to download the mount table from the network server.

It should take 2 to 15 seconds for the mount table to be downloaded from the network server:



The mount table will be displayed:



Select the desired mountpoint (typically a VRS RTCM32 or RTCM33 mountpoint will be best).

Enter the **Username** and **Password** for the NTRIP server:



Click **Next**:

Configure the advanced Rover settings:



Click **Save & Accept** to save this new profile and configure the receiver. After a moment, the receiver will be configured.



If the network **Username** and **Password** are valid then:



will be shown.


Click **No** to return to the main menu.

See [Status] on Page 95 for additional information on the **Status bar**.

This Instrument profile can be selected in the future by clicking the **Instrument select** button:



Then selecting the desired profile from the **GNSS Rover list**:



And clicking the **Accept** button.

How to: GNSS Internal UHF Base

Step-by-step RTK receiver configuration as a UHF Base using the internal UHF radio and a Bluetooth connection to the receiver from the Android device.

Because the base does not utilize any Visual features, a high-speed Wi-Fi connection is not necessary, the Bluetooth connection may be utilized.

In the USA an FCC license is required for UHF Base mode.

Be sure to connect a UHF antenna to the receiver prior to operating as a base.



Configure a reusable Instrument profile for the Base

UHF Base profiles allow a Base receiver to transmit corrections to one or more Rover receivers via UHF radios. Setup the Base on a stable tripod, attach external power if longer term operation is expected. Turn on the receiver.

From the **Main** menu, click on the **Config** (tab) then **Instrument profile**:



The existing, possibly empty, list of Instrument profiles will be shown:



Click on **New** to create a new instrument profile:




Click on **GNSS base**:



Match the **Brand**, **Type** and **Model** to your receiver. For the i93: **Brand** = **CHC**, **Type** = **RTK**, **Model** = **i93**. The **Antenna type** should automatically match the correct antenna for integrated receivers.

Since a Base won't need high speed data transfer for camera images, a Bluetooth connection will be fine. Set

Connection type = Bluetooth. If the receiver is not available in the Target list, click [Search](#) [Search](#) to find nearby devices.

When the correct receiver with Bluetooth name = GNSS-serialnumber is listed, select it  then click [Next](#):

Select [Internal Radio](#):



then click [Next](#).

The Base settings dialog will be shown:



If all the Rover receivers on the job will be recent CHC receivers (currently i83, i89, i93, iBase) that support the [CHC516](#) format, select [Differential format](#) = [CHC516](#); otherwise select [Differential format](#) = [RTCM3.2](#):



Typically, **Protocol** = **SATEL_3AS**, **Channel bandwidth** = **12.5 KHz**, **Baud** = **9600** and **FEC** = **OFF** is best for operation in the US.

Set the **Transmitting power** = **1 W** for small sites, **2 W** or **5 W** (if available on your receiver) will provide better radio coverage for large sites.

The **Channel** setting selects the **Frequency**.

The **FCC Call Sign** must be broadcast every **15 minutes** for legal operation in the US:



Since we are making a general profile, set **Start at known position** = **Enabled**. If the profile is used at an unknown location, the GNSS Measurement button can be used to read the current GPS position if needed. If you would like to always use an autonomous position, set **Start at known position** = **Disabled**.

Always set **Start logging** = **Enabled** for Base setups, the observation files can be submitted to OPUS to obtain or verify the true Base position. Set **Data format** = **HCN** and/or **RINEX** = **RINEX3.0x** to generate suitable files for NGS OPUS. **Interval** = **1 Hz** is best for processing UAV data against. **Logging duration** = **1440 minutes** (24 Hours) is reasonable. Setting the **Station name** = **device_serialnumber** or a short Point name helps identify Base and Rover data.

The default **Antenna height** is best entered as the **Vertical height** from the Ground Mark (GM) to the bottom of the receiver threads. **Slant heights** can be confusing as there is a possibility of multiple Slant Height Measurement Points (SHMP):


- Measurement line on Receiver Band.
- Top or Bottom of Receiver Band.
- Tape hook on offset plate attached under the Receiver.


When all the settings are correct, click on **Save & Accept**. The Base Start dialog will be shown:




Set **Add the point to the Point list** to **Enabled** if the receiver will be read or the location will be snapped from the CAD drawing.

If you know the Base location coordinates, you can enter them directly in Northing, Easting, Orthometric Elevation or Latitude, Longitude, Ellipsoid Height format. See [**Entering / Viewing Geographic and Projected Coordinates**] on Page 15 for information on coordinate entry and reference frames.

If the Base location is available in the **Point list**, click  to recall the point coordinates. Be sure to read the section [**Start from Point list or Previous position**] on Page 241 for important information on using Base positions in the Project **Point list**.

If the Base location is available in the **CAD** layers, click  to snap the Base position point from the **CAD** drawing.

To read the current GNSS receiver position (read GPS) click  **Measure GNSS** to use the current autonomous GPS

position:




Make sure the [Antenna height](#) is correct. Then click on [Start](#). A receiver not fixed warning may be shown:



Click [Continue](#).

A warning about the Hrms / Vrms may be displayed:




Click [Continue](#). The measurement results will be entered.

When the coordinates are correct, click [OK](#):



After the Base is configured, the Instrument profile list will be shown with the new profile:




This Instrument profile can be selected in the future by clicking the Instrument select button:



Then selecting the desired profile from the GNSS Base list:



When the Android data collector is connected to a Base receiver, this message:




will be displayed to warn you that you are NOT connected to a Rover and you should not use the current connection to store coordinates.

After 10-seconds, the corrections TxRx LED:



should begin to blink amber once each second.

Start from Point list or Previous position

Click on the  [Point list](#) button to retrieve a position from the [Point list](#). By default, previous base positions will not be


available in the list:



Click on the  3-Dot button (upper-right corner):



Click on **Show GNSS base points**. Every previously used Base point, including CORS network bases will now be shown in the list:



Select the previous Base position, or a previously surveyed or computed point, then click on **OK**.

If the entered position is significantly offset (more than 100 meters or 328 feet) from the receiver's actual position, an error message will be displayed:



It is not possible to continue with the base setup with a bad position. Receivers are unable to numerically generate corrections if the position is wrong.

This is a common error that occurs when:

Design coordinates are in a different projection than the LandStar project coordinate system.


Design coordinates are at a 0 elevation, as shown above.

The wrong point is chosen from the Point list as a known starting coordinate.

A negative longitude is entered as a positive longitude.

Easting and Northing are exchanged when hand-entering a projected position.

If you want to start the base with a position that does not

closely match the actual position, use the  **Measure button** to start the base with an autonomous GPS position. Then use the **Project: Single point localization** to perform a **Site calibration** and make the receiver match the desired coordinates. More details can be found here [Details: Project (tab) > Single point localization] on Page 68.

If the Base position is acceptable, LandStar will set up the Base and correction broadcast will begin.

After 10-seconds, the corrections TxRx LED:



should begin to blink amber once each second as corrections are sent to the radio.

How to: GNSS Internal UHF Rover

Step-by-step i93 Visual RTK receiver configuration as **UHF Rover** using the internal UHF radio. The highspeed Wi-Fi connection between the receiver and the Android data collector is used so that Visual survey functions are available.


Be sure to connect a UHF antenna to the receiver so the radio range will be maximized.



From the **Main** menu, click on the **Config** (tab) then **Instrument profile**:



The existing, possibly empty, list of Instrument profiles will be shown:



Click on **New** to create a new instrument profile:



Click on **GNSS Rover**.



Set the **Brand** = **CHC**, **Type** = **RTK**, **Model** = **i93**. If you are going to use the **Visual stakeout** or **Visual survey** functionality of the i93, you must set the **Connection type** = **Wi-Fi**.

Antenna type should automatically fill to the correct antenna based on the **Model**.

The current Wi-Fi connection of the PDA (the Android data collector) will be shown as the **Target**. Click the current connection (IGAGE above) to view the Android device's Internet connection menu:



When the i93 device serial number appears as **GNSS-serialnumber**, click on the receiver entry to connect.

If the receiver is not in the list or the receiver has been ON for more than 10-minutes without a Wi-Fi connection, click the receiver's left button twice to turn the Wi-Fi back on. (Most CHC receivers disable the Wi-Fi to save power after 10-minutes of non-use.)

After a few seconds, the Android device will connect to the receiver:



then:



Don't worry if a message noting that there is no internet connection is displayed:




Do **not** tap the 'Tap for options', let this Android warning box expire automatically.

Click the **Back** button to return back to LandStar from the Internet menu.

Note that the **Target** Wi-Fi connection is now the GNSS receiver:



Click **Next**:



Select **Radio**, then click **Next**.

Configure the receiver radio parameters:



Set the radio **Protocol**, **Channel bandwidth**, **Baud**, **Frequency** and **FEC** to exactly match the Base receiver settings.

The message type is automatically determined and matched by the receiver.

Set the **Sensitivity** = **High** which will maximize the radio range on some devices.

As the Rover will be receiving corrections, not transmitting, disable the FCC **Call Sign**.

Leave **Retransmit correction data** = **Disabled**.

Click **Next**.


Additional Rover parameters:



Set the **Elevation mask** to a reasonable value, usually between 5 and 15 degrees. Set the Position output frequency to the desired display update rate.

Click **Save & Accept**:

Wait while the receiver is configured:



It will take a few moments to configure the device.

Once corrections are being received, LandStar may note:



The TxRx LED:



should blink once each second if corrections are received. If the receiver is FIXED, the LED will blink green; if the receiver is not fixed, the LED will blink amber.