

7-INCH AUDIO/VIDEO RECEIVER iLX-W670

EN

FR

ES













QUICK REFERENCE GUIDE GUIDE DE RÉFÉRENCE RAPIDE GUÍA DE REFERENCIA RÁPIDA

Please register your product at www.alpine-usa.com/registration to protect your purchase. Enregistrez-vous sur www.alpine-usa.com/registration pour protéger votre achat. Registre su producto en la dirección www.alpine-usa.com/registration para proteger su compra.



About the Rules of Bluetooth Electromagnetic Radiation Regulation

FCC/IC CAUTION

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

USA/Canada

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement émet une énergie RF très faible qui est considérée conforme sans évaluation de l'exposition maximale autorisée (MPE). Cependant, il est souhaitable qu'il devrait être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

Contents

WARNING	2
CAUTION	3
Getting Started	4
Apple CarPlay Operation (Optional)	6
Android Auto™ (Optional)	6
Radio Operation	7
USB Flash drive Operation (Optional)	
SiriusXM® Satellite Radio Operation (Optional)	
iPod mode on iPhone (Optional)	9
Hands-Free Phone Control	10
Camera Operation (Optional)	
Installation	12
Connections	14
Specifications	16

IMPORTANT

Please record the serial number of your unit in the space provided below and keep it as a permanent record.

ERIAL NUMBER:	_
NSTALLATION DATE:	
NSTALLATION TECHNICIAN:	
PLACE OF PURCHASE:	

For details on all functions, refer to the Owner's Manual published on our website at http:// www.alpine-usa.com. If required, an ALPINE dealer will readily provide you with a print out of the Owner's Manual published on the website.



This symbol means important instructions. Failure to heed them can result in serious injury or death.

INSTALL THE PRODUCT CORRECTLY SO THAT THE DRIVER CANNOT WATCH TV/VIDEO UNLESS THE VEHICLE IS STOPPED AND THE EMERGENCY BRAKE IS APPLIED.

It is dangerous for the driver to watch TV/Video while driving a vehicle. Installing this product incorrectly enables the driver to watch TV/Video while driving. This may cause a distraction, preventing the driver from looking ahead, thus causing an accident. The driver or other people could be severely injured.

DO NOT WATCH VIDEO WHILE DRIVING.

Watching the video may distract the driver from looking ahead of the vehicle and cause an accident.

DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.

Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISES WHILE DRIVING.

Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident. LISTENING AT LOUD VOLUME LEVELS IN A CAR MAY ALSO CAUSE HEARING DAMAGE.

MINIMIZE DISPLAY VIEWING WHILE DRIVING.

Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident.

DO NOT DISASSEMBLE OR ALTER.

Doing so may result in an accident, fire or electric shock.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.

Failure to do so may result in fire or electric shock.

DO NOT BLOCK VENTS OR RADIATOR PANELS.

Doing so may cause heat to build up inside and may result in fire.

USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.

Use for other than its designed application may result in fire, electric shock or other injury.

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.

Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.



This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HALT USE IMMEDIATELY IF A PROBLEM APPEARS.

Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing.

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.


DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

Getting Started

Controls Position

The screen design used in the Quick Reference Guide may differ from the actual screen.



\bigcirc -/+(DOWN/UP) button

Touch to adjust the volume. Touch and hold this button for at least 1.7 second to adjust the volume to maximum or minimum.

2 (MUTE) button

Touch to activate/deactivate the mute mode. Touch and hold this button for at least 1.7 second to display on/off.

(HOME)/(Power Off) button

Activates the HOME screen.
Touch and hold this button for at least 1.7 second to turn the power off.

4 / (Phone) button

Activates the Phone screen.

5 Ubutton

When phone is connected to CarPlay, touch this button to activate Siri.

When phone is connected to Android Auto, touch this button to activate VR.

When Siri is activated, the function of Siri is available When VR is activated, the VR setting is ON and the function of VR is available.

When the CarPlay/Android Audio is disconnected, the operation in this button is invalidate.

When CarPlay/Android Audio is disconnected, touch and long hold to enter into the Device Searching List to activate the new device searching.

6 (Reset) button

Reset & Restart.

Turning Power On or Off

1 Turn the ignition key to the ACC or ON position.

The system is turned on.

- 2 Touch and hold the ******* (HOME) button for at least 1.7 seconds to turn the power off.
- When the system is used for the first time, the language selection menu is displayed. Select the desired language, and then touch [OK].

About the HOME Screen

Select a widget on the HOME screen to perform various settings and operations of the function.

Touch the **(HOME)** button.
The HOME screen is displayed.

■ HOME screen example





Radio	Displays the Radio main screen.
Apple CarPlay	You can use Apple CarPlay. • If compatible iPhone is not connected to usb, this widget is not available.
Android Auto	You can use Android Auto. • If compatible Android phone is not connected to usb, this widget is not available.
USB	You can play back music files, video files and photo files stored in a USB flash drive. • If a USB flash drive is not connected, this widget is not available.
iPod	Displays the iPod main screen. • If an iPhone is not connected, this widget is not available.
SiriusXM	Displays the SiriusXM main screen. • If a SiriusXM Tuner (Optional) is not connected, this widget is not available.
Bluetooth Audio	Displays the Bluetooth audio main screen.
Phone	Displays the Phone main screen.
AUX	Displays the AUX main screen. • If there is no input signal on AUX, it will be a black screen.
Camera	Displays the Camera main screen. • If there is no input signal on Camera, it will be a black screen.

Apple CarPlay Operation (Optional)

Apple CarPlay is a smarter, safer way to use your iPhone in the car. Apple CarPlay takes the things you want to do with your iPhone while driving and puts them right on this unit. You can get directions, make calls, send and receive messages, and listen to music, all in a way that allows you to stay focused on the road. Just plug in your iPhone to this unit and go.

Touch the **!!!** (HOME) button.

The HOME screen is displayed.

2 Touch [Apple CarPlay].

The Apple CarPlay screen is displayed.

• Refer to "Apple CarPlay" in the Owner's Manual for information on how to operate Apple CarPlay.

Owner's manual

Android Auto™ (Optional)

Android Auto™ (Optional)

Android Auto is designed to make it easier to use apps from your phone while you're on the road. Navigate with Google Maps, listen to Playlists or Podcasts from your favorite apps, send messages via voice, and more. Download the Android Auto App from the Google Play Store before continuing.

1 Touch the !!! (HOME) button.

The HOME screen is displayed.

2 Touch [Android Auto].

The Android Auto screen is displayed.

• Refer to "Android Auto" in the Owner's Manual for information on how to operate Android Auto.

Radio Operation




• The patterns of some keys in the Quick Reference Guide may differ from the actual screen.

Owner's manual USB Flash drive Operation (Optional)

USB Flash drive Operation (Optional)

You can play back music files (WAVE.WMA.AAC.MP3.OGG.FLAC.APE), video files (AVI, MPEG 1/2, MPEG4, WMV, Flash, QuickTime, ASF, Matroska Video, TS Stream, 3GP) and photo files (JPG, JPEG, PNG, BMP) stored in a USB flash drive on the internal player of this system.

USB Audio main screen example




• The patterns of some keys in the Quick Reference Guide may differ from the actual screen.

SiriusXM® Satellite Radio Operation (Optional)

When an optional SiriusXM Tuner is connected to this unit, the following operations may be performed.

SiriusXM main screen example



• The patterns of some keys in the Quick Reference Guide may differ from the actual screen.


iPod mode on iPhone (Optional)

Before using this function, plug in your iPhone using a Lightning-USB cable (supplied with iPhone) to the unit.

The following devices have been tested and shown to work with this unit. Correct function of earlier versions cannot be guaranteed.

iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone SE (3rd generation), iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6 Plus, iPhone 6

iPod main screen example



Searching for a Music File

For example: Searching by Artist name

- 1 Touch [Q (Search)] during playback.
- 2 Touch [Artists].



Touch the desired artist's name.



- 4 Touch the desired album's name.
- 5 Touch the desired song's name.

The selected song is played back.

Hands-Free Phone Control

The unit can connect with up to two hands-free phones.

How to connect to a Bluetooth compatible device (Pairing)

To display the Setup HOME screen:

- 1. Bring your vehicle to a complete stop at a safe location. Engage the parking brake.
- 2. Release the parking brake. (For safety, release the parking brake while depressing the foot brake pedal).
- 3. Engage the parking brake again.
- For automatic transmission vehicles, place the transmission lever in the Park position.
- Touch the (HOME) button.
 The HOME screen is displayed.
- 2 Touch [Bluetooth Audio].



3 Touch [□].



4 Touch [Q (Search)] to search for a new device.



5 Touch the device you want to connect from the list.



6 The device registration is complete.



- You can register up to 5 Bluetooth compatible mobile phones.
- The Bluetooth registration process differs depending on the device version and SSP (Simple Secure Pairing). If a 4 or 6 character Numeric Comparison appears on this system, enter the Numeric Comparison on the Bluetooth device.
- If a 6 character Passkey appears on this system, make sure the same passkey is displayed on the Bluetooth device, and follow the screen.

Answering a Call

An incoming call triggers the ringtone and an incoming call display.



2 Touch [**/**] (Call).

The call starts.



Hanging up the Telephone

1 Touch [[(End Call).

The call finishes.

Calling

Entering a Phone Number to Make a Call

1 Touch **₩** [Keypad].

The number input screen (Keypad) appears.



Touch [☒] to delete an entered number.

- 2 Enter the phone number you wish to call.
 - You can enter up to 20 digits.
- **3** Touch [**√**] (Call).

The phone call is started.

Making a phone call from the Recent Events list

Touch [2] to change to the Recent Events list screen.



Touch the name of the contact or number you want to call.

The phone call is started.

Calling from the Contacts list (Phone Book)



- Touch [] to change to the Contacts list screen.
- Touch the name of the contact or number you want to call.
- **3** Touch the phone number.

The Phone Operation screen is displayed.



4 Touch the number you want to call.

The phone call is started.

Owner's manual

Camera Operation (Optional)

Camera Operation (Optional)

Displaying the Camera Image from the Menu screen

1 Touch the !!! (HOME) button.

The HOME screen is displayed.

2 Touch [Camera].


Touch the screen while the camera image is being displayed, and touch [X] to return to the main source screen or previous screen.




Installation

Note on installation

 Install at an angle between horizontal and 30°. Note that installing at an angle outside of this range will result in a loss of performance and possible damage.



• Do not block the unit's heat sink, which would prevent air circulation. If blocked, heat will accumulate inside the unit and may cause a fire.




Mounting the Microphone

For safe use, make sure of the following:


- Location is stable and firm.
- Driver's view and operations are not obstructed.
- Microphone is located where the driver's voice can be easily picked up (on the sun visor, etc.).

When you speak into the microphone, you should not have to change your driving posture. This may cause a distraction, taking your attention away from safely driving your vehicle. Carefully consider direction and distance while mounting the microphone. Confirm that the driver's voice can be easily picked up at the selected location.



Installing the Unit

1 Mount the original mounting bracket to the unit using the supplied screws.




- 2 Connect all other leads of the unit according to details described in the "Connections" (page 14).
- **3** Mounting the unit in a car.

To securely connect the ground lead, use an already installed screw on a metal part of the vehicle (marked (\star)) or a clean, bare metal spot on the vehicle's chassis.

• Fix the cables carefully. Do not damage them by tucking them into movable parts, such as a seat rail, or by locating them against sharp or pointed edges.


Connection Diagram of SPST Switch (sold separately)

(If the ACC power supply is not available)



- If your vehicle has no ACC power supply, add an SPST (Single-Pole, Single-Throw) switch (sold separately) and fuse (sold separately).
- The diagram and the fuse amperage shown above are in the case when iLX-W670 is used individually.
- If the switched power (ignition) lead of the iLX-W670 is connected directly to the positive (+) post of the vehicle's battery, the iLX-W670 draws some current (several hundred milliamperes) even when its switch is placed in the OFF position, and the battery may be discharged.

Connections



- 1 Radio Antenna Receptacle
- **2** GPS Antenna Receptacle
- (3) Power Antenna Lead (Blue)

Connect this lead to the +B terminal of your power antenna, if applicable.

- This lead should be used only for controlling the vehicle's power antenna. Do not use this lead to turn on an amplifier or a signal processor, etc.
- (4) Remote Turn-On Lead (Blue/White)

Connect this lead to the remote turn-on lead of your amplifier or signal processor.

5 Parking Brake Lead (Yellow/Blue)

Connect this lead to the power supply side of parking brake switch to transmit the parking brake status signals to the unit.

- 6 Reverse Lead (Violet/White)
- Right Rear (+) Speaker Output Lead (Violet)
- 8 Right Rear (–) Speaker Output Lead (Violet/Black)
- 9 Right Front (+) Speaker Output Lead (Gray)
- 10 Right Front (–) Speaker Output Lead (Gray/Black)
- 11) Left Front (+) Speaker Output Lead (White)
- (12) Left Front (–) Speaker Output Lead (White/Black)
- (13) Left Rear (+) Speaker Output Lead (Green)
- 14 Left Rear (–) Speaker Output Lead (Green/Black)
- 15 Switched Power Lead (Ignition) (Red)

Connect this lead to an open terminal on the vehicle's fuse box or another unused power source that provides (+) 12V only when the ignition is turned on or in the accessory position.

- 16 Fuse Holder (15A)
- (17) Battery Lead (Yellow)

Connect this lead to the positive (+) post of the vehicle's battery.

(18) Ground Lead (Black)

Connect this lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided.

- (19) SPEED SENSOR (Green/White)
- 20 LIGHTING LINK (Brown)
- **SW1 (Black/Brown)**Steering Wheel Control

22 SW2 (Black/Blue)

Steering Wheel Control

23 SWG (Black/White)

Steering Wheel GND

24 REAR CAMERA Input RCA Connector (Black)

Use when connecting a camera with RCA Output Connector.

25 Rear Output RCA Connectors

Can be used as Rear Output RCA Connectors. RED is right and WHITE is left.

26 Front Output RCA Connectors

Can be used as Front Output RCA Connectors. RED is right and WHITE is left.

- **27** Subwoofer RCA Connectors
- 28 AUX INPUT (Black)

Audio and video input.

29 MIC Input Connector

To microphone (included)

30 SiriusXM Tuner Input Connector

To SiriusXM Tuner (sold separately).

- For more information on how to install the SiriusXM Connect Vehicle tuner, consult the installation guide included with the tuner.
- (31) USB Connector

To USB flash drive, iPhone or Android smartphone.

- 32 Power Supply Connector
- 33 CAMERA/SWC PRE OUT/AUX

Specifications

MONITOR SECTION

Screen Size 6.75"

LCD Type Normally white, Transmissive

Operation System a-Si TFT active matrix

Number of Picture Elements 1152000 pcs.

 $(800 \times 480 \times 3(RGB))$

Effective Number of Picture Elements

99% or more

Illumination System LED

FM TUNER SECTION

Tuning Range 87.7 – 107.9 MHz Mono Usable Sensitivity <9 dBu (75 ohms) 50 dB Quieting Sensitivity <5 dBu (75 ohms)

Signal-to-Noise Ratio 65 dB Stereo Separation 35 dB

AM TUNER SECTION

Tuning Range 530 – 1,710 kHz Usable Sensitivity 34 dBu

USB SECTION

USB requirements USB 2.0

Max. Power Consumption 1,500 mA (CDP Support)
USB Class USB (Play From Device)/
USB (Mass Storage Class)

 File System
 FAT16/32, NTFS

 Number of Channels
 2-Channels (Stereo)

 Frequency Response*1
 17 – 20,000 Hz (±1 dB)

 Total Harmonic Distortion
 0.05% (at 1 kHz)

 Dynamic Range
 90 dB (at 1 kHz)

Signal-to-Noise Ratio 85 dB

Channel Separation 75 dB (at 1 kHz)

- 1 Frequency response may differ depending on the encoder software/bit rate.
- Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Apple, iPhone, iPod, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc.
- Use of the Made for Apple and Works with Apple badges means that an accessory has been designed to connect specifically to the Apple product(s) identified in the Made for Apple badge and to work specifically with the technology identified in the Works with Apple badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- Please note that the use of this accessory with an Apple product may affect wireless performance.
- Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone may affect wireless performance.

Bluetooth SECTION

Bluetooth Specification Bluetooth V5.0

Output Power <+4dBm Ave. (Power class 2)
Profile HFP (Hands-Free Profile)

PBAP (Phone Book Access Profile) A2DP (Advanced Audio

A2DP (Advanced Audio Distribution Profile) AVRCP (Audio/Video Remote

Control Profile)

GENERAL

Power Requirement 14.4 V DC

(10.8-15.1 V allowable)

Operating temperature -4°F to +140°F

(-20°C to + 60°C) 16 W RMS × 4*2

Power Output $16 \text{ W RMS} \times 4^{*2}$

- 2 Primary amplifier ratings per CEA-2006 Standard
 - Power output: measured at 4 Ohms and \leq 1% THD+N
 - S/N: 80 dBA (reference: 1 W into 4 Ohms)

Weight 0.9 kg

Audio output level

Preout (Front, Rear): 4V/10k ohms (max.)
Preout (Subwoofer): 4V/10k ohms (max.)

CHASSIS SIZE

Width 178 mm Height 100 mm Depth 68mm

- Due to continuous product improvement, specifications and design are subject to change without notice.
- The LCD panel is manufactured using an extremely high precision manufacturing technology. Its effective pixel ratio is over 99.99%. This means that there is a possibility that 0.01% of the pixels could be either always ON or OFF.
- SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.
- Google, Android, Android Auto, Google Play and other marks are trademarks of Google LLC.
- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Alpine Electronics, Inc. is under license.
- MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson. Supply of this product only conveys a license for private, non-commercial use and does not convey a license nor imply any right to use this product in any commercial (i.e. revenue-generation) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/streaming via internet, intranets and/ or other networks or in other electronic content distribution systems, such as pay-audio or audio-ondemand applications. An independent license for such use is required. For details, please visit http://www.mp3licensing.com



GARANTIE LIMITÉE

Fidèle à son engagement de ne fournir que des produits de qualité, ALPINE ÉLECTRONIQUE DE L'AMÉRIQUE, INC. (« Alpine ») est heureuse de vous offrir cette garantie. Nous vous suggérons de le lire attentivement et en entier. Si vous avez la moindre question, veuillez contacter l'un de nos concessionnaires ou appeler directement Alpine aux numéros listés ci-dessous.

PRODUITS COUVERTS PAR LA GARANTIE

Cette garantie couvre les produits audio de voiture et les accessoires connexes (« le produit »). Elle ne couvre les produits que dans le pays où ils ont été achetés.

DURÉE DE LA GARANTIE

Cette garantie est en vigueur pendant un an à partir de la date du premier achat du client.

PERSONNES PROTÉGÉES PAR LA GARANTIE

Seul l'acheteur original du produit, s'il résisde aux États-Unis, à Porto Rico ou au Canada, peut se prévaloir de la garantie.

• CE QUI EST COUVERT

Cette garantie couvre tous les défauts de matériaux et de fabrication (pièces et main d'œuvre) du produit.

CE QUI N'EST PAS COUVERT

Cette garantie ne couvre pas ce qui suit:

- Les dommages survenus durant le transport des produits renvoyés à Alpine pour être réparés (les réclamations doivent être adressées au transporteur);
- ② Les dégâts provoqués par un accident ou une mauvaise utilisation, y compris des bobines acoustiques grillées suite à une surexcitation des enceintes (augmentation du niveau de l'amplificateur jusqu'à atteindre un effet de distorsion ou d'écrêtage), une défaillance mécanique des enceintes (perforations, déchirures ou fentes), panneaux LCD fissurés ou endommagés, disques durs endommagés ou ayant subi une chute.
- ① Tout dégât provoqué par négligence, usage inapproprié, mauvaise utilisation ou par le non-respect des instructions indiquées dans le manuel de l'utilisateur.
- 4 Les dommages dus à la force majeure, notamment aux tremblements de terre, au feu, aux inondations, aux tempêtes ou aux autres cataclysmes naturels; Les frais ou les dépenses relatifs à l'enlèvement ou à la réinstallation du produit;
- Les services rendus par une personne, physique ou morale non autorisée;
- Les produits dont le numéro de série a été effacé, modifié ou retiré;
- Les produits qui ont été adaptés ou modifiés sans le consentement d'Alpine;
- Les produits qui ne sont pas distribués par Alpine aux Etats-Unis, à Porto Rico ou au Canada;
- Les produits qui n'ont pas été achetés par l'entremise d'un concessionnaire Alpine autorisé;

COMMENT SE PRÉVALOIR DE LA GARANTIE

Il vous faut remettre le produit nécessitant des réparations à un centre de service autorisé Alpine ou à Alpine même et en assumer les frais de transport. Alpine a le choix entre réparer le produit ou le remplacer par un produit neuf ou révisé, le tout sans frais pour vous. Si les réparations sont couvertes par la garantie et si le produit a été envoyé à un centre de service Alpine ou à Alpine, le paiement des frais de réexpédition du produit incombe Alpine.

- ② Vous devez donner une description détaillée des problèmes qui sont à l'origine de votre demande de réparation.
- 3 Vous devez joindre la preuve de votre achat du produit.
- 4 Vous devez emballer soigneusement le produit pour éviter tout dommage durant son transport. Pour éviter la perte de l'envoi, il est conseillé de choisir un transporteur qui propose un service de suivi des envois.

LIMITATION DES GARANTIES TACITES

LA DURÉE DE TOUTES LES GARANTIES TACITES, Y COMPRIS LA GARANTIE D'ADAPTATION À L'UTILISATION ET LA GARANTIE DE QUALITÉ LOYALE ET MARCHANDE, EST LIMITÉE À CELLE DE LA GARANTIE EXPRESSE DÉTERMINÉE CI-DESSUS. PERSONNE N'EST AUTORISÉ À ENGAGER AUTREMENT LA RESPONSABILITÉ D'ALPINE EN VERTU DE LA VENTE D'UN PRODUIT.

EXCLUSIONS DE LA GARANTIE

ALPINE STIPULE EXPRESSÉMENT QU'ELLE N'EST PAS RESPONSABLE DES DOMMAGES-INTÉRÊTS ET DOMMAGES INDIRECTS PROVOQUÉS PAR LE PRODUIT. LES DOMMAGES-INTÉRÊTS SONT LES FRAIS DE TRANSPORT DU PRODUIT VERS UN CENTRE DE SERVICE ALPINE, LA PERTE DE TEMPS DE L'ACHETEUR ORIGINAL, LA PERTE D'UTILISATION DU PRODUIT, LES BILLETS D'AUTOBUS, LA LOCATION DE VOITURES ET TOUS LES AUTRES FRAIS LIÉS À LA GARDE DU PRODUIT. LES DOMMAGES INDIRECTS SONT LES FRAIS DE RÉPARATION OU DE REMPLACEMENT D'AUTRES BIENS ENDOMMAGÉS SUITE AU MAUVAIS FONCTIONNEMENT DU PRODUIT.

LES RECOURS PRÉVUS PAR LES PRÉSENTES EXCLUENT ET REMPLACENT TOUTE AUTRE FORME DE RECOURS.

• LIEN ENTRE LA GARANTIE ET LA LOI

La garantie vous donne des droits spécifiques, mais vous pouvez aussi jouir d'autres droits, qui varient d'un état ou d'une province à l'autre. En outre, certains états et certaines provinces interdisent de limiter la durée des garanties tacites ou d'exclure les dommages accessoires ou indirects. Dans ce cas, les limites et les exclusions de la garantie peuvent ne pas s'appliquer à vous.

CLAUSE APPLICABLE AU CANADA SEULEMENT

Pour que la garantie soit valable, il faut qu'un centre d'installation autorisé ait installé le système audio pour l'auto dans votre véhicule et qu'il ait ensuite apposé son cachet sur la garantie.

• NUMÉROS D'APPEL DU SERVICE À LA CLIENTÈLE

Si vous avez besoin de nos services, veuillez appeler Alpine aux numéros ci-dessous pour le centre de service autorisé Alpine le plus proche.

AUDIO DE VOITURE 1-800-ALPINE-1 (1-800-257-4631) NAVIGATION 1-888-NAV-HELP (1-888-628-4357)

Ou visitez notre site Web à l'adresse http://www.alpine-usa.com



LIMITED WARRANTY

ALPINE ELECTRONICS OF AMERICA, INC. ("Alpine"), is dedicated to quality craftsmanship and are pleased to offer this Warranty. We suggest that you read it thoroughly. Should you have any questions, please contact your Dealer or contact Alpine at one of the telephone numbers listed below.

• PRODUCTS COVERED:

This Warranty covers Car Audio Products and Related Accessories ("the product"). Products purchased in the Canada are covered only in the Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

● LENGTH OF WARRANTY:

This Warranty is in effect for one year from the date of the first consumer purchase.

WHO IS COVERED:

This Warranty only covers the original purchaser of the product, who must reside in the United States, Puerto Rico or Canada.

• WHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor) in the product.

• WHAT IS NOT COVERED:

This Warranty does not cover the following:

- ① Damage occurring during shipment of the product to Alpine for repair (claims must be presented to the carrier).
- ② Damage caused by accident or abuse, including burned voice coils caused by over-driving the speaker (amplifier level is turned up and driven into distortion or clipping). Speaker mechanical failure (e.g. punctures, tears or rips). Cracked or damaged LCD panels. Dropped or damaged hard drives.
- ③ Damage caused by negligence, misuse, improper operation or failure to follow instructions contained in the Owner's manual.
- Damage caused by act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature. Any cost or expense related to the removal or reinstallation of the product.
- Service performed by an unauthorized person, company or association.
- 6 Any product which has the serial number defaced, altered or removed.
- ② Any product which has been adjusted, altered or modified without Alpine's consent.
- 8 Any product not distributed by Alpine within the United States, Puerto Rico or Canada.
- Any product not purchased from an Authorized Alpine Dealer.

● HOW TO OBTAIN WARRANTY SERVICE:

- You are responsible for delivery of the product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option, repair or replace the product with a new or reconditioned product without charge. If the repairs are covered by the warranty, and if the product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges.
- 2 You should provide a detailed description of the problem(s) for which service is required.
- 3 You must supply proof of your purchase of the product.
- You must package the product securely to avoid damage during shipment. To prevent lost packages it is recommended to use a carrier that provides a tracking service.

HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON IS AUTHORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

• HOW WE EXCLUDE CERTAIN DAMAGES:

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. THE TERM "INCIDENTAL DAMAGES" REFERS TO EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHERS COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT. THE TERM "CONSEQUENTIAL DAMAGES" REFERS TO THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. THE REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

HOW STATE/PROVINCIAL LAW RELATES TO THE WARRANTY:

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

• IN CANADA ONLY:

This Warranty is not valid unless your Alpine car audio product has been installed in your vehicle by an Authorized Installation Center, and this warranty stamped upon installation by the installation center.

● HOW TO CONTACT CUSTOMER SERVICE:

Should the product require service, please call the following number for your nearest Authorized Alpine Service Center.

CAR AUDIO 1-800-ALPINE-1 (1-800-257-4631) NAVIGATION 1-888-NAV-HELP (1-888-628-4357)

Or visit our website at; http://www.alpine-usa.com



ALPINE ELECTRONICS MARKETING, INC.

1-7, Yukigaya-Otsukamachi, Ota-ku, Tokyo 145-0067, JAPAN Phone: 03-5499-4531

ALPINE ELECTRONICS OF AMERICA, INC.

1500 Atlantic Blvd, Auburn Hills, Michigan 48326, U.S.A. Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF AUSTRALIA PTY. LIMITED

161-165 Princes Highway, Hallam Victoria 3803, Australia Phone 03-8787-1200

ALPINE ELECTRONICS GmbH

Ohmstraße 4 85716 Unterschleißheim, Germany Phone: 089-32 42 640

ALPINE ELECTRONICS OF U.K., LTD.

Alpine House Fletchamstead Highway, Coventry CV4 9TW, U.K. www.alpine.co.uk

ALPINE ELECTRONICS FRANCE S.A.R.L.

184 allée des Erables CS 52016 – Villepinte 95 945 Roissy CDG cedex FRANCE

Phone: + 33(0)1 48 63 89 89

ALPINE ITALIA S.p.A.

Viale Cristoforo Colombo, 8 20090 Trezzano sul Naviglio MI, Italy Phone +39 02 484781

ALPINE ELECTRONICS DE ESPAÑA. S.A.

Portal de Gamarra 36, Pabellón, 32 01013 Vitoria (Alava)-APDO 133, Spain Phone 945-283588

Take a moment to protect your purchase by registering your product now at www.alpine-usa. com/registration. You will also be updated on product information, special promotions, Alpine news.

Prenez le temps de protéger votre achat en enregistrant votre produit sur www.alpine-usa.com/ registration. Vous recevrez en outre des mises à jours sur des informations de produits, des offres promotionnelles et des nouvelles concernant Alpine.

Le recomendamos que proteja su adquisición registrando su producto lo antes posible en la dirección www.alpine-usa.com/registration. Asimismo, recibirá información sobre productos, promociones especiales y noticias de Alpine.



7-INCH AUDIO/VIDEO RECEIVER iLX-W670

ΕN

FR

ES













- OWNER'S MANUAL Please read before using this equipment.
- MODE D'EMPLOI Veuillez lire avant d'utiliser cet appareil.

• MANUAL DE OPERACIÓN Léalo antes de utilizar este equipo.

Thank you for purchasing this Alpine product. Please take a moment to protect your purchase by registering your product now at the following address: www.alpine-usa.com/registration. You will be informed of product and software updates (if applicable), special promotions, news about Alpine.

Merci d'avoir acheté ce produit Alpine. Nous vous invitons à consacrer un moment à la protection de votre achat en enregistrant votre produit dès maintenant à l'adresse suivante : www.alpine-usa.com/registration.

Vous serez tenu informé des mises à jour des produits et des logiciels (le cas échéant), des promotions spéciales et de l'actualité d'Alpine.

Gracias por adquirir este producto Alpine. Con solo unos pocos pasos podrá proteger su producto, registrándolo a través de la siguiente dirección: www.alpine-usa.com/registration. Recibirá información sobre nuevos productos y software, promociones especiales y novedades sobre Alpine.

Contents	USB Flash drive (Optional) Playback	15
	Fast-forwarding/Fast-reversing	
Operating Instructions	(USB Audio/Video)	15
operating instructions	Repeat Play (USB Audio/Video)	15
	Shuffle Play (USB Audio/Video)	15
PRECAUTIONS	Searching for a Desired Song/Video/Photo	15
IMPORTANT INFORMATION5	Slide Show (USB Photo)	15
2.22 0.22.22 2.22 0.20.22.22 0.20.20.20.20.20.20.20.20.20.20.20.20.20	About USB List	15
WARNING	iPod mode on iPhone (Optional)	
Points to Observe for Safe Usage5	Playback	16
WARNING5	Searching for a Music File	17
CAUTION 6	Repeat Play	17
NOTICE 7	Shuffle Play	17
Getting Started	SiriusXM® Satellite Radio Operation	
Location of Controls9	(Optional)	
Turning Power On or Off9	Receiving Channels with the SiriusXM Tuner	18
Turning the System On9	Tuning Channels by Category	
Adjusting the Volume9	Checking the Sirius XM Radio ID Number	
Lowering Volume Quickly9	Storing Channel Presets	
Touch Screen Operation10	Tuning Channels Using Presets	
About the HOME Screen10	SiriusXM List	
About the Indicator Display11	Selecting The Channel Directly	19
	Parental Lock Function	
Radio	Bluetooth® Operation	
Radio Basic Operation	Setup Before Using	20
Listening to the Radio12	About Bluetooth	
Presetting Stations Manually12	About the Hands-free Phone	
Presetting Stations Automatically12	Before Using Bluetooth	
Mode switching Settings12	Defore Using Diactootii	20
	Hands-free Phone Control	
Apple CarPlay (Optional)	Answering a Call	21
Access to Apple CarPlay13	Hanging up the Telephone	21
Android Auto™ (Optional)	Calling	21
-	Making a phone call using the Phone Menu .	21
What is Android Auto	Siri	22
Activate Android Auto13	Phone Operation Screen	23
	Adjusting the Speech Volume	23
	Changing the Voice Output	23
	DTMF (Touch-Tone) Function	23

Phone Book Function	23	Sound Setup	
Synchronizing the Phone Book	23	Setting the Fader/Balance	3
Bluetooth® Audio		Adjusting the Bass/Middle/Treble	
		Adjusting the Graphic Equalizer	
Playback		Curve (EQ)	34
Repeat Play		Setting an Equalizer	
Shuffle Play	24	Setting the Subwoofer	
AUX Operation (Optional)		Adjusting the Crossover Settings (X-Over)	
AUX Operation	24	Adjusting the Time Correction (TCR)	3
NON Operation	2T	Setting the Speaker Level	30
Camera Operation (Optional)		Setting Defeat	30
Camera Operation	25	About the Crossover	30
Displaying the Camera Image		About Time Correction	3
from the Menu screen	25	Example 1. Listening Position:	
Displaying the rear view video		Front Left Seat	3
while the car is in reverse	25	Example 2. Listening Position: All Seats	37
About the Rear Camera Guide	25	Volume Setup	
Sound Boost and Lighting link (Op	tional)	Volume Setup	31
		volume Setup	50
Lighting Link Setting Operation		Bluetooth Setup	
Lighting Link settings Colors	2/	Device List	3
Setup		Pairing the Bluetooth Device	
Setup Operation	28	Fast pairing the Bluetooth Device	
		Deleting a Bluetooth Device from the list	
System Setup		Searching for a Bluetooth Device	
Language Setup	28	Displaying Bluetooth Information	
Time Adjust Setup	29	Auto Connection	
SiriusXM Setup	29	Downloading the Phonebook	39
Parental Control	29		
Clear Locked All	29	Rear Camera Setup	
Changing the Lock Passcode	29	Parking Guide Adjust Setup	39
Version	30	Video Setup	40
Product Information	30	Italian Italian/OFF	
Updating the firmware version	30	Lighting Link ON/OFF	
Software License	30	Information	
Connection Status	30		4
SWC Adapter	31	About the Supported Formats	
Steering Wheel Control	31	About Audio Format	
DEMO MODE	32	About Video Format	
Reset	32	About Photo Format	
Caroon/lighting Catura		In Case of Difficulty	
Screen/Lighting Setup		If this Message Appears	
Dimmer		Specifications	4
Screen Color			
Key Color	33		

Installation and Connections

WARNING	48
CAUTION	48
Precautions	48
Accessory List	49
Installation	49
Caution concerning the installation	
location	49
Mounting the Microphone	49
Installation example using the Original	
Mounting Bracket	49
Connections	50
If an ACC power supply is not available	52
System Example	53
OFM Steering Wheel Control Rentention	54

LIMITED WARRANTY

Operating Instructions

PRECAUTIONS

IMPORTANT INFORMATION

FCC COMPLIANCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide more reasonable protection against harmful interference in a residential installation, and are more stringent than "outdoor" requirements.

Operation is subjected to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an experienced radio/TV technician.

WARNING

Points to Observe for Safe Usage

- Read this manual carefully before using this system components. They contain instructions on how to use this product in a safe and effective manner. Alpine cannot be responsible for problems resulting from failure to observe the instructions in this manual.
- This manual uses various pictorial displays to show you how
 to use this product safely and to alert you to potential dangers
 resulting from improper connections and operation. Following are
 the meanings of these pictorial displays. It is important to fully
 understand the meanings of these pictorial displays in order to use
 this manual and the system properly.
- This product may be used with software applications. Please follow all usage instructions and warnings when using this product at all times. Do not use this product or any software application in a manner which will hinder safe operation of your vehicle.

\triangle w

WARNING

- Operation of the system while driving is dangerous. Users should stop vehicle before operating the software.
- Road conditions and regulations take precedence over information contained on the map display: observe actual traffic restrictions and circumstances while driving.
- This software is designed for use exclusively in the unit.
 It cannot and may not be used in conjunction with other hardware.



WARNING

This symbol means important instructions. Failure to heed them can result in serious injury or death.

INSTALL THE PRODUCT CORRECTLY SO THAT THE DRIVER CANNOT WATCH TV/VIDEO UNLESS THE VEHICLE IS STOPPED AND THE PARKING BRAKE IS APPLIED.

It is dangerous for the driver to watch TV/Video while driving a vehicle. Installing this product incorrectly enables the driver to watch TV/Video while driving. This may cause a distraction, preventing the driver from looking ahead, thus causing an accident. The driver or other people could be severely injured.

DO NOT WATCH VIDEO WHILE DRIVING.

Watching the video may distract the driver from looking ahead of the vehicle and cause an accident

DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.

Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISES WHILE DRIVING.

Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident. LISTENING AT LOUD VOLUME LEVELS IN A CAR MAY ALSO CAUSE HEARING DAMAGE.

MINIMIZE DISPLAY VIEWING WHILE DRIVING.

Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident.

DO NOT DISASSEMBLE OR ALTER.

Doing so may result in an accident, fire or electric shock.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.

Failure to do so may result in fire or electric shock.

DO NOT BLOCK VENTS OR RADIATOR PANELS.

Doing so may cause heat to build up inside and may result in fire.

USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.

Use for other than its designed application may result in fire, electric shock or other injury.

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY

Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING **OBJECTS.**

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.



This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HALT USE IMMEDIATELY IF A PROBLEM APPEARS.

Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing.

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

NOTICE

Product Cleaning

Use a soft dry cloth for periodic cleaning of the product. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

Temperature

Be sure the temperature inside the vehicle is between +45°C (+113°F) and 0°C (+32°F) before turning your unit on.

Maintenance

If you have problems, do not attempt to repair the unit yourself. Return it to your Alpine dealer or the nearest Alpine Service Station for servicing.

Protecting the USB connector

- Only an Phone or USB flash drive can be connected to the USB connector on this unit. Correct performance using other USB products cannot be guaranteed.
- If the USB connector is used, be sure to use only the supplied connector cable with the unit. A USB hub is not supported.
- Depending on the connected USB flash drive, the unit may not function or some functions may not be performed.
- The audio file format that can be played on the unit is MP3/ WMA/WAVE/AAC/FLAC/Ogg/APE.
- Artist/song name, etc., can be displayed. Certain, special characters may not be correctly displayed.



CAUTION

Alpine accepts no responsibility for lost data, etc., even if data, etc., is lost while using this product.

On Handling USB Flash drive


- This unit can control a memory storage device that supports the USB Mass Storage Class (MSC) protocol. Playable audio file formats are MP3, WMA, AAC, WAVE, APE, OGG and FLAC.
- USB Flash drive function is not guaranteed. Use a USB flash drive according to the terms of agreement. Read the USB flash drive Owner's Manual thoroughly.
- Avoid usage or storage in the following locations:
 Anywhere in the car exposed to direct sunlight or high temperatures.
 - Anywhere the possibility of high humidity or corrosive substances are present.
- Fix the USB flash drive in a location where driver operation will not be hindered.
- USB Flash drive may not function correctly at high or low temperature.
- Use only certified USB flash drive. Note that even certified USB flash drive, may not function correctly depending on its type or state
- Depending on the settings of the USB flash drive type, memory state or encoding software, the unit may not play back or display properly.
- USB Flash drive may take time to start playback. If there is a
 particular file other than audio in the USB flash drive, it may
 take considerable time before the file is played back or searched.
- The unit can play back"mp2", "mpa""mp3" m4a", "wma", "m4a", "flac"/"fla", "wav" "ogg" ape"file extensions.
- Do not add the above extensions to a file other than audio data. This non-audio data will not be recognized. The resulting playback may contain noise that can damage speakers and/or amplifiers.
- It is recommended to back up important data on a personal computer.
- Do not remove the USB device while playback is in progress.
 Change SOURCE to something other than USB, then remove the USB device to prevent possible damage to its memory.

- Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Apple, iPhone, iPod, iPod nano, iPod touch, iPad, Lightning and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc.
- Use of the Made for Apple and Works with Apple badges means
 that an accessory has been designed to connect specifically to the
 Apple product(s) identified in the Made for Apple badge and to
 work specifically with the technology identified in the Works with
 Apple badge, and has been certified by the developer to meet Apple
 performance standards. Apple is not responsible for the operation of
 this device or its compliance with safety and regulatory standards.
- Please note that the use of this accessory with an Apple product may affect wireless performance.
- Use of the Apple CarPlay logo means that a vehicle user interface meets
 Apple performance standards. Apple is not responsible for the operation
 of this vehicle or its compliance with safety and regulatory standards.
 Please note that the use of this product with iPhone may affect wireless
 performance.
- SiriusXM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.
- Google, Android, Google Play and Android Auto are trademarks of Google LLC. To use Android Auto on your car display, you'll need an Android Auto compatible vehicle or aftermarket stereo, an Android phone running Android 6.0 or higher, and the Android Auto app.
- The Bluetooth* word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Alpine Electronics, Inc. is under license.
- MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS
 and Thomson. Supply of this product only conveys a license for private,
 non-commercial use and does not convey a license nor imply any right
 to use this product in any commercial (i.e. revenue-generation) real
 time broadcasting (terrestrial, satellite, cable and/or any other media),
 broadcasting/streaming via internet, intranets and/or other networks
 or in other electronic content distribution systems, such as pay-audio or
 audio-on-demand applications. An independent license for such use is
 required. For details, please visit
 http://www.mp3licensing.com

Getting Started

Location of Controls

When system is powered off ,Short/long touch any button to turn the power on.



-/ + (DOWN/UP) button

Touch to adjust the volume.

Touch and hold this button for at least 1.7 second to adjust the volume to maximum or minimum

2 k (MUTE) button

- Touch to activate/deactivate the mute mode.
- Touch and hold this button for at least 1.7 second to display on/off

(HOME)/(Power Off) button

Activates the HOME screen.

Touch and hold this button for at least 1.7 second to turn the power off.

4 _J(Phone) button

Activates the Phone screen.

(5) | button

- When phone is connected to CarPlay, touch this button to activate Siri
- When phone is connected to Android Auto ,touch this button to activate VR
- When Siri is activated, the function of Siri is available
- When VR is activated, the VR setting is ON and the function of VR is available
- When the CarPlay/Android Audio is disconnected ,the operation in this button is invalidate
- When CarPlay/Android Audio is disconnected, touch and long hold to enter into the Device Searching List to activate the new device searching

(5) (Reset) button

Reset& Restart.

About the button descriptions used in this Owner's Manual

The buttons found on the face of the unit are expressed in bold (e.g. $\blacksquare \blacksquare \blacksquare \blacksquare (HOME))$. The buttons found on the touch-screen display are shown in bold within brackets, [] (e.g. [\times]).

Turning Power On or Off

Some of this unit's functions cannot be performed while the vehicle is in motion. Be sure to stop your vehicle in a safe location and apply the parking brake, before attempting these operations.

Turn the ignition key to the ACC or ON position. The system turns on.

 When turned on, the system displays the last screen that was displayed before the ignition key was turned off. For example, if the unit is in radio mode when ignition is turned off, it will remain in radio mode when ignition is turned back on.

2 Touch and hold the **** (HOME)/(Power Off) button for at least 1.7 second to turn the power off.

- When the system is used for the first time, the language selection menu is displayed. Select the desired language, and then touch [OK].
- The unit can be turned on by touching the [[] [] (HOME) button,
- [] button [♣] button [№] button or [_] (Phone) button.

 The unit is a precision device. Careful handling of the unit should provide you with years of trouble-free operation.

Turning the System On

When the system is used for the first time, the language selection menu is displayed.

Select a language, and then touch [OK].



 Some of this unit's functions cannot be performed while the vehicle is in motion. Be sure to stop your vehicle in a safe location and apply the parking brake before attempting these operations.

Adjusting the Volume

Adjust the volume by touching -/+

Volume decreases increases continuously by touching and holding -/ \clubsuit

Volume: 0 - 35

voidine. 0 33

Lowering Volume Quickly

Audio Mute function instantly lowers the volume level to 0.

- Touch the (MUTE) button to activate the MUTE mode.
 The audio level will be 0.
- Touching the (MUTE) button again will bring the audio back to its previous level.

Touch Screen Operation

You can operate the system by using the touch panel on the screen.

• Be sure to touch the onscreen button lightly with the pad of your finger to avoid scratching the display.

Touch a button or list item on the screen lightly.



About the HOME Screen

In the HOME screen, you can select the audio source and perform various setups or operations on the unit.

Touch the HEE (HOME) button.

The HOME screen is displayed.

■ HOME screen example (Page1)



■ HOME screen example (Page2)



Radio	Displays the Radio main screen (page 12).	
Apple CarPlay	You can use Apple CarPlay (page 13).	
Android Auto	You can use Android Auto (page 13).	
USB	You can play back music files, video files and photo files stored in a USB flash drive (page 14). If a USB flash drive is not connected, this widget is not available.	
iPod	Displays the iPod main screen (page 16) If an iPhone is not connected, this widget is not available.	
SiriusXM	Displays the SiriusXM main screen (page 18). • If a SiriusXM Tuner (Optional) is not connected, this widget is not available.	
Bluetooth Audio	Displays the Bluetooth Audio main screen (page 23).	
Phone	Displays the Phone main screen (page 23).	
AUX	Displays the AUX main screen (page 24).	
Camera	Displays the Camera main screen (page 25).	

About the Indicator Display

The Indicator Bar at the top of the screen displays various types of information, like the current time.



- ① Sound Boost.
 - You can turn the Sound Boost (page 26).
- ② Lights up when connected to a Bluetooth compatible device
 - · Sets ash when Bluetooth disconnected
- ③ Indicates the battery level of the connected Bluetooth device.

Battery Level	Level 3	Level 2	Level 1	No Battery
Icon	(III			Ш

This may not be displayed depending on the connected Bluetooth device.

(4) Indicates the signal strength level of the connected Bluetooth compatible device. Displayed when Bluetooth setting is ON.

0	1	2	3	4	5
ıll	ıll	ιII	ıll	dl	-111

- (5) Indicates the current time.
 - You can switch between the 12 hour display and 24 hour display options (page 29).
- 6 Setup
 - Click to enter the Settings
- 7 Display SiriusXM signal level

0	1	2	3
14.1	\$4.1	\$4.1	16.1

8 Indicates the volume on/off status.

Radio

Radio main screen example



- Band button Switches a band.
- 2 Preset button

Displays the preset stations with a short touch.

Touch for at least 1.5. second to memorise the current station as a preset station.

- 3 Plays each preset station for about 10 seconds.
- (4) Scan and memorises active stations automatically
- (5) Touch [] [] to select the station seek up or seek down respectively

Touch [◀] [▶] to change the radio frequency up or down respectively.

Operate in manual mode

6) Switch Local mode/Manual mode/DX mode

Seek up [🙌]

Seek up: From the current station ,seek forward according to the specified step unit ,

After selecting a active station, then play If no active station, will keep searching

Seek down [🛶]

Seek down: From the current station ,seek down according to the specified step unit ,

After selecting a active station, then play If no active station, will keep searching

Radio Basic Operation

Listening to the Radio

- 1 Touch the ******** (HOME) button and select radio mode. The display shows the radio mode screen.
- 2 Select the desired band from [FM1] / [FM2] / [FM3] / [AM1]/[AM2].
- 3 Touch [胸間], [胸間] [间], [胸] to adjust the radio frequency.

Presetting Stations Manually

- Tune in a desired radio station you wish to store in the preset memory by manual or automatic seek tuning.
- Touch and hold the Preset number you want to store for at least 1.5 second.

The selected station is stored.

Repeat the procedure to store up to 5 other stations onto the same band.

To use this procedure for other bands, simply select the desired band and repeat the procedure.

A total of 30 stations can be stored in the preset memory (6 stations for each band; FM1, FM2, FM3, orAM1,AM2).

If a preset memory has already been set in the same preset number, it
will be cleared and the new station will be memorized.

Presetting Stations Automatically

From the start Frequency ,scan upon the step unit (+1) and store the validated station ,After one cycle, store the station from low frequency to high frequency

Touch [A.MEMO] go to Scan for stations and store valid stations

 If a valid station is scanned, it is not required to play, the screen display "scanning" during the scanning process and will automatically switch to the first stored station on FM1

Mode switching Settings

Setting item:

Manual/DX(Initial setting)/Local

Setting contents:

Manual mode:manually scanning station

DX mode: When select the DX mode and start to search, it will be performed until the next or previous valid station, if no valid station is searched, the search continues

Local mode: When select the local mode and start to search ,it will be performed until the next or previous valid station, if no valid station is searched, the search continues

• :By default, Dx mode is used. The Local mode stop sensitivity is increased by 30db over Dx under AM and FM

Apple CarPlay (Optional)

Apple CarPlay is a smarter, safer way to use your iPhone in the car. Apple CarPlay takes the things you want to do with your iPhone while driving and puts them right on the unit. You can get directions, make calls, send and receive messages, and listen to music, all in a way that allows you to stay focused on the road. Just plug in your iPhone to the unit and go.

- Before using this function, plug in your iPhone using Lightning to USB Cable (Supplied with iPhone) to the unit.
- Some functions may not be available while driving.
- About iPhone models usable with this unit, see "iPod mode on iPhone (Optional)" (page 16). Only an iPhone 6 or later compatible with Apple CarPlay function.

Access to Apple CarPlay

Touch the HOME button.
The HOME screen is displayed.

2 Touch [Apple CarPlay].

The Apple CarPlay screen is displayed.

Touch the desired App icon on the unit, or use Siri function by touching the
button.

- When a used iPhone 6 or later is reconnected, touch the pop-up message-"Apple CarPlay connected." within 5 seconds to access to Apple CarPlay screen.
- The App must be Apple CarPlay compatible in order to appear in the Home screen.

Android Auto™ (Optional)

What is Android Auto

Android Auto is designed to make it easier to use apps from your phone while you're on the road. Navigate with Google Maps, listen to Playlists or Podcasts from your favorite apps, and more.

Activate Android Auto

Download the Android Auto App from the Google Play Store before continuing.

Just plug in your smartphone to the unit's USB connector, then follow the prompt to pair your smartphone with the unit.

- The connected smartphone with Android Auto will disconnect other phone's Bluetooth connection and pair to the unit.
- Touch the (HOME) button.
 The HOME screen is displayed.
- Touch [Android Auto].
 The Android Auto screen is displayed.
- You can make a call, use voice recognition function and Android Auto's compatible navigation app, etc,.
- Only Google approved apps with necessary driver-safety measures in place can be used.

USB Flash drive (Optional)

You can play back music files (WAVE.WMA.AAC.MP3.OGG.FLAC. APE), video files (AVI,MPEG 1/2,MPEG4,WMV,Flash,QuickTime,ASF, Matroska Video,TS Stream,3GP) and photo files (JPG,JPEG,PNG,BMP) stored in a USB flash drive on the internal player of this system.

⚠ WARNING

It is dangerous for the driver to watch video while driving the vehicle. The driver may be distracted from looking ahead and an accident could occur.

Install the unit correctly so that the driver cannot watch a video unless the car is stopped and the parking brake is applied.

If the unit is not installed correctly, the driver will be able to watch a video while driving and may be distracted from looking ahead and cause an accident. The driver or other people could be severely injured.

USB Audio mode screen



USB Video mode screen



USB Photo mode screen



- 1 Artwork display
- (2) Information display
- (3) Elapsed time/Total time for playing
- (4) Displays the USB List screen
- (5) Shuffle mode
- (⑥ [☐] repeat_off, [☐] repeat_folder, [☐] repeat_one, [☐] repeat_all,
- Finds the beginning of next chapter//Fast-forwards when touched for at least 2 second
- 8 Pause and Play
- (9) Finds the beginning of the current file/Finds a previous file within 1 second after playback starts/Fast-reverses when touched for at least 2 second
- (10) Video information display
- (1) Video Setup display
- (12) Photo information display
- 13) Rotate mode
- For your safety, video is not displayed and only audio can be heard while driving.

Playback

- Touch the HIM (HOME) button and select USB mode. The display shows the USB mode screen.
- **2** Touch [Q] (Search).
- 3 Select the desired mode.

: USB Audio mode

- : USB Video mode
- : USB Photo mode
- 4 Touch [] or [] to select the desired track(file).

Returning to the beginning of the previous track (file):

Touch [

Fast reverse the current track:

Touch and hold 2s [

Advancing to the beginning of the next track (file):

Touch [

Fast forward the current track:

Touch and hold 2s [].

To pause playback, touch []].

Touching [] again will resume playback.

- The playback time may not be correctly displayed when a VBR (Variable Bit Rate) recorded file is played back.
- If there is tag information, artist name/album name/track name is displayed.
- If there is no label information, no name is displayed.
- ID3 tag/WMA tag

If an MP3/WMA/AAC/FLAC/WAVE/Ogg/APE file contains ID3 tag/ WMA tag information, the ID3 tag/WMA tag information is displayed. (e.g., song name, artist name, and album name)

Fast-forwarding/Fast-reversing (USB Audio/ Video)

During playback, touch and hold [[神] (Fast-reverse) or touch and hold [神] (Fast-forward).

Touch and hold for more than 2 second to fast-forward/fast-reverse.

- · Fast-reverse Speed:
 - touch [\blacksquare] to change the speed, $x4 \rightarrow x10 \rightarrow x32 \rightarrow off$
- Fast-forward Speed:

touch [] to change the speed, $x4 \rightarrow x10 \rightarrow x32 \rightarrow off$

Repeat Play (USB Audio/Video)

- **1** Touch [□].
 - The [] button displays the currently selected mode.
- 2 Select your desired Repeat mode.

ALL :: All files are repeatedly played back.

One 📇: Only the file currently playing is repeatedly played back.

Folder 📇: Only files in a folder are repeatedly played back.

OFF 📑: Repeat mode is Off.

Shuffle Play (USB Audio/Video)

- **1** Touch [⊃ζ].
 - The [] button displays the currently selected mode.
- 2 Shuffle mode is only valid in [💭] [😅] [
- When in [🗂] touch [💢], automatically switch [🛴].

Searching for a Desired Song/Video/Photo

- **1** Touch [ℚ] (Search).
- 2 Select the desired mode.

🗖 : USB Audio mode

■ : USB Video mode

: USB Photo mode

- 3 Touch [] or [] to select the folder.
- 4 Touch your desired File name.

When you select a Folder name, repeat the same procedure to select another Folder name or File name.

Slide Show (USB Photo)

The Slide Show shows photos that change every 5 seconds.

To pause playback, touch [|]

Touching [] again will resume playback.

About USB List

You can select the desired mode

 Each page displays up to 5 files. if you want to view more than 5 files, swipe down or touch alphabet to search

About order

Display and sort according to the head character

Display in the order of $1 \rightarrow 2 \rightarrow 3$ below.

- 0: Folder: When there are folders ,the folders are displayed ahead of the files
- 1: Number (represented by "#" on the Right Search Bar)
- 2: English Alphabet
- 3: Shorting order of Unicode

Right Search Bar (order of list)

- 1: Number (represented by "#" on the Right Search Bar)
- 2: English Alphabet
- Search only the files with numeric or English alphabetic headers

iPod mode on iPhone (Optional)

Before using this function, plug in your iPhone using a Lightning-USB cable (supplied with iPhone) to the unit,

- This unit does not support video playback from iPhone which connected to this unit via USB Connector.
- Internet or telephone function, etc., of the iPhone is not controllable from the unit, but these functions can be controlled using the iPhone itself.

About iPhone models usable with this unit

 The following devices have been tested and shown to work with this unit. Correct function of earlier versions cannot be guaranteed.

iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone SE (3rd generation), iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 65 Plus, iPhone 65, iPhone 66, iPhone 67 Plus, iPhone 66, iPhone 67 Plus, iPhone 67 Plus, iPhone 67 Plus, iPhone 67 Plus, iPhone 68 Plus, iPhone 68 Plus, iPhone 69 Plus, iPhon

iPod main screen example



- 1 Artwork display
- ② Information display*
- 3 Elapsed time/Total time for playing Repeat mode
- (4) Displays the iPod List screen
- (5) Shuffle mode
- 🌀 [🚅]repeat_off, [🔁]repeat_one, [🚅]repeat_all,
- Finds the beginning of next chapter/Fast-forwards When touched for at least 2 second
- 8 Pause and Play
- (9) Finds the beginning of the current file/Finds a previous filewithin 1 second after playback starts/Fast-reverses when touched for at least 2 second

Playback

- 1 Touch the ::: (HOME) button and select iPod mode. The display shows the iPod mode screen.
- 2 Touch [] or [] or to select the desired track (file).

Returning to the beginning of the previous track (file):

Touch [].

Fast reverse the current track :

Touch and hold 2s []

Advancing to the beginning of the next track (file):

Touch [].

Fast forward the current track:

Touch and hold 2s [].

- **3** To pause playback, touch [| |]. Touching [| □] again will resume playback.
- If a song is playing on the iPhone before it is connected to the unit, it
 will continue playing when it is connected.
- An episode may have several chapters. The chapter can be changed by touching [] or [].
- If the artist, album or song name, created in iTunes, has too many characters, songs may not be played back when connected to the unit. Therefore, a maximum of 255 characters is recommended. The maximum number of characters for the unit is 255.
- Some characters may not be correctly displayed.

^{*} Podcast mode.

Searching for a Music File

<Music Search Menu>

Hierarchy 1	Hierarchy 2	Hierarchy 3	Hierarchy 4
Radio	_	_	_
Playlists	Songs	_	_
Artists	Albums	Songs	_
Albums	Songs	_	_
Songs	_	_	_
Genres	Artists	Albums	Songs
Composers	Albums	Songs	_
Podcasts	Episodes	_	_
Audiobook	_	_	_

For example: Searching by Artist name

The following example explains how an Artists search is performed.



- **1** Touch [ℚ] (Search) during playback.
- **Touch [Artists].**The Artists search screen is displayed.
- 3 Select the desired artist.
- 4 Touch the desired album's name.
 All songs of the selected album are displayed
- 5 Touch the desired song's name. The selected song is played back.
- If you touch [$\dot{\mathbf{q}}$], the category browsing mode screen is displayed.

Repeat Play

- **1** Touch [□].
 - The [] button displays the currently selected mode.
- 2 Select your desired Repeat mode.

ALL :: All files are repeatedly played back.

One :: Only the file currently playing is repeatedly played back.

OFF : Repeat mode is Off.

Shuffle Play

- 1 Touch [💢].
 - The [📆] button displays the currently selected mode.
- 2 Shuffle mode is only valid in[,] [] [].
- **3** When in [➡] touch [➡], automatically switch[➡].

SiriusXM® Satellite Radio Operation (Optional)

SiriusXM Tuner operation:

When an optional SiriusXM Tuner is connected to this unit, the following operations may be performed.

SiriusXM main screen example



- Band button Switches a band.
- 2 Tune Select the specified channel manually
- ③ Information display channel name, Artist Basic, Song Basic, Cat name
- (4) Preset buttons

Displays the preset channels with a short touch. Touch for at least 1.5 second to memorize the current channel as a preset channel.

Select the channel number

- (5) Displays the SiriusXM setup screen
- (6) Displays the SiriusXM List screen
 - 🔄 All channel:Displays all channel
 - Category:Select channel category
 - : Tune:Select the specified channel manually
- (7) Changes to the next channel
- (8) Changes to the previous channel

Receiving Channels with the SiriusXM Tuner

About SiriusXM Satellite Radio

Only SiriusXM brings you more of what you love to listen to, all in one place. Get over 140 channels, including commercial-free music plus the best sports, news, talk, comedy and entertainment. Welcome to the world of satellite radio. A SiriusXM Vehicle Tuner and Subscription are required. For more information, visit www.siriusxm.com.

In the USA, you can activate online or by calling SiriusXM Listener

- · Visit www.siriusxm.com/activatenow
- Call SiriusXM Listener Care at 1-866-635-2349

For Canadian Subscriptions, please contact:

- Visit www.siriusxm.ca/activate
- Call SiriusXM Customer Care at 1-888-539-7474
- The SiriusXM Satellite Radio controls on this unit are available only when a SiriusXM Tuner is connected.
- 1 Touch the (HOME) button and select SiriusXM mode. The display shows the SiriusXM mode screen.
- Touch [►] to select the desired channel. Touching and holding either button will rapidly browse through the channels.
- Refer to the SiriusXM Tuner User Guide for details on how to install the SiriusXM Tuner.

Tuning Channels by Category

Channels are grouped into categories based on the type of content heard on the channels.

- Touch [♣] or [♣] to select the category browsing mode. The channels within the category of the current channel are listed.
- Category browsing mode screen example



2 Select the desired channel.

Checking the Sirius XM Radio ID Number

To subscribe to the SiriusXM Satellite Radio service, it is necessary to locate and identify the Radio ID of your SiriusXM Tuner. You can check the Radio ID on the bottom surface of the SiriusXM Tuner box. You can also check it from this unit by performing the following procedure.

While receiving SiriusXM Radio, touch [⋈] or [▶] to select channel "0".

The unit displays the Radio ID number.

- 2 To cancel the Radio ID number display, change the channel to a channel other than "0".
- The SiriusXM Radio ID does not contain the letters I, O, S, or F.

Storing Channel Presets

You can store 18 of your favorite SiriusXM channels for easy recall with Preset buttons.

- 1 Long press the Preset number you can store the channel. A maximum of 6 channels can be displayed on a page.
- 2 Repeat the procedure to store up to 17 other channels.
 A total of 18 channels can be stored in the preset memory.
- If you store a new channel into a preset which already has a channel assigned, the current channel will be cleared and replaced with the new one.

Tuning Channels Using Presets

Touch any one of the Preset numbers you have already stored in the Preset mode screen.

The preset channel is received.

SiriusXM List

1 Touch [=].
The list screen appears.

List item:All Channels / Category Name*/Tune

- * The Category name for the channel currently being received is displayed.
- You can switch the category by touching [] or [] on the List screen after selecting a Search item.

List by ALL Channel

2 Touch [与].

All Channels will be displayed in a list.

3 Touch the selected channel.

The channel you selected is received.

Searching by Category

2 Touch Category Name.

The channels within the category of the current channel are listed.

3 Touch the selected channel.

The channel you selected is received.

Selecting The Channel Directly

- Touch [] or [] .

 The numeric keypad input screen is displayed.
- 2 Touch to input the channel number.
- 3 Touch [OK].

The selected channel is received.

Parental Lock Function

The Parental Control feature allows you to limit access to any SiriusXM channels, including those with mature content. When enabled, the Parental Control feature requires you to enter a passcode to tune to the locked channels. For information on setting the Parental Control passcode, see "Parental Control" (page 29).

When a locked channel is selected, "Channel [xxx] Locked" is displayed and then the numeric keypad appears for you to enter the passcode.

Input the 4-digit passcode you set in "Parental Control" (page 29).

The initial number is 0000.

- If you input a wrong passcode, "Incorrect Pass Code entered" is displayed
- After entering the correct passcode, you can access all locked channels without entering the passcode again until the unit is powered off and then back on.

Bluetooth® Operation

Setup Before Using

About Bluetooth

Bluetooth is a wireless technology allowing communication between a mobile device or personal computer over short distances. This enables a hands-free call or data transmission between Bluetooth compatible devices. Bluetooth transmission is available in the unlicensed 2.4 GHz spectrum if the distance between devices is within 10 meters. For details, refer to the Bluetooth website (http://www.bluetooth.com/).

- Depending on the Bluetooth version, a Bluetooth compatible device may not be able to communicate with this unit.
- Proper function of this unit with all Bluetooth compatible devices is not guaranteed. For handling of the Bluetooth compatible device, consult your Alpine dealer or Alpine website.
- Depending on the surroundings, Bluetooth wireless connection may be unstable.
- When you place a call, or perform setup operations, be sure to stop your car in a safe place.
- Depending on the connected Bluetooth compatible device(s), the function may differ. Also refer to the Owner's Manual of the connected device(s).

About the Hands-free Phone

Hands-free calls are possible when using a HFP (Hands-Free Profile) compatible mobile phone with this unit.

- Avoid performing a hands-free call in heavy traffic or on narrow or winding streets.
- · Close the windows while calling to reduce background noise.
- If both calling parties are using hands-free devices, or the call is made in a noisy location, difficulty hearing the other person's voice is normal.
- Depending on telephone line conditions or certain mobile devices used, voices may sound unnatural.
- When using a microphone, speak as directly as you can into the microphone to obtain the best sound quality.
- Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality.
 Always contact your service provider about feature availability and

All features, functionality, and other product specifications, as well as the information contained in the Owner's Manual are based upon the latest available information and are believed to be accurate at the time of printing.

Alpine reserves the right to change or modify any information or specifications without notice or obligation.

Before Using Bluetooth

Before using the hands-free phone/audio function, the following settings need to be made.

Register a Bluetooth device in this unit.

- · See "Bluetooth Setup" (page 38).
- You can search for this unit using a Bluetooth compatible device, and then connect that Bluetooth compatible device to this unit. The device name of this unit is "iLX-W670" and the initial number of the passcode is "0000." Also refer to the Owner's Manual of the connected device(s).


Hands-free Phone Control

Touch [Bluetooth] in the HOME screen to display the Bluetooth menu screen.



[Phone] button

■ Phone menu screen example



Recent Events list

You can display up to 100 items, such as phone numbers of the most recent incoming calls, missed calls and outgoing calls, and contact names that are registered in the Phone Book. When 100 items exist in the list, the oldest item is deleted when a further item is to be added.

Contacts list

You can make a phone call from the Phone Book, or edit the

Keypad screen

Use to type a phone number.

Answering a Call

- 1 An incoming call triggers the ringtone and an incoming call display.
- Phone Incoming screen example



Touch [__i] (Call).
The call starts.



- 1 Touch[]Display Keypad screen
- ② Touch switch Car speaker[] Or Phone speaker[]
- 3 Touch switch mute on/off
- (4) Adjust the volume level
- During a call, the audio for the current mode on the unit is muted.
 After calling, playback will resume.
- When the caller's number is transmitted to the system, if the caller's name is stored in the phone book, the name is displayed. If the name is not stored, the number is displayed.
- Touch [Decline] to reject an incoming call.

Hanging up the Telephone

Touch [] End Call.
The call finishes.

Calling

Making a phone call using the Phone Menu

Entering a Phone Number to Make a Call

Touch ## [Keypad].
The number input screen (Keypad) appears.



Touch [⟨█] to delete an entered number.

- 2 Enter the phone number you wish to call.
 - You can enter up to 20 digits.
- Touch [__1] (Call).
 The phone call is started.
- To change the Bluetooth device, see "Bluetooth Setup" (page 38).

Making a phone call from the Recent Events list

1 Touch [...] to change to the Recent Events list screen.



2 Touch the name of the contact or number you want to call.

The phone call is started.

Calling from the Contacts list (Phone Book)



- 1 Touch [| _ =] to change to the Contacts list screen.
- 2 Touch the name of the contact or number you want to call.

3 Touch the phone number.

The Phone Operation screen is displayed.



4 Touch the number you want to call.

The phone call is started

Siri

Establish iPhone Bluetooth connection and wake up Siri from phone , below interface will pop up and the voice output is from the unit.



Phone Operation Screen



Adjusting the Speech Volume

Changing the Voice Output

The voice output for calls is switchable between car speakers and the mobile phone speaker.

Touch [📢 🖟] or [🖳].

DTMF (Touch-Tone) Function

Transmits a DTMF (Touch-Tone) during a call.

Touch [i] (Keypad).

The number input screen (Keypad) appears.

2 Input number.

You can transmit a Touch-Tone signal during a call.

Phone Book Function

Phone Book screen example



- 1) Use to narrow down your search for names, etc.
- You can synchronize the system's phone book with the mobile phone's phone book.

Synchronizing the Phone Book

Touch [*]].

Synchronization of the phone books starts.

- You can store up to 1,000 registered name in the phone book.
- You can store up to 5 phone numbers by one person's name.

Bluetooth® Audio

If a Bluetooth compatible mobile phone, portable player, etc. is connected by wireless, you can play back a song (operation is controllable from the unit).

• Operation may vary, depending on the Bluetooth compatible device

Bluetooth Audio main screen example



- 1 Default image display
- Information display
- (3) Elapsed time/Total time for playing
- 4 Search device
- (5) Shuffle mode
- [□]repeat_off,[□]repeat_folder,[i □]repeat_one,
 [□]repeat_all
- (7) Finds the beginning of next chapter
- (8) Pause and Play
- (9) Finds the previous file
- Song title/Artist title/Album title/Elapsed time do not display for AVRCP Ver. 1.0.
- To play back audio, a mobile phone or a portable player conforming to A2DP (Advanced Audio Distribution Profile) or AVRCP (Audio/Video Remote Control Profile) is required.
 - Not all functions work with all devices.
- During a call, sound on the Bluetooth audio source is paused.

Compatible AVRCP versions: 1.0, 1.3, 1.4, 1.5, 1.6.2

· Available functions may differ depending on the AVRCP version.

Playback

Touch the ::: (HOME) button and select Bluetooth Audio mode.

The display shows the Bluetooth Audio mode screen.

2 Touch [] or [] to select the desired track (file).

Returns the beginning of the previous file:

Touch [].

Advance to the beginning of the next file:

Touch [

3 To pause playback, touch []].

Repeat Play

Available for AVRCP Ver. 1.0, 1.3, 1.4, 1.5, 1.6.2.

1 Touch [□].

• [] displays the currently selected mode.

2 Select your desired Repeat mode.

The selected Repeat mode changes the button.

ALL 📩: Once all of the songs have finished playing, play back is repeated, starting with the first song.

One :: Only the track currently playing is repeatedly played back.

OFF : Repeat mode is Off.

 Operations may differ depending on the connected Bluetooth compatible device.

Shuffle Play

Available for AVRCP Ver. 1.0, 1.3, 1.4, 1.5, 1.6.2.

Touch [💢].

- All songs in the Bluetooth compatible devices are played back in random sequence. Any one song does not play back again until all songs have been played back.
- Operations may differ depending on the connected Bluetooth compatible device.

AUX Operation (Optional)

AUX Operation

- Through AUX connection, you can display the videos or images output from other devices
- For safety, video image can not be displayed when vehicle is moving.
 To view the video image, please stop in a safe zone and apply the parking brake.
- A mini AV cable is required to make the connection (sold separately)
 Further details are given in << Installation Manual>>

AUX screen example



- 1 Touch [......].
- **2** Touch [AUX] Display AUX screen

Camera Operation (Optional)

Camera screen example



Setting item

Display Reverse video

Setting contents:

Camera Guide Off (Initial setting) / On

 No impacts on other modes (except video ,video shall be suspended, When playing the audio, the audio shall continue playing), Switch to this scree, other modes to run in the background

Camera Operation

Displaying the Camera Image from the Menu screen

Touch the (HOME)button.
The HOME screen is displayed

2 Touch [Camera].

- Touch the screen while the camera image is being displayed, and touch
 [X] to return to the main source screen or previous screen.
- You can perform a Guide Adjustment for the rear view image. For details, see "Rear Camera Setup" (page 39).


Displaying the rear view video while the car is in reverse

- Shift the gear lever to the reverse (R) position. The rear view image is displayed while the car remains in reverse.
- 2 If you shift the gear lever to a position other than reverse (R), the monitor returns to the previous screen.
- Never depend solely on the camera when backing up. Always turn and look and only use the camera for additional assistance.
- This function is effective when the reverse wire is properly connected.
- You can perform a Guide Adjustment for the rear view image. For details, see "Rear Camera Setup" (page 39).

About the Rear Camera Guide

Indication mark meaning

When the car is put into reverse gear, the monitor switches to the rear view camera image. Guides appear to help visualize the car's width and distance from the rear bumper.



Car width extension marks (red, yellow and green in order of distance)

If properly calibrated, the marks indicate the car's width. This helps guide the car's path when backing up in a straight line.

The marks represent the distance from the rear of the car (from the rear end of the bumper).

- The marks do not move in synchronization with the steering wheel.
- · Set the marks to suit the car's width.
- Depending on the condition of the car or road surface, the range of vision may vary.
- The camera has a limited range of vision. Objects at extreme angles to the camera (e.g. under the bumper or at opposite ends of the bumper) may not be in the its field-of-vision.
- The rear camera image may have a tint which is different from the actual surroundings.
- Depending on the car, the guidance may deviate to the right or left. This
 is not a malfunction.

Sound Boost and Lighting link (Optional)



- (1) Current screen On/Off
- ② Sub.Woofer On/Off Linkage with the Settings in sound (page 35)
- 3 Adjust Sub.Woofer Level Linkage with the Settings in sound (page 35)
- Sub.Woofer Phase Linkage with the Settings in sound (page 35) 0° (Initial setting), 180°
- (5) Lighting Link setting can change the LED color of the system model, the keyColor of this unit, and the background color in tandem.
- 6 Displays sound setup icon touch the icon to sound setup screen
- Max Mid Bass On/Off Linkage with the Settings in sound (page 33)
- Max Bass On/Off
 Linkage with the Settings in sound (page 33)
- If Lightinglink is OFF in the settings, this icon will not be displayed (page 40).

Lighting Link Setting Operation

When operating the Lighting color of the system model with Lightinglink, it is necessary to connect a model that supports Lightinglink. Check the Alpine website for compatible models.

- 1 Touch [::::].
- **2** Touch [▼]Display Sound Boost screen
- 3 Touch [] Display Lighting Link screen

Lighting Link screen example



1 LED On/Off

LED OFF: Premium Direct Color and LED Brightness and LED Lighting Speed, Other Color is grayed out and cannot be selected. And the Lighting of the connected system turns off.

- ② Select Premium Direct Color Blue,Red,Amber,Green,White Each Lighting color changes in conjunction. Please refer to page 27 for the changed parts and their colors.
- 3 Adjust LED Brightness Adjusts the brightness level of the LEDs on Lightinglinkenabled models -3 - +3 Initial: 0
- (4) Adjust LED Light Blinking Speed
- Select Other Color Select Premium Direct Color or Dynamic mode

LED Brightness

Adjusts the brightness level of the LEDs on Lightinglink-enabled models

Setting item:

LED Brightness

Setting contents:

-3~+3,0(Initial setting)

LED Lighting Speed

Adjusts the level of LED Light Blinking Speed for Lightinglink compatible models

Setting item:

LED Lighting Speed

Setting contents:

-5~+5,0(Initial setting)

Other Color



 Please connect the Lighting Link compatible model with the lighting level and speed setting values set to 0.

Lighting Link settings Colors

• Lighting Link has 8 modes.

Lighting Link Setting Colors	Premium Direct color select					Other colors	Dynamic Mode	LED OFF
	Red	Blue	Green	Amber	White	7 colors	Mode	
Lighting Link & Sound boost background, Sub.W Ring Color	Red	Blue	Green	Amber	White	Rainbow1	Rainbow2	-
Key Color*	Red	Blue	Green	Amber	White	White	White	select
Background Screen Color*	Red	Blue	Green	Amber	White	White	White	User

• Lighting Link System model is option.

^{*} key Color and Background Screen Color is linked when Lighting Link is ON. Please see page 33.

* If you select a color with the Lighting Link function, it will all change to the selected color pattern regardless of the current color settings for each.

^{*} BackgroundScreen color and keyColor can be changed individually after setting Lighting Link (page 33).

Setup

Setup Operation

To display the Setup Menu screen:

Your vehicle must be parked with the ignition key in the ACC or ON position. To do this, follow the procedures below.

- 1 Bring your vehicle to a complete stop at a safe location. Engage the parking brake.
- 2 Release the parking brake. (For safety, release the parking brake while depressing the foot brake pedal).
- 3 Engage the parking brake again.
- For automatic transmission vehicles, place the transmission lever in the Park position.
- "Sound Setup" (page 33) can be set even not engaging the parking brake.

Now, the locking system for the Setup operation has been released. Engaging the parking brake can reactivate the Setup Menu, as long as the car's ignition has not been turned off. It is not necessary to repeat the above procedure (1 through 3).

Each time the ignition is turned OFF, perform the above procedure.

1 Touch the (HOME) button.

The HOME screen is displayed.

[Setup] button



2 Touch a [Setup]button.

The Setup main screen is displayed.



Scroll Bar

* Touch [🔤] or [🐷] to show further hierarchies.



Touch the required setting list, then touch the setting item.

Setting items:

System: See "System Setup" (page 28).
Screen/Lighting: See "Screen//Lighting Setup" (page 32).
Sound: See "Sound Setup" (page 33).
Volume: See "Volume Setup" (page 38).
Bluetooth: See "Bluetooth Setup" (page 38).
Rear Camera: See "Rear Camera Setup" (page 39).
Lighting Link ON/OFF: See "Lighting Link" (page 40).

System Setup

[System] is selected on the Setup menu screen.

Setting item:

Svstem

Setting contents:

Beep, Language, Time Adjust, Sirius XM, Product Information, Software License, Connection Status, SWC Adapter, Steering Wheel Control, Demo Mode, Reset



Beep Setup

You can change the volume of the sound heard when a button is touched.

Setting item:

Веер

Setting contents:

Off, On (Initial setting)

Language Setup

[Language] is selected on the System Setup Menu screen. The Setup menu, feedback information, etc. for this unit can be changed to appear in the selected language.

Setting item:

Language


Setting contents:

English (US),French,Spanish,Portuguese

• The currently selected language is displayed.

Time Adjust Setup

[Time Adjust] is selected on the System Setup Menu screen.



Time Format

Settina item:

Time Format

Setting items:

12h, 24h(Initial setting)

Time Zone

Setting item:

Time Zone

Setting contents

UTC-12.00h~UTC+14.00

Daylight saving Time ON/OFF


Setting item:

Daylight saving Time

Setting contents

Off (Initial setting), On

SiriusXM Setup



Change Passcode

Setting item:

Change Passcode

Setting contents:

Edit the passcode.

- 1 Enter the current passcode and then touch [OK].
- **2** Enter the new passcode and then touch [OK].
- 3 Enter the confirm passcode and then touch [OK].

Parental Control

You can lock out channels with passcode protection. Channels that are locked cannot be accessed without entering the passcode. You can unlock a channel or change the passcode using this menu option.

Settina item:

Parental Lock On/Off

1 Touch [Parental Control].

A passcode input screen is displayed.

Touch the numeric keypad to input a 4-digit passcode
The initial default 4-digit passcode is set to 0000.

After entering the digit, it is displayed as " \blacksquare ". Touch [Clear] to delete all entered numbers.

3 Touch [OK].

The channels list screen is displayed.

Setting the Lock status of individual channels

- 4 Touch [Channels].
 - To lock the channel, touch the appropriate channel.
 - When you touch the locked channel, the channel is unlocked.
 appears and the channel is locked.

Clear Locked All

Setting item:

Clear Locked All

Setting contents:

Off (Initial setting) / On

- $\bullet \quad \textit{Touch the switch,} enter \textit{the current pass} code \textit{then touch [OK]}.$
- All stations will be cleared when Off. Locking again will change to ON automatically

Changing the Lock Passcode

Touch [Change Passcode].

The numeric keypad screen is displayed.

2 Use the keypad to enter the current (old) 4-digit passcode, and then touch [OK].

The initial passcode is set to "0000."

After entering the digit, it is displayed as

Touch [Clear] to delete all entered numbers.

- 3 Use the keypad to enter the new 4-digit passcode, and then touch [OK].
- 4 Use the keypad to enter the new 4-digit passcode a second time to verify it, and then touch [OK].

Remember to keep a note of the passcode in a safe place in case you forget the code.

Version



Setting item:

Version

Setting contents:

Model Brand, Model Number, Firmware Ver, HW Version.

Product Information



Setting item:

Model Number, MCU, SOC, Interface FW Version, Interface HW Version

Updating the firmware version




- 1 Download the firmware update file into your computer.
- Inset a USB with FAT32 format into your computer, copy the correct upgrade file to the root directory
- 3 Connect the USB storage device to this product.
- 4 Touch [setup]>[System setup]>
 [Product Information]>[Update].
 The firmware update file information will be read
- **5** After readingTouch[Update]

Follow the on-screen prompts to update the firmware.

- This product will reset automatically after the firmware update is completed if the update is successful.
- · If an error message on the screen, Repeat the preceding steps

Software License

[Software License] Displaying the open source software license.




Connection Status



GPS Antenna

- Display when there is an antenna [OK]
- Display without antenna [NOK]



Positioning Status

- Display [position]: When there is positioning
- Display [Not Available]: When there is no positioning
- Display [Not Connected]: When the serial port of the GPS module is not available

Installation

- Install and learn to successfully display [OK],
- No learning success display [NOK]

Speed Pulse

 Display pulse number "XXX" in unit time, and display "0" if not obtained.

SWC Adapter



Setting item:

SWC Adapter

Setting contents:

With Adapter (Initial setting)/ Without Adapter



With Adapter

- Select [With Adapter] from setup>System>SWC Adapter
- Fixed SWC is valid, learning SWC is invalid "Steering Wheel Control" button is grayed out and invalid
- After selecting the "With Adapter", the learned "Steering Wheel Control" Settings are cleared (Check with Third Party for compatible adapters.)

Some Vehicles may require a 3rd party module to achieve steering wheel control functions (Sold Separately)

Without Adapter

- Select [Without Adapter] from setup>System>SWC Adapter
- Fixed SWC is invalid, learning SWC is valid "Steering Wheel Control" button is valid
- After selecting the "Without Adapter", the "Steering Wheel Control" Settings are highlighted and can be clicked to access the Settings

Steering Wheel Control



Setting item:

Steering Wheel Control key learning

Setting contents:

- ¶ 1 Vol. Up/ ¶ · Vol. Dn, □ 1 ON HOOK, OFF HOOK, Seek Up, Seek Dn, ℚ MUTE, Ⅱ Play/pause, 収 Voice Recognition, Source (Mode)
- Please press and hold key for 2s at the same time don't press SWC key within 2s
- **2** Follow the on-screen prompts to complete the operation
- **3 Key Learning Success:** When operation finished ,If you want to continue other key learning , please repeat the operation
- Please perform key learning while parked with e-brake active.
- Keys only support learning 1 time. If you need to change the key please clear all learned keys.
- Touch the clear key to clear all the learned function.
- No time limit for key learning.

DEMO MODE

[**Demo Mode**] The images of the demo mode are pre stored in flash. Execute loop playback, replace images every 8 seconds.

Setting contents:

On,Off(Initial setting)

Entry condition

1 No operation screen within 120 seconds
If any situation occurs that causes page switching, button operation, or
touch operation, restart the timer after 120 seconds

Exit condition

- 1 During the playback of the demo mode, if it causes page switching, button operation, or touch operation, the demo mode will ston
- 2 In driving, if the demo mode is running, it stops running and returns to the previous mode
- · Recommend switching it off when installing it on your vehicle

Reset

[Reset] is selected on the System Setup Menu screen. You can initialize all data, to restore the factory settings.

Setting item:

Reset

Touch [Reset].

2 After the confirmation message appears, touch [Yes]. The system starts initialization.

 Do not turn on/off the power, change the ignition key position or until system restart is completed.

Screen/Lighting Setup



Setting item:

Screen/Lighting

Setting contents:

Dimmer, Screen Brightness (Day), Screen Brightness (Night), Screen Color, Key Color

Dimmer

You can set day, night and auto three modes in dimmer

- 1. The screen backlighting brightness can be set in day/night mode
- Auto Mode adjusts the backlighting brightness to the appropriate day/night brightness setting value based on the current ambient brightness

Setting contents:

Day, Night, Auto (Initial setting)

Dav:

The backlight brightness is adjusted by setting the screen brightness setting(Day)

Night:

The backlight brightness is adjusted by setting the screen brightness setting(night)

Auto:

Automatically adjust the backlight brightness and select the Screen brightness(Day) or Screen Brightness (Night) setting value as the backlight brightness value based on the Day/Night lighting threshold

Screen Brightness(Day)

Setting item:

Level

Setting contents:

1 to 32

Screen Brightness(Night)


Setting item:

Level

Setting contents:

1 to 32

Screen Color



Setting item:

Background Picture

Setting contents:

You can set blue, red, amber, green, white five colors or other background pictures, you can also select the background picture to be set from the USB flash drive

Setting item:

Background custom

- Insert a USB flash drive.
- 2 Touch [to the Wallpaper screen.
- **3** Select the custom picture.

Setting item:

Color Link (Key/Screen)

Setting contents:

Color link ON (Initial setting)

 You can select ON/OFF whether the button light and background picture linkage.

Key Color



Setting item:

Key Color

Setting contents:

blue, red, amber, green, white

- · Key color Settings can be set blue, red, amber, green, white five colors
- When the Color Link is ON, key Color is grayed out and cannot be selected
- When the Lighting Link function is used, that selection takes precedence and all colors are switched (page 27).
- You can change the Key Color individually after selecting the color with the Lighting Link function.

Sound Setup

[Sound] is selected on the Setup menu screen. You can set up items related to the sound quality. <Setting item>

Fader/Balance (page 33)
Bass/Treble (page 34)
EQ Setting (page 34)
Preset EQ (page 34)
X-Over (page 35)
Speaker Level (page 36)
Time Correction (page 35)
Sub Woofer (page 35)
Defeat (page 36)

* Touch [\blacksquare] or [\blacksquare] to show further .

Setting the Fader/Balance



- Back Exit[Fader/Balance]Return [SOUND].
- Close
- Close the current screen and return to the source screen
- ③ Fader/Balance Image area Touch the desired point within the image area, or touch [◄], [►], [▲] or ▼].

Fader:

[15]Front to [15]Rear

Balance:

[15]Left to [15]Right

• To reset to the initial setting (Fader: F=R, Balance: L=R), touch [-].

Adjusting the Bass/Middle/Treble



Touch [+] or [-] for each item to be adjusted.

Setting item:

Bass, Middle, Treble

Setting contents:

- -12 to 12 (Initial setting: 0)
- To reset the initial setting (Bass: 0, Middle: 0, Treble: 0), touch [Flat].
- When the Defeat setting is [On], you cannot perform the set up.


Adjusting the Graphic Equalizer Curve (EQ)

Setting item:

ΕO

• When the Defeat setting is [On], you cannot perform the set up.

1 Adjust the EQ to your preference.



Adjusting the Band

Touch [Band] to select the band to be adjusted.

 $Band1 \rightarrow Band2 \rightarrow \cdots \rightarrow Band8 \rightarrow Band13 \rightarrow Band1$

• You can select a band directly by touching the screen.

Adjusting the Frequency

Touch of "Frequency" to adjust the frequency of the selected band

Adjustable frequency bands:

Band1: 50 Hz Band2: 80 Hz Band3: 125 Hz Band4: 200 Hz Band5: 315 Hz Band6: 500 Hz Band7: 800 Hz Band8: 1.25k Hz Band9: 2k Hz Band10: 3.15k Hz Band11: Band12: Band13: 12.5k Hz

Adjusting the Level

1 Select Band Slide up or down to adjust the level of selected band.

Setting contents:

-12 to 12 (Initial setting: 0)

- To adjust another band, repeat step 1, and adjust all bands.
- To store the adjusted setting value, touch and hold [Preset 1], [Preset 2], or [Preset 3] for at least 2 seconds.
- Band2, Band7 and Band12 are the same as the Bass and Middle controls. For details on setting Bass and Treble, see "Adjusting the Bass/ Middle/Treble" (page 34).
- · Settings exceeding the frequency of adjacent bands are not available
- While adjusting the EQ Setting, you should consider the frequency response of the connected speakers.
- When you apply the adjusted Band in the EQ setting screen, Preset EQ (page 34) is unselected
- Touch [Flat] to initialize all values.

Calling the EQ Setting adjusted value

Calling the pre-set EQ Setting adjusted value.

Touch [Preset 1], [Preset 2], or [Preset 3] on the EQ Setting screen.

The setting stored in the Preset will be recalled.

Setting an Equalizer

6 typical equalizer settings are preset at the factory for a variety of musical source material. You can also preset an equalizer by customizing.



Setting item:

Preset EQ

Setting contents:

Flat (Initial setting), Hip Hop/R&B, Rock, Easy Listening, Pop, Bass Boost Mid Bass Boost

- When the Defeat setting is [On], you cannot perform the set up.
- Only one type can be set.
- you can set [preset1/preset2/preset3] in the EQ setting screen. (page 34)
- When you set [preset1/preset2/preset3] in the EQ setting screen.(page 34). Preset EQ is unselected

Setting the Subwoofer



Turning Subwoofer ON/OFF

If an optional subwoofer is connected to the unit, make the following setting.

Setting item:

Sub Woofer

Setting contents:

Off (Initial setting), On

Adjusting the Subwoofer Level

Setting item:

Level

Setting contents:

0 (Initial setting) to 15

• This setting is only available when "Sub Woofer" is set to [On].

Setting the Subwoofer Phase

The subwoofer output phase is toggled Subwoofer Normal (0°) or Subwoofer Reverse (180°) .

Setting item:

Phase

Setting contents:

0° (Initial setting), 180°

• This setting is only available when "Sub Woofer" is set to [On].

Adjusting the Crossover Settings (X-Over)

Before performing the following procedures, see "About the Crossover" (page 36).



Selecting the Front HPF

Setting item:

Front HPF

Setting contents:

Off (Initial setting)/25/32/40/50/63/80/100/125/160/200/250 Hz

Selecting the Rear HPF

Setting contents:

Rear HPF

Setting contents:

Off (Initial setting)/25/32/40/50/63/80/100/125/160/200/250 Hz

Selecting the LPF

Setting contents:

LPF

Setting contents:

Off (Initial setting)/25/32/40/50/63/80/100/125/160/200/250 Hz

• This setting is only available when "Sub Woofer" is set to [On].

Adjusting the Time Correction (TCR)

Before performing the following procedures, see "About Time Correction" (page 37).



Setting item:

TCR

Touch [-] or [+] for each speaker to adjust the time .

0.0 msec to 10.0 msec (0.1 msec/step)

 If the Subwoofer setting is [Off], the Subwoofer setting cannot be edited (page 35).

Setting the Speaker Level

Setting item:

Speaker Level



Touch [—] or [+] for each speaker to adjust the Speaker.
-24dB to 10dB (0.1 dB/step)

Setting Defeat

If Defeat is **[On]**, the EQ and Equalizer setting are turned Off. This disables any settings made for these functions.

Setting item:

Defeat

Setting contents:

Off (Initial setting) / On

About the Crossover

Crossover (X-Over):

This unit is equipped with an active crossover. The crossover limits the frequencies delivered to the outputs. Each channel is controlled independently. Thus, each speaker pair can be driven by the frequencies for which they have been optimally designed.

The crossover adjusts the HPF (high pass filter) or LPF (low pass filter) of each band.

Adjustments should be made according to the reproduction characteristics of the speakers. Depending on the speakers, a passive network may not be necessary. If you are unsure about this point, please consult your authorized Alpine dealer.

25 Hz, 32Hz, 40Hz, 50Hz, 63Hz, 80Hz

	Cut-off frequency			
	HPF	LPF		
Subwoofer (LPF)		25Hz, 32Hz, 40Hz, 50Hz, 63Hz, 80Hz 100Hz, 125Hz, 160Hz, 200Hz, 250Hz		
Rear speaker (HPF)	25Hz, 32Hz, 40Hz, 50Hz, 63Hz, 80Hz 100Hz, 125Hz, 160Hz, 200Hz, 250 Hz			
Front speaker (HPF)	25Hz, 32Hz, 40Hz, 50Hz, 63Hz, 80Hz 100Hz, 125Hz, 160Hz, 200Hz, 250Hzz			

- HPF (high pass filter): Cuts the lower frequencies and allows the higher frequencies to pass.
- LPF (low pass filter): Cuts the higher frequencies and allows the lower frequencies to pass.
- Do not use a tweeter without the HPF on or set to a low frequency, as it
 may cause damage to the speaker due to the low frequency content.
- Adjustment should be made according to the recommended crossover frequency of the connected speakers. Determine the recommended crossover frequency of the speakers. Adjusting to a frequency range outside that recommended may cause damage to the speakers.
 For the recommended crossover frequencies of Alpine speakers, refer to the respective Owner's Manual.

We are not responsible for damage or malfunction of speakers caused by using the crossover outside the recommended value.


About Time Correction

The distance between the listener and the speakers in a car vary widely due to the complex speaker placement. This difference in the distances from the speakers to the listener creates a shift in the sounds image and frequency characteristics. This is caused by the time delay between the sound reaching the listener's right versus the left ear.

To correct this, this unit is able to delay the audio signal to the speakers closest to the listener. This effectively creates a perception of increased distance for those speakers. The listener can be placed at an equal distance between the left and right speakers for optimum staging. The adjustment will be made for each speaker in 3.4 cm steps.

Example 1. Listening Position: Front Left Seat

Adjust the time correction level of the front left speaker to a high value and the rear right to zero or a low value.



The sound is not balanced because the distance between the listening position and the various speakers is different.

The difference in distance between the front left speaker and the rear right speaker is 1.75 m (68-7/8").

Here we calculate the time correction value for the front left speaker in the diagram on the above.

Conditions:

Farthest Speaker – listening position : 2.25 m (88-9/16") Front left speaker – listening position : 0.5 m (19-11/16") Calculation: L = 2.25 m - 0.5 m = 1.75 m (68-7/8") Time correction $= 1.75 \div 343* \times 1,000 = 5.1$ (ms)

In other words, giving the front left speaker a time correction value of 5.1 ms makes it seem as if its distance from the listener is the same as the distance to the farthest speaker.

Time correction eliminates the differences in the time required for the sound to reach the listening position.

The time of the front left speaker is corrected by 5.1 ms so that its sound reaches the listening position at the same time as the sound of other speakers.

Example 2. Listening Position: All Seats

Adjust the time correction level of each speaker to almost the same level

- Sit in the listening position (driver's seat, etc.) and measure the distance (in meters) between your head and the various speakers.
- 2 Calculate the difference between the distance correction value to the farthest speaker and the other speakers.

L = (distance to farthest speaker) – (distance to other speakers)

These values are the time correction values for the different speakers. Setting these values to make each sound reach the listening position at the same time as the sound of other speakers.

Time Correction Value List

Time Difference (msec)	Distance (cm)	Distance (inch)	Time Difference (msec)	Distance (cm)	Distance (inch)
0.0	0.0	0.0	5.1	173.4	68.3
0.1	3.4	1.3	5.2	176.8	69.7
0.2	6.8	2.7	5.3	180.2	71.0
0.3	10.2	4.0	5.4	183.6	72.4
0.4	13.6	5.4	5.5	187.0	73.7
0.5	17.0	6.7	5.6	190.4	75.0
0.6	20.4	8.0	5.7	193.8	76.4
0.7	23.8	9.4	5.8	197.2	77.7
0.8	27.2	10.7	5.9	200.6	79.1
0.9	30.6	12.1	6.0	204.0	80.4
1.0	34.0	13.4	6.1	207.4	81.7
1.1	37.4	14.7	6.2	210.8	83.1
1.2	40.8	16.1	6.3	214.2	84.4
1.3	44.2	17.4	6.4	217.6	85.8
1.4	47.6	18.8	6.5	221.0	87.1
1.5	51.0	20.1	6.6	224.4	88.4
1.6	54.4	21.4	6.7	227.8	89.8
1.7	57.8	22.8	6.8	231.2	91.1
1.8	61.2	24.1	6.9	234.6	92.5
1.9	64.6	25.5	7.0	238.0	93.8
2.0	68.0	26.8	7.1	241.4	95.1
2.1	71.4	28.1	7.2	244.8	96.5
2.2	74.8	29.5	7.3	248.2	97.8
2.3	78.2	30.8	7.4	251.6	99.2
2.4	81.6	32.2	7.5	255.0	100.5
2.5	85.0	33.5	7.6	258.4	101.8
2.6	88.4	34.8	7.7	261.8	103.2
2.7	91.8	36.2	7.8	265.2	104.5
2.8	95.2	37.5	7.9	268.6	105.9
2.9	98.6	38.9	8.0	272.0	107.2
3.0	102.0	40.2	8.1	275.4	108.5
3.1	105.4	41.5	8.2	278.8	109.9
3.2	108.8	42.9	8.3	282.2	111.2
3.3	112.2	44.2	8.4	285.6	112.6
3.4	115.6	45.6	8.5	289.0	113.9
3.5	119.0	46.9	8.6	292.4	115.2
3.6	122.4	48.2	8.7	295.8	116.6
3.7	125.8	49.6	8.8	299.2	117.9
3.8	129.2	50.9	8.9	302.6	119.3
3.9	132.6	52.3	9.0	306.0	120.6
4.0	136.0	53.6	9.1	309.4	121.9
4.1	139.4	54.9	9.2	312.8	123.3
4.2	142.8	56.3	9.3	316.2	124.6
4.3	146.2	57.6	9.4	319.6	126.0
4.4	149.6	59.0	9.5	323.0	127.3
4.5	153.0	60.3	9.6	326.4	128.6
4.6	156.4	61.6	9.7	329.8	130.0
4.7	159.8	63.0	9.8	333.2	131.3
4.8	163.2	64.3	9.9	336.6	132.7
4.9	166.6	65.7]		
5.0	170.0	67.0			

^{*} Speed of sound: 343 m/s (765 mph) at 20°C

Volume Setup

Volume Setup

[Volume] is selected on the Setup menu screen.



Setting item:

Main.Ring Vol.Talking.Voice/Navi Guidance.TA

Setting contents:

Main: 01 to 35(Initial setting: 10) Ring Vol: 01 to 35(Initial setting: 18) Ring Vol: 01 to 35(Initial setting: 18) Voice/Navi Guidance: 01 to 35(Initial setting: 18) TA: 01 to 35(Initial setting: 10)

Bluetooth Setup

[Bluetooth] is selected on the Setup menu screen.

Setting item:

Bluetooth

Setting contents:

Bluetooth, Devices List, Devices Info,



Bluetooth

• You can turn Bluetooth on or off

Device List

[**Devices**] is selected on the Bluetooth Setup Menu screen. You can register and set up Bluetooth compatible devices.



Pairing the Bluetooth Device

- Touch [Q] to enter [Search] screen to search for Devices.
- 2 Select a device and follow the on-screen prompts to connect devices
- 3 Screen prompts 6 character Numeric passkey to pair When the device registration is complete, a message appears and the device returns to [Device List].
- The Bluetooth registration process differs depending on the device version and SSP (Simple Secure Pairing). If a 4 or 6 character Numeric Comparison appears on this system, enter the Numeric Comparison on the Bluetooth device.
- If a 6 character Passkey appears on this system, make sure the same passkey is displayed on the Bluetooth device, and follow the screen.

Fast pairing the Bluetooth Device

Select one of 5 paired Bluetooth compatible devices that you previously registered.

1 Touch [Connect] on the Bluetooth Setup Menu screen.

Deleting a Bluetooth Device from the list

You can delete the information of a previously connected Bluetooth compatible device.

- 1 Touch [iii] on the Bluetooth Setup Menu screen.
- 2 Touch [Yes].
- Touching [No] will cancel the setting.

Searching for a Bluetooth Device

Setting item:

Search

 Touch [Q] on the device list interface in Bluetooth Setup.

The Bluetooth devices can be searched are displayed in a list.

- **2** Touch the device you want to connect from the list. You can register up to 5 Bluetooth compatible mobile phones.
- When the device registration is complete, a message appears and the device returns to [Device List].
- Connect to new Bluetooth compatible device when there are 5 paired devices registered, the system will delete the last paired device automatically

Displaying Bluetooth Information

[Info] is selected on the Bluetooth Setup Menu screen.

You can display the Bluetooth device name and device address of this unit.



Auto Connection

When the ACC is turned ON, the Bluetooth Hands-Free device is automatically connected. After connecting to the Hands-Free device, the Bluetooth Audio device is also connected automatically.

Downloading the Phonebook

If PBAP is connected, you can download the phonebook from the device.

 When the device is disconnected, the downloaded phonebook is not shown.

Rear Camera Setup

[Camera] is selected on the Setup Menu screen. You can set up items related to the Rear Camera.

Setting item:

Rear Camera

Setting contents:

Camera, Mute While Backing Up, Parking Guide Adjust, Video Setup



Camera

Setting item:

Camera

Setting contents:

Off, On (Initial setting),

 The rear camera initial setting is ON, when you turn off the camera, you cannot open and setup the camera.

Mute While Backing Up

Setting item:


Mute While Backing Up

Setting contents:

Off (Initial setting), On,

Parking Guide Adjust Setup

You can adjust the camera guide position.



Setting item:

Parking Guide Adjust

Setting contents:

Touch the icon you want to move.

- 1 Touch the icon you want to move.
- 2 Touch [↑][↓][←][→]to move the icon. Touching [Reset] clears adjustments and returns to the setting before guide line alteration.
- 3 Touch [n] to complete the adjustment and return to the previous screen.

Video Setup



Adjusting Brightness

Setting item:

Brightness

Setting contents:

-10 to 10 (Initial setting: 0)

 You can adjust the brightness of USB Video and reverse video between MIN(-10)and MAX(10)

Adjusting Color of Display

Setting item:

Colors

Setting contents:

-10 to 10 (Initial setting: 0)

 You can adjust the color of USB Video and reverse video between MIN(-10)and MAX(10)

Adjusting Display Contrast

Setting item:

Contrast

Setting contents:

-10 to 10 (Initial setting: 0)

 You can adjust the Contrast of USB Video and reverse video between MIN(-10)and MAX(10)

Lighting Link ON/OFF

[Lighting link] is selected on the Setup menu screen.



Setting item:

Lighting Link

Setting contents

On:

Lighting link icon displayed on sound boost screen

Off:

The Lighting link icon on the sound boost screen is not displayed




■ Distance guidance mark


The distance guides represent the ground level distance from the rear bumper. It is difficult to accurately estimate the distance to objects above ground level.

In the following example, the distance to A is 0.5 m and the distance to B is 1 m.

<Screen>



<Positions of A, B and C>



In the screen, according to the distance guidance marks, the truck seems to be parked about 1 m away (at the position B). In actual fact, however, if you reversed to position A, you would collide with the truck.

In the screen, positions A, B and C seem to be located in order of proximity. However, in actual fact, the position A and C are the same distance, and B is farther away than positions A and C.


 The car width extension mark represents the distance to the road surface. The distance to an object on the road is not accurately represented by the guides.

Error between the screen and the actual road surface

In the following conditions, errors are produced between the screen guidance and the actual road surface. (The illustrations represent a case when the camera is installed in the standard position.)


When there is a steep upward slope behind the car (example)

<Screen>



Distance guidance marks

<Situation of the car>




The distance guidance mark represents the distance to a flat road surface. Therefore in the case of an upward slope behind the car, the distance guides are displayed closer to the rear bumper than the actual distance. For example, if there is an obstacle on the upward slope, it may appear farther away than its actual position.


Also, an error may occur between the guidance and the actual path of the car on the road surface.

When there is a steep downward slope behind the car (example)

<Screen>



<Situation of the car>



In the case of a downward slope behind the car, the distance guides are displayed farther from the rear bumper than the actual distance.

If there is an obstacle on the downward slope, it seems closer than its actual position.

Also, an error may occur between the guidance and the actual path of the car on the road surface.

Information

About the Supported Formats

! CAUTION

Except for private use, duplicating audio data or distributing, transferring, or copying it, whether for free or for a fee, without permission of the copyright holder is strictly prohibited by the Copyright Act and by international treaty.

About Audio Format

Method for creating WAVE/WMA/AAC/AC3/MPEG/Ogg/FLAC/ APE (USB Flash drive) files

Audio data is compressed using software with WAVE/WMA/AAC/AC3/MPEG/Ogg/FLAC/APE (USB Flash drive) codecs. For details on creating WAVE/WMA/AAC/AC3/MPEG/Ogg/FLAC/APE(USB Flash drive files, refer to the user's manual for that software. WAVE/WMA/AAC/AC3/MPEG/Ogg/FLAC/APE (USB Flash drive) files that are playable on this device have the file extensions.

WAVE::WAV WMA::WMA,.asf AAC::aac AC3::ac3,.ec3

MPEG:.mp1,mp2,mpa,mp3,.mp4,m4a

Ogg:.ogg FLAC:.flac APE:.ape

WMA is not supported for the following files, Windows Media Audio Professional, Windows Media Audio 10 std or Windows Media Audio 10 Pro Lossless.

There are many different versions of the AAC format. Confirm that the software being used conforms to the acceptable formats listed above. It's possible that the format may be unplayable even though the extension is valid.

Playback of AAC files encoded by iTunes is supported.

WAVE (USB Flash drive)

Filename :.wav

Container: Waveform Audio File Format(base on RIFF)

Audio Coding: LPCM,IMA-ADPCM

WMA (USB Flash drive)

Filename:.wma,.asf

Container: Advanced Systems Format(ASF)

Audio Coding: WMA STD

* Support object:

Content Description Object: only

Title,Artist

AAC (USB Flash drive)

Filename:.aac

Container: Audio Data Transport Stream (ADTS)

Audio Coding: AAC-LC/HE-AAC

AC3 (USB Flash drive)

Filename:.ac3,.ec3 Container: AC3 bit streams Audio Coding: AC3

Container: Enhanced AC3 Bit Stream

Audio Coding: E-AC3

MPEG (USB Flash drive)

Filename:.mp1 Container: MPEG PS Audio Coding: MP1

Filename: .mp2,.mpa Container: MPEG PS Audio Coding: MP2

Filename : .mp3 Container: MPEG PS Audio Coding: MP3

* Support Tag:ID3V1 ID3v2.3: only TPE1, TALB, TCONTIT2, TYER

Filename:.mp4,.m4a Container: MP4 File Format Audio Coding: AAC-LC,HE-AAC

OGG (USB Flash drive)

Filename.:.ogg Container: Ogg Audio Coding: Vorbis

FLAC (USB Flash drive)

Filename.:.flac Container: FLAC Audio Coding: FLAC

APE (USB Flash drive)

Filename.:.ape

Container: APE (Monkey's Audio Lossless Audio File)

Audio Coding: Monkey's Audio

About Video Format

Files that are playable on this device have the file extensions.

AVI: .avi

MPEG 1/2: .mpg,.mpeg,.vob(with.info),.dat

MPEG4: .mp4,.mpeg4,.m4v Flash:.flv,.swf

QuickTime:.mov,.qt Matroska Video:.mkv

TS Stream:.ts,.tp,.trp,.m2ts <BD>,.MTS<AVCHD>

3GP:.3gp WMV:.wmv ASF:.asf

Format: AVI

Filename .: .avi

Video Coding: MPEG-4 SP/ASP(FMP4), Sorenson H.263(FLV1), H.264, Xvid, WMV 9 / VC - 1,

> MJPEG (Maximum resolution:1280x720), MPEG-2 Video, MPEG-1 Video

Audio Coding: MP3, AC3, WMA St, LPCM /ADPCM

Format: MPEG 1/2

File Name:.mpg .mpeg

Video Coding: MPEG-1 Video, MPEG-2 Video, H.264 Audio Coding: MP1 / MP2 / MP3, AAC-LC, AC3, LPCM

File Name:.vob (with.info)

Video Coding: MPEG-2 Video Main Audio Coding: MP1 / MP2 / MP3, AC3, LPCM

File Name:.dat

Video Coding: MPEG-1 Video Audio Coding: MPEG-1 Audio Layer II

Format: MPEG4

File Name:.mp4,.mpeg4

Video Coding: MPEG-2 Video, MPEG-4 SP/ASP, H.264, MJPEG (Maximum resolution:1280x720)

Audio Coding: MP3, AAC-LC/HE-AAC, AC3, LPCM

File Name:.m4v

Video Coding: H.264

Audio Coding: AAC-LC / HE-AAC, AC3

Format: Flash

File Name:.flv

Video Coding: Sorenson H.263(FLV1), H.264 Audio Coding: MP3, AAC-LC, ADPCM

File Name:.swf

Video Coding: Sorenson H.263(FLV1), H.264

Audio Coding: MP3, ADPCM

Format: QuickTime

File Name:.mov .qt

Video Coding: MPEG-4 SP/ASP, H.264,

MJPEG (MJPEG(Maximum resolution:1280x720)

Audio Coding: MP3, AAC-LC / HE-AAC, LPCM

Format: Matroska Video

File Name:.mkv

Video Coding: MPEG-1 Video, MPEG-2 Video, MPEG-4 SP/ASP, H.264,

Xvid, WMV9 / VC-1

Audio Coding: MP3, AC3, LPCM, AAC-LC / HE-AAC

Format: TS Stream

File Name:.ts .trp

Video Coding: MPEG-1 Video, MPEG-2 Video, MPEG-4 H.264,

WMV 9 / VC-1

Audio Coding: MP1 / MP2 / MP3, AC3, AAC-LC / HE-AAC

File Name:.m2ts <BD>

Video Coding: MPEG-2 Video, H.264, WMV 9 / VC-1

Audio Coding: AC3, LPCM File Name:..MTS < AVCHD>

Video Coding: H.264 Audio Coding: AC3, LPCM

Format: 3GP

File Name:.3gp

Video Coding: MPEG-4 SP/ASP, H.263, H.264

Audio Coding: ACC-LC / HE-ACC

Format: WMV

File Name:.wmv

Video Coding: VC-1 Audio Coding: WMA Std

Format: ASF

File Name:.asf

Video Coding: VC-1 Audio Coding: WMA Std

About Photo Format

Format: Jpg,jpeg

Resolution ratio: Maximum 4096 x 4096, minimum 32x32

Format:Png

Resolution ratio: Maximum 576 x 720 minimum 32x32

Format:bmp

Resolution ratio: Maximum 936 x 1920 minimum 32x32

ID3 tags/WMA tags

If the music supports ID3 tag and track title, music title, author, album name and album cover are to be displayed.

If there is no track title ,"No Name" will be displayed.

If there is no album name, the name of the folder will be displayed, if the song name is not recognized, it will be garbled, if there is no album cover, it will not be displayed.

Playing back file

- The files are prepared, then written to a USB flash drive.
- $\bullet \quad Connect \ iPod/Android \ MSC$

Maximum numbers of playable files/folders

Maximum files numbers of device:

USB Flash drive(Auido/Video/):9999 USB Flash drive(Photo):999 IPod:2000

Android MSC: Same as USB

Maximum files numbers of folders:

USB Flash drive (Auido/Video/Photo):999

 ${\it IPod:} No\ folder\ , only\ a\ playlist\ is\ available\ with\ up\ to\ 100\ files$

Android MSC: Same as USB

Maximum folders numbers of device:

USB Flash drive(Auido/Video/Photo):1000 IPod:No folder ,up to 100 playlists

Android MSC: Same as USB

· Supports a maximum of 256 GB USB

· Largest playable file size:

Audio files :4GB Video files: 4 GB Photo files: 10K-6M

Playback may not be performed if a disc exceeds the limitations described above.

Media supported

The media that this device can play back a USB flash drive.

Corresponding File Systems

This device supports FAT 16/32, NTFS.

The maximum nested folder depth is 8 (including the root directory).

Order/Search of files

Display and sort according to the head characte

Display in the order of 1 -> 2 -> 3 below.

- 0: Folder :When there are folders, the folders are displayed ahead of the files
- 1: Number (represented by "#" on the Right Search Bar)
- 2: English Alphabet
- 3: Shorting order of Unicode

Right Search Bar (order of list)

- 1: Number (represented by "#" on the Right Search Bar)
- 2: English Alphabet
- Search only the files with numeric or English alphabetic headers

Terminology

Bit rate

This is the "sound" compression rate specified for encoding. The higher the bit rate, the higher the sound quality, but also the larger the files.

Sampling rate

This value shows how many times per second the data is sampled (recorded). For example, music CDs use a sampling rate of 44.1 kHz, so the sound is sampled (recorded) 44,100 times per second. The higher the sampling rate, the higher the sound quality, but also the larger the volume of data.

Encoding

Converting music CDs, WAVE (AIFF) files, and other sound files into the specified audio compression format.

Tag

Song information such as track titles, artist names, album names, etc., written into MP3/WMA/AAC/FLAC/WAVE/Ogg/APE (USB flash drive) files.

Root folder

The root folder (or root directory) is found at the top of the file system. The root folder contains all folders and files. It is created automatically for all burned discs.

In Case of Difficulty

If you encounter a problem, please turn the power off, then on again. If the unit is still not functioning normally, please review the items in the following checklist. This guide will help you isolate the problem if the unit is at fault. Otherwise, make sure the rest of your system is properly connected, or then consult your authorized Alpine dealer.

Basic

No function or display.

- · Vehicle's ignition is off.
 - If connected according to the instructions, the unit will not operate with the vehicle's ignition off.
- · Improper power lead connections.
 - Check power lead connections.
- · Blown fuse.
 - Check the fuse on the battery lead of the unit; replace with the proper value if necessary.

No sound or unnatural sound.

- · Incorrect setting of volume/balance/fader controls.
 - Readjust the controls.
- · Connections are not properly or securely made.
 - Check the connections and firmly connect.

Screen not displayed.

- Brightness/Contrast control is set at the minimum position.
 - Adjust the Brightness/Contrast control.
- · Temperature in the vehicle is too low.
 - Increase the vehicle's interior temperature to operation temperature range.
- Connections to the Auxiliary Device are not securely made.
 - Check the connections and firmly connect.
- The Parking Brake Lead is not connected.
- The Parking Brake is not engaged.
 - Connect the Parking Brake Lead, then engage the Parking Brake

Movement of displayed picture is abnormal.

- · Temperature in the vehicle is too high.
 - Allow the vehicle's interior temperature to cool.

Radio

Unable to receive stations.

- No antenna, or open connection in the antenna cable.
 - Make sure the antenna is properly connected; replace the antenna or cable if necessary.

Unable to tune stations in the seek mode.

- · You are in a weak signal area.
- Change the radio frequency manually.
- If the area you are in is a primary signal area, the antenna may not be grounded and connected properly.
 - Check your antenna connections; make sure the antenna is properly grounded at its mounting location.
- The antenna may not be the proper length.
 - Make sure the antenna is fully extended; if broken, replace the antenna with a new one.

Broadcast is noisy.

- The antenna is not the proper length.
 - Extend the antenna fully; replace it if it is broken.
- The antenna is poorly grounded.
 - Make sure the antenna is grounded properly at its mounting location.
- · The station signal is weak and noisy.
 - If above solution does not work, tune in another station.

USB Audio

Unit does not operate.

- · Condensation.
 - Wait a while (about 1 hour) for the condensation to dry.

Picture is unclear or noisy.

- · Vehicle's battery power is weak.
 - Check the battery power and wiring. (The unit may malfunction if the battery power is under 11 volts with a load applied.)

If this Message Appears

Various messages are displayed on the screen during operation. In addition to the messages telling you the current status or providing guidance for the next operation, there are also the following error messages. If one of these error messages is displayed, carefully follow the instructions in the solution column.

System

ATTENTION!

Viewing of front seat video source while driving is strictly prohibited.

- A setup operation, etc., was carried out while the vehicle was running.
 - Move the vehicle to a safe location, stop, and engage the parking brake, then carry out this operation.

Audio/Visual

This content cannot be played.

- · Unsupported content.
 - Change to play supported contents type.

This device is not supported./Unsupport USB device

- · Unsupported device.
 - Change to play supported USB device.

Device No Response.

· No response from the device.

USB Hub is not supported.

• The USB hub is not supported.

No Audio

- There is no audio data in the current video file.
 - Download a video file whit audio date in it .

Audio format not supported

- Not supported audio format.
 - Download supported audio format to USB flash drive.

Audio trick not supported/Video Trick not supported

- Prompts fast forwarding / reversing or jumping on current audio /video is not supported.
 - Change the current audio /video format.

Video other warning

- Prompts unexpected warning message.
 - Change to play other video.

Video format not supported

- · Unsupported video format.
 - Change to play the supported video format.

Video other error

- · Unknown error.
 - Change to play other video.

No Artist (/ No Song / No album)

- There are no tag-info in the USB Audio / iPod Audio.
 - Change to play audio-file with tag-info

No Date

- · There are no data in the USB flash drive.
 - Download data to the USB flash drive and connect to this unit.

SiriusXM

Check Tuner

- The SiriusXM Tuner is disconnected or the unit is having trouble communicating with the Tuner.
 - Connect the Tuner or check the Tuner connection to the back of the unit.

Check Antenna

- The SiriusXM Satellite Radio antenna or cable is either damaged or not connected correctly to the SiriusXM Tuner.
 - Check that the SiriusXM antenna cable is connected to the SiriusXM Tuner and check that the antenna cable is not kinked or otherwise damaged. Replace the antenna if necessary.
 - SiriusXM products are available at your local car audio retailer or online at www.shop.siriusxm.com.

No Signal

- The SiriusXM satellite signal is too weak at the current location.
 - Move the vehicle to a location with a clear view of the southern sky.
 - Make sure the Satellite Radio antenna is properly mounted and not obstructed by metal objects.

Channel [xxx] Not Subscribed Call SiriusXM to Subscribe

- The active channel has become unsubscribed or the requested channel is not available in your subscription package.
 - In the USA, you can activate online or by calling SiriusXM Listener care:
 - · Visit www.siriusxm.com/activatenow
 - Call SiriusXM Listener Care at 1-866-635-2349
 - For Canadian Subscriptions, please contact:
 - · Visit www.siriusxm.ca/activate
 - · Call SiriusXM Customer Care at 1-888-539-7474
 - The unit will revert to the previously selected channel or to channel 1 automatically.

Channel [xxx] Not Available

- The active channel is no longer in the SiriusXM channel lineup or the user has entered an invalid channel number.
 - Visit www.siriusxm.com for information on the current channel lineup.
- The unit will revert to the previous channel or to channel 1 automatically.

Subscription Updated Press Enter to Continue

- Your subscription has been updated.
 - Touch [Enter] to clear this message.

Password modified successfully

- · Password entered incorrectly.
 - Enter the correct password

Bluetooth

No Bluetooth device were found

- The Bluetooth audio device was not connected correctly.
 - Check the settings for the unit and the Bluetooth audio device and reconnect

Phone

Empty

• The phone book is empty.

Phone book access is not authorized

- The phone book download is not supported.
 - On Enable phone book permission.

Handsfree device is not connected

- · Hands-Free Profile is not connected.
 - Connect Hands- Free Profile .

AUX

Picture off for your safety.

- · While the vehicle is moving.
 - Parking.

HOME

No devices available connect an Android Phone with USB cable.

When Android Auto is not connected, touch Android Auto icon, this message is displayed.

Caution! AMP Overload.

- When two volume cables are connected ,this message is displayed.
 - Take apart the volume cable and reboot the unit.

Caution! USB Overcurrent.

- Prompts USB Overcurrent
 - Remove the USB and reboot the unit

Apple CarPlay

The GNSS antenna is disconnected.

- · The GPS antenna is disconnected or bad connected.
 - Connect the GPS antenna.

Setup

Data check error..

- · Upgrade firmware check error
 - Exit upgrade progress

There is no photo in this device.

- No photo in this device
 - Download the photo with supported format ((JPG,JPEG,PNG,BMP))to this device

Specifications

MONITOR SECTION

Screen Size 6.75"

LCD Type Normally white, Transmissive Operation System a-Si TFT active matrix

Number of Picture Elements 1,152,000 pcs.

 $(800 \times 480 \times 3(RGB))$

Effective Number of Picture Elements

99% or more

Illumination System LED

FM TUNER SECTION

Tuning Range 87.7 – 107.9 MHz Mono Usable Sensitivity < 9 dBu (75 ohms) 50 dB Quieting Sensitivity < 5 dBu (75 ohms)

Signal-to-Noise Ratio 65 dB Stereo Separation 35 dB

AM TUNER SECTION

Tuning Range 530 – 1710 kHz Usable Sensitivity 34 dBu

USB SECTION

USB requirements USB 2.0

Max. Power Consumption 1,500 mA (CDP Support)
USB Class USB (Play From Device)/

USB (Mass Storage Class)

 $\begin{array}{lll} \mbox{File System} & \mbox{FAT16/32, NTFS} \\ \mbox{Number of Channels} & \mbox{2-Channels (Stereo)} \\ \mbox{Frequency Response}^{*_1} & 17 - 20,000 \mbox{ Hz (± 1 dB)} \\ \mbox{Total Harmonic Distortion} & 0.05\% (at 1 \mbox{ kHz)} \\ \mbox{Dynamic Range} & 90 \mbox{ dB (at 1 \mbox{ kHz)}} \\ \end{array}$

Signal-to-Noise Ratio 85 dB

Channel Separation 75 dB (at 1 kHz)

Bluetooth SECTION

Bluetooth Specification Bluetooth V5.0

Output Power <+4dBm Ave. (Power class 2)
Profile HFP (Hands-Free Profile)

PBAP (Phone Book Access Profile)

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio/Video Remote

Control Profile)

GENERAL

Power Requirement 14.4 V DC

(10.8 - 15.1 V allowable)

Operating temperature -4°F to +140°F

 $(-20^{\circ}\text{C to} + 60^{\circ}\text{C})$

Power Output $16 \text{ W RMS} \times 4^{*2}$ *2 Primary amplifier ratings per CEA-2006 Standard

• Power output: measured at 4 Ohms and $\leq 1\%$ THD+N

• S/N: 80 dBA (reference: 1 W into 4 Ohms)

Weight 0.9 kg

Audio output level

Preout (Front, Rear): 4V/10k ohms (max.) Preout (Subwoofer): 4V/10k ohms (max.)

CHASSIS SIZE

 Width
 178 mm

 Height
 100 mm

 Depth
 68 mm

- Due to continuous product improvement, specifications and design are subject to change without notice.
- The LCD panel is manufactured using an extremely high precision manufacturing technology. Its effective pixel ratio is over 99.99%. This means that there is a possibility that 0.01% of the pixels could be either always ON or OFF

^{*1} Frequency response may differ depending on the encoder software/bit rate.

Installation and Connections

Before installing or connecting the unit, please read the following and pages 5 to 8 of this manual thoroughly for proper use.



WARNING

KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.

Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.

A CAUTION

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

Precautions

- Be sure to disconnect the cable from the (-) battery post before installing your unit. This will reduce any chance of damage to the unit in case of a short-circuit.
- Be sure to connect the color coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage to the vehicle's electrical system.
- When making connections to the vehicle's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the unit to the fuse box, make sure the fuse for the intended circuit of the unit has the appropriate amperage. When in doubt, consult your Alpine dealer.
- The unit uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors. You may need an adaptor to connect other units. If so, please contact your authorized Alpine dealer for assistance.
- Be sure to connect the speaker (-) leads to the speaker (-) terminal. Never connect left and right channel speaker cables to each other or to the vehicle body.


Accessory List

Main unit	1
Power cable	1
RCA cable	1
GPS antenna	1set
Microphone	1
USB extension cable	
Screw	4
Countersunk screw	4
Quick Reference Guidance	1
Card note1	1
Card note2	1
Warranty card	1

Installation

CAUTION

 Do not cover the heat sink to block air circulation, as heat can accumulate in the chamber and cause a fire.




Rear of the Unit

Caution concerning the installation location

Angle of installation

Install at an angle between horizontal and 30°. Note that installing at an angle outside of this range will result in a loss of performance and possibly damage.




Mounting the Microphone

For safe use, make sure of the following:


- Location is stable and firm.
- · Does not interfere with safety equipment.
- Driver's view and operations are not obstructed.
- Microphone is located where the driver's voice can be easily picked up (for example, on the sun visor).

When you speak into the microphone, you should not have to change your driving posture. This may cause a distraction, taking your attention away from safely driving your vehicle. Carefully consider direction and distance while mounting the microphone. Confirm that the driver's voice can be easily picked up at the selected location.




Installation example using the Original Mounting Bracket

 Mount the original mounting bracket to the unit using the supplied screws.



- 2 Connect all other leads of the unit according to details described in the "Connections" (page 50).
- **3** Mount the unit in a car.
- To securely connect the ground lead, use an already installed screw on a metal part of the vehicle (marked (★)) or a clean, bare metal spot on the vehicle's chassis.
- Fix the cables carefully. Do not damage them by mounting them into movable parts, such as the seat rail, or by locating them against sharp or pointed edges.
- 4 Reattach the removed vehicle parts (panels, etc.) or other aftermarket dash kit back onto the vehicle.

Connections



- (1) Radio Antenna Receptacle
- (2) GPS Antenna Receptacle
- (3) Power Antenna Lead (Blue)

Connect this lead to the +B terminal of your power antenna, if applicable.

 This lead should be used only for controlling the vehicle's power antenna. Do not use this lead to turn on an amplifier or a signal processor, etc.

(4) Remote Turn-On Lead (Blue/White)

Connect this lead to the remote turn-on lead of your amplifier or signal processor.

(5) Parking Brake Lead (Yellow/Blue)

Connect this lead to the power supply side of parking brake switch to transmit the parking brake status signals to the unit.

- (6) Reverse Lead (Violet/White)
- 7 Right Rear (+) Speaker Output Lead (Violet)
- (8) Right Rear (-) Speaker Output Lead (Violet/Black)
- 9 Right Front (+) Speaker Output Lead (Gray)
- (10) Right Front (–) Speaker Output Lead (Gray/Black)
- (11) Left Front (+) Speaker Output Lead (White)
- (12) Left Front (-) Speaker Output Lead (White/Black)
- (13) Left Rear (+) Speaker Output Lead (Green)
- (14) Left Rear (-) Speaker Output Lead (Green/Black)
- (5) Switched Power Lead (Ignition) (Red)

Connect this lead to an open terminal on the vehicle's fuse box or another unused power source that provides (+) 12V only when the ignition is turned on or in the accessory position.

- 16 Fuse Holder (15A)
- 17 Battery Lead (Yellow)

Connect this lead to the positive (+) post of the vehicle's battery.

(18) Ground Lead (Black)

Connect this lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided.

- (19) SPEED SENSOR(Green/White)
- 20 LIGHTING LINK(Brown)
- (21) SW1 (Black/Brown)

Steering Wheel Control

22 SW2 (Black/Blue)

Steering Wheel Control

23 SWG (Black/White)

Steering Wheel GND

24 REAR CAMERA Input RCA Connector(Black)

Use when connecting a camera with RCA Output Connector.

25 Rear Output RCA Connectors

Can be used as Rear Output RCA Connectors. RED is right and WHITE is left.

26 Front Output RCA Connectors

Can be used as Front Output RCA Connectors. RED is right and WHITF is left.

- 27) Subwoofer RCA Connectors
- 28 AUX INPUT (Black)

Audio and video input.

29 MIC Input Connector

To microphone (included)

30 SiriusXM Tuner Input Connector

To SiriusXM Tuner (sold separately).

 For more information on how to install the SiriusXM Connect Vehicle tuner, consult the installation guide included with the tuner


③1 USB Connector

To USB flash drive, iPhone or Android smartphone.

- **32** Power Supply Connector
- **33** CAMERA/SWC PRE OUT/AUX

If an ACC power supply is not available

Connection Diagram of SPST Switch (sold separately)



- If your vehicle has no ACC power supply, add an SPST (single-pole, single-throw) switch (sold separately) and fuse (sold separately).
- The diagram and the fuse amperage shown above are in the case when the unit is used individually.
- If the switched power (ignition) lead of the unit is connected directly to the positive (+) post of the vehicle's battery, the unit draws some current (several hundred milliamperes) even when its switch is placed in the OFF position, and the battery may be discharged.

IMPORTANT

Please record the serial number of your unit in the space provided below and keep it as a permanent record. The serial number plate is located on the bottom of the unit.


SERIAL NUMBER:
INSTALLATION DATE:
INSTALLATION TECHNICIAN:
PLACE OF PURCHASE:
FLACE OF FUNCTIASE.

To prevent external noise from entering the audio system.

- Locate the unit and route the leads at least 10 cm away from the car harness.
- Keep the battery power leads as far away from other leads as possible.
- · Connect the ground lead securely to a bare metal spot (remove any paint, dirt or grease if necessary) of the car chassis.
- If you add an optional noise suppressor, connect it as far away from the unit as possible. Your Alpine dealer carries various noise suppressors, contact them for further information.
- · Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information.


System Example

Connection of an iPhone




· Do not leave an iPhone in a vehicle for a long time. Heat and humidity may damage the iPhone, and you may not be able to play it again.

Connection of a USB Flash Drive




• Do not leave a flash drive in a vehicle for a long time. Heat and humidity may damage the flash drive.

Connection of a camera



* RCA Extension Cable (sold separately)

Connection of Lighting Link System



- For complete installation and Sub. Enclosure features, please see Prisma Link enclosure manual.
- When connecting the Lighting Link cable, set the LED Brightness/LED Lighting Speed setting of this unit to 0 (page 26).

OEM Steering Wheel Control Rentention

To use this feature the vehicle must have resistive steering wheel controls. (Most Japanese and KoreanVehicles)

If the vehicle does not have restisive steering and uses data controlled steering wheel controls then a 3rd party Steering Wheel Interface with a female 3.5mm connection to be hardwired to the iLX-W670 steering wheel control wires is needed. (Sold Separately)

Please check what kind of Steering Wheel controls you have before install.

Professional Installation is reccomended.

For programming please see page 31.



LIMITED WARRANTY

ALPINE ELECTRONICS OF AMERICA, INC. ("Alpine"), is dedicated to quality craftsmanship and is pleased to offer this Warranty. We suggest that you read it thoroughly. Should you have any questions, please contact your Dealer or contact Alpine at one of the telephone numbers listed below.

PRODUCTS COVERED:

This Warranty covers Car Audio Products and Related Accessories ("the product"). Products purchased in the Canada are covered only in the Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

LENGTH OF WARRANTY:

This Warranty is in effect for one year from the date of the first consumer purchase.

WHO IS COVERED:

This Warranty only covers the original purchaser of the product, who must reside in the United States, Puerto Rico, Mexico, Brazil, Argentina or Canada.

WHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor) in the product.

WHAT IS NOT COVERED:

This Warranty does not cover the following:

Damage occurring during shipment of the product to Alpine for repair (claims must be presented to the carrier).

Damage caused by accident or abuse, including burned voice coils caused by over-driving the speaker (amplifier level is turned up and driven into distortion or clipping). Speaker mechanical failure (e.g. punctures, tears or rips). Cracked or damaged LCD panels. Dropped or damaged hard drives.

Damage caused by negligence, misuse, improper operation or failure to follow instructions contained in the Owner's manual.

Damage caused by act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature.

Any cost or expense related to the removal or reinstallation of the product.

Service performed by an unauthorized person, company or association.

Any product which has the serial number defaced, altered or removed

Any product which has been adjusted, altered or modified without Alpine's consent.

Any product not distributed by Alpine within the United States, Puerto Rico or Canada.

Any product not purchased from an Authorized Alpine Dealer.

● HOW TO OBTAIN WARRANTY SERVICE:

① You are responsible for delivery of the product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option, repair or replace the product with a new or reconditioned product without charge. If the repairs are covered by the warranty, and if the product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges.

- ② You should provide a detailed description of the problem(s) for which service is required.
- 3 You must supply proof of your purchase of the product.
- 4 You must package the product securely to avoid damage during shipment. To prevent lost packages it is recommended to use a carrier that provides a tracking service.

HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON IS AUTHORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

HOW WE EXCLUDE CERTAIN DAMAGES:

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. THE TERM "INCIDENTAL DAMAGES" REFERS TO EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHERS COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT. THE TERM "CONSEQUENTIAL DAMAGES" REFERS TO THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. THE REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

HOW STATE/PROVINCIAL LAW RELATES TO THE WARRANTY:

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

IN CANADA ONLY:

This Warranty is not valid unless your Alpine car audio product has been installed in your vehicle by an Authorized Installation Center, and this warranty stamped upon installation by the installation center.

HOW TO CONTACT CUSTOMER SERVICE:

Should the product require service, please call the following number for your nearest Authorized Alpine Service Center.

CAR AUDIO	1-800-ALPINE-1 (1-800-257-4631)
NAVIGATION	1-888-NAV-HELP (1-888-628-4357)

Or visit our website at; http://www.alpine-usa.com

ALPINE ELECTRONICS OF AMERICA, INC., 1500 Atlantic Blvd, Auburn Hills, Michigan 48326, U.S.A. Do not send products to this address.

Call the toll free telephone number or visit the website to locate a service center.

About the Rules of Bluetooth Electromagnetic Radiation Regulation

USA/Canada

FCC/IC CAUTION

This device complies with Part 15 of the FCC Rules and Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- · This device may not cause interference; and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that it deemed to comply without maximum permissive exposure evaluation (MPE). But it is desirable that it should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- l'appareil ne doit pas produire de brouillage;
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement émet une énergie RF très faible qui est considérée conforme sans évaluation de l'exposition maximale autorisée (MPE). Cependant, il est souhaitable qu'il devrait être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

"La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada."

resolution 680: "Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados."

Don't forget to take a moment to protect your purchase by registering your product now at the following address: www.alpine-usa.com/registration.

N'oubliez pas de consacrer un moment à la protection de votre achat en enregistrant votre produit dès maintenant à l'adresse suivante : www.alpine-usa.com/registration.

Recuerde que con solo unos pocos pasos podrá proteger su producto, registrándolo a través de la siguiente dirección: www.alpine-usa.com/registration.

Open source licenses

This software includes open source software codes licensed under GNU General Public

GNU GENERAL PUBLIC LICENSE Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things. To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps:

- (1) copyright the software.
- (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

Detailed license notice, full license texts and machine readable copy of the corresponding source code are readily available on our OSS website (*)

Disclaimer

TO THE EXTENT PERMITTED BY APPLICABLE LAW, AND AS PROVIDED IN THE GPL AND LGPL, PIONEER AND ITS LICENSORS PROVIDE AND YOU ACCEPT THE FIRMWARE "AS IS" WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YOU ACCEPT THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE FIRMWARE.

UNLESS REQUIRED BY APPLICABLE LAW, AND AS PROVIDED IN THE GPL AND LGPL, IN NO EVENT WILL PIONEER OR ITS LICENSORS BE LIABLE TO YOU OR ANY THIRD PARTIES FOR DAMAGES OF ANY KIND ARISING OUT OF YOUR USE OR INABILITY TO USE THE FIRMWARE, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

^{*} http://www.alpine.com/e/oss/download





3rd Party Steering Wheel Control Interface Instructions

iLX-W670

Introduction

This document is intended as guidance when using steering wheel controls with 3rd part adaptors (Maestro, PAC and Metra).


The iLX-W670 has a built-in steering control interface for vehicles that use resistive steering wheel control. These vehicles do not require a SW adaptor. (Most Asian Vehicles)

Vehicles that use Data steering wheel controls will need a 3rd party module (Most American Vehicles).


Metra, PAC and ADS SWC modules are compatible with the iLX-W670. Please see attached for basic instructions.

Idatalink Maestro SW


- 1. Download Maestro software and plug in Maestro SW. https://www.weblinkupdater.com/weblinkdesktop/en
- 2. Select year/make/model to verify Maestro SW compatibility.




3. Verify correct steering wheel.



4. Select firmware.




5. Select what to configure (steering wheel control is only option on MSW).




6. The button assignment page is blank. The vehicle buttons will be assigned manually in a few steps.



7. Flash The Maestro SW



8. After flashing, the install guide will be available. Download the guide



9. The guide will have diagrams, wire colors, and vehicle harness pinout. The blue/yellow will connect to the ilx W670 SW1 wire (black/brown).





10. Once all connections have been made, the ilx W670 needs to be manually programmed to the vehicle.

(Setup-system-steering wheel control)

- · Press the coordinating button on radio screen that you want to program.
- Within two seconds do not press any of the steering wheel buttons
- After 2 seconds hit the steering wheel button that corresponds with the button you want to program.




PAC SWI-CP2


1. Go to the site and scroll down and select SWI-CP2 https://pac-audio.com/swi-guide-center/controlpro-guide/




2. Select programming method DIPS (manual)



3. Select vehicle year/make/model/options and select ANDROID RADIO for radio.



4. Default button assignment. These will be programmed manually in a few steps.



5. The vehicle pin out and wire colors are shown. The 3.5 is not used, but the blue/yellow wire is. Connect that wire to SW1 on the Alpine ilx W670 (black/brown).



- 6.Go into ilx W670 setup menu (setup-system-steering wheel control) and assign functions to vehicle steering wheel buttons.
 - · Press the coordinating button on radio screen that you want to program.
 - · Within two seconds do not press any of the steering wheel buttons
 - After 2 seconds hit the steering wheel button that corresponds with the button you want to program.



Metra AXSWC

- Wire the AXSWC wires from the iLX-W670 to the female 3.5mm jack (SWC1 to brown, SWC2 to brown/white, SWC ground to ground) and plug in the AXSWC. NOTE: the SWC ground is not needed for use of the AXSWC
- 2. AXSWC should detect the iLX-W670 as a Sony and program correctly. Note: Successfully mapped buttons Volume Up, Volume Down, Seek Up, Seek Down, Mode. Failed mapped buttons: Mute, PTT, Hang Up, Pick Up, Play/Pause. **If you attempt to map other buttons, they are very close in value to others already programmed and will likely cause all buttons to clear programming. **
- 3. Go into ilx W670 setup menu (setup-system-steering wheel control) and assign functions to vehicle steering wheel buttons.
- Press the coordinating button on radio screen that you want to program.
- · Within two seconds do not press any of the steering wheel buttons
- After 2 seconds hit the steering wheel button that corresponds with the button you want to program.



This document is intended as guidance when using steering wheel controls with 3rd part adaptors (Maestro, PAC and Metra).

The iLX-W670 has a built-in steering control interface for vehicles that use resistive steering wheel control. These vehicles do not require a SW adaptor. (Most Asian Vehicles)

Vehicles that use Data steering wheel controls will need a 3rd party module (Most American Vehicles).

Metra, PAC and ADS SWC modules are compatible with the iLX-W670. Please see attached for basic instructions.

Idatalink Maestro SW

- 1. Download Maestro software and plug in Maestro SW. https://www.weblinkupdater.com/weblinkdesktop/en
- 2. Select year/make/model to verify Maestro SW compatibility.



3. Verify correct steering wheel.



4. Select firmware.



5. Select what to configure (steering wheel control is only option on MSW).



6. The button assignment page is blank. The vehicle buttons will be assigned manually in a few steps.



7. Flash The Maestro SW



8. After flashing, the install guide will be available. Download the guide.



9. The guide will have diagrams, wire colors, and vehicle harness pinout. The blue/yellow will connect to the ilx W670 SW1 wire (black/brown).





10. Once all connections have been made, the ilx W670 needs to be manually programmed to the vehicle.

(Setup-system-steering wheel control)




PAC SWI-CP2

 Go to the site and scroll down and select SWI-CP2 https://pac-audio.com/swi-guide-center/controlpro-guide/



2. Select programming method DIPS (manual)



3. Select vehicle year/make/model/options and select ANDROID RADIO for radio.



4. Default button assignment. These will be programmed manually in a few steps.



5. The vehicle pin out and wire colors are shown. The 3.5 is not used, but the blue/yellow wire is. Connect that wire to SW1 on the Alpine ilx W670 (black/brown).



6. Go into ilx W670 setup menu (setup-system-steering wheel control) and assign functions to vehicle steering wheel buttons.



Metra AXSWC

- 1. Wire the AXSWC wires from the iLX-W670 to the female 3.5mm jack (SWC1 to brown, SWC2 to brown/white, SWC ground to ground) and plug in the AXSWC. NOTE: the SWC ground is not needed for use of the AXSWC
- 2. AXSWC should detect the iLX-W670 as a Sony and program correctly. Note: Successfully mapped buttons Volume Up, Volume Down, Seek Up, Seek Down, Mode. Failed mapped buttons: Mute, PTT, Hang Up, Pick Up, Play/Pause. **If you attempt to map other buttons, they are very close in value to others already programmed and will likely cause all buttons to clear programming. **
- 3. Go into ilx W670 setup menu (setup-system-steering wheel control) and assign functions to vehicle steering wheel buttons.





REGISTER YOUR PRODUCT

Register your Alpine product(s) to help us track your warranty and get access to exclusive content, giveaways and special offers.



REGISTER ONLINE

Visit alpineusa.link/register



TEXT TO REGISTER

Text "ALPINE" to 71739 (US Only)

One message per opt-in. Text "HELP" for help. Text "STOP" to cancel. Message and data rates may apply. See full privacy policy and SMS terms at www.alpine-usa.com/terms-of-use



SCAN TO REGISTER

Scan the QR Code below using your phone or device







iLX-W670

You can see the detailed manual. Vous pouvez voir le manuel détaillé.



http://www.alpine-usa.com



If you have purchased the ILX-670 head unit, the PrismaLink is capable of LED control by the LightingLink Software from the head unit.


If you prefer to control the LEDs on the enclosure by ILX-670, please see Section A).


If you prefer to control by the wireless IR remote (included) please see Section B).


Section A

To control the LED functions on the PrismaLink by the ILX-670, connect the 3-Wire adapter plug to the IN location on the first (left or single) enclosure terminal and ensure that the terminal switch is set to Position A (Left)

- Connect the Red Wire to 12V
- Connect the Black Wire to GND
- Connect the Brown Wire to the LightingLink Brown Wire from the back of the ILX-670.
- "While in Position A the remote will only function while aimed at the ILX-670. All function while aimed at the enclosure IR sensor will be Disabled while in position A.








Section B


If you have NOT purchased the ILX-670 head unit OR Prefer to use the IR remote functions for the PrismaLink LED control, ensure the terminal switch is set to Position B


- Connect the Red Wire to 12V
- Connect the Black Wire to GND
- Leave the Brown Wire Disconnected







Wiring Diagrams










"All 3 subwooflers MUST be taken out of the enclosure and winkd from 2 Ohm to 8 Ohm (Change from Parallel to Series with the Jumper installed on the subwoofler)



"All 4 subwoofers MUST be taken out of the enclosure and wired from 2 Ohm to 8 Ohm (Change from Parallel to Series with the Jumper installed on the subwoofer)



IMPORTANT NOTICE! PLEASE READ FIRST BEFORE INSTALLING SPEAKERS

Congratulations on your purchase of high quality speakers from Alpine. Your listening satisfaction is important to us. In order to maximize and maintain peak speaker performance the following guidelines are being provided. Please read this notice carefully before operating the speakers.

- Do not over-drive the amplifier. Over-driving the amplifier will result in distortion or clipping and can damage any speaker.
- Make sure gain controls are properly set. (Follow instructions in amplifier owner's manual.)
- 3. Make sure that the speaker is properly rated for the amplifier.
- Make sure that volume, bass, treble, equalization or crossover settings do not cause the amplifier to over-drive.

Failure to follow these guidelines may result in burned or damaged speaker voice coils which will void your warranty.

If further assistance is necessary, please contact your Alpine authorized dealer.



LIMITED WARRANTY

OPRODUCTS COVERED:

This Limited Warranty ("Limited Warranty") covers Alpine Car Audio Products and Related Accessories (the "Product"). Products purchased in Canada are covered only in Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

QLENGTH OF WARRANTY:

This Warranty is in effect for one year (1) from the date of the original retail purchase on the Product.

WHO IS COVERED:

This Warranty only covers the original purchaser of the Product, who must reside in the United States, Puerto Rico or Canada.

OWHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor), under normal use, in the Product.

OWHAT IS NOT COVERED:

- This Limited Warranty does not cover the following:

 (i) Damage occurring during shipment of the Product to Alpine for repair (claims must be presented to the
- Damage caused by normal wear and tear, accidents or abuse, including burned voice coils caused by overdriving the speaker (amplifier level is turned up and driven into distortion or clipping). Speaker mechanical failure (e.g. punctures, tears or rips). Cracked or damaged LCD panels. Dropped or damaged hard
- Damage caused by negligence, misuse, improper operation or failure to follow instructions contained in the Owner's manual.
- Damage caused by an act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature. Any cost or expense related to the removal or reinstallation of the Product.
- Service performed by an unauthorized person. company or association.
- Any Product which has the serial number defaced, altered or removed.
- Any Product which has been adjusted, disassembled, altered or modified without Alpine's consent.
- Any Product not distributed by Alpine within the United States, Puerto Rico or Canada.
- (i) Any Product not purchased from an Authorized Alpine Dealer.

OHOW TO OBTAIN WARRANTY SERVICE:

- You are responsible for delivery of the Product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option, repair or replace the Product with a new or reconditioned product without charge. If the repairs are covered by this Limited Warranty, and if the Product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges. The repaired or replaced Product will continue to be covered under the original Limited Warranty period.
- You should provide a detailed description of the problem(s) for which service is required.
- To You must supply proof of your purchase of the
- You must package the Product securely to avoid damage during shipment. To prevent lost packages. it is recommended to use a carrier that provides a tracking service.

6HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON OR THIRD PARTY IS AUTHORIZED TO ADD TO, MODIFY, OR EXTEND THE TERMS OF THIS LIMITED WARRANTY AND/OR ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

OHOW WE EXCLUDE CERTAIN DAMAGES:

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, ALPINE AND ITS PARENT COMPANY, AFFILIATES, AND SUBSIDIARIES EXPRESSLY DISCLAIM LIABILITY TO YOU UNDER ANY THEORY OF LIABILITY FOR ALL INCIDENTAL, INDIRECT DAMAGES, SPECIAL, PUNITIVE, AND CONSEQUENTIAL DAMAGES WHICH MAY BE INCURRED BY YOU IN RELATION TO THE PRODUCT, THE TERM INCIDENTAL DAMAGES INCLUDES, BUT IS NOT LIMITED TO, COSTS AND EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHER COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT, THE TERM CONSEQUENTIAL DAMAGES INCLUDES, BUT IS NOT LIMITED TO, THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY, TO THE EXTENT PERMITTED BY APPLICABLE LAW, THIS LIMITED WARRANTY AND THE REMEDIES PROVIDED HEREUNDER ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE TOTAL LIABILITY OF ALPINE, ITS PARENT COMPANY, AFFILIATIES, AND SUBSIDIARIES IN CONNECTION WITH THIS LIMITED WARRANTY AND/OR THE PRODUCT SHALL NOT EXCEED THE AMOUNT YOU ACTUALLY PAID FOR THE PRODUCT.

@HOW STATE/PROVINCIAL LAW RELATES TO THE LIMITEDWARRANTY:

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/ provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

If any of the terms of this Limited Warranty are held to be null, void, illegal or unenforceable for any reason, the remaining terms of this Limited Warranty will remain in full force and effect.

For warranty service in the Canadian market, contact: Phone: (905) 513-7733 Fax: (905) 513-7740 Email: info@gentec-intl.com Or visit our website at http://www.alpine-canada.com

@HOW TO CONTACT CUSTOMER SERVICE:

Should the Product require service, please call the following: number for your nearest Authorized Alpine Service Center.

CUSTOMER SERVICE 1-800-421-2284, ext. 860304 TECH SUPPORT 1-800-TECH-101 [1-800-832-4101]

Or visit our website at http://www.alpine-usa.com

This Limited Warranty is provided by ALPINE ELECTRONICS OF AMERICA, INC., whose principal office is at 1500 Atlantic Blvd, Auburn Hills, MI 48326, U.S.A.

Do not send Products to this address.

Call the toll-free telephone number or visit the website to locate a service center.



GARANTIE LIMITÉE

OPRODUITS COUVERTS:

La présente Garantie Limitée (la « Garantie Limitée ») couvre les produits audio pour la voiture d'Alpine et les accessoires connexes (le « Produit »). Les produits achetés au Canada sont couverts au Canada seulement. Les produits achetés aux États-Unis sont couverts aux États-Unis seulement.

ODURÉE DE LA GARANTIE :

La présente Garantie d'une durée d'un (1) an entre en vigueur à la date d'achat au détail originale du produit.

GOULEST COUVERT:

La présente Garantie couvre uniquement l'acheteur d'origine du produit, qui doit résider aux États-Unis, à Puerto Rico ou au Canada.

OCE QUI EST COUVERT :

La présente Garantie couvre les vices de matériau ou de fabrication (pièces et main-d'œuvre) du produit, dans le cadre de son utilisation normale.

OCE QUI N'EST PAS COUVERT :

La présente Garantie ne couvre pas ce qui suit :

 Les dommages occasionnés pendant l'expédition du produit à Alpine pour obtenir une réparation (les demandes doivent être présentées à la compagnie de transport).

- ① Les dommages causés par l'usure normale, les incidents ou l'abus, incluant le bris des bobines acoustiques causé par l'usuge abusil du haut-parleur (niveau de l'amplificateur trop haut, causant de la distorsion ou de l'écrétage). La défaillance mécarrique du haut-parleur (p. ex. trous, déchirures ou accrocs). Les panneaux ACL craqués ou endommagés. Les disques durs échappés ou endommagés.
- ① Les dommages causés par la négligence, le mauvais usage, l'utilisation abusive ou le non-respect des instructions présentées dans le Guide d'utilisation.
- (4) Les dommages causés par les catastrophes naturelles, y compris mais sans s'y limiter, les séismes, les incendies, les inondations, les tempêtes ou d'autres calamités naturelles. Les coûts ou les frais reliés au retrait ou à la réinstallation du produit.
- Une réparation effectuée par une personne, une entreprise ou une association non autorisée.
- Tout produit dont le numéro de série est abimé, altéré ou effacé.
- (2) Tout produit ajusté, démonté, altéré ou modifié sans l'approbation d'Alpine.
- Tout produit qui n'est pas distribué par Alpine aux États-Unis, à Puerto Rico ou au Canada.
- Tout produit qui n'a pas été acheté chez un distributeur Alpine agréé.

OCOMMENT SE PRÉVALOIR DE LA GARANTIE :

- Vous êtes responsable de la livraison du produit à un centre de réparation Alpine agréé pour obtenir une réparation, ainsi que des frais d'expédition initieux. Alpine choisirs, à sa discrétion, de réparatr ou de remplacer le produit par un nouveau produit ou un produit remis à neuf sans frais. Si les réparations sont couvertes par la présente Garantie, et ai le produit a été expédié à un centre de réparation Alpine agréé ou directement à Alpine, Alpine payers les frais d'expédition du retour. La produit réparé ou remplacé continuers à être couvert par la période initiale de la Garantie.
- ② Vous devez fournir une description détaillée du ou des problèmes qui nécessitent une réparation.
- Vous devez fournir une preuve d'achat du produit.
- (i) Vous devez emballer le produit de façon sécuritaire, pour éviter tout dommage durant l'expédition. Pour prévenir la perte du colla, nous recommandons l'utilisation d'une compagnie de transport qui offre un service de suivi.

•QUELLES SONT LES LIMITES DES GARANTIES IMPLICITES :

TOUTE GARANTIE IMPLICITE, Y COMPRIS L'APTITUDE À UN USAGE PARTICULIER ET LA QUALITÉ MARCHANDE, EST LIMITÉE DANS LE TEMPS À LA PÉRIODE DE LA GARANTIE EXPRESSE ENONCÉE CI-DESSUS ET AUCUNE PERSONNE OU TIERCE PARTIE N'EST AUTORISÉE À AUOUTER, MODIFIER OU ÉTENDRE LES TERMES DE CETTE GARANTIE LIMITÉE ET/OU À ASSUMER AU NOM D'ALPINE TOUTE AUTRE RESPONSABILITÉ EN RAPPORT AVEC LA VENTE DU PRODUIT.

QUELS SONT LES DOMMAGES NON COUVERTS: DANS LA MESURE MAXIMALE PERMISE PAR LA LOI APPLICABLE, ALPINE ET SA SOCIÉTÉ MÊRE, SES FILIALES ET SES SOCIÉTÉS AFFILIÉES DÉCLINENT EXPRESSÉMENT TOUTE RESPONSABILITÉ ENVERS VOUS EN VERTU DE TOUTE THÉORIE DE RESPONSABILITÉ POUR TOUS LES DOMMAGES ACCESSORES, INDIRECTS, SPÉCIALIX, PUNITIFS ET CONSECUTIFS QUI POURRAIENT ÉTRE ENCOURUS PAR VOUS EN RELATION AVEC LE PRODUIT. LE TERME DOMMAGES ACCESSOIRES COMPREND, MAIS SANS S'Y LIMITER, LES COUTS ET LES FRAIS DE TRANSPORT DU PRODUIT AU CENTRE DE RÉPARATION ALPINE, LA PERTE DE TEMPS DE L'ACHETEUR INITIAL, LA PERTE D'UTILISATION DU PRODUIT, LES FRAIS D'AUTOBUS, DE LOCATION DE VÉHICULE OU D'AUTRES FRAIS LIÉS AU SOIN ET À LA GARDE DU PRODUIT. LE TERME DOMMAGES CONSECUTIFS COMPREND MAIS SANS S'Y LIMITER, LE COÛT DE LA RÉPARATION. OU DU REMPLACEMENT D'AUTRES BIENS QUI SONT ENDOMMAGÉS LORSQUE CE PRODUIT NE FONCTIONNE PAS CORRECTEMENT, DANS LA MESURE OÙ LA LOI APPLICABLE LE PERMET, LA PRÉSENTE GARANTIE ET LES RECOURS PRÉVUS PAR LA PRÉSENTE SONT EXCLUSIFS ET REMPLACENT TOUS LES AUTRES. DANS LA MESURE MAXIMALE PERMISE PAR LA LOI APPLICABLE, LA RESPONSABILITÉ TOTALE D'ALPINE, DE SA SOCIÉTE MÉRE, DE SES SOCIÉTÉS AFFILIÉES ET DE SES FILIALES EN RAPPORT AVEC LA PRÉSENTE GARANTIE ET/OU LE PRODUIT NE DOIT PAS DÉPASSER LE MONTANT QUE VOUS AVEZ EFFECTIVEMENT PAYÉ POUR LE PRODUIT.

OCOMMENT LA LOI DE L'ÉTAT/LA PROVINCE AFFECTE LA GARANTIE :

La présente Garantie vous confère des droits légaux spécifiques, et vous pourriez bénéficier d'autres droits qui variers d'un État ou d'une province à l'autre. De plus, certains États/certaines provinces ne permettent pas les limites de durée pour les garanties implicites, et d'autres ne permettent pas l'exclusion ou la limitation des dommages indirects. Les limitations susmentionnées pourraient donc ne pas s'appliquer dans votre cas.

Si l'une des conditions de la présente Garantie est considérée comme nulle, invalide, illégale ou inapplicable pour quelque raison que ce soit, les autres conditions de la présente Garantie resteront pleinement en vigueur.

Pour se prévaloir de la garantie sur le marché canadien, contactez : Téléphone : 905-513-7733 Télécopieur : 905-513-7740 Courriel : info@gentec-intl.com Ou visitez notre site Web au http://www.alpine-canada.com

OCOMMENT PRENDRE CONTACT AVEC LE SERVICE À LA CLIENTÈLE :

Si le produit doit être réparé, veuillez téléphoner au numéro auvant afin de connaître le centre de réparation Alpine agréé le plus près de chez vous.

SERVICE À LA CLIENTÉLE 1-800-421-2284, poste 860304 ASSISTANCE TECHNIQUE 1-800-TECH-101 (1-800-832-4101)

Ou visitez notre site Web au http://www.alpine-usa.com

La présente Garantie est fournie par ALPINE ELECTRONICS OF AMERICA, INC., dont le siège social se trouve au 1500 Atlantic Blvd, Auburn Hills, MI 48326, États-Unis.

N'envoyez pas de produits à cette adrosse.

Téléphonez au numéro sans frais ou visitez le site Web pour trouver un centre de réparation.



REGISTER YOUR PRODUCT

Register your Alpine product(s) to help us track your warranty and get access to exclusive content, giveaways and special offers.



REGISTER ONLINE

Visit alpineusa.link/register



TEXT TO REGISTER

Text "ALPINE" to 71739 (US Only)

One message per opt-in. Text "HELP" for help. Text "STOP" to cancel. Message and data rates may apply. See full privacy policy and SMS terms at www.alpine-usa.com/terms-of-use



SCAN TO REGISTER

Scan the QR Code below using your phone or device



