

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate
www.vevor.com/support

RETRACTABLE EXTENSION CORD REEL USER MANUAL

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.


VEVOR[®]

RETRACTABLE EXTENSION CORD REEL

ZX-ZD200 65FT

ZX-ZD200 80FT

ZX-ZD200 75FT



ACCESSORIES

NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. **VEVOR** reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

- ◆ **Warning:** To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.
 - ◆ **Danger:** Electrical cord can be hazardous Le cordon électrique peut être dangereux.
1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
 2. Do not try to plug it in when your hands are wet or damp.
 3. Never attempt to plug the cord reel into a non-grounded outlet.
 4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
 5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
 6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
 7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
 8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
 9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
 10. Do not disassemble the body of the reel.
 11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Cat. No.:	ZX-ZD200		
Input Voltage:	125VAC, 60Hz		
Max Power Rating:	15A		13A
Cord:	12AWG, SJTOW		14AWG, SJTOW
Lead-in Cord Length:	4 1/2 FT		
Length:	65FT	80FT	75FT

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: See specification sheet for fully extended lengths wires of different sizes. DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- a. Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - b. Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
1. Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 2. Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 3. Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 4. Adjust the cord stopper to a suitable position when required.


Figure 1



Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut


Install the bracket with the wood screws (Suitable for wood)



Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)



Technical Support and E-Warranty Certificate
www.vevor.com/support



Assistance technique et certificat de garantie
électronique www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Nous continuons à nous engager à vous fournir des outils à des prix compétitifs. "Économisez la moitié", "Moitié prix" ou toute autre expression similaire que nous utilisons ne représente qu'une estimation des économies dont vous pourriez bénéficier en achetant certains outils chez nous par rapport aux grandes marques et ne signifie pas nécessairement couvrir toutes les catégories d'outils proposés. par nous. Nous vous rappelons de vérifier attentivement lorsque vous passez une commande chez nous si vous économisez réellement la moitié par rapport aux grandes marques.

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65 PI
ZX-ZD200 80 PI
ZX-ZD200 75 PI



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Assistance technique et certificat de garantie électronique www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

- ◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**
 - ◆ **Danger:** Electrical cord can be hazardous Le cordon électrique peut être dangereux.
1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
 2. Do not try to plug it in when your hands are wet or damp.
 3. Never attempt to plug the cord reel into a non-grounded outlet.
 4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
 5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
 6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
 7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
 8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
 9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
 10. Do not disassemble the body of the reel.
 11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Chat. Non.:	ZX-ZD200		
Tension d'entrée:	125 VCA, 60 Hz		
Puissance nominale maximale :	15A		13A
Corde:	12AWG, SJTOW		14AWG, SJTOW
Longueur du cordon d'entrée :	4 1/2 PI		
Longueur:	65 pieds	80 pieds	75 pieds

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Voir la fiche technique pour les longueurs entièrement étendues de différentes tailles.
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
- Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 - Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 - Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 - Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

OUTILS ROBUSTES, À MOITIÉ PRIX

Assistance technique et certificat de garantie
électronique www.vevor.com/support



Technischer Support und E-Garantie-Zertifikat
www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Wir sind weiterhin bestrebt, Ihnen Werkzeuge zu wettbewerbsfähigen Preisen anzubieten. „Sparen Sie die Hälfte“, „Halber Preis“ oder andere ähnliche Ausdrücke, die wir verwenden, stellen nur eine Schätzung der Ersparnis dar, die Sie beim Kauf bestimmter Werkzeuge bei uns im Vergleich zu den großen Topmarken erzielen können, und decken nicht unbedingt alle von uns angebotenen Werkzeugkategorien ab. Wir möchten Sie freundlich daran erinnern, bei Ihrer Bestellung bei uns sorgfältig zu prüfen, ob Sie im Vergleich zu den großen Topmarken tatsächlich die Hälfte sparen.

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65FT
ZX-ZD200 80FT
ZX-ZD200 75FT



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Technischer Support und E-Garantie-Zertifikat www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**

◆ Gefahr: Das Stromkabel kann gefährlich sein. Das Stromkabel kann gefährlich sein.

1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
2. Do not try to plug it in when your hands are wet or damp.
3. Never attempt to plug the cord reel into a non-grounded outlet.
4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
10. Do not disassemble the body of the reel.
11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Katze nein.:	ZX-ZD200		
Eingangsspannung:	125 V Wechselstrom, 60 Hz		
Maximale Leistungsbewertung:	15A	13A	
Kabel:	12AWG, SJTOW	14AWG, SJTOW	
Länge des Zuleitungskabels:	4 1/2 FT		
Länge:	65 Fuß	80 Fuß	75 Fuß

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Siehe Datenblatt für vollständig ausgeführte Längen von Armbändern verschiedener Größen
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- a. Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
- b. Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
1. Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
2. Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
3. Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
4. Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

ROBUSTE WERKZEUGE ZUM HALBEN PREIS

Technischer Support und E-Garantie-Zertifikat
www.vevor.com/support



**Supporto tecnico e certificato di garanzia
elettronica www.vevor.com/support**


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Continuiamo a impegnarci per fornirvi strumenti a prezzi competitivi. "Risparmia la metà", "Metà prezzo" o qualsiasi altra espressione simile da noi utilizzata rappresenta solo una stima del risparmio che potresti trarre dall'acquistare determinati strumenti con noi rispetto ai principali marchi più importanti e non significa necessariamente coprire tutte le categorie di strumenti offerti da noi. Ti ricordiamo di verificare attentamente quando effettui un ordine con noi se stai effettivamente risparmiando la metà rispetto ai migliori marchi p

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65FT
ZX-ZD200 80FT
ZX-ZD200 75FT



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Supporto tecnico e certificato di garanzia elettronica www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**

◆ Pericolo: il cavo elettrico può essere pericoloso Il cavo elettrico può essere pericoloso.

1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
2. Do not try to plug it in when your hands are wet or damp.
3. Never attempt to plug the cord reel into a non-grounded outlet.
4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
10. Do not disassemble the body of the reel.
11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Gatto. NO.:	ZX-ZD200		
Tensione di ingresso:	125 V CA, 60 Hz		
Potenza nominale massima:	15A		13A
Cavo:	12AWG, SJTOW		14AWG, SJTOW
Lunghezza del cavo di ingresso:	4 1/2 piedi		
Lunghezza:	65 piedi	80 piedi	75 piedi

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Consultare la scheda tecnica per le lunghezze completamente estese di diverse dimensioni
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
- Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 - Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 - Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 - Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

STRUMENTI RESISTENTI, METÀ PREZZO

**Supporto tecnico e certificato di garanzia
elettronica www.vevor.com/support**



Soporte técnico y certificado de garantía
electrónica www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Seguimos comprometidos a proporcionarle herramientas a precios competitivos. "Ahorre a mitad de precio", "A mitad de precio" o cualquier otra expresión similar utilizada por nosotros solo representa una estimación de los ahorros que podría beneficiarse al comprar ciertas herramientas con nosotros en comparación con las principales marcas y no significa necesariamente cubrir todas las categorías de herramientas ofrecidas. por nosotros. Le recordamos que, cuando realice un pedido con nosotros, verifique cuidadosamente si realmente está ahorrando la mitad en comparación con las principales marcas.

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65 PIES
ZX-ZD200 80PIES
ZX-ZD200 75 PIES



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Soporte técnico y certificado de garantía electrónica www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

- ◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**
- ◆ Peligro: El cable eléctrico puede ser peligroso El cable eléctrico puede ser peligroso.
- 1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
- 2. Do not try to plug it in when your hands are wet or damp.
- 3. Never attempt to plug the cord reel into a non-grounded outlet.
- 4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
- 5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
- 6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
- 7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
- 8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
- 9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
- 10. Do not disassemble the body of the reel.
- 11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Gato. No.:	ZX-ZD200		
Voltaje de entrada:	125 VCA, 60 Hz		
Clasificación de potencia máxima:	15A	13A	
Cable:	12AWG, SJTOW	14AWG, SJTOW	
Longitud del cable de entrada:	4 1/2 PIES		
Longitud:	65 pies	80 pies	75 pies

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Consulte la hoja de especificaciones para longitudes completamente extendidas de diferentes tamaños:
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
- Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 - Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 - Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 - Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

HERRAMIENTAS RESISTENTES A MITAD DE PRECIO

Soporte técnico y certificado de garantía
electrónica www.vevor.com/support



Wsparcie techniczne i certyfikat e-gwarancji
www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Nadal dokładamy wszelkich starań, aby zapewnić Państwu narzędzia w konkurencyjnej cenie. „Zaoszczędź o połowę”, „o połowę ceny” lub inne podobne wyrażenia używane przez nas przedstawiają jedynie szacunkową oszczędność, jaką możesz zyskać kupując u nas określone narzędzia w porównaniu z głównymi najlepszymi markami i niekoniecznie oznaczają uwzględnienie wszystkich kategorii oferowanych narzędzi przez nas. Przypominamy, aby podczas składania zamówienia u nas dokładnie sprawdzić, czy faktycznie oszczędzasz połowę w porównaniu z czołowymi markami.

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65FT
ZX-ZD200 80FT
ZX-ZD200 75FT



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Wsparcie techniczne i certyfikat e-gwarancji www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. **VEVOR** reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**

◆ Niebezpieczeństwo: Przewód elektryczny może być niebezpieczny. Przewód elektryczny może być niebezpieczny.

1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
2. Do not try to plug it in when your hands are wet or damp.
3. Never attempt to plug the cord reel into a non-grounded outlet.
4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
10. Do not disassemble the body of the reel.
11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Kot. NIE.:	ZX-ZD200		
Napięcie wejściowe:	125 V AC, 60 Hz		
Maksymalna moc znamionowa:	15A		13A
Sznur:	12AWG, SJTOW		14AWG, SJTOW
Długość przewodu wejściowego:	4 1/2 stopy		
Długość:	65FT	80FT	75FT

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Zobacz arkusz specyfikacji, aby zapoznać się z całkowicie rozciągniętymi długościami i różnymi rozmiarami
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- a. Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - b. Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
1. Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 2. Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 3. Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 4. Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

WYTRZYMAŁE NARZĘDZIA, ZA PÓŁ CENY

Wsparcie techniczne i certyfikat e-gwarancji
www.vevor.com/support



Technische ondersteuning en e-
garantiecertificaat www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

We blijven ons inzetten om u gereedschap tegen een concurrerende prijs te bieden. "Bespaar de helft", "Halve prijs" of andere soortgelijke uitdrukkingen die door ons worden gebruikt vertegenwoordigt slechts een schatting van de besparingen die u zou kunnen profiteren als u bepaalde gereedschappen bij ons koopt in vergelijking met de grote topmerken en betekent niet noodzakelijkerwijs dat deze alle categorieën van aangeboden gereedschappen omvatten door ons. Wij verzoeken u vriendelijk om bij het plaatsen van een bestelling bij ons goed na te gaan of u daadwerkelijk de helft bespaart in vergelijking met de grote topme

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65FT
ZX-ZD200 80FT
ZX-ZD200 75FT



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Technische ondersteuning en e-garantiecertificaat www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. VEVOR reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

- ◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**
 - ◆ **Gevaar: Elektriciteitssnoer kan gevaarlijk zijn Het elektriciteitssnoer kan gevaarlijk zijn.**
1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
 2. Do not try to plug it in when your hands are wet or damp.
 3. Never attempt to plug the cord reel into a non-grounded outlet.
 4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
 5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
 6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
 7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
 8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
 9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
 10. Do not disassemble the body of the reel.
 11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Kat. Nee.:	ZX-ZD200		
Ingangsspanning:	125VAC, 60Hz		
Maximaal vermogen:	15A		13A
Koord:	12AWG, SJTOW		14AWG, SJTOW
Lengte inloopsnoer:	4 1/2 voet		
Lengte:	65FT	80FT	75FT

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Zie het specificatieblad voor volledig uitgeschoven lengtes van verschillende afmetingen
DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- a. Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - b. Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
1. Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 2. Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 3. Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 4. Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR[®]

STERK GEREEDSCHAP, HALVE PRIJS

**Technische ondersteuning en e-
garantiecertificaat www.vevor.com/support**



Teknisk support och e-garanticertifikat
www.vevor.com/support


RETRACTABLE EXTENSION CORD REEL USER MANUAL

Vi fortsätter att vara engagerade i att ge dig verktyg till konkurrenskraftiga priser. "Spara hälften", "halva priset" eller andra liknande uttryck som används av oss representerar bara en uppskattning av besparingar du kan dra nytta av att köpa vissa verktyg hos oss jämfört med de stora toppmärkena och betyder inte nödvändigtvis att täcka alla kategorier av verktyg som erbjuds av oss. Du påminns vänligen om att noggrant kontrollera när du gör en beställning hos oss om du faktiskt sparar hälften i jämförelse med de främsta stora varumärkena.

VEVOR[®]

RETRACTABLE
EXTENSION CORD REEL

ZX-ZD200 65FT
ZX-ZD200 80FT
ZX-ZD200 75FT



ACCESSORIES			
NO.	Part name	QTY	Remark
1	Bracket	1	
2	Expansion screw	4	
3	Wood screw	4	
4	Set screw	1	

NEED HELP? CONTACT US!

Have product questions? Need technical support?
Please feel free to contact us:

Teknisk support och e-garanticertifikat www.vevor.com/support

This is the original instruction, Please read all manual instructions carefully before operating. **VEVOR** reserves clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there is any technology or software updates on our product.

WARNING

- ◆ **Warning: To reduce the risk of fire, electric shock or personal injury, please strictly follow the instructions.**
 - ◆ Fara: Elsladden kan vara farlig Elsladden kan vara farlig.
1. Do not connect any devices which may exceed the maximum ratings of this cord reel.
 2. Do not try to plug it in when your hands are wet or damp.
 3. Never attempt to plug the cord reel into a non-grounded outlet.
 4. When pulling the cord from the cord reel, grasp the reel's cord itself, but not the device or tool that the cord is plugged into.
 5. Do not allow the cable to retract without restraining the retraction speed as damage or injury may occur from excessive rewind speed.
 6. Inspect before every use; do not use if parts are loose or damaged or if insulation is worn.
 7. Always unplug the retractable reel from its electrical outlet before performing any maintenance or changing accessories.
 8. Do not connect wires randomly. Connect black wires with "L", white wires with "N", and green wires with "E".
 9. When automatically retracting, a slow wire collection operation may lead to stagnation. The power cord needs to be pulled out a little, then release, and use its recovered inertia to completely retract the cable.
 10. Do not disassemble the body of the reel.
 11. Children are not allowed to use the cord reel.

OPERATION

1. Plug the lead-in cord into the grounded outlet.
2. Pull cord out to the desired length. Notice a clicking noise when pulling the cord. The cord will stay at the desired length during the clicking and rewind after a pull past the clicking noise.
3. To retract, pull the cord out and guide it slowly back into the reel.

SPECIFICATIONS

Katt. Nej.:	ZX-ZD200		
Inspänning:	125VAC, 60Hz		
Max effektvärde:	15A		13A
Sladd:	12AWG, SJTOW		14AWG, SJTOW
Längd inledningssladd:	4 1/2 FT		
Längd:	65FT	80FT	75FT

ONE YEAR LIMITED WARRANTY


VEVOR warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase. Warranty is void if damage is caused by misuse or improper installation.

NOTE: Se specifikationsblad för helt utdragna längder av olika storlekar . DO NOT keep on pulling the cord after it is fully extended.


INSTALLATION

- a. Check the wall or ceiling surface to which the retractable reel will be mounted to make sure they are sturdy enough to support the weight of the reel as well as the additional force when pulling on the outlet power cord.
 - b. Drywall will not hold the weight of the cord reel. It is necessary to locate a ceiling joist or wall stud.
1. Select a mounting location within 4 feet of an electrical outlet. The outlet for a garage door opener is ideal.
 2. Locate a wall or ceiling beam (use a stud finder, if needed) and fix the separate bracket to the wall or ceiling beam with cement screws or wood screws, see Figure 1.
 3. Slide the mounting bracket of the cord reel into the separate bracket, fix the set screw, see Figure 2.
 4. Adjust the cord stopper to a suitable position when required.


Figure 1




Mark with a pen according to the mounting position (Suitable for concrete materials)




Drill four 45-50mm deep holes with 10mm drill bits




Install the expansion screws into the holes




Install the bracket with the anchor bolt and tighten the nut




Install the bracket with wood screws (Suitable for wood)




Mark with a pen according to the mounting position (Suitable for concrete)



Drill four 45-50mm deep holes with 10mm drill bits



Install the expansion screws into the holes



Install the bracket with the anchor bolt and tighten the nut

Install the bracket with the wood screws (Suitable for wood)






Figure 2



Slide the mounting bracket of the cord reel into the separate bracket as shown (No need to use the set screw)



Slide the mounting bracket of the cord reel in the separate bracket as shown

Fix the set screw. (Please pay attention to the position of the set screw, do not fix it to another side or the cord reel will fall off.)

VEVOR®

HÅRA VERKTYG, HALVA PRISET

Teknisk support och e-garanticertifikat
www.vevor.com/support