

RMS-TD-PROFINET


Humidity & Temperature Transmitter

Table of content

1. Introduction.....	3
1.1 Information about this operating manual.....	3
1.2 Limitation of liability.....	3
2. For your safety.....	4
2.1 Proper use.....	4
2.2 Improper use.....	4
2.3 User qualifications.....	4
2.4 General safety information.....	4
2.5 Warranty.....	4
3. On receipt of your device.....	5
3.1 Taking the device out of its packaging.....	5
3.2 Making sure that all of the components have been included.....	5
3.2.1 Scope of supply.....	5
4. Installation of the transmitter.....	5
4.1 Laying of the supply line or transmission line.....	5
4.2 Mounting the transmitter.....	6
4.3 Pin assignment.....	7
4.4 Wiring Diagram.....	7
5. Integration into a B&R control system.....	8
5.1 GSD package.....	8
5.2 Settings on the B&R Profinet master.....	8
5.3 Settings on the B&R Profinet-Slave.....	10
5.4 Settings on the B&R software.....	12
5.5 Program code in ANSI C for integration.....	13
6. Technical drawing RMS-TD-PROFINET.....	15
7. Adjustment behavior of the sensor.....	15
8. Definition relative humidity.....	16
8.1 Application range.....	16
9. Cleaning and maintenance.....	17
9.1 Care instructions.....	17
9.2 Cleaning the device.....	17
10. Checking the calibration.....	17
10.1 Assembling the calibration equipment.....	17
10.2 Determining the deviation.....	18
11. Faults.....	19
12. Warranty.....	20

RMS-TD-PROFINET

Humidity & Temperature Transmitter



No.	Name
1	Air humidity and temperature sensor
2	Sensor head
3	Sensor cable (0.25m)
4	Aluminium housing
5	Sensor plug
6	RJ45 plug
7	Mounting bracket

RMS-TD-PROFINET

Humidity & Temperature Transmitter

1. Introduction

1.1 Information about this operating manual

This operating manual is designed to enable you to use the [RMS-TD-PROFINET](#) safely and effectively. It is part of the device, has to be stored nearby and must be easily accessible to users at all times. All users are required to carefully read and make sure that they have understood this operating manual before using the [RMS-TD-PROFINET](#). All of the safety and operating instructions detailed in this manual have to be observed to ensure the safety of the device.

1.2 Limitation of liability

All of the information and instructions provided in this operating manual have been compiled on the basis of the current standards and regulations, the state of the art, and the extensive expertise and experience of Checkline Europe BV. Checkline Europe BV does not accept any liability for damage associated with the following, which also voids the warranty:

- Non-observance of this operating manual
- Improper use
- Inadequately qualified users
- Unauthorized modifications
- Technical changes
- Use of unapproved spare parts

This fast measuring procedure can be affected by a range of different factors. We, as the manufacturer, do not accept any liability for any incorrect measurements and associated consequential damage.

1.3 Customer service

For technical advice, please contact our customer service. Your purchased measuring instrument can be calibrated, and the adjustment checked by using suitable test ampoules / calibration ampoules. For this purpose, use only the calibration solutions distributed by Checkline Europe.



RMS-TD-PROFINET

Humidity & Temperature Transmitter

2. For your safety

The device complies with the following European directives:

- Restriction of Hazardous Substances in Electrical and Electronic Equipment (RoHS) •
- Electromagnetic compatibility (EMC) The device corresponds to state-of-the-art technology. However, it is still associated with a number of residual hazards. These hazards can be avoided through strict observance of our safety information.

2.1 Proper use

- Transducer for measuring and transmitting relative humidity and temperature in fixed installation • The sensor technology used makes it possible to detect even small fluctuations in humidity and their tendencies quickly and reliably so that preventive actions can be taken.
- For some applications (e.g. installation in sewage pipes) it is necessary to use a remote measuring probe for the reason of temperature adjustment.

2.2 Improper use

- The device must not be used in ATEX.

2.3 User qualifications

The device must only be operated by people who can be expected to reliably take the measurements. The device must not be operated by people whose reaction times may be slowed due to, e.g. the use of drugs, alcohol or medication.

All persons using this device must have read, understood and follow the instructions provided in the operating manual.

2.4 General safety information

The following safety information has to be observed at all times to avoid damage to objects and injury to people:

- In case of damages or loose parts on the device, contact Checkline Europe.

All of the device's technical features have been inspected and tested before delivery. Every device has a serial number. Do not remove the tag with the serial number.

2.5 Warranty

The warranty does not apply to:

- Damage resulting from non-observance of the operating manual
- Damage resulting from third-party interventions
- Products that have been used improperly or modified without authorisation
- Products with missing or damaged warranty seals

RMS-TD-PROFINET

Humidity & Temperature Transmitter

- Damage resulting from force majeure, natural disasters, etc.
- Damage from improper cleaning

3. On receipt of your device

3.1 Taking the device out of its packaging

- Take the device out of its packaging.
- Next, make sure that it is not damaged and that no parts are missing.

3.2 Making sure that all of the components have been included

Make sure that all of the components have been included by checking the package contents against the following list:

3.2.1 Scope of supply

- [RMS-TD-PROFINET](#)
- Connecting cable of 1.9 m length
- Operating manual
-

Optional accessories:

- Display for RMS-TD
- Display with keypad for RMS-TD
- Relay output for moisture for RMS-TD
- Mounting bracket for RMS-TD
- Drip-catcher for RMS-TD
- Stainless steel sinter sensor cap, stainless steel sinter filter:
- Custom-made design - flat rate for air humidity transmitter series per order
- Factory calibration certificate, calibration equipment, certified calibration ampoules and reference devices - for continuous monitoring

4. Installation of the transmitter

4.1 Laying of the supply line or transmission line

- The cable must not be laid in the area of interference fields.
- Do not operate the transmitter in the area of electromagnetic interference fields.
- The permissible cross-sections for the installation must be observed.
- The cable length must be kept as short as possible. » If an extension of the cable is required, the cross-section of the extension must not be below 0,25 mm².


RMS-TD-PROFINET

Humidity & Temperature Transmitter

- If the electronics housing and the display electronics are grounded, an appropriate equipotential bonding conductor must be provided.

4.2 Mounting the transmitter


- The measuring probe must be positioned at a representative location.
 - » Avoid positions of drought and unnatural temperature fluctuations.
 - » Do not expose the device to direct sunlight.
- If the sensor tube is twisted, the tightness is no longer guaranteed.
- When there is a possibility of condensation, position the sensor probe slightly upwards (approx. 10 degrees angle).
 - » The condensation water can then flow away from the sensor probe towards the housing or cable and drain off.
 - » If it is impossible to place the unit at an upward angle, a drip nose (optional accessory) must be installed.
- Installation inside an air duct (or at mounting locations where temperature differences between sensor probe and sensor housing may occur):
 - » The sensor must be inserted fully into the opening until it stops, to avoid a temperature drop along the sensor tube. See picture:



RMS-TD-PROFINET


Humidity & Temperature Transmitter

4.3 Pin assignment



Cable color	Pin no	Function
Brown	1	Power supply V- (0 VDC) / Ground current output
White	2	Power supply V+ (12 to 29 VDC)
Blue	3	Analogue output humidity 4 - 20 mA
Black	4	n.c.
Grey	5	Analogue output temperature 4 - 20 mA
Purple	Housing	Equipotential bonding GND

4.4 Wiring Diagram




RMS-TD-PROFINET

Humidity & Temperature Transmitter

5. Integration into a B&R control system


5.1 GSD package

- The GSD package required for integration into a control system is provided by Checkline
- The GSD package is a zip file containing the required GSD file and the instructions.
» The integration was realised with a B&R controller. •
- The Profinet sensor is connected to the Profinet master using a suitable Ethernet cable (figure 1).



5.2 Settings on the B&R Profinet master


1. IP address of the master




RMS-TD-PROFINET

Humidity & Temperature Transmitter

2. Station name of the sensor: „schaller-lftd2020“




3. The IP address of the sensor is assigned by the controller:



4. From the controller's point of view, 8 words (16BIT) are defined as inputs and 8 words (16BIT) as outputs.

» These settings must be identical on the master and on the sensor for communication to work.



RMS-TD-PROFINET

Humidity & Temperature Transmitter

5. Overview address table Profinet stations „schaller-lftd2020“

The screenshot shows the RMS-TD-PROFINET software interface. At the top, it displays 'IO Device: NETX 100 RE/PHM' and 'Vendor: Hilscher GmbH'. On the right, 'Device ID: 0x0203' and 'Vendor ID: 0x011E' are shown. The left sidebar contains a 'Navigation Area' with options like 'Settings', 'Ethernet Devices', 'Configuration', 'Controller Network Settings', 'Device Table', 'IP Address Table', 'Process Data', 'Address Table' (selected), 'FSU-/Port- Settings', 'Stations Timing', and 'Controller Settings'. The main area is titled 'Address Table' and includes a checkbox for 'Auto addressing' and a 'Display mode' dropdown set to 'Decimal'. Below this, there are two tables: 'Inputs' and 'Outputs'. The 'Inputs' table has columns: Name of station, Module, Submodule, Type, Length, and Address. It contains one entry for 'schaller-lftd2020' with module 'ABP_UINT16_WRITE <Slot 1>' and submodule 'ABP_UINT16_WRITE <Subslot 1>', of type 'IB' and length '16'. The 'Outputs' table has the same columns and contains one entry for 'schaller-lftd2020' with module 'ABP_UINT16_READ <Slot 2>' and submodule 'ABP_UINT16_READ <Subslot 1>', of type 'QB' and length '16'.

Name of station	Module	Submodule	Type	Length	Address
schaller-lftd2020	ABP_UINT16_WRITE <Slot 1>	ABP_UINT16_WRITE <Subslot 1>	IB	16	

Name of station	Module	Submodule	Type	Length	Address
schaller-lftd2020	ABP_UINT16_READ <Slot 2>	ABP_UINT16_READ <Subslot 1>	QB	16	

5.3 Settings on the B&R Profinet-Slave

1. Overview Profinet sensor

The screenshot shows the 'General' settings page for the Profinet sensor. At the top, it displays 'IO Device: LFTD2020_V2_4X' and 'Vendor: Schaller Messtechnik GmbH'. On the right, 'Device ID: 0x0010' and 'Vendor ID: 0x010C' are shown. The left sidebar contains a 'Navigation Area' with options like 'Configuration', 'General' (selected), 'Modules', 'Description', 'Device Info', 'Module Info', and 'GSDML Viewer'. The main area is titled 'General' and contains fields for 'Name of station' (schaller-lftd2020) and 'Description' (LFTD2020_V2_4X). Below these are 'IP settings' with fields for 'IP address' (192.168.100.20), 'Network mask' (255.255.255.0), and 'Gateway address' (0.0.0.0). A note on the right states: 'Note: These values are set by the controller of the network!'.

Name of station	Description
schaller-lftd2020	LFTD2020_V2_4X

IP settings

IP address	Network mask	Gateway address
192.168.100.20	255.255.255.0	0.0.0.0

Note: These values are set by the controller of the network!

RMS-TD-PROFINET

Humidity & Temperature Transmitter

2. 8 x Input Register (16BIT)

IO Device: LFTD2020_V2_4X Device ID: 0x0010
Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area: Configuration, General, Modules, Description, Device Info, Module Info, GSDML Viewer

Modules

Slot	Sub Slot	Module
0	1	LFTD2020_V2_4X [LFTD2020_V2_4X]
	32768	Interface
	32769	Port 1
	32770	Port 2
1	1	ABP_UINT16_WRITE
	1	ABP_UINT16_WRITE
2	1	ABP_UINT16_READ
	1	ABP_UINT16_READ

Use of slots: 3/65
State of data length: Input 22/1440 Octets, Output 22/1440 Octets, In-Output 44/2880 Octets

Submodule details
Dataset: I/O data Display mode: Decimal

Direction	Consistence	Data type	Text ID	Length
INPUT	--	unsigned16	Humid	2
INPUT	--	unsigned16	Temp	2
INPUT	--	unsigned16	Status	2
INPUT	--	unsigned16	Counter(ms)	2
INPUT	--	unsigned16	SerialNr	2
INPUT	--	unsigned16	FWVersion	2
INPUT	--	unsigned16	M2HSerial	2
INPUT	--	unsigned16	ADI#1, Element#8	2

3. 8 x Output Register (16BIT)

IO Device: LFTD2020_V2_4X Device ID: 0x0010
Vendor: Schaller Messtechnik GmbH Vendor ID: 0x010C

Navigation Area: Configuration, General, Modules, Description, Device Info, Module Info, GSDML Viewer

Modules

Slot	Sub Slot	Module
0	1	LFTD2020_V2_4X [LFTD2020_V2_4X]
	32768	Interface
	32769	Port 1
	32770	Port 2
1	1	ABP_UINT16_WRITE
	1	ABP_UINT16_WRITE
2	1	ABP_UINT16_READ
	1	ABP_UINT16_READ

Use of slots: 3/65
State of data length: Input 22/1440 Octets, Output 22/1440 Octets, In-Output 44/2880 Octets

Submodule details
Dataset: I/O data Display mode: Decimal

Direction	Consistence	Data type	Text ID	Length
OUTPUT	--	unsigned16	ADI#2, Element#1	2
OUTPUT	--	unsigned16	ADI#2, Element#2	2
OUTPUT	--	unsigned16	ADI#2, Element#3	2
OUTPUT	--	unsigned16	ADI#2, Element#4	2
OUTPUT	--	unsigned16	ADI#2, Element#5	2
OUTPUT	--	unsigned16	ADI#2, Element#6	2
OUTPUT	--	unsigned16	ADI#2, Element#7	2
OUTPUT	--	unsigned16	ADI#2, Element#8	2

RMS-TD-PROFINET

Humidity & Temperature Transmitter

4. Device information Anybus module Profinet

IO Device:	LFTD2020_V2_4X	Device ID:	0x0010
Vendor:	Schaller Messtechnik GmbH	Vendor ID:	0x010C

Navigation Area	Device Info																								
Configuration General Modules Description ➔ Device Info Module Info GSDML Viewer	<table><thead><tr><th>Name</th><th>Value</th></tr></thead><tbody><tr><td>Main family</td><td>General</td></tr><tr><td>Product family</td><td>LFTD2020</td></tr><tr><td>DAP vendor name</td><td>Schaller Messtechnik GmbH</td></tr><tr><td>DAP hardware release</td><td>--</td></tr><tr><td>DAP software release</td><td>V2.40</td></tr><tr><td>Extended address assignment</td><td>false</td></tr><tr><td>Physical slots</td><td>0..64</td></tr><tr><td>Max. IO data length</td><td>2880</td></tr><tr><td>Max. input data length</td><td>1440</td></tr><tr><td>Max. output data length</td><td>1440</td></tr><tr><td>Info text</td><td>Schaller Messtechnik GmbH</td></tr></tbody></table>	Name	Value	Main family	General	Product family	LFTD2020	DAP vendor name	Schaller Messtechnik GmbH	DAP hardware release	--	DAP software release	V2.40	Extended address assignment	false	Physical slots	0..64	Max. IO data length	2880	Max. input data length	1440	Max. output data length	1440	Info text	Schaller Messtechnik GmbH
Name	Value																								
Main family	General																								
Product family	LFTD2020																								
DAP vendor name	Schaller Messtechnik GmbH																								
DAP hardware release	--																								
DAP software release	V2.40																								
Extended address assignment	false																								
Physical slots	0..64																								
Max. IO data length	2880																								
Max. input data length	1440																								
Max. output data length	1440																								
Info text	Schaller Messtechnik GmbH																								

5.4 Settings on the B&R software


The inputs and outputs are automatically created in the project and must now be assigned to the corresponding process variables.

Channel Name	Process Variable	Data Type	Task Class	Inverse	Simulate	Source File	Description [1]
➔ ModuleOk	LFTD20_Online	BOOL	Automatic	☐	☐	\4PP065_0571_P...	Module status (1 = module prese
➔ Module001_Humid	LFTD20_IN1	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_Temp	LFTD20_IN2	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_Status	LFTD20_IN3	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_Counter_ms	LFTD20_IN4	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_SerialNr	LFTD20_IN5	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_FWVersion	LFTD20_IN6	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_M2HSerial	LFTD20_IN7	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module001_ADI_1_Element_8	LFTD20_IN8	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_WRITE <Slot 1>
➔ Module002_ADI_2_Element_1		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_2		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_3		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_4		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_5		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_6		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_7		UINT					ABP_UINT16_READ <Slot 2>
➔ Module002_ADI_2_Element_8	LFTD20_CMD	UINT	Automatic	☐	☐	\4PP065_0571_P...	ABP_UINT16_READ <Slot 2>

RMS-TD-PROFINET

Humidity & Temperature Transmitter

Process variables:



Name	Type	Constant	Retain	Value	Description [1]
LFTD20_Online	BOOL	☐	☐		
LFTD20_Humid	REAL	☐	☐		
LFTD20_Humid_INT	INT	☐	☐		
LFTD20_Temp	REAL	☐	☐		
LFTD20_Temp_INT	INT	☐	☐		
LFTD20_Cnt	UINT	☐	☐		
LFTD20_IN1	UINT	☐	☐		LFTD-AnybusCC[1] : Humidity
LFTD20_IN2	UINT	☐	☐		LFTD-AnybusCC[2] : Tempera
LFTD20_IN3	UINT	☐	☐		LFTD-AnybusCC[3] : Status
LFTD20_IN4	UINT	☐	☐		LFTD-AnybusCC[4] : Counter
LFTD20_IN5	UINT	☐	☐		LFTD-AnybusCC[5] : SerialNr
LFTD20_IN6	UINT	☐	☐		LFTD-AnybusCC[6]
LFTD20_IN7	UINT	☐	☐		LFTD-AnybusCC[7] : Version
LFTD20_IN8	UINT	☐	☐		LFTD-AnybusCC[8]
LFTD20_CMD	UINT	☐	☐		LFTD-AnybusCC[16] : Comma

5.5 Program code in ANSI C for integration

1. It is recommended to use the counter as a watchdog.
» The counter is incremented by the sensor every millisecond.
2. Thus, the function of the sensor can be monitored by means of the counter.
» If the counter does not change for a longer period of time, a restart of the communication with the module is necessary.
3. With the LFTD-Profinet (new) with display, the Profinet connection is cut when the measuring window is left or the module is deactivated.
» In contrast to the LFTD-Profinet (old) with AnybusIC, the device starts the measurement automatically after power-up.
4. With the variable "ModulOk" or "LFTD20_Online" in connection with the counter "LFTD20_Cnt", a reliable check of the function of the sensor and the communication can be realised.
» A measurement interval with the provision of data takes less than one second.

RMS-TD-PROFINET

Humidity & Temperature Transmitter

```
#include <bur/plctypes.h>

#ifdef _DEFAULT_INCLUDES
#include <AsDefault.h>
#endif

void _INIT C_TestInit(void)
{
    LFTD20_CMD = 0;
    LFTD20_IN1 = 0;
    LFTD20_IN2 = 0;
    LFTD20_IN3 = 0;
    LFTD20_IN4 = 0;
    LFTD20_IN5 = 0;
    LFTD20_IN6 = 0;
    LFTD20_IN7 = 0;
    LFTD20_IN8 = 0;

    LFTD20_Online = 0;
    LFTD20_Humid_INT = 0;
    LFTD20_Humid = 0.0;
    LFTD20_Temp_INT = 0;
    LFTD20_Temp = 0.0;
}

void _CYCLIC C_TestCyclic( void )
{
    LFTD20_Humid = ((float)(INT)LFTD20_IN1/128.0);
    LFTD20_Temp = ((float)(INT)LFTD20_IN2/128.0);
    LFTD20_Cnt = LFTD20_IN4;


    if( (LFTD20_Online==0) && LFTD20_CMD) {
        LFTD20_CMD = 0;
    }
}
```



RMS-TD-PROFINET

Humidity & Temperature Transmitter


6. Technical drawing [RMS-TD-PROFINET](#)



7. Adjustment behavior of the sensor

In humidity and temperature measurement, several parameters are responsible for the adjustment behavior (time until the actual measured value is displayed). The parameter responsible for the highest measuring error is a temperature discrepancy between the sensor resp. the whole measuring instrument and the material being measured resp. the air.

Therefore, let the device adjust until the displayed temperature corresponds to the actual temperature. The graph below shows how long it takes to adjust from 20 °C to 30 °C.



RMS-TD-PROFINET

Humidity & Temperature Transmitter

To demonstrate the importance of temperature adjustment, the table below shows the measuring errors due to a temperature difference between the measuring instrument and the material being measured of only 1 °C, at different ambient temperatures.

	10 °C	20 °C	30 °C
10 % r.h.	+/- 0.7 %	+/- 0.6 %	+/- 0.6 %
50 % r.h.	+/- 3.5 %	+/- 3.2 %	+/- 3.0 %
90 % r.h.	+/- 6.3 %	+/- 5.7 %	+/- 5.4 %

At room temperature (20 °C) and an assumed humidity value of 50 % relative humidity a temperature difference between the measuring sensor and the material being measured of 1 °C causes a measurement error of 3.2 % relative humidity.


A temperature difference of 3 °C would cause a measurement error of more than 10 % relative humidity.

8. Definition relative humidity

Indicates the relationship between the current water vapor pressure and the maximum possible, the so-called saturation vapor pressure. The relative humidity shows the degree the air is saturated with water vapor. Examples: 50% relative humidity: At the current temperature and pressure, the air is half saturated with water vapour. 100% relative humidity means that the air is totally saturated with water vapor. If the air has more than 100% humidity, the excessive humidity would condense or precipitate as mist.

8.1 Application range

Within the normal application range (normal range) the accuracy of the device is as indicated. A long-term application beyond the normal application range (max. range), particularly at an air humidity of more than 80%, can lead to higher measuring errors. Back in the normal application range, the sensor will return to the indicated accuracy automatically.



RMS-TD-PROFINET

Humidity & Temperature Transmitter

9. Cleaning and maintenance

Regularly cleaning and maintaining the device will ensure that it will have a long service life and stay in good condition.

9.1 Care instructions

- Do not leave the device out in the rain.
- Do not immerse the sensor in water.
- Do not expose the device to extreme temperatures.
- Protect the device from strong mechanical shocks and loads.

9.2 Cleaning the device

ATTENTION Do not clean with fluids Water or cleaning fluid getting inside the device can destroy the device. ► Only clean with dry materials.

Aluminum housing and sensor tube

Clean the aluminum housing and the sensor tube with a dry cloth.

Air humidity and temperature sensor

The air humidity and temperature sensor cannot be cleaned.

In case of a polluted sensor please contact Checkline Europe.

10. Checking the calibration


To do so: Calibration equipment and calibration ampoules are required.

The device, the calibration equipment and the humidity standards must have a temperature between 20.0 °C and 26.0 °C.

It is recommended to store the device, the calibration equipment and the calibration ampoules in a room with little temperature fluctuation for 24 hours.

10.1 Assembling the calibration equipment

1. Place the sealing ring over the threads of the lower part like shown in (figure 1).
2. Place the textile pad into the lower part (figure 2) and carefully pour the humidity standard onto the pad, beginning with the humidity standard of 35 % relative humidity.
3. Carefully place the upper part onto the lower part (figure 3) and tighten the upper part clockwise. » Recommendation: Keep the lower part on the table while screwing on the upper part. » If necessary, only lift the



RMS-TD-PROFINET

Humidity & Temperature Transmitter

- calibration equipment straight up and do not tilt or turn it over.
4. Loosen the fixing nut counterclockwise until the sensor tube of the measuring device can be inserted without excessive pressure.
 5. Now carefully push the sensor tube of the measuring device into the upper part until it stops (figure 4).
 6. Secure the calibration equipment on the sensor tube by tightening the previously loosened fixing nut.
 - » Make sure to lift the device with the calibration equipment only straight up and do not tip or turn it over. Otherwise you could damage the sensor.
 - » Do not remove the calibration equipment from the sensor tube until specifically indicated otherwise.
 - » Place a distance holder under the device so that the device and the calibration equipment lay horizontally on the table.

ATTENTION Damage to the sensor

By tilting or turning the device with mounted calibration equipment the sensor can be destroyed. ► Only lift the device with mounted calibration equipment straight up

10.2 Determining the deviation

1. Let the sensor adjust to the humidity standard for at least 2 hours.
2. Then note down the measured relative humidity and temperature.
3. At ideal temperature conditions (device, calibration equipment and humidity standard have a temperature of 23 °C), the value printed on the humidity standard can be used as reference value.
4. In case of deviation from the factory temperature (23.0 °C), the real humidity value must first be determined according to the table below.

Temperature	Humidity standards		
	35 %	50 %	80 %
20 °C	34.6 %	49.8 %	79.9 %
21 °C	34.8 %	49.8 %	80.0 %
22 °C	34.9 %	49.9 %	80.0 %
23 °C	35.0 %	50.0 %	80.0 %
24 °C	35.1 %	50.1 %	80.0 %
25 °C	35.2 %	50.2 %	80.0 %
26 °C	35.4 %	50.2 %	80.1 %

5. Note down the real humidity value

RMS-TD-PROFINET

Humidity & Temperature Transmitter

6. Compare the noted displayed measuring value with the real humidity value.
 - » If the deviation revealed is below 1.5 % relative humidity, it is not recommended to recalibrate.
 - » If the deviation revealed is more than 1.5 % relative humidity, please contact Checkline Europe.
7. Now remove the calibration equipment from the sensor tube and repeat the procedure from "9.1 Assembling the calibration equipment", optionally with the humidity standard 50 % relative humidity or the humidity standard 80 % relative humidity

11. Faults

If the measures listed below fail to remedy any faults or if the device has faults not listed here, please contact Checkline Europe BV.

Fault	Cause	Remedy
Measuring error	The temperature is outside the operating temperature: lower than -20 °C or higher than +60 °C	Only use the device in temperatures between -20 °C and +60 °C
	Measurement error due to too short temperature adjustment time	Let the device adjust to the surroundings (see "6. Adjustment behavior of the sensor").
	Sources of heat or cold that do not correspond to the surrounding temperature	Reposition your device at a location that is representative for the room climate.
	Dripping water or sprayed water	Direct contact of the sensor with dripping or sprayed water will destroy it.
	Irreversible damage of the sensor due to aggressive gasses	Please contact your Checkline Europe
	Condensation caused by a change in temperature	Condensation on the sensor interferes with the calibration. Let the device adjust to the surrounding temperature
	Polluted air humidity and temperature sensor	Please contact your Checkline Europe
	Foreign particles on the sensor	Please contact your Checkline Europe

RMS-TD-PROFINET

Humidity & Temperature Transmitter

12. Warranty

Checkline Europe (Checkline) warrants to the original purchaser that this product is of merchantable quality and confirms in kind and quality with the descriptions and specifications thereof. Product failure or malfunction arising out of any defect in workmanship or material in the product existing at the time of delivery thereof which manifests itself within one year from the sale of such product, shall be remedied by repair or replacement of such product, at Checkline's option, except where unauthorized repair, disassembly, tampering, abuse or misapplication has taken place, as determined by Checkline. All returns for warranty or non-warranty repairs and/or replacement must be authorized by Checkline, in advance, with all repacking and shipping expenses to the address below to be borne by the purchaser.

THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE OR APPLICATION. CHECKLINE SHALL NOT BE RESPONSIBLE NOR LIABLE FOR ANY CONSEQUENTIAL DAMAGE, OF ANY KIND OR NATURE, RESULTING FROM THE USE OF SUPPLIED EQUIPMENT, WHETHER SUCH DAMAGE OCCURS OR IS DISCOVERED BEFORE, UPON OR AFTER REPLACEMENT OR REPAIR, AND WHETHER OR NOT SUCH DAMAGE IS CAUSED BY MANUFACTURER'S OR SUPPLIER'S NEGLIGENCE WITHIN ONE YEAR FROM INVOICE DATE.

Some State jurisdictions or States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. The duration of any implied warranty, including, without limitation, fitness for any particular purpose and merchantability with respect to this product, is limited to the duration of the foregoing warranty. Some states do not allow limitations on how long an implied warranty lasts but, notwithstanding, this warranty, in the absence of such limitations, shall extend for one year from the date of invoice.

CHECKLINE EUROPE

Dennenweg 225B, 7545 WE, Enschede, the Netherlands

Tel: +31 (0)53-4356060 // Email: info@checkline.eu

Every precaution has been taken in the preparation of this manual. Checkline Europe assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of information contained herein. Any brand or product names mentioned herein are used for identification purposes only, and are trademarks or registered trademarks of their respective holders.