



## Quick Start Guide

### RSFG-1013

Stock number: 2889873

EN





## Limited Warranty

This product is warranted to the original purchaser against defects in material and workmanship for 3 years from the date of purchase. During this warranty period, RS PRO will, at its option, replace or repair the defective unit, subject to verification of the defect or malfunction. This warranty does not cover fuses, disposable batteries, or damage from abuse, neglect, accident, unauthorized repair, alteration, contamination, or abnormal conditions of operation or handling. Any implied warranties arising out of the sale of this product, including but not limited to implied warranties of merchantability and fitness for a particular purpose, are limited to the above. RS PRO shall not be liable for loss of use of the instrument or other incidental or consequential damages, expenses, or economic loss, or for any claim or claims for such damage, expense or economic loss. Some states or countries laws vary, so the above limitations or exclusions may not apply to you. For full terms and conditions, refer to the RS PRO website.

This quick start guide contains proprietary information, which is protected by copyright. All rights are reserved. No part of this quick start guide may be photocopied, reproduced or translated to another language without prior written consent.

The information in this quick start guide was correct at the time of printing. However we continue to improve our products and therefore reserve the right to change the specifications, equipment, and maintenance procedures at any time without notice.

# SAFETY INSTRUCTIONS

## Safety Symbols

These safety symbols may appear in the user manual or on the instrument.



Warning

Warning: Identifies conditions or practices that could result in injury or loss of life.



Caution

Caution: Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Frame or Chassis Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

# GETTING STARTED

## Main Features

---

Performance • High resolution using DDS technology

- High frequency accuracy:  $\pm 20\text{ppm}$
  - Low distortion:  $-55\text{dBc}$  @  $\leq 200\text{kHz}$
  - High resolution  $100\text{mHz}$
- 

Features • Digital user interface with 6-digit LED display

- Various output waveforms: Sine, Square, and Triangle
- TTL output
- Amplitude control
- $-40\text{dB}$  attenuation
- Duty control
- Variable DC offset control
- Output On/Off control
- Voltage display
- Output overload protection

---


Interface • Frequency output

- TTL output

---


# Appearance

## Front Panel Overview



Description	
1. Main Display	2. Entry Keys
3. Shift Key	4. Output On/OFF key
5. Main Output	6. TTL Output
7. Amplitude Control	8. Offset Control
9. Duty Control	10. Frequency Adjustment Knob
11. Power Switch	

## Rear Panel Overview




Description	
1. Ground Terminal	2. AC Power Input
3. AC rating information	

# START UP


## Power Up

### Step

1. Connect the power cord to the AC voltage input. Check the voltage level displayed on the label (1) and make sure it is identical to the AC line. Then connect the power cord (2).



2. Push and turn on the main power switch on the front panel.



3. The display shows the default setup: Sine wave, 1kHz



k Hz


1.0000

## Functionality check

---

Step

1. Connect SFG main output to measurement device such as oscilloscope.



2. Press the output key. The output is activated and the LED turns on.




3. Observe the output waveform: 1kHz, sine wave.

# Operation Shortcuts

## Sine Wave

250Hz, -40dB  
amplitude


OUTPUT  
50  $\Omega$




1. Press Wave key and select Sine.



2. Press 2 + 5 + 0 + Shift + 0(Hz) key.



3. Press Output key, then pull Amplitude knob.




4. Press Output key, then press Shift + 3 (-40dB) key.



## Triangle wave

8kHz, +2V  
Offset

OUTPUT  
50  $\Omega$




1. Press Wave key and select Triangle.



2. Press 8 + Shift + 9 (kHz) key.




3. Press Output key, then pull Offset knob and rotate.



## Square Wave

1MHz, 45%  
duty

OUTPUT  
50  $\Omega$




1. Press Wave key and select Square.



2. Press 1 + Shift + 8 (MHz) key.



3. Press Output key, then pull Duty knob and rotate.



## TTL Output

TTL Output  
10kHz

TTL  
OUTPUT




1. Press Output key.



2. Press Shift + Wave (TTL) key.




3. Press 1 + 0 + Shift + 9 (kHz) key.



## Activate waveform

Sine/ Square/  
Triangle

1. Press the wave key repeatedly. The corresponding indicator appears on the display.



2. Press the output key. The LED turns On.



3. The waveform comes out from the main terminal.  
10Vp-p (50Ω load)  
20Vp-p (no load)

OUTPUT  
50 Ω




## Set Frequency


Enter  
frequency

Enter the waveform frequency using the numerical keys.

1.2MHz




37kHz





45Hz




Edit frequency




Left cursor key moves the active cursor left.




Right cursor key moves the active cursor right.





Turn the Frequency knob left to decrease the frequency.

(Flashing)  
100.0 → 99.0



Turn the frequency knob right to increase the frequency.

(Flashing)  
100.0 → 10 1.0

## Set Duty Cycle

Enter duty cycle

1. Pull out the Duty knob. Turn right (left) to increase (decrease) the duty cycle. The default is set at 50%.

OFFSET



ADJ



2. Press the Duty knob. The edited duty cycle is stored.



# SPECIFICATIONS

RSFG-1013 must be powered for at least 30 minutes within the ambient temperature 18°C ~ 28°C to meet this spec.

## Main

Output Function	Sine, Square, Triangle
Amplitude Range	10Vpp (50Ω load)
Amplitude Accuracy	±20% at maximum position
Impedance	50Ω ± 10%
Attenuator	-40dB ± 1dB x1
DC Offset	< -5V ~ >+5V (50Ω load)
Duty Range	25% ~ 75%, ≤1MHz (Square Wave)
Display	6 digits LED display

## Frequency

Sine/Square Waveform Range	0.1Hz ~ 3MHz
Triangle Waveform Range	0.1Hz ~ 1MHz
Resolution	0.1Hz maximum
Stability	±20ppm
Accuracy	±20ppm
Aging	±5ppm/year
Sine/Square Waveform Range	0.1Hz ~ 3MHz
Triangle Waveform Range	0.1Hz ~ 1MHz

## Sine Wave

Harmonic Distortion	$\geq -55\text{dBc}$ , 0.1Hz ~ 200kHz $\geq -40\text{dBc}$ , 0.2MHz ~ 2MHz $\geq -35\text{dBc}$ , 2MHz ~ 3MHz (At maximum position without any attenuation to 1/10 of any combination setting, TTL Off)
Flatness	$< \pm 0.3\text{dB}$ , 0.1Hz ~ 1MHz $< \pm 0.5\text{dB}$ , 1MHz ~ 2MHz $< \pm 1\text{dB}$ , 2MHz ~ 3MHz (At the max amplitude relating to 1kHz)

## Triangle Wave

Linearity	$\geq 98\%$ , 0.1Hz ~ 100kHz $\geq 95\%$ , 100kHz ~ 1MHz
-----------	---

## Square Wave

Symmetry	$\pm 5\%$ of period + 4ns, 0.1Hz ~ 100kHz
Rise/ Fall Time	$\leq 100\text{ns}$ at maximum output, 50 $\Omega$ load

## TTL

Level	$\geq 3\text{Vpp}$
Fan Out	20 TTL Load
Rise/ Fall Time	$\leq 25\text{ns}$

## General

Power Source	AC110/220/240V $\pm 10\%$ , 50/ 60Hz (Line voltage setting is factory installed)
Operation Environment	Indoor Use, Altitude Up to 2000m Ambient Temperature 0 ~ 40°C Relative Humidity $\leq 80\%$ , 0 ~ 40°C Install Category II / Pollution Degree 2
Storage Environment	Temperature -10 ~ 70°C Humidity $\leq 70\%$
Accessories	Instruction Manual x 1 GTL-101 x 1
Dimension	251 (W) x 91 (H) x 291 (D)
Weight	Approx. 2.1kg

## **Africa**

RS Components SA  
P.O. Box 12182, Vorna Valley 1686  
20 Indianapolis Street, Kyalami Business Park  
Kyalami, Midrand, South Africa

## **Asia**

RS Components Ltd.  
Suite 1601, Level 16, Tower 1, Kowloon Commerce Centre,  
51 Kwai Cheong Road, Kwai Chung, Hong Kong

## **China**

RS Components Ltd.  
Suite 23 A-C, East Sea Business Centre Phase 2  
NO. 618 Yan'an Eastern Road, Shanghai, 200001, China

## **Europe**

RS Components Ltd.  
PO Box 99, Corby, Northants NN17 9RS  
United Kingdom

## **Japan**

RS Components Ltd.  
West Tower (12th Floor), Yokohama Business Park,  
134 Godocho, Hodogaya, Yokohama,  
Kanagawa 240-0005 Japan

## **North America**

Allied Electronics  
7151 Jack Newell Blvd. S. Fort Worth, Texas 76118  
U.S.A.

## **South America**

RS Componentes Electrónicos Limitada  
Av. Pde. Eduardo Frei M. 6001-71, Centro Empresas El Cortijo  
Conchali, Santiago, Chile



## AUDITED

In compliance with industry standards



## INSPECTED

For guaranteed quality and performance



## TESTED

By leading engineers

