



Cisco Firepower 9300 FXOS CLI Configuration Guide, 1.1(1)

First Published: 2015-07-16

Last Modified: 2015-10-12

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2015 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1	Introduction to the Firepower Security Appliance	1
	About the Firepower Security Appliance	1
CHAPTER 2	CLI Overview	3
	Managed Objects	3
	Command Modes	3
	Object Commands	5
	Complete a Command	6
	Command History	6
	Commit, Discard, and View Pending Commands	6
	Inline Help for the CLI	7
	CLI Session Limits	7
CHAPTER 3	Getting Started	9
	Task Flow	9
	Initial Configuration Using Console Port	9
	Accessing the FXOS CLI	12
CHAPTER 4	License Management for the ASA	15
	About Smart Software Licensing	15
	Smart Software Licensing for the ASA	15
	Smart Software Manager and Accounts	16
	Licenses and Devices Managed per Virtual Account	16
	Evaluation License	16
	Smart Software Manager Communication	17
	Device Registration and Tokens	17

Periodic Communication with the License Authority	17
Out-of-Compliance State	17
Smart Call Home Infrastructure	18
Prerequisites for Smart Software Licensing	18
Guidelines for Smart Software Licensing	18
Defaults for Smart Software Licensing	19
Configure Smart Software Licensing	19
(Optional) Configure the HTTP Proxy	19
Register the Firepower Security Appliance with the License Authority	20
Change Cisco Success Network Enrollment	21
Monitoring Smart Software Licensing	22
History for Smart Software Licensing	23

CHAPTER 5
User Management 25

User Accounts	25
Guidelines for Usernames	26
Guidelines for Passwords	27
Guidelines for Remote Authentication	27
User Roles	30
Password Profile for Locally Authenticated Users	30
Select the Default Authentication Service	31
Configuring the Session Timeout	33
Configuring the Role Policy for Remote Users	34
Enabling Password Strength Check for Locally Authenticated Users	35
Set the Maximum Number of Login Attempts	35
Configuring the Maximum Number of Password Changes for a Change Interval	36
Configuring a No Change Interval for Passwords	37
Configuring the Password History Count	38
Creating a Local User Account	39
Deleting a Local User Account	41
Activating or Deactivating a Local User Account	42
Clearing the Password History for a Locally Authenticated User	42

CHAPTER 6
Image Management 45

About Image Management	45
Downloading Images from Cisco.com	46
Downloading a Firepower eXtensible Operating System Software Image to the Firepower 9300 chassis	46
Verifying the Integrity of an Image	47
Upgrading the Firepower eXtensible Operating System Platform Bundle	48
Downloading a Logical Device Software Image to the Firepower 9300 chassis	48
Updating the Image Version for a Logical Device	50
Firmware Upgrade	52

CHAPTER 7

Platform Settings 53

Changing the Management IP Address	53
Setting the Date and Time	55
Setting the Time Zone	55
Setting the Date and Time Using NTP	57
Deleting an NTP Server	58
Setting the Date and Time Manually	59
Configuring SSH	60
Configuring Telnet	61
Configuring SNMP	62
About SNMP	62
SNMP Notifications	63
SNMP Security Levels and Privileges	63
Supported Combinations of SNMP Security Models and Levels	63
SNMPv3 Security Features	64
SNMP Support	64
Enabling SNMP and Configuring SNMP Properties	65
Creating an SNMP Trap	66
Deleting an SNMP Trap	68
Creating an SNMPv3 User	68
Deleting an SNMPv3 User	70
Viewing Current SNMP Settings	71
Configuring HTTPS	72
Certificates, Key Rings, and Trusted Points	72

Creating a Key Ring	73
Regenerating the Default Key Ring	73
Creating a Certificate Request for a Key Ring	74
Creating a Certificate Request for a Key Ring with Basic Options	74
Creating a Certificate Request for a Key Ring with Advanced Options	75
Creating a Trusted Point	77
Importing a Certificate into a Key Ring	78
Configuring HTTPS	80
Changing the HTTPS Port	81
Deleting a Key Ring	82
Deleting a Trusted Point	82
Disabling HTTPS	83
Configuring AAA	84
About AAA	84
Setting Up AAA	85
Configuring LDAP Providers	86
Configuring RADIUS Providers	90
Configuring TACACS+ Providers	93
Verifying Remote AAA Server Configurations	96
Configuring Syslog	97
Configuring DNS Servers	100

CHAPTER 8

Interface Management	103
About Firepower Interfaces	103
Chassis Management Interface	103
Interface Types	103
FXOS Interfaces vs. Application Interfaces	104
Jumbo Frame Support	104
Guidelines and Limitations for Firepower Interfaces	104
Configure Interfaces	105
Configure a Physical Interface	105
Add an EtherChannel (Port Channel)	107
Configure Breakout Cables	108
Configure a Flow Control Policy	109

Monitoring Interfaces 111

CHAPTER 9

Logical Devices 113

About Logical Devices 113

Standalone and Clustered Logical Devices 113

Requirements and Prerequisites for Logical Devices 113

Requirements and Prerequisites for Hardware and Software Combinations 114

Requirements and Prerequisites for Clustering 114

Requirements and Prerequisites for High Availability 114

Guidelines and Limitations for Logical Devices 115

General Guidelines and Limitations 115

Clustering Guidelines and Limitations 115

Add a Standalone Logical Device 116

Add a Standalone ASA 116

Add a High Availability Pair 121

Add a Cluster 121

About Clustering on the Firepower 9300 Chassis 122

Primary and Secondary Unit Roles 122

Cluster Control Link 122

Management Interface 122

Add an ASA Cluster 123

Create an ASA Cluster 123

Manage Logical Devices 129

Connect to the Console of the Application 129

Remove a Cluster Unit 130

Change the ASA to Transparent Firewall Mode 132

Change an Interface on a Firepower Threat Defense Logical Device 133

Change an Interface on an ASA Logical Device 134

Monitoring Logical Devices 135

History for Logical Devices 136



CHAPTER 1

Introduction to the Firepower Security Appliance

- [About the Firepower Security Appliance, on page 1](#)

About the Firepower Security Appliance

The Cisco Firepower 9300 chassis is a next-generation platform for network and content security solutions. The Firepower 9300 chassis is part of the Cisco Application Centric Infrastructure (ACI) Security Solution and provides an agile, open, secure platform that is built for scalability, consistent control, and simplified management.

The Firepower 9300 chassis provides the following features:

- Modular chassis-based security system—provides high performance, flexible input/output configurations, and scalability.
- Firepower Chassis Manager—graphical user interface provides streamlined, visual representation of current chassis status and simplified configuration of chassis features.
- FXOS CLI—provides command-based interface for configuring features, monitoring chassis status, and accessing advanced troubleshooting features.
- FXOS REST API—allows users to programmatically configure and manage their chassis.



CHAPTER 2

CLI Overview

- [Managed Objects, on page 3](#)
- [Command Modes, on page 3](#)
- [Object Commands, on page 5](#)
- [Complete a Command, on page 6](#)
- [Command History, on page 6](#)
- [Commit, Discard, and View Pending Commands, on page 6](#)
- [Inline Help for the CLI, on page 7](#)
- [CLI Session Limits, on page 7](#)

Managed Objects

The Firepower eXtensible Operating System (FXOS) uses a managed object model, where managed objects are abstract representations of physical or logical entities that can be managed. For example, chassis, security modules, network modules, ports, and processors are physical entities represented as managed objects, and licenses, user roles, and platform policies are logical entities represented as managed objects.

Managed objects may have one or more associated properties that can be configured.

Command Modes

The CLI is organized into a hierarchy of command modes, with EXEC mode being the highest-level mode of the hierarchy. Higher-level modes branch into lower-level modes. You use **create**, **enter**, and **scope** commands to move from higher-level modes to modes in the next lower level, and you use the **up** command to move up one level in the mode hierarchy. You can also use the **top** command to move to the top level in the mode hierarchy.



Note

Most command modes are associated with managed objects, so you must create an object before you can access the mode associated with that object. You use **create** and **enter** commands to create managed objects for the modes being accessed. The **scope** commands do not create managed objects and can only access modes for which managed objects already exist.

Each mode contains a set of commands that can be entered in that mode. Most of the commands available in each mode pertain to the associated managed object.

The CLI prompt for each mode shows the full path down the mode hierarchy to the current mode. This helps you to determine where you are in the command mode hierarchy, and it can be an invaluable tool when you need to navigate through the hierarchy.

The following table lists the main command modes, the commands used to access each mode, and the CLI prompt associated with each mode.

Table 1: Main Command Modes and Prompts

Mode Name	Commands Used to Access	Mode Prompt
EXEC	top command from any mode	#
Adapter	scope adapter command from EXEC mode	/adapter #
Cabling	scope cabling command from EXEC mode	/cabling #
Chassis	scope chassis command from EXEC mode	/chassis #
Ethernet server domain	scope eth-server command from EXEC mode; this command and all subcommands are currently not supported	/eth-server #
Ethernet uplink	scope eth-uplink command from EXEC mode	/eth-uplink #
Fabric interconnect	scope fabric-interconnect command from EXEC mode	/fabric-interconnect #
Firmware	scope firmware command from EXEC mode	/firmware #
Host Ethernet interface	scope host-eth-if command from EXEC mode Note This command and all subcommands are not supported at this level; the Host Ethernet interface commands are available in /adapter # mode.	/host-eth-if #
License	scope license command from EXEC mode	/license #
Monitoring	scope monitoring command from EXEC mode	/monitoring #
Organization	scope org command from EXEC mode	/org #
Security	scope security command from EXEC mode	/security #
Server	scope server command from EXEC mode	/server #

Mode Name	Commands Used to Access	Mode Prompt
Service profile	scope service-profile command from EXEC mode Note Do not alter or configure service profiles; that is, do not use the create , set , or delete subcommand sets.	/service-profile #
SSA	scope ssa command from EXEC mode	/ssa #
System	scope system command from EXEC mode	/system #
Virtual HBA	scope vhba command from EXEC mode Note This command and all subcommands are currently not supported.	/vhba #
Virtual NIC	scope vnic command from EXEC mode	/vnic #

Object Commands

Four general commands are available for object management:

- **create** *object*
- **delete** *object*
- **enter** *object*
- **scope** *object*

You can use the **scope** command with any managed object, whether a permanent object or a user-instantiated object. The other commands allow you to create and manage user-instantiated objects. For every **create** *object* command, a corresponding **delete** *object* and **enter** *object* command exists.

In the management of user-instantiated objects, the behavior of these commands depends on whether the object exists, as described in the following tables:

Table 2: Command Behavior If The Object Does Not Exist

Command	Behavior
create <i>object</i>	The object is created and its configuration mode, if applicable, is entered.
delete <i>object</i>	An error message is generated.
enter <i>object</i>	The object is created and its configuration mode, if applicable, is entered.
scope <i>object</i>	An error message is generated.

Table 3: Command Behavior If The Object Exists

Command	Behavior
create <i>object</i>	An error message is generated.
delete <i>object</i>	The object is deleted.
enter <i>object</i>	The configuration mode, if applicable, of the object is entered.
scope <i>object</i>	The configuration mode of the object is entered.

Complete a Command

You can use the **Tab** key in any mode to complete a command. Partially typing a command name and pressing **Tab** causes the command to be displayed in full or to the point where you must enter another keyword or an argument value.

Command History

The CLI stores all commands used in the current session. You can step through the previously used commands by using the up-arrow or down-arrow keys. The up-arrow key moves to the previous command in the history, and the down-arrow key moves to the next command in the history. When you get to the end of the history, pressing the down-arrow key does nothing.

You can enter any command in the history again by stepping through the history to recall that command and then pressing **Enter**. The command is entered as if you had manually typed it. You can also recall a command and change it before you press **Enter**.

Commit, Discard, and View Pending Commands

When you enter a configuration command in the CLI, the command is not applied until you enter the **commit-buffer** command. Until committed, a configuration command is pending and can be discarded by entering a **discard-buffer** command.

You can accumulate pending changes in multiple command modes and apply them together with a single **commit-buffer** command. You can view the pending commands by entering the **show configuration pending** command in any command mode.



Note

All pending commands are checked for validity. However, if any queued command fails during commit, the remaining commands are applied; failed commands are reported in an error message.

While any commands are pending, an asterisk (*) appears before the command prompt. The asterisk disappears when you enter the **commit-buffer** command.

The following example shows how the prompts change during the command entry process:

```
Firepower# scope system
Firepower /system # scope services
Firepower /system/services # create ntp-server 192.168.200.101
Firepower /system/services* # show configuration pending
    scope services
+   create ntp-server 192.168.200.101
    exit
Firepower /system/services* # commit-buffer
Firepower /system/services #
```

Inline Help for the CLI

At any time, you can enter the ? character to display the options available at the current state of the command syntax.

If you have not entered anything at the prompt, entering ? lists all available commands for the mode you are in. With a partially entered command, entering ? lists all keywords and arguments available at your current position in the command syntax.

CLI Session Limits

FXOS limits the number of CLI sessions that can be active at one time to 32 total sessions. This value is not configurable.



CHAPTER 3

Getting Started

- [Task Flow, on page 9](#)
- [Initial Configuration Using Console Port, on page 9](#)
- [Accessing the FXOS CLI, on page 12](#)

Task Flow

The following procedure shows the basic tasks that should be completed when configuring your Firepower 9300 chassis.

Procedure

- | | |
|----------------|--|
| Step 1 | Configure the Firepower 9300 chassis hardware (see the Cisco Firepower Security Appliance Hardware Installation Guide). |
| Step 2 | Complete the initial configuration (see Initial Configuration Using Console Port, on page 9). |
| Step 3 | Set the Date and Time (see Setting the Date and Time, on page 55). |
| Step 4 | Configure a DNS server (see Configuring DNS Servers, on page 100). |
| Step 5 | Register your product license (see License Management for the ASA, on page 15). |
| Step 6 | Configure users (see User Management, on page 25). |
| Step 7 | Perform software updates as required (see Image Management, on page 45). |
| Step 8 | Configure additional platform settings (see Platform Settings, on page 53). |
| Step 9 | Configure interfaces (see Interface Management, on page 103). |
| Step 10 | Create logical devices (see Logical Devices, on page 113). |
-

Initial Configuration Using Console Port

Before you can use Firepower Chassis Manager or the FXOS CLI to configure and manage your system, you must perform some initial configuration tasks using the FXOS CLI accessed through the console port. Use the following procedure to perform initial configuration using the FXOS CLI accessed through the console port.

The first time that you access the Firepower 9300 chassis using the FXOS CLI, you will encounter a setup wizard that you can use to configure the system.



Note To repeat the initial setup, you need to erase any existing configuration using the following commands:

```
Firepower-chassis# connect local-mgmt
firepower-chassis(local-mgmt)# erase configuration
```

You can choose to either restore the system configuration from an existing backup file, or manually set up the system by going through the Setup wizard. If you choose to restore the system, the backup file must be reachable from the management network.

You must specify only one IPv4 address, gateway, and subnet mask, or only one IPv6 address, gateway, and network prefix for the single management port on the Firepower 9300 chassis. You can configure either an IPv4 or an IPv6 address for the management port IP address.

Before you begin

1. Verify the following physical connections on the Firepower 9300 chassis:
 - The console port is physically connected to a computer terminal or console server.
 - The 1 Gbps Ethernet management port is connected to an external hub, switch, or router.

For more information, refer to the [Cisco Firepower Security Appliance Hardware Installation Guide](#).

2. Verify that the console port parameters on the computer terminal (or console server) attached to the console port are as follows:
 - 9600 baud
 - 8 data bits
 - No parity
 - 1 stop bit
3. Gather the following information for use with the setup script:
 - New admin password
 - Management IP address and subnet mask
 - Gateway IP address
 - Hostname and domain name
 - DNS server IP address

Procedure

- Step 1** Power on the chassis.

Step 2 Connect to the serial console port using a terminal emulator.

The Firepower includes an RS-232-to-RJ-45 serial console cable. You might need to use a third party serial-to-USB cable to make the connection. Use the following serial parameters:

- 9600 baud
- 8 data bits
- No parity
- 1 stop bit

Step 3 Complete the system configuration as prompted.**Example:**

```
Enter the setup mode; setup newly or restore from backup. (setup/restore) ? setup
You have chosen to setup a new Fabric interconnect. Continue? (y/n): y
Enforce strong password? (yes/no) [y]: n
Enter the password for "admin": Farscape&32
Confirm the password for "admin": Farscape&32
Enter the system name: firepower-9300
Physical Switch Mgmt0 IP address : 10.80.6.12
Physical Switch Mgmt0 IPv4 netmask : 255.255.255.0
IPv4 address of the default gateway : 10.80.6.1
Configure the DNS Server IP address? (yes/no) [n]: y
  DNS IP address : 10.164.47.13
Configure the default domain name? (yes/no) [n]: y
  Default domain name : cisco.com
```

Following configurations will be applied:

```
Switch Fabric=A
System Name=firepower-9300
Enforced Strong Password=no
Physical Switch Mgmt0 IP Address=10.89.5.14
Physical Switch Mgmt0 IP Netmask=255.255.255.192
Default Gateway=10.89.5.1
IPv6 value=0
DNS Server=72.163.47.11
Domain Name=cisco.com
```

```
Apply and save the configuration (select 'no' if you want to re-enter)? (yes/no): y
Applying configuration. Please wait... Configuration file - Ok
.....
```

```
Cisco FPR Series Security Appliance
firepower-9300 login: admin
Password: Farscape&32
Successful login attempts for user 'admin' : 1
Cisco Firepower Extensible Operating System (FX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2009-2019, Cisco Systems, Inc. All rights reserved.
```

```
[...]
```

```
firepower-chassis#
```

Accessing the FXOS CLI

You can connect to the FXOS CLI using a terminal plugged into the console port. Verify that the console port parameters on the computer terminal (or console server) attached to the console port are as follows:

- 9600 baud
- 8 data bits
- No parity
- 1 stop bit

You can also connect to the FXOS CLI using SSH and Telnet. The Firepower eXtensible Operating System supports up to eight simultaneous SSH connections. To connect with SSH, you need to know the hostname or IP address of the Firepower 9300 chassis.

Use one of the following syntax examples to log in with SSH, Telnet, or Putty:



Note SSH log in is case-sensitive.

From a Linux terminal using SSH:

- **ssh ucs-auth-domain \username@{UCSM-ip-address | UCMS-ipv6-address}**

```
ssh ucs-example\\jsmith@192.0.20.11
ssh ucs-example\\jsmith@2001::1
```
- **ssh -l ucs-auth-domain \username {UCSM-ip-address | UCSM-ipv6-address | UCSM-host-name}**

```
ssh -l ucs-example\\jsmith 192.0.20.11
ssh -l ucs-example\\jsmith 2001::1
```
- **ssh {UCSM-ip-address | UCSM-ipv6-address | UCSM-host-name} -l ucs-auth-domain \username**

```
ssh 192.0.20.11 -l ucs-example\\jsmith
ssh 2001::1 -l ucs-example\\jsmith
```
- **ssh ucs-auth-domain \username@{UCSM-ip-address | UCSM-ipv6-address}**

```
ssh ucs-ldap23\\jsmith@192.0.20.11
ssh ucs-ldap23\\jsmith@2001::1
```

From a Linux terminal using Telnet:



Note Telnet is disabled by default. See [Configuring Telnet, on page 61](#) for instructions on enabling Telnet.

- **telnet ucs-UCSM-host-name ucs-auth-domain \username**

```
telnet ucs-qa-10
login: ucs-ldap23\bladmin
```

- **telnet** **ucs-**{*UCSM-ip-address* | *UCSM-ipv6-address*}**ucs-auth-domain\username**

```
telnet 10.106.19.12 2052
ucs-qa-10-A login: ucs-ldap23\bladmin
```

From a Putty client:

- Login as: **ucs-auth-domain\username**

```
Login as: ucs-example\jsmith
```



Note

If the default authentication is set to local, and the console authentication is set to LDAP, you can log in to the fabric interconnect from a Putty client using **ucs-local\admin**, where admin is the name of the local account.



CHAPTER 4

License Management for the ASA

Cisco Smart Software Licensing lets you purchase and manage a pool of licenses centrally. You can easily deploy or retire devices without having to manage each unit's license key. Smart Software Licensing also lets you see your license usage and needs at a glance.



Note

This section only applies to ASA logical devices on the Firepower 9300 chassis. For more information on licensing for Firepower Threat Defense logical devices, see the Firepower Management Center Configuration Guide.

- [About Smart Software Licensing, on page 15](#)
- [Prerequisites for Smart Software Licensing, on page 18](#)
- [Guidelines for Smart Software Licensing, on page 18](#)
- [Defaults for Smart Software Licensing, on page 19](#)
- [Configure Smart Software Licensing, on page 19](#)
- [Monitoring Smart Software Licensing, on page 22](#)
- [History for Smart Software Licensing, on page 23](#)

About Smart Software Licensing

This section describes how Smart Software Licensing works.



Note

This section only applies to ASA logical devices on the Firepower 9300 chassis. For more information on licensing for Firepower Threat Defense logical devices, see the Firepower Management Center Configuration Guide.

Smart Software Licensing for the ASA

For the ASA application on the Firepower 9300 chassis, Smart Software Licensing configuration is split between the Firepower 9300 chassis supervisor and the application.

- Firepower 9300 chassis—Configure all Smart Software Licensing infrastructure in the supervisor, including parameters for communicating with the License Authority. The Firepower 9300 chassis itself does not require any licenses to operate.
- ASA Application—Configure all license entitlements in the application.

**Note**

Cisco Transport Gateway is not supported on Firepower 4100/9300 security appliances.

Smart Software Manager and Accounts

When you purchase 1 or more licenses for the device, you manage them in the Cisco Smart Software Manager: <https://software.cisco.com/#module/SmartLicensing>

The Smart Software Manager lets you create a master account for your organization.

**Note**

If you do not yet have an account, click the link to [set up a new account](#). The Smart Software Manager lets you create a master account for your organization.

By default, your licenses are assigned to the *Default Virtual Account* under your master account. As the account administrator, you can optionally create additional virtual accounts; for example, you can create accounts for regions, departments, or subsidiaries. Multiple virtual accounts let you more easily manage large numbers of licenses and devices.

Licenses and Devices Managed per Virtual Account

Licenses and devices are managed per virtual account: only that virtual account's devices can use the licenses assigned to the account. If you need additional licenses, you can transfer an unused license from another virtual account. You can also transfer devices between virtual accounts.

Only the Firepower 9300 chassis registers as a device, while the ASA applications in the chassis request their own licenses. For example, for a Firepower 9300 chassis with 3 security modules, the chassis counts as one device, but the modules use 3 separate licenses.

Evaluation License

The Firepower 9300 chassis supports two types of evaluation license:

- Chassis-level evaluation mode—Before the Firepower 9300 chassis registers with the Licensing Authority, it operates for 90 days (total usage) in evaluation mode. The ASA cannot request specific entitlements in this mode; only default entitlements are enabled. When this period ends, the Firepower 9300 chassis becomes out-of-compliance.
- Entitlement-based evaluation mode—After the Firepower 9300 chassis registers with the Licensing Authority, you can obtain time-based evaluation licenses that can be assigned to the ASA. In the ASA, you request entitlements as usual. When the time-based license expires, you need to either renew the time-based license or obtain a permanent license.



Note You cannot receive an evaluation license for Strong Encryption (3DES/AES); only permanent licenses support this entitlement.

Smart Software Manager Communication

This section describes how your device communicates with the Smart Software Manager.

Device Registration and Tokens

For each virtual account, you can create a registration token. This token is valid for 30 days by default. Enter this token ID plus entitlement levels when you deploy each chassis, or when you register an existing chassis. You can create a new token if an existing token is expired.

At startup after deployment, or after you manually configure these parameters on an existing chassis, the chassis registers with the Cisco License Authority. When the chassis registers with the token, the License Authority issues an ID certificate for communication between the chassis and the License Authority. This certificate is valid for 1 year, although it will be renewed every 6 months.

Periodic Communication with the License Authority

The device communicates with the License Authority every 30 days. If you make changes in the Smart Software Manager, you can refresh the authorization on the device so the change takes place immediately. Or you can wait for the device to communicate as scheduled.

You can optionally configure an HTTP proxy.

The Firepower 9300 chassis must have internet access either directly or through an HTTP proxy at least every 90 days. Normal license communication occurs every 30 days, but with the grace period, your device will operate for up to 90 days without calling home. After the grace period, you must contact the Licensing Authority, or you will not be able to make configuration changes to features requiring special licenses; operation is otherwise unaffected.



Note If your device is unable to communicate with the license authority for one year, the device will enter an unregistered state without strong encryption licenses.

Out-of-Compliance State

The device can become out of compliance in the following situations:

- Over-utilization—When the device uses unavailable licenses.
- License expiration—When a time-based license expires.
- Lack of communication—When the device cannot reach the Licensing Authority for re-authorization.

To verify whether your account is in, or approaching, an Out-of-Compliance state, you must compare the entitlements currently in use by your Firepower 9300 chassis against those in your Smart Account.

In an out-of-compliance state, you will not be able to make configuration changes to features requiring special licenses, but operation is otherwise unaffected. For example, existing contexts over the Standard license limit can continue to run, and you can modify their configuration, but you will not be able to add a *new* context.

Smart Call Home Infrastructure

By default, a Smart Call Home profile exists in the FXOS configuration that specifies the URL for the Licensing Authority. You cannot remove this profile. Note that the only configurable option for the License profile is the destination address URL for the License Authority. Unless directed by Cisco TAC, you should not change the License Authority URL.

**Note**

Cisco Transport Gateway is not supported on Firepower 4100/9300 security appliances.

Prerequisites for Smart Software Licensing

- Note that this chapter only applies to ASA logical devices on the Firepower 9300 chassis. For more information on licensing for Firepower Threat Defense logical devices, see the Firepower Management Center Configuration Guide.
- Create a master account on the Cisco Smart Software Manager:
<https://software.cisco.com/#module/SmartLicensing>
If you do not yet have an account, click the link to [set up a new account](#). The Smart Software Manager lets you create a master account for your organization.
- Purchase 1 or more licenses from the [Cisco Commerce Workspace](#). On the home page, search for your platform in the **Find Products and Solutions** search field. Some licenses are free, but you still need to add them to your Smart Software Licensing account.
- Ensure internet access or HTTP proxy access from the chassis, so the chassis can contact the Licensing Authority.
- Configure a DNS server so the chassis can resolve the name of the Licensing Authority.
- Set the time for the chassis.
- Configure the Smart Software Licensing infrastructure on the Firepower 9300 chassis before you configure the ASA licensing entitlements.

Guidelines for Smart Software Licensing

ASA Guidelines for Failover and Clustering

Each Firepower 9300 chassis must be registered with the License Authority. There is no extra cost for secondary units.

Defaults for Smart Software Licensing

The Firepower 9300 chassis default configuration includes a Smart Call Home profile called “SLProfile” that specifies the URL for the Licensing Authority.

```
scope monitoring
  scope callhome
    scope profile SLProfile
    scope destination SLDest
    set address https://tools.cisco.com/its/service/oddce/services/DDCEService
```

Configure Smart Software Licensing

To communicate with the Cisco License Authority, you can optionally configure an HTTP proxy. To register with the License Authority, you must enter the registration token ID on the Firepower 9300 chassis that you obtained from your Smart Software License account.

Procedure

-
- Step 1** [\(Optional\) Configure the HTTP Proxy, on page 19.](#)
- Step 2** [Register the Firepower Security Appliance with the License Authority, on page 20.](#)
-

(Optional) Configure the HTTP Proxy

If your network uses an HTTP proxy for Internet access, you must configure the proxy address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.



Note HTTP proxy with authentication is not supported.

Procedure

-
- Step 1** Enable the HTTP proxy:

```
scope monitoring
scope callhome
set http-proxy-server-enable on
```

Example:

```
scope monitoring
  scope callhome
```

```
set http-proxy-server-enable on
```

Step 2 Set the proxy URL:

set http-proxy-server-url *url*

where *url* is the http or https address of the proxy server.

Example:

```
set http-proxy-server-url https://10.1.1.1
```

Step 3 Set the port:

set http-proxy-server-port *port*

Example:

```
set http-proxy-server-port 443
```

Step 4 Commit the buffer:

commit-buffer

Register the Firepower Security Appliance with the License Authority

When you register the Firepower 9300 chassis, the License Authority issues an ID certificate for communication between the Firepower 9300 chassis and the License Authority. It also assigns the Firepower 9300 chassis to the appropriate virtual account. Normally, this procedure is a one-time instance. However, you might need to later re-register the Firepower 9300 chassis if the ID certificate expires because of a communication problem, for example.

Procedure

Step 1 In the Smart Software Manager request and copy a registration token for the virtual account to which you want to add this Firepower 9300 chassis.

Step 2 Enter the registration token on the Firepower 9300 chassis:

scope license

register idtoken *id-token*

Example:

```
scope license
  register idtoken ZGFmNWM5NjgtYmNjYS00ZWl3L
WE3NGItMWJkOGEeZjIxNGQ0LTE0NjI2NDYx%0AMDIZNT
V8N3R0dXMlZ0NjWkdPR214eFZhMldBOS9CVnNEYnVKM1
g3R3dvemRD%0AY29NQTO%3D%0A
```

Step 3 To later unregister the device, enter:

scope license

deregister

Deregistering the Firepower 9300 chassis removes the device from your account. All license entitlements and certificates on the device are removed. You might want to deregister to free up a license for a new Firepower 9300 chassis. Alternatively, you can remove the device from the Smart Software Manager.

Step 4 To renew the ID certificate and update the entitlements on all security modules, enter:

scope license

scope licdebug

renew

By default, the ID certificate is automatically renewed every 6 months, and the license entitlement is renewed every 30 days. You might want to manually renew the registration for either of these items if you have a limited window for Internet access, or if you make any licensing changes in the Smart Software Manager, for example.

Change Cisco Success Network Enrollment

You enable Cisco Success Network when you register the Firepower 9300 with the Cisco Smart Software Manager. After that, use the following procedure to view or change enrollment status.



Note Cisco Success Network does not work in evaluation mode.

Procedure

Step 1 Enter the system scope.

scope system

Example:

```
Firepower# scope system
Firepower /system #
```

Step 2 Enter the services scope.

scope services

Example:

```
Firepower /system # scope services
Firepower /system/services #
```

Step 3 Enter the telemetry scope.

scope telemetry

Example:

```
Firepower /system/services # scope telemetry
Firepower /system/services/telemetry #
```

Step 4 Enable or disable the Cisco Success Network feature.

{enable | disable}

Example:

```
Firepower /system/services/telemetry # enable
```

Step 5 Verify the Cisco Success Network status in the Firepower 9300 Chassis.

show detail

Example:

Verify that the **Admin State** shows the correct status of Cisco Success Network.

```
Telemetry:
  Admin State: Enabled
  Oper State: Registering
  Error Message:
  Period: 86400
  Current Task: Registering the device for Telemetry
  (FSM-STAGE:sam:dme:CommTelemetryDataExchSeq:RegisterforTelemetry)
```

Example:

Verify that the **Oper State** shows **OK**, which indicates that telemetry data is sent.

```
Telemetry:
  Admin State: Enabled
  Oper State: Ok
  Error Message:
  Period: 86400
  Current Task:
```

Monitoring Smart Software Licensing

See the following commands for viewing license status:

- **show license all**

Displays the state of Smart Software Licensing, Smart Agent version, UDI information, Smart Agent state, global compliance status, the entitlements status, licensing certificate information and schedule Smart Agent tasks.

- **show license status**

- **show license techsupport**

History for Smart Software Licensing

Feature Name	Platform Releases	Description
Cisco Success Network	2.7.1	Cisco Success Network is a user-enabled cloud service. When you enable Cisco Success Network, a secure connection is established between the Firepower 9300 chassis and the Cisco cloud to stream usage information and statistics. Streaming telemetry provides a mechanism that selects data of interest from the ASA and transmits it in a structured format to remote management stations to do the following: • Inform you of available unused features that can improve the effectiveness of the product in your network • Inform you of additional technical support services and monitoring that might be available for your product • Help Cisco improve our products Once you enroll in the Cisco Success Network, the chassis establishes and maintains the secure connection at all times. You can turn off this connection at any time by disabling Cisco Success Network, which disconnects the device from the Cisco Success Network cloud. We introduced the following commands: scope telemetry {enable disable} We introduced the following screens: System > Licensing > Cisco Success Network

Feature Name	Platform Releases	Description
Cisco Smart Software Licensing for the Firepower 9300 chassis	1.1(1)	Smart Software Licensing lets you purchase and manage a pool of licenses. Smart licenses are not tied to a specific serial number. You can easily deploy or retire devices without having to manage each unit's license key. Smart Software Licensing also lets you see your license usage and needs at a glance. Smart Software Licensing configuration is split between the Firepower 9300 chassis supervisor and the security module. We introduced the following commands: deregister, register idtoken, renew, scope callhome, scope destination, scope licdebug, scope license, scope monitoring, scope profile, set address, set http-proxy-server-enable on, set http-proxy-server-url, set http-proxy-server-port, show license all, show license status, show license techsupport



CHAPTER 5

User Management

- [User Accounts, on page 25](#)
- [Guidelines for Usernames, on page 26](#)
- [Guidelines for Passwords, on page 27](#)
- [Guidelines for Remote Authentication, on page 27](#)
- [User Roles, on page 30](#)
- [Password Profile for Locally Authenticated Users, on page 30](#)
- [Select the Default Authentication Service, on page 31](#)
- [Configuring the Session Timeout, on page 33](#)
- [Configuring the Role Policy for Remote Users, on page 34](#)
- [Enabling Password Strength Check for Locally Authenticated Users, on page 35](#)
- [Set the Maximum Number of Login Attempts, on page 35](#)
- [Configuring the Maximum Number of Password Changes for a Change Interval, on page 36](#)
- [Configuring a No Change Interval for Passwords, on page 37](#)
- [Configuring the Password History Count, on page 38](#)
- [Creating a Local User Account, on page 39](#)
- [Deleting a Local User Account, on page 41](#)
- [Activating or Deactivating a Local User Account, on page 42](#)
- [Clearing the Password History for a Locally Authenticated User, on page 42](#)

User Accounts

User accounts are used to access the system. You can configure up to 48 local user accounts. Each user account must have a unique username and password.

Admin Account

The admin account is a default user account and cannot be modified or deleted. This account is the system administrator or superuser account and has full privileges. There is no default password assigned to the admin account; you must choose the password during the initial system setup.

The admin account is always active and does not expire. You cannot configure the admin account as inactive.

Locally Authenticated User Accounts

A locally authenticated user account is authenticated directly through the chassis and can be enabled or disabled by anyone with admin or AAA privileges. Once a local user account is disabled, the user cannot log in. Configuration details for disabled local user accounts are not deleted by the database. If you reenable a disabled local user account, the account becomes active again with the existing configuration.

Remotely Authenticated User Accounts

A remotely authenticated user account is any user account that is authenticated through LDAP, RADIUS, or TACACS+.

If a user maintains a local user account and a remote user account simultaneously, the roles defined in the local user account override those maintained in the remote user account.

See the following topics for more information on guidelines for remote authentication, and how to configure and delete remote authentication providers:

- [Guidelines for Remote Authentication, on page 27](#)
- [Configuring LDAP Providers, on page 86](#)
- [Configuring RADIUS Providers, on page 90](#)
- [Configuring TACACS+ Providers, on page 93](#)

Expiration of User Accounts

You can configure user accounts to expire at a predefined time. When the expiration time is reached, the user account is disabled.

By default, user accounts do not expire.

After you configure a user account with an expiration date, you cannot reconfigure the account to not expire. You can, however, configure the account with the latest expiration date available.

Guidelines for Usernames

The username is also used as the login ID for Firepower Chassis Manager and the FXOS CLI. When you assign login IDs to user accounts, consider the following guidelines and restrictions:

- The login ID can contain between 1 and 32 characters, including the following:
 - Any alphabetic character
 - Any digit
 - _ (underscore)
 - - (dash)
 - . (dot)
- The login ID must be unique.
- The login ID must start with an alphabetic character. It cannot start with a number or a special character, such as an underscore.

- The login ID is case-sensitive.
- You cannot create an all-numeric login ID.
- After you create a user account, you cannot change the login ID. You must delete the user account and create a new one.

Guidelines for Passwords

A password is required for each locally authenticated user account. A user with admin or AAA privileges can configure the system to perform a password strength check on user passwords. If the password strength check is enabled, each user must have a strong password.

We recommend that each user have a strong password. If you enable the password strength check for locally authenticated users, the Firepower eXtensible Operating System rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters.
- Must contain at least three of the following:
 - An uppercase alphabetic character
 - A lowercase alphabetic character
 - A non-alphanumeric (special) character
 - Digits
- Must not contain a space.
- Must not contain a character that is repeated more than 3 times consecutively, such as aaabbb.
- Must not contain three consecutive numbers or letters in any order, such as passwordABC or password321.
- Must not be identical to the username or the reverse of the username.
- Must pass a password dictionary check. For example, the password must not be based on a standard dictionary word.
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), and = (equals sign).



Note This restriction applies whether the password strength check is enabled or not.

- Must not be blank for local user and admin accounts.

Guidelines for Remote Authentication

If a system is configured for one of the supported remote authentication services, you must create a provider for that service to ensure that the Firepower 9300 chassis can communicate with the system. The following guidelines impact user authorization:

User Accounts in Remote Authentication Services

User accounts can exist locally in the Firepower 9300 chassis or in the remote authentication server.

You can view the temporary sessions for users who log in through remote authentication services from the Firepower Chassis Manager or the FXOS CLI.

User Roles in Remote Authentication Services

If you create user accounts in the remote authentication server, you must ensure that the accounts include the roles those users require for working in the Firepower 9300 chassis and that the names of those roles match the names used in FXOS. Based on the role policy, a user might not be allowed to log in, or is granted only read-only privileges.

User Attributes in Remote Authentication Providers

For RADIUS and TACACS+ configurations, you must configure a user attribute for the Firepower 9300 chassis in each remote authentication provider through which users log in to Firepower Chassis Manager or the FXOS CLI. This user attribute holds the roles and locales assigned to each user.

When a user logs in, FXOS does the following:

1. Queries the remote authentication service.
2. Validates the user.
3. If the user is validated, checks the roles and locales assigned to that user.

The following table contains a comparison of the user attribute requirements for the remote authentication providers supported by FXOS:

Authentication Provider	Custom Attribute	Schema Extension	Attribute ID Requirements
LDAP	Optional	You can choose to do one of the following: • Do not extend the LDAP schema and configure an existing, unused attribute that meets the requirements. • Extend the LDAP schema and create a custom attribute with a unique name, such as CiscoAVPair.	The Cisco LDAP implementation requires a unicode type attribute. If you choose to create the CiscoAVPair custom attribute, use the following attribute ID: 1.3.6.1.4.1.9.287247.1 A sample OID is provided in the following section.

Authentication Provider	Custom Attribute	Schema Extension	Attribute ID Requirements
RADIUS	Optional	You can choose to do one of the following: - Do not extend the RADIUS schema and use an existing, unused attribute that meets the requirements. - Extend the RADIUS schema and create a custom attribute with a unique name, such as cisco-avpair.	The vendor ID for the Cisco RADIUS implementation is 009 and the vendor ID for the attribute is 001. The following syntax example shows how to specify multiples user roles and locales if you choose to create the cisco-avpair attribute: <code>shell:roles="admin,aaa"</code> <code>shell:locales="L1,abc"</code>. Use a comma "," as the delimiter to separate multiple values.
TACACS+	Required	You must extend the schema and create a custom attribute with the name cisco-av-pair.	The cisco-av-pair name is the string that provides the attribute ID for the TACACS+ provider. The following syntax example shows how to specify multiples user roles and locales when you create the cisco-av-pair attribute: <code>cisco-av-pair=shell:roles="admin aaa" shell:locales*"L1 abc"</code>. Using an asterisk (*) in the cisco-av-pair attribute syntax flags the locale as optional, preventing authentication failures for other Cisco devices that use the same authorization profile. Use a space as the delimiter to separate multiple values.

Sample OID for LDAP User Attribute

The following is a sample OID for a custom CiscoAVPair attribute:

```

CN=CiscoAVPair,CN=Schema,
CN=Configuration,CN=X
objectClass: top
objectClass: attributeSchema
cn: CiscoAVPair
distinguishedName: CN=CiscoAVPair,CN=Schema,CN=Configuration,CN=X
instanceType: 0x4
uSNCreated: 26318654
attributeID: 1.3.6.1.4.1.9.287247.1
attributeSyntax: 2.5.5.12
isSingleValued: TRUE
showInAdvancedViewOnly: TRUE
adminDisplayName: CiscoAVPair
adminDescription: UCS User Authorization Field
oMSyntax: 64

```

```
IDAPDisplayName: CiscoAVPair
name: CiscoAVPair
objectCategory: CN=Attribute-Schema,CN=Schema,CN=Configuration,CN=X
```

User Roles

The system contains the following user roles:

Administrator

Complete read-and-write access to the entire system. The default admin account is assigned this role by default and it cannot be changed.

Read-Only

Read-only access to system configuration with no privileges to modify the system state.

Password Profile for Locally Authenticated Users

The password profile contains the password history and password change interval properties for all locally authenticated users. You cannot specify a different password profile for each locally authenticated user.

Password History Count

The password history count allows you to prevent locally authenticated users from reusing the same password over and over again. When this property is configured, the Firepower chassis stores passwords that were previously used by locally authenticated users up to a maximum of 15 passwords. The passwords are stored in reverse chronological order with the most recent password first to ensure that the only the oldest password can be reused when the history count threshold is reached.

A user must create and use the number of passwords configured in the password history count before being able to reuse one. For example, if you set the password history count to 8, a locally authenticated user cannot reuse the first password until after the ninth password has expired.

By default, the password history is set to 0. This value disables the history count and allows users to reuse previously passwords at any time.

If necessary, you can clear the password history count for a locally authenticated user and enable reuse of previous passwords.

Password Change Interval

The password change interval enables you to restrict the number of password changes a locally authenticated user can make within a given number of hours. The following table describes the two configuration options for the password change interval.

Interval Configuration	Description	Example
No password change allowed	This option does not allow passwords for locally authenticated users to be changed within a specified number of hours after a password change. You can specify a no change interval between 1 and 745 hours. By default, the no change interval is 24 hours.	For example, to prevent passwords from being changed within 48 hours after a locally authenticated user changes his or her password, set the following: • Change during interval to disable • No change interval to 48
Password changes allowed within change interval	This option specifies the maximum number of times that passwords for locally authenticated users can be changed within a pre-defined interval. You can specify a change interval between 1 and 745 hours and a maximum number of password changes between 0 and 10. By default, a locally authenticated user is permitted a maximum of 2 password changes within a 48 hour interval.	For example, to allow a password to be changed a maximum of once within 24 hours after a locally authenticated user changes his or her password, set the following: • Change during interval to enable • Change count to 1 • Change interval to 24

Select the Default Authentication Service

Procedure

-
- Step 1** Enter security mode:
Firepower-chassis # **scope security**
- Step 2** Enter default authorization security mode:
Firepower-chassis /security # **scope default-auth**
- Step 3** Specify the default authentication:
Firepower-chassis /security/default-auth # **set realm auth-type**
where *auth-type* is one of the following keywords:
- **ldap**—Specifies LDAP authentication
 - **local**—Specifies local authentication
 - **none**—Allows local users to log on without specifying a password
 - **radius**—Specifies RADIUS authentication
 - **tacacs**—Specifies TACACS+ authentication

Note If Default Authentication and Console Authentication are both set to use the same remote authentication protocol (RADIUS, TACACS+, or LDAP), you cannot change certain aspects of that server's configuration (for example, deleting that server, or changing its order of assignment) without updating these user settings.

Step 4 (Optional) Specify the associated provider group, if any:

Firepower-chassis /security/default-auth # **set auth-server-group** *auth-serv-group-name*

Step 5 (Optional) Specify the maximum amount of time allowed between refresh requests for a user in this domain:

Firepower-chassis /security/default-auth # **set refresh-period** *seconds*

Specify an integer between 60 and 172800. The default is 600 seconds.

If this time limit is exceeded, FXOS considers the web session to be inactive, but it does not terminate the session.

Step 6 (Optional) Specify the maximum amount of time that can elapse after the last refresh request before FXOS considers a web session to have ended:

Firepower-chassis /security/default-auth # **set session-timeout** *seconds*

Specify an integer between 60 and 172800. The default is 7200 seconds.

Note If you set two-factor authentication for a RADIUS or TACACS+ realm, consider increasing the **session-refresh** and **session-timeout** periods so that remote users do not have to reauthenticate too frequently.

Step 7 (Optional) Set the authentication method to two-factor authentication for the realm:

Firepower-chassis /security/default-auth # **set use-2-factor** *yes*

Note Two-factor authentication applies only to the RADIUS and TACACS+ realms.

Step 8 Commit the transaction to the system configuration:

commit-buffer

Example

The following example sets the default authentication to RADIUS, the default authentication provider group to provider1, enables two-factor authentications, sets the refresh period to 300 seconds (5 minutes), the session timeout period to 540 seconds (9 minutes), and enables two-factor authentication. It then commits the transaction.

```
Firepower-chassis# scope security
Firepower-chassis /security # scope default-auth
Firepower-chassis /security/default-auth # set realm radius
Firepower-chassis /security/default-auth* # set auth-server-group provider1
Firepower-chassis /security/default-auth* # set use-2-factor yes
Firepower-chassis /security/default-auth* # set refresh-period 300
Firepower-chassis /security/default-auth* # set session-timeout 540
Firepower-chassis /security/default-auth* # commit-buffer
Firepower-chassis /security/default-auth #
```

Configuring the Session Timeout

You can use the FXOS CLI to specify the amount of time that can pass without user activity before the Firepower 9300 chassis closes user sessions. You can configure different settings for console sessions and for HTTPS, SSH, and Telnet sessions.

You can set a timeout value up to 3600 seconds (60 minutes). The default value is 600 seconds. To disable this setting, set the session timeout value to 0.

Procedure

-
- | | |
|---------------|---|
| Step 1 | Enter security mode:
Firepower-chassis # scope security |
| Step 2 | Enter default authorization security mode:
Firepower-chassis /security # scope default-auth |
| Step 3 | Set the idle timeout for HTTPS, SSH, and Telnet sessions:
Firepower-chassis /security/default-auth # set session-timeout <i>seconds</i> |
| Step 4 | (Optional) Set the idle timeout for console sessions:
Firepower-chassis /security/default-auth # set con-session-timeout <i>seconds</i> |
| Step 5 | Commit the transaction to the system configuration:
Firepower-chassis /security/default-auth # commit-buffer |
| Step 6 | (Optional) View the session and absolute session timeout settings:
Firepower-chassis /security/default-auth # show detail |

Example:

```
Default authentication:
Admin Realm: Local
Operational Realm: Local
Web session refresh period(in secs): 600
Idle Session timeout (in secs) for web, ssh, telnet sessions: 600
Absolute Session timeout (in secs) for web, ssh, telnet sessions: 3600
Serial Console Session timeout(in secs): 600
Serial Console Absolute Session timeout(in secs): 3600
Admin Authentication server group:
Operational Authentication server group:
Use of 2nd factor: No
```

Configuring the Role Policy for Remote Users

By default, read-only access is granted to all users logging in to Firepower Chassis Manager or the FXOS CLI from a remote server using the LDAP, RADIUS, or TACACS+ protocols. For security reasons, it might be desirable to restrict access to those users matching an established user role.

You can configure the role policy for remote users in the following ways:

assign-default-role

When a user attempts to log in and the remote authentication provider does not supply a user role with the authentication information, the user is allowed to log in with a read-only user role.

This is the default behavior.

no-login

When a user attempts to log in and the remote authentication provider does not supply a user role with the authentication information, access is denied.

Procedure

-
- | | |
|---------------|---|
| Step 1 | Enter security mode:
Firepower-chassis # scope security |
| Step 2 | Specify whether user access to Firepower Chassis Manager and the FXOS CLI should be restricted based on user roles:
Firepower-chassis /security # set remote-user default-role {assign-default-role no-login} |
| Step 3 | Commit the transaction to the system configuration:
Firepower-chassis /security # commit-buffer |
-

Example

The following example sets the role policy for remote users and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # set remote-user default-role no-login
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Enabling Password Strength Check for Locally Authenticated Users

If the password strength check is enabled, the Firepower eXtensible Operating System does not permit a user to choose a password that does not meet the guidelines for a strong password (see [Guidelines for Passwords, on page 27](#)).

Procedure

-
- | | |
|---------------|--|
| Step 1 | Enter security mode:

Firepower-chassis # scope security |
| Step 2 | Specify whether the password strength check is enabled or disabled:

Firepower-chassis /security # set enforce-strong-password {yes no} |
-

Example

The following example enables the password strength check:

```
Firepower-chassis# scope security
Firepower-chassis /security # set enforce-strong-password yes
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Set the Maximum Number of Login Attempts

You can configure the maximum number of failed login attempts allowed before a user is locked out of the Firepower 9300 chassis for a specified amount of time. If a user exceeds the set maximum number of login attempts, the user is locked out of the system. No notification appears indicating that the user is locked out. In this event, the user must wait the specified amount of time before attempting to log in.

Perform these steps to configure the maximum number of login attempts.



Note

-
- The default maximum number of unsuccessful login attempts is 3. The default amount of time the user is locked out of the system after exceeding the maximum number of login attempts is 60 minutes (3600 seconds).

Procedure

-
- Step 1** From the FXOS CLI, enter security mode:
scope security
- Step 2** Set the maximum number of unsuccessful login attempts.
set max-login-attempts *num_attempts*
- Step 3** Specify the amount of time (in seconds) the user should remain locked out of the system after reaching the maximum number of login attempts:
set user-account-unlock-time
unlock_time
- Step 4** Commit the configuration:
commit-buffer
-

Configuring the Maximum Number of Password Changes for a Change Interval

Procedure

-
- Step 1** Enter security mode:
Firepower-chassis # **scope security**
- Step 2** Enter password profile security mode:
Firepower-chassis /security # **scope password-profile**
- Step 3** Restrict the number of password changes a locally authenticated user can make within a given number of hours:
Firepower-chassis /security/password-profile # **set change-during-interval** **enable**
- Step 4** Specify the maximum number of times a locally authenticated user can change his or her password during the Change Interval:
Firepower-chassis /security/password-profile # **set change-count** *pass-change-num*
This value can be anywhere from 0 to 10.
- Step 5** Specify the maximum number of hours over which the number of password changes specified in the **Change Count** field are enforced:
Firepower-chassis /security/password-profile # **set change-interval** *num-of-hours*
This value can be anywhere from 1 to 745 hours.

For example, if this field is set to 48 and the **Change Count** field is set to 2, a locally authenticated user can make no more than 2 password changes within a 48 hour period.

- Step 6** Commit the transaction to the system configuration:
Firepower-chassis /security/password-profile # **commit-buffer**

Example

The following example enables the change during interval option, sets the change count to 5, sets the change interval to 72 hours, and commits the transaction:

```
Firepower-chassis # scope security
Firepower-chassis /security # scope password-profile
Firepower-chassis /security/password-profile # set change-during-interval enable
Firepower-chassis /security/password-profile* # set change-count 5
Firepower-chassis /security/password-profile* # set change-interval 72
Firepower-chassis /security/password-profile* # commit-buffer
Firepower-chassis /security/password-profile #
```

Configuring a No Change Interval for Passwords

Procedure

- Step 1** Enter security mode:
Firepower-chassis # **scope security**
- Step 2** Enter password profile security mode:
Firepower-chassis /security # **scope password-profile**
- Step 3** Disable the change during interval feature:
Firepower-chassis /security/password-profile # **set change-during-interval disable**
- Step 4** Specify the minimum number of hours that a locally authenticated user must wait before changing a newly created password:
Firepower-chassis /security/password-profile # **set no-change-interval min-num-hours**
This value can be anywhere from 1 to 745 hours.
This interval is ignored if the **Change During Interval** property is not set to **Disable**.
- Step 5** Commit the transaction to the system configuration:
Firepower-chassis /security/password-profile # **commit-buffer**

Example

The following example disables the change during interval option, sets the no change interval to 72 hours, and commits the transaction:

```
Firepower-chassis # scope security
Firepower-chassis /security # scope password-profile
Firepower-chassis /security/password-profile # set change-during-interval disable
Firepower-chassis /security/password-profile* # set no-change-interval 72
Firepower-chassis /security/password-profile* # commit-buffer
Firepower-chassis /security/password-profile #
```

Configuring the Password History Count

Procedure

-
- Step 1** Enter security mode:
- ```
Firepower-chassis # scope security
```
- Step 2** Enter password profile security mode:
- ```
Firepower-chassis /security # scope password-profile
```
- Step 3** Specify the number of unique passwords that a locally authenticated user must create before that user can reuse a previously used password:
- ```
Firepower-chassis /security/password-profile # set history-count num-of-passwords
```
- This value can be anywhere from 0 to 15.
- By default, the **History Count** field is set to 0, which disables the history count and allows users to reuse previously used passwords at any time.
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower-chassis /security/password-profile # commit-buffer
```
-

Example

The following example configures the password history count and commits the transaction:

```
Firepower-chassis # scope security
Firepower-chassis /security # scope password-profile
Firepower-chassis /security/password-profile # set history-count 5
Firepower-chassis /security/password-profile* # commit-buffer
Firepower-chassis /security/password-profile #
```

Creating a Local User Account

Procedure

-
- Step 1** Enter security mode:
Firepower-chassis# **scope security**
- Step 2** Create the user account:
Firepower-chassis /security # **create local-user** *local-user-name*
where *local-user-name* is the account name to be used when logging into this account. This name must be unique and meet the guidelines and restrictions for user account names (see [Guidelines for Usernames, on page 26](#)).
After you create the user, the login ID cannot be changed. You must delete the user account and create a new one.
- Step 3** Specify whether the local user account is enabled or disabled:
Firepower-chassis /security/local-user # **set account-status** {**active**|**inactive**}
- Step 4** Set the password for the user account:
Firepower-chassis /security/local-user # **set password**
Enter a password: *password*
Confirm the password: *password*
If password strength check is enabled, a user's password must be strong and the Firepower eXtensible Operating System rejects any password that does not meet the strength check requirements (see [Guidelines for Passwords, on page 27](#)).
- Note** Passwords must not contain the following symbols: \$ (dollar sign), ? (question mark), and = (equals sign). This restriction applies whether the password strength check is enabled or not.
- Step 5** (Optional) Specify the first name of the user:
Firepower-chassis /security/local-user # **set firstname** *first-name*
- Step 6** (Optional) Specify the last name of the user:
Firepower-chassis /security/local-user # **set lastname** *last-name*
- Step 7** (Optional) Specify the date that the user account expires. The *month* argument is the first three letters of the month name.
Firepower-chassis /security/local-user # **set expiration** *month day-of-month year*
- Note** After you configure a user account with an expiration date, you cannot reconfigure the account to not expire. You can, however, configure the account with the latest expiration date available.
- Step 8** (Optional) Specify the user e-mail address.

- Firepower-chassis /security/local-user # **set email** *email-addr*
- Step 9** (Optional) Specify the user phone number.
- Firepower-chassis /security/local-user # **set phone** *phone-num*
- Step 10** (Optional) Specify the SSH key used for passwordless access.
- Firepower-chassis /security/local-user # **set sshkey** *ssh-key*
- Step 11** All users are assigned the *read-only* role by default and this role cannot be removed. For each additional role that you want to assign to the user:
- Firepower-chassis /security/local-user # **create role** *role-name*
- where *role-name* is the role that represents the privileges you want to assign to the user account (see [User Roles](#), on page 30).
- Note** Changes in user roles and privileges do not take effect until the next time the user logs in. If a user is logged in when you assign a new role to or remove an existing role from a user account, the active session continues with the previous roles and privileges.
- Step 12** To remove an assigned role from the user:
- Firepower-chassis /security/local-user # **delete role** *role-name*
- All users are assigned the *read-only* role by default and this role cannot be removed.
- Step 13** Commit the transaction.
- Firepower-chassis security/local-user # **commit-buffer**

Example

The following example creates the user account named kikipopo, enables the user account, sets the password to fool12345, assigns the admin user role, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # create local-user kikipopo
Firepower-chassis /security/local-user* # set account-status active
Firepower-chassis /security/local-user* # set password
Enter a password:
Confirm the password:
Firepower-chassis /security/local-user* # create role admin
Firepower-chassis /security/local-user* # commit-buffer
Firepower-chassis /security/local-user #
```

The following example creates the user account named lincey, enables the user account, sets an OpenSSH key for passwordless access, assigns the aaa and operations user roles, and commits the transaction.

```
Firepower-chassis# scope security
Firepower-chassis /security # create local-user lincey
Firepower-chassis /security/local-user* # set account-status active
Firepower-chassis /security/local-user* # set sshkey "ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAu09VQ2CmWBI9/S1f30klCWjnV3lgdXMzO0WU15iPw851kdQqap+NFuNmHcb4K
iaQB8X/PDdmtlxQQcawclj+k8f4VcOelBx1sGk5luq5ls1ob1VOIEwcKEL/h5lrdBNlI8y3SS9I/gGiBZ9AR1op9LDpd
```

```
m8HPh2LOgyH7Ei1MI8="
Firepower-chassis /security/local-user* # create role aaa
Firepower-chassis /security/local-user* # create role operations
Firepower-chassis /security/local-user* # commit-buffer
Firepower-chassis /security/local-user #
```

The following example creates the user account named jforlenz, enables the user account, sets a Secure SSH key for passwordless access, and commits the transaction.

```
Firepower-chassis# scope security
Firepower-chassis /security # create local-user jforlenz
Firepower-chassis /security/local-user* # set account-status active
Firepower-chassis /security/local-user* # set sshkey
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
User's SSH key:
> ---- BEGIN SSH2 PUBLIC KEY ----
>AAAAB3NzaC1yc2EAAAABIwAAAIEAuo9VQ2CmWBI9/S1f30klCWjnV3lgdXMzO0WU15iPw8
>5lkdQqap+NFuNmHcb4KiaQB8X/PDdmtlxQQcawclj+k8f4VcOelBx1sGk5luq5ls1ob1VO
>IEwcKEL/h51rdbN1I8y3SS9I/gGiBZ9ARlop9LDpDm8HPh2LOgyH7Ei1MI8=
> ---- END SSH2 PUBLIC KEY ----
> ENDOFBUF
Firepower-chassis /security/local-user* # commit-buffer
Firepower-chassis /security/local-user #
```

Deleting a Local User Account

Procedure

-
- | | |
|---------------|---|
| Step 1 | Enter security mode:

Firepower-chassis# scope security |
| Step 2 | Delete the local-user account:

Firepower-chassis /security # delete local-user <i>local-user-name</i> |
| Step 3 | Commit the transaction to the system configuration:

Firepower-chassis /security # commit-buffer |
-

Example

The following example deletes the foo user account and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # delete local-user foo
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Activating or Deactivating a Local User Account

You must be a user with admin or AAA privileges to activate or deactivate a local user account.

Procedure

- Step 1** Enter security mode:
Firepower-chassis# **scope security**
- Step 2** Enter local-user security mode for the user you want to activate or deactivate:
Firepower-chassis /security # **scope local-user** *local-user-name*
- Step 3** Specify whether the local user account is active or inactive:
Firepower-chassis /security/local-user # **set account-status** {**active** | **inactive**}
- Note** The admin user account is always set to active. It cannot be modified.
- Step 4** Commit the transaction to the system configuration:
Firepower-chassis /security/local-user # **commit-buffer**
-

Example

The following example enables a local user account called accounting:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope local-user accounting
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Clearing the Password History for a Locally Authenticated User

Procedure

- Step 1** Enter security mode:
Firepower-chassis # **scope security**
- Step 2** Enter local user security mode for the specified user account:
Firepower-chassis /security # **scope local-user** *user-name*
- Step 3** Clear the password history for the specified user account:

```
Firepower-chassis /security/local-user # clear password-history
```

Step 4 Commit the transaction to the system configuration:

```
Firepower-chassis /security/local-user # commit-buffer
```

Example

The following example clears the password history and commits the transaction:

```
Firepower-chassis # scope security  
Firepower-chassis /security # scope local-user admin  
Firepower-chassis /security/local-user # clear password-history  
Firepower-chassis /security/local-user* # commit-buffer  
Firepower-chassis /security/local-user #
```




CHAPTER 6

Image Management

- [About Image Management, on page 45](#)
- [Downloading Images from Cisco.com, on page 46](#)
- [Downloading a Firepower eXtensible Operating System Software Image to the Firepower 9300 chassis, on page 46](#)
- [Verifying the Integrity of an Image, on page 47](#)
- [Upgrading the Firepower eXtensible Operating System Platform Bundle, on page 48](#)
- [Downloading a Logical Device Software Image to the Firepower 9300 chassis, on page 48](#)
- [Updating the Image Version for a Logical Device, on page 50](#)
- [Firmware Upgrade, on page 52](#)

About Image Management

The Firepower 9300 chassis uses two basic types of images:



Note All images are digitally signed and validated through Secure Boot. Do not modify the image in any way or you will receive a validation error.

- **Platform Bundle**—The Firepower platform bundle is a collection of multiple independent images that operate on the Firepower Supervisor and Firepower security module/engine. The platform bundle is a Firepower eXtensible Operating System software package.
- **Application**—Application images are the software images you want to deploy on the security module/engine of the Firepower 9300 chassis. Application images are delivered as Cisco Secure Package files (CSP) and are stored on the supervisor until deployed to a security module/engine as part of logical device creation or in preparation for later logical device creation. For release 1.1.1, the only available application images are for the ASA. You can have multiple different versions of the same application image type stored on the Firepower Supervisor.



Note If you are upgrading both the Platform Bundle image and one or more Application images, you must upgrade the Platform Bundle first.

Downloading Images from Cisco.com

Download FXOS and application images from Cisco.com so you can upload them to the Firepower chassis.

Before you begin

You must have a Cisco.com account.

Procedure

-
- Step 1** Using a web browser, navigate to <http://www.cisco.com/go/firepower9300-software> or <http://www.cisco.com/go/firepower4100-software>.
The software download page for the Firepower 9300 chassis is opened in the browser.
- Step 2** Find and then download the appropriate software image to your local computer.
-

Downloading a Firepower eXtensible Operating System Software Image to the Firepower 9300 chassis

You can use FTP, SCP, SFTP, or TFTP to copy the FXOS software image to the Firepower 9300 chassis.

Before you begin

Collect the following information that you will need to import a configuration file:

- IP address and authentication credentials for the server from which you are copying the image
- Fully qualified name of the FXOS image file

Procedure

-
- Step 1** Enter firmware mode:
Firepower-chassis # **scope firmware**
- Step 2** Download the FXOS software image:
Firepower-chassis /firmware # **download image** *URL*
Specify the URL for the file being imported using one of the following syntax:
- **ftp**://username@hostname / path / image_name
 - **scp**://username@hostname / path / image_name
 - **sftp**://username@hostname / path / image_name
 - **tftp**://hostname : port-num / path / image_name

- Step 3** To monitor the download process:
- Firepower-chassis /firmware # **show package image_name detail**

Example

The following example copies an image using the SCP protocol:

```
Firepower-chassis # scope firmware
Firepower-chassis /firmware # download image
scp://user@192.168.1.1/images/fxos-k9.1.1.1.119.SPA
Firepower-chassis /firmware # show package fxos-k9.1.1.1.119.SPA detail
Download task:
  File Name: fxos-k9.1.1.1.119.SPA
  Protocol: scp
  Server: 192.168.1.1
  Userid:
  Path:
  Downloaded Image Size (KB): 5120
  State: Downloading
  Current Task: downloading image fxos-k9.1.1.1.119.SPA from
192.168.1.1 (FSM-STAGE:sam:dme:FirmwareDownloaderDownload:Local)
```

Verifying the Integrity of an Image

The integrity of the image is automatically verified when a new image is added to the Firepower 9300 chassis. If needed, you can use the following procedure to manually verify the integrity of an image.

Procedure

- Step 1** Connect to the FXOS CLI (see [Accessing the FXOS CLI, on page 12](#)).
- Step 2** Enter firmware mode:
- Firepower-chassis# **scope firmware**
- Step 3** List images:
- Firepower-chassis /firmware # **show package**
- Step 4** Verify the image:
- Firepower-chassis /firmware # **verify platform-pack version version_number**
- version_number* is the version number of the FXOS platform bundle you are verifying--for example, 1.1(2.51).
- Step 5** To check the status of the image verification:
- Firepower-chassis /firmware # **show validate-task**

Upgrading the Firepower eXtensible Operating System Platform Bundle

Before you begin

Download the platform bundle software image from Cisco.com (see [Downloading Images from Cisco.com, on page 46](#)) and then download that image to the Firepower 9300 chassis (see [Downloading a Logical Device Software Image to the Firepower 9300 chassis, on page 48](#)).

Procedure

- Step 1** Connect to the FXOS CLI (see [Accessing the FXOS CLI, on page 12](#)).
- Step 2** Enter firmware mode:
Firepower-chassis# **scope firmware**
- Step 3** Enter auto-install mode:
Firepower-chassis /firmware # **scope auto-install**
- Step 4** Install the FXOS platform bundle:
Firepower-chassis /firmware/auto-install # **install platform platform-vers version_number**
version_number is the version number of the FXOS platform bundle you are installing--for example, 1.1(2.51).
- Step 5** Enter **yes** to confirm that you want to proceed with installation, or enter **no** to cancel the installation.
The Firepower eXtensible Operating System unpacks the bundle and upgrades/reloads the components.
- Step 6** To monitor the upgrade process:
- Enter **scope firmware**.
 - Enter **scope auto-install**.
 - Enter **show fsm status expand**.
-

Downloading a Logical Device Software Image to the Firepower 9300 chassis

You can use FTP, SCP, SFTP, or TFTP to copy the logical device software image to the Firepower 9300 chassis.

Before you begin

Collect the following information that you will need to import a configuration file:

- IP address and authentication credentials for the server from which you are copying the image

- Fully qualified name of the software image file

Procedure

-
- Step 1** Enter Security Services mode:
Firepower-chassis # **scope ssa**
- Step 2** Enter Application Software mode:
Firepower-chassis /ssa # **scope app-software**
- Step 3** Download the logical device software image:
Firepower-chassis /ssa/app-software # **download image URL**
Specify the URL for the file being imported using one of the following syntax:
- **ftp://username@hostname/path**
 - **scp://username@hostname/path**
 - **sftp://username@hostname/path**
 - **tftp://hostname:port-num/path**
- Step 4** To monitor the download process:
Firepower-chassis /ssa/app-software # **show download-task**
- Step 5** To view the downloaded applications:
Firepower-chassis /ssa/app-software # **up**
Firepower-chassis /ssa # **show app**
- Step 6** To view details for a specific application:
Firepower-chassis /ssa # **scope app application_type image_version**
Firepower-chassis /ssa/app # **show expand**
-

Example

The following example copies an image using the SCP protocol:

```
Firepower-chassis # scope ssa
Firepower-chassis /ssa # scope app-software
Firepower-chassis /ssa/app-software # download image
scp://user@192.168.1.1/images/cisco-asa.9.4.1.65.csp
Firepower-chassis /ssa/app-software # show download-task
```

Downloads for Application Software:

File Name	Protocol	Server	Userid	State
cisco-asa.9.4.1.65.csp	Scp	192.168.1.1	user	Downloaded

```

Firepower-chassis /ssa/app-software # up

Firepower-chassis /ssa # show app

Application:
  Name      Version      Description  Author      Deploy Type  CSP Type      Is Default App
  -----
  asa       9.4.1.41      N/A          N/A          Native        Application    No
  asa       9.4.1.65      N/A          N/A          Native        Application    Yes

Firepower-chassis /ssa # scope app asa 9.4.1.65
Firepower-chassis /ssa/app # show expand

Application:
  Name: asa
  Version: 9.4.1.65
  Description: N/A
  Author:
  Deploy Type: Native
  CSP Type: Application
  Is Default App: Yes

App Attribute Key for the Application:
  App Attribute Key  Description
  -----
  cluster-role       This is the role of the blade in the cluster
  mgmt-ip             This is the IP for the management interface
  mgmt-url            This is the management URL for this application

Net Mgmt Bootstrap Key for the Application:
  Bootstrap Key  Key Data  Type  Is the Key Secret  Description
  -----
  PASSWORD       String    Yes           The admin user password.

Port Requirement for the Application:
  Port Type: Data
  Max Ports: 120
  Min Ports: 1

  Port Type: Mgmt
  Max Ports: 1
  Min Ports: 1

Mgmt Port Sub Type for the Application:
  Management Sub Type
  -----
  Default

  Port Type: Cluster
  Max Ports: 1
  Min Ports: 0
Firepower-chassis /ssa/app #

```

Updating the Image Version for a Logical Device

Use this procedure to upgrade the ASA application image to a new version, or set the Firepower Threat Defense application image to a new startup version that will be used in a disaster recovery scenario.

When you change the startup version on an ASA logical device, the ASA upgrades to that version and all configuration is restored. Use the following workflows to change the ASA startup version, depending on your configuration:

ASA High Availability -

1. Change the logical device image version(s) on the standby unit.
2. Make the standby unit active.
3. Change the application version(s) on the other unit.

ASA Inter-Chassis Cluster -

1. Change the startup version on the data unit.
2. Make the data unit the control unit.
3. Change the startup version on the original control unit (now data).

Before you begin

Download the application image you want to use for the logical device from Cisco.com (see [Downloading Images from Cisco.com, on page 46](#)) and then download that image to the Firepower 9300 chassis (see [Downloading a Logical Device Software Image to the Firepower 9300 chassis, on page 48](#)).

If you are upgrading both the Platform Bundle image and one or more Application images, you must upgrade the Platform Bundle first.

Procedure

-
- | | |
|---------------|--|
| Step 1 | Enter Security Services mode:
Firepower-chassis # scope ssa |
| Step 2 | Set the scope to the security module you are updating:
Firepower-chassis /ssa # scope slot slot_number |
| Step 3 | Set the scope to the application you are updating:
Firepower-chassis /ssa/slot # scope app-instance app_template |
| Step 4 | Set the Startup version:
Firepower-chassis /ssa/slot/app-instance # set startup-version version_number |
| Step 5 | Commit the configuration:
commit-buffer

Commits the transaction to the system configuration. The application image is updated and the application restarts. |
-

Example

The following example updates the software image for an ASA running on security module 1. Notice that you can use the **show** command to view the update status.

```
Firepower-chassis# scope ssa
Firepower-chassis /ssa # scope slot 1
Firepower-chassis /ssa/slot # scope app-instance asa
Firepower-chassis /ssa/slot/app-instance # set startup-version 9.4.1.65
Firepower-chassis /ssa/slot/app-instance* # show configuration pending
  enter app-instance asa
+   set startup-version 9.4.1.65
  exit
Firepower-chassis /ssa/slot/app-instance* # commit-buffer
Firepower-chassis /ssa/slot/app-instance # show
```

Application Instance:

Application Name	Admin State	Operational State	Running Version	Startup Version
asa	Enabled	Updating	9.4.1.41	9.4.1.65

```
Firepower-chassis /ssa/slot/app-instance #
Firepower-chassis /ssa/slot/app-instance # show
```

Application Instance:

Application Name	Admin State	Operational State	Running Version	Startup Version
asa	Enabled	Online	9.4.1.65	9.4.1.65

```
Firepower-chassis /ssa/slot/app-instance #
```

Firmware Upgrade

For information about upgrading the firmware on your Firepower 9300 chassis, see the [Cisco Firepower 4100/9300 FXOS Firmware Upgrade Guide](#).



CHAPTER 7

Platform Settings

- [Changing the Management IP Address, on page 53](#)
- [Setting the Date and Time, on page 55](#)
- [Configuring SSH, on page 60](#)
- [Configuring Telnet, on page 61](#)
- [Configuring SNMP, on page 62](#)
- [Configuring HTTPS, on page 72](#)
- [Configuring AAA, on page 84](#)
- [Verifying Remote AAA Server Configurations, on page 96](#)
- [Configuring Syslog, on page 97](#)
- [Configuring DNS Servers, on page 100](#)

Changing the Management IP Address

Before you begin

You can change the management IP address on the Firepower 9300 chassis from the FXOS CLI.



Note After changing the management IP address, you will need to reestablish any connections to Firepower Chassis Manager or the FXOS CLI using the new address.

Procedure

- Step 1** Connect to the FXOS CLI (see [Accessing the FXOS CLI, on page 12](#)).
- Step 2** To configure an IPv4 management IP address:
- a) Set the scope for fabric-interconnect a:
Firepower-chassis# **scope fabric-interconnect a**
 - b) To view the current management IP address, enter the following command:
Firepower-chassis /fabric-interconnect # **show**

- c) Enter the following command to configure a new management IP address and gateway:

```
Firepower-chassis /fabric-interconnect # set out-of-band ip ip_address netmask network_mask gw
gateway_ip_address
```

- d) Commit the transaction to the system configuration:

```
Firepower-chassis /fabric-interconnect* # commit-buffer
```

Step 3 To configure an IPv6 management IP address:

- a) Set the scope for fabric-interconnect a:

```
Firepower-chassis# scope fabric-interconnect a
```

- b) Set the scope for management IPv6 configuration:

```
Firepower-chassis /fabric-interconnect # scope ipv6-config
```

- c) To view the current management IPv6 address, enter the following command:

```
Firepower-chassis /fabric-interconnect/ipv6-config # show ipv6-if
```

- d) Enter the following command to configure a new management IP address and gateway:

```
Firepower-chassis /fabric-interconnect/ipv6-config # set out-of-band ipv6 ipv6_address ipv6-prefix
prefix_length ipv6-gw gateway_address
```

Note Only IPv6 Global Unicast addresses are supported as the chassis's IPv6 management address.

- e) Commit the transaction to the system configuration:

```
Firepower-chassis /fabric-interconnect/ipv6-config* # commit-buffer
```

Example

The following example configures an IPv4 management interface and gateway:

```
Firepower-chassis# scope fabric-interconnect a
Firepower-chassis /fabric-interconnect # show

Fabric Interconnect:
  ID    OOB IP Addr      OOB Gateway      OOB Netmask      OOB IPv6 Address OOB IPv6 Gateway
  Prefix Operability
  ----
  A      192.0.2.112         192.0.2.1        255.255.255.0    ::              ::
  64     Operable
Firepower-chassis /fabric-interconnect # set out-of-band ip 192.0.2.111 netmask 255.255.255.0
gw 192.0.2.1
Warning: When committed, this change may disconnect the current CLI session
Firepower-chassis /fabric-interconnect* #commit-buffer
Firepower-chassis /fabric-interconnect #
```

The following example configures an IPv6 management interface and gateway:

```

Firepower-chassis# scope fabric-interconnect a
Firepower-chassis /fabric-interconnect # scope ipv6-config
Firepower-chassis /fabric-interconnect/ipv6-config # show ipv6-if

Management IPv6 Interface:
  IPv6 Address          Prefix      IPv6 Gateway
  -----
  2001::8998            64         2001::1
Firepower-chassis /fabric-interconnect/ipv6-config # set out-of-band ipv6 2001::8999
ipv6-prefix 64 ipv6-gw 2001::1
Firepower-chassis /fabric-interconnect/ipv6-config* # commit-buffer
Firepower-chassis /fabric-interconnect/ipv6-config #

```

Setting the Date and Time

Use the CLI commands described below to configure the network time protocol (NTP) on the system, to set the date and time manually, or to view the current system time.

NTP settings are automatically synced between the Firepower 9300 chassis and any logical devices installed on the chassis.

Setting the Time Zone

Procedure

-
- Step 1** Enter system mode:
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:
Firepower-chassis /system # **scope services**
- Step 3** Set the time zone:
Firepower-chassis /system/services # **set timezone**
- At this point, you are prompted to enter a number corresponding to your continent, country, and time zone region. Enter the appropriate information at each prompt.
- When you have finished specifying the location information, you are prompted to confirm that the correct time zone information is being set. Enter **1** (yes) to confirm, or **2** (no) to cancel the operation.
- Step 4** To view the configured time zone:
Firepower-chassis /system/services # **top**
Firepower-chassis# **show timezone**
-

Example

The following example configures the time zone to the Pacific time zone region, commits the transaction, and displays the configured time zone:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set timezone
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
1) Africa                4) Arctic Ocean          7) Australia            10) Pacific Ocean
2) Americas              5) Asia                  8) Europe
3) Antarctica           6) Atlantic Ocean        9) Indian Ocean
#? 2
Please select a country.
1) Anguilla              28) Haiti
2) Antigua & Barbuda     29) Honduras
3) Argentina            30) Jamaica
4) Aruba                 31) Martinique
5) Bahamas              32) Mexico
6) Barbados              33) Montserrat
7) Belize               34) Nicaragua
8) Bolivia               35) Panama
9) Brazil                36) Paraguay
10) Canada               37) Peru
11) Caribbean Netherlands 38) Puerto Rico
12) Cayman Islands       39) St Barthelemy
13) Chile                40) St Kitts & Nevis
14) Colombia             41) St Lucia
15) Costa Rica           42) St Maarten (Dutch part)
16) Cuba                 43) St Martin (French part)
17) Curacao              44) St Pierre & Miquelon
18) Dominica             45) St Vincent
19) Dominican Republic  46) Suriname
20) Ecuador              47) Trinidad & Tobago
21) El Salvador          48) Turks & Caicos Is
22) French Guiana        49) United States
23) Greenland            50) Uruguay
24) Grenada              51) Venezuela
25) Guadeloupe           52) Virgin Islands (UK)
26) Guatemala            53) Virgin Islands (US)
27) Guyana
#? 49
Please select one of the following time zone regions.
1) Eastern Time
2) Eastern Time - Michigan - most locations
3) Eastern Time - Kentucky - Louisville area
4) Eastern Time - Kentucky - Wayne County
5) Eastern Time - Indiana - most locations
6) Eastern Time - Indiana - Daviess, Dubois, Knox & Martin Counties
7) Eastern Time - Indiana - Pulaski County
8) Eastern Time - Indiana - Crawford County
9) Eastern Time - Indiana - Pike County
10) Eastern Time - Indiana - Switzerland County
11) Central Time
12) Central Time - Indiana - Perry County
13) Central Time - Indiana - Starke County
14) Central Time - Michigan - Dickinson, Gogebic, Iron & Menominee Counties
15) Central Time - North Dakota - Oliver County
16) Central Time - North Dakota - Morton County (except Mandan area)
17) Central Time - North Dakota - Mercer County
18) Mountain Time
```

```

19) Mountain Time - south Idaho & east Oregon
20) Mountain Standard Time - Arizona (except Navajo)
21) Pacific Time
22) Pacific Standard Time - Annette Island, Alaska
23) Alaska Time
24) Alaska Time - Alaska panhandle
25) Alaska Time - southeast Alaska panhandle
26) Alaska Time - Alaska panhandle neck
27) Alaska Time - west Alaska
28) Aleutian Islands
29) Hawaii
#? 21

```

The following information has been given:

```

United States
Pacific Time

```

```

Therefore timezone 'America/Los_Angeles' will be set.
Local time is now:      Wed Jun 24 07:39:25 PDT 2015.
Universal Time is now:  Wed Jun 24 14:39:25 UTC 2015.
Is the above information OK?
1) Yes
2) No
#? 1
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services # top
Firepower-chassis# show timezone
Timezone: America/Los_Angeles (Pacific Time)
Firepower-chassis#

```

Setting the Date and Time Using NTP

NTP is used to implement a hierarchical system of servers that provide a precisely synchronized time among network systems. This kind of accuracy is required for time-sensitive operations, such as validating CRLs, which include a precise time stamp.

Before you begin

If you use a hostname for the NTP server, you must configure a DNS server. See [Configuring DNS Servers, on page 100](#).

Procedure

-
- | | |
|---------------|---|
| Step 1 | Enter system mode:
Firepower-chassis# scope system |
| Step 2 | Enter system services mode:
Firepower-chassis /system # scope services |
| Step 3 | Configure the system to use the NTP server with the specified hostname, IPv4, or IPv6 address:
Firepower-chassis /system/services # create ntp-server {hostname ip-addr ip6-addr} |
| Step 4 | Commit the transaction to the system configuration: |

```
Firepower-chassis /system/services # commit-buffer
```

Step 5 To view the synchronization status for all configured NTP servers:

```
Firepower-chassis /system/services # show ntp-server
```

Step 6 To view the synchronization status for a specific NTP server:

```
Firepower-chassis /system/services # scope ntp-server {hostname | ip-addr | ip6-addr}
```

```
Firepower-chassis /system/services/ntp-server # show detail
```

Example

The following example configures an NTP server with the IP address 192.168.200.101 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create ntp-server 192.168.200.101
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example configures an NTP server with the IPv6 address 4001::6 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create ntp-server 4001::6
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

Deleting an NTP Server

Procedure

Step 1 Enter system mode:

```
Firepower-chassis# scope system
```

Step 2 Enter system services mode:

```
Firepower-chassis /system # scope services
```

Step 3 Delete the NTP server with the specified hostname, IPv4, or IPv6 address:

```
Firepower-chassis /system/services # delete ntp-server {hostname | ip-addr | ip6-addr}
```

Step 4 Commit the transaction to the system configuration:

```
Firepower-chassis /system/services # commit-buffer
```

Example

The following example deletes the NTP server with the IP address 192.168.200.101 and commits the transaction:

```
Firepower-chassis# scope system  
Firepower-chassis /system # scope services  
Firepower-chassis /system/services # delete ntp-server 192.168.200.101  
Firepower-chassis /system/services* # commit-buffer  
Firepower-chassis /system/services #
```

The following example deletes the NTP server with the IPv6 address 4001::6 and commits the transaction:

```
Firepower-chassis# scope system  
Firepower-chassis /system # scope services  
Firepower-chassis /system/services # delete ntp-server 4001::6  
Firepower-chassis /system/services* # commit-buffer  
Firepower-chassis /system/services #
```

Setting the Date and Time Manually

This section describes how to set the date and time manually on the Firepower chassis. System clock modifications take effect immediately.



Note If the system clock is currently being synchronized with an NTP server, you will not be able to set the date and time manually.

Procedure

- Step 1** Enter system mode:
- ```
Firepower-chassis# scope system
```
- Step 2** Enter system services mode:
- ```
Firepower-chassis /system # scope services
```
- Step 3** Configure the system clock:
- ```
Firepower-chassis /system/services # set clock month day year hour min sec
```
- For month, use the first three digits of the month. Hours must be entered using the 24-hour format, where 7 pm would be entered as 19.

System clock modifications take effect immediately. You do not need to commit the buffer.

---

### Example

The following example configures the system clock:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set clock jun 24 2015 15 27 00
Firepower-chassis /system/services #
```

## Configuring SSH

The following procedure describes how to enable or disable SSH access to the Firepower chassis, how to enable the FXOS chassis as an SSH client, and how to configure the various algorithms used by SSH for encryption, key exchange, and message authentication for both the SSH server and SSH client.

SSH is enabled by default.

### Procedure

---

- Step 1** Enter system mode:
- ```
Firepower-chassis # scope system
```
- Step 2** Enter system services mode:
- ```
Firepower-chassis /system # scope services
```
- Step 3** To configure SSH access to the Firepower chassis, do one of the following:
- To allow SSH access to the Firepower chassis, enter the following command:  

```
Firepower-chassis /system/services # enable ssh-server
```
  - To disallow SSH access to the Firepower chassis, enter the following command:  

```
Firepower-chassis /system/services # disable ssh-server
```
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower /system/services # commit-buffer
```
-

Example

The following example enables SSH access to the Firepower chassis and commits the transaction:

```
Firepower# scope system
Firepower /system # scope services
Firepower /system/services # enable ssh-server
```

```
Firepower /system/services* # commit-buffer  
Firepower /system/services #
```

Configuring Telnet

The following procedure describes how to enable or disable Telnet access to the Firepower chassis. Telnet is disabled by default.

**Note**

Telnet configuration is currently only available using the CLI.

Procedure

- Step 1** Enter system mode:
Firepower-chassis # **scope system**
- Step 2** Enter system services mode:
Firepower-chassis /system # **scope services**
- Step 3** To configure Telnet access to the Firepower chassis, do one of the following:
- To allow Telnet access to the Firepower chassis, enter the following command:
Firepower-chassis /system/services # **enable telnet-server**
 - To disallow Telnet access to the Firepower chassis, enter the following command:
Firepower-chassis /system/services # **disable telnet-server**
- Step 4** Commit the transaction to the system configuration:
Firepower /system/services # **commit-buffer**

Example

The following example enables Telnet and commits the transaction:

```
Firepower-chassis# scope system  
Firepower-chassis /system # scope services  
Firepower-chassis /services # enable telnet-server  
Firepower-chassis /services* # commit-buffer  
Firepower-chassis /services #
```

Configuring SNMP

This section describes how to configure the Simple Network Management Protocol (SNMP) on the Firepower chassis. See the following topics for more information:

About SNMP

The Simple Network Management Protocol (SNMP) is an application-layer protocol that provides a message format for communication between SNMP managers and agents. SNMP provides a standardized framework and a common language used for the monitoring and management of devices in a network.

The SNMP framework consists of three parts:

- An SNMP manager—The system used to control and monitor the activities of network devices using SNMP.
- An SNMP agent—The software component within the Firepower chassis that maintains the data for the Firepower chassis and reports the data, as needed, to the SNMP manager. The Firepower chassis includes the agent and a collection of MIBs. To enable the SNMP agent and create the relationship between the manager and agent, enable and configure SNMP in the Firepower Chassis Manager or the FXOS CLI.
- A managed information base (MIB)—The collection of managed objects on the SNMP agent.

The Firepower chassis supports SNMPv1, SNMPv2c and SNMPv3. Both SNMPv1 and SNMPv2c use a community-based form of security. SNMP is defined in the following:

- RFC 3410 (<http://tools.ietf.org/html/rfc3410>)
- RFC 3411 (<http://tools.ietf.org/html/rfc3411>)
- RFC 3412 (<http://tools.ietf.org/html/rfc3412>)
- RFC 3413 (<http://tools.ietf.org/html/rfc3413>)
- RFC 3414 (<http://tools.ietf.org/html/rfc3414>)
- RFC 3415 (<http://tools.ietf.org/html/rfc3415>)
- RFC 3416 (<http://tools.ietf.org/html/rfc3416>)
- RFC 3417 (<http://tools.ietf.org/html/rfc3417>)
- RFC 3418 (<http://tools.ietf.org/html/rfc3418>)
- RFC 3584 (<http://tools.ietf.org/html/rfc3584>)

**Note**

Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

SNMP Notifications

A key feature of SNMP is the ability to generate notifications from an SNMP agent. These notifications do not require that requests be sent from the SNMP manager. Notifications can indicate improper user authentication, restarts, the closing of a connection, loss of connection to a neighbor router, or other significant events.

The Firepower chassis generates SNMP notifications as either traps or informs. Traps are less reliable than informs because the SNMP manager does not send any acknowledgment when it receives a trap, and the Firepower chassis cannot determine if the trap was received. An SNMP manager that receives an inform request acknowledges the message with an SNMP response protocol data unit (PDU). If the Firepower chassis does not receive the PDU, it can send the inform request again.

However, informs are available only with SNMPv2c, which is considered insecure, and is not recommended.

SNMP Security Levels and Privileges

SNMPv1, SNMPv2c, and SNMPv3 each represent a different security model. The security model combines with the selected security level to determine the security mechanism applied when the SNMP message is processed.

The security level determines the privileges required to view the message associated with an SNMP trap. The privilege level determines whether the message needs to be protected from disclosure or authenticated. The supported security level depends upon which security model is implemented. SNMP security levels support one or more of the following privileges:

- noAuthNoPriv—No authentication or encryption
- authNoPriv—Authentication but no encryption
- authPriv—Authentication and encryption

SNMPv3 provides for both security models and security levels. A security model is an authentication strategy that is set up for a user and the role in which the user resides. A security level is the permitted level of security within a security model. A combination of a security model and a security level determines which security mechanism is employed when handling an SNMP packet.

Supported Combinations of SNMP Security Models and Levels

The following table identifies what the combinations of security models and levels mean.

Table 4: SNMP Security Models and Levels

Model	Level	Authentication	Encryption	What Happens
v1	noAuthNoPriv	Community string	No	Uses a community string match for authentication.
v2c	noAuthNoPriv	Community string	No	Uses a community string match for authentication.

Model	Level	Authentication	Encryption	What Happens
v3	noAuthNoPriv	Username	No	Uses a username match for authentication. Note While you can configure it, FXOS does not support use of <code>noAuthNoPriv</code> with SNMP version 3.
v3	authNoPriv	HMAC-SHA	No	Provides authentication based on the HMAC Secure Hash Algorithm (SHA).
v3	authPriv	HMAC-SHA	DES	Provides authentication based on the HMAC-SHA algorithm. Provides Data Encryption Standard (DES) 56-bit encryption in addition to authentication based on the Cipher Block Chaining (CBC) DES (DES-56) standard.

SNMPv3 Security Features

SNMPv3 provides secure access to devices by a combination of authenticating and encrypting frames over the network. SNMPv3 authorizes management operations only by configured users and encrypts SNMP messages. The SNMPv3 User-Based Security Model (USM) refers to SNMP message-level security and offers the following services:

- Message integrity—Ensures that messages have not been altered or destroyed in an unauthorized manner and that data sequences have not been altered to an extent greater than can occur non-maliciously.
- Message origin authentication—Ensures that the claimed identity of the user on whose behalf received data was originated is confirmed.
- Message confidentiality and encryption—Ensures that information is not made available or disclosed to unauthorized individuals, entities, or processes.

SNMP Support

The Firepower chassis provides the following support for SNMP:

Support for MIBs

The Firepower chassis supports read-only access to MIBs.

For information about the specific MIBs available and where you can obtain them, see the [Cisco FXOS MIB Reference Guide](#).

Authentication Protocol for SNMPv3 Users

The Firepower chassis supports the HMAC-SHA-96 (SHA) authentication protocol for SNMPv3 users.

AES Privacy Protocol for SNMPv3 Users

The Firepower chassis uses Advanced Encryption Standard (AES) as one of the privacy protocols for SNMPv3 message encryption and conforms with RFC 3826.

The privacy password, or `priv` option, offers a choice of DES or 128-bit AES encryption for SNMP security encryption. If you enable AES-128 configuration and include a privacy password for an SNMPv3 user, the Firepower chassis uses the privacy password to generate a 128-bit AES key. The AES privacy password can have a minimum of eight characters. If the passphrases are specified in clear text, you can specify a maximum of 64 characters.

Enabling SNMP and Configuring SNMP Properties

Procedure

-
- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```
- Step 2** Enable SNMP:
- ```
Firepower-chassis /monitoring # enable snmp
```
- Step 3** (Optional) Enter SNMP community mode:
- ```
Firepower-chassis /monitoring # set snmp community
```
- After you enter the **set snmp community** command, you are prompted to enter the SNMP community name.
- When you specify an SNMP community name, you are also automatically enabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager.
- Note** Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.
- Step 4** Specify the SNMP community name; this community name is used as a SNMP password. The community name can be any alphanumeric string up to 32 characters.
- ```
Firepower-chassis /monitoring # Enter a snmp community: community-name
```
- There can be only one community name; however, you can use **set snmp community** to overwrite the existing name. To delete an existing community name (also disabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager), enter **set snmp community** but do not type a community string; that is, simply press **Enter** again. After you commit the buffer, **show snmp** output will include the line `Is Community Set: No.`
- Step 5** Specify the system contact person responsible for SNMP. The system contact name can be any alphanumeric string up to 255 characters, such as an email address or name and telephone number.
- ```
Firepower-chassis /monitoring # set snmp syscontact system-contact-name
```
- Step 6** Specify the location of the host on which the SNMP agent (server) runs. The system location name can be any alphanumeric string up to 512 characters.
- ```
Firepower-chassis /monitoring # set snmp syslocation system-location-name
```
- Step 7** Commit the transaction to the system configuration:

```
Firepower-chassis /monitoring # commit-buffer
```

Example

The following example enables SNMP, configures an SNMP community named `SnmpCommSystem2`, configures a system contact named `contactperson1`, configures a contact location named `systemlocation`, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # set snmp community
Enter a snmp community: SnmpCommSystem2
Firepower-chassis /monitoring* # set snmp syscontact contactperson1
Firepower-chassis /monitoring* # set snmp syslocation systemlocation
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

What to do next

Create SNMP traps and users.

Creating an SNMP Trap

The following procedure describes how to create SNMP traps.



Note

You can define up to eight SNMP traps.

Procedure

- Step 1** Enter monitoring mode:

```
Firepower-chassis# scope monitoring
```
- Step 2** Enable SNMP:

```
Firepower-chassis /monitoring # enable snmp
```
- Step 3** Create an SNMP trap with the specified host name, IPv4 address, or IPv6 address.

```
Firepower-chassis /monitoring # create snmp-trap {hostname | ip-addr | ip6-addr}
```
- Step 4** Specify the SNMP community string, or version 3 user name, to be used with the SNMP trap:

```
Firepower-chassis /monitoring/snmp-trap # set community community-name
```

Specifies the SNMPv1/v2c community string, or the SNMPv3 user name, to permit access to the trap destination. You are queried for the community name after you enter this command. The name can be up to 32 characters with no spaces; the name is not displayed as you type.
- Step 5** Specify the port to be used for the SNMP trap:

Firepower-chassis /monitoring/snmp-trap # **set port** *port-num*

Step 6 Specify the SNMP version and model used for the trap:

Firepower-chassis /monitoring/snmp-trap # **set version** {**v1** | **v2c** | **v3**}

Note Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

Step 7 (Optional) Specify the type of trap to send.

Firepower-chassis /monitoring/snmp-trap # **set notificationtype** {**traps** | **informs**}

This can be:

- **traps** if you select v2c or v3 for the version.
- **informs** if you select v2c for the version.

Note An inform notification can be sent only if you select v2c for the version.

Step 8 (Optional) If you select v3 for the version, specify the privilege associated with the trap:

Firepower-chassis /monitoring/snmp-trap # **set v3privilege** {**auth** | **noauth** | **priv**}

This can be:

- **auth**—Authentication but no encryption.
- **noauth**—No authentication or encryption. Note that while you can specify it, FXOS does not support this security level with SNMPv3.
- **priv**—Authentication and encryption.

Step 9 Commit the transaction to the system configuration:

Firepower-chassis /monitoring/snmp-trap # **commit-buffer**

Example

The following example enables SNMP, creates an SNMP trap using an IPv4 address, specifies that the trap will use the SnmpCommSystem2 community on port 2, sets the version to v3, sets the notification type to traps, sets the v3 privilege to priv, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-trap 192.168.100.112
Firepower-chassis /monitoring/snmp-trap* # set community SnmpCommSystem2
Firepower-chassis /monitoring/snmp-trap* # set port 2
Firepower-chassis /monitoring/snmp-trap* # set version v3
Firepower-chassis /monitoring/snmp-trap* # set notificationtype traps
Firepower-chassis /monitoring/snmp-trap* # set v3privilege priv
Firepower-chassis /monitoring/snmp-trap* # commit-buffer
Firepower-chassis /monitoring/snmp-trap #
```

The following example enables SNMP, creates an SNMP trap using an IPv6 address, specifies that the trap will use the `SnmpCommSystem3` community on port 2, sets the version to v3, sets the notification type to traps, sets the v3 privilege to priv, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-trap 2001::1
Firepower-chassis /monitoring/snmp-trap* # set community SnmpCommSystem3
Firepower-chassis /monitoring/snmp-trap* # set port 2
Firepower-chassis /monitoring/snmp-trap* # set version v3
Firepower-chassis /monitoring/snmp-trap* # set notificationtype traps
Firepower-chassis /monitoring/snmp-trap* # set v3privilege priv
Firepower-chassis /monitoring/snmp-trap* # commit-buffer
Firepower-chassis /monitoring/snmp-trap #
```

Deleting an SNMP Trap

Procedure

-
- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```
- Step 2** Delete the SNMP trap with the specified hostname or IP address:
- ```
Firepower-chassis /monitoring # delete snmp-trap {hostname | ip-addr}
```
- Step 3** Commit the transaction to the system configuration:
- ```
Firepower-chassis /monitoring # commit-buffer
```
- 

### Example

The following example deletes the SNMP trap at IP address 192.168.100.112 and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # delete snmp-trap 192.168.100.112
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

## Creating an SNMPv3 User

### Procedure

- 
- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```

Step 2 Enable SNMP:

Firepower-chassis /monitoring # **enable snmp**

Step 3 Create an SNMPv3 user:

Firepower-chassis /monitoring # **create snmp-user** *user-name*

After you enter the **create snmp-user** command, you are prompted to enter a password.

The Firepower eXtensible Operating System rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters.
- Must contain only letters, numbers, and the following characters:
~`!@#%&*()_+{}[]\|.;'<,>./
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), or = (equals sign).
- Must contain at least five different characters.
- Must not contain too many consecutively incrementing or decrementing numbers or letters. For example, the string "12345" has four such characters, and the string "ZYXW" has three. If the total number of such characters exceeds a certain limit (typically more than around 4-6 such occurrences), the simplicity check will fail.

Note The consecutively incrementing or decrementing character count is not reset when non-incrementing or decrementing characters are used in between. For example, abcd&!21 will fail the password check, but abcd&!25, will not.

Step 4 Enable or disable the use of AES-128 encryption:

Firepower-chassis /monitoring/snmp-user # **set aes-128** {no | yes}

By default, AES-128 encryption is disabled.

Step 5 Specify the user privacy password:

Firepower-chassis /monitoring/snmp-user # **set priv-password**

After you enter the **set priv-password** command, you are prompted to enter and confirm the privacy password.

The Firepower eXtensible Operating System rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters.
- Must contain only letters, numbers, and the following characters:
~`!@#%&*()_+{}[]\|.;'<,>./
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), or = (equals sign).
- Must contain at least five different characters.
- Must not contain too many consecutively incrementing or decrementing numbers or letters. For example, the string "12345" has four such characters, and the string "ZYXW" has three. If the total number of such characters exceeds a certain limit (typically more than around 4-6 such occurrences), the simplicity check will fail.

Note The consecutively incrementing or decrementing character count is not reset when non-incrementing or decrementing characters are used in between. For example, abcd&!21 will fail the password check, but abcd&!25, will not.

Step 6 Commit the transaction to the system configuration:
Firepower-chassis /monitoring/snmp-user # **commit-buffer**

Example

The following example enables SNMP, creates an SNMPv3 user named snmp-user14, enables AES-128 encryption, sets the password and privacy password, and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # enable snmp
Firepower-chassis /monitoring* # create snmp-user snmp-user14
Password:
Firepower-chassis /monitoring/snmp-user* # set aes-128 yes
Firepower-chassis /monitoring/snmp-user* # set priv-password
Enter a password:
Confirm the password:
Firepower-chassis /monitoring/snmp-user* # commit-buffer
Firepower-chassis /monitoring/snmp-user #
```

Deleting an SNMPv3 User

Procedure

Step 1 Enter monitoring mode:
Firepower-chassis# **scope monitoring**

Step 2 Delete the specified SNMPv3 user:
Firepower-chassis /monitoring # **delete snmp-user** *user-name*

Step 3 Commit the transaction to the system configuration:
Firepower-chassis /monitoring # **commit-buffer**

Example

The following example deletes the SNMPv3 user named snmp-user14 and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # delete snmp-user snmp-user14
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

Viewing Current SNMP Settings

Use the following CLI commands to display current SNMP settings, users and traps.

Procedure

Step 1 Enter monitoring mode:

```
firepower# scope monitoring
```

Step 2 Display the current SNMP settings:

```
firepower/monitoring # show snmp
```

```
Name: snmp
  Admin State: Enabled
  Port: 161
  Is Community Set: Yes
  Sys Contact: R_Admin
  Sys Location:
```

Step 3 List the currently defined SNMPv3 users:

```
firepower/monitoring # show snmp-user
```

```
SNMPv3 User:
  Name                               Authentication type
  -----
  snmp-user1                         Sha
  testuser                           Sha
  snmp-user2                         Sha
```

Step 4 List the currently defined SNMP traps:

```
firepower/monitoring # show snmp-trap
```

```
SNMP Trap:
  SNMP Trap                        Port      Community  Version  V3 Privilege  Notification Type
  -----
  trap1_informs                   162      ****      V2c      Noauth      Informs
  192.168.10.100                  162      ****      V3       Noauth      Traps
```

Example

This example show how to display detailed information about a specific SNMPv3 user:

```
firepower /monitoring # show snmp-user snmp-user1 detail
```

```
SNMPv3 User:
  Name: snmp-user1
  Authentication type: Sha
  Password: ****
  Privacy password: ****
  Use AES-128: Yes
```

```
firepower /monitoring #
```

Configuring HTTPS

This section describes how to configure HTTPS on the Firepower 9300 chassis.

**Note**

You can change the HTTPS port using Firepower Chassis Manager or the FXOS CLI. All other HTTPS configuration can only be done using the FXOS CLI.

Certificates, Key Rings, and Trusted Points

HTTPS uses components of the Public Key Infrastructure (PKI) to establish secure communications between two devices, such as a client's browser and the Firepower 9300 chassis.

Encryption Keys and Key Rings

Each PKI device holds a pair of asymmetric Rivest-Shamir-Adleman (RSA) encryption keys, one kept private and one made public, stored in an internal key ring. A message encrypted with either key can be decrypted with the other key. To send an encrypted message, the sender encrypts the message with the receiver's public key, and the receiver decrypts the message using its own private key. A sender can also prove its ownership of a public key by encrypting (also called 'signing') a known message with its own private key. If a receiver can successfully decrypt the message using the public key in question, the sender's possession of the corresponding private key is proven. Encryption keys can vary in length, with typical lengths from 512 bits to 2048 bits. In general, a longer key is more secure than a shorter key. FXOS provides a default key ring with an initial 2048-bit key pair, and allows you to create additional key rings.

The default key ring certificate must be manually regenerated if the cluster name changes or the certificate expires.

Certificates

To prepare for secure communications, two devices first exchange their digital certificates. A certificate is a file containing a device's public key along with signed information about the device's identity. To merely support encrypted communications, a device can generate its own key pair and its own self-signed certificate. When a remote user connects to a device that presents a self-signed certificate, the user has no easy method to verify the identity of the device, and the user's browser will initially display an authentication warning. By default, FXOS contains a built-in self-signed certificate containing the public key from the default key ring.

Trusted Points

To provide stronger authentication for FXOS, you can obtain and install a third-party certificate from a trusted source, or trusted point, that affirms the identity of your device. The third-party certificate is signed by the issuing trusted point, which can be a root certificate authority (CA) or an intermediate CA or trust anchor that is part of a trust chain that leads to a root CA. To obtain a new certificate, you must generate a certificate request through FXOS and submit the request to a trusted point.

**Important**

The certificate must be in Base64 encoded X.509 (CER) format.

Creating a Key Ring

FXOS supports a maximum of 8 key rings, including the default key ring.

Procedure

-
- Step 1** Enter security mode:
Firepower-chassis # **scope security**
- Step 2** Create and name the key ring:
Firepower-chassis # **create keyring** *keyring-name*
- Step 3** Set the SSL key length in bits:
Firepower-chassis # **set modulus** {**mod1024** | **mod1536** | **mod2048** | **mod512**}
- Step 4** Commit the transaction:
Firepower-chassis # **commit-buffer**
-

Example

The following example creates a keyring with a key size of 1024 bits:

```
Firepower-chassis# scope security
Firepower-chassis /security # create keyring kr220
Firepower-chassis /security/keyring* # set modulus mod1024
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring #
```

What to do next

Create a certificate request for this key ring.

Regenerating the Default Key Ring

The default key ring certificate must be manually regenerated if the cluster name changes or the certificate expires.

Procedure

-
- Step 1** Enter security mode:

Firepower-chassis # **scope security**

Step 2 Enter key ring security mode for the default key ring:

Firepower-chassis /security # **scope keyring default**

Step 3 Regenerate the default key ring:

Firepower-chassis /security/keyring # **set regenerate yes**

Step 4 Commit the transaction:

Firepower-chassis # **commit-buffer**

Example

The following example regenerates the default key ring:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring default
Firepower-chassis /security/keyring* # set regenerate yes
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring #
```

Creating a Certificate Request for a Key Ring

Creating a Certificate Request for a Key Ring with Basic Options

Procedure

Step 1 Enter security mode:

Firepower-chassis # **scope security**

Step 2 Enter configuration mode for the key ring:

Firepower-chassis /security # **scope keyring** *keyring-name*

Step 3 Create a certificate request using the IPv4 or IPv6 address specified, or the name of the fabric interconnect. You are prompted to enter a password for the certificate request.

Firepower-chassis /security/keyring # **create certreq** {**ip** [*ipv4-addr* | *ipv6-v6*] |**subject-name** *name*}

Step 4 Commit the transaction:

Firepower-chassis /security/keyring/certreq # **commit-buffer**

Step 5 Display the certificate request, which you can copy and send to a trust anchor or certificate authority:

Firepower-chassis /security/keyring # **show certreq**

Example

The following example creates and displays a certificate request with an IPv4 address for a key ring, with basic options:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring kr220
Firepower-chassis /security/keyring # create certreq ip 192.168.200.123 subject-name sjc04
Certificate request password:
Confirm certificate request password:
Firepower-chassis /security/keyring* # commit-buffer
Firepower-chassis /security/keyring # show certreq
Certificate request subject name: sjc04
Certificate request ip address: 192.168.200.123
Certificate request e-mail name:
Certificate request country name:
State, province or county (full name):
Locality (eg, city):
Organization name (eg, company):
Organization Unit name (eg, section):
Request:
-----BEGIN CERTIFICATE REQUEST-----
MIIBfTCB5wIBADARMQ8wDQYDVQQDEwZzYW1jMDQwgZ8wDQYJKoZIhvcNAQEBBQAD
gY0AMIGJAoGBALpKnlt8qMZ04UGqILKFXQQc2c8b/vW2rnRF8OPhKbhghLA1YZ1F
JqcYEG5Yl1+vgohLBTd45s0GC8m4RTLJWHO4SwccAUXQ5Zngf45YtXlWsywUWV4
0re/zgTk/WCd56RfOBvWR2Dtztu2pGA14sd761zLxt29K7R8mzj6CAUVAgMBAAGg
LTArBgkqhkiG9w0BCQ4xHjAcMBoGA1UdEQEB/wQQMA6CBnNhbWMwNlECsEiXjAN
BgkqhkiG9w0BAQQFAAOBQQCsxN0qUHYGFOQw56RwQueLTNPnrndqUwuZHU003Teg
nhsyu4satpyiPqVV9viKZ+spvc6x5PWicTWgHhH8BimOb/0OKuG8kwfIGGsEDlAv
TTYvUP+BZ9OFiPbRIA7l8S+V8ndXr1HejiQGx1DNqon+odCXPC5kjoXD01ZTL09H
BA==
-----END CERTIFICATE REQUEST-----

Firepower-chassis /security/keyring #
```

What to do next

- Copy the text of the certificate request, including the BEGIN and END lines, and save it in a file. Send the file with the certificate request to a trust anchor or certificate authority to obtain a certificate for the key ring.
- Create a trusted point and set the certificate chain for the certificate of trust received from the trust anchor.

Creating a Certificate Request for a Key Ring with Advanced Options

Procedure

- | | |
|---------------|--|
| Step 1 | Enter security mode:

Firepower-chassis # scope security |
| Step 2 | Enter configuration mode for the key ring:

Firepower-chassis /security # scope keyring <i>keyring-name</i> |
| Step 3 | Create a certificate request: |

- Firepower-chassis /security/keyring # **create certreq**
- Step 4** Specify the country code of the country in which the company resides:
Firepower-chassis /security/keyring/certreq* # **set country** *country name*
- Step 5** Specify the Domain Name Server (DNS) address associated with the request:
Firepower-chassis /security/keyring/certreq* # **set dns** *DNS Name*
- Step 6** Specify the email address associated with the certificate request:
Firepower-chassis /security/keyring/certreq* # **set e-mail** *E-mail name*
- Step 7** Specify the IP address of the Firepower 9300 chassis:
Firepower-chassis /security/keyring/certreq* # **set ip** {*certificate request ip-address*|*certificate request ip6-address* }
- Step 8** Specify the city or town in which the company requesting the certificate is headquartered:
Firepower-chassis /security/keyring/certreq* # **set locality** *locality name (eg, city)*
- Step 9** Specify the organization requesting the certificate:
Firepower-chassis /security/keyring/certreq* # **set org-name** *organization name*
- Step 10** Specify the organizational unit:
Firepower-chassis /security/keyring/certreq* # **set org-unit-name** *organizational unit name*
- Step 11** Specify an optional password for the certificate request:
Firepower-chassis /security/keyring/certreq* # **set password** *certificate request password*
- Step 12** Specify the state or province in which the company requesting the certificate is headquartered:
Firepower-chassis /security/keyring/certreq* # **set state** *state, province or county*
- Step 13** Specify the fully qualified domain name of the Firepower 9300 chassis:
Firepower-chassis /security/keyring/certreq* # **set subject-name** *certificate request name*
- Step 14** Commit the transaction:
Firepower-chassis /security/keyring/certreq # **commit-buffer**
- Step 15** Display the certificate request, which you can copy and send to a trust anchor or certificate authority:
Firepower-chassis /security/keyring # **show certreq**
-

Example

The following example creates and displays a certificate request with an IPv4 address for a key ring, with advanced options:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope keyring kr220
Firepower-chassis /security/keyring # create certreq
```

```

Firepower-chassis /security/keyring/certreq* # set ip 192.168.200.123
Firepower-chassis /security/keyring/certreq* # set subject-name sjc04
Firepower-chassis /security/keyring/certreq* # set country US
Firepower-chassis /security/keyring/certreq* # set dns bg1-samc-15A
Firepower-chassis /security/keyring/certreq* # set email test@cisco.com
Firepower-chassis /security/keyring/certreq* # set locality new york city
Firepower-chassis /security/keyring/certreq* # set org-name "Cisco Systems"
Firepower-chassis /security/keyring/certreq* # set org-unit-name Testing
Firepower-chassis /security/keyring/certreq* # set state new york
Firepower-chassis /security/keyring/certreq* # commit-buffer
Firepower-chassis /security/keyring/certreq # show certreq
Certificate request subject name: sjc04
Certificate request ip address: 192.168.200.123
Certificate request e-mail name: test@cisco.com
Certificate request country name: US
State, province or county (full name): New York
Locality name (eg, city): new york city
Organization name (eg, company): Cisco
Organization Unit name (eg, section): Testing
Request:
-----BEGIN CERTIFICATE REQUEST-----
MIIBfTCB5wIBADARMQ8wDQYDVQQDEwZzYW1jMDQwZ8wDQYJKoZIhvcNAQEBBQAD
gY0AMIGJAoGBALpKnlt8qMZO4UGqILKFXQQc2c8b/vW2rnRF8OPhKbhghLA1YZ1F
JqrYEG5Yl1+vgohLBtd45s0GC8m4RTLJWHO4SwccAUXQ5Zngf45YtX1Wsy1wUWV4
Ore/zgTk/WCd56RfOBvWR2Dtztu2pGA14sd761zLxt29K7R8mzj6CAUVAgMBAAGg
LTArBgkqhkiG9w0BCQ4xHjAcMBoGA1UdEQEB/wQQMA6CBnNhbWMwNlCECsEiXjAN
BgkqhkiG9w0BAQQFAAOBgQCsxN0qUHYGFoQw56RwQueLTNPnrndqUwuZHU003Teg
nhsyu4satpyiPqVV9viKZ+spvc6x5PWicTWgHhH8BimOb/0OKuG8kwfIGGsEDlAv
TTYvUP+BZ9OFiPbRIA718S+V8ndXr1HejiQGx1DNQoN+odCXpc5kjoXD01ZTL09H
BA==
-----END CERTIFICATE REQUEST-----
Firepower-chassis /security/keyring/certreq #

```

What to do next

- Copy the text of the certificate request, including the BEGIN and END lines, and save it in a file. Send the file with the certificate request to a trust anchor or certificate authority to obtain a certificate for the key ring.
- Create a trusted point and set the certificate chain for the certificate of trust received from the trust anchor.

Creating a Trusted Point

Procedure

- | | |
|---------------|---|
| Step 1 | Enter security mode:
Firepower-chassis # scope security |
| Step 2 | Create a trusted point:
Firepower-chassis /security # create trustpoint <i>name</i> |
| Step 3 | Specify certificate information for this trusted point:
Firepower-chassis /security/trustpoint # set certchain [<i>certchain</i>] |

If you do not specify certificate information in the command, you are prompted to enter a certificate or a list of trustpoints defining a certification path to the root certificate authority (CA). On the next line following your input, type **ENDOFBUF** to finish.

Important The certificate must be in Base64 encoded X.509 (CER) format.

Step 4

Commit the transaction:

```
Firepower-chassis /security/trustpoint # commit-buffer
```

Example

The following example creates a trusted point and provides a certificate for the trusted point:

```
Firepower-chassis# scope security
Firepower-chassis /security # create trustpoint tPoint10
Firepower-chassis /security/trustpoint* # set certchain
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Trustpoint Certificate Chain:
> -----BEGIN CERTIFICATE-----
> MIIDMDCCApmgAwIBAgIBADANBgkqhkiG9w0BAQQFADBOMQswCQYDVQQGEwJVUzEL
> BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBAST
> ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
> 9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
> AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCcYU
> ZgAMivYCsKgb/6CjQtsofvtrmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
> GMBkPayVlQjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bF5wZVNAGMBAAGgJTAjBgkq
> hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
> gYEAG61CaJoJaVMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckCld3mkOVx5gJU
> Ptt5CVQpNgNldvbdPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtlv1WvfhevskV0j6
> jtcEMyZ+f7+3yh421ido3n04MIGeBgNVHSMGgZYwgZOAFLlNjtcEMyZ+f7+3yh42
> 1ido3n04oXikdjB0MQswCQYDVQQGEwJVUzELMAkGA1UECBMCQ0ExFDASBgNVBAcT
> ClNhbnRhIENsYXJhMRswGQYDVQQKEwJodW92YSBTeXN0ZW1zIEluYy4xFDASBgNV
> BAsTC0Vuz2luZWVyaW5nMQ8wDQYDVQQDEwZ0ZXN0Q0GCAQAwDAYDVR0TBAAUwAwEB
> /zANBgkqhkiG9w0BAQQFAAOBgQAhWaRwXNR6B4g6Lsnr+fptHv+WWvB5fKqGQqXc
> wRpYiO4z42/j9Ijenh75tCKMhW51az8copP1EBmOcyuhf5C6vasrenn1ddkYt4
> PR0vxGc40whuiozBolesmsmjBbedUCwQgdFDWhDIzJwK5+N3x/kfa2EHU6id1avt
> 4YL5Jg==
> -----END CERTIFICATE-----
> ENDOFBUF
Firepower-chassis /security/trustpoint* # commit-buffer
Firepower-chassis /security/trustpoint #
```

What to do next

Obtain a key ring certificate from the trust anchor or certificate authority and import it into the key ring.

Importing a Certificate into a Key Ring

Before you begin

- Configure a trusted point that contains the certificate chain for the key ring certificate.
- Obtain a key ring certificate from a trust anchor or certificate authority.

Enter security mode:

Firepower-chassis # **scope security**

Enter configuration mode for the key ring that will receive the certificate:

Firepower-chassis /security # **scope keyring** *keyring-name*

Specify the trusted point for the trust anchor or certificate authority from which the key ring certificate was obtained:

Firepower-chassis /security/keyring # **set trustpoint** *name*

Launch a dialog for entering and uploading the key ring certificate:

Firepower-chassis /security/keyring # **set cert**

At the prompt, paste the certificate text that you received from the trust anchor or certificate authority. On the next line following the certificate, type **ENDOFBUF** to complete the certificate input.

Important The certificate must be in Base64 encoded X.509 (CER) format.

Commit the transaction:

Firepower-chassis /security/keyring # **commit-buffer**

The following example specifies the trust point and imports a certificate into a key ring:

Cisco Firepower 9300 FXOS CLI Configuration Guide, 1.1(1)

What to do next

Configure your HTTPS service with the key ring.

Configuring HTTPS

**Caution**

After you complete the HTTPS configuration, including changing the port and key ring to be used by HTTPS, all current HTTP and HTTPS sessions are closed without warning as soon as you save or commit the transaction.

Procedure

-
- Step 1** Enter system mode:
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:
Firepower-chassis /system # **scope services**
- Step 3** Enable the HTTPS service:
Firepower-chassis /system/services # **enable https**
- Step 4** (Optional) Specify the port to be used for the HTTPS connection:
Firepower-chassis /system/services # **set https port** *port-num*
- Step 5** (Optional) Specify the name of the key ring you created for HTTPS:
Firepower-chassis /system/services # **set https keyring** *keyring-name*
- Step 6** (Optional) Specify the level of Cipher Suite security used by the domain:
Firepower-chassis /system/services # **set https cipher-suite-mode** *cipher-suite-mode*
cipher-suite-mode can be one of the following keywords:
- **high-strength**
 - **medium-strength**
 - **low-strength**
 - **custom**—Allows you to specify a user-defined Cipher Suite specification string.
- Step 7** (Optional) If **cipher-suite-mode** is set to **custom**, specify a custom level of Cipher Suite security for the domain:
Firepower-chassis /system/services # **set https cipher-suite** *cipher-suite-spec-string*
cipher-suite-spec-string can contain up to 256 characters and must conform to the OpenSSL Cipher Suite specifications. You cannot use any spaces or special characters except ! (exclamation point), + (plus sign), - (hyphen), and : (colon). For details, see http://httpd.apache.org/docs/2.0/mod/mod_ssl.html#sslcipher-suite.

For example, the medium strength specification string FXOS uses as the default is:

ALL: !ADH: !EXPORT56: !LOW: RC4+RSA: +HIGH: +MEDIUM: +EXP: +eNULL

Note This option is ignored if **cipher-suite-mode** is set to anything other than **custom**.

- Step 8** Commit the transaction to the system configuration:
Firepower-chassis /system/services # **commit-buffer**

Example

The following example enables HTTPS, sets the port number to 443, sets the key ring name to kring7984, sets the Cipher Suite security level to high, and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # enable https
Firepower-chassis /system/services* # set https port 443
Warning: When committed, this closes all the web sessions.
Firepower-chassis /system/services* # set https keyring kring7984
Firepower-chassis /system/services* # set https cipher-suite-mode high
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

Changing the HTTPS Port

The HTTPS service is enabled on port 443 by default. You cannot disable HTTPS, but you can change the port to use for HTTPS connections.

Procedure

- Step 1** Enter system mode:
Firepower-chassis # **scope system**
- Step 2** Enter system services mode:
Firepower-chassis /system # **scope services**
- Step 3** Specify the port to use for HTTPS connections:
Firepower-chassis /system/services # **set https port port-number**
Specify an integer between 1 and 65535 for *port-number*. HTTPS is enabled on port 443 by default.
- Step 4** Commit the transaction to the system configuration:
Firepower /system/services # **commit-buffer**
After changing the HTTPS port, all current HTTPS sessions are closed. Users will need to log back in to the Firepower Chassis Manager using the new port as follows:
https://<chassis_mgmt_ip_address>:<chassis_mgmt_port>

where `<chassis_mgmt_ip_address>` is the IP address or host name of the Firepower chassis that you entered during initial configuration and `<chassis_mgmt_port>` is the HTTPS port you have just configured.

Example

The following example sets the HTTPS port number to 443 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # set https port 444
Warning: When committed, this closes all the web sessions.
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

Deleting a Key Ring

Procedure

-
- | | |
|---------------|--|
| Step 1 | Enter security mode:
Firepower-chassis # scope security |
| Step 2 | Delete the named key ring:
Firepower-chassis /security # delete keyring name |
| Step 3 | Commits the transaction:
Firepower-chassis /security # commit-buffer |
-

Example

The following example deletes a key ring:

```
Firepower-chassis# scope security
Firepower-chassis /security # delete keyring key10
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Deleting a Trusted Point

Before you begin

Ensure that the trusted point is not used by a key ring.

Procedure

- Step 1** Enters security mode:
Firepower-chassis# **scope security**
- Step 2** Delete the named trusted point:
Firepower-chassis /security # **delete trustpoint name**
- Step 3** Commits the transaction:
Firepower-chassis /security # **commit-buffer**
-

Example

The following example deletes a trusted point:

```
Firepower-chassis# scope security
Firepower-chassis /security # delete trustpoint tPoint10
Firepower-chassis /security* # commit-buffer
Firepower-chassis /security #
```

Disabling HTTPS

Procedure

- Step 1** Enter system mode:
Firepower-chassis# **scope system**
- Step 2** Enter system services mode:
Firepower-chassis /system # **scope services**
- Step 3** Disable the HTTPS service:
Firepower-chassis /system/services # **disable https**
- Step 4** Commit the transaction to the system configuration:
Firepower-chassis /system/services # **commit-buffer**
-

Example

The following example disables HTTPS and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # disable https
```

```
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

Configuring AAA

This section describes authentication, authorization, and accounting. See the following topics for more information:

About AAA

Authentication, Authorization and Accounting (AAA) is a set of services for controlling access to network resources, enforcing policies, assessing usage, and providing the information necessary to bill for services. Authentication identifies the user. Authorization implements policies that determine which resources and services an authenticated user may access. Accounting keeps track of time and data resources that are used for billing and analysis. These processes are considered important for effective network management and security.

Authentication

Authentication provides a way to identify each user, typically by having the user enter a valid user name and valid password before access is granted. The AAA server compares the user's provided credentials with user credentials stored in a database. If the credentials are matched, the user is permitted access to the network. If the credentials do not match, authentication fails and network access is denied.

You can configure the Firepower 9300 chassis to authenticate administrative connections to the chassis, including the following sessions:

- HTTPS
- SSH
- Serial console

Authorization

Authorization is the process of enforcing policies: determining what types of activities, resources, or services each user is permitted to access. After authentication, a user may be authorized for different types of access or activity.

Accounting

Accounting measures the resources a user consumes during access, which may include the amount of system time or the amount of data that a user has sent or received during a session. Accounting is carried out through the logging of session statistics and usage information, which is used for authorization control, billing, trend analysis, resource utilization, and capacity planning activities.

Interaction Between Authentication, Authorization, and Accounting

You can use authentication alone, or with authorization and accounting. Authorization always requires a user to be authenticated first. You can use accounting alone, or with authentication and authorization.

Supported Types of Authentication

FXOS supports the following types of user Authentication:

- **Remote** – The following network AAA services are supported:
 - LDAP
 - RADIUS
 - TACACS+
- **Local** – The Firepower chassis maintains a local database that you can populate with user profiles. You can use this local database instead of AAA servers to provide user authentication, authorization, and accounting.

User Roles

FXOS supports local and remote Authorization in the form of user-role assignment. The roles that can be assigned are:

- **Admin** – Complete read-and-write access to the entire system. The default admin account is assigned this role by default and it cannot be changed.
- **AAA Administrator** – Read-and-write access to users, roles, and AAA configuration. Read access to the rest of the system.
- **Operations** – Read-and-write access to NTP configuration, Smart Call Home configuration for Smart Licensing, and system logs, including syslog servers and faults. Read access to the rest of the system.
- **Read-Only** – Read-only access to system configuration with no privileges to modify the system state.

See [User Management, on page 25](#) for more information about local users and role assignments.

Setting Up AAA

These steps provide a basic outline for setting up Authentication, Authorization and Accounting (AAA) on a Firepower 4100/9300 appliance.

1. Configure the desired type(s) of user authentication:

- **Local** – User definitions and local authentication are part of [User Management, on page 25](#).
- **Remote** – Configuring remote AAA server access is part of Platform Settings, specifically:
 - [Configuring LDAP Providers, on page 86](#)
 - [Configuring RADIUS Providers, on page 90](#)
 - [Configuring TACACS+ Providers, on page 93](#)



Note

If you will be using remote AAA servers, be sure to enable and configure AAA services on the remote servers before configuring remote AAA server access on the Firepower chassis.

- Specify the default authentication method—this also is part of [User Management, on page 25](#).

**Note**

If Default Authentication and Console Authentication are both set to use the same remote authentication protocol (RADIUS, TACACS+, or LDAP), you cannot change certain aspects of that server's configuration (for example, deleting that server, or changing its order of assignment) without updating these user settings.

Configuring LDAP Providers

Configuring Properties for LDAP Providers

The properties that you configure in this task are the default settings for all provider connections of this type. If an individual provider includes a setting for any of these properties, the Firepower eXtensible Operating System uses that setting and ignores the default setting.

If you are using Active Directory as your LDAP server, create a user account in the Active Directory server to bind with the Firepower eXtensible Operating System. This account should be given a non-expiring password.

Procedure

-
- Step 1** Enter security mode:
Firepower-chassis# **scope security**
 - Step 2** Enter security LDAP mode:
Firepower-chassis /security # **scope ldap**
 - Step 3** Restrict database searches to records that contain the specified attribute:
Firepower-chassis /security/ldap # **set attribute** *attribute*
 - Step 4** Restrict database searches to records that contain the specified distinguished name:
Firepower-chassis /security/ldap # **set basedn** *distinguished-name*
 - Step 5** Restrict database searches to records that contain the specified filter:
Firepower-chassis /security/ldap # **set filter** *filter*
where *filter* is the filter attribute to use with your LDAP server, for example *cn=\$userid* or *sAMAccountName=\$userid*. The filter must include *\$userid*.
 - Step 6** Set the amount of time the system will wait for a response from the LDAP server before noting the server as down:
Firepower-chassis /security/ldap # **set timeout** *seconds*
 - Step 7** Commit the transaction to the system configuration:
Firepower-chassis /security/ldap # **commit-buffer**
-

Example

The following example sets the LDAP attribute to CiscoAvPair, the base distinguished name to "DC=cisco-firepower-aaa3,DC=qalab,DC=com", the filter to sAMAccountName=\$userid, and the timeout interval to 5 seconds, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap # set attribute CiscoAvPair
Firepower-chassis /security/ldap* # set basedn "DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap* # set filter sAMAccountName=$userid
Firepower-chassis /security/ldap* # set timeout 5
Firepower-chassis /security/ldap* # commit-buffer
Firepower-chassis /security/ldap #
```



Note User login will fail if the DN for an LDAP user exceeds 255 characters.

What to do next

Create an LDAP provider.

Creating an LDAP Provider

Follow these steps to define and configure a LDAP provider—that is, a specific remote server providing LDAP-based AAA services for this Firepower appliance.



Note The Firepower eXtensible Operating System supports a maximum of 16 LDAP providers.

Before you begin

If you are using Active Directory as your LDAP server, create a user account in the Active Directory server to bind with the Firepower eXtensible Operating System. This account should be given a non-expiring password.

Procedure

- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security LDAP mode:
- ```
Firepower-chassis /security # scope ldap
```
- Step 3** Create an LDAP server instance and enter security LDAP server mode:
- ```
Firepower-chassis /security/ldap # create server server-name
```

If SSL is enabled, the *server-name*, typically an IP address or FQDN, must exactly match a Common Name (CN) in the LDAP server's security certificate. Unless an IP address is specified, a DNS server must be configured.

**Step 4** (Optional) Set an LDAP attribute that stores the values for the user roles and locales:

```
Firepower-chassis /security/ldap/server # set attribute attr-name
```

This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.

This value is required unless a default attribute has been set for LDAP providers.

**Step 5** (Optional) Set the specific distinguished name in the LDAP hierarchy where the server should begin a search when a remote user logs in and the system attempts to get the user's DN based on their user name:

```
Firepower-chassis /security/ldap/server # set basedn basedn-name
```

The length of the base DN can be a maximum of 255 characters minus the length of CN=username, where username identifies the remote user attempting to access Firepower Chassis Manager or the FXOS CLI using LDAP authentication.

This value is required unless a default base DN has been set for LDAP providers.

**Step 6** (Optional) Set the distinguished name (DN) for an LDAP database account that has read and search permissions for all objects under the base DN:

```
Firepower-chassis /security/ldap/server # set binddn binddn-name
```

The maximum supported string length is 255 ASCII characters.

**Step 7** (Optional) Restrict the LDAP search to user names that match the defined filter.

```
Firepower-chassis /security/ldap/server # set filter filter-value
```

where *filter-value* is the filter attribute to use with your LDAP server; for example *cn=\$userid* or *sAMAccountName=\$userid*. The filter must include *\$userid*.

This value is required unless a default filter has been set for LDAP providers.

**Step 8** Specify the password for the LDAP database account specified for Bind DN:

```
Firepower-chassis /security/ldap/server # set password
```

To set the password, press **Enter** after typing the **set password** command and enter the key value at the prompt.

You can enter any standard ASCII characters except for space, \$ (section sign), ? (question mark), or = (equal sign).

**Step 9** (Optional) Specify the order in which the Firepower eXtensible Operating System uses this provider to authenticate users:

```
Firepower-chassis /security/ldap/server # set order order-num
```

**Step 10** (Optional) Specify the port used to communicate with the LDAP server. The standard port number is 389.

```
Firepower-chassis /security/ldap/server # set port port-num
```

**Step 11** Enable or disable the use of encryption when communicating with the LDAP server:

```
Firepower-chassis /security/ldap/server # set ssl {yes | no}
```

The options are as follows:

- **yes** —Encryption is required. If encryption cannot be negotiated, the connection fails.
- **no** —Encryption is disabled. Authentication information is sent as clear text.

LDAP uses STARTTLS. This allows encrypted communication using port 389.

**Step 12** Specify the length of time in seconds the system will spend trying to contact the LDAP database before it times out:

Firepower-chassis /security/ldap/server # **set timeout** *timeout-num*

Enter an integer from 1 to 60 seconds, or enter 0 (zero) to use the global timeout value specified for LDAP providers. The default is 30 seconds.

**Step 13** Specify the vendor that is providing the LDAP provider or server details:

Firepower-chassis /security/ldap/server # **set vendor** {*ms-ad* | *openldap*}

The options are as follows:

- **ms-ad**—LDAP provider is Microsoft Active Directory.
- **openldap**—LDAP provider is not Microsoft Active Directory.

**Step 14** Commit the transaction to the system configuration:

Firepower-chassis /security/ldap/server # **commit-buffer**

### Example

The following example creates an LDAP server instance named 10.193.169.246, configures the binddn, password, order, port, SSL settings, vendor attribute, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap* # create server 10.193.169.246
Firepower-chassis /security/ldap/server* # set binddn
"cn=Administrator,cn=Users,DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap/server* # set password
Enter the password:
Confirm the password:
Firepower-chassis /security/ldap/server* # set order 2
Firepower-chassis /security/ldap/server* # set port 389
Firepower-chassis /security/ldap/server* # set ssl yes
Firepower-chassis /security/ldap/server* # set timeout 30
Firepower-chassis /security/ldap/server* # set vendor ms-ad
Firepower-chassis /security/ldap/server* # commit-buffer
Firepower-chassis /security/ldap/server #
```

The following example creates an LDAP server instance named 12:31:71:1231:45b1:0011:011:900, configures the binddn, password, order, port, SSL settings, vendor attribute, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
```

```

Firepower-chassis /security/ldap* # create server 12:31:71:1231:45b1:0011:011:900
Firepower-chassis /security/ldap/server* # set binddn
"cn=Administrator,cn=Users,DC=cisco-firepower-aaa3,DC=qalab,DC=com"
Firepower-chassis /security/ldap/server* # set password
Enter the password:
Confirm the password:
Firepower-chassis /security/ldap/server* # set order 1
Firepower-chassis /security/ldap/server* # set port 389
Firepower-chassis /security/ldap/server* # set ssl yes
Firepower-chassis /security/ldap/server* # set timeout 45
Firepower-chassis /security/ldap/server* # set vendor ms-ad
Firepower-chassis /security/ldap/server* # commit-buffer
Firepower-chassis /security/ldap/server #

```

## Deleting an LDAP Provider

### Procedure

- 
- |               |                                                                                                                |
|---------------|----------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Enter security mode:<br>Firepower-chassis# <b>scope security</b>                                               |
| <b>Step 2</b> | Enter security LDAP mode:<br>Firepower-chassis /security # <b>scope ldap</b>                                   |
| <b>Step 3</b> | Delete the specified server:<br>Firepower-chassis /security/ldap # <b>delete server</b> <i>serv-name</i>       |
| <b>Step 4</b> | Commit the transaction to the system configuration:<br>Firepower-chassis /security/ldap # <b>commit-buffer</b> |
- 

### Example

The following example deletes the LDAP server called ldap1 and commits the transaction:

```

Firepower-chassis# scope security
Firepower-chassis /security # scope ldap
Firepower-chassis /security/ldap # delete server ldap1
Firepower-chassis /security/ldap* # commit-buffer
Firepower-chassis /security/ldap #

```

## Configuring RADIUS Providers

### Configuring Properties for RADIUS Providers

The properties that you configure in this task are the default settings for all provider connections of this type. If an individual provider includes a setting for any of these properties, the Firepower eXtensible Operating System uses that setting and ignores this default setting.

### Procedure

- 
- Step 1** Enter security mode:  
Firepower-chassis# **scope security**
- Step 2** Enter security RADIUS mode:  
Firepower-chassis /security # **scope radius**
- Step 3** (Optional) Specify the number of times to retry contacting the RADIUS server before noting the server as down:  
Firepower-chassis /security/radius # **set retries** *retry-num*
- Step 4** (Optional) Set the amount of time the system will wait for a response from the RADIUS server before noting the server as down:  
Firepower-chassis /security/radius # **set timeout** *seconds*
- Step 5** Commit the transaction to the system configuration:  
Firepower-chassis /security/radius # **commit-buffer**
- 

### Example

The following example sets the RADIUS retries to 4, sets the timeout interval to 30 seconds, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # set retries 4
Firepower-chassis /security/radius* # set timeout 30
Firepower-chassis /security/radius* # commit-buffer
Firepower-chassis /security/radius #
```

### What to do next

Create a RADIUS provider.

## Creating a RADIUS Provider

Follow these steps to define and configure a RADIUS provider—that is, a specific remote server providing RADIUS-based AAA services for this Firepower appliance.




---

**Note** The Firepower eXtensible Operating System supports a maximum of 16 RADIUS providers.

---

### Procedure

- 
- Step 1** Enter security mode:

- Firepower-chassis# **scope security**
- Step 2** Enter security RADIUS mode:  
Firepower-chassis /security # **scope radius**
- Step 3** Create a RADIUS server instance and enter security RADIUS server mode:  
Firepower-chassis /security/radius # **create server** *server-name*
- Step 4** (Optional) Specify the port used to communicate with the RADIUS server.  
Firepower-chassis /security/radius/server # **set authport** *authport-num*
- Step 5** Set the RADIUS server key:  
Firepower-chassis /security/radius/server # **set key**  
To set the key value, press **Enter** after typing the **set key** command and enter the key value at the prompt.  
You can enter any standard ASCII characters except for space, \$ (section sign), ? (question mark), or = (equal sign).
- Step 6** (Optional) Specify when in the order this server will be tried:  
Firepower-chassis /security/radius/server # **set order** *order-num*
- Step 7** (Optional) Set the number of times to retry communicating with the RADIUS server before noting the server as down:  
Firepower-chassis /security/radius/server # **set retries** *retry-num*
- Step 8** Specify the length of time in seconds the system will wait for a response from the RADIUS server before noting the server as down:  
Firepower-chassis /security/radius/server # **set timeout** *seconds*
- Tip** It is recommended that you configure a higher **Timeout** value if you select two-factor authentication for RADIUS providers.
- Step 9** Commit the transaction to the system configuration:  
Firepower-chassis /security/radius/server # **commit-buffer**
- 

### Example

The following example creates a server instance named `radiusserv7`, sets the authentication port to 5858, sets the key to `radiuskey321`, sets the order to 2, sets the retries to 4, sets the timeout to 30, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # create server radiusserv7
Firepower-chassis /security/radius/server* # set authport 5858
Firepower-chassis /security/radius/server* # set key
Enter the key: radiuskey321
Confirm the key: radiuskey321
Firepower-chassis /security/radius/server* # set order 2
```

```
Firepower-chassis /security/radius/server* # set retries 4
Firepower-chassis /security/radius/server* # set timeout 30
Firepower-chassis /security/radius/server* # commit-buffer
Firepower-chassis /security/radius/server #
```

## Deleting a RADIUS Provider

### Procedure

- 
- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security RADIUS mode:
- ```
Firepower-chassis /security # scope RADIUS
```
- Step 3** Delete the specified server:
- ```
Firepower-chassis /security/radius # delete server serv-name
```
- Step 4** Commit the transaction to the system configuration:
- ```
Firepower-chassis /security/radius # commit-buffer
```
- 

### Example

The following example deletes the RADIUS server called radius1 and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope radius
Firepower-chassis /security/radius # delete server radius1
Firepower-chassis /security/radius* # commit-buffer
Firepower-chassis /security/radius #
```

## Configuring TACACS+ Providers

### Configuring Properties for TACACS+ Providers

The properties that you configure in this task are default settings for all provider connections of this type. If an individual provider configuration includes a setting for any of these properties, the Firepower eXtensible Operating System uses that setting and ignores this default setting.

### Procedure

- 
- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security TACACS+ mode:
- ```
Firepower-chassis /security # scope tacacs
```

- Step 3** (Optional) Set the amount of time the system will wait for a response from the TACACS+ server before noting the server as down:

```
Firepower-chassis /security/tacacs # set timeout seconds
```

Enter an integer from 1 to 60 seconds. The default value is 5 seconds.

- Step 4** Commit the transaction to the system configuration:

```
Firepower-chassis /security/tacacs # commit-buffer
```

---

### Example

The following example sets the TACACS+ timeout interval to 45 seconds and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # set timeout 45
Firepower-chassis /security/tacacs* # commit-buffer
Firepower-chassis /security/tacacs #
```

### What to do next

Create a TACACS+ provider.

## Creating a TACACS+ Provider

Follow these steps to define and configure a TACACS+ provider—that is, a specific remote server providing TACACS-based AAA services for this Firepower appliance.




---

**Note** The Firepower eXtensible Operating System supports a maximum of 16 TACACS+ providers.

---

### Procedure

---

- Step 1** Enter security mode:
- ```
Firepower-chassis# scope security
```
- Step 2** Enter security TACACS+ mode:
- ```
Firepower-chassis /security # scope tacacs
```
- Step 3** Create a TACACS+ server instance and enter security TACACS+ server mode:
- ```
Firepower-chassis /security/tacacs # create server server-name
```
- Step 4** Specify the TACACS+ server key:
- ```
Firepower-chassis /security/tacacs/server # set key
```
- To set the key value, press **Enter** after typing the **set key** command and enter the key value at the prompt.

You can enter any standard ASCII characters except for space, \$ (section sign), ? (question mark), or = (equal sign).

**Step 5** (Optional) Specify when in the order this server will be tried:

Firepower-chassis /security/tacacs/server # **set order** *order-num*

**Step 6** Specify the time interval that the system will wait for a response from the TACACS+ server before noting the server as down:

Firepower-chassis /security/tacacs/server # **set timeout** *seconds*

**Tip** It is recommended that you configure a higher timeout value if you select two-factor authentication for TACACS+ providers.

**Step 7** (Optional) Specify the port used to communicate with the TACACS+ server:

Firepower-chassis /security/tacacs/server # **set port** *port-num*

**Step 8** Commit the transaction to the system configuration:

Firepower-chassis /security/tacacs/server # **commit-buffer**

### Example

The following example creates a server instance named tacacsserv680, sets the key to tacacskey321, sets the order to 4, sets the authentication port to 5859, and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # create server tacacsserv680
Firepower-chassis /security/tacacs/server* # set key
Enter the key: tacacskey321
Confirm the key: tacacskey321
Firepower-chassis /security/tacacs/server* # set order 4
Firepower-chassis /security/tacacs/server* # set port 5859
Firepower-chassis /security/tacacs/server* # commit-buffer
Firepower-chassis /security/tacacs/server #
```

## Deleting a TACACS+ Provider

### Procedure

**Step 1** Enter security mode:

Firepower-chassis# **scope security**

**Step 2** Enter security TACACS+ mode:

Firepower-chassis /security # **scope tacacs**

**Step 3** Delete the specified server:

Firepower-chassis /security/tacacs # **delete server** *serv-name*

Firepower-chassis /security/tacacs # **commit-buffer**

The following example deletes the TACACS+ server called tacacs1 and commits the transaction:

```
Firepower-chassis# scope security
Firepower-chassis /security # scope tacacs
Firepower-chassis /security/tacacs # delete server tacacs1
Firepower-chassis /security/tacacs* # commit-buffer
Firepower-chassis /security/tacacs #
```

The following sections describe how to use the FXOS CLI to determine the current configuration for the various remote AAA servers.

The following example shows you how to use the **show authentication** command to determine the current FXOS authentication settings. In this example, LDAP is the default mode of authentication.

```
firepower# scope security
firepower /security # show authentication
Console authentication: Local
Operational Console authentication: Local
Default authentication: Ldap
Operational Default authentication: Ldap
Role Policy For Remote Users: Assign Default Role
firepower /security #
```

The following example shows you how to use the **show server detail** command in ldap mode to determine the current LDAP configuration settings.

```
firepower# scope security
firepower /security # scope ldap
firepower /security/ldap # show server detail

LDAP server:
 Hostname, FQDN or IP address: 10.48.53.132
 Descr:
 Order: 1
 DN to search and read: CN=cisco,CN=Users,DC=fxosldapuser,DC=lab
 Password:
 Port: 389
 SSL: No
 Key:
 Cipher Suite Mode: Medium Strength
 Cipher Suite:
ALL:DH-RS-AES-256-GCM-SHA:EDH-RS-AES-256-GCM-SHA:EDH-RS-AES-256-GCM-SHA:DES-CBC-SHA:ADH:DES:EXPORT:EXPORT56:LOW:RC4:M5:IDEA:HIGH:MEDIUM:EXP:NULL
```

```
CRL: Relaxed
Basedn: CN=Users,DC=fxosldapuser,DC=lab
User profile attribute: CiscoAVPair
Filter: cn=$userid
Timeout: 30
Ldap Vendor: MS AD
firepower /security/ldap #
```

### Determining Current RADIUS Configuration

The following example shows you how to use the **show server detail** command in radius mode to determine the current RADIUS configuration settings.

```
firepower# scope security
firepower /security # scope radius
firepower /security/radius # show server detail

RADIUS server:
 Hostname, FQDN or IP address: 10.48.17.199
 Descr:
 Order: 1
 Auth Port: 1812
 Key: ****
 Timeout: 5
 Retries: 1
firepower /security/radius #
```

### Determining Current TACACS+ Configuration

The following example shows you how to use the **show server detail** command in tacacs mode to determine the current TACACS+ configuration settings.

```
firepower# scope security
firepower /security # scope tacacs
firepower /security/tacacs # show server detail

TACACS+ server:
 Hostname, FQDN or IP address: 10.48.17.199
 Descr:
 Order: 1
 Port: 49
 Key: ****
 Timeout: 5
firepower /security/tacacs #
```

## Configuring Syslog

System logging is a method of collecting messages from devices to a server running a syslog daemon. Logging to a central syslog server helps in aggregation of logs and alerts. A syslog service accepts messages and stores them in files, or prints them according to a simple configuration file. This form of logging provides protected long-term storage for logs. Logs are useful both in routine troubleshooting and in incident handling.

## Procedure

---

- Step 1** Enter monitoring mode:
- ```
Firepower-chassis# scope monitoring
```
- Step 2** Enable or disable the sending of syslogs to the console:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog console
```
- Step 3** (Optional) Select the lowest message level that you want displayed. If syslogs are enabled, the system displays that level and above on the console. The level options are listed in order of decreasing urgency. The default level is Critical.
- ```
Firepower-chassis /monitoring # set syslog console level {emergencies | alerts | critical}
```
- Step 4** Enable or disable the monitoring of syslog information by the operating system:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog monitor
```
- Step 5** (Optional) Select the lowest message level that you want displayed. If the monitor state is enabled, the system displays that level and above. The level options are listed in order of decreasing urgency. The default level is Critical.
- ```
Firepower-chassis /monitoring # set syslog monitor level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```
- Note** Messages at levels below Critical are displayed on the terminal monitor only if you have entered the **terminal monitor** command.
- Step 6** Enable or disable the writing of syslog information to a syslog file:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog file
```
- Step 7** Specify the name of the file in which the messages are logged. Up to 16 characters are allowed in the file name.
- ```
Firepower-chassis /monitoring # set syslog file name filename
```
- Step 8** (Optional) Select the lowest message level that you want stored to a file. If the file state is enabled, the system stores that level and above in the syslog file. The level options are listed in order of decreasing urgency. The default level is Critical.
- ```
Firepower-chassis /monitoring # set syslog file level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```
- Step 9** (Optional) Specify the maximum file size, in bytes, before the system begins to write over the oldest messages with the newest ones. The range is 4096 to 4194304 bytes.
- ```
Firepower-chassis /monitoring # set syslog file size filesize
```
- Step 10** Configure sending of syslog messages to up to three external syslog servers:
- a) Enable or disable the sending of syslog messages to up to three external syslog servers:
- ```
Firepower-chassis /monitoring # {enable | disable} syslog remote-destination {server-1 | server-2 | server-3}
```

- b) (Optional) Select the lowest message level that you want stored to the external log. If the remote-destination is enabled, the system sends that level and above to the external server. The level options are listed in order of decreasing urgency. The default level is Critical.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3}
level {emergencies | alerts | critical | errors | warnings | notifications | information | debugging}
```

- c) Specify the hostname or IP address of the specified remote syslog server. Up to 256 characters are allowed in the hostname.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3} hostname
hostname
```

- d) (Optional) Specify the facility level contained in the syslog messages sent to the specified remote syslog server.

```
Firepower-chassis /monitoring # set syslog remote-destination {server-1 | server-2 | server-3} facility
{local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7}
```

### Step 11

Configure the local sources. Enter the following command for each of the local sources you want to enable or disable:

```
Firepower-chassis /monitoring # {enable | disable} syslog source {audits | events | faults}
```

This can be one of the following:

- **audits**—Enables or disables the logging of all audit log events.
- **events**—Enables or disables the logging of all system events.
- **faults**—Enables or disables the logging of all system faults.

### Step 12

Commit the transaction:

```
Firepower-chassis /monitoring # commit-buffer
```

### Example

This example shows how to enable the storage of syslog messages in a local file and commits the transaction:

```
Firepower-chassis# scope monitoring
Firepower-chassis /monitoring # disable syslog console
Firepower-chassis /monitoring* # disable syslog monitor
Firepower-chassis /monitoring* # enable syslog file
Firepower-chassis /monitoring* # set syslog file name SysMsgsFirepower
Firepower-chassis /monitoring* # set syslog file level notifications
Firepower-chassis /monitoring* # set syslog file size 4194304
Firepower-chassis /monitoring* # disable syslog remote-destination server-1
Firepower-chassis /monitoring* # disable syslog remote-destination server-2
Firepower-chassis /monitoring* # disable syslog remote-destination server-3
Firepower-chassis /monitoring* # commit-buffer
Firepower-chassis /monitoring #
```

# Configuring DNS Servers

You need to specify a DNS server if the system requires resolution of host names to IP addresses. For example, you cannot use a name such as `www.cisco.com` when you are configuring a setting on the Firepower chassis if you do not configure a DNS server. You would need to use the IP address of the server, which can be either an IPv4 or an IPv6 address. You can configure up to four DNS servers.



## Note

When you configure multiple DNS servers, the system searches for the servers only in any random order. If a local management command requires DNS server lookup, it can only search for three DNS servers in random order.

## Procedure

- 
- Step 1** Enter system mode:  
Firepower-chassis # **scope system**
- Step 2** Enter system services mode:  
Firepower-chassis /system # **scope services**
- Step 3** To create or delete a DNS server, enter the appropriate command as follows:
- To configure the system to use a DNS server with the specified IPv4 or IPv6 address:  
Firepower-chassis /system/services # **create dns {ip-addr | ip6-addr}**
  - To delete a DNS server with the specified IPv4 or IPv6 address:  
Firepower-chassis /system/services # **delete dns {ip-addr | ip6-addr}**
- Step 4** Commit the transaction to the system configuration:  
Firepower /system/services # **commit-buffer**
- 

## Example

The following example configures a DNS server with the IPv4 address 192.168.200.105 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create dns 192.168.200.105
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example configures a DNS server with the IPv6 address 2001:db8::22:F376:FF3B:AB3F and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # create dns 2001:db8::22:F376:FF3B:AB3F
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```

The following example deletes the DNS server with the IP address 192.168.200.105 and commits the transaction:

```
Firepower-chassis# scope system
Firepower-chassis /system # scope services
Firepower-chassis /system/services # delete dns 192.168.200.105
Firepower-chassis /system/services* # commit-buffer
Firepower-chassis /system/services #
```





## CHAPTER 8

# Interface Management

- [About Firepower Interfaces, on page 103](#)
- [Guidelines and Limitations for Firepower Interfaces, on page 104](#)
- [Configure Interfaces, on page 105](#)
- [Monitoring Interfaces, on page 111](#)

## About Firepower Interfaces

The Firepower 9300 chassis supports physical interfaces and EtherChannel (port-channel) interfaces. EtherChannel interfaces can include up to 16 member interfaces of the same type.

## Chassis Management Interface

The chassis management interface is used for management of the FXOS Chassis by SSH or Firepower Chassis Manager. This interface is separate from the mgmt-type interface that you assign to the logical devices for application management.

To configure parameters for this interface, you must configure them from the CLI. See also [Changing the Management IP Address, on page 53](#). To view information about this interface in the FXOS CLI, connect to local management and show the management port:

```
Firepower # connect local-mgmt
```

```
Firepower(local-mgmt) # show mgmt-port
```

Note that the chassis management interface remains up even if the physical cable or SFP module are unplugged, or if the **mgmt-port shut** command is performed.

## Interface Types

Each interface can be one of the following types:

- **Data**—Use for regular data. Data interfaces cannot be shared between logical devices, and logical devices cannot communicate over the backplane to other logical devices. For traffic on Data interfaces, all traffic must exit the chassis on one interface and return on another interface to reach another logical device.
- **Mgmt**—Use to manage application instances. These interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical

devices that share the interface. You can only assign one management interface per logical device. For ASA: You can later enable management from a data interface; but you must assign a Management interface to the logical device even if you don't intend to use it after you enable data management.

- Cluster—Use as the cluster control link for a clustered logical device. By default, the cluster control link is automatically created on Port-channel 48. The Cluster type is only supported on EtherChannel interfaces.

## FXOS Interfaces vs. Application Interfaces

The Firepower 9300 manages the basic Ethernet settings of physical interfaces and EtherChannel (port-channel) interfaces. Within the application, you configure higher level settings. For example, you can only create EtherChannels in FXOS; but you can assign an IP address to the EtherChannel within the application.

The following sections describe the interaction between FXOS and the application for interfaces.

### VLAN Subinterfaces

For all logical devices, you can create VLAN subinterfaces within the application.

### Independent Interface States in the Chassis and in the Application

You can administratively enable and disable interfaces in both the chassis and in the application. For an interface to be operational, the interface must be enabled in both operating systems. Because the interface state is controlled independently, you may have a mismatch between the chassis and application.

## Jumbo Frame Support

The Firepower 9300 chassis has support for jumbo frames enabled by default. To enable jumbo frame support on a specific logical device installed on the Firepower 9300 chassis, you will need to configure the appropriate MTU settings for the interfaces on the logical device.

The maximum MTU that is supported for the application on the Firepower 9300 chassis is 9000.

## Guidelines and Limitations for Firepower Interfaces

### Default MAC Addresses

Default MAC address assignments depend on the type of interface.

- Physical interfaces—The physical interface uses the burned-in MAC address.
- EtherChannels—For an EtherChannel, all interfaces that are part of the channel group share the same MAC address. This feature makes the EtherChannel transparent to network applications and users, because they only see the one logical connection; they have no knowledge of the individual links. The port-channel interface uses a unique MAC address from a pool; interface membership does not affect the MAC address.

# Configure Interfaces

By default, physical interfaces are disabled. You can enable interfaces, add EtherChannels, edit interface properties, and configure breakout ports.

**Note**

If you remove an interface in FXOS (for example, if you remove a network module, remove an EtherChannel, or reassign an interface to an EtherChannel), then the ASA configuration retains the original commands so that you can make any necessary adjustments; removing an interface from the configuration can have wide effects. You can manually remove the old interface configuration in the ASA OS.

## Configure a Physical Interface

You can physically enable and disable interfaces, as well as set the interface speed and duplex. To use an interface, it must be physically enabled in FXOS and logically enabled in the application.

**Before you begin**

- Interfaces that are already a member of an EtherChannel cannot be modified individually. Be sure to configure settings before you add it to the EtherChannel.

**Procedure**

**Step 1** Enter interface mode.

```
scope eth-uplink
```

```
scope fabric a
```

**Step 2** Enable the interface.

```
enter interface interface_id
```

```
enable
```

**Example:**

```
Firepower /eth-uplink/fabric # enter interface Ethernet1/8
Firepower /eth-uplink/fabric/interface # enable
```

**Note** Interfaces that are already a member of a port-channel cannot be modified individually. If you use the **enter interface** or **scope interface** command on an interface that is a member of a port channel, you will receive an error stating that the object does not exist. You should edit interfaces using the **enter interface** command before you add them to a port-channel.

**Step 3** (Optional) Set the interface type.

```
set port-type {data | mgmt | cluster}
```

**Example:**

```
Firepower /eth-uplink/fabric/interface # set port-type mgmt
```

The **data** keyword is the default type. Do not choose the **cluster** keyword; by default, the cluster control link is automatically created on Port-channel 48.

- Step 4** Enable or disable autonegotiation, if supported for your interface.

**set auto-negotiation {on | off}**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set auto-negotiation off
```

- Step 5** Set the interface speed.

**set admin-speed {10mbps | 100mbps | 1gbps | 10gbps | 40gbps | 100gbps}**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set admin-speed 1gbps
```

- Step 6** Set the interface duplex mode.

**set admin-duplex {fullduplex | halfduplex}**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set admin-duplex halfduplex
```

- Step 7** If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, apply it to the interface. See [Configure a Flow Control Policy, on page 109](#).

**set flow-control-policy name**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set flow-control-policy flow1
```

- Step 8** Save the configuration.

**commit-buffer**

**Example:**

```
Firepower /eth-uplink/fabric/interface* # commit-buffer
Firepower /eth-uplink/fabric/interface #
```

---

## Add an EtherChannel (Port Channel)

An EtherChannel (also known as a port channel) can include up to 16 member interfaces of the same media type and capacity, and must be set to the same speed and duplex. The media type can be either RJ-45 or SFP; SFPs of different types (copper and fiber) can be mixed. You cannot mix interface capacities (for example 1GB and 10GB interfaces) by setting the speed to be lower on the larger-capacity interface. The Link Aggregation Control Protocol (LACP) aggregates interfaces by exchanging the Link Aggregation Control Protocol Data Units (LACPDUs) between two network devices.

The Firepower 9300 chassis only supports EtherChannels in Active LACP mode so that each member interface sends and receives LACP updates. An active EtherChannel can establish connectivity with either an active or a passive EtherChannel. You should use the active mode unless you need to minimize the amount of LACP traffic.

LACP coordinates the automatic addition and deletion of links to the EtherChannel without user intervention. It also handles misconfigurations and checks that both ends of member interfaces are connected to the correct channel group.

### Procedure

**Step 1** Enter interface mode:

**scope eth-uplink**

**scope fabric a**

**Step 2** Create the port-channel:

**create port-channel *id***

**enable**

**Step 3** Assign member interfaces:

**create member-port *interface\_id***

#### Example:

```
Firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
Firepower /eth-uplink/fabric/port-channel/member-port* # exit
Firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
Firepower /eth-uplink/fabric/port-channel/member-port* # exit
Firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
Firepower /eth-uplink/fabric/port-channel/member-port* # exit
Firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
Firepower /eth-uplink/fabric/port-channel/member-port* # exit
```

**Step 4** (Optional) Set the interface type.

**set port-type {data | mgmt | cluster}**

#### Example:

```
Firepower /eth-uplink/fabric/port-channel # set port-type data
```

The **data** keyword is the default type. Do not choose the **cluster** keyword unless you want to use this port-channel as the cluster control link instead of the default.

**Step 5** (Optional) Set the interface speed for all members of the port-channel.

**set speed** {10mbps | 100mbps | 1gbps | 10gbps | 40gbps | 100gbps}

**Example:**

```
Firepower /eth-uplink/fabric/port-channel* # set speed 1gbps
```

**Step 6** (Optional) Set the duplex for all members of the port-channel.

**set duplex** {fullduplex | halfduplex}

**Example:**

```
Firepower /eth-uplink/fabric/port-channel* # set duplex fullduplex
```

**Step 7** Enable or disable autonegotiation, if supported for your interface.

**set auto-negotiation** {on | off}

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set auto-negotiation off
```

**Step 8** If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, apply it to the interface. See [Configure a Flow Control Policy, on page 109](#).

**set flow-control-policy** name

**Example:**

```
Firepower /eth-uplink/fabric/interface* # set flow-control-policy flow1
```

**Step 9** Commit the configuration:

**commit-buffer**

## Configure Breakout Cables

The following procedure shows how to configure breakout cables for use with the Firepower 9300 chassis. You can use a breakout cable to provide four 10 Gbps ports in place of a single 40 Gbps port.

### Procedure

**Step 1** To create a new breakout, use the following commands:

a) Enter cabling mode:

**scope cabling**

**scope fabric a**

- b) Create the breakout:

**create breakout** *network\_module\_slot port*

**Example:**

```
Firepower /cabling/fabric/ # create breakout 2 1
```

- c) Commit the configuration:

**commit-buffer**

This will cause an automatic reboot. If you are configuring more than one breakout, you should create all of them before you issue the commit-buffer command.

**Step 2** To enable/configure the breakout ports, use the following commands:

- a) Enter interface mode:

**scope eth-uplink**

**scope fabric a**

**scope aggr-interface** *network\_module\_slot port*

**Note** Interfaces that are already a member of a port-channel cannot be modified individually. If you use the **enter interface** or **scope interface** command on an interface that is a member of a port channel, you will receive an error stating that the object does not exist. You should edit interfaces using the **enter interface** command before you add them to a port-channel.

- b) Use the **set** command to configure the interface speed and port type.

Use the **enable** or **disable** command to set the administrative state of the interface.

- c) Commit the configuration:

**commit-buffer**

---

## Configure a Flow Control Policy

Flow control policies determine whether the Ethernet ports send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears. For flow control to work between devices, you must enable the corresponding receive and send flow control parameters for both devices.

The default policy disables send and receive control, and sets the priority to autonegotiate.

### Procedure

---

**Step 1** Enter eth-uplink and then flow-control mode.

**scope eth-uplink**

**scope flow-control****Example:**

```
firepower-4110# scope eth-uplink
firepower-4110 /eth-uplink # scope flow-control
firepower-4110 /eth-uplink/flow-control #
```

**Step 2** Edit or create a flow control policy.

**enter policy name**

If you want to edit the default policy, enter **default** for the name.

**Example:**

```
firepower-4110 /eth-uplink/flow-control # enter policy default
firepower-4110 /eth-uplink/flow-control/policy* #
```

**Step 3** Set the priority.

**set prio {auto | on}**

The priority sets whether to negotiate or enable PPP for this link.

**Example:**

```
firepower-4110 /eth-uplink/flow-control/policy* # set prio on
```

**Step 4** Enable or disable flow control receive pauses.

**set receive {on | off}**

- **on**—Pause requests are honored and all traffic is halted on that uplink port until the network cancels the pause request.
- **off**—Pause requests from the network are ignored and traffic flow continues as normal.

**Example:**

```
firepower-4110 /eth-uplink/flow-control/policy* # set receive on
```

**Step 5** Enable or disable flow control send pauses.

**set send {on | off}**

- **on**—The Firepower 9300 sends a pause request to the network if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels.
- **off**—Traffic on the port flows normally regardless of the packet load.

**Example:**

```
firepower-4110 /eth-uplink/flow-control/policy* # set send on
```

**Step 6** Save the configuration.

**commit-buffer****Example:**

```
firepower-4110 /eth-uplink/flow-control/policy* # commit-buffer
firepower-4110 /eth-uplink/flow-control/policy #
```

**Example**

The following example configures a flow control policy.

```
firepower-4110# scope eth-uplink
firepower-4110 /eth-uplink # scope flow-control
firepower-4110 /eth-uplink/flow-control # enter policy FlowControlPolicy23
firepower-4110 /eth-uplink/flow-control/policy* # set prio auto
firepower-4110 /eth-uplink/flow-control/policy* # set receive on
firepower-4110 /eth-uplink/flow-control/policy* # set send on
firepower-4110 /eth-uplink/flow-control/policy* # commit-buffer
firepower-4110 /eth-uplink/flow-control/policy #
```

## Monitoring Interfaces

- **show interface**

Shows interface status.



**Note** Interfaces that act as ports in port channels do not appear in this list.

```
Firepower# scope eth-uplink
Firepower /eth-uplink # scope fabric a
Firepower /eth-uplink/fabric # show interface
```

Interface:

| Port Name   | Port Type | Admin State | Oper State      | State Reason                  |
|-------------|-----------|-------------|-----------------|-------------------------------|
| Ethernet1/1 | Mgmt      | Enabled     | Up              |                               |
| Ethernet1/2 | Data      | Enabled     | Link Down       | Link failure or not-connected |
| Ethernet1/3 | Data      | Enabled     | Up              |                               |
| Ethernet1/4 | Data      | Enabled     | Sfp Not Present | Unknown                       |
| Ethernet1/6 | Data      | Enabled     | Sfp Not Present | Unknown                       |
| Ethernet1/7 | Data      | Enabled     | Sfp Not Present | Unknown                       |
| Ethernet1/8 | Data      | Disabled    | Sfp Not Present | Unknown                       |
| Ethernet2/1 | Data      | Enabled     | Up              |                               |
| Ethernet2/2 | Data      | Enabled     | Up              |                               |
| Ethernet2/4 | Data      | Enabled     | Up              |                               |
| Ethernet2/5 | Data      | Enabled     | Up              |                               |
| Ethernet2/6 | Data      | Enabled     | Up              |                               |
| Ethernet3/2 | Data      | Enabled     | Up              |                               |

```

Ethernet3/4 Data Enabled Up

```

### • show port-channel

Shows port-channel status.

```

Firepower# scope eth-uplink
Firepower /eth-uplink # scope fabric a
Firepower /eth-uplink/fabric # show port-channel

```

```

Port Channel:
 Port Channel Id Name Port Type Admin State Oper State
Port Channel Mode State Reason

1 Port-channel1 Data Enabled Up
Active
2 Port-channel2 Data Enabled Failed
Active
48 Port-channel48 Cluster Enabled Up
Active

```



## CHAPTER 9

# Logical Devices

---

- [About Logical Devices, on page 113](#)
- [Requirements and Prerequisites for Logical Devices, on page 113](#)
- [Guidelines and Limitations for Logical Devices, on page 115](#)
- [Add a Standalone Logical Device, on page 116](#)
- [Add a High Availability Pair, on page 121](#)
- [Add a Cluster, on page 121](#)
- [Manage Logical Devices, on page 129](#)
- [Monitoring Logical Devices, on page 135](#)
- [History for Logical Devices, on page 136](#)

## About Logical Devices

A logical device lets you run one application instance .

When you add a logical device, you also define the application instance type and version, assign interfaces, and configure bootstrap settings that are pushed to the application configuration.

## Standalone and Clustered Logical Devices

You can add the following logical device types:

- **Standalone**—A standalone logical device operates as a standalone unit or as a unit in a High Availability pair.
- **Cluster**—A clustered logical device lets you group multiple units together, providing all the convenience of a single device (management, integration into a network) while achieving the increased throughput and redundancy of multiple devices. Multiple module devices, like the Firepower 9300, support intra-chassis clustering. For the Firepower 9300, all three modules must participate in the cluster.

## Requirements and Prerequisites for Logical Devices

See the following sections for requirements and prerequisites.

## Requirements and Prerequisites for Hardware and Software Combinations

The Firepower 9300 supports multiple models, security modules, application types, and high availability and scalability features. See the following requirements for allowed combinations.

### Firepower 9300 Requirements

The Firepower 9300 includes 3 security module slots and multiple types of security modules. See the following requirements:

- Security Module Types—All modules in the Firepower 9300 must be the same type.
- Clustering—All security modules in the cluster, whether it is intra-chassis or inter-chassis, must be the same type. You can have different quantities of installed security modules in each chassis, although all modules present in the chassis must belong to the cluster including any empty slots. For example, you can install 2 SM-36s in chassis 1, and 3 SM-36s in chassis 2.
- High Availability—High Availability is only supported between same-type modules on the Firepower 9300.
- ASA and FTD application types—You can only install one application type on the chassis, ASA or FTD.
- ASA or FTD versions—You can run different versions of an application instance type on separate modules. For example, you can install FTD 6.3 on module 1, FTD 6.4 on module 2, and FTD 6.5 on module 3.

## Requirements and Prerequisites for Clustering

### Switch Requirements for Inter-Chassis Clustering

- Be sure to complete the switch configuration and successfully connect all the EtherChannels from the chassis to the switch(es) before you configure clustering on the Firepower 9300 chassis.
- For supported switch characteristics, see [Cisco FXOS Compatibility](#).

## Requirements and Prerequisites for High Availability

- The two units in a High Availability Failover configuration must:
  - Be on a separate chassis; intra-chassis High Availability for the Firepower 9300 is not supported.
  - Be the same model.
  - Have the same interfaces assigned to the High Availability logical devices.
  - Have the same number and types of interfaces. All interfaces must be preconfigured in FXOS identically before you enable High Availability.
- For High Availability system requirements, see the application configuration guide chapter for High Availability.

# Guidelines and Limitations for Logical Devices

See the following sections for guidelines and limitations.

## General Guidelines and Limitations

### Firewall Mode

You can set the firewall mode to routed or transparent in the bootstrap configuration for the FTD. For the ASA, you can change the firewall mode to transparent after you deploy. See [Change the ASA to Transparent Firewall Mode, on page 132](#).

### High Availability

- Configure high availability within the application configuration.
- You can use any data interfaces as the failover and state links.

### Context Mode

- Multiple context mode is only supported on the ASA.
- Enable multiple context mode in the ASA after you deploy.

## Clustering Guidelines and Limitations

- When adding a unit to an existing cluster, or when reloading a unit, there will be a temporary, limited packet/connection drop; this is expected behavior. In some cases, the dropped packets can hang connections; for example, dropping a FIN/ACK packet for an FTP connection will make the FTP client hang. In this case, you need to reestablish the FTP connection.
- If you use a Windows 2003 server connected to a Spanned EtherChannel interface, when the syslog server port is down, and the server does not throttle ICMP error messages, then large numbers of ICMP messages are sent back to the cluster. These messages can result in some units of the cluster experiencing high CPU, which can affect performance. We recommend that you throttle ICMP error messages.
- We recommend connecting EtherChannels to a VSS or vPC for redundancy.
- Within a chassis, you cannot cluster some security modules and run other security modules in standalone mode; you must include all security modules in the cluster.

### Defaults

- The cluster health check feature is enabled by default with the holdtime of 3 seconds. Interface health monitoring is enabled on all interfaces by default.

# Add a Standalone Logical Device

Standalone logical devices can be used alone or as high availability units. For more information about high availability usage, see [Add a High Availability Pair, on page 121](#).

## Add a Standalone ASA

Standalone logical devices work either alone or in a High Availability pair. On the Firepower 9300 with multiple security modules, you can deploy either a cluster or standalone devices. The cluster must use all modules, so you cannot mix and match a 2-module cluster plus a single standalone device, for example.

You can deploy a routed firewall mode ASA from the Firepower 9300 chassis. To change the ASA to transparent firewall mode, complete this procedure, and then see [Change the ASA to Transparent Firewall Mode, on page 132](#).

For multiple context mode, you must first deploy the logical device, and then enable multiple context mode in the ASA application.

### Before you begin

- Download the application image you want to use for the logical device from Cisco.com, and then download that image to the Firepower 9300 chassis.
- Configure a management interface to use with the logical device. The management interface is required. Note that this management interface is not the same as the chassis management port that is used only for chassis management (in FXOS, you might see it displayed as MGMT, management0, or other similar names).
- Gather the following information:
  - Interface IDs for this device
  - Management interface IP address and network mask
  - Gateway IP address

### Procedure

---

**Step 1** Enter security services mode.

**scope ssa**

**Example:**

```
Firepower# scope ssa
Firepower /ssa #
```

**Step 2** Set the application instance image version.

a) View available images. Note the Version number that you want to use.

**show app**

**Example:**

```
Firepower /ssa # show app
 Name Version Author Supported Deploy Types CSP Type Is Default
App

asa 9.9.1 cisco Native
asa 9.10.1 cisco Native
ftd 6.2.3 cisco Native
Application No
Application Yes
Application Yes
```

- b) Set the scope to the security module/engine slot.

**scope slot** *slot\_id*

The *slot\_id* is 1, 2, or 3 for the Firepower 9300.

**Example:**

```
Firepower /ssa # scope slot 1
Firepower /ssa/slot #
```

- c) Create the application instance.

**enter app-instance** *asa*

**Example:**

```
Firepower /ssa/slot # enter app-instance asa
Firepower /ssa/slot/app-instance* #
```

- d) Set the ASA image version.

**set startup-version** *version*

**Example:**

```
Firepower /ssa/slot/app-instance* # set startup-version 9.10.1
```

- e) Exit to slot mode.

**exit**

**Example:**

```
Firepower /ssa/slot/app-instance* # exit
Firepower /ssa/slot* #
```

- f) Exit to ssa mode.

**exit**

**Example:**

```
Firepower /ssa/slot* # exit
Firepower /ssa* #
```

**Example:**

```
Firepower /ssa # scope slot 1
Firepower /ssa/slot # enter app-instance asa
Firepower /ssa/slot/app-instance* # set startup-version 9.10.1
Firepower /ssa/slot/app-instance* # exit
Firepower /ssa/slot* # exit
Firepower /ssa* #
```

**Step 3** Create the logical device.

**enter logical-device** *device\_name* **asa** *slot\_id* **standalone**

**Example:**

```
Firepower /ssa # enter logical-device ASA1 asa 1 standalone
Firepower /ssa/logical-device* #
```

**Step 4** Assign the management and data interfaces to the logical device. Repeat for each interface.

**create external-port-link** *name* *interface\_id* **asa**

**set description** *description*

**exit**

- *name*—The name is used by the Firepower 9300 chassis supervisor; it is not the interface name used in the ASA configuration.
- *description*—Use quotes (") around phrases with spaces.

The management interface is not the same as the chassis management port. You will later enable and configure the data interfaces on the ASA, including setting the IP addresses.

**Example:**

```
Firepower /ssa/logical-device* # create external-port-link inside Ethernet1/1 asa
Firepower /ssa/logical-device/external-port-link* # set description "inside link"
Firepower /ssa/logical-device/external-port-link* # exit
Firepower /ssa/logical-device* # create external-port-link management Ethernet1/7 asa
Firepower /ssa/logical-device/external-port-link* # set description "management link"
Firepower /ssa/logical-device/external-port-link* # exit
Firepower /ssa/logical-device* # create external-port-link outside Ethernet1/2 asa
Firepower /ssa/logical-device/external-port-link* # set description "external link"
Firepower /ssa/logical-device/external-port-link* # exit
```

**Step 5** Configure the management bootstrap information.

a) Create the bootstrap object.

**create mgmt-bootstrap** **asa**

**Example:**

```
Firepower /ssa/logical-device* # create mgmt-bootstrap asa
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- b) Specify the admin password.

**create bootstrap-key-secret PASSWORD**

**set value**

Enter a value: *password*

Confirm the value: *password*

**exit**

**Example:**

The pre-configured ASA admin user is useful for password recovery; if you have FXOS access, you can reset the admin user password if you forget it.

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key-secret PASSWORD
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # set value
Enter a value: floppylampshade
Confirm the value: floppylampshade
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- c) Configure the IPv4 management interface settings.

**create ipv4 slot\_id default**

**set ip ip\_address mask network\_mask**

**set gateway gateway\_address**

**exit**

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # create ipv4 1 default
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # set ip 10.10.10.34 mask 255.255.255.0
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # set gateway 10.10.10.1
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- d) Configure the IPv6 management interface settings.

**create ipv6 slot\_id default**

**set ip ip\_address prefix-length prefix**

**set gateway gateway\_address**

**exit**

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # create ipv6 1 default
Firepower /ssa/logical-device/mgmt-bootstrap/ipv6* # set ip 2001:0DB8:BA98::3210
prefix-length 64
Firepower /ssa/logical-device/mgmt-bootstrap/ipv6* # set gateway 2001:0DB8:BA98::3211
Firepower /ssa/logical-device/mgmt-bootstrap/ipv6* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- e) Exit the management bootstrap mode.

**exit**

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # exit
Firepower /ssa/logical-device* #
```

## Step 6 Save the configuration.

**commit-buffer**

The chassis deploys the logical device by downloading the specified software version and pushing the bootstrap configuration and management interface settings to the application instance. Check the status of the deployment using the **show app-instance** command. The application instance is running and ready to use when the **Admin State is Enabled** and the **Oper State is Online**.

**Example:**

```
Firepower /ssa/logical-device* # commit-buffer
Firepower /ssa/logical-device # exit
Firepower /ssa # show app-instance
```

| App Name    | Identifier    | Slot ID | Admin State    | Oper State    | Running Version | Startup Version |
|-------------|---------------|---------|----------------|---------------|-----------------|-----------------|
| Deploy Type | Profile Name  | Cluster | State          | Cluster Role  |                 |                 |
| asa         | asa1          | 2       | Disabled       | Not Installed |                 | 9.12.1          |
| Native      |               |         | Not Applicable | None          |                 |                 |
| ftd         | ftd1          | 1       | Enabled        | Online        | 6.4.0.49        | 6.4.0.49        |
| Container   | Default-Small |         | Not Applicable | None          |                 |                 |

## Step 7 See the ASA configuration guide to start configuring your security policy.

**Example**

```
Firepower# scope ssa
Firepower /ssa # scope slot 1
Firepower /ssa/slot # enter app-instance asa
Firepower /ssa/slot/app-instance* # set startup-version 9.10.1
Firepower /ssa/slot/app-instance* # exit
Firepower /ssa/slot* # exit
Firepower /ssa* # create logical-device MyDevice1 asa 1 standalone
Firepower /ssa/logical-device* # create external-port-link inside Ethernet1/1 asa
Firepower /ssa/logical-device/external-port-link* # set description "inside link"
Firepower /ssa/logical-device/external-port-link* # exit
Firepower /ssa/logical-device* # create external-port-link management Ethernet1/7 asa
Firepower /ssa/logical-device/external-port-link* # set description "management link"
Firepower /ssa/logical-device/external-port-link* # exit
Firepower /ssa/logical-device* # create external-port-link outside Ethernet1/2 asa
Firepower /ssa/logical-device/external-port-link* # set description "external link"
Firepower /ssa/logical-device/external-port-link* # exit
Firepower /ssa/logical-device* # create mgmt-bootstrap asa
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key-secret PASSWORD
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # set value
Enter a value: secretglassine
```

```

Confirm the value: secretglassine
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* # create ipv4 1 default
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # set gateway 10.0.0.1
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # set ip 10.0.0.31 mask 255.255.255.0
Firepower /ssa/logical-device/mgmt-bootstrap/ipv4* # exit
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # commit-buffer
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key #

```

## Add a High Availability Pair

ASA High Availability (also known as failover) is configured within the application, not in FXOS. However, to prepare your chassis for high availability, see the following steps.

### Before you begin

See [Requirements and Prerequisites for High Availability, on page 114](#).

### Procedure

- 
- Step 1** Allocate the same interfaces to each logical device.
- Step 2** Allocate 1 or 2 data interfaces for the failover and state link(s).
- These interfaces exchange high availability traffic between the 2 chassis. We recommend that you use a 10 GB data interface for a combined failover and state link. If you have available interfaces, you can use separate failover and state links; the state link requires the most bandwidth. You cannot use the management-type interface for the failover or state link. We recommend that you use a switch between the chassis, with no other device on the same network segment as the failover interfaces.
- Step 3** Enable High Availability on the logical devices.
- Step 4** If you need to make interface changes after you enable High Availability, perform the changes on the standby unit first, and then perform the changes on the active unit.
- Note** For the ASA, if you remove an interface in FXOS (for example, if you remove a network module, remove an EtherChannel, or reassign an interface to an EtherChannel), then the ASA configuration retains the original commands so that you can make any necessary adjustments; removing an interface from the configuration can have wide effects. You can manually remove the old interface configuration in the ASA OS.
- 

## Add a Cluster

Clustering lets you group multiple devices together as a single logical device. A cluster provides all the convenience of a single device (management, integration into a network) while achieving the increased throughput and redundancy of multiple devices. The Firepower 9300, which includes multiple modules, supports intra-chassis clustering where you group all modules within a single chassis into a cluster.




---

**Note** The Firepower 9300 does not support a cluster across multiple chassis (inter-chassis); only intra-chassis clustering is supported.

---

## About Clustering on the Firepower 9300 Chassis

The cluster consists of multiple devices acting as a single logical unit. When you deploy a cluster on the Firepower 9300 chassis, it does the following:

- Creates a *cluster-control link* (by default, port-channel 48) for unit-to-unit communication.  
For intra-chassis clustering, this link utilizes the Firepower 9300 backplane for cluster communications.
- Creates the cluster bootstrap configuration within the application.

When you deploy the cluster, the chassis supervisor pushes a minimal bootstrap configuration to each unit that includes the cluster name, cluster control link interface, and other cluster settings.

- Assigns data interfaces to the cluster as *Spanned* interfaces.

For intra-chassis clustering, spanned interfaces are not limited to EtherChannels. The Firepower 9300 supervisor uses EtherChannel technology internally to load-balance traffic to multiple modules on a shared interface, so any data interface type works for Spanned mode.




---

**Note** Individual interfaces are not supported, with the exception of a management interface.

---

- Assigns a management interface to all units in the cluster.

The following sections provide more detail about clustering concepts and implementation.

### Primary and Secondary Unit Roles

One member of the cluster is the primary unit. The primary unit is determined automatically. All other members are secondary units.

You must perform all configuration on the primary unit only; the configuration is then replicated to the secondary units.

### Cluster Control Link

The cluster control link is automatically created using the Port-channel 48 interface.

For intra-chassis clustering, this interface has no member interfaces. This Cluster type EtherChannel utilizes the Firepower 9300 backplane for cluster communications for intra-chassis clustering.

Cluster control link traffic includes both control and data traffic.

### Management Interface

You must assign a Management type interface to the cluster. This interface is a special *individual* interface as opposed to a Spanned interface. The management interface lets you connect directly to each unit.

For the ASA, the Main cluster IP address is a fixed address for the cluster that always belongs to the current primary unit. You must configure a range of addresses so that each unit, including the current primary unit, can use a Local address from the range. The Main cluster IP address provides consistent management access to an address; when a primary unit changes, the Main cluster IP address moves to the new primary unit, so management of the cluster continues seamlessly. The Local IP address is used for routing, and is also useful for troubleshooting. For example, you can manage the cluster by connecting to the Main cluster IP address, which is always attached to the current primary unit. To manage an individual member, you can connect to the Local IP address. For outbound management traffic such as TFTP or syslog, each unit, including the primary unit, uses the Local IP address to connect to the server.

## Add an ASA Cluster

You can add a single Firepower 9300 chassis as an intra-chassis cluster.

### Create an ASA Cluster

Set the scope to the image version.

You can easily deploy the cluster from the Firepower 9300 chassis supervisor. All initial configuration is automatically generated for each unit.

In a Firepower 9300 chassis, you must enable clustering for all 3 module slots, even if you do not have a module installed. If you do not configure all 3 modules, the cluster will not come up.

For multiple context mode, you must first deploy the logical device, and then enable multiple context mode in the ASA application.

To change the ASA to transparent firewall mode, complete the initial deployment, and then change the firewall mode within the ASA CLI.

#### Before you begin

- Download the application image you want to use for the logical device from Cisco.com, and then upload that image to the Firepower 9300 chassis.
- Gather the following information:
  - Management interface ID, IP address, and network mask
  - Gateway IP address

#### Procedure

- |               |                               |
|---------------|-------------------------------|
| <b>Step 1</b> | Configure interfaces.         |
| <b>Step 2</b> | Enter security services mode. |

**scope ssa**

**Example:**

```
Firepower# scope ssa
Firepower /ssa #
```

**Step 3** Set the application instance image version.

- a) View available images. Note the Version number that you want to use.

**show app****Example:**

```
Firepower /ssa # show app
 Name Version Author Supported Deploy Types CSP Type Is Default
 App

 asa 9.9.1 cisco Native Application No
 asa 9.10.1 cisco Native Application Yes
 ftd 6.2.3 cisco Native Application Yes
```

- b) Set the scope to the image version.

**scope app asa application\_version****Example:**

```
Firepower /ssa # scope app asa 9.10.1
Firepower /ssa/app #
```

- c) Set this version as the default.

**set-default****Example:**

```
Firepower /ssa/app # set-default
Firepower /ssa/app* #
```

- d) Exit to ssa mode.

**exit****Example:**

```
Firepower /ssa/app* # exit
Firepower /ssa* #
```

**Example:**

```
Firepower /ssa # scope app asa 9.12.1
Firepower /ssa/app # set-default
Firepower /ssa/app* # exit
Firepower /ssa* #
```

**Step 4** Create the cluster.**enter logical-device device\_name asa slots clustered**

- *device\_name*—Used by the Firepower 9300 chassis supervisor to configure clustering settings and assign interfaces; it is not the cluster name used in the security module configuration. You must specify all three security modules, even if you have not yet installed the hardware.
- *slots*—Assigns the chassis modules to the cluster. For the Firepower 4100, specify **1**. For the Firepower 9300, specify **1,2,3**. You must enable clustering for all 3 module slots in a Firepower 9300 chassis, even if you do not have a module installed. If you do not configure all 3 modules, the cluster will not come up.

**Example:**

```
Firepower /ssa # enter logical-device ASA1 asa 1,2,3 clustered
Firepower /ssa/logical-device* #
```

**Step 5** Configure the cluster bootstrap parameters.

These settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can later change most values in the application CLI configuration.

- a) Create the cluster bootstrap object.

**enter cluster-bootstrap**

**Example:**

```
Firepower /ssa/logical-device* # enter cluster-bootstrap
Firepower /ssa/logical-device/cluster-bootstrap* #
```

- b) Configure an authentication key for control traffic on the cluster control link.

**set key**

**Example:**

```
Firepower /ssa/logical-device/cluster-bootstrap* # set key
Key: diamonddogs
```

You are prompted to enter the shared secret.

The shared secret is an ASCII string from 1 to 63 characters. The shared secret is used to generate the key. This option does not affect datapath traffic, including connection state update and forwarded packets, which are always sent in the clear.

- c) Set the cluster interface mode.

**set mode spanned-etherchannel**

Spanned EtherChannel mode is the only supported mode.

**Example:**

```
Firepower /ssa/logical-device/cluster-bootstrap* # set mode spanned-etherchannel
Firepower /ssa/logical-device/cluster-bootstrap* #
```

- d) Set the cluster group name in the security module configuration.

**set service-type *cluster\_name***

The name must be an ASCII string from 1 to 38 characters.

**Example:**

```
Firepower /ssa/logical-device/cluster-bootstrap* # set service-type cluster1
Firepower /ssa/logical-device/cluster-bootstrap* #
```

- e) Configure the management IP address information.

This information is used to configure a management interface in the security module configuration.

1. Configure a pool of Local IP addresses, one of which will be assigned to each cluster unit for the interface.

**set ipv4 pool start\_ip end\_ip**

**set ipv6 pool start\_ip end\_ip**

Include at least as many addresses as there are units in the cluster. Note that for the Firepower 9300, you must include 3 addresses per chassis, even if you do not have all module slots filled. If you plan to expand the cluster, include additional addresses. The Virtual IP address (known as the Main cluster IP address) that belongs to the current control unit is *not* a part of this pool; be sure to reserve an IP address on the same network for the Main cluster IP address. You can use IPv4 and/or IPv6 addresses.

2. Configure the Main cluster IP address for the management interface.

**set virtual ipv4 ip\_address mask mask**

**set virtual ipv6 ip\_address prefix-length prefix**

This IP address must be on the same network as the cluster pool addresses, but not be part of the pool.

3. Enter the network gateway address.

**set ipv4 gateway ip\_address**

**set ipv6 gateway ip\_address**

**Example:**

```
Firepower /ssa/logical-device/cluster-bootstrap* # set ipv4 gateway 10.1.1.254
Firepower /ssa/logical-device/cluster-bootstrap* # set ipv4 pool 10.1.1.11 10.1.1.27
Firepower /ssa/logical-device/cluster-bootstrap* # set ipv6 gateway 2001:DB8::AA
Firepower /ssa/logical-device/cluster-bootstrap* # set ipv6 pool 2001:DB8::11 2001:DB8::27
Firepower /ssa/logical-device/cluster-bootstrap* # set virtual ipv4 10.1.1.1 mask
255.255.255.0
Firepower /ssa/logical-device/cluster-bootstrap* # set virtual ipv6 2001:DB8::1
prefix-length 64
```

- f) Exit the cluster bootstrap mode.

**exit**

**Example:**

```
Firepower /ssa/logical-device* # enter cluster-bootstrap
Firepower /ssa/logical-device/cluster-bootstrap* # set chassis-id 1
Firepower /ssa/logical-device/cluster-bootstrap* # set key
Key: f@arscape
Firepower /ssa/logical-device/cluster-bootstrap* # set mode spanned-etherchannel
```

```
Firepower /ssa/logical-device/cluster-bootstrap* # set service-type cluster1
Firepower /ssa/logical-device/cluster-bootstrap* # exit
Firepower /ssa/logical-device/* #
```

## Step 6 Configure the management bootstrap parameters.

These settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can later change most values in the application CLI configuration.

- a) Create the management bootstrap object.

**enter mgmt-bootstrap asa**

**Example:**

```
Firepower /ssa/logical-device* # enter mgmt-bootstrap asa
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- b) Specify the admin password.

**create bootstrap-key-secret PASSWORD**

**set value**

Enter a value: *password*

Confirm the value: *password*

**exit**

**Example:**

The pre-configured ASA admin user is useful for password recovery; if you have FXOS access, you can reset the admin user password if you forget it.

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key-secret PASSWORD
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # set value
Enter a value: floppylampshade
Confirm the value: floppylampshade
Firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key-secret* # exit
Firepower /ssa/logical-device/mgmt-bootstrap* #
```

- c) Exit the management bootstrap mode.

**exit**

**Example:**

```
Firepower /ssa/logical-device/mgmt-bootstrap* # exit
Firepower /ssa/logical-device* #
```

## Step 7 Save the configuration.

**commit-buffer**

The chassis deploys the logical device by downloading the specified software version and pushing the bootstrap configuration and management interface settings to the application instance. Check the status of the deployment

using the **show app-instance** command. The application instance is running and ready to use when the **Admin State is Enabled** and the **Oper State is Online**.

#### Example:

```
Firepower /ssa/logical-device* # commit-buffer
Firepower /ssa/logical-device # exit
Firepower /ssa # show app-instance
```

| App Name    | Identifier   | Slot ID | Admin State    | Oper State    | Running Version | Startup Version |
|-------------|--------------|---------|----------------|---------------|-----------------|-----------------|
| Deploy Type | Profile Name | Cluster | State          | Cluster Role  |                 |                 |
| ftd         | cluster1     | 1       | Enabled        | Online        | 6.4.0.49        | 6.4.0.49        |
| Native      |              |         | In Cluster     | Slave         |                 |                 |
| ftd         | cluster1     | 2       | Enabled        | Online        | 6.4.0.49        | 6.4.0.49        |
| Native      |              |         | In Cluster     | Master        |                 |                 |
| ftd         | cluster1     | 3       | Disabled       | Not Available |                 | 6.4.0.49        |
| Native      |              |         | Not Applicable | None          |                 |                 |

### Step 8 Connect to the control unit ASA to customize your clustering configuration.

#### Example

For chassis 1:

```
scope eth-uplink
 scope fabric a
 enter port-channel 1
 set port-type data
 enable
 enter member-port Ethernet1/1
 exit
 enter member-port Ethernet1/2
 exit
 exit
 enter port-channel 2
 set port-type data
 enable
 enter member-port Ethernet1/3
 exit
 enter member-port Ethernet1/4
 exit
 exit
 enter port-channel 3
 set port-type data
 enable
 enter member-port Ethernet1/5
 exit
 enter member-port Ethernet1/6
 exit
 exit
 enter port-channel 4
 set port-type mgmt
 enable
 enter member-port Ethernet2/1
 exit
 enter member-port Ethernet2/2
 exit
```

```

 exit

 exit
 exit
 commit-buffer

scope ssa
 enter logical-device ASA1 asa "1,2,3" clustered
 enter cluster-bootstrap
 set chassis-id 1
 set ipv4 gateway 10.1.1.254
 set ipv4 pool 10.1.1.11 10.1.1.27
 set ipv6 gateway 2001:DB8::AA
 set ipv6 pool 2001:DB8::11 2001:DB8::27
 set key
 Key: f@arscape
 set mode spanned-etherchannel
 set service-type cluster1
 set virtual ipv4 10.1.1.1 mask 255.255.255.0
 set virtual ipv6 2001:DB8::1 prefix-length 64
 exit
 exit
scope app asa 9.5.2.1
 set-default
 exit
 commit-buffer

```

## Manage Logical Devices

You can delete a logical device, convert an ASA to transparent mode, change the interface configuration, and perform other tasks on existing logical devices.

## Connect to the Console of the Application

Use the following procedure to connect to the console of the application.

### Procedure

**Step 1** Connect to the module CLI.

**connect module *slot\_number* console**

To connect to the security engine of a device that does not support multiple security modules, always use **1** as the *slot\_number*.

#### Example:

```

Firepower# connect module 1 console
Telnet escape character is '~'.
Trying 127.5.1.1...
Connected to 127.5.1.1.
Escape character is '~'.

CISCO Serial Over LAN:
Close Network Connection to Exit

```

```
Firepower-module1>
```

**Step 2** Connect to the application console.

**connect asa**

**Example:**

```
Firepower-module1> connect asa
Connecting to asa(asal) console... hit Ctrl + A + D to return to bootCLI
[...]
asa>
```

**Example:**

```
Firepower-module1> connect ftd
Connecting to ftd(ftd-native) console... enter exit to return to bootCLI
[...]
>
```

**Step 3** Exit the application console to the FXOS module CLI.

- ASA—Enter **Ctrl-a, d**

**Step 4** Return to the supervisor level of the FXOS CLI.

a) Enter ~

You exit to the Telnet application.

b) To exit the Telnet application, enter:

telnet>**quit**

## Remove a Cluster Unit

The following sections describe how to remove units temporarily or permanently from the cluster.

### Temporary Removal

A cluster unit will be automatically removed from the cluster due to a hardware or network failure, for example. This removal is temporary until the conditions are rectified, and it can rejoin the cluster. You can also manually disable clustering.

To check whether a device is currently in the cluster, check the cluster status within the application using the **show cluster info** command:

```
ciscoasa# show cluster info
Clustering is not enabled
```

- Disable clustering in the application—You can disable clustering using the application CLI. Enter the **cluster remove unit name** command to remove any unit other than the one you are logged into. The

bootstrap configuration remains intact, as well as the last configuration synced from the control unit, so you can later re-add the unit without losing your configuration. If you enter this command on a data unit to remove the control unit, a new control unit is elected.

When a device becomes inactive, all data interfaces are shut down; only the Management interface can send and receive traffic. To resume traffic flow, re-enable clustering. The Management interface remains up using the IP address the unit received from the bootstrap configuration. However if you reload, and the unit is still inactive in the cluster, the Management interface is disabled.

To reenabling clustering, on the ASA enter **cluster group name** and then **enable**.

- Disable the application instance—At the FXOS CLI, see the following example:

```
Firepower-chassis# scope ssa
Firepower-chassis /ssa # scope slot 1
Firepower-chassis /ssa/slot # scope app-instance asa asa1
Firepower-chassis /ssa/slot/app-instance # disable
Firepower-chassis /ssa/slot/app-instance* # commit-buffer
Firepower-chassis /ssa/slot/app-instance #
```

To reenabling:

```
Firepower-chassis /ssa/slot/app-instance # enable
Firepower-chassis /ssa/slot/app-instance* # commit-buffer
Firepower-chassis /ssa/slot/app-instance #
```

- Shut down the security module/engine—At the FXOS CLI, see the following example:

```
Firepower-chassis# scope service-profile server 1/1
Firepower-chassis /org/service-profile # power down soft-shut-down
Firepower-chassis /org/service-profile* # commit-buffer
Firepower-chassis /org/service-profile #
```

To power up:

```
Firepower-chassis /org/service-profile # power up
Firepower-chassis /org/service-profile* # commit-buffer
Firepower-chassis /org/service-profile #
```

- Shut down the chassis—At the FXOS CLI, see the following example:

```
Firepower-chassis# scope chassis 1
Firepower-chassis /chassis # shutdown no-prompt
```

## Permanent Removal

You can permanently remove a cluster member using the following methods.

- Delete the logical device—At the FXOS CLI, see the following example:

```
Firepower-chassis# scope ssa
Firepower-chassis /ssa # delete logical-device cluster1
Firepower-chassis /ssa* # commit-buffer
```

```
Firepower-chassis /ssa #
```

- Remove the chassis or security module from service—If you remove a device from service, you can add replacement hardware as a new member of the cluster.

## Change the ASA to Transparent Firewall Mode

You can only deploy a routed firewall mode ASA from the Firepower 9300 chassis. To change the ASA to transparent firewall mode, complete the initial deployment, and then change the firewall mode within the ASA CLI. For standalone ASAs, because changing the firewall mode erases the configuration, you must then redeploy the configuration from the Firepower 9300 chassis to regain the bootstrap configuration. The ASA then remains in transparent mode with a working bootstrap configuration. For clustered ASAs, the configuration is not erased, so you do not need to redeploy the bootstrap configuration from FXOS.

### Procedure

**Step 1** Connect to the ASA console according to [Connect to the Console of the Application, on page 129](#). For a cluster, connect to the primary unit. For a failover pair, connect to the active unit.

**Step 2** Enter configuration mode:

```
enable
```

```
configure terminal
```

By default, the enable password is blank.

**Step 3** Set the firewall mode to transparent:

```
firewall transparent
```

**Step 4** Save the configuration:

```
write memory
```

For a cluster or failover pair, this configuration is replicated to secondary units:

```
asa(config)# firewall transparent
asa(config)# write memory
Building configuration...
Cryptochecksum: 9f831dfb 60dffa8c 1d939884 74735b69

3791 bytes copied in 0.160 secs
[OK]
asa(config)#
Beginning configuration replication to unit-1-2
End Configuration Replication to data unit.

asa(config)#
```

**Step 5** On the Firepower Chassis Manager **Logical Devices** page, click the **Edit** icon to edit the ASA. The **Provisioning** page appears.

- Step 6** Click the device icon to edit the bootstrap configuration. Change any value in your configuration, and click **OK**.
- You must change the value of at least one field, for example, the **Password** field.
- You see a warning about changing the bootstrap configuration; click **Yes**.
- Step 7** Click **Save** to redeploy the configuration to the ASA.
- Wait several minutes for the chassis/security modules to reload, and for the ASA to become operational again. The ASA now has an operational bootstrap configuration, but remains in transparent mode.
- 

## Change an Interface on a Firepower Threat Defense Logical Device

You can allocate or unallocate an interface on the FTD logical device. You can then sync the interface configuration in .

Adding a new interface, or deleting an unused interface has minimal impact on the FTD configuration. However, deleting an interface that is used in your security policy will impact the configuration. Interfaces can be referenced directly in many places in the FTD configuration, including access rules, NAT, SSL, identity rules, VPN, DHCP server, and so on. Policies that refer to security zones are not affected. You can also edit the membership of an allocated EtherChannel without affecting the logical device or requiring a sync on the .

### Before you begin

- Configure your interfaces, and add any EtherChannels according to [Configure a Physical Interface, on page 105](#) and [Add an EtherChannel \(Port Channel\), on page 107](#).
- If you want to add an already-allocated interface to an EtherChannel (for example, all interfaces are allocated by default to a cluster), you need to unallocate the interface from the logical device first, then add the interface to the EtherChannel. For a new EtherChannel, you can then allocate the EtherChannel to the device.
- If you want to replace the management or firepower eventing interface, you must use the Firepower Chassis Manager; the CLI does not support this change.
- For clustering or High Availability, make sure you add or remove the interface on all units before you sync the configuration in the . We recommend that you make the interface changes on the data/standby unit(s) first, and then on the control/active unit. Note that new interfaces are added in an administratively down state, so they do not affect interface monitoring.

### Procedure

---

- Step 1** Enter security services mode:
- ```
Firepower# scope ssa
```
- Step 2** Edit the logical device:
- ```
Firepower /ssa # scope logical-device device_name
```

- Step 3** Allocate a new interface to the logical device:  
 Firepower /ssa/logical-device\* # **create external-port-link** *name interface\_id ftd*  
 Do not delete any interfaces yet.
- Step 4** Commit the configuration:  
**commit-buffer**  
 Commits the transaction to the system configuration.
- Step 5** In FXOS, unallocate an interface from the logical device:  
 Firepower /ssa/logical-device # **delete external-port-link** *name*  
 Enter the **show external-port-link** command to view interface names.
- Step 6** Commit the configuration:  
**commit-buffer**  
 Commits the transaction to the system configuration.
- Step 7** Sync the interfaces again in .

## Change an Interface on an ASA Logical Device

You can allocate, unallocate, or replace a management interface on an ASA logical device. ASDM discovers the new interfaces automatically.

Adding a new interface, or deleting an unused interface has minimal impact on the ASA configuration. However, if you remove an allocated interface in FXOS (for example, if you remove a network module, remove an EtherChannel, or reassign an allocated interface to an EtherChannel), and the interface is used in your security policy, removal will impact the ASA configuration. In this case, the ASA configuration retains the original commands so that you can make any necessary adjustments. You can manually remove the old interface configuration in the ASA OS.



**Note** You can edit the membership of an allocated EtherChannel without impacting the logical device.

### Before you begin

- Configure your interfaces and add any EtherChannels according to [Configure a Physical Interface, on page 105](#) and [Add an EtherChannel \(Port Channel\), on page 107](#).
- If you want to add an already-allocated interface to an EtherChannel (for example, all interfaces are allocated by default to a cluster), you need to unallocate the interface from the logical device first, then add the interface to the EtherChannel. For a new EtherChannel, you can then allocate the EtherChannel to the device.
- For clustering or failover, make sure you add or remove the interface on all units. We recommend that you make the interface changes on the data/standby unit(s) first, and then on the control/active unit. New interfaces are added in an administratively down state, so they do not affect interface monitoring.

## Procedure

- 
- Step 1** Enter security services mode:
- ```
Firepower# scope ssa
```
- Step 2** Edit the logical device:
- ```
Firepower /ssa # scope logical-device device_name
```
- Step 3** Unallocate an interface from the logical device:
- ```
Firepower /ssa/logical-device # delete external-port-link name
```
- Enter the **show external-port-link** command to view interface names.
- For a management interface, delete the current interface then commit your change using the **commit-buffer** command before you add the new management interface.
- Step 4** Allocate a new interface to the logical device:
- ```
Firepower /ssa/logical-device* # create external-port-link name interface_id asa
```
- Step 5** Commit the configuration:
- ```
commit-buffer
```
- Commits the transaction to the system configuration.
-

Monitoring Logical Devices

• show app

View available images.

```
Firepower# scope ssa
Firepower /ssa # show app
```

Name	Version	Author	Supported Deploy Types	CSP Type	Is Default
asa	9.10.1	cisco	Native	Application	Yes
ftd	6.2.3	cisco	Native	Application	Yes

• show app-instance

View the application instance status and information.

```
Firepower# scope ssa
Firepower /ssa # show app-instance
```

App Name	Slot ID	Admin State	Oper State	Running Version	Startup Version	Cluster State	Cluster Role
ftd	1	Enabled	Online	6.2.1.62	6.2.1.62		Not

Applicable None

- **show logical-device**

View details for logical devices.

```
Firepower# scope ssa
Firepower /ssa # show logical-device
```

Logical Device:

Name	Description	Slot ID	Mode	Oper State	Template Name
asa1		1	Standalone	Ok	asa

History for Logical Devices

Feature Name	Platform Releases	Feature Information
Intra-chassis Clustering for the ASA on the Firepower 9300	1.1.1	You can cluster all ASA security modules within the Firepower 9300 chassis. We introduced the following commands: enter cluster-bootstrap, enter logical-device clustered, set chassis-id, set ipv4 gateway, set ipv4 pool, set ipv6 gateway, set ipv6 pool, set key, set mode spanned-etherchannel, set port-type cluster, set service-type, set virtual ipv4, set virtual ipv6



INDEX

A

AAA [86, 87, 90, 91, 93, 94, 95](#)
 LDAP providers [86, 87, 90](#)
 RADIUS providers [90, 91, 93](#)
 TACACS+ providers [93, 94, 95](#)
 accessing the command line interface [12](#)
 accounts [30, 36, 37, 38, 42](#)
 locally authenticated [30, 36, 37, 38, 42](#)
 asa [50, 115, 116, 123, 129](#)
 connecting to [129](#)
 creating a cluster [123](#)
 creating a clustered [115](#)
 creating a standalone asa logical device [116](#)
 exiting from connection [129](#)
 updating image version [50](#)
 asa images [45, 46, 48](#)
 about [45](#)
 downloading from Cisco.com [46](#)
 downloading to the Firepower security appliance [48](#)
 authentication [31](#)
 default [31](#)
 authNoPriv [63](#)
 authPriv [63](#)

B

breakout cables [108](#)
 configuring [108](#)
 breakout ports [108](#)

C

call home [19](#)
 configure http proxy [19](#)
 certificate [72](#)
 about [72](#)
 chassis [9](#)
 initial configuration [9](#)
 Cisco Secure Package [45, 46, 48](#)
 about [45](#)
 downloading from Cisco.com [46](#)
 downloading to the Firepower security appliance [48](#)
 cli, *See* command line interface
 CLI session limits [7](#)

clusters [115, 122, 123](#)
 about [122](#)
 creating [115, 123](#)
 command line interface [12](#)
 accessing [12](#)
 command modes [3](#)
 commands [6](#)
 history [6](#)
 communication services [65, 73, 74, 75, 77, 78](#)
 HTTPS [73, 74, 75, 77, 78](#)
 SNMP [65](#)
 community, SNMP [65](#)
 configuring [73, 74, 75, 77, 78](#)
 HTTPS [73, 74, 75, 77, 78](#)
 connecting to a logical device [129](#)
 console [33](#)
 timeout [33](#)
 CSP, *See* Cisco Secure Package

D

date [59](#)
 setting manually [59](#)
 date and time [55](#)
 configuring [55](#)
 DNS [100](#)

E

enabling [65](#)
 SNMP [65](#)
 enforcing password strength [35](#)
 exiting from logical device connection [129](#)

F

Firepower chassis [9](#)
 initial configuration [9](#)
 Firepower eXtensible OS [48](#)
 upgrading the platform bundle [48](#)
 Firepower platform bundle [45, 46, 47, 48](#)
 about [45](#)
 downloading from Cisco.com [46](#)
 downloading to the Firepower security appliance [46](#)

Firepower platform bundle (*continued*)

- upgrading [48](#)
- verifying integrity [47](#)

Firepower security appliance [1](#)

- overview [1](#)

firmware [52](#)

- upgrading [52](#)

fpga [52](#)

- upgrading [52](#)

Hhigh-level task list [9](#)history, passwords [30](#)http proxy [19](#)

- configuring [19](#)

HTTPS [33, 73, 74, 75, 77, 78, 80, 81, 83](#)

- certificate request [74, 75](#)
- changing port [81](#)
- configuring [80](#)
- creating key ring [73](#)
- disabling [83](#)
- importing certificate [78](#)
- regenerating key ring [73](#)
- timeout [33](#)
- trusted point [77](#)

Iimage version [50](#)

- updating [50](#)

images [45, 46, 47, 48](#)

- downloading from Cisco.com [46](#)
- downloading to the Firepower security appliance [46, 48](#)
- managing [45](#)
- upgrading the Firepower eXtensible Operating System platform
 - bundle [48](#)
 - verifying integrity [47](#)

informs [63](#)

- about [63](#)

initial configuration [9](#)interfaces [105](#)

- configuring [105](#)
- properties [105](#)

Kkey ring [72, 73, 74, 75, 77, 78, 82](#)

- about [72](#)
- certificate request [74, 75](#)
- creating [73](#)
- deleting [82](#)
- importing certificate [78](#)
- regenerating [73](#)
- trusted point [77](#)

LLDAP [86, 87, 90](#)LDAP providers [87, 90](#)

- creating [87](#)
- deleting [90](#)

license [20](#)

- registering [20](#)

license authority [20](#)locally authenticated users [30, 36, 37, 38, 42](#)

- change interval [36](#)
- clearing password history [42](#)
- no change interval [37](#)
- password history count [38](#)
- password profile [30](#)

logical devices [50, 115, 116, 123, 129](#)

- connecting to [129](#)
- creating a cluster [115, 123](#)
- creating a standalone [116](#)
- exiting from connection [129](#)
- updating image version [50](#)

Mmanaged objects [3](#)management IP address [53](#)

- changing [53](#)

NnoAuthNoPriv [63](#)NTP [55, 57, 58](#)

- adding [57](#)
- configuring [55, 57](#)
- deleting [58](#)

Oobject commands [5](#)**P**password profile [30, 36, 37, 38, 42](#)

- about [30](#)
- change interval [36](#)
- clearing password history [42](#)
- no change interval [37](#)
- password history count [38](#)

passwords [27, 30, 35](#)

- change interval [30](#)
- guidelines [27](#)
- history count [30](#)
- strength check [35](#)

pending commands [6](#)PKI [72](#)

- platform bundle [45, 46, 47, 48](#)
 - about [45](#)
 - downloading from Cisco.com [46](#)
 - downloading to the Firepower security appliance [46](#)
 - upgrading [48](#)
 - verifying integrity [47](#)
- policies [34](#)
 - role for remote users [34](#)
- port channels [107](#)
 - configuring [107](#)
- profiles [30](#)
 - password [30](#)

R

- RADIUS [90, 91, 93](#)
- RADIUS providers [91, 93](#)
 - creating [91](#)
 - deleting [93](#)
- registering a license [20](#)
- role policy for remote users [34](#)
- rommon [52](#)
 - upgrading [52](#)
- RSA [72](#)

S

- session timeout [33](#)
- smart call home [19](#)
 - configure http proxy [19](#)
- SNMP [62, 63, 64, 65, 66, 68, 70, 71](#)
 - about [62](#)
 - community [65](#)
 - current settings [71](#)
 - enabling [65](#)
 - notifications [63](#)
 - privileges [63](#)
 - security levels [63](#)
 - support [62, 64](#)
 - traps [66, 68](#)
 - creating [66](#)
 - deleting [68](#)
 - users [68, 70](#)
 - creating [68](#)
 - deleting [70](#)
 - Version 3 security features [64](#)
- SNMPv3 [64](#)
 - security features [64](#)
- SSH [33, 60](#)
 - configuring [60](#)
 - timeout [33](#)
- syslog [97](#)
 - configuring local destinations [97](#)

- syslog (*continued*)
 - configuring local sources [97](#)
 - configuring remote destinations [97](#)
- system [9](#)
 - initial configuration [9](#)

T

- TACACS+ [93, 94, 95](#)
- TACACS+ providers [94, 95](#)
 - creating [94](#)
 - deleting [95](#)
- task flow [9](#)
- Telnet [33, 61](#)
 - configuring [61](#)
 - timeout [33](#)
- time [59](#)
 - setting manually [59](#)
- time zone [55, 57, 59](#)
 - setting [55, 57, 59](#)
- timeout [33](#)
 - console [33](#)
 - HTTPS, SSH, and Telnet [33](#)
- traps [63, 66, 68](#)
 - about [63](#)
 - creating [66](#)
 - deleting [68](#)
- trusted points [72, 77, 82](#)
 - about [72](#)
 - creating [77](#)
 - deleting [82](#)

U

- upgrading the firmware [52](#)
- user accounts [30, 36, 37, 38, 42](#)
 - password profile [30, 36, 37, 38, 42](#)
- users [7, 25, 26, 27, 30, 31, 34, 35, 36, 37, 38, 39, 41, 42, 68, 70](#)
 - activating [42](#)
 - CLI session limits [7](#)
 - creating [39](#)
 - deactivating [42](#)
 - default authentication [31](#)
 - deleting [41](#)
 - locally authenticated [30, 36, 37, 38, 42](#)
 - managing [25](#)
 - naming guidelines [26](#)
 - password guidelines [27](#)
 - password strength check [35](#)
 - remote, role policy [34](#)
 - roles [30](#)
 - SNMP [68, 70](#)

