

WC20 A&V "55" Manual Firmware Update Instructions



- ❖ Please read through the instructions before downloading the file. **This update can only be done** on a windows-based computer or a MAC.
- ❖ If you currently have a password on your camera. You'll need to DEFAULT the camera. Without doing so, it can potentially lock you out of the camera.
- ❖ You can do this on the camera. With the camera in the OFF position, Remove the SD card, Turn the camera ON, Hit MENU(M), Arrow right to Default, select OK, arrow to YES, Select OK. You can then turn the camera OFF.

STEP 1


- Insert the SD card into the computer!
- Format your SD card (Making sure it's completely empty)

STEP 2 - *Don't change the file name and only download the File once! If you download the file more than once and there's a number beside it (1),(2),etc. All will cause the update to be unsuccessful.

(Using a Windows Computer)

- Select "Download Firmware" under WC20.
- You'll then need to open your downloads folder.  You should see the ZIP file. *Left click & hold, drag, and drop the file onto your main desktop.*
- Once the ZIP file is on your desktop.  Open the ZIP file Then *Left click & hold, drag, and drop the file onto your desktop.*
- Once on your desktop. You can then pull up your FILE Explorer  Once opened, on the left side scroll to the bottom and click on the SDHC file  or whichever your SD card is reading as.
- You'll then *Left click & hold, drag, and drop the file from the desktop onto the SD card.*
- **Please make sure this file is the only thing on the SD card** 
- You can remove the SD card from your computer

(Using a MAC/Apple Computer)

- Select "Download Firmware" under WC20.
- You'll Double click on the ZIP file to open it. It'll put the file into an unzipped folder on your Desktop.
- You'll need to open this folder and remove the file (It CANNOT BE IN A FOLDER ON THE SD CARD)
- You can *Left click & hold, drag, and drop the file into your Removeable Disk*  OR SD card icon. (Whichever it reads as)
- **Please make sure this file is the only thing on the SD card** 
- You can remove the SD card from your computer

STEP 3

- With camera in the **OFF** position, Insert the SD card and turn the camera **ON**.
- Once the camera screen turns ON. It'll ask **YES** or **NO** for updating, you'll arrow to **YES** and press **OK**. Camera will show in percentage as the firmware is updating.
- You must wait for the camera to say either "**success**" or "**failed**". Once you see either, hit the MENU button, arrow to the LEFT once to SOFTWARE version and check that the current firmware reads **CT660Nx055**.
- IF the firmware is up to date, you can turn the camera OFF and proceed with the next steps below.
- Put the camera into the ON position and wait for it to show "connection success".
- Once you receive "connection success" Press the left arrow key 1 time. (It'll pop up a few different things during this cycle)
- You should see "Upload Thumbnail", when that goes away, check your app for the manual photo.

*If the manual photo was received on the app, you can let the camera count down into WORKMODE and let it trigger photos!

SD CARD SPECIFICATIONS- Our cameras function with a Standard SD card, Class 10, between 8-32 GB. *We ONLY recommend Sony, ONN, or Covert SD cards. *We don't recommend using San Disk brand, as they don't meet the requirements for the cameras. **Please, don't use any cards that say** Ultra/Ultra Plus, High Performance, Platinum, Extreme, Tough, HD/High definition, Plus, Elite, Pro, Image Mate, Edge, MICRO adapter, etc. These types of SD cards don't work well with our devices.