



Lossnay Energy Recovery Ventilator

MODELS:

**LGH-F300RVX2-E, LGH-F380RVX2-E, LGH-F470RVX2-E,
LGH-F600RVX2-E, LGH-F940RVX2-E, LGH-F1200RVX2-E**

Operating Instructions

(For the user)

Please read this manual carefully before use for proper and safe use.

Do not attempt to install the product by yourself.

Safety precautions

The following signs indicate that death or serious injury may be caused by failure to heed the precautions described below.

WARNING


 Prohibited	Do not turn the unit on or off when flammable gas has leaked. (It could catch fire or cause explosion with sparks released from electric contractor.) Open windows to ventilate.	 Wet hands prohibited	Do not operate with wet hands. (Electrical shock can result.)
 Do not disassemble	Do not modify or disassemble. (It could cause fire, electric shock or injury.)		Use the specified power supply and voltage. (Use of incorrect power supply could cause fire or electric shock.)
 Do not wet	Do not apply water to the unit and remote controller. (Electrical shock can result.)	 The instructions given must be followed.	Make sure the power supply isolator is turned off on the power distribution panel before starting maintenance. (It could cause electric shock or injury if it is turned on.)
 Do not touch	Do not poke your fingers or sticks into the air intake and outlet while the product is operating. (Failure to heed this warning may result in injury.)		When any abnormal conditions (burning smell, or others) are observed, stop operation, turn off the power supply isolator on the power distribution panel and consult your dealer. (Continuing operation under such conditions could cause, electric shock, fire, or damage.)

CAUTION


 Prohibited	Do not place a burning appliance in a place where it is exposed directly to the wind from Lossnay. (It could cause an accident as a result of incomplete combustion.) Do not operate with the "BY-PASS" when heating the room in winter. (Condensed water may drip from the unit and wet the surface of ceiling.) Do not use at a place where exposed to high temperatures (104°F(40°C) or higher), naked flames, or in environment with heavy fumes. (It could cause fire.) Do not use in an environment such as a chemical factory, where hazardous gases such as acidic gases, alkaline gases, organic solvent fumes, paint fumes, or gases containing corrosive components are generated. (It could malfunction.)	 The instructions given must be followed.	Securely install parts after maintenance. (It could cause injury if parts fall.) Put on gloves during maintenance. (It could cause injury.) Make sure the power supply isolator is turned off on the power distribution panel when Lossnay is not used for a long period of time. (It could cause electric shock, power leakage, or fire as a result of deteriorated insulation.) This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
---	--	---	--

Names of the parts

Models LGH-F300 to F600RVX2-E



Model LGH-F940 and F1200RVX2-E



Operation

Lossnay can be connected with Lossnay remote controller (PZ-62DR-E), and other systems (City Multi, Mr.Slim, Central controller (MELANS))

Following shows the use of PZ-62DR-E. Please refer to the manuals for the other systems.

For connection of a Lossnay remote controller (PZ-62DR-E)

If the Lossnay's operation is linked with the operation of an external device such as an air conditioner, the method of use will differ, so carry out the appropriate operation in accordance with the following table. Also, please see the installation and user manual for the Lossnay remote controller (PZ-62DR-E).


<Not connected to an external device>

Example of System	Operation	Function
Lossnay Remote Controller (Optional parts) (PZ-62DR-E) Power Supply	Run using the remote controller.	If 2 remote controllers are used, the last controller to be used has priority. (Last Command)

<Connected to an external device>

Lossnay Remote Controller (Optional parts) (PZ-62DR-E) Power Supply External device Operation switch for the external device	If an external device is connected the "On/Off" function of this device, it will also control the Lossnay operation.	If you would like to turn ON the Lossnay alone while the external device is OFF, operate it by the Lossnay remote controller.
Lossnay Power Supply External device Operation switch for the external device		- The fan speed is on Fan speed 3 or Fan speed 4. - The ventilation mode is "Auto Ventilation Mode".

■ Display and Function button (PZ-62DR-E)




Operation (continued)

■ LOSSNAY ENERGY RECOVERY VENTILATE setting

Both fresh air supply and return air pass through the energy recovery cores. Energy recovery ventilation makes the fresh air temperature close to the indoor temperature in the winter and the summer season.


Models LGH-F300 to F600RVX2-E Models LGH-F940 and F1200RVX2-E



■ BY-PASS VENTILATE setting

The fresh air passes through the Lossnay cores and the return room air is exhausted direct. Lossnay By-pass ventilate is normally operated during the spring/autumn season.

Models LGH-F300 to F600RVX2-E Models LGH-F940 and F1200RVX2-E



Maintenance

Remove all dust and dirt on air filters and Lossnay cores at regular intervals in order to prevent a deterioration in the Lossnay functions.

Guideline: Clean the air filters once a year.

(or when  are indicated on the remote controller)

Clean the Lossnay cores once two year.


(Clean the Lossnay cores once a year if possible.)

(Frequency should be increased depending on the extent of dirt.)

Removing the parts

1) Maintenance cover


1. Remove the black screw.
2. Slide the fix piece to out side.
3. Open hinge wire.



Models LGH-F940 and LGH-F1200RVX2-E have 2 fix pieces.

2) Lossnay cores

Take hold of the handle and draw the Lossnay cores out from the main unit.



Models LGH-F300 to F600RVX2-E Models LGH-F940 and F1200RVX2-E

■ AUTOMATIC VENTILATION setting

The automatic ventilation mode automatically provides the correct ventilation for the conditions in the room. The following shows the effect "By-pass" ventilation will have under various conditions.

1. Reduces cooling load

If the air outside is cooler than the air inside the building during the cooling season (such as early morning or at night), "By-pass" ventilation will draw in the cooler outside air and reduce the cooling load on the system.

2. Night purge

"By-pass" ventilation can be used to release hot air from inside the building that has accumulated in buildings a business district during the hot summer season.

3. Office equipment room cooling


During cold season, fresh air can be drawn in and used as is to cool rooms where the temperature has risen due to the use of office equipment.

⚠ CAUTION

- In the case of "By-pass" ventilation, the supply air temperature slightly rises more than the outside air temperature because of the heat effect around the ducts or the unit motors.
- When set to auto ventilation mode while using the pre-heater function, the outdoor temperature may be detected as higher and the mode may change to by-pass mode, even in winter.

3) Air filters

After pulling out the Lossnay cores, undo filter guides, then remove the air filters, located at the bottom left and right of the Lossnay cores, as below.



Models LGH-F300 to F600RVX2-E: 2 cores, 4 filters

Models LGH-F940 and F1200RVX2-E: 4 cores, 8 filters


⚠ CAUTION

- Bow filter stoppers a little to remove them from filter guide.
- Take filter stoppers careful not to break them.

Cleaning the parts

1) Air filters

Use a vacuum cleaner to remove light dust. To remove stubborn dirt wash in a mild solution of detergent and lukewarm water. (under 104°F(40°C))



⚠ CAUTION


- Never wash the filters in very hot water and never wash them by rubbing them.
- Do not dry the filters by exposing them to a flame.

Maintenance (continued)

2) Lossnay cores

Use a vacuum cleaner to suck up the dust and dirt on the exposed surfaces of the Lossnay cores.
Use a soft brush only to clean exposed surface areas.

Do NOT wash in water.



⚠ CAUTION

- Do not use the hard nozzle of the vacuum cleaner. It may damage the exposed surfaces of the Lossnay cores.
- Under no circumstances should the Lossnay cores be washed in water.

Assembly after maintenance

Bearing in mind the following points, assemble the parts following the sequence for their removal in reverse.

- Arrange the Lossnay core with the air filter side downward.
- The filter has front and back side. Set the "FRONT" (printed) side of the filter on the outer side.

Note

- If  are indicated on the remote controller, turn off the indication, after maintenance.

Specifications

Model name	Input power (W)	Air volume			Static pressure		Exchange efficiency (%)			Noise (dB)	Weight	
		(CFM)	(CMH)	(W/CFM)	(in W.G)	(Pa)	Temperature	Enthalpy			(lbs)	(kg)
								Heating	Cooling	Below the unit		
LGH-F300RVX2-E	235	300	510	0.78	1.0	250	65.5	63.0	50.0	37	75	34
LGH-F380RVX2-E	340	380	646	0.89	0.86	215	65.0	61.0	49.0	38	90	41
LGH-F470RVX2-E	425	470	799	0.91	1.0	250	69.0	64.0	51.0	40	110	50
LGH-F600RVX2-E	515	600	1019	0.86	0.86	215	67.0	64.0	50.0	41	123	56
LGH-F940RVX2-E	850	940	1597	0.91	1.0	250	69.0	64.0	51.0	43	225	102
LGH-F1200RVX2-E	1030	1200	2039	0.86	0.86	215	67.0	64.0	50.0	43	251	114

* The above values apply during Lossnay ventilation when the fan speed is set to Fan speed 4 at the rating pressure loss and 230 V / 60 Hz.

* For the specifications at the other frequency or voltages, contact your dealer.

* The values given in the table for the noise level reflect the levels measured at a position 4.9 feet(1.5 m) immediately below the unit in an anechoic chamber.

* Noise change or increase may occur because of the Bypass-Automatic function or Automatic fan speed change by timer setting and/or other functions.

* Temperature Exchange efficiency (%) are average of summer and winter condition.

* Mitsubishi Electric measures products according to ISO 16494:2014, therefore P-Q curves are measured by chamber method.

* On-site commissioning measurements by pitot tube method could be as much 20% difference from JIS test room conditions. If the measuring point is close to sources of turbulence like bends, contractions and dampers etc, it is difficult to measure air volume correctly. A straight duct length more than 10D (D=duct diameter) from the source of turbulence is recommended for correct measurement. On-site measurement should therefore be measured in accordance with BSRIA guideline (Commissioning Air System. Application procedures for buildings AG3/89.3(2001))

After-sales servicing

Consult with your dealer about the after-sales services provided for this Lossnay product.

If you hear strange sounds, if no air is blown out or if some other trouble occurs, switch off the power and contact your dealer. Consult with your dealer concerning the cost of inspection or repair work.

■ Recommended inspection and maintenance

After several years of use, the following might occur. We recommend inspection and maintenance by a professional.

- Entry of dust due to deterioration of filters
- Abnormal noise or vibration due to the motor reaching the end of its service life
- Air leakage due to the Lossnay core reaching the end of its service life

The following are consumables: Motor / Supply air filter / Exhaust air filter / Lossnay core / Circuit board / Thermistor

■ Repair costs include technical fee, cost of parts, (and business trip charges), etc.

Attentive inspection			Inspect your unit of good service!	
	Have you noticed?	● Fan do not run when the unit is turned on. ● Abnormal noises or vibrations while the unit is running. ● Retarded or irregular rotations. (Motors are component which requires maintenance.) ● Burnt odor. ● Corroded or damaged installation section.		Stop running. Turn off the unit. Then, contact your dealer for prevention of failure or hazard. The dealer should appraise the possible cost.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN