

ipega®

派普伊

大黄蜂无线游戏手柄

产品说明书(PG-4019)中文版

功能按键图示:

SHARE键

喇叭

十字键

左3D摇杆加下压键

右3D摇杆加下压键

PS HOME 按键

TYPE-C插口

R1键

R2键

耳机座

触摸板

导光条

OP TIONS键

□; X; O△键

触摸板下压按键

L1键

L2键

产品特性参数:

1.内置/外置电池 内置

工作电压 DC4.2V

输入充电电压 5V

输入充电电流 500mA

静态电流 <15uA

电池容量 600mAh

是否支持无线 支持

适用游戏平台 P4主机,P3主机,PC电脑; IOS

单机工作电流 <70mA

是否有振动功能 有振动

是否有内置喇叭 内置喇叭

传输距离 ≤8M

充电时间 约 3 H

产品适用说明:

1. 产品主要适用于P4游戏主机、可兼容P3游戏主机、IOS 13.0以上PC电脑上连接,进行游戏操作时使用。

2. 采用高性能无线连接技术，提供8米以内无延迟不掉线的可靠信号，抗干扰性强，不会受其它无线设备的影响。免驱动，自动连接，无需繁琐的对码过程。

3. 内置LED彩灯,△;□;×;○;键功能键有背光功能。

4. 内置左右非对称马达，支持双马达双振动功能。

5. 内置3D加速度传感器和陀螺仪传感器，具有六轴感应功能。

6. 配置了喇叭和3.5mm耳机插孔，可以通过手柄的喇叭和耳机输出游戏的音频信号。

7. 结构符合人体工程学,手感舒适。

8. 手柄在无任何动作操作时，约15分钟左右进入休眠状态，手柄指示灯熄灭。

9. 支持两点电容式感应触控板。

10. 支持PC USB在线升级产品程序,从而支持PS4主机最新升级系统,可避免因主机升级系统导致产品无法使用难题。

*因官方游戏平台软件升级或源代码变更等不可抗拒的因素造成部分游戏无法与本产品连接操作，我公司不负任何责任。对此我公司保留最终解释权。

1.连接PS4主机

1) 启动P4主机进入界面，USB数据线一端与主机连接，另一端TYPE-C头插入手柄端口。

2) 按手柄HOME键，手柄与主机配对连接。连接成功灯常亮，拔开USB线即可使用手柄。

3) 使用者登入每个用户号光条会依1P:Blue蓝、2P:Red红 3P:Green绿、4P:Pink粉红色点亮，主机自动配置各控制器。

4) 六轴校正：手柄关机状态，先按住OPTIONS键 + HOME键，导光条绿灯点亮，按一下OPTIONS键，红灯熄灭校正完成（校正时手柄平放桌面上）。

5) 功能键背光灯开/关：同时按SHARE键 + □键即可切换（无线模式操作）。

6) 长按HOME键10秒为手柄关机（主机选项关机手柄跟随关机）

2.连接P3/PC

1) 连接PC：通过USB数据线将手柄连至PC USB端口，当有线手柄使用。连接成功导光条亮绿灯，默认为Xbox360 模式，长按HOME键可切换 P3 和Xbox360模式，P3 模式导光条亮红色。（见图一）

长按HOME键可切换
P3 和Xbox360模式

Xbox360 模式导光条亮绿灯
P3 模式导光条亮红灯

有线连接成功导光条亮蓝色
(根据主机自动配置)

拔掉USB线/按HOME键开机,连接成功后导光条亮蓝光当无线使用.

(图一)

(图二)

2) P3主机开机进入界面：通过USB数据线将手柄连至P3主机的USB端口，当有线手柄使用，连接成功导光条亮蓝色（导光条颜色根据主机自动配置）；拔掉USB线按HOME键开机回连当无线使用（见如上图二）。

3) PS3/PC端不支持六轴感应功能，连接PC电脑时，不需要安装驱动程序，即插即用，可以玩PC上的游戏。

3) 支持在线升级更新手柄程序，避免因主机升级系统导致产品无法使用难题。

3.IOS MFI游戏模式

1) 手柄关机状态下同时按SHARE + HOME开启手柄无线配对模式，导光条蓝灯闪烁，喇叭发出声音并马达震动。

2) 在IOS设备的无线列表中，找到并点击“DUALSHOCK 4 Wireless Controller”进行配对，配对成功后蓝灯常亮。

3) 配对成功可以玩MFI认证的游戏。

4) 功能键背光灯开/关：同时按SHARE键 + □键即可切换。

5) 手柄关机或休眠状态按HOME键回连，导光条蓝红灯呼吸循环转变，喇叭发出声音马达震动，功能键背光点亮，回连成功后导光条常亮。

6) 支持在线升级更新手柄程序，避免因主机升级系统导致产品无法使用难题。
注意事项：iOS设备仅支持系统在IOS 13以上系统版本即可使用

4.手柄充电/低电说明

1.低电指示：电池电压在3.45V-3.3V低电压时，手柄导光条快闪烁；电压低于3.3V时，手柄进入休眠状态。

2.充电指示：手柄关机状态时，插入USB充电线，导光条黄色灯呼吸状态，充满灯熄灭。

注意事项

a. 请不要把本产品在潮湿或高温地方存储。

b. 不要敲击、摔打、刺穿、或试图去分解本产品，以免对产品造成不必要的损害。

c. 非专业人员误拆卸本产品,否则不在售后保修服务内。

d. 因官方软件升级或源代码变更等不可抗拒的因素造成部分游戏无法与本产品连接操作，我公司不负任何责任。对此我公司保留最终解释权；

产品清单:

大黄蜂无线游戏手柄 x1

说明书 x1

Type-C线 x1

Function keys:

Specifications:

- This product able to support PS4, PS3, IOS 13.0 or above and PC.
- Using the wireless to connect between the device and the gamepad. Ensure to provide a reliable signal (within 8 meters).
- Built-in LED light .△ ; ◻ ; × ; ○ : button be provide with backlight function.
- Built-in left and right asymmetric motors, supporting dual motors and dual vibration functions.
- Built-in 3D acceleration sensor and gyroscope sensor, with six-axis sensing function.
- Equipped with speakers and 3.5mm headset jack, which able to output game audio signals through the handle's speakers and headphones.
- The structure accords with ergonomics and feels comfortable.
- Gamepad without any motion will go to sleeping mode in 15 mins, the gamepad signal light will turn off.
- Support dual-point capacitive sensing touchpad.
- PC USB online upgrade product program, to support the latest upgrade system of PS4 host. It can avoid the console upgrade system issue.

**Due to the official game platform software upgrade or source code changes and other not resist factors caused of some games can not be played or connected with our gamepad. Our company has no responsibility, we reserves the right of final interpretation for this.

2. P3 / PC Mode :

- PC wired mode : Using the Type-C USB cable to connect between gamepad and console usb port. Once the light bar turn green, the gamepad will default as Xbox360 ver. Press "Home" button to switch P3 and Xbox360 ver. (Image 1)

(Image 1)

- P3 wired mode : Turn on P3 console, using the Type-C USB cable to connect between P3 console and gamepad. Once they connected, the light bar will turn blue. Switch to P3 wireless mode : Unplug the Type-C USB cable and press "Home" to turn on the gamepad.
- Update the gamepad firmware to avoid the disconnection between gamepad and console.

4.Controller charging function :

- Low battery : When the battery voltage getting down to 3.45V - 3.3V, the light bar will keep flashing. Below 3.3V, the gamepad will directly go to sleeping mode.
- Charging instruction : When the gamepad is off, plug the Type-C USB cable to charge the gamepad. During the charging mode, the light bar will turn yellow. Once it finished, the light bar will turn off.

* When the charging nearly finished, the light bar will flashing to info the users almost ready.

Note :

- Please do not store this product in wet or high-temperature areas.
- Don't knap, beat, drub, pierce, or try to decompose this product, to avoid unnecessary damage to the product.
- Non professional personnel should not disassemble the product, otherwise it will not be covered in the after-sales warranty service.
- Due to the official game platform software upgrade or source code changes and other not resist factors caused of some games can not be played or connected with our gamepad. Our company has no responsibility, we reserves the right of final interpretation for this.

Accessories:

- Wireless gamepad x 1
- User Manual x 1
- Type-C cable x 1

ipega trademarks belongs to PEGA LIMITED

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment