

# ***TAF 801***



## **Instruction manual**



## EU DECLARATION OF CONFORMITY

According to  
The Low Voltage Directive 2014/35/EU, entering into force 20 April 2016  
The EMC Directive 2014/30/EU, entering into force 20 April 2016  
The RoHS Directive 2011/65/EU, entering into force 2 January 2013

**Type of equipment**

Welding power source

**Type designation**

TAF 801, from serial number 935 xxx xxxx (2009 w35)

**Brand name or trade mark**

ESAB

**Manufacturer or his authorised representative established within the EEA****Name, address, and telephone No:**

ESAB AB

Lindholmsallén 9, Box 8004, SE-402 77 Göteborg, Sweden

Phone: +46 31 50 90 00, Fax: +46 31 50 92 22

**The following harmonised standard in force within the EEA has been used in the design:**

EN 60974-1:2012, Arc Welding Equipment – Part 1: Welding Power Sources

EN 60974-10:2014, A1:2015 Arc Welding Equipment – Part 10: Electromagnetic Compatibility (EMC) requirements

**Additional Information:**

Restrictive use, Class A equipment, intended for use in location other than residential

**By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorised representative established within the EEA, that the equipment in question complies with the safety requirements stated above.**

**Date**

**Signature**

**Position**

Gothenburg

A handwritten signature in dark ink, appearing to read "Peter Kjällström", with a small flourish above the final letter.

2017-12-18

Peter Kjällström

Director Welding Automation

CE 2017

## TABLE OF CONTENTS

---

<b>1</b>	<b>SAFETY .....</b>	<b>4</b>
1.1	Meaning of symbols .....	4
1.2	Safety precautions .....	4
<b>2</b>	<b>INTRODUCTION .....</b>	<b>7</b>
<b>3</b>	<b>TECHNICAL DATA .....</b>	<b>8</b>
<b>4</b>	<b>INSTALLATION .....</b>	<b>9</b>
4.1	Location .....	9
4.2	Connections .....	10
<b>5</b>	<b>OPERATION .....</b>	<b>11</b>
5.1	Controls .....	11
<b>6</b>	<b>MAINTENANCE .....</b>	<b>12</b>
6.1	Cleaning .....	12
6.1.1	Welding power source .....	12
6.1.2	Contactors .....	12
<b>7</b>	<b>ORDERING SPARE PARTS .....</b>	<b>13</b>
	<b>DIAGRAM .....</b>	<b>14</b>
	<b>CONNECTION INSTRUCTION .....</b>	<b>18</b>
	<b>ORDERING NUMBERS .....</b>	<b>19</b>

# 1 SAFETY

## 1.1 Meaning of symbols

As used throughout this manual: Means Attention! Be Alert!

**DANGER!**

Means immediate hazards which, if not avoided, will result in immediate, serious personal injury or loss of life.

**WARNING!**

Means potential hazards which could result in personal injury or loss of life.

**CAUTION!**

Means hazards which could result in minor personal injury.

**WARNING!**

Before use, read and understand the instruction manual and follow all labels, employer's safety practices and Safety Data Sheets (SDSs).



## 1.2 Safety precautions

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
  - its operation
  - location of emergency stops
  - its function
  - relevant safety precautions
  - welding and cutting or other applicable operation of the equipment
2. The operator must ensure that:
  - no unauthorised person is stationed within the working area of the equipment when it is started up
  - no-one is unprotected when the arc is struck or work is started with the equipment
3. The workplace must:
  - be suitable for the purpose
  - be free from drafts

4. Personal safety equipment:
  - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves
  - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns
5. General precautions:
  - Make sure the return cable is connected securely
  - Work on high voltage equipment **may only be carried out by a qualified electrician**
  - Appropriate fire extinguishing equipment must be clearly marked and close at hand
  - Lubrication and maintenance must **not** be carried out on the equipment during operation

**WARNING!**

Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting.

**ELECTRIC SHOCK - Can kill**

- Install and ground the unit in accordance with instruction manual.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from work and ground.
- Ensure your working position is safe

**ELECTRIC AND MAGNETIC FIELDS - Can be dangerous to health**

- Welders having pacemakers should consult their physician before welding. EMF may interfere with some pacemakers.
- Exposure to EMF may have other health effects which are unknown.
- Welders should use the following procedures to minimize exposure to EMF:
  - Route the electrode and work cables together on the same side of your body. Secure them with tape when possible. Do not place your body between the torch and work cables. Never coil the torch or work cable around your body. Keep welding power source and cables as far away from your body as possible.
  - Connect the work cable to the workpiece as close as possible to the area being welded.

**FUMES AND GASES - Can be dangerous to health**

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

**ARC RAYS - Can injure eyes and burn skin**

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

**NOISE - Excessive noise can damage hearing**

Protect your ears. Use earmuffs or other hearing protection.

**MOVING PARTS - Can cause injuries**

- Keep all doors, panels and covers closed and securely in place. Have only qualified people remove covers for maintenance and troubleshooting as necessary. Reinstall panels or covers and close doors when service is finished and before starting engine.



- Stop engine before installing or connecting unit.
- Keep hands, hair, loose clothing and tools away from moving parts.

**FIRE HAZARD**

- Sparks (spatter) can cause fire. Make sure that there are no inflammable materials nearby.
- Do not use on closed containers.

**MALFUNCTION - Call for expert assistance in the event of malfunction.**

**PROTECT YOURSELF AND OTHERS!****CAUTION!**


This product is solely intended for arc welding.

**WARNING!**

Do not use the power source for thawing frozen pipes.

**CAUTION!**

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.

**NOTE!****Dispose of electronic equipment at the recycling facility!**

In observance of European Directive 2012/19/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.



**ESAB has an assortment of welding accessories and personal protection equipment for purchase. For ordering information contact your local ESAB dealer or visit us on our website.**

## **2 INTRODUCTION**

---

TAF 801 is a remote-controlled, two-phase AC welding power source designed for high-throughput, mechanised submerged-arc welding (SAW).

The welding power source converts, via a thyristor bridge-rectifier, the secondary voltage's sine wave to a square wave with excellent arc ignition and welding characteristics.

The welding power source is fan cooled and is overload protected by a thermal cut-out. Re-setting takes place automatically as soon as the temperature has reduced to a permitted level.

### 3 TECHNICAL DATA

	<b>TAF 801</b>
<b>Voltage</b>	346/380/400/415/500 V $\pm$ 10%, 1~50 Hz 440/550 V $\pm$ 10%, 1~60 Hz
<b>Primary current</b>	$I_{\max}$ 147 A
<b>Permissible load at:</b>	
100 % duty cycle	800 A / 44.0 V
<b>Setting range</b>	300 A/32.0 V - 800 A/44.0 V
<b>No-load voltage</b>	70 V
<b>No-load power</b>	214 W
<b>Efficiency</b> at maximum current	84%
<b>Power factor</b> at maximum current	0.83
<b>Apparent power</b> at maximum current	50.7 kVA
<b>Active power</b> at maximum current	42.2 kW
<b>Operating temperature</b>	-10 °C to +40 °C (+14 °F to +104 °F)
<b>Weight</b>	495.0 kg (1091.3 lb)
<b>Dimensions L x W x H</b>	774 × 598 × 1228 mm (30.47 × 23.54 × 48.35 in.)
<b>Insulation class (transformer)</b>	<b>F</b>
<b>Enclosure class</b>	IP23
<b>Application class</b>	<b>S</b>

#### Enclosure class

The **IP** code indicates the enclosure class, i.e. the degree of protection against penetration by solid objects or water.

Equipment marked **IP23** is intended for indoor and outdoor use.



## 4 INSTALLATION

The installation must be carried out by a professional.


**NOTE!****Mains supply requirements**

High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see "TECHNICAL DATA" chapter). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.


### 4.1 Location

**WARNING!**



Secure the equipment - particularly if the ground is uneven or sloping.




- Place the welding power source on a level foundation.
- Make sure there is nothing to prevent the cooling.

**Lifting instructions**

## 4.2 Connections

- On delivery the welding power source is connected for 400 V. For other supply voltage, switch over to the desired voltage on the main transformer and the control transformer according to the connection instructions in "CONNECTION INSTRUCTION" chapter.
- Make sure the mains cable has the right sectional area and fuse it with an adequate fuse according to applicable local directions (see table below in "Mains connection" section).
- Connect the earth cable to the screw marked .
- Connect the mains cable to the main terminal blocks L1 and L3.
- Tighten the cable support (1).
- Connect the control cable between the welding power source and the control unit to the 28-pole contact (2) inside the welding power source.
- Connect the 1-pin measuring cable (4) for measuring the arc voltage to the return cable/welding head.
- Connect a suitable welding and return cable to the contacts (3) marked  on the front of the power source.



### Mains connection

TAF 801	50 Hz				60 Hz	
Voltage (V)	346 ± 10%	380 ± 10%	400/415 ± 10%	500 ± 10%	440 ± 10%	550 ± 10%
Phase current $I_{1eff}$ (A)	147	134	127	102	127	102
Cable area (mm <sup>2</sup> )	2 × 70 + 35	2 × 70 + 35	2 × 70 + 35	2 × 50 + 35	2 × 70 + 35	2 × 50 + 35
Fuse, slow (A)	160	160	160	125	160	125



#### NOTE!

The mains cable areas and fuse sizes as shown above are in accordance with Swedish regulations. For other regions, supply cables must be suitable for the application and meet local and national regulations.

## 5 OPERATION

General safety regulations for handling the equipment can be found in the "SAFETY" chapter of this manual. Read it through before you start using the equipment!


**NOTE!**


**Never** use the welding power source without side plates.


**NOTE!**

The power source must be set to analogue mode to use the PEI control unit.

### 5.1 Controls

The front panel contains:



1.		<p>Main circuit-breaker for switching the mains voltage and the fan on and off in the welding power source.</p> <ul style="list-style-type: none"> <li>• Position "1" On</li> <li>• Position "0" Off</li> </ul>
2.		<ul style="list-style-type: none"> <li>• The indicator lamp (white) illuminates when the main switch is switched on.</li> </ul>
3.		<p>Indicator lamp for overheating (yellow)</p> <ul style="list-style-type: none"> <li>• The indicator lamp illuminates when the thermal cutout is deployed due to excess temperature in the welding power source.</li> <li>• The indicator lamp goes out when the temperature in the welding power source has decreased to a permitted level.</li> </ul>
4.		<p>Pushbutton resetting the automatic fuse FU2 for 42 V supply voltage.</p>

## 6 MAINTENANCE

---



### CAUTION!

All warranty undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the warranty period.

### 6.1 Cleaning

#### 6.1.1 Welding power source



### WARNING!

Blocked air inlets or outlets will lead to overheating.

- Clean the welding power source as necessary.  
Dry compressed air is recommended for the purpose.

#### 6.1.2 Contactor



### WARNING!

Never use compressed air to clean the contactor without first taking it apart completely.



### NOTE!

To ensure the reliable operation of the contactor, the magnetic parts must be kept clean.

If the contactor has to be cleaned it **must** be taken apart, and all the pieces be cleaned.

Alternatively, the contactor can be replaced.

## 7 ORDERING SPARE PARTS

---



### CAUTION!


Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.


**TAF 801 is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.**

Spare parts and wear parts can be ordered through your nearest ESAB dealer, see [esab.com](http://esab.com). When ordering, please state product type, serial number, designation and spare part number in accordance with the spare parts list. This facilitates dispatch and ensures correct delivery.


# DIAGRAM

Valid for serial no. 935-xxx-xxxx







Valid for serial no. 126-xxx-xxxx







# CONNECTION INSTRUCTION



---

## ORDERING NUMBERS

---



Ordering number	Denomination	Type	Notes
0460 516 880	Welding power source	TAF 801	
0459 839 062	Spare parts list	TAF 801	

The spare parts list is published in a separate document that can be downloaded from the Internet: [www.esab.com](http://www.esab.com)



# A WORLD OF PRODUCTS AND SOLUTIONS.



For contact information visit [esab.com](http://esab.com)

<http://manuals.esab.com>



CE

