



**Ventilation Inserts & Liners
Use & Care Manual
Intended for Residential Cooking Only**

READ AND SAVE THESE INSTRUCTIONS

**Models covered by these instructions:
UIB, UIBTF, CMUIB, UIM**

Installer: Leave this manual with homeowner.

Homeowner: Use and Care information inside.

Prestige America Ltd.
25 Riverside Dr. Suite 4
Pine Brook, NJ 07058

-Table of Contents -

Important Safety Instructions.....	1-2
Handling Precautions.....	2
Important Ventilation Information Before You Begin.....	2
Accessories Sold Separately.....	3
Cleaning and Maintenance.....	3
Packing List for your Inserts	
a) UIB Inserts with Blowers.....	3-4
b) UIB Liners without Blowers.....	4
c) UIM Inserts.....	5
d) UIBTF & CMUIB Inserts without Blowers.....	5
Rear ducting Instructions.....	10
Instructions for connection of Wall Switch Kit (UIBWSK)	10
Installation Guide for your Insert.....	11-12
Hood Operating Instructions.....	13
Warranty Information.....	14

Prestige Products Division
Signature Marketing Group Ltd.
25 Riverside Drive Suite 4
Pine Brook, NJ 07058
800-358-8886

-Important Safety Instructions-

PRESTIGE® INSERTS ARE FOR RESIDENTIAL USE ONLY!

CAUTION: FOR GENERAL VENTILATION USE ONLY. DO NOT USE TO EXHAUST HAZARDOUS OR EXPLOSIVE MATERIALS OR VAPORS.

1. Use this unit only in the manner intended by the manufacturer. (If you have questions, contact Prestige® at 800-358-8886.)
2. Before servicing or cleaning this unit, switch power off at service panel and lock the panel to prevent power from being switched on by accident. When the service panel cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.

WARNING: TO REDUCE THE RISK OF RANGE TOP GREASE FIRE, PLEASE OBSERVE THE FOLLOWING:

1. Never leave surface units unattended at high settings. Boil-overs can cause smoking and may ignite. Heat oils slowly on low heat.
2. Always turn ventilation system ON five minutes prior to cooking to begin airflow.
3. Clean ventilation filters frequently. **DO NOT ALLOW GREASE TO ACCUMULATE ON FAN OR FILTER.**
4. Use proper pan size. Always use cookware appropriate for the size of the burner or element.

-Important Safety Instructions-

WARNING - IN THE EVENT OF RANGE TOP GREASE FIRE, OBSERVE THE FOLLOWING:

1. Smother the flames with a close fitting lid, cooking sheet or other metal tray, and then turn off the burner. **BE CAREFUL TO PREVENT BURNS.** If the flames do not go out immediately, **EVACUATE AND CALL THE FIRE DEPARTMENT.**
2. **NEVER PICK UP A FLAMING PAN.**
3. **MAKE SURE YOUR VENTILATION SYSTEM IS COMPLETELY TURNED OFF. DO NOT TURN HOOD ON TO TRY AND EVACUATE SMOKE.**
4. **DO NOT USE WATER,** including wet dishcloths or towels - a violent steam explosion may result.
5. Use an extinguisher only if:
 - a) You know you have a class ABC extinguisher and you already know how to operate it.
 - b) The fire is small and contained in the area where it started.
 - c) The fire department is being called.
 - d) You can fight the fire with your back to an exit.

- Handling Precautions -

- Remove all rings, watches, belt buckles, jewelry and any clothing with metal buttons or snaps to prevent damage to the Insert.
- **DO NOT REMOVE INSERT FROM ITS ORIGINAL CARTON UNTIL YOU ARE READY TO INSTALL IT.**
- When you are ready to begin the installation process, remove the insert from its carton and place it on a clean soft blanket.
- Inspect the insert carefully for any damage or imperfections before you begin to install the insert. If any damage or imperfections exist, re-carton the insert and call your dealer IMMEDIATELY, do not install a damaged hood.
- It is highly recommended that rubber gloves be used to prevent scratches on the insert and to provide you with a firm grip.
- **When removing the insert from the carton locate the filters. The filters are not pre-installed in the insert. The filters are in a box marked filters, inside the insert carton.**
- Internal blower inserts can be ducted to the top or the rear. Check product guide for additional transitions, wall caps and roof caps.
- Duct size for units ending in 600 is 6" round and an optional transition model TRC8/6 should be used to increase the duct size to 8" round for optimal performance.
- Units with model numbers ending in 1200 require the use of transition model TR6x15/10 (NOT INCLUDED AND SOLD SEPERATELY).
- All Prestige® ventilation inserts have a variable speed blower switch as well as a light dimmer switch.
- Inserts can be set up for ductless applications. See product guide for optional ductless conversion kits.

-Important Ventilation Information Before You Begin-

The desired installation height of the insert is at the discretion of the user, however, a height of 30" to 36" above the cooking surface is recommended. Two persons are required to install insert.

Before installing your insert, be sure to read the following!

Prestige® inserts are designed to utilize internal, in-line, or remote blowers. Other blowers CANNOT be substituted. Select the series best suited for your application. Units labeled "NB" are for use with in-line blowers or remote blowers. Units labeled "600" or "1200" come with pre-installed 600 or 1200 CFM motors. Before installing ANY unit, inspect and test blowers to ensure there is no packing or obstructions remaining in the unit and that blower(s) spin freely.


The custom hood frame must be sized to the shape and total weight of the insert assembly. (See hood liner/insert dimension guide.) Run power cable to the installation location. Stub out a 4-foot length of electrical cable behind the custom hood. DETERMINE WHETHER OR NOT THE USE OF A WALL SWITCH IS NEEDED. A 3" to 4" recess should be provided to allow for a proper capture area. If the cooking product contains a grill (BBQ), a minimum of 6" additional capture area should be provided. The custom hood depth should be at least 19" minimum for common gas or electric cooktops. A 24" depth is to be provided for use with pro-style ranges, whether dual fuel or all gas. If the cooking appliance contains a grill (BBQ) or a high output wok or griddle, the use of an in-line blower or remote blower is highly recommended.

NOTE TO INSTALLER: To avoid damage that will not be covered under warranty make sure blowers are free from obstructions (packing and debris) prior to running blowers. Test run blowers before finalizing installation. Check with manufacturer before attempting to use other than Prestige® blower systems. (800.358.8886 for technical information)

-Cleaning and Maintenance-

Be sure lights are cool before cleaning your insert. Your insert will not function properly if not cleaned regularly and maintained properly. Clean the filters regularly (at least twice a month or every 24 hours of use) by soaking them in soapy water and rinsing them in the dishwasher at the normal cycle. When the filters are removed the accessible interior can be cleaned of grease, again using only soap and water. Burned out halogen light bulbs are exchanged in the same way as normal light bulbs. Make sure to replace them with the same type and wattage (replacement bulbs are Par 16, 60 watt, halogen 115 volt) Make it a habit to turn on the insert on low speed even when you are boiling water. **Do not use abrasive or aggressive chemicals!** Check the outside end of the duct at least once a year. Make sure that the back draft damper (sold separately) hinges are free of grease and move easily. If you have an insect screen installed in the duct termination, make sure that it is not broken or dislocated. Filters are dishwasher safe or you may hand wash them with warm soapy water.

- 1) Turn the fan and lights off.
- 2) Push the filters towards the top and extract downward.
- 3) When placing filters into the dishwasher be sure that the filters are angled.
- 4) Drain water and let each filter dry before replacing.



-Accessories Sold Separately-

- In-line blowers IL600, IL1200 and IL1600
- Remote blowers, RB1000, RB1200, RB1600, RB2000
- Transitions TR6x15/8, TR6x15/10 (for use with 1200 blower system), TRC8/6 transition collar (for use with 600 blower)
- Wall Caps, WC6HD, WC8HD, WC10HD. The WC6x15/HD is for use with the 1200 blower system when rear ducting.
- Roof Caps RC6 and RC10 will accommodate 6" to 10" round duct sizes.
- Backdraft damper BD8 or BD10 (in-line 8" or 10" section duct with backdraft damper installed.)
- Wall switch kit UIBWSK controls both lights and fan(s) in lieu of unit switches.

INSPECT ALL MOLDED PACKING AND BOXES FOR PARTS BEFORE DISCARDING. ANY DAMAGE MUST BE REPORTED BEFORE INSTALLING THE HOOD. ONCE THE HOOD HAS BEEN INSTALLED, NO RETURN WILL BE ACCEPTED.

-Packing List for UIB Insert-

UIB20-600, UIB26-600 UIB30-600 UIB28-600

Blower Pre-Installed in Unit

One (1) Stainless Steel Baffle Filter

Two (2) Pre-Installed Lights

Lid for Electrical Box

UIB34-600

Blower Pre-Installed in Unit

Two (2) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

UIB34-1200, UIB40-1200

Two (2) Blowers Pre-Installed in Unit

Two (2) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

Transition required and NOT supplied (sold separately)

UIB46-1200, UIB52-1200, UIB58-1200

Two (2) Blowers Pre-Installed in Unit

Three (3) Stainless Steel Baffle Filters

Three (3) Pre-Installed Lights

Lid for Electrical Box

Transition required and NOT supplied (sold separately)

UIB58S2 includes two (2) Filter Spacers

-Packing List for UIB Hood Liner-

UIB28-NB

One (1) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

Starter Collar Included

UIB34-NB, UIB40-NB

Two (2) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

Starter Collar Included

UIB46-NB, UIB52-NB, UIB58-NB

Three (3) Stainless Steel Baffle Filters

Three (3) Pre-Installed Lights

Lid for Electrical Box

Starter Collar Included

UIB58-NB includes two (2) Filter Spacers

-Packing List for UIBTF or CMUIBTF Hood Liner-

UIBTF34-NB, UIBTF40-NB

Four (4) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

UIBTF48-NB, UIBTF58-NB

Six (6) Stainless Steel Baffle Filters

Three (3) Pre-Installed Lights

Lid for Electrical Box

UIBTF580WC15 includes two (2) Filter Spacers

CMUIBTF34-NB, CMUIBTF40-NB

Four (4) Stainless Steel Baffle Filters

Two (2) Pre-Installed Lights

Lid for Electrical Box

CMUIBTF48-NB, CMUIBTF58-NB

Six (6) Stainless Steel Baffle Filters

Three (3) Pre-Installed Lights

Lid for Electrical Box

CMUIBTF580WC15 includes two (2) Filter Spacers

-Rear Ducting Instructions-

In some cases, you will not be able to duct the unit to the top. In that case, rear ducting is necessary.

- 1) Lay insert on its face on top of a soft, non-abrasive blanket.
- 2) Remove the screws from the L-bracket on the blower assembly. DO NOT LOSE SCREWS.
- 3) Disconnect motor wires from terminal block.
- 4) Flip the unit so the exit hole is facing the back of the unit.
- 5) Re-apply the screws to the L-bracket on the blower assembly.
- 6) Be sure that your unit is secure and in place and available for ducting through the back.

-Instructions for connection of optional Wall Switch Kit (UIBWSK)-

- 1) Disconnect wires from Fan and Light switches from the wiring harness supplied with your insert.
- 2) Connect Fan and Light switches to harness supplied with Prestige® wall switch kit
- 3) Make all electrical connections between supplied harness and wires for wall switch inside of insert electrical box
- 4) Before hanging your hood and wall switch kit, be sure that the connections made are fully operational.

Be sure to have a licensed electrician make all connections to prevent from electric shock. By using a Wall Switch Kit you will render the on-board controls on your ventilation hood non-operational.

-Installation Guide-

NOTE: During installation, protect countertop and/or cooking appliances.

- 1) Choose an installation height that is comfortable for the user. IMPORTANT: Most building codes require a 30" minimum clearance from the top of a surface burner to the underside of any combustible material.
- 2) Choose the appropriate cutout dimension from the cutout dimension section (page 13). Mark the underside of the wood hood, alcove, or hearth making sure you leave adequate clearance for the stainless steel trim overlay and body of the hood liner. Cut along your marked line.
- 3) Caution: SWITCH POWER OFF AT SERVICE PANEL. Insert 115-volt line through the 7/8" hole that is punched through the back of the unit and attach with the appropriate ROMEX or BX connector.
- 4) Attach the metal duct to the unit either directly to the collar provided or by using a duct transition. See chart B. NOTE: USE RIGID METAL DUCTWORK ONLY. DO NOT ATTEMPT TO USE FLEXIBLE DUCT OR PLASTIC DUCT. FLOW RESTRICTIONS AND GREASE BUILD UP WILL OCCUR.
- 5) Lift hood liner into position. Fasten to underside of the wood hood, alcove or hearth with appropriate fastener. Make certain the unit is fastened securely to prevent vibration.

A licensed electrician should make all electrical connections

- 6) Complete the electrical connection in the junction box inside the insert. If equipped with internal fan check to be certain that the fan blade turns freely by hand and there are no packing materials or other obstructions in the motor housing. Also, make sure light bulbs are tightly screwed into sockets.
- 7) Install stainless steel filters by sliding filters into the top channel then down into the lower channel.
- 8) Turn power on at service panel.

-Cutout Dimensions-

Use the below dimensions to make the cutout for your Prestige®

Model#	Width	Depth
UIB28-600	25 1/8"	13 5/8"
UIB34-600	31 1/8"	13 5/8"
UIB34-1200	31 1/8"	13 5/8"
UIB40-1200	37 1/8"	13 5/8"
UIB46-1200	44 5/8"	16 5/8"
UIB52-1200	50 5/8"	16 5/8"
UIB58-1200	56 5/8"	16 5/8"
UIB28-NB	25 1/8"	13 5/8"
UIB34-NB	31 1/8"	13 5/8"
UIB40-NB	37 1/8"	13 5/8"
UIB46-NB	44 5/8"	16 5/8"
UIB52-NB	50 5/8"	16 5/8"
UIB58-NB	56 5/8"	16 5/8"
UIBTF34	32 3/4"	21 1/4"
UIBTF40	38 3/4"	21 1/4"
UIBTF46	44 3/4"	21 1/4"
UIBTF52	50 3/4"	21 1/4"
UIBTF58	56 3/4"	21 1/4"
CMUIBTF34	32 3/4"	21 1/4"
CMUIBTF40	38 3/4"	21 1/4"
CMUIBTF46	44 3/4"	21 1/4"
CMUIBTF52	50 3/4"	21 1/4"
CMUIBTF58	56 3/4"	21 1/4"

-Installation of In-Line or Remote blower-

Using the harness supplied with your Prestige® in-line or remote blower, plug into connector located near insert finger guard. Make all connections between supplied harness and wiring connected to the blower using wire nuts (not included) inside of insert electrical box.

-Hood Operating Instructions-

The blower should be turned on for about 5 minutes BEFORE cooking in order to establish air currents upward through the insert. Use low speeds for normal use and the higher speeds for strong odors or fumes. Minimize drafts across the range or cooktop, they will reduce the effectiveness of the insert.

Warranty Information

Prestige® will warranty all parts and related labor to replace them for a term of one (1) year. The one (1) year warranty period applies to the actual parts and NORMAL labor and excludes all other costs, removal and re-installation.

One-year service repair warranty:

During the first year from date of original purchase, Prestige® will, at its option, repair or replace, without charge, any product or part which is found to be defective under normal use and service.

Who is covered?

Prestige® warrants to the ORIGINAL CONSUMER PURCHASER of its products that such products will be free from defects in materials and workmanship for a period of one (1) year from the original date of purchase. There are no other warranties, express or implied, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose or application.

What is NOT covered?

Items NOT covered in the warranty include: light bulbs, items fabricated to customer design, consequential damage, removal and re-installation, abnormal travel outside the service area, including but not limited to: remote area transport, ferries or excessive mileage. If any of these situations apply, the customer will be responsible for payment in full and said exclusion.

For any questions or concerns please contact the following:

Prestige America Ltd.

25 Riverside Dr. Suite 4

Pine Brook, NJ 07058

800-358-8886