





GULLABERG



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.






DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.





109048

2x




10087223

2x




109049

1x




100823

2x



1x

10102070



106989


1x

370173


1



18x



4x




30x



36x




4x




2x




4x




14x




4x




4x



4x




1x




10108520


2




18x




18x



10x



18x




10x




36x



36x





4x




1x


1




2




3




4




5




6




7




8




9




10




11




12




13




14









16






2x




17




4x




18




19




20




21




22




23




24




25




26




27





28




29




30






31




32




33






34







35








36



37








www.IKEA.com/secure-it



www.IKEA.cn/secure-it




39

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")





1




2







40




41













43




44




45












46





47




48




49




50




51







52





53









57

