

AC Nio Elevator Control Guide

Introduction

This guide goes over how to configure ACS-ELV elevator control panels on the AC Nio™ software, including adding hardware and programming.

These instructions are focused on elevator control. For instructions on initial software, hardware, and account setup, as well as other settings, see these links:

AC Series Quick Start Guide: <https://www.aiphone.com/ACSeriesQuickStartGuide>

AC Series Programming YouTube Playlist: <https://www.aiphone.com/ac-video-guide>

Adding an Elevator Panel


Make sure that the ACS-ELV control panel is connected to the same network as the PC or host running AC Nio. Configure the hardware to be in the same IP range. See the YouTube playlist linked above for assistance with this process.

Log into AC Nio™ on the host or PC. A pop-up may appear indicating that a new panel was discovered. This message can be clicked to bring up a menu to add the panel. If it does not, navigate to **Hardware**, **Panels** on the left menu. Click **+Add** in the top right corner.



On the new page, set the **Panel Model** to ACS-ELV. Assign the panel a **Name**. Use the drop-down menu next to **Site** to assign the elevator to a site. If it has not already been discovered, add in the panel's **MAC Address**. Add in the **Panel Password**. Check off whether the panel is installed, whether the tamper sensor is being used, and how many AC-IOE expanders have been installed. There will always be at least one expander included with the ACS-ELV.


Under **TCP Connection**, either leave the **Connection Mode** set to DHCP, or set the network information manually. This should match the mode used on the main panel. Once everything is filled out, click **+Create**.



Adding Elevators to a Panel

Once the initial settings on the panel are complete, elevators will need to be added. Each elevator represents a single elevator cab and the individual floors it reaches.

Navigate to **Hardware**, **Elevators** on the left menu. Click **+Add** in the top right corner.




Give the elevator a **Name**. Use the drop-down menu to assign the elevator to the newly created **Panel**. If **Button Sensing** will be used, check off that box. Button sensing configures the ACS-ELV to react to outputs from the elevator buttons themselves. These will need to be directly wired into inputs on one of the expansion boards.

A screenshot of the 'Add Elevator' form in a web application. The form has a title bar 'Elevators > Add Elevator' and a section header 'Elevator'. It contains four fields: 'Name' with the value 'Main Building', 'Description' with the placeholder 'Optional Description', 'Panel' with a dropdown menu showing 'Main Building', and 'Button Sensing' with an unchecked checkbox. A 'Clear' button is at the bottom left. An orange box highlights the 'Name', 'Description', 'Panel', and 'Button Sensing' fields.


Assign a **Starting Floor Number** and set the number of floors. The equipment included with the ACS-ELV will support a single elevator with eight floors. With the maximum number of expanders, an ACS-ELV panel can support one elevator with 64 floors or two elevators with up to 32 floors each.

Once everything is configured, click **+Create**. Click **+Add Another** to repeat the process and add more elevators, or click **+Continue Configuration** to set up the newly created elevator.

A screenshot of the 'Floors' configuration form. It has a section header 'Floors' and two input fields: 'Starting Floor Number' with the value '1' and 'Number of Floors' with the value '8'. An orange box highlights these two fields. At the bottom right, there is a blue button labeled '+ Create' with an orange arrow pointing to it.

Configuring an Elevator

If **+Continue Configuration** was clicked on the last screen, the **General** settings page for the elevator will open. The settings can also be reached under **Hardware**, Elevators on the left menu. An elevator can be selected from the list by clicking its gear symbol.



Below is a list of functions available under the **General** menu. Once all setting are configured, click **Save**.

Setting	Function
Associated Panel	Click View Panel to navigate to the panel settings
Name	Displays the name of the elevator. This can be changed.
Description	Optional descriptive text for the elevator.
Button Sensing	If a floor button in the elevator cab is directly connected to an input on the ACS-ELV, this allows different features in AC Nio™ software to be activated.
Button Delay	Sets how long the elevator's floor buttons are enabled after a credential is presented.
Relay Pulse Time	How long a programmed relay will activate once access is granted to a particular floor or group of floors.
Invert Inputs	Change inputs associated with the elevator from normally open to normally closed.
Outputs Normally Closed	Change outputs associated with the elevator from normally open to normally closed.

Configuring an Elevator (continued)

The **Floors** page sets the schedules related to each floor. The settings are described below. Click the green disc to save any changes.

The screenshot shows the 'Floors' configuration page. At the top, there is a 'Create Floor' button and a '+ Add' button. Below is a table with the following columns: 'Disabled' (checkbox), 'Floor' (number), 'Name' (text), 'Schedule' (dropdown), and 'Holiday Group' (dropdown). The table contains 8 rows for floors 1 through 8. Each row has a checkbox for 'Disabled', a floor number, a name, a schedule dropdown (all set to 'Card Always'), and a holiday group dropdown (all set to 'Default Holiday Group'). A green disc icon with a plus sign is visible in the top right corner, and an orange hand cursor is pointing at it.

Setting	Function
Create Floor	Add a new floor to the system. Requires a floor number and name.
Disabled	Disables all settings on a floor.
Floor	Displays the floor number of the elevator.
Name	Displays the name of the elevator. This can be changed from this menu.
Schedule	Use the drop-down menu to assign a schedule to the floor. These are configured under Scheduling , <i>Schedules</i> , <i>Floors</i> . See the AC Nio™ software's Quick Start Guide or the video playlist linked on page 1 of this guide for instructions on configuring new schedules.
Holiday Group	Use the drop-down menu to assign a holiday group to the floor. See the AC Nio™ Quick Start Guide or video playlist linked on page 1 of this guide for instructions on configuring new holiday groups.
Red X symbol	Delete a floor and all associated settings.

Configuring an Elevator (continued)

The **Reader** menu configures a card reader associated with the elevator cab, usually mounted inside of it. The settings are described below. Once all setting are configured, click **Save**.

Reader

Enabled

☐

Name

Reader Port

Port 4

Action

No Action

Perform action only on Access Granted

☐

Undo

Save

Setting	Function
Enabled	Enable or disable the reader.
Name	Enter a name for the reader.
Reader Port	Select which port on the panel the reader will connect to.
Action	Selects which action is initiated when the reader is scanned. Click the pen symbol to the right to choose from a list of available actions.
Perform Action Only On Access Granted	Sets the action to only activate if a valid credential is selected.

The **Camera Association** menu allows a camera from an associated camera system to be assigned to the elevator. Use the drop-down menu to select a camera system, then place a check next to the desired camera. Only one camera can be selected. Click **Save** to confirm.

Camera Association

Camera System

Office Camera System

Associated

Camera Name

☐

DWC-INTCAM02

☐

AXISPR231

☐

Body Cam Badge Number 227

☐

DWC-MB45IALPT

☐

DWC-MB4BWAT

☐

DWC-MB4BWATW

☐

DWC-MB4RWI2TW

☐

DWC-MF5WIATW

☐

DWC-MPT2230XTW


☐

DWC-MT95WATW(8)


0 of 14 Selected

Configuring a Panel

Once at least one elevator is added, other settings on the panel can be configured. Navigate to **Hardware**, Panels on the left menu. Select the panel from the list by clicking the gear symbol.




This will open the **General** page. The available settings are described on the next page. Once all settings are configured, click **Save**.



Configuring a Panel *(continued)*

Setting	Function
Name	How the panel is labeled under Hardware , <u>P</u> anels.
Description	Information text about the panel. Optional.
MAC Address	The panel's MAC address. Only change this if the panel's hardware is replaced.
Panel Password	The panel hardware's password. Setting a new panel here and uploading it will also change this on the panel's interface itself.
Installed	A check mark that shows whether or not the panel has been installed.
Expanders	Sets the number of AC-IOE expander boards installed on the ACS-ELV.
Auto Firmware Update	Set AC Nio™ software to automatically push firmware updates to the panel.
Update Priority	This sets the panel's priority to receive settings uploads when multiple panels are updated at once.
Running Mode	Sets whether the panel is operating normally or in debug mode.

On the **Connectivity** page, the network settings of the panel can be set. By default, the panel uses DHCP for its **Connection Mode**, which can be changed over to using a static IP address. An **Override Server Address** can also be set to for hosts and panels that may need multiple paths to connect to each other. Once all settings are configured, click **Save**.



TCP Connection

Connection Mode: Automatic (DHCP) ▼

Override Server Address:

Under specific circumstances it may be required to override one or more panel's server addresses to avoid reverse NAT lookups. In most cases we recommended leaving this field empty and using the primary server address under system configuration. Any value entered in this field will take precedence over the global server address field but only for this panel. This value may be a DNS name or IP address.

Undo Save

Configuring a Panel (continued)

The **Option** page shows various settings for the panel hardware itself. The options are described below. Once all settings are configured, click **Save**.

LCD

Backlight Mode

Automatic

Backlight Duty

50

Backlight On Time

120 s

Undo

Tamper Sensor

Enabled

☒

Sensitivity

30

Save

Setting	Function
Backlight Mode	Sets the behavior for the backlight on the panel's LCD display. The options are for it to activate automatically, to be on, or be off.
Backlight Duty	Sets how bright the backlight is, measured from 0 to 100.
Backlight On Time	How long the backlight will activate when automatically engaged, measured in seconds.
Enabled	Enables or disables the tamper sensor on the panel.
Sensitivity	Sets the sensitivity of the tamper sensor. The default setting is 30 on a scale from 0 to 255.

Configuring a Panel *(continued)*

Settings for each input and output are configured on the **I/O** page. Click on an input or output to display the available options, which are described below. Once all settings are configured, click **Save** at the bottom of the page.

The screenshot shows the 'I/O' configuration page. At the top, there's a tab labeled 'I/O' and buttons for 'Import' and 'Export'. Below this is a dropdown menu for 'I/O-Expander' with '1' selected. The main area displays a list of inputs, each with a green diamond icon and a label 'Elevator Button'. The inputs are numbered 1-1 through 1-7. To the right of the list, a detailed configuration panel for 'Input 1-1' is shown. This panel includes fields for 'Name' (input 1-1), 'Function' (Elevator Button), 'Detection Time' (0), 'Schedule' (No Schedule), 'Holiday Group' (No Holiday Group), 'Options' (Supervised, Normally Closed, Send Events), 'Action' (No Action), and 'Secondary Action' (No Action). Each field has a corresponding edit icon.

Shared Settings	Function
I/O Expander	Select which expansion board to display.

Input Settings	Function
Name	Enter a name for the input.
Function	Select the desired function for the input.
Detection Time	Set how long the contact closure needs to last before the input is triggered.
Schedule	Applies a schedule to the input.
Holiday Group	Applies a holiday schedule to the input.
Options	Toggle on or off with the check boxes. Supervised: indicates whether resistors are in place to detect tampering. Off by default. Normally Closed: change the input from normally open to normally closed. Send Events: set whether events are generated when the input is triggered.
Action	Choose from a list of available actions.
Secondary Action	Choose an additional action from a list of available actions.

Output Setting	Function
Name	Enter a name for the output.
Function	Select the desired function for the output from a list of options.
Options	Toggle options on or off with the check boxes. Normally Closed: change the input from normally open to normally closed. No Events: change whether events are generated when the output is triggered.

Configuring a Panel (*continued*)

The **Floor I/O Map** page displays the expanders and the names and statuses of all of the floors assigned to them. There are no settings to configure on this page.

General			
Output	Status	Elevator	Floor
Expander 1			
Elevator: Main Building			
Address: 1			
1	Enabled	Main Building	[1] Floor 1
2	Enabled	Main Building	[2] Floor 2
3	Enabled	Main Building	[3] Floor 3
4	Enabled	Main Building	[4] Floor 4
5	Enabled	Main Building	[5] Floor 5
6	Enabled	Main Building	[6] Floor 6
7	Enabled	Main Building	[7] Floor 7
8	Enabled	Main Building	[8] Floor 8
Expander 2			
Elevator: Service Elevator			
Address: 2			
1	Enabled	Service Elevator	[1] Floor 1
2	Enabled	Service Elevator	[2] Floor 2
3	Enabled	Service Elevator	[3] Floor 3
4	Enabled	Service Elevator	[4] Floor 4
5	Enabled	Service Elevator	[5] Floor 5
6	Enabled	Service Elevator	[6] Floor 6
7	Enabled	Service Elevator	[7] Floor 7
8	Enabled	Service Elevator	[8] Floor 8

Configuring a Panel *(continued)*

Settings related to card credentials are adjusted on the **Card Formats** page. The options are described below. Once all settings are configured, click **Save**.

Card Settings

- ☐ Use Fixed Site Code of 60000
- ☐ Remap Site Code 0 to 60000
- ☐ Suppress Invalid Card Format Events
- ☐ Suppress Unknown Card Format Events

Card Formats

Multicard format is enabled. If required by your site our readers and controllers support a wide variety of card formats but in the case of overlapping formats you may need to specify your preferred format. Your software license must also be configured to allow multiple card formats. If your license does not have multi card enabled, and you believe it is required, please contact your dealer/installer.

☐ Override Site's card format settings

Format	Site Code
Standard Format	Alpha (40 bit)
26 Bit Format	ISO 256K (Industry Standard)
32 Bit Format	Korbeck
33 Bit Format	Site
34 Bit Format	ISO Standard
35 Bit Format	Academy
36 Bit Format	Keycard Reader
37 Bit Format	ISO 2711 F301
38 Bit Format	Korbeck 301
48 Bit Format	ISO 10646/4
50 Bit Format	ISO
75 Bit Format	Common Access Card

Undo Save


Card Settings	Function
Use Fixed Site Code of 60000	For sites without a site code or there are too many site codes to track, set all credentials presented to readers on this panel will report a site code of 60000. Toggle on or off. Default is Off.
Remap Site Code 0 to 60000	All credentials presented with a site code of 0 and a format other than 8 bit bursts are set to a site code of 60000. Toggle on or off. Default is Off.
Suppress Invalid Card Format Events	Panel does not report events related to invalid card formats. Toggle on or off. Default is Off, meaning it that it will report the events.
Suppress Unknown Card Format Events	Panel does not report events related to unknown card formats. Toggle on or off. Default is Off, meaning that it will report the events.

Card Formats	Function
Override Card Format	Toggle on or off. Default is Off. By default, the panel will follow the site's card format settings. If this is toggled on, options for each available card format can be configured individually by using the drop-down menu. Not all formats will have more than one option available.

Assigning Floors to an Access Privilege Group

Access Privilege Groups define which users can access particular areas of the building, and on what schedule. These can be used to define which floors users can access.

Navigate to **Users**, Access Privilege Groups on the left side menu. To create a new group, click **+Add**.



Assigning Floors to an Access Privilege Group (continued)

Fill out the information for the new access group.

Access Privilege Groups > Add Access Privilege Group

Access Group

Group Type

Local

Name

Main Building Elevators

Description

Elevators in the main building

Tags

Partition

Default Partition

Note

Starts On and Expires On only work with PRC controllers and are accurate to within 90 minutes.

Starts On

Expires On

Users

import

Page

Page

All

All

Jane Doe

Tom Robinson

Richard Roe

Bob Smith

10

2 of 4 Selected

Search

Access Group Settings	Definition
Group Type	Options for LDAP (Lightweight Directory Access Protocol) or Local.
Name	A name for the site.
Description	Optional descriptive text for the site.
Partition	Select the partition this group will apply to.
Holiday Group	Set if any of the existing holiday schedules will be applied to this group.
Starts On / Ends On	Groups can be temporary. These settings set a start and end date for the group.
Users	Use the check boxes to select which users will be part of this group.

06/25 13

Assigning Floors to an Access Privilege Group *(continued)*

Under **Readers**, use the check boxes to select all readers that are assigned to the elevator.



Readers: Import

Search


Page Page All All

Access SAM to SPM Set

Access SAM to SPM

1 of 1 Selected

Under **Floors**, use the check boxes to select all floors the group's users can access. Once everything is configured, click **+Create**.



Floors: Import

Search

Page Page All All

Access SAM to SPM Set

Floor 1 Main Building (Default Site) Always Access

Floor 2 Main Building (Default Site) Always Access

Floor 3 Main Building (Default Site) Always Access

Floor 4 Main Building (Default Site) Always Access

Floor 5 Main Building (Default Site) Always Access

Floor 6 Main Building (Default Site) Always Access

Floor 7 Main Building (Default Site) Always Access

Floor 8 Main Building (Default Site) Always Access

50 3 of 32 Selected

Clear +Create

All of these settings can be adjusted afterwards by navigating back to **+Create**.



Access Privilege Groups


+Add

Search All

	Name	Description	Group Type	Partition	
<input type="checkbox"/>	Regular Employees	Empty	Local	Service Entrance	
<input type="checkbox"/>	Management	Empty	Local	Side Entrance	

Updating a Panel

Once all settings are configured, the panel will need to be updated. Click **Update Panels** towards the top of the page, then click **Yes** to confirm.



A list of all stations will appear, showing their update status. Once the upload is finished, click the **X** symbol to return to normal operation.

