



## AEL Series Multi-Position Electric Furnace



### 1. Safety Instruction

Potential safety hazards are alerted using the following symbols. The symbol is used in conjunction with terms that indicate the intensity of the hazard.



#### **WARNING**

This symbol indicates a potentially hazardous situation, which if not avoided, could result in serious injury, property damage, product damage or death.



#### **CAUTION**

This symbol indicates a potentially hazardous situation, which if not avoided, may result in moderate injury or property damage.



#### **WARNING**

Certified technicians or those individuals meeting the requirements specified by NATE may use this information. Property and product damage or personal injury hazard may occur without such background.



#### **WARNING**

All power sources should be disconnected prior to servicing. Failure to do so may cause personal injury or property damage.



#### **WARNING**

Product designed and manufactured to permit installation in accordance with local and national building codes. It is the installer's responsibility to ensure that product is installed in strict compliance with national and local codes. Manufacturer takes no responsibility for damage (personal, product or property) caused due to installations violating regulations. In absence of local/state codes, refer to National Electric Code: NFPA 90A & 90B Uniform Mechanical Code.



#### **WARNING**

When this unit is installed in an enclosed area, such as a garage or utility room with any Carbon Monoxide producing devices (i.e. automobile, space heater, water heater etc.) ensure that the enclosed area is properly ventilated.



#### **CAUTION**

Only factory authorized kits and accessories should be used when installing or modifying this unit unless it is so noted in these instructions. Some localities may require a licensed installer/service personnel.



#### **WARNING**

Unit is not approved for outdoor installations.



#### **WARNING**

The unit is designed for operation with 208/240 V, single phase, 60 Hz power supply. Aspen will not be responsible for damages caused due to modification of the unit to operate with alternative power sources.

### 2. Important Messages

#### 2A. To the Installer:

"The United States Environmental Protection Agency ("EPA") has issued various regulations regarding the introduction of disposal of refrigerants in this unit. Failure to follow these regulations may harm the environment and can lead to the imposition of substantial fines. Because these regulations may vary due to the passage of new laws we suggest that any work on this unit be done by a certified technician. Should you have any questions please contact the local office of EPA." Some Aspen coils may include a Schrader valve on the suction manifold. During installation, this Schrader valve must be protected from heat or it may leak.

All Aspen coils are shipped with a nitrogen holding charge. DO NOT install the coil if this charge is not present.

#### 2B. To the Owner:

These instructions should be carefully read and kept near product, for future reference. While these instructions are addressed primarily to the installer, useful maintenance information is included. Have your installing dealer acquaint you with the operating characteristics of the product and periodic homeowner maintenance requirements. As expressed in our product warranty, Aspen will not be billed for any structural damage due to failure to follow these installation requirements. Once installed, Aspen coils may contain chlorofluorocarbons (CFC's) or hydrochlorofluorocarbons (HCFC's). Under certain conditions, CFC's & HCFC's may pose a health risk. Please notify a licensed service technician immediately if you suspect your system may contain a leak.

### 3. Codes And Regulations

This product is designed and manufactured to permit installation in accordance with National Codes. It is the installer's responsibility to install the product in accordance with National Codes and/or prevailing local codes and regulations. The manufacturer assumes no responsibility for equipment installed in violation of any code or regulation.

### 4. Inspection

This product has been inspected and run tested at the factory and released to the transportation agency without known damage. Inspect exterior of carton for evidence of rough handling in shipment. Unpack carefully, if damage is found, report immediately to the transportation agency.

5. Replacement Parts

Order all replacement parts through your local distributor. When ordering parts, give complete model and serial number as shown on the unit rating plate.


6. Specifications

BLOWER DATA									
MODEL	MOTOR SPEED	MOTOR HP	MOTOR AMPS	MOTOR VOLTAGE	CFM V. EXTERNAL STATIC *				
					0.10	0.20	0.30	0.40	0.50
AELS	T1	1/3	2.8	240	650	590	540	500	470
	T2				685	650	600	575	540
	T3				885	850	810	775	750
	T4				1075	1040	1000	960	930
	T5				1300	1250	1210	1170	1130
AELM	T1	1/2	4.1	240	990	980	930	800	750
	T2				1100	1050	1020	1000	950
	T3				1275	1240	1200	1175	1150
	T4				1450	1410	1380	1350	1310
	T5				1575	1550	1525	1490	1465
AELL	T1	1	7.6	240	1340	1200	1050	865	775
	T2				1480	1375	1230	1100	980
	T3				1725	1650	1630	1590	1540
	T4				1900	1865	1830	1775	1740
	T5				2120	2075	2015	1975	1940

\*Dry coil with filter in place. CFM is based on a 3 row coil. For approximate CFM with a 4 row coil multiply CFM by .96

DIMENSIONS AND SPECIFICATIONS								
MODEL	WIDTH A"	HEIGHT B"	DUCT OPENING		BOTTOM OPENING	FILTER SIZE	SHIP WEIGHT (LBS)	SKID QTY
			C"	D"	E"			
AELS	21	26	18-3/4	12	18-1/2	16X20	69	8
AELM	21	26	18-3/4	12	18-1/2	16X20	78	8
AELL	24-1/2	32	22-1/4	10-1/2	22	20x20	89	8

INSTALLATION CLEARANCES		
	OPERATION	SERVICE
TOP	0"	0"
FRONT	0"	30"
SIDES	0"	0"
REAR	0"	0"



7. Equipment Sizing

7A. Air Handler Selection

Select an air handler with a heating output that exceeds the space heating loss of the structure and that has a cooling coil sized to match the outdoor condensing unit. Special note... the heating output of the air handler or hot water coil will not be greater than the output of the selected hot water heater. Therefore, if the water heater is undersized the heating BTUH of the air handler will be LESS than it's rated output.

## 8. Installation

### 8A. Product Location

In an attic installation, where unit is resting on the floor, a suitable isolation pad should be provided to minimize equipment sound transmission to ceiling below.


FURTHERMORE, IN ALL COOLING APPLICATIONS, A SECONDARY DRAIN PAN MUST BE PROVIDED BY THE INSTALLER AND PLACED UNDER THE ENTIRE UNIT WITH A SEPARATE DRAIN LINE PROPERLY SLOPED AND TERMINATED IN AN AREA VIS-

ABLE TO OWNER. THIS SECONDARY PAN CAN PROVIDE EXTRA PROTECTION TO THE AREA UNDER THE UNIT SHOULD THE PRIMARY DRAIN PLUG UP AND OVERFLOW. AS EXPRESSED IN OUR PRODUCT WARRANTY, ASPEN WILL NOT BE BILLED FOR ANY STRUCTURAL DAMAGE DUE TO THE FAILURE TO FOLLOW THIS INSTALLATION REQUIREMENT.

### 8B. Installation Notes

This unit must be installed in accordance with all local and national codes. The furnace is completely serviceable from the front. All Units are approved for 0" clearance. This Electric Furnace allows substantial freedom in positioning the product to best serve the structure requirements. Units may, without field modification, be positioned for upflow, horizontal left or horizontal right installation. The downflow position requires a slight field modification.

### 8C. Horizontal Application



### 8D. Duct Installation

Air duct systems should be installed in accordance with standards for air-conditioning systems, National Fire Protection Association Pamphlet No. 90A or 90B. They should be sized in accordance with National Environmental System Contractors Association Manual K, or whichever is applicable.

On any job, non-flammable flexible collars should be used for the return air and discharge connections to prevent transmission of vibration. Although these units have been specially designed for quiet vibration-free operation, air ducts can act as soundboards and could, if poorly installed, amplify the slightest vibration to the annoyance level.

All main supply and return air drops should be run full size as determined by the designer of the duct system and should not necessarily be the size of the duct flange openings of the unit


When installing a central air return grille in or near the living space, it is advisable to design the ductwork so that the grille is not in direct line with the opening in the unit. One or two elbows and acoustical duct liner will also assure a quieter installation and system.

It is recommended that wherever supply and return air sheet metal duct pass through unconditioned areas, they be insulated to prevent excessive heat loss during heating operation. When applied in conjunction with summer air conditioning, sheet metal duct routed through unconditioned areas should be insulated and have an outside vapor barrier to prevent formation of condensation.

### 8E. Electrical Installation

These units are designed for single or three phase 208/230 volt 60 Hertz power supply. Wire selection and wiring must be in accordance with the National Electric Code and/or local codes. Unit terminals are designed to accommodate copper and aluminum wiring. If aluminum wiring is used, please observe the special precautions relative to sizing, handling, wire connections and corrosion protection.

All models with 5, 8, or 10 KW electric heat are arranged for single circuit connection. Models larger than 10 KW are arranged for multi-circuit connection. All information needed to connect the 208/240VAC supply and 24VAC control wiring is supplied with the unit. Two knock-outs are located for connection of power and control wiring. Since this unit is supplied with a 24 volt Class 2 transformer, a thermostat with isolating contacts must be used when connecting other add-on equipment using a Class 2 transformer.



### 8F. Special Instructions For Counterflow Applications (AEL)

The AEL Series Electric Furnace is specifically designed for the use in the upflow, horizontal and counterflow positions. Should the application be for counterflow position, the following steps should be taken:

- 1) Some units are supplied with factory installed circuit breakers. If the air handler has circuit breakers, they must be snapped out of the factory installed bracket and inverted to reflect "up" as the "on" and "down" as the "off" position.
- 2) The above procedure should be done at the job site, as the unit is not designed to be shipped in the counterflow mode.

## 9. Start Up

After all connections are made, start up and check out of the unit must be performed before proper evaluation of the entire system can be made. Make sure that heat anticipator is properly set as noted on low voltage wiring diagrams.

Load requirements can vary in each residence and it may be necessary for the installer or homeowner to make slight adjustments to the heat anticipator setting for longer or shorter cycles. It is recommended to change the setting no more than plus or minus .05 amps at one time. Greater changes can cause the unit to rapid cycle or remain on excessively. To properly check the unit's operation, the installer should have an electrical current measuring device (0-10 amp Amprobe), air pressure measuring device (0-1.0 in slope gauge), and a temperature-measuring device (0-200°F thermometer).

Install the amprobe to measure blower current, the slope gauge to measure static air pressure at the units and the temperature device to measure unit supply and return air temperature. Before taking measurements, be sure that all registers, grilles and dampers are open or are set to their proper positions. Be sure that clean filters are in place. Temperature measuring device must be installed to obtain average temperature at both inlet and outlet. For outlet, measure temperature of each main trunk at a location far enough away to avoid heater radiation and read the average temperatures.

## 10. General Operation And Maintenance

### 10A. Room Thermostat

This is the device that controls that operation of your heating and/or cooling unit. It senses the indoor temperature and signals the equipment to start or stop maintaining the temperature you have selected for your comfort. The room thermostat should be in a central, draft free inside wall location for best operation. Do not place any heat producing apparatus such as lights, radio, etc., near the thermostat as this will cause erratic operation of the comfort system. The thermostat can accumulate dust or lint, which can affect its accuracy. It should be cleaned annually.

### 10B. Air Filter(s)

All central air moving comfort systems must include air filter(s). These filters will be located either in the equipment or in the return air duct system upstream of the equipment. The filter(s) removes dust and debris from the air thus helping to keep your air conditioned space clean. More important, the filter keeps dust and debris from collecting on the heat transfer surfaces thus maintaining optimum equipment efficiency and performance. Inspect and clean or replace filters every month. This routine maintenance procedure will pay big dividends in reduced operating cost and reduced service expense. Never operate comfort equipment without filter(s).

*An air filter can restrict the airflow of air to the fan coil if it is not cleaned or replaced periodically. When replacing the air filter, always replace with the same type and size as originally furnished with the unit.*

### 10C. Fuses and/or Circuit Breakers

This comfort equipment should be connected to the building electric service in accordance with local and National Electric codes. This electrical connection will include over current protection in the form of circuit breakers. Have your contractor identify the circuits and the location of over current protection so that you may be in a position to make inspections or replacements in the event the equipment fails to operate.



#### WARNING

Do not store combustible materials or use gasoline or other flammable liquids or vapors in the vicinity of this appliance.



#### CAUTION

Do not operate the comfort equipment with panels removed.



#### WARNING

Have your contractor point out and identify the various cutoff devices, switches, etc., that serve your comfort equipment.

There is a main switch that will cut off energy to your heating system. Know where they are so that you may cut off the flow of energy in the event of overheating.

## 10D. Periodic Checkup and Service

This product is designed to provide many years of dependable, trouble free comfort when properly maintained. Proper maintenance will consist of annual checkups and cleaning of the internal electrical and heat transfer components by a qualified service technician. Failure to provide periodic checkup and cleaning can result in excessive operating cost and/or equipment malfunction.

## 10E. Lubrication

Direct drive blower motors are equipped with permanently lubricated bearings and do not require further lubrication.

## 11. Checking Air Flow/Temperature Rise Method

1. Turn on power supply. Set thermostat fan switch to on. Set the cooling indicator to maximum, heating to minimum. System switch may be on heat or cool. Check slope gauge measurement against appropriate air flow chart. Make damper, register and motor speed adjustments to obtain required airflow.
2. Set thermostat fan switch to auto, system to heat and thermostat heating indicator to maximum heat. Blower should start and all heat be energized.
3. Check air flow using temperature rise method.

$$CFM = \frac{OUTPUT(BTUH)}{1.08 \bullet TEMP.RISE}$$

**NOTE:** BTUH output should be computed by VOLT x AMPS x 3.4 = BTUH OUTPUT. Since line volt can vary, do not use nameplate rating to determine output.

## 12. Operation and Maintenance

1) Room Thermostat- This is the device that controls that operation of your heating and/or cooling unit. It senses the indoor temperature and signals the equipment to start or stop maintaining the temperature you have selected for your comfort. The room thermostat should be in a central, draft free inside wall location for best operation. Do not place any heat producing apparatus such as lights, radio, etc., near the thermostat as this will cause erratic operation of the comfort system. The thermostat can accumulate dust or lint which can affect its accuracy. It should be cleaned annually.

2) Air Filter(s)- All central air moving comfort systems must include air filter(s). These filters will be located either in the equipment or in the return air duct system upstream of the equipment. The filter(s) removes dust and debris from the air thus helping to keep your air conditioned space clean. More important, the filter keeps dust and debris from collecting on the heat transfer surfaces thus maintaining optimum equipment efficiency and performance. Inspect and clean or replace filters every month. This routine maintenance procedure

will pay big dividends in reduced operating cost and reduced service expense. Never operate comfort equipment without filter(s).

3) Fuses and/or Circuit Breakers- This comfort equipment should be connected to the building electric service in accordance with local and National Electric codes. This electrical connection will include over current protection in the form of circuit breakers. Have your contractor identify the circuits and the location of over current protection so that you may be in a position to make inspections or replacements in the event the equipment fails to operate.

#### 4) WARNING

A) Do not store combustible materials or use gasoline or other flammable liquids or vapors in the vicinity of this appliance.

B) Do not operate the comfort equipment with panels removed.

C) Have your contractor point out and identify the various cut-off devices, switches, etc., that serve your comfort equipment. There is a main switch that will cut off energy to your heating system. Know where they are so that you may cut off the flow of energy in the event of overheating.


5) Periodic Checkup and Service- This product is designed to provide many years of dependable, trouble-free comfort when properly maintained. Proper maintenance will consist of annual check-ups and cleaning of the internal electrical and heat transfer components by a qualified service technician. Failure to provide periodic checkup and cleaning can result in excessive operating cost and/or equipment malfunction.

6) Lubrication- Direct drive blower motors are equipped with permanently lubricated bearings and do not require further lubrication.

## 13. Final System Checkout

1. Make certain all cabinet openings are properly sealed and any grommets moved during installation are moved into proper place.
2. With cooling system operating, check for condensate leakage.
3. Perform leak detection inspection of refrigerant circuit and connecting piping.
4. Secure all cabinet doors

DRAIN PAN TEMPERATURE TABLE	
DRAIN PAN TYPE	TEMP LIMITS
Plastic - Standard	290°
Plastic - High Temp	425°
Metal - High Temp	600°



**HIGH VOLTAGE disconnect all power sources prior to servicing. Failure might lead to safety hazard**





373 Atascocita Rd.  
Humble, TX 77396  
Phone: 281.441.6500  
Toll Free: 800.423.9007  
Fax: 281.441.6510  
**[www.aspenmfg.com](http://www.aspenmfg.com)**



Revised 06-2024. Subject to change without notice and without incurring obligation.

© Copyright 2024 Aspen Manufacturing. All Rights Reserved