

If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

Quick Start Guide

alt







How to Remap Your QMK Enabled K HE Series Keyboard on macOS, Windows, Linux:

https://www.keychron.com/blogs/news/how-to-use-launcher-to-program-your-keyboard

https://www.keychron.com/pages/how-to-use-he-mode-on-keychron-launcher

Source Code, download link will be available on the product page of our official website if the code is up on Github, you can then search "source code" to find it.

More files for further customization: https://www.keychron.com/pages/keychron-k2-he-user-guide


3 Connect Cable






5 The Backlight

Press fn + Q to change the lighting effect





Press fn + tab to turn the backlight on/off

7 The Keychron Launcher App


Please visit launcher.keychron.com to access the Keychron online launcher app. This app enables users to remap keys, adjust key actuation points, assign multiple commands to a single key, enter game controller mode, and more.

If it cannot recognize your keyboard, please reach our support to get instruction.



*The online launcher App can only run on the latest version of Chrome, Edge, and Opera browsers yet.

9 Factory Reset & Firmware Update



Troubleshooting? Don't know what's going on with the keyboard?

- Factory reset your keyboard 1. Power on your keyboard.
- 2. Press and hold fn + J + Z (for 4 seconds). The keyboard backlight will flash in red quickly for 3 seconds, indicating that the keyboard has been reset.
- Flash vour keyboard firmware
- 1. Visit launcher.keychron.com to open the online Launcher web app.
- 2. Ensure the keyboard is in Cable or Wired mode and plug in the power cable.
- 3. Find the 'Firmware Update' tab on the left side of the Launcher and connect your keyboard with it.
- 4. Follow the instructions on the Launcher and complete the firmware update. *Step-by-step guide, search the keyword "firmware" on keychron.com.

4 Switch To The Right System

Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.




6 Adjust The Backlight Brightness

Press fn + W to increase the backlight brightness



Press fn + S to decrease the backlight brightness



8 The Layers

There are four layers of key settings on the keyboard. The layer 0 and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.

LAYER 0 1 2 3

If your system toggle is switched to Mac, then the layer 0 will be activated.

If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a common mistake people are making.





10 Warranty

The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.



