

FZ6R MOTORCYCLE

A Read this manual carefully before operating this vehicle.

FZ6RGC

EAU10043

AWARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

YAMAHA LIT GALIF 55 01

Nead this manual carefully before operating this vehicle. This manual should stay with this vehicle if it is sold.

Introduction

FAU10084

EWA10012

Congratulations on your purchase of the Yamaha FZ6RG / FZ6RGC. This model is the result of Yamaha's vast experience in the production of fine sporting, touring, and pacesetting racing machines. It represents the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields.

This manual will give you an understanding of the operation, inspection, and basic maintenance of this motorcycle. If you have any questions concerning the operation or maintenance of your motorcycle, please consult a Yamaha dealer.

The design and manufacture of this Yamaha motorcycle fully comply with the emissions standards for clean air applicable at the date of manufacture. Yamaha has met these standards without reducing the performance or economy of operation of the motorcycle. To maintain these high standards, it is important that you and your Yamaha dealer pay close attention to the recommended maintenance schedules and operating instructions contained within this manual.

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

♠ WARNING

Please read this manual and the "YOU AND YOUR MOTORCYCLE: RIDING TIPS" booklet carefully before operating this motorcycle. Do not attempt to operate this motorcycle until you have attained adequate knowledge of its controls and operating features. Regular inspections and careful maintenance, along with good operating techniques, will help ensure that you safely enjoy the capabilities and reliability of this motorcycle.

EAU63350

Particularly important information is distinguished in this manual by the following notations:

\triangle	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
▲ WARNING	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.
TIP	A TIP provides key information to make procedures easier or clearer.

^{*}Product and specifications are subject to change without notice.

EAU10194

FZ6RG / FZ6RGC
OWNER'S MANUAL
©2015 by Yamaha Motor Corporation, U.S.A.
1st edition, August 2015
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.
Printed in Japan.
P/N LIT-11626-29-47

Table of contents

Location of important labels1-1	Periodic maintenance and	
	adjustment7-1	
Safety information2-1	Owner's tool kit7-2	
	Periodic maintenance chart for the	
Description 3-1	emission control system7-3	
Left view3-1	General maintenance and	
Right view3-2	lubrication chart7-4	
Controls and instruments3-3	Removing and installing cowlings	
	and panels7-7	
Instrument and control functions4-1	Checking the spark plugs7-10	
Main switch/steering lock4-1	Canister (for California only)7-11	
Indicator lights and warning	Engine oil and oil filter cartridge 7-11	
lights4-2	Coolant7-14	
Multi-function meter unit4-4	Replacing the air filter element 7-18	
Handlebar switches4-7	Checking the engine idling	
Clutch lever4-8	speed7-19	
Shift pedal4-9	Checking the throttle grip free	
Brake lever4-9	play7-20	
Brake pedal4-10	Valve clearance7-20	
Fuel tank cap4-10	Tires7-21	
Fuel4-11	Cast wheels7-23	
Fuel tank breather hose and	Adjusting the clutch lever free	
overflow hose4-12	play7-24	
Catalytic converter4-13	Checking the brake lever free	
Seats4-13	play7-25	
Adjusting the rider seat height4-15	Brake light switches7-25	
Helmet holder4-17	Checking the front and rear	
Storage compartment4-18	brake pads7-26	
Handlebar position4-18	Checking the brake fluid level7-27	
Rear view mirrors4-19	Changing the brake fluid7-28	
Adjusting the shock absorber	Drive chain slack7-28	
assembly4-19	Cleaning and lubricating the	
Sidestand4-20	drive chain7-30	
Ignition circuit cut-off system4-21	Checking and lubricating the	
	cables7-30	
For your safety – pre-operation	Checking and lubricating the	
checks5-1	throttle grip and cable7-31	
	Checking and lubricating the	
Operation and important riding	brake and shift pedals7-31	
points6-1	Checking and lubricating the	
Starting the engine6-2	brake and clutch levers7-32	
Shifting6-3	Checking and lubricating the	
Engine break-in6-4	sidestand7-32	
Parking6-5	Lubricating the swingarm pivots7-33	
	Checking the front fork7-33	
	Checking the steering7-34	


Table of contents

Checking the wheel bearings	. 7-34
Battery	
Replacing the fuses	. 7-36
Replacing the headlight bulb	. 7-37
Replacing the brake/tail light	
bulb	. 7-38
Replacing a turn signal light	
bulb	. 7-39
Replacing the license plate light	
bulb	. 7-40
Supporting the motorcycle	. 7-40
Front wheel	. 7-41
Rear wheel	. 7-42
Troubleshooting	
Troubleshooting charts	. 7-45
Motorcycle care and storage	
Matte color caution	
Care	
Storage	8-4
0	0.4
Specifications	9-1
Consumer information	10 1
Identification numbers	
Reporting safety defects	
Motorcycle noise regulation	
Maintenance record	
YAMAHA MOTOR	. 10-3
CORPORATION, U.S.A.	
2015 AND LATER MODEL	
STREET & DUAL-PURPOSE	
STREET & DUAL-PURPOSE MOTORCYCLE LIMITED	. 10-6
STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY	. 10-6
STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY YAMAHA EXTENDED SERVICE	
STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY	

Location of important labels

EAU63360

Read and understand all of the labels on your vehicle. They contain important information for safe and proper operation of your vehicle. Never remove any labels from your vehicle. If a label becomes difficult to read or comes off, a replacement label is available from your Yamaha dealer.



NOTICE

- · Cleaning with alkaline or acid cleaner, gasoline or solvent will damage windshield.
- Use neutral detergent.

2

WARNING

- BEFORE YOU OPERATE THIS VEHICLE, READ THE OWNER'S MANUAL AND ALL LABELS.
- ALWAYS WEAR AN APPROVED MOTORCYCLE **HELMET**, eye protection, and protective clothing.

3

AWARNING

This unit centains high pressure nitrogen gas. Mishanding can because explosion

- Sead own efairmanual locid structions.
- Do not incinerate, princaure ar open.

4700000 0

TIRE INFORMATION

Colon reinformal preceive whould be sen es nultican.

●Using 90 kg (1967 ber foed

226 kGb, √2.26 kg/pm/g, 32 ms 11503911 HEAR 200 kGs, v2 64 kg/2mG, 30 ks.

●90 og 19e har i maximum fosci

ITXXX4T 200 (0), (2 50 log())) (3.30 ps.

BEAR 290 (0), (2.69 log()); (3.12 hs.

ر اشعاداته ۱۹۰


5

AWARNING

Improper loading can cause loss of control. Read owner's manual for proper loading.

3.I.I-28446-A1

6




3 kg {7 lbs}.


3TB-37577-40

Location of important labels

7 California only



8 California only



⚠ Safety information

EAU1028B

Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your motorcycle.

Motorcycles are single-track vehicles. Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this motorcycle.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of motorcycle operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.
- Never operate a motorcycle without proper training or instruction.
 Take a training course. Beginners should receive training from a certified instructor. Contact an authorized motorcycle dealer to find out about the training courses nearest you.

Safe Riding

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage.

See page 5-1 for a list of pre-operation checks.

- This motorcycle is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize motorcycles in traffic is the predominating cause of automobile/motorcycle accidents. Many accidents have been caused by an automobile driver who did not see the motorcycle. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.

Therefore:

- Wear a brightly colored jacket.
- Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for motorcycle accidents to occur.
- Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Never maintain a motorcycle without proper knowledge. Contact an authorized motorcycle dealer to inform you on basic motorcycle maintenance. Certain maintenance can only be carried out by certified staff.

⚠ Safety information

- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current motorcycle license.
 - Make sure that you are qualified and that you only lend your motorcycle to other qualified operators.
 - Know your skills and limits.
 Staying within your limits may help you to avoid an accident.
 - We recommend that you practice riding your motorcycle where there is no traffic until you have become thoroughly familiar with the motorcycle and all of its controls.
- Many accidents have been caused by error of the motorcycle operator. A typical error made by the operator is veering wide on a turn due to excessive speed or undercornering (insufficient lean angle for the speed).
 - Always obey the speed limit and never travel faster than warranted by road and traffic conditions.
 - Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
 - The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the motorcycle.

- The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.
- This motorcycle is designed for on-road use only. It is not suitable for off-road use.

Protective Apparel

The majority of fatalities from motorcycle accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles.
 Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, heavy boots, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers, footrests, or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.
- A passenger should also observe the above precautions.

Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREAT-MENT.

- Do not run engine indoors. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.
- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.
- Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

Loading

Adding accessories or cargo to your motorcycle can adversely affect stability and handling if the weight distribution of the motorcycle is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your motorcycle. Use

extra care when riding a motorcycle that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your motorcycle:

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit. Operation of an overloaded vehicle could cause an accident.

Maximum load:

187 kg (412 lb) (FZ6RGC) 188 kg (414 lb) (FZ6RG)

When loading within this weight limit, keep the following in mind:

- Cargo and accessory weight should be kept as low and close to the motorcycle as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the motorcycle to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the motorcycle before riding. Check accessory mounts and cargo restraints frequently.
 - Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.
 - Never attach any large or heavy items to the handlebar, front fork, or front fender. These

items, including such cargo as sleeping bags, duffel bags, or tents, can create unstable handling or a slow steering response.

 This vehicle is not designed to pull a trailer or to be attached to a sidecar.

Choosing accessories for your vehicle

Genuine Yamaha Accessories

is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle. Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

Aftermarket Parts, Accessories, and Modifications

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others

at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle. Keep the following guidelines in mind

Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

- Never install accessories or carry cargo that would impair the performance of your motorcycle. Carefully inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.
 - Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.
 - Bulky or large accessories may seriously affect the stability of the motorcycle due to aerodynamic effects. Wind may attempt to lift the motorcycle, or the motorcycle may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
 - Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the

operator and may limit control ability, therefore, such accessories are not recommended.

 Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the motorcycle's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

Aftermarket Tires and Rims

The tires and rims that came with your motorcycle were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 7-21 for tire specifications and more information on replacing your tires.

Transporting the Motorcycle


Be sure to observe following instructions before transporting the motorcycle in another vehicle.

- Remove all loose items from the motorcycle.
- Check that the fuel cock (if equipped) is in the "OFF" position and that there are no fuel leaks.
- Point the front wheel straight ahead on the trailer or in the truck bed, and choke it in a rail to prevent movement.
- Shift the transmission in gear (for models with a manual transmission).
- Secure the motorcycle with tiedowns or suitable straps that are attached to solid parts of the mo-

- torcycle, such as the frame or upper front fork triple clamp (and not, for example, to rubber-mounted handlebars or turn signals, or parts that could break). Choose the location for the straps carefully so the straps will not rub against painted surfaces during transport.
- The suspension should be compressed somewhat by the tiedowns, if possible, so that the motorcycle will not bounce excessively during transport.


EAU63371

Left view



- 1. Air filter element (page 7-18)
- 2. Seat lock (page 4-13)
- 3. Fuses (page 7-36)
- 4. Storage compartment (page 4-18)
- 5. Owner's tool kit (page 7-2)
- 6. Shift pedal (page 4-9)
- 7. Engine oil filter cartridge (page 7-11)
- 8. Engine oil drain bolt (page 7-11)


Right view



- 1. Helmet holder (page 4-17)
- 2. Battery (page 7-35)
- 3. Rear brake fluid reservoir (page 7-27)
- 4. Engine oil filler cap (page 7-11)
- 5. Radiator cap (page 7-14)
- 6. Coolant reservoir (page 7-14)
- 7. Coolant drain bolt (page 7-15)
- 8. Engine oil dipstick (page 7-11)
- 9. Brake pedal (page 4-10)
- 10.Rear brake light switch (page 7-25)
- 11. Shock absorber assembly spring preload adjusting ring (page 4-19)


Controls and instruments





- 1. Clutch lever (page 4-8)
- 2. Left handlebar switches (page 4-7)
- 3. Main switch/steering lock (page 4-1)
- 4. Multi-function meter unit (page 4-4)
- 5. Front brake fluid reservoir (page 7-27)
- 6. Right handlebar switches (page 4-7)
- 7. Throttle grip (page 7-20)
- 8. Brake lever (page 4-9)

Main switch/steering lock



The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

ON

EAU10542

All electrical circuits are supplied with power; the meter lighting, taillight, license plate light and position lights come on, and the engine can be started. The key cannot be removed.

TIP

The headlight comes on automatically when the engine is started and stays on until the key is turned to "OFF", even if the engine stalls.

EAU10662

OFF

All electrical systems are off. The key can be removed.

EWA10062

WARNING


Never turn the key to "OFF" or "LOCK" while the vehicle is moving. Otherwise the electrical systems will be switched off, which may result in loss of control or an accident.

LOCK

The steering is locked and all electrical systems are off. The key can be removed.

EAU10687

To lock the steering




- 1. Push.
- 2. Turn.
 - 1. Turn the handlebars all the way to the left.
 - 2. With the key in the "OFF" position, push the key in and turn it to "LOCK".
 - 3. Remove the key.

TIP

If the steering will not lock, try turning the handlebars back to the right slightly.


To unlock the steering



- 1. Push.
- 2. Turn.

- 1. Insert the key.
- 2. With the key in the "LOCK" position, push the key in and turn it to "OFF".

Indicator lights and warning lights



- 1. Turn signal indicator light "♦ ♦"
- 2. Neutral indicator light " N "
- 3. High beam indicator light "≣⊘"
- 4. Engine trouble warning light "+₺"
- 5. Oil level warning light "♥±¬,"
- 6. Coolant temperature warning light " & "

EAU11022

Turn signal indicator light "⇔ ⇔"

This indicator light flashes when a turn signal light is flashing.

Neutral indicator light "N"

EAU11061

This indicator light comes on when the transmission is in the neutral position.

EALI4400:

High beam indicator light "≣⊜"

This indicator light comes on when the high beam of the headlight is switched on.

EAU11256

Oil level warning light ""

This warning light comes on if the engine oil level is low.

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds and then go off.

If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on after confirming that the oil level is correct (see page 7-11), have a Yamaha dealer check the vehicle.

TIP _____

- Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.
- This model is equipped with a selfdiagnosis device for the oil level detection circuit. If a problem is detected in the oil level detection circuit, the oil level warning light will flash repeatedly. If this occurs, have a Yamaha dealer check the vehicle.

Coolant temperature warning light " £"

This warning light comes on if the engine overheats. If this occurs, reduce the load on the engine immediately. If message "HI" flashes in the coolant temperature display, stop the vehicle, then stop the engine and let the engine cool.

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off.

If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

NOTICE

Do not continue to operate the engine if it is overheating.

TIP _____

- For radiator-fan-equipped vehicles, the radiator fan(s) automatically switch on or off according to the coolant temperature in the radiator.
- If the engine overheats, see page 7-46 for further instructions.

EAU5911

FCA10022

Engine trouble warning light " "

This warning light comes on or flashes if a problem is detected in the electrical circuit monitoring the engine. If this occurs, have a Yamaha dealer check the self-diagnosis system. (See page 4-7 for an explanation of the self-diagnosis device.)

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off.


If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

TIP _____

The engine trouble warning light will come on while the start switch is pushed, but this does not indicate a malfunction.

EAU47345

Multi-function meter unit



- 1. Fuel meter
- 2. Coolant temperature display
- 3. Speedometer
- 4. Tachometer
- 5. Odometer/tripmeter/fuel reserve tripmeter
- 6. "SELECT" button
- 7. "RESET" button
- 8. Clock

EWA12423

WARNING

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit. Changing settings while riding can distract the operator and increase the risk of an accident.

The multi-function meter unit is equipped with the following:

- speedometer
- tachometer
- odometer
- two tripmeters
- fuel reserve tripmeter
- clock
- fuel meter
- coolant temperature display
- self-diagnosis device


TIP_-

- The key must be turned to "ON" before you can use the "SELECT" and "RESET" buttons.
- To switch the speedometer and odometer/tripmeter displays between kilometers and miles, press the "SELECT" button for one second.

Speedometer

The speedometer shows the vehicle's traveling speed.

Tachometer



- 1. Tachometer
- 2. Tachometer red zone

The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

When the key is turned to "ON", the tachometer needle will sweep once across the r/min range and then return to zero r/min in order to test the electrical circuit.


ECA10032

NOTICE

Do not operate the engine in the tachometer red zone.

Red zone: 11666 r/min and above

Clock




1. Clock

The clock uses a 12-hour time system. When the main switch is not in the "ON" position, the clock can be viewed for 10 seconds by pushing the "SE-LECT" button.

To set the clock

- 1. Turn the key to "ON".
- 2. Push the "SELECT" button and "RESET" button together for two seconds. The hour digits start flashing.
- 3. Use the "RESET" button to set the hours.
- 4. Push the "SELECT" button, and the minute digits will start flashing.
- Use the "RESET" button to set the minutes.
- 6. Push the "SELECT" button and then release it to start the clock.

Odometer and tripmeters



1. Odometer/tripmeter/fuel reserve tripmeter

The odometer shows the total distance traveled by the vehicle.

The tripmeters show the distance traveled since they were last reset.

To reset a tripmeter, use the "SELECT" button to display the tripmeter you want to reset, and then push the "RESET" button for one second.

TIP

- The odometer will lock at 999999 and cannot be reset.
- The tripmeters will reset and continue counting after 9999.9 is reached.

Push the "SELECT" button to switch the display between the odometer mode "ODO" and the tripmeter modes "TRIP A" and "TRIP B" in the following order:


TRIP A \rightarrow TRIP B \rightarrow ODO \rightarrow TRIP A When the fuel amount in the fuel tank decreases to 3.2 L (0.84 US gal, 0.70 Imp.gal), the left segment of the fuel meter will start flashing, and the odometer display will automatically change to the fuel reserve tripmeter mode "F-TRIP" and start counting the distance traveled from that point. In that case, push the "SELECT" button

to switch the display between the various tripmeter and odometer modes in the following order:

F-TRIP \rightarrow TRIP A \rightarrow TRIP B \rightarrow ODO \rightarrow F-TRIP

If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to the prior mode after refueling and traveling 5 km (3 mi).

Fuel meter




1. Fuel meter

The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear from "F" (full) towards "E" (empty) as the fuel level decreases. When the last segment on the left starts flashing, refuel as soon as possible.

TIP

This fuel meter is equipped with a self-diagnosis system. If a problem is detected in the electrical circuit, the fuel level segments and the symbol "" will flash repeatedly. If this occurs, have a Yamaha dealer check the electrical circuit.

Coolant temperature display



1. Coolant temperature display

The coolant temperature display indicates the temperature of the coolant from 104 °F to 274 °F in 1 °F increments.

If the coolant temperature is 243 °F–274 °F, the coolant temperature display flashes and the coolant temperature warning light comes on. If this occurs, reduce the load on the engine by riding at a moderate pace, at low rpm, until the coolant temperature goes down. If the temperature does not go down, stop the engine. (See page 7-46.)

If the message "HI" flashes, and the warning light is on, stop the engine and let it cool. (See page 7-46.)

TIP


- When the coolant temperature is below 104 °F, "LO" will be displayed.
- The coolant temperature varies with changes in the weather and engine load.

ECA10022

NOTICE

Do not continue to operate the engine if it is overheating.

Self-diagnosis device



- 1. Error code display
- 2. Engine trouble warning light "点"

This model is equipped with a self-diagnosis device for various electrical circuits.

If a problem is detected in any of those circuits, the engine trouble warning light will come on and the display will indicate an error code.

If the display indicates any error codes, note the code number, and then have a Yamaha dealer check the vehicle.


ECA11591

NOTICE

If the display indicates an error code, the vehicle should be checked as soon as possible in order to avoid engine damage.


Handlebar switches

Left



- 1. Dimmer switch "≣O/≣O"
- 2. Turn signal switch "⟨¬/¬>"
- 3. Horn switch "

Right



- Engine stop switch "○/♥"
- 2. Start switch "(≶)"

FAI 112401

EAU1234H

Dimmer switch "≣⊘/ ≨⊘"

Set this switch to "≣○" for the high beam and to "≣○" for the low beam.

EAU12461

Turn signal switch "⟨¬/¬⇒"

To signal a right-hand turn, push this switch to "⇒". To signal a left-hand turn, push this switch to "⇐". When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

EAU12501

EAU12661

Horn switch "▶ "

Press this switch to sound the horn.

Engine stop switch "○/⊠"

Set this switch to "\(\cap\)" before starting the engine. Set this switch to "\(\omega\)" to stop the engine in case of an emergency, such as when the vehicle overturns or when the throttle cable is stuck.

EAU12713

Start switch "(§)"


Push this switch to crank the engine with the starter. See page 6-2 for starting instructions prior to starting the engine.

EAU41701

The engine trouble warning light will come on when the key is turned to "ON" and the start switch is pushed, but this does not indicate a malfunction.

Clutch lever

EAU12822




1. Clutch lever

The clutch lever is located on the left side of the handlebar. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 4-21.)

Shift pedal



1. Shift pedal


The shift pedal is located on the left side of the motorcycle and is used in combination with the clutch lever when shifting the gears of the 6-speed constant-mesh transmission equipped on this motorcycle.

EAU12872

Brake lever

The brake lever is located on the right side of the handlebar. To apply the front brake, pull the lever toward the throttle grip.

EAU26825




- Brake lever
- 2. Brake lever position adjusting dial
- 3. " <u>∧</u>" mark
- 4. Distance between brake lever and throttle grip

The brake lever is equipped with a brake lever position adjusting dial. To adjust the distance between the brake lever and the throttle grip, turn the adjusting dial while holding the lever pushed away from the throttle grip. Make sure that the appropriate setting on the adjusting dial is aligned with the " \triangle " mark on the brake lever.

EAU13075

Instrument and control functions


Brake pedal



1. Brake pedal

The brake pedal is located on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.

Fuel tank cap



- 1. Fuel tank cap lock cover
- 2. Unlock.

To open the fuel tank cap

Open the fuel tank cap lock cover, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be opened.

To close the fuel tank cap

- Push the fuel tank cap into position with the key inserted in the lock.
- 2. Turn the key counterclockwise to the original position, remove it, and then close the lock cover.

TIP

The fuel tank cap cannot be closed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly closed and locked.

EWA11092



Make sure that the fuel tank cap is properly closed after filling fuel. Leaking fuel is a fire hazard.

Fuel

Make sure there is sufficient gasoline in the tank.


EWA10882

EAU13222

WARNING

Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.

- Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
- Do not overfill the fuel tank. When refueling, be sure to insert the pump nozzle into the fuel tank filler hole. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



- 1. Fuel tank filler tube
- 2. Maximum fuel level

- 3. Wipe up any spilled fuel immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts. [ECA10072]
- 4. Be sure to securely close the fuel tank cap.

₩ WARNING

EWA15152

Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

EAU13315

Recommended fuel:

Regular unleaded gasoline (Gasohol [E10] acceptable)

Fuel tank capacity:

17 L (4.5 US gal, 3.7 Imp.gal)

Fuel reserve amount:

3.2 L (0.84 US gal, 0.70 Imp.gal)

ECA11401

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.


Your Yamaha engine has been designed to use regular unleaded gasoline with a pump octane number

[(R+M)/2] of 86 or higher, or a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

Gasohol

There are two types of gasohol: gasohol containing ethanol and that containing methanol. Gasohol containing ethanol can be used if the ethanol content does not exceed 10% (E10). Gasohol containing methanol is not recommended by Yamaha because it can cause damage to the fuel system or vehicle performance problems.

Fuel tank breather hose and overflow hose



- 1. Fuel tank breather hose and overflow hose
- 2. Clamp
- 3. Original position (paint mark)

TIP

For California: See page 7-11 for breather hose information.

Before operating the motorcycle:

- Check each hose connection.
- Check each hose for cracks or damage, and replace if necessary.
- Make sure that the end of each hose is not blocked, and clean if necessary.
- Make sure that each hose is routed through the clamp.
- Make sure that the paint mark on each hose is below the clamp.

Catalytic converter

This model is equipped with a catalytic converter in the exhaust system.

EWA108

EAU13434

WARNING

The exhaust system is hot after operation. To prevent a fire hazard or burns:

- Do not park the vehicle near possible fire hazards such as grass or other materials that easily burn.
- Park the vehicle in a place where pedestrians or children are not likely to touch the hot exhaust system.
- Make sure that the exhaust system has cooled down before doing any maintenance work.
- Do not allow the engine to idle more than a few minutes. Long idling can cause a build-up of heat.

ECA10702

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause unrepairable damage to the catalytic converter.


Seats

Passenger seat

To remove the passenger seat

 Insert the key into the seat lock, and then turn it counterclockwise.


EAU47363



- 1. Seat lock
- 2. Unlock.
 - 2. Lift the front of the passenger seat and pull it forward.

To install the passenger seat

 Insert the projection on the rear of the passenger seat into the seat holder as shown, and then push the front of the seat down to lock it in place.




- 1. Projection
- 2. Seat holder
 - 2. Remove the key.

Rider seat

To remove the rider seat

- 1. Remove the passenger seat.
- 2. Remove the bolts, and then pull the rider seat off.


The rider seat height can be adjusted to change the riding position. (See the "Adjusting the rider seat height" section.)



- 1. Rider seat
- 2. Bolt

To install the rider seat

 Insert the projection on the front of the rider seat into the seat holder as shown, place the seat in the original position, and then tighten the bolts.



- 1. Seat holder
- 2. Projection
 - 2. Install the passenger seat.

TIP ___


Make sure that the seats are properly secured before riding.

EAU47451

Adjusting the rider seat height

The rider seat height can be adjusted to one of two positions to suit the rider's preference.


The rider seat height was adjusted to the lower position at delivery.




- 1. Low position
- 2. High position

To change the rider seat height to the high position


- Remove the passenger and rider seats. (See page 4-13.)
- Remove the rider seat height position adjuster by removing the adjuster bolts.




- 1. Rider seat height position adjuster
- 2. Adjuster bolt
 - Install the rider seat height position adjuster so that its bolt holes marked "H" are aligned with the bolt holes of the adjuster brackets, and then install the adjuster bolts.



- 1. Rider seat height position adjuster
- 2. "H" mark
- 3. Adjuster bracket
 - Insert the projection on the front of the rider seat into seat holder B as shown.



- 1. Projection
- 2. Seat holder B (for high position)
 - Align the lower bolt holes in the rider seat with the bolt holes in the seat brackets, and then install the bolts.




1. Bolt


6. Install the passenger seat.

To change the rider seat height to the low position

- 1. Remove the passenger and rider seats. (See page 4-13.)
- Remove the rider seat height position adjuster by removing the adjuster bolts.
- Install the rider seat height position adjuster so that its bolt holes marked "L" are aligned with the bolt holes of the adjuster brackets, and then install the adjuster bolts.




- 1. Rider seat height position adjuster
- 2. "L" mark
- 3. Adjuster bracket
 - Insert the projection on the front of the rider seat into seat holder A as shown.



- 1. Projection
- 2. Seat holder A (for low position)

Align the upper bolt holes in the rider seat with the bolt holes in the seat brackets, and then install the bolts.




- 1. Bolt
 - 6. Install the passenger seat.

TIP_

Make sure that the seats are properly secured before riding.

EAU47352

Helmet holder




- 1. Helmet holder
- 2. Owner's tool kit
- 3. Helmet holding cable

The helmet holder is located under the passenger seat. A helmet holding cable is provided in the owner's tool kit to secure a helmet to the helmet holder.

To secure a helmet to the helmet holder

- 1. Remove the passenger seat. (See page 4-13.)
- Pass the helmet holding cable through the buckle on the helmet strap as shown, and then hook the cable loops over the helmet holder.




- 1. Helmet
- 2. Helmet holding cable
- 3. Helmet holder

 Place the helmet on the right side of the vehicle, and then install the passenger seat. WARNING! Never ride with a helmet attached to the helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident. [EWAID162]

To release the helmet from the helmet holder

Remove the passenger seat, remove the helmet holding cable from the helmet holder and the helmet, and then install the passenger seat.

Storage compartment



1. Storage compartment

The storage compartment is located under the passenger seat. (See page 4-13.)

When storing documents or other items in the storage compartment, be sure to wrap them in a plastic bag so that they will not get wet. When washing the vehicle, be careful not to let any water enter the storage compartment.

EWA10962


EAU14465

WARNING

- Do not exceed the load limit of 3 kg (7 lb) for the storage compartment.
- Do not exceed the maximum load of 187 kg (412 lb) (FZ6RGC) 188 kg (414 lb) (FZ6RG) for the vehicle.

Handlebar position

The handlebar can be adjusted to one of two positions to suit the rider's preference. Have a Yamaha dealer adjust the position of the handlebar.




1. Handlebar

EAU46833

EAU47261

Rear view mirrors

The rear view mirrors of this vehicle can be folded forward for parking in narrow spaces. Fold the mirrors back to their original position before riding.



- 1. Riding position
- 2. Parking position

WARNING

EWA14372

Be sure to fold the rear view mirrors back to their original position before riding. EAU470

Adjusting the shock absorber assembly

This shock absorber assembly is equipped with a spring preload adjusting ring.

ECA10102


NOTICE

To avoid damaging the mechanism, do not attempt to turn beyond the maximum or minimum settings.

Adjust the spring preload as follows.

To increase the spring preload and thereby harden the suspension, turn the adjusting ring in direction (a). To decrease the spring preload and thereby soften the suspension, turn the adjusting ring in direction (b).

- Align the appropriate notch in the adjusting ring with the position indicator on the shock absorber.
- Use the special wrench and extension bar included in the owner's tool kit to make the adjustment.



- 1. Extension bar
- 2. Special wrench
- 3. Spring preload adjusting ring
- 4. Position indicator

Instrument and control functions

Spring preload setting:

Minimum (soft):

1

Standard:

3

Maximum (hard):

7

EWA10222

WARNING

This shock absorber assembly contains highly pressurized nitrogen gas. Read and understand the following information before handling the shock absorber assembly.

- Do not tamper with or attempt to open the cylinder assembly.
- Do not subject the shock absorber assembly to an open flame or other high heat source.
 This may cause the unit to explode due to excessive gas pressure.
- Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.
- Do not dispose of a damaged or worn-out shock absorber assembly yourself. Take the shock absorber assembly to a Yamaha dealer for any service.

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

TIP

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See the following section for an explanation of the ignition circuit cutoff system.)

EWA10242

EAU15306

WARNING

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly and have a Yamaha dealer repair it if it does not function properly.

Instrument and control functions

EAU66730


Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.

Instrument and control functions



For your safety – pre-operation checks

EAU63440

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

EWA11152

WARNING

Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
Fuel	Check fuel level in fuel tank. Refuel if necessary. Check fuel line for leakage. Check fuel tank breather hose and overflow hose for obstructions, cracks or damage, and check hose connections.	4-11, 4-12
Engine oil	 Check oil level in engine. If necessary, add recommended oil to specified level. Check vehicle for oil leakage. 	7-11
Coolant	Check coolant level in reservoir. If necessary, add recommended coolant to specified level. Check cooling system for leakage.	7-14
Front brake	Check operation. If soft or spongy, have Yamaha dealer bleed hydraulic system. Check brake pads for wear. Replace if necessary. Check fluid level in reservoir. If necessary, add specified brake fluid to specified level. Check hydraulic system for leakage.	7-26, 7-27
Rear brake	 Check operation. If soft or spongy, have Yamaha dealer bleed hydraulic system. Check brake pads for wear. Replace if necessary. Check fluid level in reservoir. If necessary, add specified brake fluid to specified level. Check hydraulic system for leakage. 	7-26, 7-27
Clutch	 Check operation. Lubricate cable if necessary. Check lever free play. Adjust if necessary. 	7-24

For your safety - pre-operation checks

ITEM	CHECKS	PAGE
Throttle grip	 Make sure that operation is smooth. Check throttle grip free play. If necessary, have Yamaha dealer adjust throttle grip free play and lubricate cable and grip housing. 	7-20, 7-31
Control cables	Make sure that operation is smooth.Lubricate if necessary.	7-30
Drive chain	Check chain slack.Adjust if necessary.Check chain condition.Lubricate if necessary.	7-28, 7-30
Wheels and tires	 Check for damage. Check tire condition and tread depth. Check air pressure. Correct if necessary. 	7-21, 7-23
Brake and shift pedals	Make sure that operation is smooth.Lubricate pedal pivoting points if necessary.	7-31
Brake and clutch levers	Make sure that operation is smooth.Lubricate lever pivoting points if necessary.	7-32
Sidestand	Make sure that operation is smooth.Lubricate pivot if necessary.	7-32
Chassis fasteners	Make sure that all nuts, bolts and screws are properly tightened. Tighten if necessary.	
Instruments, lights, signals and switches	Check operation. Correct if necessary.	_
Sidestand switch	Check operation of ignition circuit cut-off system. If system is not working correctly, have Yamaha dealer check vehicle.	4-20

EAU15952

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

EWA10272

WARNING

Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury.

TIP

This model is equipped with:

a lean angle sensor to stop the engine in case of a turnover. In this case, the display will indicate error code 30, but this is not a malfunction. Turn the key to "OFF" and then to "ON" to clear the error code. Failing to do so will prevent the engine from starting even though the engine will crank when pushing the start switch.

EAU47152

 an engine auto-stop system. The engine stops automatically if left idling for 20 minutes. In this case, the display will indicate error code 70, but this is not a malfunction. Push the start switch to clear the error code and to restart the engine.

Starting the engine

In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met.

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.
 - See page 4-21 for more information.
- Turn the key to "ON" and make sure that the engine stop switch is set to "()".

The following warning lights should come on for a few seconds, then go off.

- Oil level warning light
- Coolant temperature warning light
- Engine trouble warning light

ECA1548

EAU4019A

NOTICE

If a warning light does not come on initially when the key is turned to "ON", or if a warning light remains on, see page 4-2 for the corresponding warning light circuit check.

- Shift the transmission into the neutral position. The neutral indicator light should come on. If not, ask a Yamaha dealer to check the electrical circuit.
- 3. Start the engine by pushing the start switch.

If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.


ECA11043

NOTICE

For maximum engine life, never accelerate hard when the engine is cold!

EAU16673

Shifting



- 1. Shift pedal
- 2. Neutral position

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

TIP

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

ECA10261

NOTICE

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.
- Always use the clutch while changing gears to avoid damaging the engine, transmission,

and drive train, which are not designed to withstand the shock of forced shifting.

EAU16682

To start out and accelerate

- 1. Pull the clutch lever to disengage the clutch.
- Shift the transmission into first gear. The neutral indicator light should go out.
- 3. Open the throttle gradually, and at the same time, release the clutch lever slowly.
- 4. At the recommended shift points shown in the following table, close the throttle, and at the same time, quickly pull the clutch lever in.
- 5. Shift the transmission into second gear. (Make sure not to shift the transmission into the neutral position.)
- 6. Open the throttle part way and gradually release the clutch lever.
- 7. Follow the same procedure when shifting to the next higher gear.

TIP _____

When shifting gears in normal operating conditions, use the recommended shift points.

EAU16701

To decelerate

- 1. Apply both the front and the rear brakes to slow the motorcycle.
- Shift the transmission into first gear when the motorcycle reaches 25 km/h (16 mph). If the engine is about to stall or runs very roughly, pull the clutch lever in and use the brakes to stop the motorcycle.

 Shift the transmission into the neutral position when the motorcycle is almost completely stopped. The neutral indicator light should come on.

EAU72960

Recommended shift points

The recommended shift points during acceleration and deceleration are shown in the table below.

Shift up points:

1st \rightarrow 2nd: 20 km/h (12 mph) 2nd \rightarrow 3rd: 30 km/h (19 mph) 3rd \rightarrow 4th: 40 km/h (25 mph) 4th \rightarrow 5th: 50 km/h (31 mph) 5th \rightarrow 6th: 60 km/h (37 mph)

Shift down points:

 $6\text{th} \rightarrow 5\text{th}$: 25 km/h (16 mph) $5\text{th} \rightarrow 4\text{th}$: 25 km/h (16 mph) $4\text{th} \rightarrow 3\text{rd}$: 25 km/h (16 mph) $3\text{rd} \rightarrow 2\text{nd}$: 25 km/h (16 mph)

Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1600 km (1000 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1600 km (1000 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAU17094

EAU16842

0-1000 km (0-600 mi)

Avoid prolonged operation above 5800 r/min. *NOTICE:* After 1000 km (600 mi) of operation, the engine oil must be changed and the oil filter cartridge or element replaced. [ECA10303]

1000-1600 km (600-1000 mi)

Avoid prolonged operation above 7000 r/min.

1600 km (1000 mi) and beyond

The vehicle can now be operated normally.

ECA10311

NOTICE

- Keep the engine speed out of the tachometer red zone.
- If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

Parking

When parking, stop the engine, and then remove the key from the main switch.

EWA10312

EAU17214

⚠ WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.
- Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.
- Do not park near grass or other flammable materials which might catch fire.

EAU17246

Periodic inspection, adjustment, and lubrication will keep your vehicle in the safest and most efficient condition possible. Safety is an obligation of the vehicle owner/operator. The most important points of vehicle inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance charts should be simply considered as a general guide under normal riding conditions. However, depending on the weather, terrain, geographical location, and individual use, the maintenance intervals may need to be shortened.

EWA10322

WARNING

Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If you are not familiar with vehicle service, have a Yamaha dealer perform service.

EWA15123

WARNING

Turn off the engine when performing maintenance unless otherwise specified.

- A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.
- Running the engine while servicing can lead to eye injury, burns, fire, or carbon monoxide poisoning – possibly leading to

death. See page 2-3 for more information about carbon monoxide.

EWA15461

MARNING


Brake discs, calipers, drums, and linings can become very hot during use. To avoid possible burns, let brake components cool before touching them.

EAU17303

Emission controls not only function to ensure cleaner air, but are also vital to proper engine operation and maximum performance. In the following periodic maintenance charts, the services related to emissions control are grouped separately. These services require specialized data, knowledge. equipment. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual that is certified (if applicable). Yamaha dealers are trained and equipped to perform these particular services.

Owner's tool kit

EAU17543



1. Owner's tool kit

The owner's tool kit is located under the passenger seat. (See page 4-13.) The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

TIP

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EAU48491

TIP ___

- From 24000 mi (37000 km) or 36 months, repeat the maintenance intervals starting from 8000 mi (13000 km) or 12 months.
- Items marked with an asterisk require special tools, data and technical skills, have a Yamaha dealer perform the service.

EAU63291

Periodic maintenance chart for the emission control system

			ROUTINE	INTIAL ODOMETER READINGS						
			ROUTINE	INITIAL	ODC)IVIE I	EKK	EADII	NGS	
N	5.	ITEM	× 1000 mi	0.6	4	8	12	16	20	
			× 1000 km	1	7	13	19	25	31	
			month	1	6	12	18	24	30	
1	*	Fuel line	Check fuel hoses for cracks or damage. Replace if necessary.		V	V	V	V	V	
2	*	Spark plugs	Check condition.Adjust gap and clean.		√		√		V	
			Replace.			√		\checkmark		
3	*	Valve clearance	Check and adjust valve clear- ance when engine is cold.	Every 26600 mi (42000 km)					m)	
4	*	Crankcase breather system	Check breather hose for cracks or damage. Replace if necessary.		1	1	√	1	√	
5	*	Fuel injection	Check and adjust engine idle speed and synchronization.	√	V	√	√	√	V	
6	*	Exhaust system	Check for leakage.Tighten if necessary.Replace gasket(s) if necessary.	V	V	√	√	V	V	
7	*	Evaporative emission control system (for California only)	Check control system for damage. Replace if necessary.				√		√	
8	*	Air induction system	Check the air cut-off valve, reed valve, and hose for damage. Replace any damaged parts if necessary.				√		V	

EAU63451

General maintenance and lubrication chart

			ROUTINE	INITIAL	ODO	OMET	ER R	EADI	NGS
No		ITEM	× 1000 mi	0.6	4	8	12	16	20
1	<i>,</i> .	II EIW	× 1000 km	1	7	13	19	25	31
			month	1	6	12	18	24	30
1		Air filter element	Replace.	Every 24000 mi (37000 km					
2	*	Clutch	Check operation. Adjust or replace cable.	V V V V				1	V
3	*	Front brake	Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary.	V	V	V	V	V	V
4	*	Rear brake	Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary.	V	√	V	V	V	V
5	*	Brake hoses	Check for cracks or damage. Check for correct routing and clamping.		√	√	√	√	V
			Replace.	Every 4 years					
6	*	Brake fluid	Change.		Е	very 2	2 year	s	
7	*	Wheels	Check runout and for damage.Replace if necessary.	\ \ \ \ \ \ \ \ \ \ \ \ \				V	V
8	*	Tires	 Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		√	V	V	V	1
9	*	Wheel bearings	Check bearings for smooth operation.Replace if necessary.		√	√	√	√	V
10	*	Swingarm pivot	Check operation and for excessive play.		V	V	V	V	V
10		bearings	Moderately repack with lithium- soap-based grease.	Every 32000 mi (50000 km)					m)
11		Drive chain	Check chain slack, alignment and condition. Adjust and lubricate chain with a special O-ring chain lubricant thoroughly.	Every 600 mi (1000 km) and arter washing the motorcycle, ricing in the rain or riding in wet areas					, rid-
10	*	Stooring keepings	Check bearing assemblies for looseness.	√	√	√	√	√	V
12		Steering bearings	Moderately repack with lithium- soap-based grease.	1- Every 12000 m				000 k	m)

		ROUTINE	INITIAL	ODC	MET	ER R	EADII	NGS
No.	ITEM	× 1000 mi	0.6	4	8	12	16	20
		× 1000 km	1	7	13	19	25	31
		month	1	6	12	18	24	30
13 *	Chassis fasteners	Check all chassis fitting and fasteners. Correct if necessary.		1	1	V	V	V
14	Brake lever pivot shaft	Apply silicone grease lightly.		√	√	~	√	V
15	Brake pedal pivot shaft	 Apply lithium-soap-based grease lightly. 		$\sqrt{}$	√	$\sqrt{}$	V	V
16	Clutch lever pivot shaft	Apply lithium-soap-based grease lightly.		√	√	~	√	V
17	Shift pedal pivot shaft	Apply lithium-soap-based grease lightly.		V	√	√	V	V
18	Sidestand pivot	Check operation.Apply lithium-soap-based grease lightly.		√	√	7	√	√
19 *	Sidestand switch	Check operation and replace if necessary.	V	1	1	V	√	√
20 *	Front fork	Check operation and for oil leakage.Replace if necessary.		V	√	√	~	√
21 *	Shock absorber assembly	Check operation and for oil leakage.Replace if necessary.		1	1	V	√	√
22	Engine oil	Change (warm engine before draining).	V	√	1	1	V	V
23	Engine oil filter car- tridge	• Replace.	V		1		√	
24 *	Cooling system	Check hoses for cracks or damage. Replace if necessary.		V	√	V	V	V
		Change coolant.					$\sqrt{}$	
25 *	Front and rear brake switches	Check operation.	V	√	1	V	V	√
26 *	Control cables	Apply Yamaha cable lubricant or other suitable cable lubricant thoroughly.	V	V	V	V	V	V
27 *	Throttle grip	 Check operation. Check throttle grip free play, and adjust if necessary. Lubricate cable and grip housing. 		√	V	V	V	√

No.			ROUTINE	INITIAL	ODOMETER READING					
	٥.	ITEM	× 1000 IIII 313 1 3	8	12	16	20			
				1	7	13	19	25	31	
			month	1	6	12	18	24	30	
28	*	Lights, signals and switches	Check operation.Adjust headlight beam.	1	1	V	V	V	√	

EAU17651


TIP ____

- Air filter
 - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
 - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
 - After disassembling the brake master cylinders and calipers, always change the fluid. Regularly check the brake fluid levels and fill the reservoirs as required.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.


EAU18713

Removing and installing cowlings and panels


The cowlings and panels shown need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.



- Cowling A
- 2. Cowling B



- 1. Cowling C
- 2. Panel A




- 1. Panel B
- 2. Panel C

EAU55870

Cowling A

To remove the cowling

Remove the bolts, and then take the cowling off.



- 1. Cowling A
- 2. Bolt

To install the cowling


Place the cowling in the original position, and then install the bolts.

Cowlings B and C


To remove a cowling

1. Remove cowling A.

Remove the quick fastener and the bolts, and then take the cowling off.




- 1. Cowling B
- 2. Quick fastener
- 3. Bolt
 - Remove the turn signal light lead from the guide, and then disconnect the turn signal light lead coupler.



- 1. Turn signal light lead
- 2. Guide
- 3. Turn signal light lead coupler

To install a cowling

- Connect the turn signal light coupler, and then route the turn signal light lead through the guide.
- 2. Place the cowling in the original position, and then install the bolts and the quick fastener.




3. Install cowling A.

EAU56060

Panel A

To remove the panel

Remove the bolt and the quick fastener, and then take the panel off.



- 1. Panel A
- 2. Bolt
- 3. Quick fastener


To install the panel

Place the panel in the original position, and then install the bolt and the quick fastener


Panels B and C


To remove a panel

Remove the quick fastener and the bolt.




- 1. Panel B
- 2. Quick fastener
- 3. Bolt
 - 2. Slide the panel backward, and then lift up the rear of the panel slightly.






3. Pull the panel backward to remove it.



To install a panel

1. Fit the projections on the panel into the slots and slide it forward.



2. Install the bolt and the quick fastener.

Checking the spark plugs EAU19643


The spark plugs are important engine components, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, they should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

The porcelain insulator around the center electrode of each spark plug should be a medium-to-light tan (the ideal color when the vehicle is ridden normally), and all spark plugs installed in the engine should have the same color. If any spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle.

If a spark plug shows signs of electrode erosion and excessive carbon or other deposits, it should be replaced.

Specified spark plug: NGK/CR9E

Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.



1. Spark plug gap

Spark plug gap: 0.7–0.8 mm (0.028–0.031 in)

Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.


Tightening torque:

Spark plug: 13 Nm (1.3 m·kgf, 9.4 ft·lbf)

TIP

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

Canister (for California only)



This model is equipped with a canister to prevent the discharging of fuel vapor into the atmosphere. Before operating this vehicle, make sure to check the following:

- Check each hose connection.
- Check each hose and canister for cracks or damage. Replace if damaged.
- Make sure that the canister breather is not blocked, and if necessary, clean it.

EAU46723

Engine oil and oil filter cartridge


The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

- Place the vehicle on a level surface and hold it in an upright position. A slight tilt to the side can result in a false reading.
- Start the engine, warm it up for several minutes, and then turn it off.
- 3. Wait a few minutes until the oil settles.
- 4. Remove the engine oil dipstick and wipe it clean, insert it back into the hole (without screwing it in), and then remove it again to check the oil level.


TIP

The engine oil should be between the minimum and maximum level marks.



- 1. Engine oil dipstick
- 2. Maximum level mark
- 3. Minimum level mark


 If the engine oil is at or below the minimum level mark, remove the oil filler cap, and then add sufficient oil of the recommended type to raise it to the correct level.



- 1. Engine oil filler cap
 - Insert and tighten the engine oil dipstick, and then install and tighten the oil filler cap.

To change the engine oil (with or without oil filter cartridge replacement)

- 1. Remove cowling B. (See page 7-7.)
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Place an oil pan under the engine to collect the used oil.
- Remove the engine oil filler cap, the engine oil drain bolt and its gasket to drain the oil from the crankcase.




- 1. Engine oil drain bolt
- 2. Gasket

TIP____

Skip steps 5–7 if the oil filter cartridge is not being replaced.

5. Remove the oil filter cartridge with an oil filter wrench.




- 1. Oil filter cartridge
- 2. Oil filter wrench

TIP

An oil filter wrench is available at a Yamaha dealer.

Apply a thin coat of clean engine oil to the O-ring of the new oil filter cartridge.




1. O-ring

TIP_

Make sure that the O-ring is properly seated.

 Install the new oil filter cartridge with an oil filter wrench, and then tighten it to the specified torque with a torque wrench.



1. Torque wrench

Tightening torque:

Oil filter cartridge: 17 Nm (1.7 m·kgf, 12 ft·lbf)

8. Install the engine oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Engine oil drain bolt: 43 Nm (4.3 m·kgf, 31 ft·lbf) Refill with the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 9-1.

Oil quantity:

Oil change:

2.50 L (2.64 US qt, 2.20 Imp.qt) With oil filter removal:

2.80 L (2.96 US qt, 2.46 Imp.qt)

TIP ___

Be sure to wipe off spilled oil on any parts after the engine and exhaust system have cooled down.

ECA11621

NOTICE

- In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives. Do not use oils with a diesel specification of "CD" or oils of a higher quality than specified. In addition, do not use oils labeled "ENERGY CONSERVING II" or higher.
- Make sure that no foreign material enters the crankcase.
- Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

TIP_

After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

ECA10402

NOTICE

If the oil level warning light flickers or remains on even if the oil level is correct, immediately turn the engine off and have a Yamaha dealer check the vehicle.

- 11. Turn the engine off, wait a few minutes until the oil settles, and then check the oil level and correct it if necessary.
- 12. Install the cowling.

Coolant

The coolant level should be checked before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

FAI 147334

EAU20071

To check the coolant level


- 1. Place the vehicle on a level surface.
- 2. Remove cowling A. (See page 7-7.)
- 3. Hold the vehicle in an upright position.

TIP ____

- The coolant level must checked on a cold engine since the level varies with engine temperature.
- Make sure that the vehicle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.
- 4. Check the coolant level in the coolant reservoir.


TIP _____

The coolant should be between the minimum and maximum level marks.



- 1. Coolant reservoir
- 2. Maximum level mark
- 3. Minimum level mark
 - 5. If the coolant is at or below the minimum level mark, remove cowling C. (See page 7-7.)
 - 6. Remove the coolant reservoir breather hose from the guide, and then remove the coolant reservoir cap. WARNING! Remove only the coolant reservoir cap. Never attempt to remove the radiator cap when the engine is hot.

[EWA15162]




- 1. Coolant reservoir cap
- 2. Coolant reservoir breather hose
- 3. Guide
 - Add coolant to the maximum level mark, and then install the coolant reservoir cap. NOTICE: If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water

since it is harmful to the engine. If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the cooling system will not be protected against frost and corrosion. If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced. ECA104731

Coolant reservoir capacity (up to the maximum level mark):

0.25 L (0.26 US qt, 0.22 Imp.qt)

8. Route the coolant reservoir breather hose through the guide as shown.




- Coolant reservoir breather hose
- 2. Guide
 - 9. Install the cowlings.

EAU47323


To change the coolant

- Place the vehicle on a level surface and let the engine cool if necessary.
- 2. Remove cowlings A and C. (See page 7-7.)
- 3. Place a container under the engine to collect the used coolant.


 Remove the radiator cap. WARNING! Never attempt to remove the radiator cap when the engine is hot. [EWA10382]




- 1. Radiator cap
 - Remove the coolant reservoir breather hose from the guide, and then remove the coolant reservoir cap.



- 1. Coolant reservoir cap
- 2. Coolant reservoir breather hose
- 3. Guide
 - Remove the coolant reservoir cover and coolant reservoir by removing the bolts.



- 1. Bolt
- 2. Coolant reservoir cover
- 3. Coolant reservoir
 - Drain the coolant from the coolant reservoir by turning it upside down.
 - Remove the coolant drain bolt and its gasket to drain the cooling system.



- 1. Coolant drain bolt
- 2. Gasket
 - After the coolant is completely drained, thoroughly flush the cooling system with clean tap water.
- 10. Install the coolant drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Coolant drain bolt:

10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- Install the coolant reservoir and its cover by placing them in the original position, and then installing the bolts.
- Pour the specified amount of the recommended coolant into the radiator and reservoir.

Antifreeze/water mixture ratio:

1.1

Recommended antifreeze:


High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Coolant quantity:

Radiator (including all routes): 2.00 L (2.11 US qt, 1.76 Imp.qt) Coolant reservoir (up to the maximum level mark):

0.25 L (0.26 US qt, 0.22 Imp.qt)

- 13. Install the radiator cap.
- 14. Install the coolant reservoir cap.
- 15. Start the engine, let it idle for several minutes, and then turn it off.
- Remove the radiator cap to check the coolant level in the radiator. If necessary, add sufficient coolant until it reaches the top of the radiator, and then install the radiator cap.
- Check the coolant level in the reservoir. If necessary, remove the coolant reservoir cap, add coolant to the maximum level mark, and then install the cap.
- Route the coolant reservoir breather hose through the guide as shown.




- 1. Coolant reservoir breather hose
- 2. Guide
- Start the engine, and then check the vehicle for coolant leakage. If coolant is leaking, have a Yamaha dealer check the cooling system.
- 20. Install the cowlings.

EAU47461


Replacing the air filter element

The air filter element should be replaced at the intervals specified in the periodic maintenance and lubrication chart. Replace the air filter element more frequently if you are riding in unusually wet or dusty areas.


- 1. Remove the rider seat. (See page 4-13.)
- 2. Remove panels B and C. (See page 7-7.)
- 3. Remove the fuel tank bolts, and then lift the fuel tank away from the air filter case.



- 1. Fuel tank bolt
 - Remove the air filter case cover by removing the screws. NOTICE: When removing the air filter case cover, be careful not to allow foreign objects to drop into the air intake manifold. ECAL2882I



- 1. Air filter case cover
- 2. Screw
 - 5. Pull the air filter element out.



- 1. Air filter element
- 2. Air intake manifold
 - 6. Insert a new air filter element into the air filter case. NOTICE: Make sure that the air filter element is properly seated in the air filter case. The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.

[ECA10482]


- 7. Install the air filter case cover by installing the screws.
- Place the fuel tank in its original position. Make sure that the fuel hoses are properly connected and routed, and are not pinched. Be sure to place the hoses in their original position. WARNING! Be-

7

Periodic maintenance and adjustment

fore placing the fuel tank in the original position, make sure that all hoses (i.e., fuel hose, fuel tank breather hose, fuel tank overflow hose) are not damaged, that they are properly connected and routed, and that they are not pinched. If any hose is damaged, have a Yamaha dealer replace the hose before starting the engine, otherwise fuel may leak, creating a fire hazard. [EWA12464]

1. Hose



- 1. Original position (paint mark)
 - 9. Install the fuel tank bolts.
- 10. Install the panels.
- 11. Install the rider seat.

Checking the engine idling speed


Check the engine idling speed and, if necessary, have it corrected by a Yamaha dealer.

Engine idling speed: 1250–1350 r/min

EAU21386

Checking the throttle grip free play

Measure the throttle grip free play as shown.



1. Throttle grip free play

Throttle grip free play: 3.0-5.0 mm (0.12-0.20 in)

Periodically check the throttle grip free play and, if necessary, have a Yamaha dealer adjust it. Valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

EAU21402

EAU64250

Tires

Tires are the only contact between the vehicle and the road. Safety in all conditions of riding depends on a relatively small area of road contact. Therefore, it is essential to maintain the tires in good condition at all times and replace them at the appropriate time with the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10504

WARNING

Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Tire air pressure (measured on cold tires):

Up to 90 kg (198 lb) load:

Front:

225 kPa (2.25 kgf/cm², 33 psi)

Rear:

250 kPa (2.50 kgf/cm², 36 psi) 90 kg (198 lb) to maximum load:

Front:

250 kPa (2.50 kgf/cm², 36 psi)

Rear:

290 kPa (2.90 kgf/cm², 42 psi)

Maximum load*:

187 kg (412 lb) (FZ6RGC) 188 kg (414 lb) (FZ6RG)


* Total weight of rider, passenger, cargo and accessories

EWA10512

WARNING

Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.

Tire inspection



- 1. Tire sidewall
- 2. Tire wear indicator
- 3. Tire tread depth

The tires must be checked before each ride. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the sidewall is cracked, contact a Yamaha dealer immediately and have the tire replaced.

Minimum tire tread depth (front and rear):


1.0 mm (0.04 in)

EWA10582

WARNING

- It is dangerous to ride with a worn-out tire. When a tire tread begins to show crosswise lines, have a Yamaha dealer replace the tire immediately.
- The replacement of all wheeland brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience to do so.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

Tire information



- 1. Tire air valve
- 2. Tire air valve core
- 3. Tire air valve cap with seal

This model is equipped with tubeless tires and tire air valves.

Tires age, even if they have not been used or have only been used occasionally. Cracking of the tread and sidewall rubber, sometimes accompanied by

carcass deformation, is an evidence of ageing. Old and aged tires shall be checked by tire specialists to ascertain their suitability for further use.

EWA10902

⚠ WARNING

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle may be different, which could lead to an accident.
- Always make sure that the valve caps are securely installed to prevent air pressure leakage.
- Use only the tire valves and valve cores listed below to avoid tire deflation during a ride.

After extensive tests, only the tires listed below have been approved for this model by Yamaha.

Front tire:

Size:

120/70 ZR17M/C (58W) Manufacturer/model: BRIDGESTONE/BT021 DUNLOP/ROADSMART

Rear tire:

Size:

160/60 ZR17M/C (69W) Manufacturer/model: BRIDGESTONE/BT021 DUNLOP/ROADSMART

FRONT and REAR:

Tire air valve:

TR412

Valve core:

#9100 (original)

EAU21963

Periodic maintenance and adjustment

EWA10601

WARNING

This motorcycle is fitted with superhigh-speed tires. Note the following points in order to make the most efficient use of these tires.


- Use only the specified replacement tires. Other tires may run the danger of bursting at super high speeds.
- Brand-new tires can have a relatively poor grip on certain road surfaces until they have been "broken in". Therefore, it is advisable before doing any highspeed riding to ride conservatively for approximately 100 km (60 mi) after installing a new tire.
- The tires must be warmed up before a high-speed run.
- Always adjust the tire air pressure according to the operating conditions.

Cast wheels

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends, warpage or other damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.

Adjusting the clutch lever free play



- 1. Clutch lever free play adjusting bolt
- 2. Clutch lever free play


The clutch lever free play should measure 10.0–15.0 mm (0.39–0.59 in) as shown. Periodically check the clutch lever free play and, if necessary, adjust it as follows.

To increase the clutch lever free play, turn the clutch lever free play adjusting bolt at the clutch lever in direction (a). To decrease the clutch lever free play, turn the adjusting bolt in direction (b).

TIP_

If the specified clutch lever free play cannot be obtained as described above, proceed as follows.

- 1. Fully turn the adjusting bolt at the clutch lever in direction (a) to loosen the clutch cable.
- 2. Remove cowlings A and B. (See page 7-7.)
- 3. Loosen the locknut further down the clutch cable.
- To increase the clutch lever free play, turn the clutch lever free play adjusting nut in direction (a). To decrease the clutch lever free play, turn the adjusting nut in direction (b).




- 1. Locknut
- 2. Clutch lever free play adjusting nut
 - 5. Tighten the locknut.
 - 6. Install the cowlings.

EAU22274

Periodic maintenance and adjustment

Checking the brake lever free play



1. No brake lever free play

There should be no free play at the brake lever end. If there is free play, have a Yamaha dealer inspect the brake system.


EWA14212

EAU37914

WARNING

A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the vehicle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.

Brake light switches



- 1. Rear brake light switch
- 2. Rear brake light switch adjusting nut

The brake light, which is activated by the brake pedal and brake lever, should come on just before braking takes effect. If necessary, adjust the rear brake light switch as follows, but the front brake light switch should be adjusted by a Yamaha dealer.

Turn the rear brake light switch adjusting nut while holding the rear brake light switch in place. To make the brake light come on earlier, turn the adjusting nut in direction (a). To make the brake light come on later, turn the adjusting nut in direction (b).


EAU22393

FAU22421

Checking the front and rear brake pads

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.


Front brake pads



1. Brake pad wear indicator groove

Each front brake pad is provided with a wear indicator groove, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator groove. If a brake pad has worn to the point that the wear indicator groove has almost disappeared, have a Yamaha dealer replace the brake pads as a set.

Rear brake pads



EAU46292


1. Brake pad wear indicator groove

Each rear brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that a wear indicator groove almost appears, have a Yamaha dealer replace the brake pads as a set.

EAU39373 Checking the brake fluid level


Before riding, check that the brake fluid is above the minimum level mark. Check the brake fluid level with the top of the reservoir level. Replenish the brake fluid if necessary.

Front brake



1. Minimum level mark

Rear brake



1. Minimum level mark

The rear brake fluid reservoir is located behind panel A. (See page 7-7.)

Specified brake fluid: DOT 4

FWA15991

WARNING

Improper maintenance can result in loss of braking ability. Observe these precautions:

- Insufficient brake fluid may allow air to enter the brake sysbraking tem, reducing performance.
- Clean the filler cap before removing. Use only DOT 4 brake fluid from a sealed container.
- Use only the specified brake fluid; otherwise, the rubber seals may deteriorate, causing leakage.
- Refill with the same type of brake fluid. Adding a brake fluid other than DOT 4 may result in a harmful chemical reaction.
- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.

ECA17641

NOTICE

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled fluid immediately.

As the brake pads wear, it is normal for the brake fluid level to gradually go down. A low brake fluid level may indicate worn brake pads and/or brake system leakage; therefore, be sure to check the brake pads for wear and the brake system for leakage. If the brake fluid level goes down suddenly, have a Yamaha dealer check the cause before further riding.

Changing the brake fluid

Have a Yamaha dealer change the brake fluid at the intervals specified in the periodic maintenance and lubrication chart. In addition, have the oil seals of the master cylinders and calipers as well as the brake hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hoses: Replace every four years.

EAU22733

Drive chain slack

The drive chain slack should be checked before each ride and adjusted if necessary.

EAU22779

EAU22762

To check the drive chain slack

 Place the motorcycle on the sidestand.


TIP

When checking and adjusting the drive chain slack, there should be no weight on the motorcycle.

- 2. Shift the transmission into the neutral position.
- Measure the drive chain slack as shown.

Drive chain slack:

45.0-55.0 mm (1.77-2.17 in)



- 1. Drive chain slack
- 4. If the drive chain slack is incorrect, adjust it as follows.

EAU53911

To adjust the drive chain slack


Consult a Yamaha dealer before adjusting the drive chain slack.

 Loosen the locknut at each end of the swingarm, and then loosen the axle nut.


2. To tighten the drive chain, turn the drive chain slack adjusting nut at each end of the swingarm in direction (a). To loosen the drive chain, turn the adjusting nut at each end of the swingarm in direction (b), and then push the rear wheel forward. NOTICE: Improper drive chain slack will overload the engine as well as other vital parts of the motorcycle and can lead to chain slippage or breakage. To prevent this from occurring, keep the drive chain slack within the specified limits. [ECA10572]

TIP

Using the alignment marks on each drive chain puller, make sure that both chain pullers are in the same position for proper wheel alignment.



- 1. Axle nut
- 2. Drive chain slack adjusting nut
- 3. Locknut



- 1. Drive chain puller
- 2. Alignment marks
 - Tighten the axle nut, and then tighten the locknuts to the specified torques.

Tightening torques:

Axle nut: 90 Nm (9.0 m·kgf, 65 ft·lbf) Locknut: 16 Nm (1.6 m·kgf, 12 ft·lbf)

 Make sure that the drive chain pullers are in the same position, the drive chain slack is correct, and the drive chain moves smoothly.

EAU23026

Cleaning and lubricating the drive chain

The drive chain must be cleaned and lubricated at the intervals specified in the periodic maintenance and lubrication chart, otherwise it will quickly wear out, especially when riding in dusty or wet areas. Service the drive chain as follows.

ECA10584

NOTICE

The drive chain must be lubricated after washing the motorcycle, riding in the rain or riding in wet areas.

- Clean the drive chain with kerosene and a small soft brush.
 NOTICE: To prevent damaging the O-rings, do not clean the drive chain with steam cleaners, high-pressure washers or inappropriate solvents. [ECA11122]
- 2. Wipe the drive chain dry.
- Thoroughly lubricate the drive chain with a special O-ring chain lubricant. NOTICE: Do not use engine oil or any other lubricants for the drive chain, as they may contain substances that could damage the O-rings.

[ECA11112]

Checking and lubricating the cables

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it. WARNING! Damage to the outer housing of cables may result in internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions. [EWA10712]

Recommended lubricant:

Yamaha cable lubricant or other suitable cable lubricant

EAU49921


Checking and lubricating the throttle grip and cable

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart.


Checking and lubricating the brake and shift pedals

The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

Brake pedal



Shift pedal




Recommended lubricant: Lithium-soap-based grease

EAU23144


Checking and lubricating the brake and clutch levers

The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Brake lever



Clutch lever




Recommended lubricants:

Brake lever: Silicone grease Clutch lever:

Lithium-soap-based grease

Checking and lubricating the sidestand



The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

EWA10732

WARNING


If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the sidestand could contact the ground and distract the operator, resulting in a possible loss of control.

Recommended lubricant:

Lithium-soap-based grease

EALIM1653

Lubricating the swingarm pivots



The swingarm pivots must be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant: Lithium-soap-based grease

Checking the front fork

The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

Check the inner tubes for scratches, damage and excessive oil leakage.

To check the operation

- Place the vehicle on a level surface and hold it in an upright position. WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. [EWA10752]
- While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.



ECA10591

EAU23273

NOTICE

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.


Checking the steering

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.


- Raise the front wheel off the ground. (See page 7-40.)
 WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. [EWA10752]
- Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.

EAU23285


Checking the wheel bearings



The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.



Battery



- 1. Battery
- 2. Negative battery lead (black)
- 3. Positive battery lead (red)

The battery is located under the rider seat. (See page 4-13.)

This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However, the battery lead connections need to be checked and, if necessary, tightened.

EWA10761

FAU50211

WARNING

- Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.
 - EXTERNAL: Flush with plenty of water.
 - INTERNAL: Drink large quantities of water or milk and immediately call a physician.
 - EYES: Flush with water for 15 minutes and seek prompt medical attention.

- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.
- KEEP THIS AND ALL BATTER-IES OUT OF THE REACH OF CHILDREN.

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the vehicle is equipped with optional electrical accessories.

ECA16522

NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery.

To store the battery

 If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place. NOTICE: When removing the battery, be sure the key is turned to "OFF", then disconnect the negative lead before disconnecting the positive lead.

[ECA16303]

If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.

 Fully charge the battery before installation. NOTICE: When installing the battery, be sure the key is turned to "OFF", then connect the positive lead before connecting the negative lead.

[ECA16841]

4. After installation, make sure that the battery leads are properly connected to the battery terminals.

ECA16531

NOTICE

Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.


Replacing the fuses

The main fuse and the fuse box, which contains the fuses for the individual circuits, are located under the rider seat. (See page 4-13.)


EAU47472

TIP

To access the main fuse, remove the starter relay cover as shown.



- 1. Starter relay cover
- 2. Main fuse
- 3. Spare main fuse
- 4. Fuse box



- 1. Spare fuse
- 2. Headlight fuse
- 3. Ignition fuse
- 4. Signaling system fuse
- 5. Backup fuse (for clock)
- 6. Fuel injection system fuse
- 7. Radiator fan motor fuse

If a fuse is blown, replace it as follows.

1. Turn the key to "OFF" and turn off the electrical circuit in question.

 Remove the blown fuse, and then install a new fuse of the specified amperage. WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire. [EWA15132]

Specified fuses:

Main fuse:
30.0 A
Headlight fuse:
15.0 A
Signaling system fuse:
15.0 A
Ignition fuse:
10.0 A
Radiator fan motor fuse:
20.0 A
Fuel injection system fuse:
10.0 A
Backup fuse:
10.0 A

- 3. Turn the key to "ON" and turn on the electrical circuit in question to check if the device operates.
- 4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

Replacing the headlight bulb

This model is equipped with a halogen bulb headlight. If the headlight bulb burns out, replace it as follows.

ECA10651

NOTICE

Take care not to damage the following parts:


Headlight bulb

Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.


Headlight lens

Do not affix any type of tinted film or stickers to the headlight lens.


Do not use a headlight bulb of a wattage higher than specified.



- 1. Do not touch the glass part of the bulb.
 - Remove cowlings A and C. (See page 7-7.)
 - Disconnect the headlight coupler, and then remove the headlight bulb cover.




- 1. Headlight bulb cover
- 2. Headlight coupler
 - 3. Unhook the headlight bulb holder, and then remove the burnt-out bulb.




- 1. Headlight bulb holder
- 2. Headlight bulb
 - 4. Place a new headlight bulb into position, and then secure it with the bulb holder.
 - 5. Install the headlight bulb cover, and then connect the coupler.
 - 6. Install the cowlings.
 - 7. Have a Yamaha dealer adjust the headlight beam if necessary.

Replacing the brake/tail light bulb

- 1. Remove the passenger seat. (See page 4-13.)
- 2. Remove the owner's tool kit.
- 3. Remove the brake/tail light bulb socket (together with the bulb) by turning it counterclockwise.




- 1. Brake/tail light bulb socket
 - 4. Remove the burnt-out bulb by pulling it out.




- 1. Brake/tail light bulb
- 2. Brake/tail light bulb socket
 - 5. Insert a new bulb into the socket.
 - 6. Install the socket (together with the bulb) by turning it clockwise.
 - 7. Install the owner's tool kit.
 - 8. Install the passenger seat.

Replacing a turn signal light bulb


1. Remove the turn signal light unit by removing the screw.



- 1. Turn signal light unit
- 2. Screw
 - 2. Remove the turn signal light bulb socket (together with the bulb) by turning it counterclockwise.



- 1. Turn signal light bulb socket
 - 3. Remove the burnt-out bulb by pulling it out.




- 1. Turn signal light bulb
 - 4. Insert a new bulb into the socket.
 - 5. Install the socket (together with the bulb) by turning it clockwise.
 - Install the turn signal light unit by installing the screw. NOTICE: Do not overtighten the screw, otherwise the lens may break. [ECA11192]


EAU24314

Replacing the license plate light bulb

1. Remove the license plate light unit by removing the screws.



- 1. License plate light unit
- 2. Screw
 - Remove the license plate light bulb socket (together with the bulb) by pulling it out.



- 1. License plate light bulb socket
- 2. License plate light bulb
 - 3. Remove the burnt-out bulb by pulling it out.
 - 4. Insert a new bulb into the socket.
 - 5. Install the socket (together with the bulb) by pushing it in.
 - Install the license plate light unit by installing the screws.

EAU24351

Supporting the motorcycle

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.

To service the front wheel

- Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
- 2. Raise the front wheel off the ground by using a motorcycle stand.

To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

Front wheel

EAU24361

EAU56391


To remove the front wheel

FWA10822


WARNING

To avoid injury, securely support the vehicle so there is no danger of it falling over.

 Loosen the front wheel axle pinch bolt, then the wheel axle and the brake caliper bolts.



- 1. Front wheel axle pinch bolt
- 2. Wheel axle
- 3. Brake caliper bolt
 - Lift the front wheel off the ground according to the procedure in the previous section "Supporting the motorcycle".
 - Remove the brake caliper (together with the reflector) on each side by removing the bolts. NOTICE:
 Do not apply the brake after the brake calipers have been removed, otherwise the brake pads will be forced shut. [ECA11052]



- 1. Reflector
- 2. Brake caliper bolt
- 3. Brake caliper
 - 4. Remove the wheel axle, and then remove the wheel.

To install the front wheel

- Lift the wheel up between the fork legs.
- Insert the wheel axle.
- Install the brake caliper (together with the reflector) on each side by installing the bolts.

TIP

Make sure that there is enough space between the brake pads before installing the brake calipers onto the brake discs.

- Lower the front wheel so that it is on the ground, and then put the sidestand down.
- Tighten the wheel axle, the front wheel axle pinch bolt and the brake caliper bolts to the specified torques.

Tightening torques:

Wheel axle: 65 Nm (6.5 m·kgf, 47 ft·lbf) Front wheel axle pinch bolt: 19 Nm (1.9 m·kgf, 14 ft·lbf) Brake caliper bolt: 40 Nm (4.0 m·kgf, 29 ft·lbf)

Push down hard on the handlebar several times to check for proper fork operation.

Rear wheel

EAU25081

EAU56662


To remove the rear wheel

EWA10822


WARNING

To avoid injury, securely support the vehicle so there is no danger of it falling over.

- Loosen the locknut and drive chain slack adjusting nut on each side of the swingarm.
- 2. Loosen the axle nut.




- 1. Axle nut
- 2. Drive chain slack adjusting nut
- 3. Locknut
 - 3. Lift the rear wheel off the ground according to the procedure on page 7-40.
 - 4. Remove the axle nut.
 - Push the wheel forward, and then remove the drive chain from the rear sprocket.



TIP

- If the drive chain is difficult to remove, remove the wheel axle first, and then lift the wheel upward enough to remove the drive chain from the rear sprocket.
- The drive chain does not need to be disassembled in order to remove and install the rear wheel.
- While supporting the brake caliper and slightly lifting the wheel, pull the wheel axle out.



- 1. Brake caliper
- 2. Wheel axle

TIP ___


A rubber mallet may be useful to tap the wheel axle out. 7. Remove the wheel. **NOTICE:** Do not apply the brake after the wheel and brake disc have been removed, otherwise the brake pads will be forced shut. [ECA11073]

To install the rear wheel

 Install the wheel and the brake caliper bracket by inserting the wheel axle from the right side.

TIP _____

- Make sure that the slot in the brake caliper bracket is fit over the retainer on the swingarm.
- Make sure that there is enough space between the brake pads before installing the wheel.



- 1. Brake caliper bracket
- 2. Slot
- 3. Retainer
 - Install the drive chain onto the rear sprocket.
 - 3. Install the axle nut.
 - 4. Lower the rear wheel so that it is on the ground, and then put the sidestand down.
 - 5. Adjust the drive chain slack. (See page 7-28.)
 - Tighten the axle nut, and then tighten the locknuts to the specified torques.

Tightening torques:

Axle nut:

90 Nm (9.0 m·kgf, 65 ft·lbf)

Locknut:

16 Nm (1.6 m·kgf, 12 ft·lbf)

Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15142

FAI 125872


WARNING


When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.


Troubleshooting charts


EAU63470

Starting problems or poor engine performance










Engine overheating

WARNING

EWAT1041

- Do not remove the radiator cap when the engine and radiator are hot.
 Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.
- Place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



TIP

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.

Matte color caution

EAU37834 ECA15193

NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

Before cleaning

- Cover the muffler outlet with a plastic bag after the engine has cooled down.
- Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
- Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets, sprockets, the drive chain and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

ECA10773

EAU54661

NOTICE

 Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the af-

fected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.

- Improper cleaning can damage plastic parts (such as cowlings, panels, windshields, headlight lenses, meter lenses, etc.) and the mufflers. Use only a soft, clean cloth or sponge with water to clean plastic. However, if the plastic parts cannot be thoroughly cleaned with water, diluted mild detergent with water may be used. Be sure to rinse off any detergent residue using plenty of water, as it is harmful to plastic parts.
- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swingarm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
- For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or

scratching. Some cleaning compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

TIP_

Salt sprayed on roads in the winter may remain well into spring.

 Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down. NOTICE: Do not use warm water since it increases the corrosive action of the salt. [ECA10792]

 Apply a corrosion protection spray on all metal, including chromeand nickel-plated, surfaces to prevent corrosion.

Cleaning the windshield

Avoid using any alkaline or strong acid cleaner, gasoline, brake fluid, or any other solvent. Clean the windshield with a cloth or sponge dampened with a mild detergent, and then wash it off thoroughly with water. For additional cleaning, use Yamaha Windshield Cleaner or another high-quality windshield cleaner. Some cleaning compounds for plastics may scratches on the windshield. Before using such cleaners, test an area of the windshield which does not affect your visibility and which cannot be easily recognized.

After cleaning

- 1. Dry the motorcycle with a chamois or an absorbing cloth.
- 2. Immediately dry the drive chain and lubricate it to prevent it from rusting.
- Use a chrome polish to shine chrome, aluminum and stainlesssteel parts, including the exhaust system. (Even the thermally induced discoloring of stainlesssteel exhaust systems can be removed through polishing.)
- To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
- 5. Use spray oil as a universal cleaner to remove any remaining dirt.

- 6. Touch up minor paint damage caused by stones, etc.
- 7. Wax all painted surfaces.
- 8. Let the motorcycle dry completely before storing or covering it.

EWA11132

WARNING

Contaminants on the brakes or tires can cause loss of control.

- Make sure that there is no oil or wax on the brakes or tires.
- If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent. Before riding at higher speeds, test the motorcycle's braking performance and cornering behavior.

ECA10801

NOTICE

- Apply spray oil and wax sparingly and make sure to wipe off any excess.
- Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.
- Avoid using abrasive polishing compounds as they will wear away the paint.

TIP

- Consult a Yamaha dealer for advice on what products to use.
- Washing, rainy weather or humid climates can cause the headlight lens to fog. Turning the headlight

on for a short period of time will help remove the moisture from the lens.

Storage

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover. Be sure the engine and the exhaust system are cool before covering the motorcycle.

FCA10811

EAU26183

NOTICE

- Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.
- To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.

Long-term

Before storing your motorcycle for several months:

- 1. Follow all the instructions in the "Care" section of this chapter.
- 2. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
- 3. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion.
 - a. Remove the spark plug caps and spark plugs.
 - b. Pour a teaspoonful of engine oil into each spark plug bore.
 - c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylin-

8

Motorcycle care and storage

- der head so that the electrodes are grounded. (This will limit sparking during the next step.)
- d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.) WARNING! To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.

[EWA10952]

- Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.
- Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
- Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
- Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
- 7. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place [less than 0 °C (30 °F) or more than 30 °C (90 °F)]. For more information on storing the battery, see page 7-35.

TIP ____

Make any necessary repairs before storing the motorcycle.

Specifications

Dimensions:

Overall length:

2120 mm (83.5 in)

Overall width:

770 mm (30.3 in)

Overall height:

1185 mm (46.7 in)

Seat height:

785 mm (30.9 in)

Wheelbase:

1440 mm (56.7 in)

Ground clearance:

140 mm (5.51 in)

Minimum turning radius:

2.8 m (9.19 ft)

Weight:

Curb weight:

212 kg (467 lb) (FZ6RG)

213 kg (470 lb) (FZ6RGC)

Engine:

Combustion cycle:

4-stroke

Cooling system:

Liquid cooled

Valve train:

DOHC

Cylinder arrangement:

Inline

Number of cylinders:

4-cylinder

Displacement:

600 cm³

Bore × stroke:

 $65.5 \times 44.5 \text{ mm} (2.58 \times 1.75 \text{ in})$

Compression ratio:

12.2:1

Starting system:

Electric starter

Lubrication system:

Wet sump

Engine oil:


Recommended brand:

YAMALUBE

SAE viscosity grades:

10W-40, 10W-50, 15W-40, 20W-40 or

20W-50



Recommended engine oil grade:

API service SG type or higher, JASO

standard MA

Engine oil quantity:

Oil change:

2.50 L (2.64 US qt, 2.20 Imp.qt)

With oil filter removal:

2.80 L (2.96 US qt, 2.46 Imp.qt)

Coolant quantity:

Coolant reservoir (up to the maximum level mark):

0.25 L (0.26 US qt, 0.22 Imp.qt)

Radiator (including all routes):

2.00 L (2.11 US qt, 1.76 Imp.qt)

Air filter:

Air filter element:

Oil-coated paper element

Fuel:

Recommended fuel:

Regular unleaded gasoline (Gasohol [E10]

acceptable)

Fuel tank capacity:

17 L (4.5 US gal, 3.7 Imp.gal)

Fuel reserve amount:

3.2 L (0.84 US gal, 0.70 Imp.gal)

Fuel injection:

Throttle body:

ID mark:

20SF 20 (FZ6RG)

36PT 10 (FZ6RGC)

Spark plug(s):

Manufacturer/model:

NGK/CR9E

Spark plug gap:

0.7-0.8 mm (0.028-0.031 in)

Clutch:

Clutch type:

Wet, multiple-disc

Specifications

Drivetrain:	Loading:		
Primary reduction ratio:	Maximum load:		
1.955 (86/44)	187 kg (412 lb) (FZ6RGC)		
Final drive:	188 kg (414 lb) (FZ6RG)		
Chain	(Total weight of rider, passenger, cargo		
Secondary reduction ratio:	and accessories)		
2.875 (46/16)	Tire air pressure (measured on cold		
Transmission type:	tires):		
Constant mesh 6-speed	Up to 90 kg (198 lb) load:		
Gear ratio:	Front:		
1st:	225 kPa (2.25 kgf/cm², 33 psi)		
2.846 (37/13)	Rear:		
2nd:	250 kPa (2.50 kgf/cm², 36 psi)		
1.947 (37/19)	90 kg (198 lb) load - maximum load:		
3rd:	Front:		
1.556 (28/18)	250 kPa (2.50 kgf/cm², 36 psi)		
4th:	Rear:		
1.333 (32/24)	290 kPa (2.90 kgf/cm², 42 psi)		
5th:	Front wheel:		
1.190 (25/21) 6th:	Wheel type:		
	Cast wheel		
1.083 (26/24) Chassis:	Rim size:		
	17M/C x MT3.50		
Frame type:	Rear wheel:		
Diamond	Wheel type:		
Caster angle: 26.0 °	Cast wheel		
Zo.u Trail:	Rim size:		
103 mm (4.1 in)	17M/C x MT4.50		
Front tire:	Front brake:		
Type:	Type:		
Tubeless	Hydraulic dual disc brake		
Size:	Specified brake fluid:		
120/70 ZR17M/C (58W)	DOT 4		
Manufacturer/model:	Rear brake:		
BRIDGESTONE/BT021	Type:		
Manufacturer/model:	Hydraulic single disc brake		
DUNLOP/ROADSMART	Specified brake fluid:		
Rear tire:	DOT 4		
Type:	Front suspension:		
Tubeless	Type:		
Size:	Telescopic fork		
160/60 ZR17M/C (69W)	Spring:		
Manufacturer/model:	Coil spring		
BRIDGESTONE/BT021	Shock absorber:		
Manufacturer/model:	Hydraulic damper		
DUNLOP/ROADSMART	Wheel travel: 130 mm (5.1 in)		
	_ ` _ '		
	Rear suspension:		
	Type:		
	Swingarm		

Specifications

Spring: Coil spring Shock absorber: Gas-hydraulic damper Wheel travel: 130 mm (5.1 in) **Electrical system:** System voltage: 12 V Ignition system: TCI Charging system: AC magneto **Battery:** Model: GT12B-4 Voltage, capacity: 12 V, 10.0 Ah (10 HR) **Headlight:** Bulb type: Halogen bulb Bulb wattage × quantity: Headlight: H4, 60.0 W/55.0 W x 1 Brake/tail light: 21.0 W/5.0 W × 1 Front turn signal/position light: 21.0 W/5.0 W × 2 Rear turn signal light: 21.0 W × 2 License plate light: 5.0 W × 1 Meter lighting: **LED** Neutral indicator light: High beam indicator light: Oil level warning light: Turn signal indicator light: **LED**

Coolant temperature warning light:

Engine trouble warning light:

LED Fuse(s): Main fuse: 30.0 A

Headlight fuse: 15.0 A Signaling system fuse: 15.0 A lanition fuse: 10.0 A Radiator fan motor fuse: 20.0 A Fuel injection system fuse: 10.0 A Backup fuse:

10.0 A


Consumer information

Identification numbers

Record the vehicle identification number, engine serial number, model label information, and the key identification number in the spaces provided below. These identification numbers are needed when registering the vehicle with the authorities in your area and when ordering spare parts from a Yamaha dealer.

VEHICLE IDENTIFICATION NUMBER:
ENGINE SERIAL NUMBER:
MODEL LABEL INFORMATION:
○●
KEY IDENTIFICATION NUMBER:

Vehicle identification number



1. Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

TIP


EAU26357

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.

Engine serial number

EAU26442

EAU26401




1. Engine serial number

The engine serial number is stamped into the crankcase.

Model label

EAU26521



1. Model label


The model label is affixed to the frame under the passenger seat. (See page 4-13.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

Key identification number

EAU26382

Vehicle Emission Control Information label

EAU48271



1. Vehicle Emission Control Information label

The Vehicle Emission Control Information label is affixed at the location in the illustration. This label shows specifications related to exhaust emissions as required by federal law, state law and Environment Canada.

10

1 [

1. Key identification number

The key identification number is stamped into the key tag. Record this number in the space provided and use it for reference when ordering a new key.

Consumer information

EAU26553

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Yamaha Motor Corporation, U.S.A. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Yamaha Motor Corporation, U.S.A. To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

10

Motorcycle noise regulation TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED:

Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

"AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW".

These acts include tampering with the following systems; i.e., modification, removal, etc.

Exhaust system

- Muffler
- Exhaust pipe
- Silencer

Intake system

- Air cleaner case
- Air cleaner element
- Intake duct

Consumer information

EAU63481

Maintenance record

Copies of work orders and/or receipts for parts purchased and installed on your vehicle will be required to document that maintenance has been completed in accordance with the emissions warranty. The chart below is printed only as a reminder that maintenance work is required. It is not acceptable proof of maintenance work.

Maintenance interval	Date of service	Mileage	Servicing dealer name and address	Remarks
600 mi (1000 km) or 1 month				
4000 mi (7000 km) or 6 months				
8000 mi (13000 km) or 12 months				
12000 mi (19000 km) or 18 months				
16000 mi (25000 km) or 24 months				
20000 mi (31000 km) or 30 months				
24000 mi (37000 km) or 36 months				
28000 mi (43000 km) or 42 months				
32000 mi (49000 km) or 48 months				
36000 mi (55000 km) or 54 months				
40000 mi (61000 km) or 60 months				

10

FALI63493

YAMAHA MOTOR CORPORATION, U.S.A. 2015 AND LATER MODEL STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY

Yamaha Motor Corporation, U.S.A. hereby warrants that each new Yamaha motorcycle purchased from an authorized Yamaha motorcycle dealer in the continental United States will be free from defects in material and workmanship for the period of time stated herein, subject to certain stated limitations.

THE PERIOD OF WARRANTY for Yamaha motorcycles originally equipped with headlight, stoplight, and turn signals shall be one (1) year from the date of purchase, with no mileage limitation, except for the battery, which is warranted for thirty (30) days from the date of purchase.

MODELS EXCLUDED FROM WARRANTY include those used for non-Yamaha-authorized renting, leasing, or other commercial purposes.

DURING THE PERIOD OF WARRANTY any authorized Yamaha motorcycle dealer will, free of charge, repair or replace, at Yamaha's option, any part adjudged defective by Yamaha due to faulty workmanship or material from the factory. Parts used in warranty repairs will be warranted for the balance of the product's warranty period. All parts replaced under warranty become the property of Yamaha Motor Corporation, U.S.A.

GENERAL EXCLUSIONS from this warranty shall include any failures caused by:

- a. Competition or racing use.
- b. Installation of parts or accessories that are not qualitatively equivalent to genuine Yamaha parts.
- c. Abnormal strain, neglect, or abuse
- d. Lack of proper maintenance and off-season storage as described in the Owner's Manual.
- e. Accident or collision damage.
- f. Modification to original parts.
- g. Damage due to improper transportation

SPECIFIC EXCLUSIONS from this warranty shall include parts replaced due to normal wear or routine maintenance.

THE CUSTOMER'S RESPONSIBILITY under this warranty shall be to:

- 1. Operate and maintain the motorcycle as specified in the appropriate Owner's Manual, and
- Give notice to an authorized Yamaha motorcycle dealer of any and all apparent defects within ten (10) days after discovery, and make the machine available at that time for inspection and repairs at such dealer's place of business.

WARRANTY TRANSFER: To transfer the warranty from the original purchaser to any subsequent purchaser, it is imperative that the machine be inspected and registered for warranty by an authorized Yamaha motorcycle dealer. In order for this warranty to remain in effect, this inspection and registration must take place within ten (10) days after transfer. A reasonable dealer-imposed fee may be charged for the inspection.

EMISSIONS CONTROL SYSTEM WARRANTY

280cc or over

Yamaha Motor Corporation, U.S.A. also warrants to the ultimate purchaser and each subsequent purchaser of each Yamaha motorcycle covered by this warranty with a displacement of 50cc or greater, that the vehicle is designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards applicable at the time of manufacture and that it is free from defects in materials and workmanship which would cause it not to meet these standards within the periods listed immediately below. Failures other than those resulting from defects in material or workmanship which arise solely as a result of owner abuse and/or lack of proper maintenance are not covered by this warranty.

ENGINE DISPLACEMENT
50cc to 169cc
12,000 km (7,465 miles) or five years, whichever occurs first
170cc to 279cc
18,000 km (11,185 miles) or five years, whichever occurs first

YAMAHA MOTOR CORPORATION, U.S.A. MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEED THE OBLIGATIONS AND TIME LIMITS STATED IN THIS WARRANTY ARE HEREBY DISCLAIMED BY YAMAHA MOTOR CORPORATION, U.S.A. AND EXCLUDED FROM THIS WARRANTY.

30,000 km (18,641 miles) or five years, whichever occurs first

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. ALSO EXCLUDED FROM THIS WARRANTY ARE ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING LOSS OF USE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

YAMAHA MOTOR CORPORATION, U.S.A. P.O. Box 6555 Cypress, California 90630

Consumer information

WARRANTY QUESTIONS AND ANSWERS

- Q. What costs are my responsibility during the warranty period?
- A. The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accident and collision damages, and oil, oil filters, air filters, spark plugs, and brake shoes.
- Q. What are some examples of "abnormal" strain, neglect, or abuse?
- A. These terms are general and overlap each other in areas. Specific examples include: Running the machine out of oil, sustained high rpm, full-throttle, operating the machine with a broken or damaged part which causes another part to fail, damage or failure due to improper or careless transportation and/or tie-down. If you have any specific questions on operation or maintenance, please contact your dealer for advice.
- Q. Does the warranty cover incidental costs such as towing or transportation due to a failure?
- A. No. The warranty is limited to repair of the machine itself.
- Q. May I perform any or all of the recommended maintenance shown in the Owner's Manual instead of having the dealer do them?
- A. Yes, if you are a qualified mechanic and follow the procedures specified in the Owner's and Service Manual. We do recommend, however, that items requiring special tools or equipment be done by a Yamaha motorcycle dealer.
- Q. Will the warranty be void or cancelled if I do not operate or maintain my new motorcycle exactly as specified in the Owner's Manual?
- A. No. The warranty on a new motorcycle cannot be "voided" or "cancelled." However, if a particular failure is caused by operation or maintenance other than as described in the Owner's Manual, that failure may not be covered under warranty.
- Q. What responsibility does my dealer have under this warranty?
- A. Each Yamaha motorcycle dealer is expected to:
 - Completely set up every new machine before sale.
 - Explain the operation, maintenance, and warranty requirements to your satisfaction at the time of sale, and upon your request at any later date.
 - 3. Each Yamaha motorcycle dealer is held responsible for his setup, service and warranty repair work.
- Q. Is the warranty transferable to second owners?
- A. Yes. The remainder of the existing warranty can be transferred upon request. The unit has to be inspected and re-registered by an authorized Yamaha motorcycle dealer for the policy to remain effective.

CUSTOMER SERVICE

If your machine requires warranty service, you must take it to any authorized Yamaha motorcycle dealer within the continental United States. Be sure to bring your warranty registration card or other valid proof of the original date of purchase. If a question or problem arises regarding the warranty, first contact the owner of the dealership. Since all warranty matters are handled at the dealer level, this person is in the best position to help you. IF you are still not satisfied and require additional assistance, please write to:

YAMAHA MOTOR CORPORATION, U.S.A. CUSTOMER RELATIONS DEPARTMENT P.O. Box 6555 Cypress, California 90630

When contacting Yamaha Motor Corporation, U.S.A., don't forget to include any important information such as names, addresses, model, V.I.N. (frame number), dates, and receipts.

CHANGE OF ADDRESS

The federal government requires each manufacturer of a motor vehicle to maintain a complete, up-to-date list of all first purchasers against the possibility of a safety-related defect and recall. This list is compiled from the purchase registrations sent to Yamaha Motor Corporation, U.S.A. by the selling dealer at the time of your purchase.

If you should move after you have purchased your new motorcycle, please advise us of your new address by sending a postcard listing your motorcycle model name, V.I.N. (frame number), dealer number (or dealer's name) as it is shown on your warranty card, your name and new mailling address. Mail to:

YAMAHA MOTOR CORPORATION, U.S.A. P.O. Box 6555 Cypress, California 90630 Attention: Warranty Department

This will ensure that Yamaha Motor Corporation, U.S.A. has an up-to-date registration record in accordance with federal law.

10

YAMAHA EXTENDED SERVICE (Y.E.S.)

Keep your Yamaha protected even after your warranty expires with genuine Yamaha Extended Service (Y.E.S.).

- Y.E.S. is designed and administered by Yamaha Motor Corporation to provide maximum owner satisfaction. You get uninterrupted factory-backed coverage for extra peace of mind.
- Y.E.S. is flexible. You choose the plan that's right for you: 12 months, 24 months, 36 months or, on certain models, even 48 months beyond your warranty period.
- Y.E.S. is designed and administered by the same Yamaha people who handle your warranty—
 and it shows in the comprehensive coverage benefits. There are no mileage limitations.
 Coverage isn't limited to "moving parts" or the "drive train" like many other plans. And Y.E.S.
 covers manufacturing defects just like the warranty. See the sample contract at your Yamaha
 dealer to see how comforting uninterrupted factory-backed protection can be.
- You don't have to pay anything for covered repairs. There's no deductible to pay, and repairs
 aren't "pro-rated." You don't have any "out-of-pocket" expenses for covered repairs.
- In addition, Travel and Recreation Interruption Protection (TRIP) is included at no extra cost.
 TRIP gives you up to \$250 reimbursement per occurrence for any reasonable expenses you
 incur because your Yamaha needs covered service: replacement vehicle rental, emergency
 towing, phone calls, even food and lodging when you are away from home. This superb
 coverage goes into effect when you purchase Y.E.S., so it applies to any warranty repairs as
 well as covered repairs during your entire Y.E.S. plan period.
- Y.E.S. coverage is honored at any authorized Yamaha dealer nationwide.
- Y.E.S. coverage is transferable to a new owner if you sell or trade-in. That can make your Yamaha much more valuable!

This excellent Y.E.S. plan coverage is only available to Yamaha owners like you, and only while your Yamaha is still within the Yamaha Limited Warranty period. So visit your authorized Yamaha dealer to get all the facts. He can show you how easy it is to protect your investment with Yamaha Extended Service.

Consumer information

We urge you to act now. You'll get the excellent benefits of TRIP coverage right away, and you'll rest easy knowing you'll have strong factory-backed protection even after your Yamaha Limited Warranty expires.

A special note:

If visiting your dealer isn't convenient, contact Yamaha with your Primary ID number (your frame number). We'll be happy to help you get the Y.E.S. coverage you need.

Yamaha Service Marketing P.O. Box 6555 Cypress, CA 90630 1-(866)-YES-EXTD (1-866-937-3983)







YAMAHA EXTENDED SERVICE

Index

A	Horn switch4-8
Air filter element, replacing7-18	1
В	Identification numbers10-1
Battery7-35	Ignition circuit cut-off system 4-21
Brake and clutch levers, checking and	Indicator lights and warning lights 4-2
lubricating7-32	K
Brake and shift pedals, checking and	Key identification number 10-2
lubricating7-31	L
Brake fluid, changing7-28	Labels, location 1-1
Brake fluid level, checking7-27	License plate light bulb, replacing 7-40
Brake lever4-9	M
Brake lever free play, checking7-25	Main switch/steering lock 4-1
Brake light switches7-25	Maintenance and lubrication, periodic 7-4
Brake pedal4-10	Maintenance, emission control
C	system7-3
Cables, checking and lubricating7-30	Maintenance record 10-5
Canister (for California only)7-11	Matte color, caution 8-1
Care8-1	Model label10-2
Catalytic converter4-13	Multi-function meter unit 4-4
Clutch lever4-8	N
Clutch lever free play, adjusting7-24	Neutral indicator light 4-2
Coolant7-14	Noise regulation 10-4
Coolant temperature warning light4-3	0
Cowlings and panels, removing and	Oil level warning light 4-2
installing7-7	Р
D	Parking 6-5
Dimmer switch4-7	Part locations 3-1
Drive chain, cleaning and lubricating7-30	R
Drive chain slack7-28	Rear view mirrors 4-19
E	Rider seat height, adjusting 4-15
Engine break-in6-4	S
Engine idling speed, checking7-19	Safety defects, reporting10-3
Engine oil and oil filter cartridge7-11	Safety information2-1
Engine serial number10-1	Seats 4-13
Engine stop switch4-8	Shifting 6-3
Engine trouble warning light4-3	Shift pedal 4-9
F	Shock absorber assembly, adjusting 4-19
Front and rear brake pads, checking7-26	Sidestand 4-20
Front fork, checking7-33	Sidestand, checking and lubricating 7-32
Fuel4-11	Spark plugs, checking7-10
Fuel tank breather hose and overflow	Specifications9-1
hose4-12	Starting the engine 6-2
Fuel tank cap4-10	Start switch 4-8
Fuses, replacing7-36	Steering, checking7-34
H	Storage8-4
Handlebar position, adjusting4-18	Storage compartment 4-18
Handlebar switches	Supporting the motorcycle7-40
Headlight bulb, replacing7-37	_Swingarm pivots, lubricating7-33
Helmet holder4-17	Т
High beam indicator light4-2	Tail/brake light bulb, replacing 7-38

Index

Throttle grip and cable, checking and lubricating	. 7-31
Throttle grip free play, checking	
Tires	
Tool kit	7-2
Troubleshooting	. 7-44
Troubleshooting charts	. 7-45
Turn signal indicator light	4-2
Turn signal light bulb, replacing	. 7-39
Turn signal switch	4-7
V	
Valve clearance	. 7-20
Vehicle Emission Control Information	
label	. 10-2
Vehicle identification number	. 10-1
W	
Warranty, extended	. 10-8
Warranty, limited	. 10-6
Wheel bearings, checking	. 7-34
Wheel (front)	. 7-41
Wheel (rear)	. 7-42
Wheels	. 7-23

For your best ownership experience, think **Genuine Yamaha!**

Genuine Yamaha Parts – Genuine Yamaha replacement parts are the exact same parts as the ones originally equipped on your vehicle, providing you with the performance and durability you have come to expect. Why settle for aftermarket parts that may not provide full confidence and satisfaction?

Genuine Yamaha Accessories – Yamaha only offers accessories that meet our high standards for quality and performance. Buy with confidence, knowing your Genuine Yamaha Accessories will fit right and perform right – right out of the box.

Yamalube – Take care of your Yamaha with legendary Yamalube oils, lubricants, and care products. They're formulated and approved by the toughest judges we know: the Yamaha engineering teams that know your Yamaha from the inside out.

Genuine Yamaha Service Manuals – Get the same factory manual for your vehicle that the technicians at your authorized Yamaha dealer use. Service manuals are available through your Yamaha dealer or you can order them directly through yamahapubs.com (for US consumers only).

Genuine Yamaha products are available only from your Yamaha dealer.

Find out more at:

For US consumers, please visit yamaha-motor.com For Canadian consumers, please visit yamaha-motor.ca

