

# USER MANUAL

**EDECOA®**

**HYBRID INVERTER / CHARGER**

**MODEL:**

EM-352A

EM-654A

VERSION:2.3

**Language:** English/Deutsch/Français/Español/Italiano

# Table Of Contents

ABOUT THIS MANUAL .....	3
SAFETY INSTRUCTIONS .....	3
INTRODUCTION .....	4
<b>Features</b> .....	4
<b>Basic System Architecture</b> .....	4
<b>Product Overview</b> .....	5
OPERATION .....	6
<b>Power ON/OFF</b> .....	6
<b>Operation and Display Panel</b> .....	6
<b>LCD Setting</b> .....	8
<b>Lithium battery connection</b> .....	18
<b>LCD Display Information</b> .....	23
<b>Operating Mode Description</b> .....	26
<b>Battery Equalization Description</b> .....	30
<b>Warning Indicator</b> .....	32
SPECIFICATIONS .....	33
<b>Table 1 Line Mode Specifications</b> .....	33
<b>Table 2 Inverter Mode Specifications</b> .....	34
<b>Table 3 Double Output Specification</b> .....	34
<b>Table 4 Charging Mode Specifications</b> .....	35
<b>Table 5 General Specifications</b> .....	36
TROUBLE SHOOTING .....	36

# ABOUT THIS MANUAL

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installation and operations. Keep this manual for future reference.

This manual provides safety and installation guidelines as well as information on tools and wiring.

## SAFETY INSTRUCTIONS

1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries, and all appropriate sections of this manual.
2. **CAUTION** --To reduce the risk of injury, charge only deep-cycle lead acid-type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
3. **DO NOT** disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce the risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk
5. **CAUTION** - Only qualified personnel can install this device with battery.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charge, please follow the required specs to select the appropriate cable size. It's very important to correctly operate this inverter/ charger.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts which could cause an explosion.
9. Please strictly follow the installation procedure when you want to disconnect AC or DC terminals. Please refer to the **INSTALLATION** section of this manual for the details.
10. **GROUNDING INSTRUCTIONS** -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
11. NEVER cause AC output and DC input short-circuited. **DO NOT** connect to the mains when DC input short circuits.
12. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following the troubleshooting table, please send this inverter/charger back to the local dealer or service center for maintenance.

# INTRODUCTION

This is a multifunctional off-grid photovoltaic inverter, integrating an MPPT photovoltaic charge controller, a high-frequency pure sine wave inverter, and a UPS function module. It is very suitable for off-grid backup power and self-generation systems. The high-frequency transformer design allows the machine to provide reliable power conversion even under minimal size. This inverter can also operate without batteries.

The entire system requires other devices to achieve complete operation, such as photovoltaic modules, generators or public grids. Please consult your system integrator according to your requirements to obtain other possible system components that may be needed. The Wi-Fi module is a plug-and-play monitoring device installed on the inverter. With this device, users can monitor the operation of the photovoltaic system anytime and anywhere through their mobile phones or websites.

## Features

- Pure sine wave solar inverter
- Double AC output design –one for main load and one for emergency backup
- Built-in MPPT, working range 55-430V, maximum open-circuit voltage 450V
- RGB led lights – indicating different working modes
- Configurable AC/Battery input priority via LCD setting
- Auto restart while PV is recovering
- Over-load, over temperature and output short circuit protection
- Cold start function
- Built-in lithium battery automatic activation – better usage of your lithium batteries.
- RS485 for communication with BMS of lithium batteries.
- Wi-Fi monitoring function (optional)
- Built-in clock – configurable utility charging timing and quantifiable solar power generation
- Off-line upgrading function – COM port for software upgrade
- No-battery mode available

## Basic System Architecture

The following illustration shows the basic application for this inverter/charger. It also includes the following devices to have a complete running system.

- Generator or Utility.
- PV modules (option)

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in the home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.






Figure 1 Hybrid Power System

## Product Overview



1

1. LCD display and buttons
2. Power on/off switch
3. Ground
4. AC input
5. AC main output
6. AC Emergency Power Supply output
7. PV input
8. Ground
9. Battery input
10. BMS port
11. RS485 communication port






# OPERATION

## Power ON/OFF




Once the unit has been properly installed and the batteries are connected well, simply press the ON/OFF switch (located on the right side of the case) to turn on the unit.

## Operation and Display Panel

The operation and display panel, shown in the below chart, is on the front panel of the inverter. It includes three indicators, four function keys, and an LCD display, indicating the operating status and input/output power information.












### LED Indicator





LED Indicator		Messages
 <b>AC / INV</b>	Solid On	Output is powered by utility in Line mode.
	Flashing	Output is powered by battery or PV in battery mode.
 <b>CHG</b>	Solid On	Battery is fully charged.
	Flashing	Battery is charging.
 <b>FAULT</b>	Solid On	Fault occurs in the inverter.
	Flashing	Warning condition occurs in the inverter.

### Function keys

Function Key	Description
ESC	To exit current page
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode





## LCD Display Icons

Icon	Description
<b>AC Input Information</b>	
	AC input, voltage and frequency
	AC bypass providing power
<b>PV Input Information</b>	
	PV input, power, voltage and current
<b>Output Information</b>	
	Icon of the inverter
	Output voltage, output frequency, output current and temperature
<b>Load Information</b>	
	Load (in kW or in VA) and load percentage
	Overload warning
<b>Battery Information</b>	
	Battery, battery voltage, current and capacity percentage.
	Lithium battery connected










Configuration Program and Fault Information	
	Program setting
	Warning and fault codes.
	Fault code
	Alarm muted.





## LCD Setting














Press and hold ENTER button for 5 seconds to enter setting mode. Press "UP" or "DOWN" button to select setting programs. Press "ENTER" button to confirm the selection or ESC button to exit.

Program	Description	Selectable option	
	Exit setting mode	Escape 	
	Output source priority: To configure load power source priority	(Default) 	Solar energy provides power to the loads as a priority. If solar energy is not sufficient to power all connected loads; utility energy will be the next supplement.








		56U	Solar energy provides power to the loads as a priority. If solar energy is not sufficient to power all connected loads; battery will be the next supplement. Battery low voltage warning is programmable in Program 13.
	Maximum total charging current	10A 	110A 
		Default charging current 80A, setting range is 10A – 110A. (Max. charging current = utility charging current (10-80A, program 11) + solar charging current)	
	AC input voltage range	Appliance (default) 	AC input voltage range becomes within 90 -265VAC.
		UPS mode 	AC input voltage range becomes within 170 - 265VAC.
	*Power saving mode	Saving mode disable (default) 	If disabled, no matter connected load is low or high, the on/off status of inverter output will not be affected.
		Saving mode enable 	If enabled, the output of inverter will be off when connected load is too low or not detected

<div>[ 05 ]</div> 	Battery type	AGM (default) AGM	Flooded FLD
		User-Defined USE	If "User-Defined" is enabled, battery charge voltage can be set up in program 26, 27 and 29
		Lithium-ion battery LIB	After setting to "LIB", the floating charge will be cancelled. Once LIB is enabled, battery charging voltage and DC cut-off voltage can be set up in program 26 and 29 respectively.
		Communication with Lithium battery: <div>LIB      485</div> If "485" is selected here, Program 12, 13 and 29 will display SOC.	
<div>[ 06 ]</div> 	Auto restart when overload occurs	Restart disabled (default) LTD	Restart enabled LTE
<div>[ 07 ]</div> 	Auto restart when over temperature occurs	Restart disabled LTD	Restart enabled LTE
<div>[ 08 ]</div> 	Output voltage	220V 220 V	230V(default) 230 V
		240V 240 V	The setting range is 100-240V, <b>DO NOT change this setting except professional personnel</b>












	Output frequency	50Hz (default) 	60Hz 
	Battery producers (optional)		 If your batteries were not from Pylontec or Paceex, please disregard this program.
	Maximum utility charging current (Setting range 11-80A)		
	When "SBU priority" in Program 01 is selected, you can set the voltage of switching back to utility here. When battery voltage is lower than setting value, power supply will be switched back to utility.	Available options for EM-352A: 22.0 – 25.5V, 23.0V by default. 22.0V 	
	When "SBU priority" in Program 01 is selected, you can set the voltage of switching back	Available options for EM-654A: 44.0 – 51.0V, 46.0V by default. 44.0V 	
		Available options for EM-352A: 24.0 – 29.0V, 27.0V by default. 24.0V 	








	to batteries here. When battery voltage is higher than setting value, power supply will be switched back to batteries.	Available options for EM-654A: 48.0 – 58.0V, 54.0V by default.	
		48.0 V	58.0 V
		When fully charged: FUL	
[ 16 ] 	Charger source priority: To configure charger source priority	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
		Solar and Utility (default) 5NU	Solar energy and utility will charge battery at the same time.
		Solar only 050	Solar energy will be the only charger source regardless utility is available or not.
		Solar first 150	Solar energy will charge batteries as first priority. Utility will charge battery only when solar energy is not available.
		If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	
[ 17 ] 	For factory use only, please disregard this one.		
[ 18 ] 	Alarm control	Alarm on (default) 60n	Alarm off 60f




























	Auto return to default display screen	Return to default display screen (default) ESP	If enabled, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) if no operation for 1 minute.
		Stay at latest screen FEP	If enabled, the display screen will stay at latest screen user finally switches.
	Backlight control	Backlight on (default) LON	Backlight off LOF
	Beeps while primary source is interrupted	Alarm on (default) RON	Alarm off ROF
	When this function is enabled, if overload occurs in battery mode, inverter will switch to AC by-pass mode	By-pass disabled (default) bYd	By-pass enabled bYE
	Record Fault code	Record disabled (default) Fds	Record enabled FEN
	Bulk charging voltage (C.V voltage)	EM-352A default setting for AGN battery: 28.2V	














 		
		EM-654A default setting: 56.4V 
		If USE or LIB is enabled in program 05, charging voltage can be adjusted. The setting range is from 24.0V to 29.2V for EM-352A and 48.0V to 58.4V for EM-654A. Increment of each click is 0.1V.
 	Floating charging voltage	EM-352A default to 27.0V 
		EM-654A default setting: 54.0V 
		If USE or LIB is enabled in program 5, this program can be set up. Setting range is from 24.0V to 29.2V for EM-452A, and 48.0V to 58.4V for EM-654A. Increment of each click is 0.1V.
 	Low DC cut-off voltage	EM-452A default setting: 21.0V 
		EM-654A default setting: 42.0V

		<div data-bbox="683 96 1471 309">  </div> <p data-bbox="691 320 1471 510">If "485" is selected in program 5, Program 29 will indicate a percentage. The default value is 20%. The value ranges from 5% to 30%.</p> <p data-bbox="691 521 1471 835">If self-defined is selected in program 5, this program can be set up. The setting range is from 20.0V to 24.0V for EM-452A, and 40.0V to 48.0V for EM-654A. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.</p>	
<div data-bbox="116 857 368 1133">  </div>	Battery equalization	<div data-bbox="683 857 1011 1003">           Disabled (Default)   </div>	<div data-bbox="1034 857 1471 1003">           Activated   </div> <p data-bbox="691 1014 1471 1133">Only if "Flooded" or "User-Defined" was selected in program 05, this program can be set up.</p>
<div data-bbox="116 1155 368 1637">  </div>	Battery equalized voltage	<div data-bbox="683 1155 1471 1402">  </div> <p data-bbox="691 1413 1471 1496">The setting range is from 25.0V to 29.5V. Increment of each click is 0.1V.</p> <div data-bbox="683 1507 1471 1753">  </div> <p data-bbox="691 1765 1471 1848">The setting range is from 50.0V to 59V. Increment of each click is 0.1V.</p>	

	Battery equalized time	60min (default) 	Setting range is from 5min to 900 min. Increment of each click is 5 min.
	Battery equalized timeout	60min (default) 	Setting range is from 5min to 900 min. Increment of each click is 5 min.
	Equalization interval	30days (default) 	The setting range is from 0 to 90 days. Increment of each click is 1 day
	Equalization activated immediately	Disabled (default) 	Enabled 
		If equalization function is enabled in program 33, this program can be set up. If "Enable" is confirmed in this program, it's to activate battery equalization immediately and LCD main page will show "  ". If "Disable" is confirmed, it will cancel equalization function until next activated equalization time arrives based on program 37 setting. At this time, "  " will not be shown in LCD main page.	
	Time setting: Year		The setting range is 2023-2099
	Time setting: Month	Use up and down key to adjust month. 	

	Time setting: Day	Use up and down key to adjust day. 	
	Time setting: Hour	Use up and down key to adjust hour. 	
	Time setting: Minute	Use up and down key to adjust minute. 	
	Time setting: Second	Use up and down key to adjust second. 	
	Utility charging hours	0000 by default, allowing charging all day. 	Use the 4 digits for charging hours setting: the first 2 digits represent starting hour and the last 2 digits represent ending hours. For example, 2320 means starting charging from 23:00 and ending at 20:00 the second day.

	Load time of utility power	0000 by default, allowing using utility/mains all day. 	Use the 4 digits to set up timing of using utility/mains power for loads. The first 2 digits represent starting hour and the last 2 digits represent ending hours. For example, 2320 means starting charging from 23:00 and ending at 20:00 the second day.
	RGB light mode	RGB lights ON (default) 	RGB lights OFF 
	Double-output	Disabled (default) 	Enabled 
If double-output is enabled, when low-voltage occurs, inverter will cut off main-output until battery voltage recovers to setting value in program 13.			
	On-grid	 Disabled (default)	 Enabled
If enabled, PV energy output will be charging battery first, then the rest of it will be returned to grid.			

## Lithium battery connection

If the inverter is matched with lithium batteries, only lithium batteries that have been matched with the BMS communication protocol are allowed to be used:

Please follow below steps to implement lithium battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal specifications.
2. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure that the bolts are tightened with a torque of 2-3Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are



tightly screwed to the battery terminals.

3. Connect the RJ45 connector to the COMM port on the inverter.

4. Connect the other end of the RJ45 plug to the battery communication port (RS485).

Note: If choosing lithium battery, make sure you have connected the BMS communication cable between the battery and the inverter. You need to choose battery type as "LIB-485" mode in program 05.

### Lithium battery communication and setting


In order to communicate with battery BMS, you should set the battery type to "485" in Program 5.

1. Connect the end of RJ45 of battery to BMS communication port of inverter

Ensure that the BMS port of the lithium battery corresponds to the pin of the BMS communication

port of the inverter. The pin of the inverter BMS interface is defined as shown in the following figure:

Pin number	Port definitions
1	RS485B
2	RS485A
3	NG
4	NG
5	NG
6	NG
7	RS485A
8	RS485B



2. Press ENTER for 5 seconds, enter program setting 05 and set battery type to LIB-485.

[ 05 ]	Battery type	AGM (default) AGM
		Flooded FLD
		User-Defined USE


		Lithium-ion battery Lib
		Lib 485 Lib 485





**Note:** When the battery type is set to 485, the charge current can't be modified by the user. The inverter will cut off output if communication fails.


( 12 ) ⊗	When "SBU" in Program 01 is enabled, set up the voltage where inverter switches to utility/mains input.	50 %	Battery percentage ranges from 10%-50%
( 13 ) ⊗	When "SBU" in Program 01 is enabled, set up the voltage where inverter switches to battery input.	95 %	Battery percentage ranges from 30%-100%
( 29 ) ⊗	Low DC cut-off voltage	20 %	Battery percentage ranges from 5%-30%

3. Long press ESC key to the initial screen to check battery voltage and remaining battery level.

4. Detailed description of display interface for lithium battery




<p>Battery charging current, Battery discharge current</p>	 <p>The diagram illustrates the power flow between the GRID, AC BYPASS, LOAD, and BATTERY. The GRID is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD.</p>
<p>Battery capacity, Battery charger/discharge Times</p>	 <p>The diagram illustrates the power flow between the GRID, AC BYPASS, LOAD, and BATTERY. The GRID is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD.</p>
<p>BMS board temperature and MOSFET temperature of BMS board</p>	 <p>The diagram illustrates the power flow between the GRID, AC BYPASS, LOAD, and BATTERY. The GRID is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD.</p>
<p>Maximum voltage of a single battery cell, Minimum voltage of a single battery cell</p>	 <p>The diagram illustrates the power flow between the GRID, AC BYPASS, LOAD, and BATTERY. The GRID is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD. The BATTERY is also connected to the AC BYPASS, which leads to the LOAD.</p>














## 5. Warning Code

Warning Code	Warning Event	Warning Icon
21	Battery cell over-voltage	( 21 ) !
22	Battery cell low-voltage	( 22 ) !
24	Single battery cell low-voltage	( 24 ) !
25	Charging over-current	( 25 ) !
26	Discharging over-current	( 26 ) !
27	Charging cell high temperature	( 27 ) !
28	Discharging cell high temperature	( 28 ) !
29	Charging cell low temperature	( 29 ) !
30	Discharging cell high temperature	( 30 ) !

34	Low capacity of battery	
----	-------------------------	---





## 6. Fault Code




Error Code	Error Event	Error Icon
21	Battery cell over-voltage	
22	Battery cell low voltage	
23	Single battery cell over-voltage	
24	Single battery cell low voltage	
25	Charging over-current	
26	Discharging over-current	
27	Charging cell high temperature	
28	Discharging cell high temperature	
29	Charging cell low temperature	
30	Charging cell high temperature	
61	Communication error	

## LCD Display Information



The LCD display information can be switched in turns by pressing the "UP" or "DOWN" key. Information is displayed in the following order: input voltage, input frequency, PV voltage, charging current, PV power, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, DC discharging current, CPU Version.





Information	LCD display
<p>Default Display Screen</p> <ol style="list-style-type: none"> <li>1. AC Input voltage</li> <li>2. Output voltage</li> <li>3. Load percentage</li> <li>4. PV input voltage</li> <li>5. Battery Voltage</li> </ol>	 <p>The diagram shows a central inverter icon with four arrows pointing to four display boxes. The top-left box is labeled 'GRID' and shows '230 V' with a power line icon. The top-right box is labeled 'LOAD' and shows '18%' with a house icon. The bottom-left box is labeled 'SOLAR' and shows '3080 V' with a solar panel icon. The bottom-right box is labeled 'BATTERY' and shows '540 V' with a battery icon. Arrows indicate power flow: from GRID to inverter, from inverter to LOAD, from SOLAR to inverter, and from inverter to BATTERY. A central label 'AC BYPASS' is at the top, and 'AC/INV' and 'CHG' are at the bottom.</p>
<ol style="list-style-type: none"> <li>1. AC Input frequency</li> <li>2. Output frequency</li> <li>3. Load power rate in VA</li> <li>4. PV input current</li> <li>5. Battery Voltage</li> </ol>	 <p>The diagram is similar to the default screen but with different data: 'GRID' shows '500 Hz', 'LOAD' shows '800 VA', 'SOLAR' shows '82 A', and 'BATTERY' shows '540 V'. The central inverter icon and arrows remain the same.</p>
<ol style="list-style-type: none"> <li>1. AC Input voltage</li> <li>2. Output voltage</li> <li>3. Load power rate</li> <li>4. PV input power</li> <li>5. Battery charging current</li> </ol>	 <p>The diagram is similar to the default screen but with different data: 'GRID' shows '230 V', 'LOAD' shows '108 kW', 'SOLAR' shows '22 kW', and 'BATTERY' shows '366 A'. The central inverter icon and arrows remain the same.</p>
<ol style="list-style-type: none"> <li>1. AC Input frequency</li> <li>2. Temperature of inverter</li> <li>3. Output current</li> <li>4. PV generated power in kWh</li> <li>5. Battery charging current</li> </ol>	 <p>The diagram is similar to the default screen but with different data: 'GRID' shows '50 Hz', 'LOAD' shows '124 A', 'SOLAR' shows '52 kWh', and 'BATTERY' shows '68 A'. The central inverter icon and arrows remain the same.</p>


<p>Top right: PV power generated within the last 30 days</p> <p>Bottom left: PV power generated within the last 365 days</p> <p>Bottom right: PV power generated within the last 24 hours</p>	<div> <div>88</div> <div>  </div> <div> <div>2883</div> <div>kWh</div> </div> <div>36</div> </div>
Firmware version	<div> <div>51</div> <div>  </div> <div>51</div> <div>00</div> </div>
Time: 2023-07-26 15:35:06	<div> <div>15</div> <div>35</div> <div>6</div> <div>  </div> <div>2023</div> <div>07</div> <div>26</div> </div>

## Operating Mode Description


Operation mode	Description	LCD display
Standby mode / Power saving mode <b>Note:</b> *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge the batteries. *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output is supplied by the unit but it still can charge batteries.	<p>Battery charged by utility and PV panels.</p> 
		<p>Battery charged by utility.</p> 

		<p>Battery charging by PV energy.</p> 
<p>Utility mode</p>	<p>Utility provides electricity to loads. Batteries can be charged in this mode.</p>	<p>Battery charged by utility and PV.</p> 

Battery charged by utility.



Inverter runs without battery.







Inverter Mode

Solar panels (PV) and battery provide electricity to loads.

Solar panels (PV) and battery provide electricity to loads.



Battery provides electricity to loads.



## Battery Equalization Description

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have but up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize the battery periodically.


### ● How to Apply Equalization Function

You must enable the battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in the device by either one of the following methods:

1. Setting equalization interval in program 37.
2. Active equalization immediately in program 39.


### ● When to Equalize

In the float stage, when the setting equalization interval (battery equalization cycle) arrives, or equalization is active immediately, the controller will start to enter Equalize stage.




### ● Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge the battery as much as possible until the battery voltage raises to the battery equalization voltage. Then, constant-voltage regulation is applied to maintain the battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.






However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.










## Fault Reference Code

Code/Icon	Fault Event	Code/Icon	
	Fan is locked when inverter is off		Overload time out
	Over temperature		BUS voltage is too high
	Battery voltage is too high		BUS soft start failed
	Battery voltage is too low		Over-voltage from PV panels
	Output short circuited or over temperature is detected by internal converter components		Over-current or surge
	Output voltage is too high		BUS voltage is too low
	Inverter soft start failed		Over DC voltage in AC output

	Loosen battery connection/battery disconnected		Electrical current sensor failed
	Output voltage is too low		


## Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	
15	PV is weak		
EQ	Battery equalization		

BP	No battery connected	
----	----------------------	--

## SPECIFICATIONS

**Table 1 Line Mode Specifications**

INVERTER MODEL	EM-452A	EM-654A
<b>Input Voltage Waveform</b>	Sinusoidal (utility or generator)	
<b>Nominal Input Voltage</b>	230Vac	
<b>Low Loss Voltage</b>	170Vac± 7V (UPS) 90Vac± 7V (Appliances)	
<b>Low Loss Return Voltage</b>	180Vac± 7V (UPS) 100Vac± 7V (Appliances)	
<b>High Loss Voltage</b>	280Vac± 7V	
<b>High Loss Return Voltage</b>	270Vac± 7V	
<b>Max AC Input Voltage</b>	300Vac	
<b>Nominal Input Frequency</b>	50Hz / 60Hz (Auto detection)	
<b>Low Loss Frequency</b>	40±1Hz	
<b>Low Loss Return Frequency</b>	42±1Hz	
<b>High Loss Frequency</b>	65±1Hz	
<b>High Loss Return Frequency</b>	63±1Hz	
<b>Output Short Circuit Protection</b>	Utility mode: Circuit Breaker Battery mode: Electronic Circuits	
<b>Efficiency (Line Mode)</b>	>95% (Rated R load, battery full charged)	
<b>Transfer Time</b>	10ms typical (UPS); 20ms typical (Appliances)	
<b>Output power derating:</b> When AC input voltage drops to 170V, the output power will be derated.	 <p>The graph illustrates the output power derating characteristic. The x-axis represents Input Voltage (V) with markers at 90V, 170V, and 280V. The y-axis represents Output Power. The power is zero for input voltages below 90V. At 90V, the power begins to rise linearly, reaching the Rated Power at 170V. From 170V to 280V, the output power remains constant at the Rated Power level. Beyond 280V, the power drops to zero. A dashed horizontal line at 50% of the Rated Power intersects the linear portion of the curve at 170V.</p>	



**Table 2 Inverter Mode Specifications**

INVERTER MODEL	EM-352A	EM-654A
Rated Output	3800W	6200KW
Output Voltage Waveform	Pure Sine Wave	
Output Voltage Regulation	230Vac±5%	
Output Frequency	60Hz or 50Hz	
Peak Efficiency	95%	
Overload Protection	5s@≥150% load; 10s@110% ~ 150% load	
Surge Capacity	2* rated power for 5 seconds	
Nominal DC Input Voltage	24 Vdc	48 Vdc
Cold Start Voltage	23.0 Vdc	46.0Vdc
<b>Low DC Warning Voltage</b>		
@ Load<20%	22.0Vdc	44.0Vdc
@ 20%≤Load<50%	21.4Vdc	42.8Vdc
@ Load≥50%	20.2Vdc	40.4Vdc
<b>Low DC Warning Relieving Voltage</b>		
@ Load<20%	23.0Vdc	46.0Vdc
@ 20%≤Load<50%	22.4Vdc	44.8Vdc
@ Load≥50%	21.2Vdc	42.4Vdc
<b>Low DC Cut-off Voltage</b>		
@ Load<20%	21.0Vdc	42.0Vdc
@ 20%≤Load<50%	20.4Vdc	40.8Vdc
@ Load≥50%	19.2Vdc	38.4Vdc
High DC Recovery Voltage	29Vdc	58Vdc
High DC Cut-off Voltage	31Vdc	62Vdc
No Load Power loss	<25W	<50W
ECO mode power loss	<10W	<15W

**Table 3 Double Output Specification**

Model	EM-352A	EM-654A
Full load	3800W	6200W
Main output Maximum load	3800W	6200W
EPS output Maximum load (Battery mode)	1200W	2000W
Main output cut-off voltage	22V	44V
Main output recovery voltage (Same as program 13 setting)	27V	54V

**Table 4 Charging Mode Specifications**

Utility Charging Mode			
INVERTER MODEL		EM-352A	EM-654A
Charging Current (UPS) @ Nominal Input Voltage		80A	
Bulk Charging Voltage	Flooded Battery	29.2	58.4
	AGM/Gel Battery	28.2	56.4
Floating Charging Voltage		27Vdc	54Vdc
Charging Algorithm		3-Step	
Charging Curve		<p>The graph illustrates the 3-step charging algorithm. The left y-axis represents Battery Voltage, per cell, with marked values at 2.25Vdc and 2.29Vdc. The right y-axis represents Charging Current, %, with marked values at 50% and 100%. The x-axis represents Time. The algorithm consists of three phases: Bulk (Constant Current), Absorption (Constant Voltage), and Maintenance (Floating). In the Bulk phase, the voltage rises linearly while the current remains constant at 100%. In the Absorption phase, the voltage is constant at 2.29Vdc and the current decreases exponentially. In the Maintenance phase, the voltage is constant at 2.25Vdc and the current is near zero. A note indicates that T2 = 90% T1, with a maximum of 20 hours or 4 hours.</p>	
MPPT Solar Charging Mode			
INVERTER MODEL		EM-352A	EM-654A
Maximum Power		6000W	
Rated Solar Power Voltage		240V	
Max. PV Array Open Circuit Voltage		450Vdc	
PV Array MPPT Voltage Range		55-430Vdc	
Maximum open-circuit voltage		450V	
Maximum charging current of utility and solar panels		110A	

**Table 5 General Specifications**

INVERTER MODEL	EM-352A	EM-654A
<b>Operating Temperature Range</b>	0°C to 55°C	
<b>Storage temperature</b>	-15°C~ 60°C	
<b>Dimension (D*W*H), mm</b>	423*300*120	
<b>Net Weight, kg</b>	7.3	8

## TROUBLE SHOOTING

Problem	LCD/LED/ Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process.	LCD/LED and buzzer will be activated for 3 seconds and then off.	The battery voltage is too low	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. 2. Battery polarity is connected reversed.	1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery.
Utility connected but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped.	Check if AC breaker is tripped and AC wiring is connected well.
	Utility icon and LED are flashing	Insufficient quality of AC power (utility or generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→APL)
	Utility icon is on and LED is flashing	Solar panel was set as the priority of input source.	Change input source priority to Utility first.
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LED are flashing	Battery is disconnected.	Check battery wire connections.

Buzzer beeps continuously and red LED is on.	Fault code 07	Overload. Load reaches 110% rated power and has lasted longer than limit.	Reduce the connected load by switching off some equipment and restart.
Buzzer beeps continuously and red LED is on.	Fault code 05	Output short circuited.	Check connection of circuits and remove abnormal loads.
	Fault code 02	Internal temperature of inverter component is too high	Check whether the air ventilation of the unit is good.
	Fault code 03	Battery is over-charged.	Contact sales team.
		The battery voltage is too high.	Check if specification and quantity of batteries have met requirements.
	Fault code 01	Fan fault	Replace the fan.
	Fault code 06/58	Output abnormal	1.Reduce the connected load. 2.contact sales team
	Fault code 08/09/53/57	Internal components failed.	Contact sales team.
	Fault code 51	Over-current or surge.	Restart the unit, if the error happens again, please contact sales team
	Fault code 52	Bus Voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	

**\*Product technical specifications are subject to change without notice.**

Visit our official website for more information

