

the Light and Fluffy™

Instruction Book - LEG250GRY



Breville



Contents

- 2 Breville Recommends Safety First
- 7 Components
- 8 Functions
- 11 Care & Cleaning
- 12 Recipes

BREVILLE RECOMMENDS SAFETY FIRST

At Breville we are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE

- Carefully read all instructions before operation and save for future reference.
- Remove any packaging material and promotional stickers before using the omelette maker for the first time.
- To eliminate a choking hazard for young children, remove and safely discard the protective cover fitted to the power plug of this appliance.
- Always ensure the omelette maker is properly assembled before use. Follow the instructions provided in this book.

- Do not place the omelette maker near the edge of a bench or table during operation. Ensure the surface is level, clean and free of water.
- Do not use on a sink drain board.
- Always operate the omelette maker on a stable and heat resistant surface. Do not use on a cloth-covered surface, near curtains or other flammable materials.
- Keep the omelette maker clear of walls, curtains and other heat or steam sensitive materials
- Do not place the omelette maker on or near a hot gas or electric burner, or where it could touch a heated oven. Use the omelette maker well away from walls.
- Do not touch hot surfaces. Use the handle to lift and open the top plate.
- Do not leave the omelette maker unattended when in use.
- Do not place anything on top of the omelette maker when the lid is closed, when in use and when stored.
- When operating the omelette maker, ensure the power cord is kept away from any heat source including the surface of the omelette maker. Ensure the power cord does not become trapped between the upper and lower hot plates of the omelette maker during use and storage.
- Always switch the omelette maker off at the power outlet, then unplug the power cord and allow to cool, if the appliance is not in use, before cleaning, before attempting to move the appliance, disassembling, assembling and when storing the appliance.

- Do not use chemicals, steel wool, metal scouring pad or abrasive cleaners to clean the omelette maker as these can damage the housing or the coating of the cooking plates.
- Always remove the food from the omelette maker with a heatproof plastic spatula or tongs. Never use your hands.
- Do not use sharp objects or utensils inside the omelette maker as they may scratch or damage the interior surface of the hot cooking plate.
- The appliance is not intended to be operated by means of an external timer or separate remote control system.
- Keep the exterior housing and the non-stick cooking plates clean. Follow the cleaning instructions provided in this book (Page 11).

WARNING

Fully unwind power cord from cord storage facility before use.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Fully unwind the power cord before use.
- Connect only to 230V or 240V power outlet.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.
- To protect against electric shock, do not immerse the power cord, power plug or appliance in water or any other liquid, unless it is recommended in the cleaning instructions.

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- It is recommended to inspect the appliance regularly. Do not use the appliance if the power supply cord, plug, connector or appliance becomes damaged in any way. Return the entire appliance to the nearest authorised Breville Service Centre for examination and/or repair.
- Any maintenance other than cleaning should be performed at an authorised Breville Service Centre.
- This appliance is for household use only. Do not use this appliance for other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors.
Misuse may cause injury.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

- Always turn the appliance to the OFF position, switch off at the power outlet and unplug at the power outlet when the appliance is not in use.
- Before cleaning, always turn the appliance to the OFF position, switch off at the power outlet, unplug at the power outlet and remove the power cord, if detachable, from the appliance and allow all parts to cool.
- Do not place this appliance on or near a heat source, such as hot plate, oven or heaters.
- Position the appliance at a minimum distance of 20cm away from walls, curtains and other heat or steam sensitive materials and provide adequate space above and on all sides for air circulation.

FOR HOUSEHOLD USE ONLY
SAVE THESE INSTRUCTIONS



Components



- A. Cool-touch handle
- B. Wrap-around moat
- C. START/CANCEL button
- D. 'Power' & 'Ready' indicator lights
- E. LED Display with count-down timer
- F. Timer Increase/Decrease buttons
- G. PFOA-free non-stick coating
For quick and easy cleaning.
- H. Deep-cooking plates
Cooks up to 2 large eggs per omelette and fits all
your favourite fillings.
- I. Non-slip feet For stability

Not Shown

- Auto off
Heating turns off after timer counts down to zero
and the omelette maker will enter Standby mode.
- Cord storage integrated into base



Functions

OPERATING YOUR BREVILLE PRODUCT

Before first use, remove and safely discard any packing material, promotional labels and tape from the omelette maker.

BEFORE FIRST USE

Check that cooking plates are clean and free of dust. If necessary, wipe over with a damp cloth. Place the omelette maker on a flat, level surface with the lid in the closed position.

Ensure there is a minimum distance of 20cm of space on all sides of the omelette maker. Ensure there are no items on top of the omelette maker.

1. Insert power plug into a 230/240V power outlet and turn the power on. The unit will be in standby mode and 2 dashes ‘--’ will be displayed on the screen.

Press the  button to start pre-heating.

The ‘POWER’ light will illuminate red and the screen will show a rotating loop ‘C’ whilst pre-heating.

2. Once the omelette maker has finished pre-heating the ‘POWER’ light will remain lit and the ‘READY’ light will illuminate green, the unit will beep 3 times to alert that the pre-heat has finished and ‘00’ will continuously flash on the screen.



NOTE

If you don't attend to the unit within 30 seconds after the initial pre-heat, the unit will continue pre-heating for an additional 20 minutes with screen continuing to show the rotating loop. The ‘Power’ light will remain on and the ‘READY’ light will cycle on and off.

If after 20 minutes you still have not attended to the unit to set your cooking time, the unit will automatically go into auto off, the unit will sound 5 beeps, stop heating and 2 dashes ‘--’ will be displayed on the screen and both the ‘POWER’ and ‘READY’ lights will no longer be illuminated, indicating heating has stopped.

3. Open the lid and place your ingredients evenly into the centre of each pocket. The total volume of ingredients should not exceed the rim of the bottom cooking pockets.

4. Set your required cooking time using the timer increase  decrease  buttons. Select a time between 1 to 15 minutes.

5. Press  button to commence cooking. The time will stop flashing to indicate that the timer is counting down.

6. During this time the ‘POWER’ light will remain lit, while the ‘READY’ light will illuminate green.



NOTE

The ‘READY’ light will continue to cycle on and off to indicate the omelette maker is maintaining the correct temperature.

7. The timer will countdown by 1 minute intervals, displaying the remaining cooking time on the LED screen. Once it reaches 1 minute it will then count down by seconds until cooking time has elapsed.



NOTE

If the omelette maker has been filled as instructed, the upper lid will lift slightly during cooking as the omelettes approach the end of the cooking cycle. When the lid lifts slightly, continue cooking for around 30 seconds to achieve the best results.

8. When the cooking time has elapsed, the omelette maker will beep 5 times and go into standby mode. The LED screen will continuously flash displaying ‘--’ on the screen. Both the ‘POWER’ and ‘READY’ light will no longer illuminate, indicating heating has stopped.



NOTE

If the unit is in standby mode, and you would like to cook your food further, press the  button once - this will restart the unit and show a rotating loop again. The pre-heat time will be shorter since the plate is still warm after initial cooking.

9. Open the lid and carefully remove your omelette with the help of a silicone spatula. Never use metal tongs or a knife as these can cause damage to the non-stick coating.
10. Before making the next omelette, ensure that the green 'READY' light has illuminated. This means that the unit has now reached the correct temperature and is ready to use.
11. If you are finished cooking, switch the unit off at the power outlet and remove the power plug from the power outlet.



NOTE

Making a standard omelette should take approximately six to seven minutes. Exact cooking time will depend on the type of filling used. To maintain even heat, keep the lid closed until you are ready to add your next batch of ingredients.



NOTE

At all times the lid must be closed. When using the omelette maker for the first time you may notice a fine smoke haze. This is caused by the heating of some of the components. There is no need for concern.



WARNING

Steam will be ejected from between the cooking plates when the lid is closed. Be careful not to make contact with the steam as it may cause burns.



WARNING

Fully unwind power cord from cord storage facility before use.



Hints & Tips

- Try to use canned or pre-cooked fruit as fresh fruit may give off excessive juices when heated.
- Be careful when biting into cooked items containing fillings such as cheese and tomato or jam as they retain heat and can burn if eaten too quickly. One cup of filling for each cooking pocket is sufficient. Do not overfill the cooking pockets.
- Fewer eggs will be required when using filling in an omelette.
- Eggs should be at room temperature (not from the refrigerator) for best results when making omelettes.
- Whisk the eggs with a hand whisk in a large bowl to achieve a well aerated egg mixture.
- For best cooking results, we recommend to season the plates occasionally to prevent sticking and to make cleaning easier. To season, brush the cooking plates with a little vegetable oil and rub off the excess with absorbent paper. Do this after pre-heating the unit.
- Thawed ready-rolled pastry is the easiest to use, either in sheets or from a roll.
- To keep the omelette warm, place in an oven proof dish on a rack in a low oven, about 100°C. The omelette will keep warm for up to 20 minutes this way, but will then begin to dry out.
- You can cook more than just omelettes in your omelette maker. Make a combination of sweet and savoury snacks such as peach crumbles, brownies, cakes and chicken pies).
- **See recipes in this booklet for great ideas.**



Care & Cleaning

Before cleaning, ensure the **POWER** is switched off and then remove the power plug from the power outlet.

Allow your omelette maker to cool before cleaning however, the omelette maker is easier to clean when still slightly warm.

Always clean your omelette maker after each use to prevent a build-up of baked-on foods. Wipe cooking plates and overflow moat with a soft, damp cloth to remove food residue.



WARNING

Do not immerse any part of the Breville Omelette maker or the power cord in water or any other liquid.

PFOA-FREE NON-STICK COATING

Cooking on a non-stick surface minimises the need for oil as food does not stick and cleaning is easier.

Any discolouration that may occur will only detract from the appearance of the omelette maker and will not affect the cooking performance.

When cleaning the non stick coating, do not use metal (or other abrasive) scourers. Wash with warm soapy water and dry thoroughly. Remove stubborn residue using a damp cloth.



NOTE

The cooking plates, hinges and overflow moat are coated with a non-stick surface, do not use abrasives.

STORAGE

To store your omelette maker

1. Ensure the **POWER** is off and then unplug power cord from the power outlet.
2. Allow the omelette maker to fully cool.
3. Wrap the power cord in the cord wrap area below the omelette maker.
4. Store on a flat, dry level surface. Do not place anything on top of the omelette maker.



WARNING

The handle is designed for opening and closing the omelette maker during cooking. It should not be used for moving or carrying the omelette maker.

When moving the omelette maker, allow the unit to fully cool down and carry the unit via the base.



Recipes

Potato, Goat's cheese and thyme omelette

Makes 2

Preparation time	5 minutes
Cooking time	11 minutes

2 large eggs
2 tbsp. fresh cream
2 sprigs fresh thyme
Salt and pepper
160g peeled and grated potato
60g Goat's cheese
60g spinach leaves

1. Mix together the eggs, cream, thyme, salt and pepper and whisk to combine. Set aside.
2. Pre-heat the omelette maker until the **READY** light is illuminated.
3. Lightly spray the omelette maker with baking spray.
4. Divide the grated potato between the omelette wells and then evenly crumble the Goat's cheese between the 2 wells. Divide the egg mix between the 2 wells and close the lid.
5. Set the timer for 11 minutes.
6. Remove using a silicone spatula.
7. Serve with spinach leaves.

Turkey, spinach and brie egg white omelette

Makes 2

Preparation time	5 minutes
Cooking time	8 minutes

6 egg whites
40g brie cheese, diced
40g turkey, fine shreds
30g baby spinach, shredded
8 dried cranberries, finely diced
Salt and pepper

To serve

50g spinach leaves
4 cherry tomatoes, cut into 1/4's
1/4 red onion, finely diced
1/4 avocado, diced

Drizzle caramelised balsamic dressing

1. Pre-heat the omelette maker until the green **READY** light illuminates.
2. Divide the ingredients into 2 bowls and stir to combine.
3. When pre-heat is complete, gently pour the ingredients of each bowl into each well and close the lid.
4. Adjust the timer to 8 minutes.
5. Prepare spinach salad by mixing the salad ingredients together and dress with drizzle of caramelised balsamic dressing.
6. Remove using a silicone spatula.
7. Serve with spinach salad.

Asparagus, Goat's cheese and truffle omelette

 Makes 2

 Preparation time 3 minutes

 Cooking time 7 minutes

2 eggs

2 tbsp. fresh cream

Fresh black pepper

Salt

$\frac{1}{4}$ tsp. butter

10 spears asparagus, cut into 10cm lengths

40g bocconcini, sliced

40g Goat's cheese

$\frac{1}{4}$ bunch watercress, picked and washed

Drizzle truffle oil

1. Mix together the eggs, cream, black pepper and salt and whisk together.
2. Pre-heat the omelette maker. Add the butter and asparagus to the omelette maker and adjust the timer to 2 minutes, leaving the lid open.
3. Divide the egg mix, Goat's cheese and bocconcini between the 2 wells and close the lid.
4. Adjust the timer to 6 minutes.
5. When cooked remove and place on a serving plate.
6. Serve with watercress and truffle oil drizzle over the omelette and watercress salad. Season with sea salt and freshly ground black pepper.

Quiche Lorraine

 Makes 2

 Preparation time 5 minutes

 Cooking time 11 minutes

1 sheet store bought shortcrust pastry

60g bacon, sliced

2 shallots, white part sliced – green discarded

60g spinach leaves

40g tasty cheese, grated

2 tbsp. fresh cream

2 eggs

1. Line the omelette wells with pastry and trim off the excess pastry using the edge of a silicon scraper.
2. Divide the ingredients into 2 bowls and mix to combine well. Add to the pastry lined wells and close the lid.
3. Turn the omelette maker on and when pre heat is complete adjust the timer to 9 minutes.
4. Remove using a silicone scraper.
5. Serve with spinach leaves.

Roast pumpkin and fetta omelette

 Makes 2

 Preparation time 25 minutes

 Cooking time 10 minutes

150g pumpkin, torn dice

1 clove garlic, crushed

3 eggs

2 tbsp. fresh cream

40g feta, small dice

Salt and pepper

To serve

1 tbsp. sunflower seeds, roasted

30g baby rocket

Olive oil drizzle

1. Roast diced pumpkin and garlic for 12 minutes on 180°C.
2. Beat together the eggs, cream, feta, salt and pepper. Add the roast pumpkin to the egg mix.
3. Divide the mixture in 2 bowls and pour into each well. Close the lid. Adjust the timer to 10 minutes.
4. When complete, serve with rocket, roasted sunflower seeds and olive oil drizzle.

Chocolate brownie

 Makes 5

 Preparation time 8 minutes

 Cooking time 40 minutes

200g dark chocolate

140ml vegetable oil

200g light brown sugar

3 eggs

1 tsp vanilla essence

$\frac{1}{2}$ cup plain flour

$\frac{1}{4}$ cup cocoa powder

2 tsp baking powder

$\frac{1}{4}$ cup chocolate chips

Chocolate sauce

$\frac{1}{4}$ cup fresh cream

1 tsp butter

100g dark chocolate

1. Cut a semi-circle shaped piece of baking paper and line the omelette maker wells and a small one for the top of the brownie.
2. Place the chocolate and the oil into a heatproof bowl and place over boiling water and stir until the chocolate is melted. Stir to combine and remove from the heat to cool.
3. Put the eggs, sugar and vanilla essence into a bowl and whisk to combine. Add the melted chocolate and oil and stir through.
4. Sift the dry ingredients together and fold through the egg and chocolate mix. Stir through the chocolate chips.
5. Pre-heat the omelette maker until the green light is illuminated.
6. Place the baking paper into the omelette well and pour $\frac{1}{2}$ cup of brownie mixture into each of the lined wells. Place the smaller piece on top of the brownie mixture and close the lid.
7. Adjust the time to 12 minutes on the timer and press start to begin cooking.
8. When complete, carefully remove from the omelette wells and let cool.
9. To make the sauce—place the cream and butter into a saucepan to heat. Take off the heat and stir in the chocolate until it is melted. Drizzle over the brownie and serve.

Lemon and ricotta cake

Gluten free

 Makes 4

 Preparation time	10 minutes
 Cooking time	20 minutes

65g unsalted butter, softened
 ¼ cup caster sugar
 1 egg
 Zest of ¼ lemon
 1 tbsp. lemon juice
 ¼ tsp. vanilla paste
 ¼ cup smooth ricotta
 ½ cup gluten free self-raising flour
 ½ cup almond meal

Ricotta icing
 ¼ cup smooth ricotta
 1 tsp. vanilla paste
 1 tbsp. icing sugar

Lemon drizzle
 3 tbsp. lemon juice
 2 tbsp. caster sugar
 1 tsp. honey

1. Cut a semi-circle shaped piece of baking paper to line the omelette maker wells.
2. For the syrup - Place ingredients into a small saucepan and bring to the boil. Put aside to cool until cakes are ready.
3. In a bench mixer, cream the butter and sugar until pale. Add the egg, zest, lemon juice and vanilla and beat well. Add the ricotta and fold through the flour and almond meal until combined.
4. Pre-heat the omelette maker until the green light is illuminated.
5. Place the baking paper into the omelette well and spoon ¼ cup of cake mixture into each of the lined wells and close the lid.
6. Adjust the time to 10 minutes on the timer and press start to begin cooking.
7. For the ricotta icing - Place the ingredients into a bowl and mix well together. Set aside.
8. When cakes are ready, remove from the omelette maker and let cool.
9. Spread the icing over the top of the cake and drizzle the cooled syrup over the top.

Peach crumble cake

 Makes 6

 Preparation time	15 minutes
 Cooking time	20 minutes (30 minutes per 2)

Streusel top
 ¼ cup self-raising flour
 40g cold unsalted butter, diced
 ¼ tsp. vanilla paste
 ¼ (25g) cup brown sugar
 ¼ (25g) cup caster sugar
 Pinch cinnamon
 ¼ cup oats

Cake bottom
 60g unsalted butter, at room temperature
 60g caster sugar
 1 egg
 2 tsp. milk
 ¼ tsp. vanilla paste
 ½ cup self-raising flour
 Pinch cinnamon
 200g tinned sliced peaches drained and liquid discarded
 4 scoops vanilla ice-cream

1. Cut a semi-circle shaped piece of baking paper to line the omelette maker wells.
2. To make the crumble top - place the flour, butter, vanilla paste, brown sugar and cinnamon into the food processor and pulse until it resembles coarse crumbs. Add oats and pulse briefly, only to combine the oats, do not blend the oats. Place the crumble top in the refrigerator until required.
3. To make the cake - place the butter and sugar into the mixing bowl of your bench mixer and beat until light and fluffy. Crack your egg into a cup and then slowly pour it into the sugar and butter mixture until combined. Switch your bench mixer onto a low speed and add milk, vanilla, flour and cinnamon.
4. Pre-heat the omelette maker until the green light is illuminated.
5. Place a small piece of greaseproof paper in the 2 omelette wells and spread ¼ of the cake batter into the omelette maker wells. Place a layer of sliced peaches on the cake then sprinkle ¼ of the crumble on the top of the peaches.
6. Close the lid and adjust the timer to 10 minutes.
7. Remove using a silicone spatula and serve with vanilla ice-cream.

Breville Customer Service Centre

Australian Customers

Phone: 1300 138 798

Web: www.breville.com.au

New Zealand Customers

Phone: 0800 273 845

Web: www.breville.co.nz

Breville
Thought for food

Breville is a registered trademark of Breville Pty Ltd A.B.N. 96 000 030 006.
Copyright Breville Pty Ltd 2008

Due to continual product improvement, the products illustrated/photographed
in this brochure may vary slightly from the actual product.

LEB250GRY D18