



Service manual: Washing machine

Type: WM70

Contents

Updates.....	4
Introduction	5
General product information.....	6
Troubleshooting strategy.....	7
Overview: Panels and programs	8
Program tables	10
Program selection, options and making settings WM70.3.....	18
Program selection, options and making settings WM70.2.....	26
Program selection, options and making settings WM70.1	29
Service menu WM70.3.....	33
Service menu WM70.2.....	35
Service menu WM70.1	36
Shop program	37
Fault indications WM70.3.....	38
Fault indications WM70.2.....	39
Fault indications WM70.1	40
Components and measurement values.....	41
Thermistor measurement values.....	41
Technical data.....	42
Tools.....	42
Wiring diagram WM70.3.....	43
Wiring diagram WM70.2.....	44
Wiring diagram WM70.1 CIM.....	45
Wiring diagram WM70.1 UM.....	46
Rehanging the door.....	47
Replacing panels, control unit and detergent compartment	50
Replacing front panel, door, cover plate and the hinges.....	53
Emergency opener for door lock.....	54
Wash agitator removal	55

Updates

Rev	Date	Description	Sign
01	2010-10-06	First version developed	BPA


Introduction

You are holding the service manual for WM70 type washing machines.

It should be easy to service a washing machine. It is important that you, as a service technician, are given the conditions to be able to carry out work in an efficient and satisfactory way. Our hope is that this service manual is a useful tool for your daily work.

The type designation is located by the inside of the glass door (see image below).

Asko Appliances AB
SE-534 82 Vara
Sweden



General product information

In conjunction with the introduction of the WM70 (August 2010), our washing machines have been altered in a number of areas. Here we present the changes to the wash drum and wash agitators.

- Larger wash drum:
 - 60 litres (previously 50 litres)
 - 23 mm deeper, the drum is now 343 mm deep in total (previously 320 mm)
 - 30 mm larger diameter, 480 mm in total (previously 450 mm)
- New drum hole pattern to cause as little wear as possible on clothing.
- New agitators that improve the wash process.

All cylinder holes flanged to reduce wear on textiles.


Area with large holes (3.7 mm) to remove larger objects, such as grit.

Area with smaller holes (2,2mm) to reduce wear on textiles.

The angle of the edge of the cylinder, combined with the shape of the agitators, moves the load towards the middle of the drum. This improves drum balance and reduces wear on textiles.


Hourglass-shaped agitators:

- Move the load towards the smaller, gentler holes in the middle of the drum.
- Move larger objects, such as grit, towards the larger holes at the edges of the drum.




Troubleshooting strategy

At Asko, we believe in always remaining focused on the customer, and as an ASKO service technician, you are one of the most important ambassadors of our brand. As such, it is important that the customer finds the service callout a pleasant experience. Troubleshooting is an important part of the service callout, and as such we have drawn up a troubleshooting strategy that describes, in broad terms and step by step, what you need to do to find and diagnose faults arising in our machines.



Overview: Panels and programs


WM70.3



Programs: 14, where one consists of the menu for settings (Program 15)
for V826, it is possible to add a program(stain program)

Options: 6

Settings: 8




Programs: 14, where one consists of the menu for settings (Program 15)
for V826, it is possible to add a program(stain program)

Options: 6

Settings: 8

WM70.2



Programs: 12

Options: 1 or 5

Settings: 3

WM70.I



- Programs: 10
- Options: 4 or 6
- Settings: 1

Program

The tables present a few examples of the energy, water and time consumption of a few different programme settings. Consumption can vary according to water pressure, water hardness, water supply temperature, room temperature, load weight and content, variations in the power supply and selected options. In the examples presented here the rinse setting was set to "Normal" and no options were selected.

Machine type: WM70.3

Market: EU

Max load: 8kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Last	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Stain											
P3	Time program											
P4	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P5	Normal White/Colour	Cotton	No	1/1	60	1600	65		3	4	3:15	1,20
					40	1600	65		3	4	2:57	0,67
P6	Quick White/Colour	Cotton	No	1/1	60	1600	59		3	4	1:39	1,17
P7	Super Quick	Cotton	No	1/2	40	1600	33		3	1	0:48	0,45
P8	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P9	Synthetics	Synthetics	No	1/2	40	800	38		4	1	1:22	0,39
P10	Wool	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P11	Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P12	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
P13	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
P14	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

P5,P8 This programme has been tested in accordance with EN 60456.

P5 40°C programme for test institutes. 40°C option must be selected.

P1 Short programme for test institutes, max 1/2-load.

Machine type: WM70.3

Market: EU

Max load: 8kg

Rinse setting: 5

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Stain											
P3	Time program											
P4	Heavy	Bomull	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P5	Normal White/Colour	Cotton	No	1/1	60	1600	78		5	3	3:22	1,20
					40	1600	78		5	3	3:04	0,67
P6	Quick White/Colour	Cotton	No	1/1	60	1600	72		5	3	1:46	1,18
P7	Super Quick	Cotton	No	1/2	40	1600	33		3	1	0:48	0,45
P8	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P9	Synthetics	Synthetics	No	1/2	40	800	38		4	1	1:22	0,39
P10	Wool	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P11	Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P12	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
P13	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
P14	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

P5,P8 This programme has been tested in accordance with EN 60456.

P5 40°C programme for test institutes. 40°C option must be selected.

P1 Short programme for test institutes, max ½-load.

Machine type: WM70.3

Market: US

Max load: 8kg

Rinse Setting: 3

							Water	Includes level intake	Number of rinses	Number of Spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Stain											
P3	Time program											
P4	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P5	Normal White/Colour	Cotton	No	1/1	60	1600	59		3	4	2:21	1,20
					40	1600	59		3	4	2:02	0,59
P6	Quick White/Colour	Cotton	Noj	1/1	60	1600	59		3	4	1:39	1,17
P7	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P8	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P9	Synthetics	Synthetics	No	1/2	40	800	38		4	1	1:22	0,39
P10	Wool	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P11	Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P12	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
P13	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
P14	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

Machine type: WM70.3

Market: Swan

Max load: 6kg

Rinse Setting: 5

							Water	Includes level intake	Number of rinses	Number of Spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Stain											
P3	Time program											
P4	Heavy	Cotton	Yes	1/1	90	1600	82		5	3	2:36	2,17
					60	1600	74		5	3	2:35	1,20
P5	Normal White/Colour	Cotton	No	1/1	60	1600	80		3	4	2:22	1,20
					40	1600	80		3	4	2:08	0,59
P6	Quick White/Colour	Cotton	Noj	1/1	60	1600	80		3	4	1:46	1,17
P7	Super Quick	Cotton	No	1/2	40	1600	33		2	1	0:48	0,45
P8	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P9	Synthetics	Synthetics	No	1/2	40	800	38		4	1	1:22	0,39
P10	Wool	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P11	Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P12	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
P13	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
P14	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

Machine type: WM70.3

Market: AU

Max load: 7kg

Rinse Setting: 3

							Water	Includes level intake	Number of	Number of Spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Stain											
P3	Time program											
P4	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P5	Normal White/Colour	Cotton	No	1/1	60	1600	60		3	4	3:21	1,13
					40	1600	60		3	4	3:06	0,47
P6	Quick White/Colour	Cotton	Noj	1/1	60	1600	59		3	4	1:39	1,12
P7	Super Quick	Cotton	No	1/2	40	1600	33		2	1	0:48	0,45
P8	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P9	Synthetics	Synthetics	No	1/2	40	800	38		4	1	1:22	0,39
P10	Wool	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P11	Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P12	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
P13	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
P14	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

Machine type:

WM70.2

Market: EU

Max load: 8kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Time program											
P3	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P4	Normal White/Colour	Cotton	No	1/1	60	1600	65		3	4	3:15	1,20
					40	1600	65		3	4	2:57	0,67
P5	Quick White/Colour	Cotton	No	1/1	60	1600	59		3	4	1:39	1,17
P6	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P7	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P8	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P9	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
PI1	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
PI2	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
PI3	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

P4,P7 This programme has been tested in accordance with EN 60456.

P4 40°C programme for test institutes. 40°C option must be selected.

PI Short programme for test institutes, max ½-load.

Machine type:

WM70.2

Market: EU

Max load: 8kg

Rinse setting: 5

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Time program											
P3	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P4	Normal White/Colour	Cotton	No	1/1	60	1600	65		5	3	3:22	1,20
					40	1600	78		5	3	3:04	0,67
P5	Quick White/Colour	Cotton	No	1/1	60	1600	72		5	3	1:46	1,18
P6	Super Quick	Cotton	No	1/2	40	1600	26		5	1	0:42	0,45
P7	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		5	1	1:20	0,52
P8	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P9	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
PI1	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
PI2	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
PI3	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

P4,P7 This programme has been tested in accordance with EN 60456.

P4 40°C programme for test institutes. 40°C option must be selected.

PI Short programme for test institutes, max ½-load.

Machine type:

WM70.2

Market: US

Max load: 8kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Time program											
P3	Heavy	Cotton	Yes	I/I	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P4	Normal White/Colour	Cotton	No	I/I	60	1600	59		3	4	2:21	1,20
					40	1600	59		3	4	2:02	0,59
P5	Quick White/Colour	Cotton	No	I/I	60	1600	59		3	4	1:39	1,17
P6	Super Quick	Cotton	No	I/2	40	1600	26		2	1	0:42	0,45
P7	Easy care/Sportswear	Cotton	No	I/2	40	1200	52		2	1	1:20	0,52
P8	Synthetics	Synthetics	No	I/2	40	800	31		3	1	1:19	0,39
P9	Wool/Hand	Wool	No	I/3	30	800	68	!	3	1	0:46	0,49
PI1	Rinse program	Cotton	No	I/2	-	1600	13	!	1	1	0:18	0,07
PI2	Spin program	Cotton	No	I/2	-	1600	0		0	1	0:13	0,06
PI3	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

Machine type:

WM70.2

Market: Swan

Max load: 6kg

Rinse setting: 5

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Time program											
P3	Heavy	Cotton	Yes	I/I	90	1600	82		5	3	2:36	1,79
					60	1600	74		5	3	2:35	1,01
P4	Normal White/Colour	Cotton	No	I/I	60	1600	80		5	3	2:22	1,14
					40	1600	80		5	3	2:08	0,64
P5	Quick White/Colour	Cotton	No	I/I	60	1600	80		5	3	1:46	1,18
P6	Super Quick	Cotton	No	I/2	40	1600	26		2	1	0:42	0,45
P7	Easy care/Sportswear	Cotton	No	I/2	40	1200	52		2	1	1:20	0,52
P8	Synthetics	Synthetics	No	I/2	40	800	31		3	1	1:19	0,39
P9	Wool/Hand	Wool	No	I/3	30	800	68	!	3	1	0:46	0,49
PI0	Rinse program	Cotton	No	I/2	-	1600	13	!	1	1	0:18	0,07
PI1	Spin program	Cotton	No	I/2	-	1600	0		0	1	0:13	0,06
PI2	Drain program	-	-	-	-	-	0		0	0	0:01	0,00
PI3	Allergy program Cotton	Cotton					73		5	3	2:25	1,10
PI4	Allergy program Synthetics	Synthetics	No	4,6 kg	60	1600	69		5	3	1:50	0,70
PI5	Drum cleaning		No	2,3 kg	40	1200						

Machine type:
WM70.2

Market: AU

Max load: 7kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Time program											
P3	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P4	Normal White/Colour	Cotton	No	1/1	60	1600	60		2	3	3:21	1,13
					40	1600	60		2	3	3:06	0,47
P5	Quick White/Colour	Cotton	No	1/1	60	1600	59		3	4	1:39	1,12
P6	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P7	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P8	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P9	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
PI1	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	0:18	0,07
PI2	Spin program	Cotton	No	1/2	-	1600	0		0	1	0:13	0,06
PI3	Drain program	-	-	-	-	-	0		0	0	0:01	0,00

Machine type:
WM70.1

Market: EU

Max load: 8kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	st	st	h:mm	kWh
P1	Auto											
P2	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
					60	1600	77		5	3	2:40	1,20
P3	Normal White/Colour	Cotton	No	1/1	60	1600	65		3	4	3:15	1,20
					40	1600	65		3	4	2:57	0,67
P4	Quick White/Colour	Cotton	No	1/1	60	1600	59		3	4	1:39	1,17
P5	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P6	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P7	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P8	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P9	Rinse Program	Cotton	No	1/2	-	1600	13	!	1	1	4:19	0,07
PI0	Spin & Drain	Cotton	-	1/2	-	1600	0		0	1	0:13	0,06

P3,P6 This programme has been tested in accordance with EN 60456.

P3 40°C programme for test institutes. 40°C option must be selected.

PI Short programme for test institutes, max ½-load.

Machine type:

WM70.I

Market: EU

Max load: 8kg

Rinse setting: 5

	Prog	Load	Pre-wash	Load	Temp	Rpm	Water l	Includes level intake !	Number of rinses no.	Number of spins no.	Time h:mm	Energy kWh
P1	Auto											
P2	Heavy	Cotton	Yes	I/I	95	1600	85		5	3	2:46	2,17
P3	Normal White/ Colour	Cotton	No		60	1600	77		5	3	2:40	1,20
P4	Quick White/Colour	Cotton	No	I/I	60	1600	78		5	3	3:22	1,20
				I/I	40	1600	78		5	3	3:04	0,67
P4	Quick White/Colour	Cotton	No	I/I	60	1600	72		5	3	1:46	1,18
P5	Super Quick	Cotton	No	I/2	40	1600	26		2	1	0:42	0,45
P6	Easy care/Sportswear	Cotton	No	I/2	40	1200	52		2	1	1:20	0,52
P7	Synthetics	Synthetics	No	I/2	40	800	31		3	1	1:19	0,39
P8	Wool/Hand	Wool	No	I/3	30	800	68	!	3	1	0:46	0,49
P9	Rinse program	Cotton	No	I/2	-	1600	13	!	1	1	4:19	0,07
P10	Spin & Drain	Cotton		I/2	-	1600	0		0	1	0:13	0,06

Machine type:

WM70.I

Market: US

Max load: 8kg

Rinse setting: 3

	Prog	Load	Pre-wash	Load	Temp	Rpm	Water l	Includes level intake !	Number of rinses no.	Number of spins no.	Time h:mm	Energy kWh
P1	Auto											
P2	Heavy	Cotton	Yes	I/I	95	1600	85		5	3	2:46	2,17
P3	Normal White/ Colour	Cotton	No		60	1600	77		5	3	2:40	1,20
P4	Quick White/Colour	Cotton	No	I/I	60	1600	59		3	4	2:21	1,20
				I/I	40	1600	59		3	4	2:02	0,59
P4	Quick White/Colour	Cotton	No	I/I	60	1600	59		3	4	1:39	1,17
P5	Super Quick	Cotton	No	I/2	40	1600	26		2	1	0:42	0,45
P6	Easy care/Sportswear	Cotton	No	I/2	40	1200	52		2	1	1:20	0,52
P7	Synthetics	Synthetics	No	I/2	40	800	31		3	1	1:19	0,39
P8	Wool/Hand	Wool	No	I/3	30	800	68	!	3	1	0:46	0,49
P9	Rinse program	Cotton	No	I/2	-	1600	13	!	1	1	4:19	0,07
P10	Spin & Drain	Cotton	-	I/2	-	1600	0		0	1	0:01	0,06

Machine type:
WM70.I

Market: Swan

Max load: 6kg

Rinse setting: 5

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Heavy	Cotton	Yes	1/1	95	1600	82		5	3	2:36	1,79
P3	Normal White/Colour	Cotton	No		60	1600	74		5	3	2:35	1,01
P4	Quick White/Colour	Cotton	No	1/1	60	1600	80		5	3	2:22	1,14
				1/1	40	1600	80		5	3	2:08	0,64
P5	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P6	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P7	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P8	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P9	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	4:19	0,07
P10	Spin & Drain	Cotton	-	1/2	-	1600	0		0	1	0:13	0,06

Machine type:
WM70.I



Market: AU

Max load: 7kg

Rinse setting: 3

							Water	Includes level intake	Number of rinses	Number of spins	Time	Energy
	Prog	Load	Pre-wash	Load	Temp	Rpm	l	!	no.	no.	h:mm	kWh
P1	Auto											
P2	Heavy	Cotton	Yes	1/1	95	1600	85		5	3	2:46	2,17
P3	Normal White/Colour	Cotton	No		60	1600	77		5	3	2:40	1,20
P4	Quick White/Colour	Cotton	No	1/1	60	1600	60		2	3	3:21	1,13
				1/1	40	1600	60		2	3	3:06	0,47
P5	Super Quick	Cotton	No	1/2	40	1600	26		2	1	0:42	0,45
P6	Easy care/Sportswear	Cotton	No	1/2	40	1200	52		2	1	1:20	0,52
P7	Synthetics	Synthetics	No	1/2	40	800	31		3	1	1:19	0,39
P8	Wool/Hand	Wool	No	1/3	30	800	68	!	3	1	0:46	0,49
P9	Rinse program	Cotton	No	1/2	-	1600	13	!	1	1	4:19	0,07
P10	Spin & Drain	Cotton	-	1/2	-	1600	0		0	1	0:13	0,06


Program selection, options and making settings WM70.3

Program selector
Standard machine

Main power switch


Program selector
Fully built-in machine

Programme selector use on standard machines



1. Press the program selector button to navigate between the different menus (e.g. to go from temperature menu to spin menu).
2. Press the small arrows to make a selection in the menus (e.g. select 1400 rpm). Confirm the selection and go to the next menu by pressing the program selector button.
3. Press Start/Stop to start. Hold Start/Stop in for 3 seconds to exit the current program.

Programme selector use on built-in machines



1. Press the program selector button to navigate between the different menus (e.g. to go from temperature menu to spin menu).
2. Turn the program selector button to make a selection in the menus (e.g. select 1400 rpm). Confirm the selection and go to the next menu by pressing the program selector button.
3. Press Start/Stop to start. Hold Start/Stop in for 3 seconds to exit the current program.

Program selection WM70.3

The options are displayed in the order they occur in LCDI. All display text language versions are displayed.

Press/ turn	Pos.	LCD I	Comments/instruction
			Turn on the main power
 	1	Auto, Auto, Auto, Automatprogram, Autovask, Autovask, Automaattipesu, Automatique, Automatikprogramm, Automatico, Auto, Автоматическая, Automatisch programma	This program automatically adjusts the length of the main wash and the number of rinses depending on the amount of washing and how heavily soiled it is.
	2	Stain Care, Stain prog, Fläckprogram, Plet program, Flekkprogram, Tahraohjelma, Tache, Flecken-Progr., Prog Antimacchia, Manchas, Пятна, Vlekkenprog.	A special program for stains. Stain removal requires attention as soon as possible.
	3	Time program, Time Choice, Time program, Tidsprogram, Tidsprogram, Tidsprogram, Aikaohjelma, Programme minute, Zeitprogramm, Progr. del tempo, Prog. de secado, Время окончания, Tijdprogramma	Choose a temperature up to 60°C/ 140 °F, set the spin speed to a maximum of 1600 rpm and set the time when you want the program to finish. The machine will automatically choose a program of the right length with the settings you have selected.
	4	Heavy, Sani, Heavy, Grov- med förtvätt, Kogevask+forvask, Intensiv m/forvask, Esipesu + Tehopesu, Super intensif, Vor-/Kochwäsche, Intensivo, Sani, Интенсивная, Intensieve was	Use this program for heavily-soiled washing. You only need to use the maximum temperature, 60°C/ 140 °F, if the washing is very heavily soiled.
	5	Normal, Stain, Normal, Vittvätt, Hvidvask, Intensiv, Tehopesu, Super intensif blanc, Intensiv, Intensivo bianchi, Manchas-Color, Нормальная, Normale was	This program is equivalent to the Heavy program, but without the pre-wash. It is used for heavily-soiled whites where 95°C/ 203 °F is a suitable temperature.
	6	White, White, White, Snabb vittvätt, Hurtig hvidvask, Hvit, Normaalipesu, Intensif, Kochwäsche, Capi resistenti, Pesado, Белое, Witte was	Normally-soiled sheets, pillowcases and towels will come clean at 60 °C/140 °F.
	7	Quick, Quick, Quick, Kvicktvätt, Kvivask, Hurtig, Pikapesu, Rapide, Schnell, Rapido, Rápido, Быстрая стирка, Kort programma	Lightly soiled laundry that only needs freshening up can be washed for a short time at 40°C.
	8	Everyday wear, Easy care, Strykfritt/sport, Sport og fritid, Sport og fritid, Sport, Sport, Sportkleidung, Sport, Everyday wear, Спортивная одежда, Sportkleding	Program for blended materials, permanent press shirts and functional sports clothing. The program has a high water level and as such is also suitable for cushions, quilted jackets and the like. Read the washing instructions carefully and remember, for example, that fabric softener must not be used with the membranes found in some outer garments. A washing temperature up to 60°C and a spin speed up to 1200 rpm can be selected.
	9	Synthetics, PermaPress, Synthetics, Syntettvätt, Syntetisk vask, Syntet, Siliävät/Synteettiset, Synthétique, Pflegeleicht/Fein, Sintetici, Perma Press, Синтетика, Synthetische was	This program is suitable for shirts and blouses made of synthetic and blended material. Wash white items at 60°C/ 140 °F and coloured items at 40°C/ 104 °F.
	10	Wool, Wool, Wool, Ylletvätt, Uldvask, Ull, Villapesu, Laine, Wolle, Lana, Lavado manual/ Lana, Шерсть, Wolwas	This program is used for garments labelled for Wool wash only. The maximum temperature is 40°C/ 104 °F and the program has a short spin.
	11	Hand, Delicate / Hand, Hand, Handtvätt, Håndvask, Hånd, Käsinpesu, Main, Hand, A mano/ delicati, Delicado, Ручная стирка, Handwas	This program is used for garments labelled hand wash only. The maximum temperature is 30°C/ 86 °F and the program has a short spin.
	12	Rinse, Rinse, Rinse, Sköljprogram, Skylleprogram, Skylling, Huuhteluohjelma, Rinçage, Spülen, Risciacquo, Enjuague, Полоскани, Spoelprogramma	This program performs one rinse cycle + spin. Good for cleaning cloths and mops.
	13	Spin, Spin, Spin, Centrifugering, Centrifugering, Sentrifugering, Linkous, Essorage, Schleudern, Centrifuga, Centrifugado, Отжим, Centrifugeren	To be used when you only want to spin the load.
	14	Drain, Drain, Drain, Utpumpning, Udpumpning, Utpumping, Tyhjennys, vidange, Abpumpen, Scarico, Drenaje, Слив, Pompen	To be used when you only want to drain the water from the machine.
	15	Settings, Settings, Settings, Inställningar, Indstillinger, Innstillinger, Asetukset, Réglage, Einstellungen, Impostazioni, Ajustes, Настройки, Instellingen	See chapter "Settings".
			Exits the program menu and advances to options or the menu for Settings.

Options selection WM70.3

The options are displayed in the order they occur in LCD2. All display text language versions are displayed.

Press/	LCD 2	Comments/Instructions
 	95°C	 Temperature Temperature Selection of temperatures between Cold and 95°C. Cold is the same as the incoming water temperature. For program 8 and 9, the maximum temperature is 60°C, for program 10, the maximum temperature is 40°C.
	80°C	
	70°C	
	60°C	
	50°C	
	40°C	
	30°C	
	20°C	
	Cold, Cold, Cold, Kalt, Kold, Kald, Kylmä, Froid, Kaltt, Freddo, Fría, Доп.полоскани,, Koud	
		
	1800 	 Spin Option of choosing spin speed between 400 and 1800 rpm. Spinning at 400 – 800 rpm signifies a short spin. In program 3, you can not choose a higher spin than 1600 rpm. In program 8, you can not choose a higher spin than 1200 rpm. In program 9 and 10, you can not choose a higher spin than 800 rpm.
	1700 	
	1600 	
	1400 	
	1200 	
	1000 	
	800 	
	400 	
		"No spin" means that the program does not include a spin cycle and ends by draining.
		"No draining" means that the program does not include a spin cycle and ends with the water from the final rinse still in the machine.
		
 	 Economy Rinse, Economy Rinse, Economy Rinse, Lätt sköljning, Økonomi skyl, Økonomi skylling, Ekohuuhtelut, Rinçage économique, Eco Spülen, Risciacquo economico, Enjuague económico, Норм. полоскание, Eco spoelen	Rinse The rinse program can be selected in program: 4, 5, 6, 7, 8, 9, 10 and 11 - Economy rinse (reduces the number of rinses, used for lightly soiled laundry) - Normal rinse (recommended number of rinses during normal soiled laundry.) - Super rinse (adds rinses, maximum 7) Number of rinses varies depending on program.
	 Normal Rinse, Normal Rinse, Normal Rinse, Normal sköljning, Normalt skyl, , Normaaliuuhtelut, Rinçage normal, Normal Spülen, Risciacquo normale, Enjuague normal, Норм.полоскание , Normaal spoelen	
	 Super Rinse, Super Rinse, Super Rinse, Supersköljning, Superskyl, Superskyl, Superhuuhtelut, Super rinçage, Super Spülen, Risciacquo super, Superenjuague, перполоскание, Super spoelen	

Options selection WM70.3 cont.

Press/ turn	LCD 2	Comments/instructions
		
 	 Normal water level, Normal Water Level, Normal water level, Normal vattennivå, Normal vandstand, Normalt vannivå, Normaali vedenpinta, Niveau d'eau normal, Normaler Wasserstand, Livello acqua normale, Nivel normal de agua, Норм.уровень вод, Normaali waterniveau  High water level, High Water Level, High water level, Hög vattennivå, Høj vandstand, Høyt vannivå, Korkea vedenpinta, Niveau d'eau élevé, Hoher Wasserstand, Livello acqua alto, Nivel alto de agua, Высокий уровень воды, Hoog waterniveau	High water level Can be selected in programs: 4, 5, 6, 7, 8 and 9. Cannot be selected during No spin and No draining. With this option selected, extra water is taken in after approximately 15 minutes, the extra water is used in the main wash and rinses.
	The following only applies to program 3, the time program.	
 	 Start, Start, Start, Start, Start, Start, Start, Démarrer, Start, Avvio, Inicio, Старт, Start  Start - Done, Start-End, Start-Done, Start-Klar, Start-Færdig, Start-Ferdig, Start-Valmis, Démarrer-Fin, Start-Fertig, Avvio-Fine, Inicio-Fin, Старт-Конец, Start-Gereed	Delayed start (when setting: "No Real time") The start of the selected program can be delayed for up to 24 hours (in half an hour intervals). The delay and program time is shown in the display.  Start: 1:00 2:35 Delayed start (when setting: "24 Hour Clock" or "12 Hour Clock") The start of the selected program can be delayed for up to 24 hours (in half an hour intervals). Start and end times are shown in the display.  Start 16:22 Done 18:00 15:52
		
 	 Start, Start, Start, Start, Start, Start, Start, Démarrer, Start, Avvio, Inicio, Старт, Start  Start - Done, Start-End, Start-Done, Start-Klar, Start-Færdig, Start-Ferdig, Start-Valmis, Démarrer-Fin, Start-Fertig, Avvio-Fine, Inicio-Fin, Старт-Конец, Start-Gereed	Time program (when setting: "No Real time") Desired program time can be set. Selections up to 3 hours in units of 15 minutes can be made. The selected program time is shown in the display.  3:00 Time program (when setting: "24 Hour Clock" or "12 Hour Clock") Desired program time can be set. Selections up to 3 hours in units of 15 minutes can be made. Start and end times are shown in the display.  Start 15:54 Done 17:09 15:54
		

Make settings WM70.3

The setting options below are shown in the order they occur in LCD2 (Program 14 under the program menu is, however, shown in LCD1). All display text language versions are displayed. If no choices is done within 2 minutes the display will be set in Stand-by mode.

Press/ turn	LCD 2	Press/ turn	LCD3	Comments/instructions
 	Settings, Settings, Settings, Inställningar, Indstillinger, Innstillinger, Asetukset, Réglage, Einstellungen, Impostazioni, Ajustes, Настройк, Instellingen			In the program menu: Scroll to Program 15 (Settings) Program 15 is shown in LCD1.
	You will now enter the Settings menu.			
 	1 Presoak, Presoak, Presoak, Förblötning , Iblødsætning, Bløtlegging , Liotus, Trempage, Einweichen, Ammollo, Remojar, амачивание, Inweken			
			On, On, On, På, Til, På, Päällä, On, An, On, encendido, Вкл., Aan	The laundry will soak in cold water for two hours before the program starts.
			Off, Off, Off, Av, Fra, Av, Poissa, Off, Aus, Off, apagado, Выкл., Uit	Setting deactivated.
			Saves the setting and returns to the program menu, Program 15.	
	2 Anti crease, Anti Wrinkle, Anti crease, Skrynkelfritt, Anti-krøl, Antikrøll , Rypistymisen esto, Antifroissage, Knitterschutz, Antisgualcit., Antiarrugas, Против сминания, Anti-kreuk			
			On, On, On, På, Til, På, Päällä, On, An, On, encendido, Вкл., Aan	The drum rotates 3 seconds per minute for two hours after the program has ended
			Off, Off, Off, Av, Fra, Av, Poissa, Off, Aus, Off, apagado, Выкл., Uit	Setting deactivated.
			Saves the setting and returns to the program menu, Program 15	
	3 Clock, Clock, Clock, Klocka, Ur, Klokke, Kello, Horloge, Uhr, Orologio, Reloj, Часы, Klok			
			24hr Realtime, 24 Hour Clock, 24hr Realtime, 24 timmarsvisning, 24 timers ur, 24t realtid, 24 h aika, Horloge 24 h, 24 Std. Echtzeit, 24h Tempo reale, Reloj 24 horas, ормат времени 24- , 24 uur weergave	Three O'clock is displayed as "15.00". Press SI to access a sub-menu where you can set the correct current time. Press SI again to store and exit the sub-menu.
			12hr Realtime, 12 Hour Clock, 12hr Realtime, 12 timmarsvisning, 12 timers ur, 12t realtid, 12 h aika, Horloge 12 h, 12 Std. Echtzeit, 12h Tempo reale, Reloj 12 horas, ормат времени12- , 12 uur weergave	Three O'clock is displayed as "03.00". Press SI to access a sub-menu where you can set the correct current time. Press SI again to store and exit the sub-menu.
			No Real time, No Real Time, No Real time, Ej realtid, Intet ur, Ingen realtid, Ei aikaa, Pas d'horloge, Keine Echtzeit, No tempo reale, Sin hora real, Время не установлено, Geen tijdsweergave	No Real Time. Press SI to return to program menu Program 15.
			Saves the setting and returns to the program menu, Program 15.	

Make settings WM70.3 cont.


Press/ turn	LCD 2	Press/ turn	LCD3	Comments/instruction
4	Audible volume, Buzzer Volume, Audible volume, Ljudsignal volym, Lydsignal, Lydsignal, Hälytysääni, Volume buzzer, Tonsignal, Volume allarme, Volumen timbre, Громкость сигнала, Geluidssignaal			
			Off, Off, Off, Av, Fra, Av, Poissa, Off, Aus, Off, apagado, Выкл., Uit	No buzzer
			Low, Low, Low, Låg, Lav, Lav, Matala, Faible, Niedrig, Bassa, Bajo, Низкая, Laag	Buzzer that indicates the end of a program or error.
			Normal, Normal, Normal, Normal, Normal, Normal, Normaali, Normal, Normal, Normale, Normal, Нормальная, Normaal	Buzzer that indicates the end of a program or error.
			High, High, High, Hög, Høj, Høy, Korkea, Elevé, Hoch, Alta, Alto, Выкл., Hoog	Buzzer that indicates the end of a program or error.
			Saves the setting and returns to the program menu, Program 15.	
5	Child-safe Child-safe Barnsäker Børnesikker, Barnesikring, Lapsilukko, Sécurité enfant, Kindersicherung, Avvio sicurezza, Int. de seguridad, Блокировка от детей, Kindveilige		Saves the setting and returns to the program menu, Program 15.	
			On, On, On, På, Til, På, Päällä, On, An, On, encendido, Вкл., Aan	If S1, S2, S3 or J1 are pressed or turned, S2 S1 must be pressed to temporarily deactivate the child-safe start (is deactivated for 3 minutes after last press of S1, S2, S3).
			Off, Off, Off, Av, Fra, Av, Poissa, Off, Aus, Off, apagado, Выкл., Uit	Setting deactivated.
			Saves the setting and returns to the program menu, Program 15.	
6	Automatic door opening, Automatic Door Opening, Automatic door opening, Automatisk lucköppning, Automatisk lugeåbning, Auto døråpning, Automaattinen luukun avaus, Ouverture auto porte, Automatische Lukenöffnung, Apertura autom. sportello, Apertura auto de puerta, Авто-открытие дверцы, Aut. deuropening			
			On, On, On, På, Til, På, Päällä, On, An, On, encendido, Вкл., Aan	When then setting has been activated, the door will open automatically after the end of the program. Does not apply if Nodrain is selected (as there is still water in the machine).
			Off, Off, Off, Av, Fra, Av, Poissa, Off, Aus, Off, apagado, Выкл., Uit	Setting deactivated.
			Saves the setting and returns to the program menu, Program 15.	

Make settings WM70.3 cont.

	7	Language, Language, Language, Språk, Sprog, Språk, Kieli, Langue, Sprache, Lingua, Idioma, Язык, Taal			
			US English		
			English	Default	
			Svenska		
			Dansk		
			Norsk		
			Suomi		
			Francais		
			Deutsch		
			Italiano		
			español		
			Русский		
	nederlands				
		Saves the setting and returns to the program menu, Program 15			
8	Temperature , F° or C° Setting, Temperatur , Temperatur, Temperatur enhed, Temperaturenhet, Lämpötilayksikkö, Unités de température, Temperatureinheit, Unità temperatura, Unidad de temperatura, Шкала температур, Temperatuurweergave				
		°C	Celsius		
		°F	Fahrenheit		
			Saves the setting and returns to the program menu, Program 15		
9	Rinses, Rinses, Sköljningar, Skylninger, Skylling, Huuhtelut, Rincage, Spülen, Risciacqui, Enjuages, полоскания, Spoelen				
			Off	3 Rinses	
			On	5 Rinses	
			Saves the setting and returns to the program menu, Program 15		

10	Spin option, Spin option, Rpm alternativ, Centrifugeringsvalg, Sentrifuger alternativ, Linkouksen säätö, Spin option, Spin option, Spin option, центрифугирование, centrifuge-opties			
			Comment: Spin option 0 is the default setting. Spin option 1 decrease the spin rpm with 15 rpm's. Spin option 2 decrease the spin rpm with 30 rpm's and reduce the spin time with 30 sec. Spin option 3 decrease the spin rpm with 45 rpm's and reduce the spin time with 60 sec.	
			Spin option	Spin option 0
			Spin option	Spin option 1
			Spin option	Spin option 2
			Spin option	Spin option 3
	Return, Return, Return, Tillbaka, Tilbage, Tilbake, Takaisin, Retour, Zurück, Uscire, Salir, Назад, Terug		Saves the setting and returns to the program menu, Program 15	

Make settings WM70.2



Option selection WM70.2

Press -/+		Comments/Instructions
	90°C	Temperature Selection of temperatures between Cold and 90°C. Cold is the same as the incoming water temperature. For program 8 and 9, the maximum temperature is 40°C, for program 10, the maximum temperature is 60°
	80°C	
	70°C	
	60°C	
	50°C	
	40°C	
	30°C	
	20°C	
	-°C	Cold, no heating of the incoming water
		Spin Option of choosing spin speed between 400 and 1800 rpm. Spinning at 400 – 800 rpm signifies a short spin. Program 8 and 9 cannot be selected at speeds greater than 800 rpm.
	1800	
	1700	
	1600	
	1500	
	1400	
	1200	
	1000	
	800	
	400	
	0	"No spin" means that the program does not include a spin cycle and ends by draining
	No d	"No draining" means that the program does not include a spin cycle and ends with the water from the final rinse still in the machine.
	1-24 h	Delayed start

Option selection WM70.2 cont.


Press -/+		Comments/instructions
Press 	The maximum number of rinses is seven and varies depending on selected program. Can be used with all programs except Auto, Time, Rinse, Spin or Drain programs.	Superrinse
Press 	Additional water is used during the main wash and rinse cycles. The machine takes in the additional water for the high water level about 15 minutes after the main wash has started.	High waterlevel
Press 	The drum rotate for three seconds /minute for two hours. Can be used with alla programs except Auto, Time, Wool/hand, No spin and Rinse.	Easy care
Press 	Increases the time during which water is pumped into the machine. Can be used with alla programs except Time, Quick, Wool/hand and Rinse.	Superwash
Press 	The laundry lies for two hours in cold water. Can be used in all programs except Auto, Time and Rinse.	Presoak

Make settings WM70.2

		Comments/instructions
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • The display shows: "Child-safe" • Turn the program selector to select Off or On • Press the door opening button to store your selection	Child safety
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • Turn the program selector until "Door opening" appears in the display • Turn the program selector to select Off or On • Press the door opening button to store your selection	Automatic door opening
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • Turn the program selector until "Language" appears in the display • Turn the program selector to select a language: US English, English, Svenska, Dansk, Norsk, Suomi, Français, Deutsch, Italiano, Espanol, Русский, Nederlands • Press the door opening button to store your selection	Language

		Comments/instructions
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • Turn the program selector until "Temperature" appears in the display • Turn the program selector to select °C or °F • Press the door opening button to store your selection	Temperature
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • Turn the program selector until "Rinses" appears in the display • Turn the program selector to select Off or On • Press the door opening button to store your selection	Rinses
	• Turn off the machine using the main power switch • Press and hold the door opening button • Turn on the main power switch • Press the door opening button 5 times when the display starts to lighten up • Turn the program selector until "Hot water" appears in the display • Turn the program selector to select Off or On • Press the door opening button to store your selection	Hot water
	Press the Start/Stop-button to store all your selections	


Program selection WM70.I



Turn/ Press	Program	Description
	1. Auto	This program automatically adjusts the length of the main wash and the number of rinses to the amount of laundry loaded in the machine.
	2. Heavy	Program for heavily soiled laundry, with dirt that needs to be fully dissolved before the main wash. A pre-wash is used to do this. You can select the temperature freely, so follow the washing instructions for each garment. The highest temperature, 95°C, is suitable for very heavily soiled laundry. The spin speed can be selected freely. The machine adapts the program time and water consumption to the load size.
	3. Normal White/Colour	Program for normal to heavily soiled laundry, whites and colours. You can select the temperature freely, so follow the washing instructions for each garment. 60°C is a good temperature for heavily soiled cotton garments, as well as for garments worn next to the skin. Select 40°C if the laundry is less soiled. The spin speed can be selected freely. The machine adapts the program time and water consumption to the load size.
	4. Quick white/Colour	Program for normal to heavily soiled laundry, whites and colours. You can select the temperature freely, so follow the washing instructions for each garment. 60°C is a good temperature for heavily soiled cotton garments, as well as for garments worn next to the skin. Select 40°C if the laundry is less soiled. The spin speed can be selected freely. The machine adapts the program time and water consumption to the load size.
	5. Quick	Fast program for laundry that just needs freshening up. The program can be run at any temperature, so follow the washing instructions for each garment. The lower the selected temperature, the shorter the program time. Garments worn next to the skin ought to be washed at 60°C. The spin speed can be selected freely.
	6. Easy care/sportswear	Program for blended materials, permanent press shirts and functional sports clothing. The program has a high water level and as such is also suitable for cushions, quilted jackets and the like. Read the washing instructions carefully and remember, for example, that fabric softener must not be used with the membranes found in some outer garments. A washing temperature up to 60°C and a spin speed up to 1200 rpm can be selected.
	7. Synthetics	Program for delicate fabrics made of synthetic fibres, blended materials or silk. The maximum temperature is 60°C, but follow the washing instructions for each garment. Many synthetics will come clean at 40°C. Garments worn next to the skin ought to be washed at 60°C. The maximum spin speed is 800 rpm.

Turn/ Press	Program	Description
	8. Wool/Hand	A gentle laundry program for wool, silk and garments that should be washed by hand. The highest available temperature is 40°C. This program has a short spin. The maximum spin speed is 800 rpm.
	9. Rinse program	This program performs one cold rinse cycle + spin. Suitable for laundry that just needs to be dampened and for cleaning cloths and mops
	10. Spin/Drain	Used to just spin the wash. If you only want to drain the machine of water, select the  symbol (no spin)
	Press the start/Stop-button to start the program	

Option selection WM70.I


Press	Description
40° 30° 20°  95° 60° 50°	Select the temperature by pressing the button until the LED by the desired temperature lights. You can select temperatures between 20°C and 95°C. For Wool/Hand you cannot choose a temperature higher than 40°C, when choosing Synthetics or Easy care the maximum temperature is 60°C.
400  1600 800	- Select the spin speed by pressing the button until the LED by the desired speed lights. - You can select speeds between 400 and 1600 rpm, No spin or No drain. A spin with a speed of 400-800 rpm is always a short spin. (Some models up to 1200 respectively 1400 rpm) - You cannot choose a spin speed higher than 800 rpm for Wool/Hand and Synthetics - No spin () means that the program does not include a spin cycle and ends by draining. - No draining () means that the program does not include a spin cycle and ends with the water from the final rinse still in the machine. The washing will remain covered by the water from the final rinse and therefore will not become creased - If you only want to drain the machine of water, select the Spin & drain program
	Available only on some models with 6 options. - Select Super wash () by pressing the button by the symbol. - An LED next to the button lights when this option is activated. - Super wash can be selected to better dissolve difficult stains and heavy soiling on clothing. The main wash time in cold water is extended by approximately six minutes. The main wash time is also extended. - This option cannot be selected with the auto, heavy, white and quick colours programmes.
	- Select High water level () by pressing the button by the symbol. - An LED next to the button lights when this option is activated. - High water level means that additional water is used during the main wash and rinse cycles. This option can be used with all programmes except Wool/Hand, rinse and spin/drain. Note! The machine takes in the additional water for the high water level about 15 minutes after the main wash has started.
	- Use the Super rinse () option if you want to increase the number of rinses. The maximum number of rinses is seven and varies depending on the selected programme. This option cannot be selected with rinse and spin/drain - Select Super rinse by pressing the button by the symbol. - An LED next to the button lights when this option is activated.
	Select Delayed Start () by pressing the Time button. You can delay the start by between 1 and 24 hours, the time is shown in whole hours. The LED next to the Time button shows that Delayed Start has been activated. The machine counts down 1 hour at a time and starts after the selected delay. Note! Make sure the detergent compartment is completely dry before you add detergent, otherwise there is a risk that the detergent will clump before the machine starts.
	Press the Start/Stop button to start program


Make Settings WM70.I

Setting	Instruction
Automatic door opening	1. Turn off the machine using the main power switch. 2. Press the Super rinse button  and then the main power switch. 3. "AdO" is shown on the display if automatic door opening is activated, or "AdF" if the option has not been activated. 4. Press the Super rinse button  to change the setting. 5. Press the Door opening button to save the setting.
Rinses	It is possible to set the number of rinses (3 or 5) in the Normal and Colour/White programmes. 1. Turn off the machine using the main power switch. 2. Press and hold the Delayed Start button and then switch on the main power switch. 3. The display shows "R O" if extra rinses (5 rinses) is activated or "R F" if it is not activated (3 rinses). 4. Turn the programme selector to change the setting. 5. Press the Door opening button to save the setting.

Service menu WM70.3

This is how to enter the service menu	
	If the machine is on: First switch the power off with the main power switch.
	Press the program selector (SI) at the same time as the Main power switch.
	Press the program selector button 3 times within 5 seconds. You are now in the service menu (shown in LCD 2. See instructions below for navigating the service menu.

Program selector	
	1. Press the program selector button to scroll between the various service menus. 2. Turn the program selector button to make a selection between the menus (e.g. set a certain water inlet). Confirm the selection and go to the next menu by pressing the program selector button (1). 3. Press the Start/Stop button to confirm the settings and exit the service menu.

Program selector button for integrated machines	
	1. Press the program selector button to scroll between the various options. 2. Press the small arrows to make a selection between the options (e.g. set a certain water inlet). Confirm the selection and go to the next option by pressing the program selector button (1). 3. Press the Start/Stop button to confirm the settings and exit the service menu.

Service menu WM70.3 cont.

The options below are displayed in the order they occur in LCD 2. All display text language versions are displayed.

Press/ turn	LCD 2	Comments/instructions
 	DataSerialNo, Data Ser Num, DataSerialNo, DataSerialNo, Serienummer, Serienummer, Dataversio Nro, N° de série, Seriennummer, Num. di serie, N° de serie, Серийный номер, Serienummer	Date for programming the software (Year_Week)
	CU date code, CU Date Code, CU date code, CU datum kod, CU dato kode, Styrekort prod dato, CU pvm koodi, Code date CU, CU Datumscode, Codice data CU, Código fecha CU, Код даты БУ, CU datacode	Control unit's date of manufacture (Year_Week)
	Software1, Software1, Software1, Mjukvar1, Software1, Software ver.1, Ohjelmisto1, Logiciel1, Software1, Software1, Software1, Версия прог.1, Software1	The software version number of the software that controls the program flow
	Software2, Software2, Software2, Mjukvara2, Software2, Software ver.2, Ohjelmisto2, Logiciel2, Software2, Software2, Software2, Версия прог.2, Software2	The software version number of the software that controls the display.
	No. of cycles, Number of Cycles, No. of cycles, Antal cykler, Antal cyklusser, Antall bruk, Syklien lkm, Nb. de cycles, Anzahl der Zyklen, Numero cicli, N° de ciclos, Кол-во циклов, Aantal cycli	Number of cycles/programs run
	 Press  to exit the service menu	
 	"Error_Number of cycles"	Last three errors and number of cycles is shown. Total reset deletes the error indications from the system. Delete the error indications by pressing the DOOR OPENING BUTTON and the MAIN POWER SWITCH at the same time.
	"Error_Number of cycles"	
	"Error_Number of cycles"	
	 Press  to exit the service menu	
 	Testing	
	Test valve 1, Testing Valve 1, Test valve 1, Ventiltest 1, Tester ventil 1, Test av vannventil 1, Mg venttiilitesti 1, Essai vanne 1, Ventil testen 1, Test valvola 1, Test válvula 1, Тест клапана 1, Test inlaatventiel 1	Inlet valve 1 is open. Pressure sensor value is shown in LCD 2.
	Test valve 2, Testing Valve 2, Test valve 2, Ventiltest 2, Tester ventil 2, Test av vannventil 2, Mg venttiilitesti 2, Essai vanne 2, Ventil testen 2, Test valvola 2, Test válvula 2, Тест клапана 2, Test inlaatventiel 2	Inlet valve 2 is open. Pressure sensor value is shown in LCD 2.
 	Test valve SM, Testing Valve SM, Test valve SM, Ventiltest SM, Tester ventil SM, Test av vannventil SM, Mg venttiilitesti SM, Essai vanne SM, Ventil testen SM, Test valvola SM, Test válvula SM, Тест клапана SM, Test inlaatventiel SM	Inlet valve 1 and 2 is open. Pressure sensor value is shown in LCD 2.
	Test heater, Testing Heater, Test heater, Elementtest, Tester varmelegeme, Test av element, Vastustesti, Essai résistance, Heizung testen, Test elem. riscald., Test elemento calef, Тест ТЭНа, Test verw.element	Heater is on until max 60 °C. Thermistor value is shown in LCD 2.

Service menu WM70.3 cont.


Service menu VVI 170.5 cont.

 	Test motor, Testing Motor, Test motor, Motortest, Tester motor, Test av motor, Moottoritest, Essai moteur, Motor testen, Test motore, Test motor, Тест мотора, Test motor	The motor is running at normal action (49 rpm)
	Test drain, Testing Drain, Test drain, Tömningsstest, Tester udpumpning, Test av tömning, Tyhjennyspumpputesti, Essai vidange, Abfluss testen, Test scarico, Test drenaje, Тест насоса, Test afvoer pomp	Drain pump is on. Pressure sensor value is shown in LCD 2
	Test spin, Testing Spin, Test spin, Centifugeringstest, Tester centrifugering, Test av sentrifugering, Linkousteisti, Essai essorage, Schleudern testen, Test centrifuga, Test centrifugado, Тест отжима, Test centrifugeren	A Spin sequence is performed, the drain pump is running. Unbalance value is shown in LCD 2.
	Test door, Testing Door, Test door, Dörrtest, Tester luge, Test av dørå, Luukun lukon testi, Essai porte, Luke testen, Test sportello, Test puerta, Тест замка дверцы, Test deurslot	Door lock is activated, the door is then opened.
	Press  to exit the service menu	
 	0	Setting amount of water taken into the machine. Default value is "0".
	-15%	
	-10%	
	-5%	
	+5%	
	+10%	
	+15%	
	Press  to exit the service menu	
 	0	Adjust LCD contrast Default value is "0".
	+3	
	+2	
	+1	
	-1	
	-2	
	-3	
	Press  to exit the service menu	
 	1500	Setting maximum speed. Default value is "1600 rpm".
	1600	
	1700	
	1800	
	Press  to exit the service menu	
	Reset	
	Language	US English, English, Svenska, Dansk, Norsk, Suomi, Francais, Deutsch, Italiano, Esoanol, Русский, Nederlands

Service menu WM70.3 cont.


	Clock	24hr Realtime, 24 Hour Clock, 24hr Realtime, 24 timmarsvis ning, 24 timers ur, 24t realtid, 24 h aika, Horloge 24 h, 24 Std. Echtzeit, 24h Tempo reale, Reloj 24 horas, Формат времени 24-ч., 24 uur weergave 12hr Realtime, 12 Hour Clock, 12hr Realtime, 12 timmarsvis ning, 12 timers ur, 12t realtid, 12 h aika, Horloge 12 h, 12 Std. Echtzeit, 12h Tempo reale, Reloj 12 horas, Формат времени 12-ч., 12 uur weergave No Real time, No Real Time, No Real time, Ej realtid, Intet ur, Ingen realtid, Ei aikaa, Pas d'horloge, Keine Echtzeit, No tempo reale, Sin hora real, Время не установлено, Geen tijdsweergave
	Transport protection	Transport protection, Transport protection, Transportskydd, Transportbeskytt., Transportvern, Kuljetustuet, Protection transport, Transportsicherung, Protezione trasporto, Andaje transport, защита при транспортировке, Transportbescherming
	Press 	to exit the service menu

Service menu WM70.2



	Switch off, and then on main power.
S6	•Wait for at least 5 seconds •Press down button S6 •Turn on the power •Pressing S6 when power on followed by 3 pushes on S6 within 5 sec enters the service menu.
NOTE!	Make all selections. Pressing S13 stores all selections made in service menu and leaves service mode.
Turn J1	Tracking data read out SP: (software programming date: year week CM: (control unit manufacturing date: year week SV1: (Software version) SV2: (Software version) NC: Number of cycles Press S14 next step is accessed.
	Failure read out Rotating J1 will display 2nd and 3rd last deviating fault, ex "Thermistor fault (2); 30" , "Over flow (3); 20" Failure record is cleared by total reset Pressing S14 next step is accessed.
	Diagnostics Separate test of auxiliary components. Rotating J1 each component will be turned on (with a 1 sec delay) and inputs detected in sequence: "Testing" (no component), "Testing valve 1" (inlet valve 1 on), "Testing valve 2" (inlet valve 2 on), "Testing valve SM" (inlet valve 1 and 2 on), "Testing heater" (heater on until max 60°C), "Testing motor" (normal action), "Testing drain" (drain pump on), "Testing spin" (spin sequence, drain pump on), "Testing door". Pressing S14 components will be off and next step is accessed.
	Spin speed Turn J1 counter clockwise 1500 rpm, 1600 rpm, 1700 rpm, 1800 rpm, default or clockwise 1800 rpm, 1700 rpm ... Pressing S14 next step is accessed or S13 to store or leave service mode.

Service menu WM70.I



How to get to the service menu	
	Is the machine turned on: turn off the power first at the main switch.
+	Press and hold the button for super wash (S4) while you press the main switch.
	Press button (S4) three times within 5 seconds. You are about to component testing.

Turn/press	SCREENING	Comments/Instructions
		No component
		Intake valve 1 starting
		Intake valve 2 starting
		Intake valve 1 and 2 starting
		Heater starts and warms up to a maximum of 60 ° C
		Drain pump starts
		Spin and drain pump starts
		Door opening

	Press the Start/Stop button to exit the service menu	
 + 	"Auto door on/off"	
	Ad O	"Auto door on"
	Ad F	"Auto door off"
		Press button (S11) to store your selection
 + 		"Extra rinses Off/On"
	r F	"Extra rinses off" - 3 rinses
	r 0	"Extra rinses On" 5 rinses
		Press button (S11) to store your selection

Shop program WM70.3

1. Activating the Shop program (for machines manufactured up to week 736)	
 + 	If the machine is on: First turn off the power at the main power switch. Then press and hold the Start button while turning on the main power switch. At this point no settings can be made. The centre display will activate after 3 minutes. Settings can now be made, but the machine cannot be started.
2. Stopping the Shop program (for machines manufactured up to week 736)	
 + 	First turn off the power at the main power switch. Then press and hold the Start button while turning on the main power switch. The Shop program is now stopped.
1. Activating the Shop program (for machines manufactured from week 737 on)	
 +   x5	If the machine is on: First turn off the power at the main power switch. Then press and hold the Start button while turning on the main power switch. Press the program selector 5 times At this point no settings can be made. The centre display will activate after 3 minutes. Settings can now be made, but the machine cannot be started.
2. Stopping the Shop program (for machines manufactured from week 737 on)	
 +   x5	First turn off the power at the main power switch. Then press and hold the Start button while turning on the main power switch. Press the program selector 5 times. The Shop program is now stopped.

Store program WM70.2 and WM70.1

There are no store programs on the WM70.2 and WM70.1.

Fault indications WM70.3

The below faults are indicated in plaintext in LCD I. The table shows the indication in all languages and language variations.

LCD I	Cause	Action
Over flow fault, Overflow Fault, Over flow fault, Överflyllnad, Overløbsfejl, Overflom, Ylitulviminen, Trop plein, Überfüllt, Troppo pieno, Desborde, Перелив воды, Te veel water	Too much water in the machine	Service action: Check the machine's level system, inlet valve and drain pump. Make sure that there is no leaks.
	The drain pump is on, without any water in the machine.	Service action: The overflow protection at the bottom of the machine is activated (not all models). Make sure that there is no leaks (water on the machines base)
Water outlet fault, Water Outlet Fault, Water outlet fault, Uttömningsfel, Udpumpningsfejl, Vannutløp, Vedenpoistovika, Défaut , Wasserablauffehler, Uscita acqua, Fallo, Слив воды, Waterafvoer fout	1. The drain pump has been activated more than 3 minutes. There is still water in the machine. 2. The wash cycle is interrupted and the program is cleared	Customer information: 1. Check that no objects are stuck in the drainage hose outlet. 2. Check that the drain pump is not blocked by foreign objects. 3. Check that there are no kinks in the drainage hose. Service action: 1. If the pump only runs for a short while (approximately 20 seconds), this indicates a fault in the level system. Check the level sensor and hoses. 2. Check wiring and voltage to the pump. If necessary, replace the pump and/or control 3. After implementing corrective action, run the Drain program or press the Key button
Water inlet fault, Water Inlet Fault, Water inlet fault, Vattenintagsfel, Vandindtagsfejl, Vanntilførsel, Vika vedenotossa, Défaut, Wasseraufn.-fehler, Entrata acqua , Fallo , Набор воды, Watertoevoer fout	If the correct water level is not reached within 5 minutes, the wash cycle is interrupted.	Customer information: 1. Check that the tap on the water pipe is open. Service action: 1. Check that the filter in the machine's water intake is not blocked. 2. Check the inlet valve. If necessary, replace the valve. 3. Check voltage to the inlet valve. If there is no voltage, this could be due to a fault in the level system, wiring or control unit.
Security fault, Security Sys Fault, Security fault, Lucköppningsfel, Sikkerhedsfejl, Sikkerhetsfeil, Vika turvajärj., Erreur sécurité, Sicherh.-fehler, Err. sis.sicurezza, Fallo sistema seguridad, Ошибка сис.безоп., Deurslot fout	The door is open.	Close the door
Thermistor fault, Thermistor Fault, Thermistor fault, Termistorfel, Termostat fejl, Termistor, Termistorivika, Défaut , Termistorfehler, Termistore , Fallo , Термистор, Temp. sensor fout	1. The circuit for the thermistor is open. 2. The thermistor is faulty 3. The measurment value for the thermistor is <300 Ω (>120 °C)	Service action: Check the thermistors function. If needed, replace it.
Temperature fault, Temperature Fault , Temperature fault, Temperaturstoppfel, Temperatur fejl, Temperaturstopp, Ei lämmitä vettä, Défaut , Temp.-stoppfehler, Errore arresto , Fallo , Температура, Temperatuurstopp	• The temperature is raised < 5 °C/41°F within 10 minutes. The wash cycle continues to next step	Service action: Check the heater, cables, thermistor and level system.
Wash motor fault, Wash Motor Fault , Wash motor fault, Motorfel, Motor fejl, Motorfeil, Moottorivika, Défaut , Motorfehler, Motore lavaggio , Fallo , Мотор, Motorstoring	No signal from Tacho or MCU..	Service action: Check signal from the MCU and cables between motor and MCU.
Pressure fault, Pres Sensor Fault, Pressure fault, Tryksensorfel, Tryksensor fejl, Nivåfeil, Painesensorivika, Défaut , Drucksensorfehler, Pressostato , Fallo , Датчик уровня, Druksensor fout	Indicated if the level drops to 0 within 30 seconds of the first rinsing.	Service action: Check the leakage
Unbalance, Unbalance, Unbalance, Obalans, Ubalance, Ubalance, Epätasapaino, Balourd, Unwucht, Non bilanciato, Desequilibrio, Дисбаланс, Onbalans	After 10 failed attempts to spin the load the machine has stoped to spin beacuse of to high umbalance.	Information to customer: - Small loads with heavy items can cause this problem when these articles are difficult to redistribute.

Fault indications WM70.2

Error messages	Cause	Action
Over flow fault	Too much water in the machine	Service action: Check the machine's level system, inlet valve and drain pump. Make sure that there is no leaks.
	The drain pump is on, without any water in the machine.	Service action: The overflow protection at the bottom of the machine is activated (not all models). Make sure that there is no leaks (water on the machines base)
Water outlet fault	1. The drain pump has been activated more than 3 minutes. There is still water in the machine. 2. The wash cycle is interrupted and the program is cleared	Customer information: 1. Check that no objects are stuck in the drainage hose outlet. 2. Check that the drain pump is not blocked by foreign objects. 3. Check that there are no kinks in the drainage hose. Service action: 1. If the pump only runs for a short while (approximately 20 seconds), this indicates a fault in the level system. Check the level sensor and hoses. 2. Check wiring and voltage to the pump. If necessary, replace the pump and/or control 3. After implementing corrective action, run the Drain program or press the Key button (door open) to empty the machine.
Water inlet fault	If the correct water level is not reached within 5 minutes, the wash cycle is interrupted.	Customer information: 1. Check that the tap on the water pipe is open. Service action: 1. Check that the filter in the machine's water intake is not blocked. 2. Check the inlet valve. If necessary, replace the valve. 3. Check voltage to the inlet valve. If there is no voltage, this could be due to a fault in the level system, wiring or control unit.
Security fault	The door is open.	Close the door
Thermistor fault	1. The circuit for the thermistor is open. 2. The thermistor is faulty 3. The measurment value for the thermistor is $<300 \Omega$ ($>120^\circ\text{C}$)	Service action: Check the thermistors function. If needed, replace it.
Temperature fault	The temperature is raised $< 5^\circ\text{C}/41^\circ\text{F}$ within 10 minutes. The wash cycle continues to next step	Service action: Check the heater, cables, thermistor and level system.
Engine fault	No signal from Tacho or MCU.	Service action: Check the output from the MCU and the wiring between the motor and the MCU
Pressour sensor fault	Indicated if the level drops to 0 within 30 seconds of the first rinsing.	Service action: Check the leakage
Unbalance detection	After 10 failed attempts to spin the load the machine has stoped to spin beacuse of to high umbalance.	nformation to customer: - Small loads with heavy items can cause this problem when these articles are difficult to redistribute.

After carrying out corrective actions as above, reset the fault indications by pressing the DOOR OPERING BUTTON at the same time as the main power switch.

Fault indications WM70.I

Error messages on the display	Cause	Action
FI0 – Overflow	Too much water in the machine.	Service action: - Check the machine's level system, inlet valve and drainage pump. - Check for any leaks.
	The drainage pump is running but the machine is empty.	Service action: - The overflow cut-out at the bottom of the machine has been activated (some models only). - Check for leaks.
FI1 - Water outlet fault	The drainage pump has been running for 3 minutes. Water remains in the machine. The wash cycle has been interrupted and the programme reset.	Information to customer: - Check that no objects are stuck in the drainage hose outlet. - Check that the drainage pump is not blocked by foreign objects. - Check that there are no kinks in the drainage hose. Service action: - If the pump only runs for a short while (approximately 20 seconds), this indicates a fault in the level system. Check the level sensor and hoses. - Check wiring and voltage to the pump. If necessary, replace the pump and/or control unit. After implementing corrective action, run the Drain programme or press the Key (door opening) button to empty the machine.
FI2 – Water inlet fault	If the correct water level is not achieved within 5 minutes the wash cycle will be interrupted.	Information to customer: - Check that the tap on the water pipe is open. Service action: - Check that the filter in the machine's water intake is not blocked. - Check the inlet valve. If necessary, replace the valve. - Check voltage to the inlet valve. If there is no voltage, this could be due to a fault in the level system, wiring or control unit.
 - Unbalance detection	After 10 failed attempts to spin the load the machine has stopped to spin because of too high unbalance.	Information to customer: - Small loads with heavy items can cause this problem when these articles are difficult to redistribute.

Components and measurement values

Item number	Component	Measurement value	Comments
80 886 44	CIM-motor	See wiring diagram	
80 886 42	UM-Motor 50 Hz	See wiring diagram	
80 886 43	UM-Motor 60 Hz		
80 617 06	Heating element 2000 W	See wiring diagrama	
80 761 02	Thermistor	See wiring diagram	The thermistor for temperature reading is located between the motor cradle and the container. The thermistor measures and controls the water temperature that can vary from 0 to 90°C/ 194°F. The element is disconnected if the thermistor is short-circuited or disconnected from the program control card.
88 012 63.	Drain pump 50 Hz	See wiring diagram	The drain pump is combined with an integrated fine filter trap, which can be cleaned by the user. If the drain pump has run for 180 seconds during draining, the program stops, resets and a fault code is indicated in the display. The drain pumps capacity is 20 liters/min.
88 012 64.	Drain pump 60 Hz	See wiring diagram	
80 782 21	Level switch		Electro mechanical level switch with two levels, see wiring diagram. Indicates levels for door opening, heat and overfilling
80 897 65	Level switch, WM70.I		
80 762 02	EMC-Filter with inductor	See wiring diagram	The filter eliminates interference to and from the machine
80 793 24	Inlet valve	See wiring diagram	2 way inlet valve 8 litres / minute
80 798 73	Door lock	See wiring diagram	The door lock is electro mechanical and equipped with a magnet.
88 014 40	Control unit WM70.3		
88 014 41	Control unit WM70.3 FI		
80 896 72	Motor Control Unit, WM70.2		
80 896 73	Motor Control Unit WM70.I, WM70.3		
80 928 56	Fuse, Motor Control Unit 18A 250V 5X22		

Thermistor measurement values

Temp, ° C	Resistance, Ohm
0	15806
10	9634
20	6046
25	4841
30	3900
40	2579
50	1744
60	1204
70	848
80	609
85	519


Technical data WM70

Height:	850 mm
Width:	595 mm
Depth:	585 mm
Weight:	77 kg / 81 kg (with outer door)
Cylinder volume:	60 l
Max. washing capacity	EU 7,0/8,0kg, AU 7,0kg US 7,0/8,0kg Swan 6,0 kg
Spin speed:	WM70.3 400–1800 rpm, WM70.2 400–1800 rpm, WM70.1 400–1600 rpm
Connection:	1 phase 10 A
Element power:	2000W, 230V (See Type designation)
Water pressure/inlet valve:	0,1 – 1 MPa., 1 – 10 kp/cm ² , 10 – 100 N/cm ² . 8 litre/min
Wash drum and liquid compartment material:	Stainless steel
Outer casing material:	Powder coated and galvanized sheet steel or stainless steel
Set-up:	Stationary on four adjustable, rubber-covered feet
Water connection:	1,5 m pex pipe, 3/4" – 3/4" eller 3/4" – 1/2"
Drain:	1,7 m polypropylene tube
Protection class:	IP X4
Water consumption (tested normal program)	65 litre (3-rinse), <78 litre (5-rinse)
Energy consumption (tested normal program)	8kg: 1,2kWh, 6kg: 1,14kWh
Electricity consumption, Standby:	
- Main power switch off	<0,3 W
- Display on	<6,0 W
- Display off	<3,0 W

Tools

Torx; T25, T20, T10
Socket screwdriver 10 mm
5mm socket head cap screwdriver + small locking handle
Ring spanners; 11/16", 16mm, 13 mm, 10 mm
24mm extended socket + locking handle
Plastic hammer
Star socket head screwdriver
A pair of nippers

Wiring diagram WM70.3




This document must not be copied without our written permission, and the contents may not be used for any unauthorized purpose. All rights are reserved. Asko Appliances AB


CIRCUIT DIAGRAM WM70.3

80 886 17 - 00


Wiring diagram\WM70.2



Wiring diagram WM70.1 CIM



Wiring diagram WM70.I UM









Rehanging the door




Some machines in the WM60-series is supplied with a door - is that the case the door is hung on the left-hand side. It is, however, possible to re-hang it according to the instructions below. Take care not to damage the paint when carrying out work with tools.

Required tools	
Flathead screwdriver	
Torx size 20	
Fixed spanner size 8	













Instructions	Image
1. Remove the plinth by carefully pulling it out.	
2. Remove both screws for the lower hinge. Use Torx.	
3. Push the door upwards with care and angle outwards. If necessary, carefully press the lower hinge to detach the door.	
4. Slacken off the lower and upper hinge pins using a fixed spanner.	








5. Remove the plastic plugs covering the holes for the hinge pins and switch location	
Method for removing plastic plugs, lock and catch located on the machine and the door: Carefully push the plug, catch or lock upwards with a flat screwdriver, as the picture shows.	
6. Carefully remove the catch and plastic plug on the door (according to the method above) and switch location.	
7. Carefully remove the lock and plastic plug on the machine (according to the method above) and switch location.	
8. Screw the hinge pins securely into place on the corresponding side of the machine.	
9. Slacken off the screws for the lower hinge on the corresponding side of the machine. This must be done to hang the door.	

10. Align the door in the upper hinge. Carefully push the lower hinge down if necessary and align the door.	
11. Screw the lower hinge into place securely. Use Torx.	
12 Press the plinth into place. The door has now been re-hung.	





Replacing panels, control unit and detergent compartment

Instruction	Image
1. Attach the anti-static wristband to a part of the machine that is earthed! NOTE! An anti-static wristband must be used, otherwise you risk destroying the control card.	
2. Unscrew the top cover.	
3. Remove the top cover.	
4. Use a screwdriver to carefully free the panel. As you do so, carefully angle the panel outwards.	
5. Remove the panel and the cables. NOTE! Don't forget to remove the pressure sensor tube.	


Instruction	Image
6. Carefully pull the programme selector from the panel.	
7. Use a screwdriver to free the control card from the panel. NOTE! The control card must be placed in an ESD-safe bag.	
8. Check that the push button, lens and decorative inlay are in place. Now carefully press the new control card into place. NOTE! Don't forget to replace the rubber seal.	
9. Carefully disconnect the wiring from the control unit.	
10. When removing the detergent container, first slacken off the screw on the front member and then the two screws holding the detergent container in the side panel.	

Instruction	Image
10. Lift the detergent compartment. Then remove the hose clamps for all hoses, which are secured in the detergent container. Then detach the hoses from the detergent compartment.	
11. If necessary: Replace the decor panel for the detergent compartment. Detach the decor panel by pressing according to image 1. Install the decor panel by first placing the decor panel in the grooves on the detergent container and then snapping it into place as illustrated in image 2.	
12. Install the detergent compartment by first pressing all hoses into place and then securing them using the hose clamps.	
13. Screw the detergent compartment into place using the three screws (one in the front panel and two in the frame)	
14. Install all wiring in the relevant locations on the control card.	
15. Install the panel. Angle the panel outwards and place the mounting plates in the relevant grooves in the front frame. Angle the panel downwards and secure it with the catches	
16. Screw the top cover into place.	

Replacing front panel, door, cover plate and the hinges

Instruction	Image
1. Unscrew the screws in the hooks holding the front panel. Then carefully pull off the drainage hose that is secured in the door for the drain pump. Note! Water is pouring out when the drainage hose is pulled off.	
2. Unscrew the screws holding the front panel. Then remove the front panel by carefully pulling it out at the lower edge.	
3. Unscrew the two screws holding the glass door. Use Torx.	
4. Unscrew the three screws that hold the covering plate to the container. Use a Torx driver. Fully open the hinge and remove the cover plate.	
5. Unscrew the three screws that hold the cover plate to the container. Use Torx.	


Emergency opener for door lock

Instruction	Image
1. The emergency opener is in the documentation kit.	
2. Push the emergency opener into the slot beside the glass door.	 A diagram showing a close-up of the door frame with a small slot. An arrow points from a separate image of the emergency opener (a long, thin metal rod with a circular end) into the slot.
3. Push the emergency opener upwards. and the door will open	 A photograph showing a hand pushing the emergency opener upwards into the slot on the door frame.


Wash agitator removal

When replacing or cleaning the wash agitators, or when removing items that have fallen through the wash drum, first you need to remove the agitators. Follow the instructions below.

1. Insert a screwdriver or the like into the hole on the agitator as illustrated and carefully pry to the left.



2. Use your other hand to grasp the agitator and pull it towards you.
3. Lift the agitator.
4. Remove any foreign objects.



5. Place the agitator in the mounting hole with the letter F towards you. Ensure that all the agitator fasteners are in their holes in the drum. Push it away from you until it fastens.

